

Sun ILOM 3.0 Supplement for the Sun Fire X4640 Server

Copyright © 2009, 2010, Oracle and/or its affiliates. All rights reserved.

This software and related documentation are provided under a license agreement containing restrictions on use and disclosure and are protected by intellectual property laws. Except as expressly permitted in your license agreement or allowed by law, you may not use, copy, reproduce, translate, broadcast, modify, license, transmit, distribute, exhibit, perform, publish, or display any part, in any form, or by any means. Reverse engineering, disassembly, or decompilation of this software, unless required by law for interoperability, is prohibited.

The information contained herein is subject to change without notice and is not warranted to be error-free. If you find any errors, please report them to us in writing.

If this is software or related software documentation that is delivered to the U.S. Government or anyone licensing it on behalf of the U.S. Government, the following notice is applicable:

U.S. GOVERNMENT RIGHTS Programs, software, databases, and related documentation and technical data delivered to U.S. Government customers are "commercial computer software" or "commercial technical data" pursuant to the applicable Federal Acquisition Regulation and agency-specific supplemental regulations. As such, the use, duplication, disclosure, modification, and adaptation shall be subject to the restrictions and license terms set forth in the applicable Government contract, and, to the extent applicable by the terms of the Government contract, the additional rights set forth in FAR 52.227-19, Commercial Computer Software License (December 2007). Oracle America, Inc., 500 Oracle Parkway, Redwood City, CA 94065.

This software or hardware is developed for general use in a variety of information management applications. It is not developed or intended for use in any inherently dangerous applications, including applications which may create a risk of personal injury. If you use this software or hardware in dangerous applications, then you shall be responsible to take all appropriate fail-safe, backup, redundancy, and other measures to ensure its safe use. Oracle Corporation and its affiliates disclaim any liability for any damages caused by use of this software or hardware in dangerous applications.

Oracle and Java are registered trademarks of Oracle and/or its affiliates. Other names may be trademarks of their respective owners.

AMD, Opteron, the AMD logo, and the AMD Opteron logo are trademarks or registered trademarks of Advanced Micro Devices. Intel and Intel Xeon are trademarks or registered trademarks of Intel Corporation. All SPARC trademarks are used under license and are trademarks or registered trademarks of SPARC International, Inc. UNIX is a registered trademark licensed through X/Open Company, Ltd.

This software or hardware and documentation may provide access to or information on content, products, and services from third parties. Oracle Corporation and its affiliates are not responsible for and expressly disclaim all warranties of any kind with respect to third-party content, products, and services. Oracle Corporation and its affiliates will not be responsible for any loss, costs, or damages incurred due to your access to or use of third-party content, products, or services.

Ce logiciel et la documentation qui l'accompagne sont protégés par les lois sur la propriété intellectuelle. Ils sont concédés sous licence et soumis à des restrictions d'utilisation et de divulgation. Sauf disposition de votre contrat de licence ou de la loi, vous ne pouvez pas copier, reproduire, traduire, diffuser, modifier, breveter, transmettre, distribuer, exposer, exécuter, publier ou afficher le logiciel, même partiellement, sous quelque forme et par quelque procédé que ce soit. Par ailleurs, il est interdit de procéder à toute ingénierie inverse du logiciel, de le désassembler ou de le décompiler, excepté à des fins d'interopérabilité avec des logiciels tiers ou tel que prescrit par la loi.

Les informations fournies dans ce document sont susceptibles de modification sans préavis. Par ailleurs, Oracle Corporation ne garantit pas qu'elles soient exemptes d'erreurs et vous invite, le cas échéant, à lui en faire part par écrit.

Si ce logiciel, ou la documentation qui l'accompagne, est concédé sous licence au Gouvernement des Etats-Unis, ou à toute entité qui délivre la licence de ce logiciel ou l'utilise pour le compte du Gouvernement des Etats-Unis, la notice suivante s'applique :

U.S. GOVERNMENT RIGHTS. Programs, software, databases, and related documentation and technical data delivered to U.S. Government customers are "commercial computer software" or "commercial technical data" pursuant to the applicable Federal Acquisition Regulation and agency-specific supplemental regulations. As such, the use, duplication, disclosure, modification, and adaptation shall be subject to the restrictions and license terms set forth in the applicable Government contract, and, to the extent applicable by the terms of the Government contract, the additional rights set forth in FAR 52.227-19, Commercial Computer Software License (December 2007). Oracle America, Inc., 500 Oracle Parkway, Redwood City, CA 94065.

Ce logiciel ou matériel a été développé pour un usage général dans le cadre d'applications de gestion des informations. Ce logiciel ou matériel n'est destiné à être utilisé dans des applications à risque, notamment dans des applications pouvant causer des dommages corporels. Si vous utilisez ce logiciel ou matériel dans le cadre d'applications dangereuses, il est de votre responsabilité de prendre toutes les mesures de secours, de sauvegarde, de redondance et autres mesures nécessaires à son utilisation dans des conditions optimales de sécurité. Oracle Corporation et ses affiliés déclinent toute responsabilité quant aux dommages causés par l'utilisation de ce logiciel ou matériel pour ce type d'applications.

Oracle et Java sont des marques déposées d'Oracle Corporation et/ou de ses affiliés. Tout autre nom mentionné peut correspondre à des marques appartenant à d'autres propriétaires qu'Oracle.

AMD, Opteron, le logo AMD et le logo AMD Opteron sont des marques ou des marques déposées d'Advanced Micro Devices. Intel et Intel Xeon sont des marques ou des marques déposées d'Intel Corporation. Toutes les marques SPARC sont utilisées sous licence et sont des marques ou des marques déposées de SPARC International, Inc. UNIX est une marque déposée concédée sous licence par X/Open Company, Ltd.

Contents

- Preface5
 - Product Information Web Site5
 - Related Books5
 - About This Documentation (PDF and HTML)7
 - We Welcome Your Comments8
 - Change History8
- Overview of the ILOM Supplement9
- Introduction to ILOM Software 11
 - ILOM Software Overview 11
 - What Does ILOM Do? 11
- Communicating With the ILOM and the System Console 13
 - Server Connections 13
 - About ILOM SP IP Addresses and the ILOM Interfaces 15
 - Determining the SP IP Address 15
 - Connecting to the ILOM 17
 - Connecting to the System Console 20
- Updating Firmware 27
 - Firmware Versions Worksheet 27
 - Determining Current Firmware Versions 28
 - Preparing for the Firmware Update 32
 - Updating the ILOM and System BIOS 33
 - Updating the Embedded HBA BIOS 38
- Using ILOM to Monitor the Host 41
- Index45**

Preface

This preface describes related documentation, submitting feedback, and a document change history.

- “Product Information Web Site” on page 5
- “Related Books” on page 5
- “About This Documentation (PDF and HTML)” on page 7
- “We Welcome Your Comments” on page 8
- “Change History” on page 8

Product Information Web Site

For information about the Sun Fire X4640 server, go to the following web site:

<http://www.oracle.com/goto/x86>

Click “Previous Products” from the left nav menu.

At that site, you can find links to the documentation, parts lists and downloads.

Related Books

The following is a list of documents related to your Oracle Sun Fire X4640 server. These and additional support documents are available on the web at:

<http://docs.sun.com/app/docs/prod/server.x64#hic>

Document Group	Document	Description
Sun Fire X4640 Server-Specific Documentation	Sun Fire X4640 Server Product Documentation	Integrated HTML version of all starred (*) documents, including Search and Index.
	<i>Sun Fire X4640 Server Getting Started Guide</i>	Pictorial setup quick reference.

Document Group	Document	Description
	“Installation Overview” in <i>Sun Fire X4640 Server Installation Guide</i>*	How to install, rack, and configure the server up to initial power-on.
	“Overview of the Sun Fire X4640 Server Product Notes” in <i>Sun Fire X4640 Server Product Notes</i>*	Important late-breaking information about the Sun Fire X4640 server.
	“Introduction to Sun Installation Assistant” in <i>Sun Installation Assistant 2.3 through 2.4 User’s Guide for x64 Servers</i>*	A Sun tool used to perform an assisted installation of a supported Windows or Linux OS, upgrade firmware (regardless of OS), and other tasks.
	Introduction to Solaris OS and OpenSolaris Installation*	How to install the Solaris OS on your server.
	“Introduction to Linux Installation” in <i>Sun Fire X4640 Server Linux Installation Guide</i>*	How to install a supported Linux OS on your server.
	“Introduction to Windows Installation” in <i>Sun Fire X4640 Server Windows Installation Guide</i>*	How to install supported versions of Microsoft Windows on your server.
	“Introduction to ESX Installation” in <i>Sun Fire X4640 Server ESX Installation Guide</i>*	How to install supported versions of the ESX OS on your server.
	Sun ILOM 3.0 Supplement for the Sun Fire X4640 Server*	Version-specific supplemental information for your server’s <i>Integrated Lights Out Manager</i> .
	Sun Fire X4640 Server Diagnostics Guide*	How to diagnose problems with your server.
	“Sun Fire X4640 Server Service Manual Overview” in <i>Sun Fire X4640 Server Service Manual</i>*	How to service and maintain your server.
	Sun Fire X4640 Server Safety and Compliance Guide	Safety and compliance information about your server.
	4U Express Rail Rackmounting Kit Label	Pictorial label on racking your server
	Sun Fire X4640 System Overview Label	Pictorial label on servicing your server
	Sun Fire X4640 Top Cover Label	Pictorial label on removing components

Document Group	Document	Description
Sun Integrated Controller Disk Management	<i>Sun Fire X4640 CPU Matrix Label</i>	Pictorial label on CPU module and fillers
	<i>Sun x64 Server Disk Management Overview</i>	Information about managing your server's storage.
	<i>Sun LSI 106x RAID Users Guide</i>	Information about LSI RAID features
x64 Servers Applications and Utilities Reference Documentation	<i>Sun x64 Server Utilities Reference Manual</i>	How to use the available utilities included with your server.
Oracle Integrated Lights Out Manager (ILOM) 3.0 Documentation	<i>Oracle Integrated Lights Out Manager (ILOM) 3.0 Feature Updates and Release Notes</i>	Information about new ILOM features
	<i>Oracle Integrated Lights Out Manager (ILOM) 3.0 Getting Started Guide</i>	Overview of ILOM 3.0
	<i>Oracle Integrated Lights Out Manager (ILOM) 3.0 Concepts Guide</i>	Conceptual information on ILOM 3.0
	<i>Oracle Integrated Lights Out Manager (ILOM) 3.0 Web Interface Procedures Guide</i>	How to use ILOM through the web interface
	<i>Oracle Integrated Lights Out Manager (ILOM) 3.0 CLI Procedures Guide</i>	How to use ILOM through commands
	<i>Oracle Integrated Lights Out Manager (ILOM) 3.0 Management Protocols Reference Guide</i>	Information on management protocols

About This Documentation (PDF and HTML)

This documentation set is available in both PDF and HTML. The information is presented in topic-based format (similar to online help) and therefore does not include chapters, appendices or section numbering.

We Welcome Your Comments

Oracle is interested in improving its documentation and welcomes your comments and suggestions. To share your comments, go to <http://docs.sun.com> and click Feedback.

Change History

The following changes have been made to the documentation set.

- October 2009, initial publication
- January 2010, two documents revised
 - Service Manual - Revised DIMM population rules and addressed illustration issues
 - Product Notes - Revised software information and fixed bugs
- April 2010, one document revised
 - Installation Guide - Revised power specifications
- December 2010, two documents revised
 - Service Manual - Revised motherboard FRUID update instructions
 - Product Notes - Revised software information and fixed bugs

Overview of the ILOM Supplement

Note – Before performing the procedures contained in this topic set, set up your hardware as shown in the [Sun Fire X4640 Server Installation Guide](#).

This document describes server-specific features of the Oracle Integrated Lights Out Manager (ILOM) for the Sun Fire X4640 server. The following topics are covered:

Description	Link
Learn about managing the server with the Integrated Lights Out Manager (ILOM).	“ILOM Software Overview” on page 11
Connect to the ILOM or system console.	“Communicating With the ILOM and the System Console” on page 13
Update ILOM, BIOS, and HBA firmware.	“Updating Firmware” on page 27
View ILOM sensor information.	“Using ILOM to Monitor the Host” on page 41

Introduction to ILOM Software

This section contains information on the following topics:

- [“ILOM Software Overview” on page 11](#)
- [“What Does ILOM Do?” on page 11](#)

ILOM Software Overview

Sun's Integrated Lights Out Manager (ILOM) provides advanced service processor hardware and software that you can use to manage and monitor your Sun servers. ILOM's dedicated hardware and software is preinstalled on a variety of Sun server platforms, including x64-based Sun Fire servers, Sun Blade modular chassis systems, Sun Blade server modules, as well as on SPARC-based servers. ILOM is a vital management tool in the data center and can be used to integrate with other data center management tools that are already installed on your systems.

Sun is currently transitioning many systems to support ILOM so that customers will have a single, consistent, and standards-based service processor (SP) across Sun's product lines.

For customers, this means you will have:

- Single, consistent system management interfaces for operators
- Rich protocol and standards support
- Broadening third-party management support
- System management functions integrated into Sun servers at no extra cost

What Does ILOM Do?

ILOM enables you to actively manage and monitor the server independently of the operating system state, providing you with a reliable Lights Out Management (LOM) system. With ILOM, you can proactively:

- Learn about hardware errors and faults as they occur
- Remotely control the power state of your server
- View the graphical and non-graphical consoles for the host
- View the current status of sensors and indicators on the system

- Determine the hardware configuration of your system
- Receive generated alerts about system events in advance using IPMI PETs, SNMP Traps, or Email Alerts

The ILOM service processor (SP) runs its own embedded operating system and has a dedicated Ethernet port, which together provide out-of-band management capability. In addition, you can access ILOM from the server's host operating system that Sun supports (Solaris, Linux, and Windows). Using ILOM, you can remotely manage your server as if you were using a locally attached keyboard, monitor, and mouse.

ILOM automatically initializes as soon as power is applied to your server. It provides a full-featured, browser-based web interface and has an equivalent command-line interface (CLI). There is also an industry-standard SNMP interface and IPMI interface.

Communicating With the ILOM and the System Console

These topics provide instructions for connecting to the system service processor (SP) Integrated Lights Out Manager (ILOM) and the system console:

- [“Server Connections” on page 13](#)
- [“About ILOM SP IP Addresses and the ILOM Interfaces” on page 15](#)
- [“Determining the SP IP Address” on page 15](#)
- [“Connecting to the ILOM” on page 17](#)
- [“Connecting to the System Console” on page 20](#)

Server Connections

The following illustration shows the cabling locations on the rear panel of the server.




TABLE 1 Figure Legend

1	Connect power cable to power source.
2	Connect a serial cable between the SER MGT port and a terminal device or a PC. Note – You might need an adapter. The server comes with a DB9-to-RJ45 serial port adapter.
3	(Optional) Connect an Ethernet cable between the NET MGT port and the network to which future connections to the SP and the host will be made.
4	Connect an Ethernet cable between one of the NET ports and the network.

About ILOM SP IP Addresses and the ILOM Interfaces

The ILOM SP is assigned a DHCP IP address by default.

There are two requirements for DHCP IP address assignment to occur:

- Connection to your network must be through a NET MGT port.
- DHCP services must be present on your network infrastructure.

If a DHCP server cannot be reached after three DHCP requests, the ILOM SP is assigned a *static* IP address based on the network management port MAC address. This IP address is always in the format 192.168.xxx.xxx, where xxx.xxx is the remainder of the IP address.

You can choose from one of several ILOM SP interfaces to support system management on your server.

You can access SP firmware applications through the following ILOM SP interfaces:

- Serial port command-line interface (CLI) (local access)
- Secure shell (SSH) CLI (remote access over the network)
- Web browser user interface (remote access over the network)

Determining the SP IP Address

You need to determine the service processor (SP) IP (network) address to use the SP Integrated Lights Out Manager (ILOM) to manage the server.

You can determine the IP address through either one of these ways:

- [“How to Get the SP IP Address Using the BIOS Setup Utility” on page 15](#)
- [“How to Get the SP IP Address By Using a Serial Connection and the CLI” on page 16](#)

▼ How to Get the SP IP Address Using the BIOS Setup Utility

- Before You Begin**
- Complete the hardware setup as described in the hardware setup documentation.
 - Apply standby power for your server by plugging an AC cord into the system power supply. See [“Server Connections” on page 13](#) for the location of the power cord connectors.

- 1 Reboot the server.**
- 2 Press the F2 key when prompted, to access the BIOS Setup Utility.**
- 3 In the BIOS Setup Utility, choose Advanced → IPMI 2.0 Configuration → Set LAN Configuration → IP address.**

The IP address for the SP is displayed.

▼ How to Get the SP IP Address By Using a Serial Connection and the CLI

Before You Begin

- Complete the hardware setup as described in the hardware setup documentation.
- Apply standby power for your server by plugging an AC cord into the system power supply. See “[Server Connections](#)” on page 13 for the location of the power cord connectors.

- 1 **Verify that your terminal, laptop, or terminal server is operational.**
- 2 **Configure the terminal device or the terminal emulation software running on a laptop or PC to the following settings:**

- 8N1: eight data bits, no parity, one stop bit
- 9600 baud
- Disable hardware flow control (CTS/RTS)
- Disable software flow control (XON/XOFF)

- 3 **Connect a serial cable from the RJ-45 SERIAL MGT port on the server’s back panel to a terminal device.**

See “[Server Connections](#)” on page 13 for the location of the RJ-45 SERIAL MGT port.

- 4 **Press Enter on the terminal device to establish a connection between that terminal device and the ILOM SP.**

The SP eventually displays a login prompt, such as the following example:

SUNSP 0111AP0-0814YT06B4 login:

In this example login prompt:

- The string SUNSP is the same for all SPs.
- *0111AP0-0814YT06B4* is the product serial number by default. This value can also be the host name, which is assigned by the user or the DHCP server.

- 5 **Log in to the ILOM.**

a. **Type the default user name: root.**

b. **Type the default password: changeme.**

Once you have successfully logged in, the SP displays its default command prompt:

->

You can now run CLI commands to configure ILOM for the server’s user accounts, network settings, access lists, alerts, and so on. For detailed instructions on CLI commands, see the *Sun Integrated Lights-Out Manager 3.0 CLI Procedures Guide*.

6 To display the SP IP address, type:

```
cd /SP/network
```

Note – You can switch back to the SP CLI from the serial console by entering the **Esc** (key sequence.

Connecting to the ILOM

This section describes three different procedures for connecting to the ILOM:

- [“How to Connect to the Command-Line Interface Using SSH” on page 17](#)
- [“How to Connect to the ILOM Command-Line Interface Through the Serial Management Port” on page 17](#)
- [“How to Connect to the ILOM Web Interface” on page 19](#)

▼ How to Connect to the Command-Line Interface Using SSH

Before You Begin

- Perform the hardware setup as described in the hardware setup documentation.
- Apply standby power to the server by connecting AC power to the system power supply. See [“Server Connections” on page 13](#) for the location of the power connectors.

1 Connect the server to the Internet with an Ethernet cable connected to the server's RJ-45 NET MGT Ethernet port.

See [“Server Connections” on page 13](#) for the location of the RJ-45 NET MGT port.

2 Using a client system, access a command line and establish a Secure Shell (SSH) connection to the service processor's IP address with the following command:

```
ssh -l root sp_ip_address
```

For example, to connect to the SP with the DHCP-assigned IP address of 129.144.82.20, type the following command:

```
ssh -l root 129.144.82.20
```

3 Log in to the ILOM.

The default user name is root and the default password is changeme.

▼ How to Connect to the ILOM Command-Line Interface Through the Serial Management Port

Use this procedure to establish a serial connection to the ILOM SP so that you can perform initial configuration of ILOM.

Before You Begin

- Perform the hardware setup as described in the hardware setup documentation.

- Apply standby power to the server by connecting AC power to the system power supply. See [“Server Connections” on page 13](#) for the location of the power connectors.
- Verify that your terminal, laptop, or terminal server is operational.

1 Configure the terminal device or the terminal emulation software running on a laptop or PC to the following settings:

- 8N1: eight data bits, no parity, one stop bit
- 9600 baud
- Disable hardware flow control (CTS/RTS)
- Disable software flow control (XON/XOFF)

2 Connect a serial cable from the RJ-45 SERIAL MGT port on the server’s back panel to a terminal device.

See [“Server Connections” on page 13](#) for the location of the RJ-45 SERIAL MGT port.

3 Press Enter on the terminal device to establish a connection between that terminal device and the ILOM SP.

The SP eventually displays a login prompt, such as the following example:

```
SUNSP0111AP0-0814YT06B4 login:
```

In this example login prompt:

- The string SUNSP is the same for all SPs.
- 0111AP0-0814YT06B4 is the product serial number by default. This value can also be the host name, which is assigned by the user or the DHCP server.

4 Log in to the ILOM.

a. Type the default user name: root.

b. Type the default password: changeme.

Once you have successfully logged in, the SP displays its default command prompt:

```
->
```

You can now run CLI commands to configure ILOM for the server’s user accounts, network settings, access lists, alerts, and so on. For detailed instructions on CLI commands, see the *Sun Integrated Lights-Out Manager 3.0 CLI Procedures Guide*.

5 To start the serial console, type:

```
cd /SP/console
```

```
->start
```


Note – You can switch back to the SP CLI from the serial console by entering the **Esc** (key sequence.

▼ How to Connect to the ILOM Web Interface


- Before You Begin**
- Perform the hardware setup as described in the hardware setup documentation.
 - Apply standby power to the server by connecting AC power to the system power supply. See [“Server Connections” on page 13](#) for the location of the power connectors.

1 Type the IP address of the ILOM SP in the browser locator box and press Enter.

For example, if the IP address for your ILOM SP is 129.144.02.20, you would enter it as shown here:



2 Log in to the web interface using the default user name, root, and the default password, changeme.



Connecting to the System Console

There are three different ways to connect to the system console.

- Physical console. See [“How to Connect to the Server Locally \(Physical Console\)”](#) on page 20
- Remote console through the ILOM web interface. See [“How to Connect Remotely Using the ILOM Web Interface”](#) on page 20
- Serial console through the ILOM command-line interface. See [“How to Connect to the Serial Console Using the ILOM Command-Line Interface”](#) on page 24

▼ How to Connect to the Server Locally (Physical Console)

If you plan to interact with the system console directly, make the connections described in this procedure. See [“Server Connections”](#) on page 13 for the locations of the system connectors.

Before You Begin Perform the hardware setup as described in the hardware setup documentation.

- 1 **Connect a mouse and a keyboard to the server USB connectors.**
- 2 **Connect a monitor to the server video connector.**


See Also For the locations of the USB connectors and the server video connector, see [Sun Fire X4640 Server Front and Back Panel Features and Components](#).

▼ How to Connect Remotely Using the ILOM Web Interface

Before You Begin The requirements for the JavaRConsole (remote console) system are:

- Solaris, Linux, or Windows operating system is installed.
- The system must be connected to a network that has access to the server's Ethernet management port.
- Java Runtime Environment (JRE) 1.5 or later is installed.
- If the remote console system is running Solaris OS, volume management must be disabled for the remote console to access the physical floppy and CD/DVD-ROM drives.
- If the remote console system is running Windows, Internet Explorer Enhanced Security must be disabled.
- The remote console system and ILOM service processor must be set up according to the instructions in the *Sun Integrated Lights Out Manager (ILOM) Web Interface Procedures Guide*.

- 1 Start the remote console application by typing the IP address of the ILOM service processor into a browser on the remote console system.




The Security Alert dialog box is displayed.



- 2 Click Yes.


The ILOM login screen appears.



- 3 Enter the user name and password and click Log In.

The default user name is **root** and default password is **changeme**.


The ILOM Version Information screen appears.



4 Click the Remote Control tab in the ILOM Web interface.

The Launch Redirection screen appears.

Note – Make sure that the mouse mode is set to Absolute mode in the Mouse Mode Settings tab.




5 Click 8-bit color or 16-bit color, and then click Launch Redirection.

Note – When using a Windows system for remote console redirection, an additional warning appears after clicking Launch Redirection. If the Hostname Mismatch dialog box is displayed, click the Yes button.



The Remote Control dialog box appears.




- 6 In the Remote Control Login dialog box, enter your user name and password and click OK.

Note – You must have administrator privileges.

The default user name is **root** and default password is **changeme**.

The JavaRConsole screen appears.

- 7 From the **Devices** menu, select the appropriate item based on the delivery method you have chosen.



- **Remote Physical Floppy Disk:** Select **Floppy** to redirect the server to the physical floppy drive attached to the remote console.
- **Remote Floppy Image:** Select **Floppy Image** to redirect the server to the floppy image file located on the remote console.
- **Remote Physical CD/DVD:** Select **CD-ROM** to redirect the server to the CD/DVD in the CD/DVD drive attached to the remote console.
- **Remote CD/DVD Image:** Select **CD-ROM Image** to redirect the server to the .iso image file located on the remote console.

Note – Using the CD-ROM Remote or CD-ROM Image options to install software on your server significantly increases the time necessary to perform the installation because the content is accessed over the network. The installation duration depends on the network connectivity and traffic.

▼ How to Connect to the Serial Console Using the ILOM Command-Line Interface

Before You Begin

- Connect the server to your network through an Ethernet cable. See [“Server Connections” on page 13](#).
- If you have not already done so, determine the service processor’s IP address. See [“Determining the SP IP Address” on page 15](#).

- 1 Using a client system, establish a Secure Shell (SSH) connection to the service processor's IP address:

```
ssh -l root sp_ip_address
```

- 2 Log in to the service processor as an administrator.

The default user name is **root** and default password is **changeme**.

Note – Only accounts with Administrator privileges are enabled to configure the SP serial port. See “Configuring Network Settings” in the *Sun Integrated Lights Out Manager (ILOM) 3.0 CLI Procedures Guide*.

- 3 Start the ILOM console mode by typing the following:

```
start /SP/console
```

- 4 If you have changed the SP Serial Port default settings, make sure you reset them to the default settings.

Updating Firmware

Updates to the firmware for ILOM, system BIOS, and LSI HBA are periodically available on the server download site to provide additional features and bug fixes for the server. The firmware components must all be updated together for a given software update. The [“Firmware Versions Worksheet” on page 27](#) can be used to keep track of the firmware versions needed for the upgrade process.

The firmware update process includes the procedures covered in the following topics. The procedures are listed in the recommended completion order.

Step	Description	Link
1	Verify the firmware versions that are currently running on the server.	“Determining Current Firmware Versions” on page 28
2	Determine the target firmware versions and download the firmware.	“Preparing for the Firmware Update” on page 32
3	Update the ILOM and system BIOS.	“Updating the ILOM and System BIOS” on page 33
4	Update the Embedded HBA BIOS.	“Updating the Embedded HBA BIOS” on page 38

Firmware Versions Worksheet

The following table is provided to help keep track of firmware versions that you will identify in the procedures described in this section.

Firmware Type	Current Version	Intermediate Version	Target Version
ILOM			
BIOS			
LSI HBA		n/a	

Determining Current Firmware Versions

The first three methods this section describe ways to determine current the ILOM and BIOS firmware versions. The fourth method describes how to determine the LSI HBA firmware version.

This section contains the following procedures:


- “How to Verify the ILOM and BIOS Firmware Versions Using the Web Interface” on page 28
- “How to Verify the ILOM and BIOS Firmware Versions Using the Command-Line Interface Through the Serial Port” on page 30
- “How to Verify the ILOM and BIOS Firmware Versions Using the Command—Line Interface Through the Management Ethernet Port” on page 31
- “How to Verify the LSI HBA Firmware Version” on page 32

▼ How to Verify the ILOM and BIOS Firmware Versions Using the Web Interface

- 1 **Connect to the ILOM Web interface by typing the IP address of the server's SP into your browser's address field. For example:**

`https://129.146.53.150`

The ILOM login screen appears.



- 2 Log in to the ILOM SP and type the default user name (root) with the default password (changeme).


The first web page presented is the System Information —> Versions page, which includes the ILOM version and Build Number.



- 3 Click on System Information —> Components.
- 4 Click on /SYS/MB/BIOS in the Component Name field.

The view component name and information dialog box is displayed.

The fru_version field shows the BIOS version number.



- 5 Note the ILOM and BIOS versions on the “Firmware Versions Worksheet” on page 27.

▼ How to Verify the ILOM and BIOS Firmware Versions Using the Command-Line Interface Through the Serial Port

- 1 **Configure your terminal device or the terminal emulation software running on a laptop or PC to the following settings:**

- 8N1: eight data bits, no parity, one stop bit
- 9600 baud
- Disable hardware flow control (CTS/RTS)
- Disable software flow control (XON/XOFF)

- 2 **Connect a serial cable from the RJ-45 SER MGT port on your server's back panel to your terminal device or PC.**

- 3 **Press Enter on the terminal device to establish a connection between that terminal device and the server's SP.**

The SP displays the login prompt:

SUN0111AP0-0814YT06B4 login:

In this example, the login prompt, 0111AP0-0814YT06B4 is the product serial number by default. This value can also be the host name, which is assigned by the user or the DHCP server.

- 4 **Log in to the ILOM SP and type the default user name (root) with the default password (changeme).**

After you have successfully logged in, the SP displays its default command prompt:

->

- 5 **To view the ILOM version information, type:**

version

This command returns output similar to the following:

```
SP firmware 2.0.2.16
SP firmware build number: 42063
SP firmware date: Mon Feb 9 22:45:34 PST 2009
SP filesystem version: 0.1.16
```

- 6 **To view the BIOS version, type:**

show /SYS/MB/BIOS

The command returns output similar to the following:

```
/SYS/MB/BIOS
Targets:

Properties:
type = BIOS
```

```
ipmi_name = MB/BIOS
fru_name = SYSTEM BIOS
fru_manufacturer = AMERICAN MEGATRENDS
fru_version = IABSF005
fru_part_number = AMIBIOS8
```

```
Commands:
cd
show
```

The fru_version field contains the BIOS version number.

- 7 Note the ILOM and BIOS versions on the [“Firmware Versions Worksheet” on page 27](#).

▼ How to Verify the ILOM and BIOS Firmware Versions Using the Command—Line Interface Through the Management Ethernet Port

- 1 Connect an RJ-45 Ethernet cable to the NET MGT Ethernet port on the back panel.
- 2 Establish an SSH connection using the following command, and then enter the default password (changeme) when you are prompted:

```
# ssh -l root sp_ip_address
```

changeme

After you have successfully logged in, the SP displays its default command prompt:

->

- 3 To view the ILOM version information, type:

```
version
```

This command returns input similar to the following:

```
SP firmware 2.0.2.16
SP firmware build number: 42063
SP firmware date: Mon Feb 9 22:45:34 PST 2009
SP filesystem version: 0.1.16
```

- 4 To view the BIOS version, type:

```
show /SYS/MB/BIOS
```

The command returns input similar to the following:

```
/SYS/MB/BIOS
Targets:

Properties:
  type = BIOS
  fru_name = SYSTEM BIOS
  fru_description = SYSTEM BIOS
  fru_manufacturer = AMERICAN MEGATRENDS
```

```
fru_version = 0ABMN052
fru_part_number = AMIBIOS8
```

```
Commands:
cd
show
```

The fru_version field contains the BIOS version number.

- 5 Note the ILOM and BIOS versions on the [“Firmware Versions Worksheet” on page 27](#).

▼ How to Verify the LSI HBA Firmware Version

- 1 Reboot the server.
- 2 Note the LSI firmware version that is displayed during system boot.
- 3 Record the current LSI firmware version in the [“Firmware Versions Worksheet” on page 27](#).

Preparing for the Firmware Update

This section contains the following topics:

- [“How to Plan the Firmware Update” on page 32](#)
- [“How to Download Firmware Updates” on page 33](#)

▼ How to Plan the Firmware Update

Firmware for the ILOM, BIOS, and LSI HBA must be updated together. Use the [“Firmware Versions Worksheet” on page 27](#) to record intermediate and target firmware version identified in this procedure.

- 1 View the Product Notes for information on all firmware versions available for the server, and select the software download version that contains the versions of the firmware that you want to download.

Note – For some ILOM and BIOS updates, you need to update to an intermediate firmware version before you update to the final target ILOM version. Any needed intermediate firmware versions will be specified in the Product Notes.

- 2 Record the intermediate and target firmware versions in the [“Firmware Versions Worksheet” on page 27](#).

- 3 Navigate to the A-to-Z listing downloads page from the Servers and Storage Systems section of the Software download page:

<http://www.oracle.com/technology/software/index.html>

▼ How to Download Firmware Updates

- 1 Determine which software update corresponds to the firmware that you want to download. See [“Preparing for the Firmware Update” on page 32](#).
- 2 Click on Download in the row for the correct firmware update.
- 3 Choose Firmware from the Platform drop-down list.
- 4 Click the box to agree to the software license agreement.
- 5 Enter your Sun download center user name and password.
If you do not have a user name and password, you can register free of charge by clicking Register Now.
- 6 Click the appropriate image file name: **ILOM-firmware_version.ima**.
For example: ILOM-3_0_3_31-r42822.ima-Sun_Fire_X4640.ima
- 7 Select the files you want, and then click the "Download Selected with Sun Download Manager" (SDM) button to automatically install and use SDM.

Additional instructions for using SDM are available on the download site.

Use of SDM is recommended but not required. Alternately, you can click directly on file names to download with your browser.

Updating the ILOM and System BIOS

The following procedures describe two different methods for updating the ILOM and system BIOS.

- [“How to Update the ILOM and System BIOS Using the Web Interface” on page 33](#)
- [“How to Update the ILOM and System BIOS Using the Command-Line Interface” on page 36](#)

▼ How to Update the ILOM and System BIOS Using the Web Interface

- Before You Begin**
- Identify the version of ILOM that is currently running on your system. See [“Determining Current Firmware Versions” on page 28](#).

- Download the firmware image for your server or CMM from the Sun platform's product web site. See [“How to Download Firmware Updates” on page 33](#).
- Copy the firmware image to the system on which the web browser is running, using a supported protocol (TFTP, FTP, HTTP, HTTPS).
- Obtain an ILOM user name and password that has Admin (a) role account privileges. You must have Admin (a) privileges to update the firmware on the system.


Note – The firmware update process takes about six minutes to complete. During this time, do not perform other ILOM tasks. When the firmware update is complete, the system will reboot.

1 Log in to the ILOM web interface.

See [“How to Connect to the ILOM Web Interface” on page 19](#).

2 Select Maintenance → Firmware Upgrade.

The Firmware Upgrade page appears.



3 In the Firmware Upgrade page, click Enter Upgrade Mode.

An Upgrade Verification dialog appears, indicating that other users who are logged in will lose their session when the update process is completed.

4 In the Upgrade verification dialog box, click OK to continue.

You are prompted to select an image file to upload.

5 Perform the following actions:

a. Specify the image location by performing one of the following:

- Click Browse to select the location of the firmware image you want to install.
- If supported on your system, click Specify URL. Then type into the text box the URL for the firmware image.

b. Click the Upload button to upload and validate the file.

Wait for the file to upload and validate.

The Firmware Verification page appears.

6 In the Firmware Verification page, enable any of the following options:

- **Preserve Configuration.** Enable this option if you want to save your existing configuration in ILOM and restore that existing configuration after the update process is completed.
- **Delay BIOS upgrade until next server power off.** Enable this option if you want to postpone the BIOS upgrade until the next time the system reboots.

7 Click Start Upgrade to start the upgrade process or click Exit to cancel the process.

When you click Start Upgrade the upload process starts and a prompt to continue the process appears.

Note – If you did not preserve the ILOM configuration before the firmware update, you need to perform the initial ILOM setup procedures to reconnect to ILOM.

8 At the prompt, click OK to continue.

The Update Status page appears, providing details about the update progress. When the update indicates 100%, the firmware upload is complete. When the upload is completed, the system automatically reboots.

Note – The ILOM web interface might not refresh properly after the update is completed. If the ILOM web interface is missing information or displays an error message, you might be viewing a cached version of the page from the version previous to the update. Clear your browser cache and refresh your browser before continuing.

9 Log in to the SP ILOM web interface.

10 Select System Information –> Version to verify that the firmware version on the SP or CMM corresponds to the firmware image you installed.

Sun® Microsystems, Inc.

System Information	System Monitoring	Configuration	User Management	Remote Control	Maintenance
Versions	Session Time-Out	Components	Identification Information		

Versions

View the version of ILOM firmware currently in use.

Version Information

Property	Value
SP Firmware Version	3.0.3.31
SP Firmware Build Number	46984
SP Firmware Date	Wed Jul 22 09:57:54 CST 2009
SP Filesystem Version	0.1.22

▼ **How to Update the ILOM and System BIOS Using the Command-Line Interface**

Before You Begin

- Identify the version of ILOM that is currently running on your system. See [“Determining Current Firmware Versions” on page 28](#).
- Download the firmware image for your server from the Sun platform product web site. See [“How to Download Firmware Updates” on page 33](#).
- Copy the firmware image to a local server using a supported protocol (TFTP, FTP, HTTP, HTTPS).

- Obtain an ILOM user name and password that has Admin (a) role account privileges. You must have Admin (a) privileges to update the firmware on the system.
- To verify that you have network connectivity to update the firmware, type `-> show /SP/network`.

Note – The firmware update process takes about six minutes to complete. During this time, do not perform other ILOM tasks. When the firmware update is complete, the system reboots automatically.

1 Log in to the ILOM CLI.

See [“Connecting to the ILOM” on page 17](#) for more info.

2 Type the following command to load the ILOM firmware image:

`->load -source supported_protocol://server_ip/path_to_firmware_image/filename.ima`

If your system has an ILOM 2.x version, you must use the TFTP protocol to load the firmware image. If your system has a ILOM 3.x version, you can use TFTP, FTP, HTTP, or HTTPS.

A note about the firmware update process is displayed, followed by message prompts to load the image. The text of the note depends on your server platform.

3 At the prompt for loading the specified file, type y for yes or n for no.

The prompt to preserve the configuration appears.

4 At the preserve configuration prompt, type y for yes or n for no.

Type y to save your existing ILOM configuration and to restore that configuration when the update process is completed.

Typing n at this prompt advances you to another platform-specific prompt.

A prompt to postpone the BIOS update appears.

5 When asked if you want to force the server off to upgrade the BIOS, type y for yes or n for no.

Note – If you answer no (n) to the prompt, the system postpones the BIOS update until the next time the system reboots. If you answer yes (y) to the prompt, the system automatically updates the BIOS, if necessary, when updating the firmware.

The system loads the specified firmware file and then automatically reboots to complete the firmware update.

6 Reconnect to the ILOM server SP or CMM using an SSH connection and using the same user name and password that you provided in Step 1 of this procedure.

Note – If you did not preserve the ILOM configuration before the firmware update, you will need to perform the initial ILOM setup procedures to reconnect to ILOM.

- 7 To ensure that the proper firmware version was installed, at the CLI prompt, type:
-> version

Updating the Embedded HBA BIOS


To update the LSI firmware, you must boot the system from a special CD or CD image.

There are two ways you can do this:


- [“How to Update the LSI Firmware Using the Remote Console Method” on page 38](#)
- [“How to Update the LSI Firmware Using the Local Method” on page 39](#)

▼ How to Update the LSI Firmware Using the Remote Console Method

- 1 Connect to the ILOM Remote Console, according to the instructions in [“How to Connect Remotely Using the ILOM Web Interface” on page 20](#).
- 2 In the remote console window, select Devices.
- 3 At the pop-up screen, select the CD-ROM Image.
A check mark is displayed on the drop-down menu selection.
- 4 Browse to the LSI firmware update image .iso file, and select the correct .iso image file.



5 Select Remote Control -> Remote Power Control in the ILOM GUI.



6 Select Reset from the drop-down menu.

7 When the system reboots, select 1 (Perform the Update) from the remote console window.

The update proceeds.

When complete, the console responds with a new prompt.

8 In the remote console window, select Devices -> CDROM Image to detach the LSI firmware update .iso file.

9 Select Keyboard -> Control Alt Delete.

The system boots, and the new LSI firmware version is displayed in the boot messages.

You will notice the new LSI firmware version.

▼ How to Update the LSI Firmware Using the Local Method

1 Download the LSI firmware .iso file from the Sun Fire X64 servers web site and burn it to a bootable CD.

Note – The bootable CD appear blanks when viewed using the operating system. This is expected behavior.

2 Insert the bootable CD and reboot the server.

The firmware is upgraded.

3 Reboot the system.

The new LSI firmware version is displayed in the boot messages.

Using ILOM to Monitor the Host

This section describes the sensors and indicators that can be accessed through the ILOM.

Sensors report physical information about the server, including voltages, temperatures, fan speeds, and installation and removal of components.

Indicators report important server conditions.

All sensors and indicators are IPMI-compliant.

TABLE 2 System ILOM Sensors

Name	Description
/SYS/DBP/HDDX/FAIL	HDDX Predictive Failure
/SYS/DBP/PRSNT	Disk Backplane Present
/SYS/FP/PRSNT	Front Panel Indicator Module Present
/SYS/FTX/FMY/FZ/SPEED	Front Fan Board X Fan Module Y Fan Z Speed in RPMs
/SYS/FTX/FMY/PRSNT	Front Fan Board X Fan Module Y Present
/SYS/INTSW	Intrusion Switch Tripped
/SYS/MB/T_AMBX	Motherboard Sensor X Ambient Temperature in Degrees Celsius
/SYS/MB/V_+12V	Motherboard 12V Main Input
/SYS/MB/V_+1V2	Motherboard 1.2V Core Input for Motherboard
/SYS/MB/V_+1V5	Motherboard 1.5V Core Input
/SYS/MB/V_+2V5	Motherboard 2.5V Core Input
/SYS/MB/V_+3V3	Motherboard 3.3V Main Input
/SYS/MB/V_+3V3AUX_R	Motherboard Standby Devices 3.3V Auxiliary Input
/SYS/MB/V_+5V	Motherboard 5V Main Input
/SYS/MB/V_-12V	Motherboard -12V Main Input
/SYS/MB/V_BAT	Motherboard Battery Voltage

TABLE 2 System ILOM Sensors *(Continued)*

Name	Description
/SYS/PSX/PRSNT	Power Supply X Present
/SYS/PSX/PWROK	Power Supply X Supplying Power
/SYS/PSX/VINOK	Power Supply X AC Input Available
/SYS/PX/CARDFAIL	CPU Module X Failure
/SYS/PX/PROCHOT	CPU Module X Overheating (split-plane modules only)
/SYS/PX/PRSNT	CPU Module X Present
/SYS/PX/T_AMB	CPU Module X Ambient Temperature in Degrees Celsius
/SYS/PX/T_CORE	CPU Module X Core Temperature in Degrees Celsius
/SYS/PX/V_+0V9VTT	CPU Module X 0.9V VTT Input
/SYS/PX/V_+12V	CPU Module X !2V Main Input
/SYS/PX/V_+1V2	CPU Module X 1.2V Core Input
/SYS/PX/V_+1V8	CPU Module X 1.8V Core Input
/SYS/PX/V_+2V5	CPU Module X 2.5V Core Input
/SYS/PX/V_+3V3AUX_R	CPU Module X 3.3V Auxiliary Input
/SYS/PX/V_CORE	CPU Module X Core Voltage
/SYS/PX/V_NB	CPU Module X 5V Main Input (split-plane modules only)

TABLE 3 System ILOM Indicators

Name	Description
/SYS/DBP/HDDX/SERVICE	Service LED for HDD X is lit.
/SYS/FTX/FMY/SERVICE	Service LED for Front Fan Board X Fan Module Y is lit
/SYS/PX/CARD/SERVICE	Service LED for CPU Module X is lit
/SYS/PX/DY/SERVICE	Service LED for CPU Module X DIMM Y is lit
/SYS/PX/SERVICE	Service LED for CPU on CPU Module X is lit
/SYS/FAN_FAULT	Fan Fault LED on Front Panel is lit
/SYS/LOCATE	Locate LEDs are lit
/SYS/POWER	Power LED is lit
/SYS/PSU_FAULT	PSU Fault Detected

TABLE 3 System ILOM Indicators *(Continued)*

Name	Description
/SYS/SERVICE	Front Panel Service LED is lit
/SYS/TEMP_FAULT	Temperature Fault Detected

Index

B

- BIOS firmware
 - updating, 33
 - updating using CLI, 36–38
 - updating using web interface, 33–36

C

- CLI
 - accessing via serial management port, 16–17, 17–19
 - accessing via SSH, 17
- connecting
 - to physical console, 20
 - to remote console, 20–24
 - to serial console, 24–25
- connecting to the ILOM CLI
 - using serial management port, 16–17, 17–19
 - using SSH, 17
- connecting to the ILOM web interface, 19
- connectors, 13
- console
 - connecting directly, 20
 - connecting remotely, 20–24
 - serial connection, 24–25

D

- direct connection to console, 20

F

- firmware
 - downloading, 33
 - planning the update, 32–33
 - preparing for update, 32
 - updating, 27–39
 - updating HBA BIOS, 38
 - using local method, 39
 - using remote console method, 38–39
 - updating ILOM and system BIOS
 - using CLI, 36–38
 - using web interface, 33–36
- firmware versions
 - determining current versions, 28
 - verifying using CLI through management Ethernet port, 31–32
 - verifying using CLI through serial port, 30–31
 - verifying using web interface, 28–29
 - worksheet, 27

H

- HBA BIOS update
 - using local method, 39
 - using remote console method, 38–39

I

- ILOM firmware
 - updating, 33

ILOM firmware (*Continued*)

- updating using CLI, 36–38

- updating using web interface, 33–36

ILOM sensors, 41–43

ILOM SP, *See* service processor

introduction to ILOM software, 11

O

overview of ILOM Supplement, 9

P

physical console, connecting directly, 20

R

remote console, connecting, 20–24

S

serial console, connecting, 24–25

serial management port

- connecting to the ILOM CLI, 16–17, 17–19

server connectors, 13

service processor interfaces, 15

service processor IP addresses

- accessing through BIOS, 15

- accessing through serial connection, 16–17

- determining, 15

- overview, 15

SSH, connecting to the ILOM CLI, 17

W

web ILOM interface, 19