



# Sun Fire™ X2270 Server Installation Guide

---

Sun Microsystems, Inc.  
[www.sun.com](http://www.sun.com)

Part No. 820-5604-11, Rev. A  
August 2009

Submit comments about this document by clicking the Feedback[+] link at: <http://docs.sun.com>

Copyright © 2009 Sun Microsystems, Inc., 4150 Network Circle, Santa Clara, California 95054, U.S.A. All rights reserved.

Sun Microsystems, Inc. has intellectual property rights relating to technology embodied in the product that is described in this document. In particular, and without limitation, these intellectual property rights may include one or more of the U.S. patents listed at <http://www.sun.com/patents> and one or more additional patents or pending patent applications in the U.S. and in other countries.

This distribution may include materials developed by third parties.

Parts of the product may be derived from Berkeley BSD systems, licensed from the University of California. UNIX is a registered trademark in the U.S. and in other countries, exclusively licensed through X/Open Company, Ltd.

Sun, Sun Microsystems, the Sun logo, Java, Solaris, OpenSolaris, Sun Blade, docs.sun.com, Sun Fire and the Solaris logo are trademarks or registered trademarks of Sun Microsystems, Inc., or its subsidiaries, in the U.S. and other countries.

Intel is a trademark or registered trademark of Intel Corporation or its subsidiaries in the United States and other countries. The Adobe logo is a registered trademark of Adobe Systems, Incorporated.

The OPEN LOOK and Sun(TM) Graphical User Interface was developed by Sun Microsystems, Inc. for its users and licensees. Sun acknowledges the pioneering efforts of Xerox in researching and developing the concept of visual or graphical user interfaces for the computer industry. Sun holds a non-exclusive license from Xerox to the Xerox Graphical User Interface, which license also covers Sun's licensees who implement OPEN LOOK GUIs and otherwise comply with Sun's written license agreements.

Use of any spare or replacement CPUs is limited to repair or one-for-one replacement of CPUs in products exported in compliance with U.S. export laws. Use of CPUs as product upgrades unless authorized by the U.S. Government is strictly prohibited.

DOCUMENTATION IS PROVIDED "AS IS" AND ALL EXPRESS OR IMPLIED CONDITIONS, REPRESENTATIONS AND WARRANTIES, INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE OR NON-INFRINGEMENT, ARE DISCLAIMED, EXCEPT TO THE EXTENT THAT SUCH DISCLAIMERS ARE HELD TO BE LEGALLY INVALID.

---

Copyright © 2009 Sun Microsystems, Inc., 4150 Network Circle, Santa Clara, California 95054, Etats-Unis. Tous droits réservés.

Sun Microsystems, Inc. détient les droits de propriété intellectuelle relatifs à la technologie incorporée dans le produit qui est décrit dans ce document. En particulier, et ce sans limitation, ces droits de propriété intellectuelle peuvent inclure un ou plus des brevets américains listés à l'adresse <http://www.sun.com/patents> et un ou les brevets supplémentaires ou les applications de brevet en attente aux Etats - Unis et dans les autres pays.

Cette distribution peut comprendre des composants développés par des tierces parties.

Des parties de ce produit pourront être dérivées des systèmes Berkeley BSD licenciés par l'Université de Californie. UNIX est une marque déposée aux Etats-Unis et dans d'autres pays et licenciée exclusivement par X/Open Company, Ltd.

Sun, Sun Microsystems, le logo Sun, Java, Solaris, OpenSolaris, Sun Blade, docs.sun.com, Sun Fire et le logo Solaris sont des marques de fabrique ou des marques déposées de Sun Microsystems, Inc., ou ses filiales, aux Etats-Unis et autres pays.

Intel est une marque ou une marque déposée de Intel Corporation, ou ses filiales, aux Etats-Unis, et dans d'autres pays. Le logo Adobe. est une marque déposée de Adobe Systems, Incorporated.

L'interface d'utilisation graphique OPEN LOOK et Sun(TM) a été développée par Sun Microsystems, Inc. pour ses utilisateurs et licenciés. Sun reconnaît les efforts de pionniers de Xerox pour la recherche et le développement du concept des interfaces d'utilisation visuelle ou graphique pour l'industrie de l'informatique. Sun détient une licence non exclusive de Xerox sur l'interface d'utilisation graphique Xerox, cette licence couvrant également les licenciés de Sun qui mettent en place l'interface d'utilisation graphique OPEN LOOK et qui, en outre, se conforment aux licences écrites de Sun.

L'utilisation de pièces détachées ou d'unités centrales de remplacement est limitée aux réparations ou à l'échange standard d'unités centrales pour les produits exportés, conformément à la législation américaine en matière d'exportation. Sauf autorisation par les autorités des Etats-Unis, l'utilisation d'unités centrales pour procéder à des mises à jour de produits est rigoureusement interdite.

LA DOCUMENTATION EST FOURNIE "EN L'ETAT" ET TOUTES AUTRES CONDITIONS, DECLARATIONS ET GARANTIES EXPRESSES OU TACITES SONT FORMELLEMENT EXCLUES, DANS LA MESURE AUTORISEE PAR LA LOI APPLICABLE, Y COMPRIS NOTAMMENT TOUTE GARANTIE IMPLICITE RELATIVE A LA QUALITE MARCHANDE, A L'APTITUDE A UNE UTILISATION PARTICULIERE OU A L'ABSENCE DE CONTREFACON.



# Contents

---

## **Preface   vii**

### **1.   Setting Up the Sun Fire X2270 Server Hardware   1**

Safety and Compliance Information   1

Planning the Installation Process   2

Package Contents Inventory   3

Installing the Server Into a Rack With Optional Slide Rails   3

Connecting the Cables   4

▼ To Connect the Cables   4

Powering On and Off the Server   6

▼ To Apply Standby Power for Initial Service Processor Configuration   6

▼ To Power On Main Power Mode   8

▼ To Power Off Main Power Mode   9

Setup Troubleshooting and Support   10

Troubleshooting the Sun Fire X2270 Server Setup   10

Contacting Support   12

### **2.   Setting Up the Sun Fire X2270 Server Software   15**

Introduction to the Sun Integrated Lights Out Manager   15

Connecting to the ILOM Service Processor   17

Connecting to ILOM Using a Serial Connection	17
▼ To Connect to ILOM Using a Serial Connection	17
Connecting to ILOM Using an Ethernet Connection	19
Configuring ILOM Using Dynamic Ethernet Settings	19
▼ To Configure ILOM Ethernet Settings Using DHCP	19
Configuring ILOM Using Static Ethernet Settings	22
▼ To Configure Static IP Addresses Using the Web Interface	22
▼ To Configure Static IP Addresses Using the CLI	23
▼ To Configure Static IP Addresses Using the BIOS Setup Utility	24
Setting Up Platform Operating System and Driver Software	25
<b>3. Configuring the Preinstalled OpenSolaris Operating System</b>	<b>27</b>
Before You Begin	27
Installation Worksheet	28
Configuring the Preinstalled OpenSolaris Operating System	32
▼ Accessing the System Over the Network	32
▼ Accessing the System Locally	33
▼ Configure the Preinstalled OpenSolaris Operating System	34
▼ Redirect the Console Output to the Video Port (Optional)	35
▼ To Modify the GRUB Menu to Auto Boot (Optional)	36
Getting Started on OpenSolaris	37
OpenSolaris Operating System User Information	37
OpenSolaris User Documentation	37
OpenSolaris Training	38
Using the OpenSolaris Installation Program	38
Reinstalling the OpenSolaris Operating System	38
Download OpenSolaris Operating System	38

<b>4. Configuring the Preinstalled Solaris 10 Operating System</b>	<b>39</b>
Before You Begin	39
Installation Worksheet	40
Selecting Your Console Output	43
Configuring the Preinstalled Solaris 10 Operating System	44
▼ To Connect to the Server Using the Service Processor's IP Address	45
▼ To Connect to the Server Using a Terminal Program	46
Solaris 10 Operating System User Information	47
Accessing Solaris 10 OS User Documentation	48
Downloading Solaris 10 OS Software	48
Solaris 10 OS Training	48
<b>Index</b>	<b>49</b>



# Preface

---

The *Sun Fire X2270 Server Installation Guide* contains procedures for installing the server into a rack, connecting to the service processor, and configuring the either the preinstalled OpenSolaris or Solaris™ Operating System.

---

## Product Updates

For product updates that you can download for the Sun Fire X2270 Server, visit the following web site:

<http://www.sun.com/download/index.jsp>.

Find the Hardware Drivers section and click x64 Servers & Workstations. The Sun Fire X2270 Server site contains updates for firmware and drivers, as well as CD-ROM .iso images.

---

## Related Documentation

Refer to the following table to identify other documentation that is currently available for the Sun Fire X2270. You can access these documents online at:

<http://docs.sun.com/app/docs/prod/sf.2270>

<b>Title</b>	<b>Content</b>	<b>Part Number</b>	<b>Format</b>
<i>Sun Fire X2270 Server Product Notes</i>	Late-breaking information about the server.	820-5608	PDF HTML
<i>Sun Fire X2270 Server Getting Started Guide</i>	Basic installation information for setting up the server.	820-5610	PDF Print
<i>Sun Fire X2270 Server Installation Guide</i>	Detailed installation information for setting up the server.	820-5604	PDF HTML Print option
<i>Sun Fire X2270 Server Linux, VMware, OpenSolaris, and Solaris Operating Systems Installation Guide</i>	Installation instructions for the Linux, VMware, OpenSolaris, and Solaris operating systems.	820-5606	PDF HTML
<i>Sun Fire X2270 Server Windows Operating System Installation Guide</i>	Installation instructions for the Windows Server operating system.	820-7143	PDF HTML
<i>Sun Installation Assistant for Windows and Linux User's Guide</i>	Instructions for using the Sun Installation Assistant to install the Windows and Linux operating systems.	820-3357	PDF HTML
<i>Sun Fire X2270 Server Service Manual</i>	Information and procedures for maintaining and upgrading the server.	820-5607	PDF HTML
<i>Sun x64 Servers Diagnostics Guide</i>	Information for diagnosing and troubleshooting the server.	820-6750	PDF HTML
<i>x64 Servers Utilities Reference Manual</i>	Information for using applications and utilities common to x64 servers and server modules.	820-1120	PDF HTML
<i>Sun Integrated Lights Out Manager 2.0 User's Guide</i>	ILOM features and tasks that are common to servers and server modules that support ILOM.	820-1188	PDF HTML



<b>Title</b>	<b>Content</b>	<b>Part Number</b>	<b>Format</b>
<i>Sun Integrated Lights Out Manager (ILOM) 2.0 Supplement for Sun Fire X2270 Server</i>	ILOM information that is specific to the server.	820-5609	PDF HTML
<i>Sun Integrated Lights Out Manager (ILOM) 3.0 Documentation Collection</i>	Information for the initial setup to ILOM, ILOM conceptual information, and procedures that can be performed using the ILOM web interface, command-line interface, SNMP, and IPMI.	820-5523 820-6410 820-6411 820-6412 820-6413	PDF HTML
<i>Sun Integrated Lights Out Manager (ILOM) 3.0 Supplement for Sun Fire X2270 Server</i>	ILOM information that is specific to the server.	821-0039	PDF HTML
<i>Sun Fire X2270 Server Safety and Compliance Manual</i>	Hardware safety and compliance information for the server.	820-5605	PDF
<i>Important Safety Information for Sun Hardware Systems</i>	Multilingual hardware safety and compliance information for all Sun hardware systems.	816-7190	Print
<i>Accessing Sun Product Documentation</i>	Multilingual information that provides the URL to Sun online documentation.	820-0541	Print

Translated versions of some of these documents are available at the web site described above in French, Japanese, and Simplified Chinese. English documentation is revised more frequently and might be more up-to-date than the translated documentation.

## Documentation, Support, and Training

<b>Sun Function</b>	<b>URL</b>
Sun Documentation	<a href="http://docs.sun.com">http://docs.sun.com</a>
Support	<a href="http://www.sun.com/support/">http://www.sun.com/support/</a>
Training	<a href="http://www.sun.com/training/">http://www.sun.com/training/</a>

---

# Using UNIX Commands

This document might not contain information about basic UNIX® commands and procedures such as shutting down the system, booting the system, and configuring devices. Refer to the following for this information:

- Software documentation that you received with your system
- Solaris™ Operating System documentation, which is at:

<http://docs.sun.com>

---

# Third-Party Web Sites

Sun is not responsible for the availability of third-party web sites mentioned in this document. Sun does not endorse and is not responsible or liable for any content, advertising, products, or other materials that are available on or through such sites or resources. Sun will not be responsible or liable for any actual or alleged damage or loss caused by or in connection with the use of or reliance on any such content, goods, or services that are available on or through such sites or resources.

---

# Typographic Conventions

Typeface*	Meaning	Examples
AaBbCc123	The names of commands, files, and directories; on-screen computer output	Edit your <code>.login</code> file. Use <code>ls -a</code> to list all files. % You have mail.
<b>AaBbCc123</b>	What you type, when contrasted with on-screen computer output	% <b>su</b> Password:
<i>AaBbCc123</i>	Book titles, new words or terms, words to be emphasized. Replace command-line variables with real names or values.	Read Chapter 6 in the <i>User's Guide</i> . These are called <i>class</i> options. You <i>must</i> be superuser to do this. To delete a file, enter <code>rm filename</code> .

\* The settings on your browser might differ from these settings.

---

## Sun Welcomes Your Comments

Sun is interested in improving its documentation and welcomes your comments and suggestions. You can submit your comments by going to:

<http://www.sun.com/hwdocs/feedback>

Please include the following document title and part number with your feedback:

*Sun Fire X2270 Server Installation Guide*, part number 820-5604-11



# Setting Up the Sun Fire X2270 Server Hardware

---

This chapter describes how to set up the Sun Fire™ X2270 server hardware. It includes the following topics:

- “Safety and Compliance Information” on page 1
- “Planning the Installation Process” on page 2
- “Package Contents Inventory” on page 3
- “Installing the Server Into a Rack With Optional Slide Rails” on page 3
- “Connecting the Cables” on page 4
- “Powering On and Off the Server” on page 6
- “Setup Troubleshooting and Support” on page 10

---

## Safety and Compliance Information


Refer to the following documents for safety information regarding the Sun Fire X2270 Server:

- *Important Safety Information for Sun Hardware Systems* (816-7190): printed document included in the ship kit.
- *Sun Fire X2270 Server Safety and Compliance Manual* (820-5605): available online by navigating to the Sun Fire X2270 Server document page from the following URL:  
<http://docs.sun.com/app/docs/prod/servers>

# Planning the Installation Process

Use the flowchart in [FIGURE 1-1](#) to assist you with the server installation process.

**FIGURE 1-1** Sun Fire X2270 Server Installation Process



---

# Package Contents Inventory

Carefully unpack all server components from the packing cartons. The following items might be packaged with your Sun Fire X2270 Server:

- Sun Fire X2270 Server Base Documentation Kit, which includes the following:
  - *Sun Fire X2270 Server Getting Started Guide* (820-5610)
  - License and safety documentation
- (Optional) Sun Fire X2270 Server Documentation and Media Kit, which includes the following:
  - *Sun Fire X2270 Server Installation Guide* (820-5604)
  - *Accessing Sun Product Documentation* (820-0541)
  - Tools & Drivers DVD (includes drivers and additional software)
  - Sun Installation Assistant (SIA) CD/DVD
  - SunVTS CD/DVD
  - Additional license and safety documentation
- Hardware applicable to the system, such as adapters and network cables
- Power cord packaged separately with country kit
- (Optional) Rackmount kit containing rack rails and installation instructions

---

## Installing the Server Into a Rack With Optional Slide Rails

The service label on the top cover of the Sun Fire X2270 Server contains instructions for installing your server into a four-post rack using the orderable slide-rail and cable management arm options. Detailed instructions can also be found online in the *Sun Fire X2270 Server Service Manual* (820-5607) at the following URL:

<http://docs.sun.com/app/docs/prod/servers>

The slide rails for the Sun Fire X2270 Server are compatible with a wide range of equipment racks that meet the following standards:

- Four-post structure (mounting at both front and rear). Two-post racks are not compatible.
- Rack horizontal opening and unit vertical pitch conforming to ANSI/EIA 310-D-1992 or IEC 60927 standards.

- Distance between front and rear mounting planes of 610 mm to 915 mm (24 inches to 36 inches).
- Clearance depth (to front cabinet door) in front of front rack mounting plane of at least 25.4 mm (1 inch).
- Clearance depth (to rear cabinet door) behind front rack mounting plane of at least 800 mm (31.5 inches) with the cable management arm, or 700 mm (27.5 inches) without the cable management arm.
- Clearance width (between structural supports and cable troughs) between front and rear mounting planes of at least 456 mm (18 inches).



---

**Caution** – Always load equipment into a rack from the bottom up so that the rack will not become top-heavy and tip over. Deploy your rack’s anti-tilt bar to prevent the rack from tipping during equipment installation.

---



---

**Caution** – Ensure that the temperature in the rack does not exceed the server’s maximum ambient rated temperatures. Consider the total airflow requirements of all equipment installed in the rack, to ensure that the equipment is operating within its specified temperature range.

---

---

## Connecting the Cables

See [FIGURE 1-2](#) and [TABLE 1-1](#) for the locations of the connectors.

### ▼ To Connect the Cables

Connect the server and external devices as follows:

**1. Connect a serial null modem cable to the serial port.**

The default serial port speed is 9600 baud with no flow control.

**2. Connect Ethernet cables to the RJ-45 LAN Gigabit Ethernet ports as needed (see [FIGURE 1-2](#)).**

Note the following guidelines regarding the Ethernet (NET) ports:

- The Network Management (NET MGT) Ethernet port on the optional SP module, or the Serial Management (SER MGT)/ RS-232-F RJ-45 serial port can be used for server management and network access.




See “Setting Up the Sun Fire X2270 Server Software” on page 15 for additional information about setting up the service processor (SP) for remote system management.

- The two Gigabit Ethernet ports (NET-0 and NET-1) are the primary network interface controllers (NICs) and should be used for network installation of the operating system and drivers.

### 3. Connect any additional external devices to the server’s other ports.

**FIGURE 1-2** Back Panel



**TABLE 1-1** Back Panel

Label	Connector/Slot	Label	Connector/Slot
1	AC Power connector	7	Gigabit Ethernet port (NET-1)
2	White Locate LED	8	USB 2.0 ports (2)
3	Amber Fault LED	9	Network Management (NET MGT) Ethernet port (available only in systems that contain an SP module)
4	Green Power/OK LED	10	HD15 video connector (available only in systems that contain an SP module)
5	Serial Management (SER MGT) / RS-232-F RJ-45 serial port	11	PCI Express slot
6	Gigabit Ethernet port (NET-0)		

---

# Powering On and Off the Server

You only need to apply standby power to the server at this point so that you can perform initial configuration of the service processor (SP). Procedures for powering on to main power mode and for shutting down from main power mode are also included in this section, for your reference.

---

**Note** – The procedures for applying standby power for initial service processor configuration are applicable only to systems that contain an optional service processor module. If your system *does not* contain a service processor, continue with the instructions [“To Power On Main Power Mode” on page 8](#).

---

## ▼ To Apply Standby Power for Initial Service Processor Configuration

Use this procedure to apply standby power to the service processor before initial configuration.



---


**Caution** – Do not operate the server without all fans, component heatsinks, air baffles, and the cover installed. Severe damage to server components can occur if operated without adequate cooling mechanisms.

---

1. **Connect a grounded AC power cord to the AC power connector on the back panel of the server and to a grounded AC power outlet.**

In standby power mode, the Power/OK LED on the front panel flashes, indicating that the SP is receiving power. See [FIGURE 1-3](#) and [TABLE 1-2](#) for the Sun Fire X2270 with removable hard disk drives (HDDs) or solid state drives (SSDs), and [FIGURE 1-4](#) and [TABLE 1-3](#) for the Sun Fire X2270 with fixed HDDs or SSDs.


**FIGURE 1-3** Front Panel With Removable Hard Disk Drives or Solid State Disk Drives



**TABLE 1-2** Front Panel With Removable Hard Disk Drives or Solid State Drives

Label	Button/LED/Port	Label	Button/LED/Port
1	White Locate LED/Switch	8	Optional removable SATA HDD/SSD 1
2	Amber Fault LED	9	Optional removable SATA HDD/SSD 2
3	Green Power/OK LED	10	Optional removable SATA HDD/SSD 3
4	Power button	11	Disk Ready-to-Remove LED–non-operational
5	USB 2.0 ports (2)	12	Disk Service Action Required LED–non-operational
6	System serial label	13	Green Disk OK LED–indicates that data is being read from or written to the HDD/SSD
7	Optional removable SATA HDD/SSD 0		

**FIGURE 1-4** Front Panel With Fixed Hard Disk Drives or Solid State Drives



**TABLE 1-3** Front Panel With Fixed Hard Disk Drives or Solid State Drives

Label	Button/LED/Port	Label	Button/LED/Port
1	White Locate LED/Switch	7	System serial label
2	Amber Fault LED	8	Optional fixed SATA HDD/SSD 0
3	Green Power/OK LED	9	Optional fixed SATA HDD/SSD 1
4	Power button	10	Optional fixed SATA HDD/SSD 2
5	USB 2.0 ports (2)	11	Optional fixed SATA HDD/SSD 3
6	HDD/SSD Activity LED		

**2. Continue with initial software setup tasks, as described in Chapter 2.**

**Note** – At this point, standby power is supplied only to the service processor and power supply fans. You can proceed to Chapter 2 of this guide to begin initial configuration. Do not apply main power to the rest of the server until you are ready to install a platform operating system.

▼ **To Power On Main Power Mode**

**Note** – If your system *does not* contain an SP module, begin with [Step 2](#).

To power on main power for all server components:

1. **Verify that the power cord has been connected to the server. If your server contains an SP module, verify that standby power is on.**

For servers with an SP module, in standby power mode, the Power/OK LED on the front panel flashes. Depending on your server configuration, see either [FIGURE 1-3](#) or [FIGURE 1-4](#).

2. **Press and release the Power button on the server front panel.**

When main power is applied to the full server, the Power/OK LED next to the Power button lights and remains lit.

---

**Note** – The first time the server powers on, the power-on self-test (POST) can take up to one minute to complete.

---

## ▼ To Power Off Main Power Mode

- **To power off the server from main power mode, use one of the following two methods:**
  - **Graceful shutdown:** Press and release the Power button on the front panel. This causes Advanced Configuration and Power Interface (ACPI) enabled operating systems to perform an orderly shutdown of the operating system. Servers not running ACPI-enabled operating systems will shut down to standby power mode immediately.
  - **Emergency shutdown:** Press and hold the Power button for at least four seconds to force main power off and enter standby power mode. When the main power is off, the Power/OK LED on the front panel will begin flashing (only in systems that contain an SP module), indicating that the server is in standby power mode.



---

**Caution** – To completely power off the server, you must disconnect the AC power cords from the back panel of the server.

---

---

# Setup Troubleshooting and Support

This section contains information to help you troubleshoot minor server setup problems. It includes the following topics:

- [“Troubleshooting the Sun Fire X2270 Server Setup” on page 10.](#)
- [“Contacting Support” on page 12](#)

## Troubleshooting the Sun Fire X2270 Server Setup

If you experience problems while setting up your server, refer to the troubleshooting information in [TABLE 1-4](#).

**TABLE 1-4** Troubleshooting Procedures

Problem	Possible Solution
Server powers on, but the monitor does not.	<ul style="list-style-type: none"><li>• Is the Power button for the monitor turned on?</li><li>• Is the monitor power cord connected to a wall outlet?</li><li>• Does the wall outlet have power? Test by connecting another device.</li></ul>
CD or DVD does not eject from the media tray when you press the Eject button.	<ul style="list-style-type: none"><li>• Move the mouse or press any key on the keyboard. The drive might be in low power mode.</li><li>• Use the utility software installed on your server to eject the CD.</li><li>• Ensure that the media in the device is not in use and is not mounted by the operating system.</li></ul>
No video is displayed on the monitor screen.	<ul style="list-style-type: none"><li>• Is the monitor cable attached to the video connector?</li><li>• Does the server have an SP module? If the server <i>does not</i> contain an SP module or an optional video card, video is routed to the server serial port. Connect the monitor to the server serial port.</li><li>• Does the monitor work when connected to another system?</li><li>• If you have another monitor, does it work when connected to the original system?</li><li>• If, after POST and BIOS complete, you no longer see video output on your monitor and only see a flashing cursor, check the configuration of the operating system to determine whether it is configured to redirect its output exclusively over the serial line.</li></ul>

**TABLE 1-4** Troubleshooting Procedures (*Continued*)

Problem	Possible Solution
Server does not power on when the front panel Power button is pressed.	<p>Keep notes on the following situations in case you need to call Sun service:</p> <ul style="list-style-type: none"> <li>• Is the Power/OK LED illuminated on the front of the system? (Ensure that the power cord is connected to the system and to a grounded power supply.)</li> <li>• Does the wall outlet have power? Test by connecting another device.</li> <li>• Does the monitor synchronize within five minutes after power on? (The green LED on the monitor stops flashing and remains illuminated.)</li> </ul>
Keyboard or mouse does not respond to actions.	<ul style="list-style-type: none"> <li>• Verify that the mouse and keyboard cables are connected to the on-board USB 2.0 ports on the server.</li> <li>• Verify that the server is powered on and the front Power/OK LED is illuminated.</li> </ul>
Server appears to be in low power mode, but the Power/OK LED does not blink.	<p>The Power/OK LED only blinks when all server components are in low power mode. A tape drive might be connected to your server. Because tape drives do not enter low power mode, the Power/OK LED does not blink.</p>
Server is hung or frozen: No response from mouse or keyboard or any application.	<p>Try to access your system from a different server on the network:</p> <ol style="list-style-type: none"> <li>1. On another system, type <b>ping</b> <i>IP_address_of_X2270</i></li> <li>2. If a response is returned, then try logging in to the Sun Fire X2270 Server using either <code>telnet</code>, <code>ssh</code> or <code>rlogin</code>.</li> <li>3. If you successfully log in, list the running processes using the <b>ps</b> command.</li> <li>4. Kill any processes that appear unresponsive or should not be running, by using the <b>kill</b> <i>process_ID</i> command.</li> <li>5. Check the responsiveness of the Sun Fire X2270 Server after each process is killed.</li> </ol> <p>If the above procedure does not work, power cycle the server:</p> <ol style="list-style-type: none"> <li>1. Press the Power button to power off the server and wait 20 to 30 seconds.</li> <li>2. Press the Power button again to power on the system.</li> </ol>
<p><b>Note</b> – For additional troubleshooting information, see the <i>Sun Fire X2270 Server Service Manual</i> (820-5607).</p>	

# Contacting Support

If the troubleshooting procedures in this chapter fail to solve your problem, use [TABLE 1-5](#) to collect information that you might need to communicate to the support personnel. [TABLE 1-6](#) lists the Sun web sites and telephone numbers for additional technical support.

**TABLE 1-5** System Information Needed for Support

System Configuration Information Needed	Your Information
Sun service contract number	
System model	
Operating environment	
System serial number	
Peripherals attached to the system	
Email address and phone number for you and a secondary contact Street address where the system is located	
Superuser password	
Summary of the problem and the work being done when the problem occurred	
<b>Other Useful Information</b>	
IP address	
Server name (system host name)	
Network or internet domain name	
Proxy server configuration	

**TABLE 1-6** Sun Technical Support Contacts

Server Documents and Support Resources	URL or Telephone Number
PDF files for all current Sun Fire X2270 Server documents.	<a href="http://docs.sun.com/app/docs/prod/servers">http://docs.sun.com/app/docs/prod/servers</a>
Solaris™ 10 and other software documents. This web site has full search capabilities.	<a href="http://docs.sun.com/documentation/">http://docs.sun.com/documentation/</a>
Discussion and troubleshooting forums.	<a href="http://supportforum.sun.com/">http://supportforum.sun.com/</a>



**TABLE 1-6** Sun Technical Support Contacts *(Continued)*

Server Documents and Support Resources	URL or Telephone Number
Support, diagnostic tools, and alerts for all Sun products.	<a href="http://www.sun.com/bigadmin/">http://www.sun.com/bigadmin/</a>
SunSolve <sup>SM</sup> web site. Contains links to software patches. Lists some system specifications, troubleshooting and maintenance information, and other tools.	<a href="http://www.sunsolve.sun.com/handbook_pub/">http://www.sunsolve.sun.com/handbook_pub/</a>
SunService <sup>SM</sup> support phone numbers.	1-800-872-4786 (1-800-USA-4Sun), select Option 1
International telephone numbers for SunService support.	<a href="http://www.sun.com/service/contacting/solution.html">http://www.sun.com/service/contacting/solution.html</a>
Warranty and contract support contacts. Links to other service tools.	<a href="http://www.sun.com/service/warrantiescontracts/">http://www.sun.com/service/warrantiescontracts/</a>
Warranties for every Sun product.	<a href="http://www.sun.com/service/support/warranty">http://www.sun.com/service/support/warranty</a>



# Setting Up the Sun Fire X2270 Server Software

---

This chapter describes the tasks for initial setup of the server's service processor and Sun Integrated Lights Out Manager (ILOM) software. This chapter includes the following topics:

- [“Introduction to the Sun Integrated Lights Out Manager” on page 15](#)
- [“Connecting to the ILOM Service Processor” on page 17](#)
- [“Setting Up Platform Operating System and Driver Software” on page 25](#)

---

**Note** – ILOM can be used only in systems that contain an optional service processor (SP) module. If your system *does not* contain an SP, continue with the instructions in [“Setting Up Platform Operating System and Driver Software” on page 25](#).

---

---

## Introduction to the Sun Integrated Lights Out Manager

The Sun Integrated Lights Out Manager (ILOM) provides powerful tools for managing your server.

**FIGURE 2-1** Integrated Lights Out Manager Login Page



ILOM consists of four components, three that are on your host server and one that is on the client system that accesses your host server. The four components are as follows:

- **ILOM SP hardware.** Your server is equipped with a service processor that performs the following functions:
  - Monitors the status and configuration of field-replaceable components of your server, such as fans, disk drives, and power supplies.
  - Provides serial and Ethernet connections to external terminals or local area networks (LANs).
- **ILOM SP firmware.** A library of system management firmware applications that is preinstalled on the SP. This ILOM firmware is operating system independent. These firmware applications provide the following system management interfaces into your server:
  - A web-based graphical interface
  - A Secure Shell (SSH) command-line interface
  - An IPMI v2.0 command interface
  - A Simple Network Management Protocol (SNMP) v1, v2c, or v3 interface

These interfaces call the same underlying system management functions on your service processor, so you can choose to work with one or more of these ILOM interfaces to integrate with the other management interfaces running in your data center.

- **Remote Console application.** The Remote Console application enables remote clients to view the graphical console of your host server as though they were directly attached to its video connector. The Remote Console is a mirror of the 1024x768 output from the server's VGA video connector. The remote keyboard, mouse, CD/DVD drive, or diskette drive will appear as standard USB devices.

---

**Note** – The Remote Console application is not required on the client systems, but a web browser and Sun Java™ runtime environment version 5.0 or later are required on the client systems. You can download Java free from <http://java.sun.com>.

---

- **Client-side Secure Shell application.** To access the ILOM SP through a remote Secure Shell (SSH), you must install a Secure Shell communications application on the remote client system (server, workstation, or laptop). Many Secure Shell communications applications are available from commercial or open-source distribution. Refer to <http://www.openssh.org> for information about open-source client-side SSH applications.

Sun Microsystems has configured the ILOM hardware and firmware on your server to reflect the most common default settings used in the field. It is unlikely that you will need to change these defaults.

---

## Connecting to the ILOM Service Processor

There are two methods for connecting to the ILOM SP to perform initial setup and configuration. Use the procedure that you prefer:

- “Connecting to ILOM Using a Serial Connection” on page 17
- “Connecting to ILOM Using an Ethernet Connection” on page 19

### Connecting to ILOM Using a Serial Connection

You can establish a serial connection to the ILOM SP so that you can perform initial configuration of ILOM.

#### ▼ To Connect to ILOM Using a Serial Connection

---

**Note** – This procedure assumes that you have already completed the hardware setup and have applied standby power to your server, as described in [Chapter 1](#).

---

1. **Verify that your terminal, laptop, or terminal server is operational.**

2. Configure that terminal device or the terminal emulation software running on a laptop or PC to the following settings:

- 8N1: eight data bits, no parity, one stop bit
- 9600 baud
- Disable hardware flow control (CTS/RTS)
- Disable software flow control (XON/XOFF)

3. Connect a serial cable from the RJ-45 SER MGT port on the server's back panel to a terminal device. See [FIGURE 1-2](#) for the location of this port.

4. Press Enter on the terminal device to establish a connection between that terminal device and the ILOM SP.

The SP eventually displays a login prompt, such as the following example:

```
SUNSP0003BA84D777 login:
```

In this example login prompt:

- The string `SUNSP` is the same for all SPs.
- `0003BA84D777` is the Ethernet MAC address of the particular SP. This will be different for each server.

5. Log in to ILOM.

a. Type the default user name: **root**

b. Type the default password: **changeme**.

Once you have successfully logged in, the SP displays its default command prompt:

```
->
```

You can now run commands using the ILOM command-line interface (CLI) to configure ILOM for the server's user accounts, network settings, access lists, alerts, and other parameters. For detailed instructions on CLI commands, see the *Sun Integrated Lights Out Manager 2.0 User's Guide* (820-1188).

For instructions on configuring static network settings using the CLI, see ["Configuring ILOM Using Static Ethernet Settings"](#) on page 22.

6. To start the serial console, type:

```
-> cd /SP/console
```

```
-> start
```

---

**Note** – You can switch back to the SP CLI from the serial console by entering the **Esc** ( key sequence.

---

7. **Continue with** [“Setting Up Platform Operating System and Driver Software” on page 25.](#)

## Connecting to ILOM Using an Ethernet Connection

To access the full range of ILOM functionality such as the graphical user interface (GUI), you must connect the server’s Ethernet port to your local area network (LAN) and configure your Ethernet connection.

ILOM supports Dynamic Host Configuration Protocol (DHCP) and static IP addressing.

- To configure the Ethernet connection using DHCP, see [“To Configure ILOM Ethernet Settings Using DHCP” on page 19.](#)
- To configure the Ethernet connection using a static IP address, see [“Configuring ILOM Using Static Ethernet Settings” on page 22.](#)

## Configuring ILOM Using Dynamic Ethernet Settings

You can configure the Ethernet settings using DHCP.

### ▼ To Configure ILOM Ethernet Settings Using DHCP

---

**Note** – This procedure assumes that you have already completed the hardware setup and have applied standby power for your server, as described in [Chapter 1.](#)

---

1. **Verify that your DHCP server is configured to accept new media access control (MAC) addresses by checking with your system administrator.**
2. **Connect an Ethernet cable to the server’s RJ-45 NET MGT Ethernet port.** See [FIGURE 1-2.](#)

If the ILOM SP is *not* using static IP addresses, it broadcasts a DHCPDISCOVER packet with the ID of its MAC address. A DHCP server on your LAN returns a DHCPOFFER packet containing an IP address and other information. The ILOM SP then manages its “lease” of the IP address that was assigned to it by the DHCP server.

3. **Obtain the ILOM SP IP address from one of the following locations. Record the IP address for future reference.**

- **CLI commands.** The SP has a serial port to which you can attach a terminal device. Log in to the SP and enter the CLI command **show /SP/network**. The SP displays the current IP address. Continue with [Step 4](#).
  - **System BIOS Setup screen.** Press F2 during the server power-on, then choose Advanced → IPMI 2.0 Configuration → LAN Configuration → IP Assignment. Continue with [Step 4](#).
  - **DHCP server log files.** To use this method, use [Step a](#) through [Step c](#) below.
- a. **Identify the MAC address of the ILOM SP from one of the following locations. Record the MAC address for future reference.**
- **CLI commands.** The SP has a serial port to which you can attach a terminal device. Log in to the SP and type the CLI command **show /SP/network**. The SP displays the current MAC address.
  - **Customer Information Sheet.** This document is shipped with your server.
  - **System BIOS Setup screen.** Press F2 during power-on, then choose Advanced → IPMI 2.0 Configuration → LAN Configuration → MAC address.
- b. **Log in to your DHCP server and view its DHCP log file.**

---

**Note** – Different DHCP server applications running on different operating systems store these log files in different locations. Consult your DHCP system administrator to locate the correct path to the log file.

---

- c. **Identify the IP address in the log file that corresponds to the MAC address of your ILOM SP.**

Typically, DHCP log file entries are individual lines with the following comma-separated fields:

*ID, Date, Time, Description, IP Address, Host Name, MAC Address*

Locate the MAC address of your ILOM SP in the MAC Address (seventh) field of the correct DHCP file entry and record the corresponding value of the IP Address (fifth) field. This is the IP address that you must use to access the system management firmware applications on your ILOM SP. Continue with [Step 4](#).

4. **Open a session to the ILOM SP using the IP address that you obtained in [Step 3](#).**

You can use the CLI or the web interface.




- To establish a Secure Shell (SSH) connection to the ILOM SP CLI, type the appropriate connection command in the SSH application. For example, to connect to the SP with the DHCP-assigned IP address of 129.144.82.20, type the following command:

```
# ssh -l root 129.144.82.20
```

The default user name is **root**, which was included in the **ssh** command. When you are prompted, enter the default password for the SP, **changeme**. You can then enter commands to manage user accounts or to monitor the status of devices on your server. See the example in [FIGURE 2-2](#).


**FIGURE 2-2** Opening a Session With an SSH Command-Line Interface



- To establish a connection to the ILOM SP web interface, type the IP address of the ILOM SP in the browser locator box and press Enter.

For example, if the IP address for your ILOM SP was 129.144.02.20, you would enter it as shown in [FIGURE 2-3](#). The first web page prompts you for the default username, **root**, and the default password, **changeme**.

**FIGURE 2-3** Opening a Session With a Web Interface



5. After you have entered the user name and password in either the CLI or web interface, you can use the interface to configure your ILOM SP.

For detailed instructions on configuring your system, see the *Sun Integrated Lights Out Manager 2.0 User's Guide* (820-1188).

6. Continue with [“Setting Up Platform Operating System and Driver Software” on page 25.](#)

## Configuring ILOM Using Static Ethernet Settings

As an alternative to having your DHCP server assign an IP address to your ILOM SP, you can also assign a static IP address to it. You can do this by using the web interface, by using the CLI over the network or serial port, or by using the server’s BIOS Setup utility. Use the procedure you prefer.

- [“To Configure Static IP Addresses Using the Web Interface” on page 22](#)
- [“To Configure Static IP Addresses Using the CLI” on page 23](#)
- [“To Configure Static IP Addresses Using the BIOS Setup Utility” on page 24](#)

### ▼ To Configure Static IP Addresses Using the Web Interface

1. **Determine the current IP address of the ILOM SP from one of the following locations:**
  - **CLI command.** The SP has a serial port to which you can attach a terminal device. Log in to the SP and enter the CLI command **show /SP/network**. The SP displays the current IP address.
  - **System BIOS Setup screen.** Press F2 during power-on, then choose Advanced → IPMI 2.0 Configuration → LAN Configuration → IP Assignment.
2. **Connect to the ILOM SP through a web browser running on a remote system.**

To establish a connection to the ILOM SP web interface, type the IP address of the ILOM SP in the browser locator box and press **Enter**. See [FIGURE 2-3](#) for an example.

The ILOM web interface Login screen appears.
3. **Log in to the web interface using the default user name, `root`, and the default password, `changeme`.**
4. **Choose the Configuration tab and its Network tab to display information about the current network configuration of your ILOM SP.** See [FIGURE 2-4](#).

5. Select the **Use the Following IP Address** option and type your static IP address information. See the example in [FIGURE 2-4](#).

**FIGURE 2-4** Integrated Lights Out Manager Network Settings Page



## ▼ To Configure Static IP Addresses Using the CLI

1. Log in to the CLI using SSH or by connecting to the serial port.

To establish a Secure Shell (SSH) connection to the iLOM CLI, type the appropriate connection command in the SSH application. For example, to connect to the SP with the DHCP-assigned IP address of 129.144.82.20, you would type the following command:

```
# ssh -l root 129.144.82.20
```

See the example in [FIGURE 2-2](#).

2. Type the following commands, using your own addresses in place of the examples below:

The addresses shown in the commands below are examples.

```
cd /SP/network
set pendingipaddress=129.144.82.26
set pendingipnetmask=255.255.255.0
set pendingipgateway=129.144.82.254
set pendingipdiscovery=static
set commitpending=true
```

## ▼ To Configure Static IP Addresses Using the BIOS Setup Utility

1. Enter the BIOS Setup utility by pressing the F2 key while the system is powering on and performing the power-on self-test (POST).
2. When the BIOS Main menu screen is displayed, select **Advanced**.
3. From the Advanced menu screen, select **IPMI 2.0 Configuration**.
4. From the IPMI 2.0 Configuration screen, select **LAN Configuration**.
5. From the LAN Configuration screen, select **IP Assignment**.
6. On the IP Address Mode screen, select **Static**.
7. Type the static IP address in the **IP Address** field.  
Click **ESC** to go back and enter the subnet mask and default gateway settings in their respective fields.
8. Select **Commit** and press **Enter** to commit the changes.
9. Select **Refresh** and press **Enter** to see your new static IP settings displayed in the **Current IP address** in **BMC** field.
10. Press and release the right arrow key until the Exit menu screen is displayed.
11. Follow the instructions on the Exit menu screen to save your changes and exit the BIOS Setup utility.

---

# Setting Up Platform Operating System and Driver Software

After configuring the ILOM SP with network settings, you can configure a preinstalled operating system or install a supported Linux, VMware, Solaris, OpenSolaris, or Windows platform operating system and drivers.

---

**Note** – Sun highly recommends that you use the Sun Installation Assistant (SIA) software when installing an OS other than Solaris. SIA will help locate and install all necessary OS components automatically.

---

- If your server contains the preinstalled OpenSolaris Operating System, refer to [“Configuring the Preinstalled OpenSolaris Operating System” on page 27](#) for instructions on configuring the OpenSolaris OS on your server.
- If your server contains the preinstalled Solaris 10 Operating System, refer to [“Configuring the Preinstalled Solaris 10 Operating System” on page 39](#) for instructions on configuring the Solaris OS on your server.
- For details about installing a supported Linux, VMware, OpenSolaris, Solaris, or Windows OS and the required drivers, refer to *Sun Fire X2270 Server Linux, VMware, OpenSolaris, and Solaris Operating Systems Installation Guide* (820-5606), *Sun Fire X2270 Server Windows Operating System Installation Guide* (820-7143), or the *Sun Installation Assistant for Windows and Linux User’s Guide* (820-3357).
  - Refer to the *Sun Fire X2270 Server Linux, VMware, OpenSolaris, and Solaris Operating Systems Installation Guide* for information to manually install and configure a supported Linux, VMware, OpenSolaris, or Solaris OS on your server.
  - Refer to the *Sun Fire X2270 Server Windows Operating System Installation Guide* for information to manually install and configure a supported Windows OS on your server.
  - Refer to the *Sun Installation Assistant for Windows and Linux User’s Guide* for information on using the Sun Installation Assistant (SIA) to install and configure a supported Windows or Linux OS on your server. With SIA, you can install the OS, the appropriate drivers, and if necessary, additional system software by simply booting the SIA media and following the prompts.
- For additional OS considerations specific to this server, refer to the *Sun Fire X2270 Server Product Notes* (820-5608).

If you do not plan to use an operating system that is preinstalled on your Sun Fire X2270 Server, install your preferred OS at this time. If either the OpenSolaris or Solaris 10 OS is preinstalled on the primary boot drive, you will need to remove the OS using the Erase Primary Boot Disk utility on the Tools & Drivers DVD.

See the *Sun Fire X2270 Server Linux, VMware, OpenSolaris, and Solaris Operating Systems Installation Guide* (820-5606) for more information on erasing the primary boot disk.

# Configuring the Preinstalled OpenSolaris Operating System

---

This chapter explains the steps for configuring the OpenSolaris Operating System (OS) that is preinstalled on the hard disk drive (or solid state drive), if ordered. The preinstalled OpenSolaris version is OpenSolaris 2009.06 or later.

---

**Note** – Unlike with SPARC® systems, you will *not* see the output of the preinstalled OpenSolaris image through a monitor when you power on the server. Instead, the output of the preinstalled image is directed to a *serial console*.

---

---

## Before You Begin

Before you begin configuring the preinstalled OpenSolaris OS, do the following:

1. If your system contains a service processor (SP) module, perform initial configuration of the server's Integrated Lights Out Manager (ILOM) service processor and determine the server's network settings, as described in ["Connecting to the ILOM Service Processor" on page 17](#).
2. Ensure that main power has been applied to the server. For more information, see ["To Power On Main Power Mode" on page 8](#).
3. Gather the information that you will need for the configuration, as listed in ["Installation Worksheet" on page 28](#). Note that default values are indicated by an asterisk (\*).

---

**Note** – To identify the MAC address for a server or other chassis components, see the Customer Information Sheet (shipped with the component), or inspect the printed MAC address label attached to the server or chassis component.

---

4. The server ships with its console redirected to the *serial* port. You can choose an option to send the output to VGA (video port). For more information, see [“Redirect the Console Output to the Video Port \(Optional\)”](#) on page 35.

## Installation Worksheet

Use the worksheet in [TABLE 3-1](#) to gather the information that you need to configure the preinstalled OpenSolaris OS. You only need to collect the information that applies to your application of the system.



**TABLE 3-1** Worksheet for OpenSolaris Configuration

Information for Installation		Description or Example	Your Answers: Defaults (*)
Language		Select from the list of available languages for the OpenSolaris software.	English*
Locale		Select your geographic region from the list of available locales.	
Terminal		Select the type of terminal that you are using from the list of available terminal types.	
Network connection		Is the system connected to a network?	<ul style="list-style-type: none"> <li>• Networked</li> <li>• Non-networked*</li> </ul>
DHCP		Can the system use Dynamic Host Configuration Protocol (DHCP) to configure its network interfaces?	<ul style="list-style-type: none"> <li>• Yes</li> <li>• No*</li> </ul>
If you are not using DHCP, note the network address:	IP address	If you are not using DHCP, supply the IP address for the system. Example: 129.200.9.1	
	Subnet	If you are not using DHCP, is the system part of a subnet? If yes, what is the netmask of the subnet? Example: 255.255.0.0	255.255.0.0*
	IPv6	Do you want to enable IPv6 on this machine?	<ul style="list-style-type: none"> <li>• Yes</li> <li>• No*</li> </ul>
Host name		Choose a host name for the system.	
Kerberos		Do you want to configure Kerberos security on this machine? If yes, gather this information:	<ul style="list-style-type: none"> <li>• Yes</li> <li>• No*</li> </ul>
		Default realm:	
		Administration server:	
		First KDC:	
		(Optional) Additional KDCs:	

**TABLE 3-1** Worksheet for OpenSolaris Configuration (Continued)

Information for Installation		Description or Example	Your Answers: Defaults (*)
Name service	Name service	If applicable, which name service should this system use?	<ul style="list-style-type: none"><li>• NIS+</li><li>• NIS</li><li>• DNS</li><li>• LDAP</li><li>• None*</li></ul>
	Domain name	Provide the name of the domain in which the system resides.	
	NIS+ and NIS	Do you want to specify a name server, or let the installation program find one?	<ul style="list-style-type: none"><li>• Specify One</li><li>• Find One*</li></ul>
	DNS	Provide IP addresses for the DNS server. You must enter at least one IP address, but you can enter up to three addresses.  You can also enter a list of domains to search when a DNS query is made.	
		Search domain: Search domain: Search domain:	
LDAP			
	LDAP	Provide the following information about your LDAP profile:	
		Profile name:	
		Profile server:	
		If you specify a proxy credential level in your LDAP profile, gather the following information: Proxy-bind distinguished name: Proxy-bind password:	

**TABLE 3-1** Worksheet for OpenSolaris Configuration (*Continued*)

Information for Installation	Description or Example	Your Answers: Defaults (*)
Default route	<p>Do you want to specify a default route IP address, or let the OpenSolaris installation program find one?</p> <p>The default route provides a bridge that forwards traffic between two physical networks. An IP address is a unique number that identifies each host on a network.</p> <p>You have the following choices:</p> <ul style="list-style-type: none"><li>• You can specify the IP address. An <code>/etc/defaultrouter</code> file is created with the specified IP address. When the system is rebooted, the specified IP address becomes the default route.</li><li>• You can let the OpenSolaris installation program detect an IP address. However, the system must be on a subnet that has a router that advertises itself by using the Internet Control Message Protocol (ICMP) for router discovery. If you are using the command-line interface, the software detects an IP address when the system is booted.</li><li>• You can select None if you do not have a router or do not want the software to detect an IP address at this time. The software automatically tries to detect an IP address on reboot.</li></ul>	<ul style="list-style-type: none"><li>• Specify One</li><li>• Detect One</li><li>• None*</li></ul>
Time zone	How do you want to specify your default time zone?	<ul style="list-style-type: none"><li>• Geographic region*</li><li>• Offset from GM</li><li>• Time zone file</li></ul>
Root password	Choose a root password for the system.	

---

# Configuring the Preinstalled OpenSolaris Operating System

---

**Note** – If your system contains a service processor, you need to set it up before you perform this procedure. If you have not done so, see [“Before You Begin” on page 27](#).

---

Use the information that you gathered in [“Installation Worksheet” on page 28](#) as you perform the configuration.

After configuring the server ILOM service processor (SP), you can configure the preinstalled OpenSolaris Operating System (OS) over the network using Secure Shell (SSH) or locally using the SER MGT port to connect to the system console.

Configuration instructions, see the following topics:

- [“Accessing the System Over the Network” on page 32](#)
- [“Accessing the System Locally” on page 33](#)
- [“Configure the Preinstalled OpenSolaris Operating System” on page 34](#)
- [“Redirect the Console Output to the Video Port \(Optional\)” on page 35](#)
- [“To Modify the GRUB Menu to Auto Boot \(Optional\)” on page 36](#)

## ▼ Accessing the System Over the Network

---

**Note** – This procedure can be used only for systems that contain an SP module.

---

### 1. Log in to ILOM:

- a. In a networked terminal window, enter `ssh root@<IP_address>`

Where `<IP_address>` is internet address of the server in the format xxx.xxx.xxx.xxx.

- b. At the password prompt, enter the default password **changeme**.

ILOM displays a default command prompt (`- >`), indicating that you have successfully logged in to ILOM.

2. Verify that the communication properties of the service processor are set to the defaults.

For example:

```
-> show /SP/serial/host
/SP/serial/host
  Targets:

  Properties:
    commitpending = (Cannot show property)
    pendingspeed = 9600
    speed = 9600

  Commands:
    cd
    show
```

---

**Note** – If the speed is anything other than 9600, change it using this command:

```
-> set /SP/serial/host pendingspeed=9600 commitpending=true
```

---

3. Start the serial console mode by entering the following:

```
-> start /SP/console
```

Only accounts with Administrator privileges are enabled to configure the SP.

4. When the following prompt appears, type **y**:

```
Are you sure you want to start /SP/console (y/n)? y
```

## ▼ Accessing the System Locally

---

**Note** – This procedure can be used for systems that contain an SP and systems that do not contain an SP. If your system *does not* contain an SP module, skip [Step 3](#) and [Step 4](#) and continue with instructions in “[Configure the Preinstalled OpenSolaris Operating System](#)” on page 34.

---

1. Use a cable to connect the SER MGT port of the host server to the serial port of the client system.
2. To access the system console, start a terminal session using one of the following methods:

- **From a Solaris client:**

Type the appropriate command to start a terminal session. For example, you can start a terminal session on a OpenSolaris console by typing:

```
$tip -9600 /dev/ttya
```

- **From a Windows client:**

Open the appropriate program to start a terminal session. For example, you can start a terminal session on a Windows console by selecting:

```
Start -> Programs -> Accessories -> Communications ->  
Hyperterminal
```

- **From a Linux client:**

Type the appropriate command to start a terminal session. For example, to start a terminal session on a Linux console, you could launch Minicom.

Minicom is a text-based serial communication program that is included in the Linux distributions. For more information, see the man pages included in the Linux distribution.

3. **Press Enter on the terminal device to establish a connection between the terminal device and the ILOM SP.**

ILOM displays a login prompt, after a short wait.

```
login:
```

---

**Note** – If you connect to the serial port on the server before the ILOM SP has been powered on or during its power-on sequence, SP boot messages might be displayed prior to the login prompt.

---

4. **Type the default user name and password to log in to the ILOM SP.**

```
Username: root
```

```
Password: changeme
```

ILOM displays a default command prompt (- >), indicating that you have successfully logged in to ILOM.

## ▼ **Configure the Preinstalled OpenSolaris Operating System**

1. **Press and release the main Power button on the server front panel.**

Power-on self-test (POST) messages appear on your screen as the OS boots up.

2. **Follow the OpenSolaris preinstallation on-screen prompts.**

3. Use the information gathered in [“Installation Worksheet” on page 28](#) to help you enter the system and network information as you are prompted.

The screens that are displayed will vary, depending on the method that you chose for assigning network information to the server (DHCP or static IP address).

After you have entered the system configuration information, the server completes the boot process and displays the OpenSolaris login prompt.

## ▼ Redirect the Console Output to the Video Port (Optional)

GRUB, the open source boot loader, is the default boot loader in the OpenSolaris OS for x86-based or x64-based systems. The boot loader is the first software program that runs after you power on a system.


---

**Note** – If your server *does not* contain an SP module or an optional video card, connect the monitor to the server serial port. Video is routed to the server serial port in systems that do not contain an SP or a video card.

---

1. Connect to the server over the network or locally as described in these procedures:
  - [“Accessing the System Over the Network” on page 3-32](#)
  - [“Accessing the System Locally” on page 3-33](#)
2. From the GRUB menu, you have the option of displaying the installation process to a ttya connection (Serial Port) or a VGA connection (video port) (see [FIGURE 3-1](#)).

**FIGURE 3-1** OpenSolaris GRUB Menu Screen



**3. To display output to the video port, choose this option:**

OpenSolaris 2009.06 Graphics Adapter

## ▼ To Modify the GRUB Menu to Auto Boot (Optional)

The GRUB menu on the preinstalled image has been configured for an infinite timeout so that you can choose the console output on power-up. However, you can modify this setting so that your system boots automatically.

To modify the GRUB menu to auto boot, edit the `/rpool/boot/grub/menu.lst` file as follows:

**1. Change the `-1` value on the `timeout` line to reflect the duration you want the menu to be presented.**

For example, for a 10-second delay, change the timeout value to 10.

**2. Add a line that specifies the default boot entry.**

For example, to specify the first entry, add `default 10`.




---

# Getting Started on OpenSolaris

For information on getting started on OpenSolaris, click the Start Here icon on the OpenSolaris Desktop (see [FIGURE 3-2](#)).

**FIGURE 3-2** OpenSolaris Desktop



---

## OpenSolaris Operating System User Information

This section provides pointers to information about the OpenSolaris Operating System.

### OpenSolaris User Documentation

You can access the various collections of the OpenSolaris OS user documentation at:

<http://opensolaris.org/os/documentation/>

# OpenSolaris Training

Sun provides flexible training options that accommodate your personal schedule and learning style. The training options include instructor-led, web-based online, CD-ROM, and Live Virtual Class. For OpenSolaris Training and Certification options at a glance, go to:

<http://www.opensolaris.com/learn/subscriptions/>

---

## Using the OpenSolaris Installation Program

The documentation listed in this section provides instructions for using the OpenSolaris installation program and is available at the following web site:

<http://dlc.sun.com/osol/docs/content/2009.06/getstart/index.html>

After you configure the preinstalled OpenSolaris OS, the OpenSolaris installation program reboots the system and prompts you to log in.

---

## Reinstalling the OpenSolaris Operating System

If you want to reinstall the OpenSolaris OS or install a different version of the OpenSolaris OS, refer to *Getting Started With OpenSolaris 2009.06* at:

<http://dlc.sun.com/osol/docs/content/2009.06/getstart/>

## Download OpenSolaris Operating System

You can download software for the OpenSolaris OS from the following sites:

- To download the OpenSolaris OS, go to:

<http://opensolaris.org/os/TryOpenSolaris/>

- To download support repository updates (SRUs), which contain the latest released bug fixes for the OpenSolaris OS, go to:

<http://sunsolve.sun.com/show.do?target=opensolaris>

# Configuring the Preinstalled Solaris 10 Operating System

---

This chapter explains the steps for configuring the Solaris™ 10 Operating System (OS) that is preinstalled on the hard disk drive (or solid state drive), if ordered. The preinstalled version is Solaris 10 10/08 or later.

---

## Before You Begin

Before you begin configuring the preinstalled OS, you need to do the following:

1. If your system contains a service processor (SP) module, perform initial configuration of the server's Integrated Lights Out Manager (ILOM) service processor and determine the server's network settings, as described in ["Connecting to the ILOM Service Processor" on page 17](#).
2. Gather the information that you will need for the configuration, as listed in ["Installation Worksheet" on page 40](#).
3. Select your console output. For details, see ["Selecting Your Console Output" on page 43](#).

# Installation Worksheet

Use the worksheet in [TABLE 4-1](#) to gather the information you need to configure the preinstalled Solaris 10 OS. You need to collect only the information that applies to your application.

**TABLE 4-1** Installation Worksheet for Preinstalled Solaris 10 OS

Information for Installation		Description or Example	Your Answers: Defaults are noted with an asterisk. (*)
Language		Choose from the list of available languages for the Solaris 10 software.	English*
Locale		Choose your geographic region from the list of available locales.	English (C - 7-bit ASCII)*
Terminal		Choose the type of terminal that you are using from the list of available terminal types.	
Network connection		Is the system connected to a network?	<ul style="list-style-type: none"> <li>• Networked</li> <li>• Non-networked*</li> </ul>
DHCP		Can the system use Dynamic Host Configuration Protocol (DHCP) to configure its network interfaces?	<ul style="list-style-type: none"> <li>• Yes</li> <li>• No*</li> </ul>
If you are not using DHCP, note the network address:	IP address	If you are not using DHCP, supply the IP address for the system. Example: 129.200.9.1	
	Subnet	If you are not using DHCP, is the system part of a subnet? If yes, what is the netmask of the subnet? Example: 255.255.0.0	255.255.0.0*
	IPv6	Do you want to enable IPv6 on this machine?	<ul style="list-style-type: none"> <li>• Yes</li> <li>• No*</li> </ul>
Host name		A host name that you choose for the system.	
Kerberos		Do you want to configure Kerberos security on this machine? If yes, gather the following information: <div style="text-align: right;">             Default Realm:              Administration Server:              First KDC:              (Optional) Additional KDCs:           </div>	<ul style="list-style-type: none"> <li>• Yes</li> <li>• No*</li> </ul>

**TABLE 4-1** Installation Worksheet for Preinstalled Solaris 10 OS (*Continued*)

Information for Installation		Description or Example	Your Answers: Defaults are noted with an asterisk. (*)
Name service: if the system uses a name service, provide the following information.	Name service	Which name service should this system use?	<ul style="list-style-type: none"> <li>• NIS+</li> <li>• NIS</li> <li>• DNS</li> <li>• LDAP</li> <li>• None*</li> </ul>
	Domain name	Provide the name of the domain in which the system resides.	
	NIS+ and NIS	Do you want to specify a name server or let the installation program find one?	<ul style="list-style-type: none"> <li>• Specify One</li> <li>• Find One*</li> </ul>
	DNS	Provide IP addresses for the DNS server. You must enter at least one IP address, but you can enter up to three addresses.  You can also enter a list of domains to search when a DNS query is made.  <div style="text-align: right;">             Search Domain:              Search Domain:              Search Domain:           </div>	
	LDAP	Provide the following information about your LDAP profile:  <div style="text-align: right;">             Profile name:              Profile server:           </div> If you specify a proxy credential level in your LDAP profile, gather this information: <div style="text-align: right;">             Proxy-Bind Distinguished Name:              Proxy-Bind Password:           </div>	

**TABLE 4-1** Installation Worksheet for Preinstalled Solaris 10 OS (*Continued*)

Information for Installation	Description or Example	Your Answers: Defaults are noted with an asterisk. (*)
Default route	<p>Do you want to specify a default route IP address or let the Solaris installation program find one?</p> <p>The default route provides a bridge that forwards traffic between two physical networks. An IP address is a unique number that identifies each host on a network. You have the following choices:</p> <ul style="list-style-type: none"><li>• You can specify the IP address. An <code>/etc/defaultrouter</code> file is created with the specified IP address. When the system is rebooted, the specified IP address becomes the default route.</li><li>• You can let the Solaris installation program detect an IP address. However, the system must be on a subnet that has a router that advertises itself by using the ICMP router discovery protocol. If you are using the command-line interface, the software detects an IP address when the system is booted.</li><li>• You can choose None if you do not have a router or do not want the software to detect an IP address at this time. The software automatically tries to detect an IP address on reboot.</li></ul>	<ul style="list-style-type: none"><li>• Specify One</li><li>• Detect One</li><li>• None*</li></ul>
Time zone	How do you want to specify your default time zone?	<ul style="list-style-type: none"><li>• Geographic region*</li><li>• Offset from GM</li><li>• Time zone file</li></ul>
Root password	Choose a root password for the system.	

## Selecting Your Console Output

Unlike with SPARC® systems, you will *not* see the output of the preinstalled Solaris 10 image through a monitor when you power on the server. Instead, the output of the preinstalled image is directed to a *serial console*.

---

**Note** – If your server *does not* contain an SP module or an optional video card, connect the monitor to the server serial port. Video is routed to the server serial port in systems that do not contain an SP or a video card.

---

GRUB, the open source boot loader, is the default boot loader. The boot loader is the first software program that runs after you power on a system.

From the GRUB menu, you have the option of displaying the installation process to a VGA connection (video port), as shown below.

```
*****
* Solaris 10 10/08 s10x_u6wos_07b X86 - Serial Port (ttya) *
* Solaris 10 10/08 s10x_u6wos_07b X86 - Graphics Adapter *
* Solaris failsafe *
* *
* *
* *
* *
* *
*****
```

---

**Note** – The first line of the above figure shows the default startup mode.

---

### *Example*

To display output to the video port, choose the following option:

```
Solaris 10 10/08 s10x_u6wos_07b X86 - Graphics Adapter
```

---

# Configuring the Preinstalled Solaris 10 Operating System

---

**Note** – If your system contains a service processor, you need to set it up before you perform this procedure. If you have not done so, see [“Before You Begin” on page 39](#).

---

Use the information that you gathered in [“Installation Worksheet” on page 40](#) as you perform the configuration.

After configuring the ILOM SP, you can configure the preinstalled Solaris 10 Operating System (OS) by using another system to connect to the server, or install a Linux or Windows platform operating system. The possible ways to do this are described here:

- [“To Connect to the Server Using the Service Processor’s IP Address” on page 45](#)  
If you use this method, you first need to determine the service processor’s IP address and the server must be connected to the network. This procedure can be used only for systems that contain an SP module.
- [“To Connect to the Server Using a Terminal Program” on page 46](#)  
If you use this method, you do *not* need to determine the service processor’s IP address, but you will need to have a cable connection from the server to the serial port of a host system. This procedure can be used for systems that contain an SP and systems that do not contain an SP.
- If you want to install a supported Linux or Solaris OS and the required drivers, refer to the *Sun Fire X2270 Server Operating System Installation Guide* (820-5606).
- If you want to install a supported Windows OS and the required drivers, refer to the *Sun Fire X2270 Server Windows Operating System Installation Guide* (820-7143).
- For additional OS considerations specific to this server, refer to the *Sun Fire X2270 Server Product Notes* (820-5608).



## ▼ To Connect to the Server Using the Service Processor's IP Address

---

**Note** – This procedure assumes that you have connected the server to your network through an Ethernet cable. This procedure can be used only for systems that contain an SP module.

---

1. **Verify that the communication properties of the serial port of the system are set to the defaults.**

The default settings are 9600 baud, 8N1 (eight data bits, no parity, one stop bit), disable flow control.

2. **If you have not already done so, determine the service processor's IP address:**

- a. **Press and release the Power button on the server front panel.**

Power-on self-test (POST) messages appear on your screen as the OS boots.

- b. **Initialize the BIOS Setup utility by pressing the F2 key while the system is performing the power-on self-test (POST).**

- c. **When the main BIOS screen is displayed, select Advanced.**

- d. **When the Advanced screen is displayed, select IPMI 2.0 Configuration.**

- e. **When the IPMI 2.0 Configuration screen is displayed, select LAN Configuration.**

- f. **Select the IP Address menu item.**

The service processor's IP address is displayed using the following format:  
Current IP address in BMC: xxx.xxx.xxx.xxx

3. **Using a client system, establish a Secure Shell (SSH) connection to the service processor's IP address and log in as an Administrator. Type:**

```
# ssh -l root sp_ip_address
```

password: **changeme**

You can connect to the ILOM service processor CLI, using the serial management port on the rear of the server, or by using SSH over the network.

4. **To access the server serial port, you must connect to the ILOM service processor CLI. Type:**

```
-> start /SP/console
```

A message appears prompting you to confirm that you want to start the SP console.

5. Continue the operation for starting the SP console by typing **y** (yes) and pressing Enter.

The GRUB boot loader menu appears.

6. Press and release the Power button on the server front panel.

POST messages appear on your screen as the OS boots.

7. To make Solaris output appear on the server VGA (video) port, you must select the video port from the GRUB boot loader menu, as shown on [“Selecting Your Console Output” on page 43](#).

8. If you have changed the SP serial port default settings, you must reset them to the default settings.

9. Follow the Solaris 10 on-screen prompts.

Use the information gathered in [“Installation Worksheet” on page 40](#) to help you enter the system and network information as you are prompted.

The screens that are displayed will vary, depending on the method that you chose for assigning network information to the server (DHCP or static IP address).

After you have entered the system-configuration information, the server completes the boot process and displays the Solaris login prompt. Refer to the *Sun Fire X2270 Operating Systems Installation Guide* (820-5606) for information about configuring the Solaris OS.

## ▼ To Connect to the Server Using a Terminal Program

---

**Note** – This procedure can be used for systems that contain an SP and systems that do not contain an SP. If your system *does not* contain an SP module, skip [Step 4](#) and [Step 5](#) and continue with [Step 6](#).

---

1. Use a cable to connect the serial port of the server to the serial port of the host system.
2. Verify that the communication properties of the serial port of the host system are set to the defaults.

The default settings are 9600 baud, 8N1 (eight data bits, no parity, one stop bit), disable flow control.

3. **Start a terminal session to capture the serial port output by doing one of the following:**
  - On a client running Solaris OS, type:
    - **\$tip -9600 /dev/ttya**
  - On a client running Windows, start a program such as Hyperterminal.
  - On a client running Linux, start a program such as Minicom, a text-based serial communication program that is included in the Linux distributions. For more information, see the man pages included in the Linux distribution.
4. **Log in to the service processor as an Administrator, for example:**

```
login: root
password: changeme
```
5. **Start the ILOM SP CLI by entering the following:**

```
-> start /SP/console
```
6. **Press and release the Power button on the server front panel.**

POST messages appear on your screen as the OS boots.
7. **Follow the Solaris 10 preinstallation on-screen prompts.**

Use the information gathered in [“Installation Worksheet” on page 40](#) to help you enter the system and network information as you are prompted.

The screens that are displayed will vary, depending on the method that you chose for assigning network information to the server (DHCP or static IP address).

After you have entered the system-configuration information, the server completes the boot process and displays the Solaris login prompt. Refer to the *Sun Fire X2270 Operating Systems Installation Guide* (820-5606) for information about configuring the Solaris OS.

---

## Solaris 10 Operating System User Information

This section provides pointers to information about the Solaris 10 Operating System.

## Accessing Solaris 10 OS User Documentation

You can access the various collections of the Solaris 10 OS user documentation at:

<http://docs.sun.com/app/docs/prod/solaris.10>

Specifically, you can access the Solaris 10 OS Release and Installation collection at:

<http://docs.sun.com/app/docs/coll/1236.1>

## Downloading Solaris 10 OS Software

If you need to install the Solaris 10 OS or reinstall the OS after removing it, you can download the CD or DVD image from the following site:

<http://www.sun.com/software/solaris/get.jsp>

See the *Sun Fire X2270 Server Operating System Installation Guide* (820-5606) for specific instructions on Solaris 10 OS installation.

## Solaris 10 OS Training

Sun provides flexible training options that accommodate your personal schedule and learning style. The training options include instructor-led, web-based online, CD-ROM, and Live Virtual Class. For Solaris 10 Training and Certification options at a glance, please visit:

<http://www.sun.com/training/catalog/solaris10.html>

# Index

---

## C

client-side secure shell, 17

## D

default boot loader

GRUB, 35

DVD drive

location, 7, 8

## E

Ethernet connection to service processor, 19

Ethernet connectors, location, 5

## F

fault LED, 5, 7, 8

front panel, 7, 8

## G

GRUB

default boot loader, 35

## H

hard disk drive

location, 7, 8

## I

ILOM

client-side secure shell, 17

configuring with Ethernet, 19

configuring with serial, 17

configuring with static Ethernet, 22

introduction, 15

Remote Console application, 16

service processor firmware, 16

service processor hardware, 16

software components, 16

ILOM SP

boot messages, 34

default user name and password, 34

installing to a rack, 3

Integrated Lights Out Manager, see ILOM

## O

OpenSolaris OS

downloading, 38

location of user Documentation, 37

reinstalling, 38

training options, 38

OpenSolaris preinstalled OS

configuring the preinstalled OS, 27

on-screen prompts, 34

prerequisites, 27

operating systems

OpenSolaris preinstalled OS

configuring, 27

preinstalled OS

configuring Solaris OS, 39

OS installation, references, 25

## P

PCI Express slots, 5

POST messages, 34

Power button, 7, 8

using stylus to press, 34

- power connector, 5
- power LED, 5, 7, 8

## **R**

- rack installation, 3
- rear panel connectors, 5
- rear panel LEDs, 5
- Remote Console application, 16

## **S**

- serial connection to service processor, 17
- serial connector
  - location, 5
- serial console mode
  - start command, 33
- serial management port, 5
- service processor
  - configuring with Ethernet, 19
  - configuring with serial, 17
  - default communication properties, 33
  - firmware, 16
  - hardware, 16
- Solaris 10 Operating System
  - configuring the preinstalled OS, 39
- static Ethernet configuration, 22
- system identification LED, 5, 7, 8

## **T**

- troubleshooting procedures, 10
- typographic conventions, xi

## **U**

- USB connectors
  - location, 7, 8

## **V**

- video port redirection, 35