



Sun Blade™ X6275 Server Module Getting Started

This guide summarizes the procedure you must perform to install the server module into a chassis.

Server Module Installation Summary

For detailed installation information, refer to the *Sun Blade X6275 Server Module Installation Guide*. Go to this web site: <http://docs.sun.com/app/docs/prod/blade.x6275?l=en#hic>

TABLE 1 summarizes how to install the server module into a Sun Blade modular system chassis.

TABLE 1 Installation Task Summary

Step	Task
1	Unpack the Sun Blade X6275 server module from the shipping containers and any optional components ordered.
2	Register the server module. Locate the serial number for your system on the customer information sheet on the shipping carton. Go to this web site: http://www.sun.com/service/warranty/index.xml#reg
3	If applicable, install the optional server module components before you install the server module into the chassis.
4	Install the server module into a powered-on Sun Blade modular system chassis. When you are done, the server module is in standby mode.
5	Obtain the SP IP address.
6	Set up ILOM.
7	If applicable, install an operating system.

Documentation for This Product

Find the server module documentation at this web site:
<http://docs.sun.com/app/docs/prod/blade.x6275?l=en#hic>

For translated documentation, select your language at this web site: <http://docs.sun.com>.

The following table lists the documents for the Sun Blade X6275 Server Module.

Server Module Documentation

Task	Document Name (or URL)	Part Num.
Get started, view documentation set. (This guide.)	<i>Sun Blade X6275 Server Module Getting Started Guide</i>	820-6847
Review known issues, workarounds, and new information.	<i>Sun Blade X6275 Server Module Product Notes</i>	820-6853
Connect server to chassis, configure network.	<i>Sun Blade X6275 Server Module Installation Guide</i>	820-6977
Install supported operating systems.	<i>Sun Blade X6275 Server Module Linux OS Installation Guide</i>	820-6848
Access ILOM. Set remote access. Upgrade BIOS and SP firmware. View status and event logs.	<i>Sun Integrated Lights Out Manager Supplement for Sun Blade X6275 Server Modules</i>	820-6851
Diagnose and troubleshoot the server module.	<i>Sun Blade X6275 Server Module Diagnostics Guide</i>	820-6849
Remove and replace components.	<i>Sun Blade X6275 Server Module Service Manual</i>	820-6850
Review safety information.	<i>Sun Blade X6275 Server Module Safety and Compliance Guide</i> <i>Important Safety Information for Sun Hardware Systems</i>	820-6852 816-7190
Review chassis specific information	http://docs.sun.com/app/docs/prod/blade.srvr#hic	

Sun Contact Information

Topic	URL
Patches and firmware updates	http://www.sun.com/download/
Technical support	http://www.sun.com/support/
Submitting comments	http://www.sun.com/hwdocs/feedback Please include the title and part number of your document with your feedback: <i>Sun Blade X6275 Server Module Getting Started Guide, 820-6847</i>

Copyright 2009 Sun Microsystems, Inc. All rights reserved.
Copyright 2009 Sun Microsystems, Inc. Tous droits réservés.



Sun Microsystems, Inc.
www.sun.com

Part No. 820-6847-10, Rev. A
March 2009