



VERITAS NetBackup™ 6.0

Media Manager Device Configuration Guide

for UNIX, Windows, and Linux

N15280C

September 2005

Disclaimer

The information contained in this publication is subject to change without notice. VERITAS Software Corporation makes no warranty of any kind with regard to this manual, including, but not limited to, the implied warranties of merchantability and fitness for a particular purpose. VERITAS Software Corporation shall not be liable for errors contained herein or for incidental or consequential damages in connection with the furnishing, performance, or use of this manual.

VERITAS Legal Notice

Copyright © 1995-2005 VERITAS Software Corporation. All rights reserved. VERITAS, the VERITAS Logo, and VERITAS NetBackup are trademarks or registered trademarks of VERITAS Software Corporation or its affiliates in the U.S. and other countries. Other names may be trademarks of their respective owners.

Portions of this software are derived from the RSA Data Security, Inc. MD5 Message-Digest Algorithm. Copyright 1991-92, RSA Data Security, Inc. Created 1991. All rights reserved.

VERITAS Software Corporation
350 Ellis Street
Mountain View, CA 94043
USA
Phone 650-527-8000
Fax 650-527-2908
www.veritas.com

Third-Party Copyrights

For a list of third-party copyrights, see the *NetBackup Release Notes* appendix.



Contents

| | |
|--|-----------|
| Preface | ix |
| What Is In This Guide? | ix |
| How To Use This Guide | x |
| Getting Help | x |
| Finding NetBackup Documentation | x |
| Accessing the VERITAS Technical Support Web Site | xi |
| Contacting VERITAS Licensing | xii |
| Accessibility Features | xii |
| Comment on the Documentation | xiii |
| Chapter 1. Using This Guide | 1 |
| Before You Start Configuring Devices | 1 |
| Considerations When Using This Guide | 1 |
| Use the VERITAS Support Web Site | 2 |
| Read the NetBackup Release Notes | 2 |
| General Device Configuration Sequence | 3 |
| Configuration Cautions | 3 |
| Chapter 2. Sun Solaris | 5 |
| Before You Start | 6 |
| Preventing Possible System Problems | 7 |
| Understanding the SCSI Passthru Drivers | 7 |
| Configuring SG and ST Drivers | 9 |
| Configuring the Sun StorEdge Network Foundation HBA Driver | 12 |



| | |
|---|-----------|
| Configuring Third-Party Fibre Channel HBA Drivers | 12 |
| Configuring Robotic Controls | 13 |
| Configuring SCSI Robotic Controls | 13 |
| Examples of SCSI Robotic Control Device Files | 14 |
| Configuring Tape Drives | 16 |
| Using Berkeley-Style Close | 16 |
| Fast-Tape Positioning (locate-block) | 16 |
| Enabling locate-block | 17 |
| Disabling locate-block | 17 |
| No Rewind Device Files | 17 |
| Examples of No Rewind Device Files | 18 |
| Configuring Nonstandard Tape Drives | 18 |
| Solaris Patches | 19 |
| Configuring Non-QIC Tape Drives | 19 |
| Editing the st.conf File | 19 |
| Lab-Tested st.conf Entries | 20 |
| Adding Logical Unit Number Entries | 23 |
| Configuring Optical Disk Drives | 23 |
| Configuring HP Optical Disk Drives | 23 |
| Creating Device Files | 23 |
| Examples of Optical Disk Device Files | 24 |
| Setting the HP Optical Drive Type in Nonvolatile Memory | 25 |
| Command Summary | 26 |
| Chapter 3. IBM AIX | 27 |
| Before You Start | 28 |
| RS6000 AIX Adapter Number Conventions | 28 |
| The SCSI Passthru Driver (ovpass) | 30 |
| Upgrading The SCSI Passthru Driver | 31 |
| Configuring Robotic Controls | 31 |



| | |
|---|-----------|
| Configuring SCSI Robotic Controls | 32 |
| Examples of SCSI Robotic Control Device Files | 35 |
| Configuring IBM 3590 Stacker Robotic Controls | 38 |
| Configuring Tape Drives | 38 |
| Configuring Non-QIC Tape Drives | 39 |
| Automatic Configuration | 39 |
| Using the chdev Command | 39 |
| Using Extended-File Marks for Drives | 39 |
| Automatic Configuration | 40 |
| Using the chdev Command | 40 |
| Fast-Tape Positioning (locate-block) | 40 |
| Creating No Rewind Device Files | 40 |
| No Rewind Device File Example | 42 |
| Using Multiple Tape Densities | 43 |
| Adding Sony AIT Drives | 44 |
| Configuring Optical Disk Drives | 45 |
| Creating Device Files | 45 |
| Examples of Optical Disk Device Files | 47 |
| Setting the HP Optical Drive Type in Nonvolatile Memory | 48 |
| Command Summary | 51 |
| Chapter 4. Hewlett-Packard HP-UX | 53 |
| Before You Start | 54 |
| If You Are Using NetBackup Server | 54 |
| Topics Not Applicable to NetBackup Server | 54 |
| Configuring Robotic Controls | 55 |
| Configuring SCSI Robotic Controls | 55 |
| Determining Which Passthru Driver to Configure | 55 |
| Examples | 55 |
| Configuring Device Files for the sctl Passthru Driver | 56 |



| | |
|---|---------------|
| Configuring Device Files for the spt Passthru Driver | 60 |
| Configuring Tape Drives | 62 |
| Using Berkeley Style Close | 62 |
| Using the Passthru Driver for Tape Drives | 62 |
| Automatic Configuration | 63 |
| Enabling Passthru Paths | 63 |
| Fast-Tape Positioning (locate-block) | 65 |
| Enabling locate-block | 65 |
| Disabling locate-block | 65 |
| Enabling SCSI Reserve/Release | 66 |
| Cautions with Using the HP-UX EMS Tape Device Monitor | 66 |
| No Rewind Device Files | 67 |
| No Rewind Device File Example | 67 |
| Configuring Optical Disk Drives | 68 |
| Example of an Optical Disk Device File | 68 |
| Using the Configure Storage Devices Wizard with Optical Disk Drives | 69 |
| Handling Errors when More Than 10 NetBackup Jobs are Active | 69 |
| Command Summary | 70 |
| Chapter 5. Hewlett-Packard Tru64 | 73 |
| Before You Start | 74 |
| Configuring Robotic Controls | 74 |
| Configuring SCSI Robotic Controls | 74 |
| Creating SCSI Robotic Control Device Files | 75 |
| Example of SCSI Robotic Control Device File | 75 |
| Configuring Tape Drives | 75 |
| Fast-Tape Positioning (locate-block) | 75 |
| Adding Standard Tape Drives | 76 |
| No Rewind Device File Example | 76 |
| Adding Nonstandard Tape Drives | 77 |



| | |
|--|-----------|
| Device-Specific Entry for HP Ultrium 460 | 77 |
| Device-Specific Entry for HP Ultrium 230e | 78 |
| Device-Specific Entry for Seagate Viper 200 - LTO | 79 |
| Device-Specific Entry for STK 9840 | 80 |
| Command Summary | 81 |
| Chapter 6. Enterprise Linux | 83 |
| Before You Start | 84 |
| Using the Passthru Driver | 85 |
| Enabling Passthru Paths | 86 |
| Configuring Robotic Controls | 86 |
| Configuring SCSI Robotic Control Device Paths (2.4 kernel) | 87 |
| Examples of SCSI Robotic Control Device Files | 87 |
| Configuring SCSI Robotic Control Device Paths (2.6 kernel) | 87 |
| Configuring Tape Drives | 88 |
| Adding Standard Tape Drives (2.4 kernel) | 88 |
| Examples of SCSI Tape Device Files | 88 |
| Adding Standard Tape Drives (2.6 kernel) | 89 |
| Verifying The Device Configuration | 89 |
| Other Considerations (Advanced Topics) | 89 |
| Support for Additional Tape Devices | 89 |
| Improving Performance | 90 |
| Using the Debug Mode | 90 |
| Using an Emulex HBA | 90 |
| Using Persistent Binding | 91 |
| Utilities to Test SCSI Devices | 91 |
| Command Summary | 92 |
| Chapter 7. Microsoft Windows 2000, 2003 | 93 |
| Before You Start | 94 |
| Installing Tape Device Drivers on 32 Bit Servers | 94 |



| | |
|--|-----------|
| Installing Tape Device Drivers on 64 Bit Servers | 96 |
| Index | 97 |



Preface

This guide contains configuration information for adding storage peripherals (devices) to NetBackup media servers or SAN media servers controlled by Media Manager (NetBackup master servers can also be media servers).

NetBackup (includes Media Manager) can be installed on UNIX or Windows servers. See the NetBackup release notes for information on the supported UNIX and Windows server platforms.

Media Manager is the component of VERITAS NetBackup™ and VERITAS Storage Migrator™ that is used to configure and manage media, drives, and robots that are used to store and retrieve your backup data.

The intended audience for this guide is the system administrator responsible for adding the storage peripherals to media servers, and it assumes a thorough knowledge of UNIX and Windows system and device configuration.

What Is In This Guide?

“Using This Guide” on page 1 provides important instructions for using this guide that you should read.

In addition, this guide contains a device configuration chapter for Windows and for each of the UNIX server platforms that are supported by NetBackup as media servers or SAN media servers as follows:

- ◆ “Sun Solaris” on page 5.
- ◆ “IBM AIX” on page 27.
- ◆ “Hewlett-Packard HP-UX” on page 53.
- ◆ “Hewlett-Packard Tru64” on page 73.
- ◆ “Enterprise Linux” on page 83.
- ◆ “Microsoft Windows 2000, 2003” on page 93.



How To Use This Guide

Keep the following points in mind when using this guide.

- ◆ Each server platform that is supported by NetBackup as a media server or SAN media servers is described in a separate chapter in this guide. You should only have to use the chapters for the platforms on which you are configuring devices.
- ◆ This guide is intended for use with NetBackup Server and NetBackup Enterprise Server. For readability in this guide, the term NetBackup refers to both NetBackup server types unless specifically noted.
- ◆ Portions of this guide apply only to a specific NetBackup server type (for example, NetBackup Enterprise Server). These topics are identified with the use of italics, as in the following example:

This is a NetBackup Enterprise Server topic.

- ◆ Portions of this guide include topics and examples that may not be applicable to your system hardware configuration. It is important to refer to the VERITAS support web site and the NetBackup release notes to determine if your hardware configuration is supported by your NetBackup server type before using this guide.

Getting Help

You can find answers to questions and get help from the NetBackup documentation and from the VERITAS technical support web site.

Finding NetBackup Documentation

A list of the entire NetBackup documentation set appears as an appendix in the *NetBackup Release Notes*. All NetBackup documents are included in PDF format on the NetBackup Documentation CD.

For definitions of NetBackup terms, consult the online glossary.

▼ To access the NetBackup online glossary

1. In the NetBackup Administration Console, click **Help > Help Topics**.
2. Click the **Contents** tab.
3. Click **Glossary of NetBackup Terms**.

Use the scroll function to navigate through the glossary.



Accessing the VERITAS Technical Support Web Site

The address for the VERITAS Technical Support Web site is <http://support.veritas.com>.

The VERITAS Support Web site lets you do any of the following:

- ◆ Obtain updated information about NetBackup, including system requirements, supported platforms, and supported peripherals
- ◆ Contact the VERITAS Technical Support staff and post questions to them
- ◆ Get the latest patches, upgrades, and utilities
- ◆ View the NetBackup Frequently Asked Questions (FAQ) page
- ◆ Search the knowledge base for answers to technical support questions
- ◆ Receive automatic notice of product updates
- ◆ Find out about NetBackup training
- ◆ Read current white papers related to NetBackup

From <http://support.veritas.com> you can complete various tasks to obtain specific types of support for NetBackup:

1. Subscribe to the VERITAS Email notification service to be informed of software alerts, newly published documentation, Beta programs, and other services.
 - a. From the main <http://support.veritas.com> page, select a product family and a product.
 - b. Under Support Resources, click **Email Notifications**.

Your customer profile ensures you receive the latest VERITAS technical information pertaining to your specific interests.
2. Locate the telephone support directory at <http://support.veritas.com> by clicking the **Phone Support** icon. A page appears that contains VERITAS support numbers from around the world.

Note Telephone support for NetBackup is only available with a valid support contract. To contact VERITAS for technical support, dial the appropriate phone number listed on the Technical Support Guide included in the product box and have your product license information ready for quick navigation to the proper support group.

3. Contact technical support using e-mail.



- a. From the main <http://support.veritas.com> page, click the **E-mail Support** icon.
A wizard guides you to do the following:
 - ◆ Select a language of your preference
 - ◆ Select a product and a platform
 - ◆ Provide additional contact and product information, and your message
 - ◆ Associate your message to an existing technical support case
- b. After providing the required information, click **Send Message**.

Contacting VERITAS Licensing

For license information, you can contact us as follows:

- ◆ Call 1-800-634-4747 and select option 3
- ◆ Fax questions to 1-650-527-0952
- ◆ In the Americas, send e-mail to amercustomercare@veritas.com
In the Asia and Pacific areas, send email to apaccustomercare@veritas.com.
In all other areas, send email to internationallicense@veritas.com.

Accessibility Features

NetBackup contains features that make the user interface easier to use by people who are visually impaired and by people who have limited dexterity. Accessibility features include:

- ◆ Support for assistive technologies such as screen readers and voice input (Windows servers only)
- ◆ Support for keyboard (mouseless) navigation using accelerator keys and mnemonic keys

For more information, see the *NetBackup Installation Guide*.



Comment on the Documentation

Let us know what you like and dislike about the documentation. Were you able to find the information you needed quickly? Was the information clearly presented? You can report errors and omissions or tell us what you would find useful in future versions of our manuals and online help.

Please include the following information with your comment:

- ◆ The title and product version of the manual on which you are commenting
- ◆ The topic (if relevant) on which you are commenting
- ◆ Your comment
- ◆ Your name

Email your comment to NBDocs@veritas.com.

Please only use this address to comment on product documentation. See “Getting Help” in this preface for information on how to contact Technical Support about our software.

We appreciate your feedback.





Before You Start Configuring Devices

Observe the following important points before using this guide to configure media servers or SAN media servers, and devices.

Considerations When Using This Guide

- ◆ “How To Use This Guide” on page x provides additional instructions for using this guide that you should review.
- ◆ This guide is intended for use with NetBackup Server and NetBackup Enterprise Server. For readability in this guide, the term *NetBackup* refers to both NetBackup server types unless specifically noted.
- ◆ Portions of this guide apply only to a specific NetBackup server type (for example, NetBackup Enterprise Server). These topics are identified with the use of italics, as in the following example:

This is a NetBackup Enterprise Server topic.

- ◆ Read the **Before You Start** section (if applicable) of the chapters in this guide. These sections provide any important platform-specific instructions, or may contain specific instructions or limitations pertaining to NetBackup server types.
- ◆ Portions of this guide include hardware-specific topics and examples that may not be applicable to your system hardware configuration or NetBackup server type.

It is important to refer to the VERITAS support web site (see “Use the VERITAS Support Web Site” on page 2) and the NetBackup release notes (see “Read the NetBackup Release Notes” on page 2) to determine if your hardware configuration is supported before using this guide.

- ◆ The information in this guide supplements the manuals provided by hardware and operating system vendors.
- ◆ Configuration file settings found in portions of this guide were tested and are known to work, but other configuration settings may also work.



- ◆ To minimize configuration errors, you can cut/paste configuration details from the text version of this configuration guide. The formatting of this text file is similar, but is not identical to the printed version of the guide. Be sure to review the differences as explained at the beginning of the text file.

This file is installed with NetBackup Media Manager software in the following UNIX path:

```
/usr/opensv/volmgr/MediaMgr_DeviceConfig_Guide.txt.
```

This file is installed with NetBackup Media Manager software in the following Windows path:

```
\program files\VERITAS\volmgr\MediaMgr_DeviceConfig_Guide.txt.
```

Use the VERITAS Support Web Site

The VERITAS support web site (<http://www.support.veritas.com>) contains device and library compatibility information for a number of vendors and products (see the NetBackup Product > Compatibility area of the site). In addition, visit the site to determine the current support for the following:

- ◆ NetBackup Enterprise Server and NetBackup Server.
- ◆ NetBackup licensed optional software (for example, SSO).
- ◆ Your UNIX or Windows server platform.
- ◆ Your robot and drive types.

Read the NetBackup Release Notes

Each server platform that is supported by NetBackup as a media server or SAN media server is described in a separate chapter in this guide. You should have to use only the chapters for the platforms on which you are configuring devices for Media Manager. Refer to the NetBackup release notes to determine the server platforms that are supported.



General Device Configuration Sequence

Use the following general sequence when configuring your devices.

1. Physically connect the storage devices to the media server and perform any hardware configuration steps specified by the device or operating system vendor.

See the appropriate chapter of this guide for your media server or SAN media server platform.

2. For NetBackup to recognize and communicate with the connected devices, and for device discovery to discover devices, NetBackup issues SCSI pass-thru commands to the devices.

The server platforms supported by NetBackup as servers may require special operating system configuration changes. This may include changes needed for device discovery and other configuration requirements for devices to be recognized.

Create any required system device files for the drives and robotic control. Device files are created automatically on Windows and on some UNIX platforms.

See the appropriate chapter of this guide for your media server or SAN media server platform.

3. Use one of the available Media Manager configuration interfaces to add the storage devices to your Media Manager configuration.

See the *VERITAS NetBackup Media Manager System Administrator's Guide for UNIX and Linux* or the *VERITAS NetBackup Media Manager System Administrator's Guide for Windows* for instructions.

Configuration Cautions

Observe the following cautions:

- ◆ Starting with release 4.5, NetBackup uses SCSI reserve/release to improve data integrity. SCSI reserve/release operates at the SCSI target level and depends on the fibre-to-scsi bridge hardware working correctly.

The use of SCSI reserve/release is enabled by default, but can be disabled using the NetBackup Administration Console configuration GUI. See the Reference Topics appendix of the *VERITAS NetBackup Media Manager System Administrator's Guide for UNIX and Linux* or the *VERITAS NetBackup Media Manager System Administrator's Guide for Windows* for information about the NetBackup use of SCSI reserve/release.

- ◆ VERITAS does not recommend or support the use of single-ended to differential SCSI converters on Media Manager controlled devices. You may encounter problems if you use these converters.





This chapter explains how to configure storage devices for use with Media Manager running on a Solaris platform.

After configuring the hardware, use one of the available Media Manager configuration interfaces to add the drives and robots to your Media Manager configuration

The major topics included are as follows:

- ◆ “Before You Start” on page 6
- ◆ “Preventing Possible System Problems” on page 7
- ◆ “Understanding the SCSI Passthru Drivers” on page 7
- ◆ “Configuring SG and ST Drivers” on page 9
- ◆ “Configuring the Sun StorEdge Network Foundation HBA Driver” on page 12
- ◆ “Configuring Third-Party Fibre Channel HBA Drivers” on page 12
- ◆ “Configuring Robotic Controls” on page 13
- ◆ “Configuring Tape Drives” on page 16
- ◆ “Configuring Optical Disk Drives” on page 23
- ◆ “Command Summary” on page 26



Before You Start

Observe the following points when performing the configurations described in this chapter:

- ◆ The VERITAS support web site (<http://www.support.veritas.com>) contains server platform compatibility information for a number of vendors and products (see the NetBackup Product > Compatibility area of the site). Verify that your server platform is supported before configuring devices.
- ◆ For NetBackup to recognize and communicate with connected devices, and for device discovery to discover devices, NetBackup issues SCSI pass-thru commands to the devices in a configuration.

Devices must have device files, which are links to character-special files with naming conventions that are driver and HBA-dependent. NetBackup installs its own pass-through driver called SG (SCSI Generic).

This driver must be properly configured to create device files for any device used by NetBackup, or performance and functionality is limited. Each tape or optical disk drive device also has a device file that is created for use by the system tape/disk driver interface, which must exist for all read or write I/O capability.

Device files must exist that follow the naming conventions explained in “Configuring Robotic Controls” on page 13, “Configuring Tape Drives” on page 16, and “Configuring Optical Disk Drives” on page 23.

- ◆ Use `mt` and `/usr/opensv/volmgr/bin/sgscan` to verify that the devices are configured correctly. Make sure you can “see” your devices on the SAN before you install and configure the SSO option.
- ◆ When configuring devices, you should attach all peripherals and reboot the system with the reconfigure option (`boot -r` or `reboot -- -r`).
- ◆ When removing or replacing adapter cards, remove all device files previously associated with the adapter card.
- ◆ If you use the Automated Cartridge System (ACS) robotic software, you must ensure that the SunOS/BSD Source Compatibility Package is installed, so that the ACS software can make use of shared libraries in `/usr/ucblib`.
- ◆ Sun systems with parallel SCSI HBA's cannot use sixteen byte commands on any device attached to these HBA's. WORM media is not supported with these HBA's for either LTO-3 or SDLT drives. To override this rule, run:

```
touch /usr/opensv/volmgr/database/SIXTEEN_BYTE__CDB
```

Preventing Possible System Problems

When system memory is limited, Solaris unloads unused drivers from memory and reloads drivers as needed. Tape drivers are a frequent candidate for unloading, since they tend to be less heavily used than disk drivers. Depending on the timing of these unload and load events for the `st` (Sun), `sg` (VERITAS), and fibre channel drivers, various problems may result. These problems can range from devices “disappearing” from a SCSI bus to system panics.

VERITAS recommends adding the following `forceload` statements to the `/etc/system` file. These statements prevent the `st` and `sg` drivers from being unloaded from memory.

```
forceload: drv/st
forceload: drv/sg
```

Other statements may be necessary for various fibre channel drivers, such as the following example for JNI drivers. This statement prevents the named driver from being unloaded from memory.

```
forceload: drv/fcaw
```

Understanding the SCSI Passthru Drivers

NetBackup Media Manager provides its own driver for communicating with SCSI-controlled robotic peripherals. This driver is called the `SCSA` (Generic SCSI passthru driver), also referred to as the `sg` driver.

Note Since NetBackup uses its own passthru driver, the Solaris `sgen scsi` passthru driver is not supported.

The SCSI passthru driver and SCSI passthru device paths are required by NetBackup for full feature support. Performance will be degraded if SCSI passthru is not provided. The passthru driver is used

- ◆ By `avrd` and robotic processes to scan drives.
- ◆ By NetBackup and Storage Migrator for locate-block positioning.
- ◆ By NetBackup and Storage Migrator for SAN error recovery.
- ◆ By NetBackup and Storage Migrator for Quantum SDLT performance optimization.
- ◆ By NetBackup and Storage Migrator for SCSI reserve/release.
- ◆ To set the optical drive type (as explained in “Setting the HP Optical Drive Type in Nonvolatile Memory” on page 25).
- ◆ By the NetBackup device configuration GUIs to collect robot and drive information.



- ◆ To collect TapeAlert information from tape devices allowing support of functions such as tape drive cleaning.
- ◆ For WORM tape support.
- ◆ Future NetBackup features and enhancements

▼ To manipulate the sg driver

Perform the following steps as the root user.

1. Determine if an sg driver is loaded by using the following command:

```
/usr/sbin/modinfo | grep sg
```

```
141 fc580000 2d8c 116 1 sg (SCSA Generic Revision: 3.4d)
153 fc7fa000 1684 49 1 msgsys (System V message facility)
```

2. Remove the existing driver:

```
/usr/sbin/rem_drv sg
```

3. Install or reconfigure the sg driver.

- a. If configuration is needed, run the following command first:

```
/usr/bin/rm -f /kernel/drv/sg.conf
```

- b. To install the driver run the following command:

```
/usr/opensv/volmgr/bin/driver/sg.install
```

Once the driver has been installed, it is not necessary to reboot the system or run the `sg.install` command during or after each system boot.

Configuring SG and ST Drivers

This procedure contains instructions for configuring the `sg` driver for SCSI targets 0 thru 6 and 8 thru 15 for fast or wide adapter cards.

In this procedure, you execute `sg.build` to add these targets to the `st.conf`, `sg.conf` and `sg.links` files. Adjust the `-mt` and `-ml` parameters to create the range of targets and LUNs required by your configuration. See the following command summary or the more detailed explanation which follows.

▼ To configure drivers

1. Execute the `sg.build` script to add target IDs 0-6, 8-15, and LUNs 0-1 to the following files:

```
/usr/opensv/volmgr/bin/driver/st.conf
/usr/opensv/volmgr/bin/driver/sg.conf
/usr/opensv/volmgr/bin/driver/sg.links
```

```
cd /usr/opensv/volmgr/bin/driver
/usr/opensv/volmgr/bin/sg.build all -mt 15 -ml 1
```

The `-mt 15` parameter specifies the maximum target ID that is in use on any SCSI bus (or bound to a fibre channel device).

The `-ml 1` parameter specifies the maximum target LUN that is in use on any SCSI bus (or by a fibre channel device).

2. The file `/usr/opensv/volmgr/bin/driver/st.conf` is used to replace the following seven entries in the `/kernel/drv/st.conf` file:

```
name="st" class="scsi"
    target=0 lun=0;
name="st" class="scsi"
    target=1 lun=0;
name="st" class="scsi"
    target=2 lun=0;
name="st" class="scsi"
    target=3 lun=0;
name="st" class="scsi"
    target=4 lun=0;
name="st" class="scsi"
    target=5 lun=0;
name="st" class="scsi"
    target=6 lun=0;
```



- a. Make a copy of the `/kernel/drv/st.conf` file.
 - b. Edit the `/kernel/drv/st.conf` file.
Place a # in column one of each line of the seven default entries.
The temporary file `./st.conf` contains the entries that you need to insert into `/kernel/drv/st.conf`.
 - c. Reboot the system with the reconfigure option (`boot -r` or `reboot -- -r`).
 - d. Verify that the system created device nodes for all the tape devices using the following command: `ls -l /dev/rmt/*cbn`
3. The following is an example of the `/usr/opensv/volmgr/bin/driver/sg.conf` file to add targets 0-6, 8-15, and LUNs 0-1:

```
name="sg" class="scsi" target=0 lun=0;
name="sg" class="scsi" target=0 lun=1;
name="sg" class="scsi" target=1 lun=0;
name="sg" class="scsi" target=1 lun=1;
name="sg" class="scsi" target=2 lun=0;
name="sg" class="scsi" target=2 lun=1;
name="sg" class="scsi" target=3 lun=0;
name="sg" class="scsi" target=3 lun=1;
name="sg" class="scsi" target=4 lun=0;
name="sg" class="scsi" target=4 lun=1;
name="sg" class="scsi" target=5 lun=0;
name="sg" class="scsi" target=5 lun=1;
name="sg" class="scsi" target=6 lun=0;
name="sg" class="scsi" target=6 lun=1;
name="sg" class="scsi" target=8 lun=0;
name="sg" class="scsi" target=8 lun=1;
name="sg" class="scsi" target=9 lun=0;
name="sg" class="scsi" target=9 lun=1;
name="sg" class="scsi" target=10 lun=0;
name="sg" class="scsi" target=10 lun=1;
name="sg" class="scsi" target=11 lun=0;
name="sg" class="scsi" target=11 lun=1;
name="sg" class="scsi" target=12 lun=0;
name="sg" class="scsi" target=12 lun=1;
name="sg" class="scsi" target=13 lun=0;
name="sg" class="scsi" target=13 lun=1;
name="sg" class="scsi" target=14 lun=0;
name="sg" class="scsi" target=14 lun=1;
name="sg" class="scsi" target=15 lun=0;
name="sg" class="scsi" target=15 lun=1;
```



4. The following is an example of the `/usr/opensv/volmgr/bin/driver/sg.links` file to add targets 0-6, 8-15, and LUNs 0-1:

```
# begin SCSI Generic devlinks file - creates nodes in /dev/sg
type=ddi_pseudo;name=sg;addr=0,0;   sg/c\N0t010
type=ddi_pseudo;name=sg;addr=0,1;   sg/c\N0t010
type=ddi_pseudo;name=sg;addr=1,0;   sg/c\N0t110
type=ddi_pseudo;name=sg;addr=1,1;   sg/c\N0t111
type=ddi_pseudo;name=sg;addr=2,0;   sg/c\N0t210
type=ddi_pseudo;name=sg;addr=2,1;   sg/c\N0t211
type=ddi_pseudo;name=sg;addr=3,0;   sg/c\N0t310
type=ddi_pseudo;name=sg;addr=3,1;   sg/c\N0t311
type=ddi_pseudo;name=sg;addr=4,0;   sg/c\N0t410
type=ddi_pseudo;name=sg;addr=4,1;   sg/c\N0t411
type=ddi_pseudo;name=sg;addr=5,0;   sg/c\N0t510
type=ddi_pseudo;name=sg;addr=5,1;   sg/c\N0t511
type=ddi_pseudo;name=sg;addr=6,0;   sg/c\N0t610
type=ddi_pseudo;name=sg;addr=6,1;   sg/c\N0t611
type=ddi_pseudo;name=sg;addr=8,0;   sg/c\N0t810
type=ddi_pseudo;name=sg;addr=8,1;   sg/c\N0t811
type=ddi_pseudo;name=sg;addr=9,0;   sg/c\N0t910
type=ddi_pseudo;name=sg;addr=9,1;   sg/c\N0t911
type=ddi_pseudo;name=sg;addr=a,0;   sg/c\N0t1010
type=ddi_pseudo;name=sg;addr=a,1;   sg/c\N0t1011
type=ddi_pseudo;name=sg;addr=b,0;   sg/c\N0t1110
type=ddi_pseudo;name=sg;addr=b,1;   sg/c\N0t1111
type=ddi_pseudo;name=sg;addr=c,0;   sg/c\N0t1210
type=ddi_pseudo;name=sg;addr=c,1;   sg/c\N0t1211
type=ddi_pseudo;name=sg;addr=d,0;   sg/c\N0t1310
type=ddi_pseudo;name=sg;addr=d,1;   sg/c\N0t1311
type=ddi_pseudo;name=sg;addr=e,0;   sg/c\N0t1410
type=ddi_pseudo;name=sg;addr=e,1;   sg/c\N0t1411
type=ddi_pseudo;name=sg;addr=f,0;   sg/c\N0t1510
type=ddi_pseudo;name=sg;addr=f,1;   sg/c\N0t1511
# end SCSI devlinks
```

Caution The field separator between the fields `addr=x,y;` and `sg/` is a tab. The `addr=` field uses hexadecimal notation, while the `sg/` field uses decimal values.

5. Install the new sg driver configuration.

```
/usr/bin/rm -f /kernel/drv/sg.conf
/usr/opensv/volmgr/bin/driver/sg.install
```

6. Verify that the sg driver found all the robots, tape drives, and optical disk drives (see the appropriate hardware configuration sections in this chapter for instructions).



Configuring the Sun StorEdge Network Foundation HBA Driver

The StorEdge Network Foundation HBA requires special configuration to bind device World Wide port names for use by the VERITAS `sg` driver.

The script `/usr/opensv/volmgr/bin/sg.build` adds the proper entries to the `sg.links` and `sg.conf` files. Before running the script, make sure that all devices are powered on and connected to the HBA.

An example of the additional entries in `/usr/opensv/volmgr/bin/driver/sg.conf` follows:

```
name="sg" parent="fp" target=0 lun=0 fc-port-wwn="22000090a50001c8";
name="sg" parent="fp" target=0 lun=1 fc-port-wwn="22000090a50001c8";
```

An example of the additional entries in `/usr/opensv/volmgr/bin/driver/sg.links` follows:

```
type=ddi_pseudo;name=sg;addr=w22000090a50001c8,0;          sg/c\N0t\A110
type=ddi_pseudo;name=sg;addr=w22000090a50001c8,1;          sg/c\N0t\A111
```

Note Each time a new device is added or an old device removed, re-create and re-install the new `sg` configuration (see “Configuring SG and ST Drivers” on page 9).

The script `/usr/opensv/volmgr/bin/sgscan` checks for devices that are not configured, and produces output similar to the following example:

```
#WARNING: detected StorEdge Network Foundation connected devices not
          in sg configuration file:
#
#   Device World Wide Port Name 21000090a50001c8
#
#   See /usr/opensv/volmgr/MediaMgr_DeviceConfig_Guide.txt topic
#   "Configuring the Sun StorEdge Network Foundation HBA/Driver"
#   for information on how to use sg.build and sg.install
#   to configure these devices
```

Configuring Third-Party Fibre Channel HBA Drivers

Fibre channel devices should be bound to specific target IDs by modifying the HBA driver's configuration files. The binding process assures that the target ID will not change after a system reboot or a fibre channel configuration change. In some instances, VERITAS products are configured to use a specific target ID, which if changed will cause the products to fail until they are configured correctly.



The binding process is vendor and product unique. Please refer to the documentation available for your specific HBA.

The binding may be based on the fibre channel World Wide name of the port (WWPN) or the node (WWNN), or the destination ID (AL-PA or fabric assigned).

Once the selected binding is in place, the configuration proceeds in the same manner as for parallel SCSI installations (see “Configuring SG and ST Drivers” on page 9).

Note Each time a new device is added or an old device removed, the binding must be updated to the new configuration.

Configuring Robotic Controls

Robots are controlled through a SCSI or a network connection.

- ◆ SCSI control is covered in the following sections.
- ◆ Configuration of network controlled robotic libraries (for example, ACS robot types) is discussed in the appendices of the *VERITAS NetBackup Media Manager System Administrator's Guide for UNIX and Linux* or the *VERITAS NetBackup Media Manager System Administrator's Guide for Windows*.

Configuring SCSI Robotic Controls

Read this topic if you plan to use a robotic storage device that is controlled through a SCSI robotic connection. Information on supported SCSI robots (vendor models) can be found on the VERITAS support web site.

When communicating with SCSI-controlled robotic peripherals, Media Manager utilizes the SCSI Generic (*sg*) driver. This driver is provided with NetBackup.

Note You must install the *sg* driver before continuing with the instructions in this topic (see “Configuring SG and ST Drivers” on page 9 for details).

To display the device files that are available to be used through the *sg* driver, use the *sgscan* command with the *all* parameter and note the lines that indicate changer devices (robotic libraries), as in the following example:

```
# /usr/opensv/volmgr/bin/sgscan all
/dev/sg/c0t5l0: Tape (/dev/rmt/0): "HP          C1537A"
/dev/sg/c0t6l0: Cdrom: "TOSHIBA XM-5401TASUN4XCD"
/dev/sg/c1t2l0: Tape (/dev/rmt/7): "EXABYTE  EXB-85058HE-0000"
/dev/sg/c1t4l0: Tape (/dev/rmt/9): "EXABYTE  EXB-8900MH000202"
/dev/sg/c1t5l0: Changer: "EXABYTE  EXB-210"
```



```
/dev/sg/c2t210: Tape (/dev/rmt/10): "Quantum DLT4000"  
/dev/sg/c2t510: Tape (/dev/rmt/11): "QUANTUM DLT7000"  
/dev/sg/c3t010: Disk (/dev/rdisk/c1t0d0): "FUJITSU M2952ESP SUN2.1G"  
/dev/sg/c3t310: Disk (/dev/rdisk/c1t3d0): "FUJITSU M2952ESP SUN2.1G"  
/dev/sg/c4t410: Tape (/dev/rmt/4): "Quantum DLT4000"  
/dev/sg/c4t510: Tape (/dev/rmt/5): "Quantum DLT4000"  
/dev/sg/c5t010: Disk (/dev/rdisk/c5t0d0): "SONY SMO-F541"  
/dev/sg/c5t110: Disk (/dev/rdisk/c5t1d0): "SONY SMO-F541"  
/dev/sg/c5t210: Disk (/dev/rdisk/c5t2d0): "SEAGATE ST11200N SUN1.05"  
/dev/sg/c5t610: Disk (/dev/rdisk/c5t6d0): "SEAGATE ST11200N SUN1.05"  
/dev/sg/c6t310: Changer: "SONY DMS-B35"  
/dev/sg/c6t510: Tape (/dev/rmt/6): "SONY GY-2120"  
/dev/sg/c7t010: Disk (/dev/rdisk/c7t0d0): "SEAGATE ST32550W SUN2.1G"  
/dev/sg/c7t310: Disk (/dev/rdisk/c7t3d0): "MICROP 4221-09 1128RA"  
/dev/sg/c7t410: Disk (/dev/rdisk/c7t4d0): "MICROP 4221-09MZ Q4D"  
/dev/sg/c8t210: Tape (/dev/rmt/14): "Quantum DLT4000"  
/dev/sg/c8t310: Changer: "STK 9740"  
/dev/sg/c8t410: Tape (/dev/rmt/13): "STK SD-3"  
/dev/sg/c8t610: Changer: "STK 9710"  
/dev/sg/c9t010: Changer: "EXABYTE Exabyte 18D"  
/dev/sg/c9t110: Tape (/dev/rmt/15): "Quantum DLT4000"
```

Note Specific device types can be filtered from the output using other forms of `sgscan`.
Usage: `sgscan [all|basic|changer|disk|tape] [conf] [-v]`

Examples of SCSI Robotic Control Device Files

Example 1

Using the previous `sgscan` output, if the SCSI robotic control for an Exabyte 210 is SCSI ID 5 of adapter 1, use the following path:

```
/dev/sg/c1t510
```

Example 2

Using the previous `sgscan` output, if the SCSI robotic control for a Sony library is SCSI ID 3 of adapter 6, use the following path:

```
/dev/sg/c6t310
```



Example 3

Using the previous `sgscan` output, if the SCSI robotic control for an STK 9710 is SCSI ID 6 of adapter 8 and you want to use TLD robotics, use the following path:

```
/dev/sg/c8t6l0
```

Example 4

If the SCSI robotic control for a DLT2700, DLT4700, or HP C1560B was SCSI ID 5 of adapter 0, use the following path:

```
/dev/sg/c0t5l1
```

Note that logical unit number 1 is used for those devices. The `sg` driver configuration can be modified so `sgscan` lists LUN 1 devices. In the sample `sgscan` output the configuration was not modified.

Example 5

Using the previous `sgscan` output, even if the SCSI robotic control for an STK 9740 is SCSI ID 3 of adapter 8, you would not enter any path to configure ACS robotic control.

Instead, assuming ACS control over the network, enter the appropriate ACSLS Host name. If you want to use TLD robotics to control the 9740, specify the following path:

```
/dev/sg/c8t3l0
```

Example 6 (IBM 3570 B-series Robotic Libraries)

If there is one drive in the robotic library, the robotic control is LUN 1 of the drive's SCSI ID. If there are two drives, the robotic control is LUN 1 of the Drive 1 SCSI ID. The SCSI ID's are viewed and configured by using the front panel on the robot.

The robotic control for the IBM 3570 B01/B02 is TLD, so if there are two drives, they may be connected to different host systems. If this is the case, the host system which is connected to drive 1 must also have the robotic control. Also, the library should be in RANDOM mode and BASE configuration. See the operator's guide supplied with the unit for information on setting library mode and configuration.

Assume a configuration as follows:

```
# /usr/opensv/volmgr/bin/sgscan

/dev/sg/c0t0l0: Disk (/dev/rdisk/c0t0d0): "IBM    DCAS32160SUN2.1G"
/dev/sg/c0t6l0: Cdrom: "TOSHIBA XM5701TASUN12XCD"
/dev/sg/c1t5l0: Tape (/dev/rmt/1): "IBM      03570B02"
/dev/sg/c1t6l0: Tape (/dev/rmt/2): "IBM      03570B02"
```

If drive 1 is SCSI ID 5, the robotic control for the robotic library is `/dev/sg/c1t5l1`.



Example 7 (Fujitsu M8100 Stackers)

The robotic control for the Fujitsu M8100 stacker is TSH. The unit must be set up to run in SYSTEM Mode and 2LUN Mode. See the M8100 Cartridge Tape Drive product guide supplied with the unit for information on setting the library modes.

The robotic control is LUN 1 of the drive's SCSI ID. The SCSI ID's are viewed and configured by using the front panel on the stacker.

Assume a configuration as follows:

```
# /usr/opensv/volmgr/bin/sgscan

/dev/sg/clt010: Tape (/dev/rmt/0): "FUJITSU M8100AA2"
/dev/sg/clt011: Changer: "FUJITSU M8100AA2"
```

If the drive is SCSI ID 0, the robotic control for the stacker is `/dev/sg/clt011`.

Configuring Tape Drives

Read the following topics if you plan to use any peripheral with physical or virtual tape drives.

Using Berkeley-Style Close

The examples in this section use Berkeley-style close for tape drives. This is indicated by the letter `b` after the density specification. You must specify Berkeley-style close for tape devices that you configure under Media Manager.

The terms *Berkeley-style close* and *AT&T style close* refer to where a tape is left logically positioned after a close operation (in relation to a tape mark). One style leaves an application logically positioned before a tape mark and the other leaves it after. Applications must assume where the tape is left after a close in order to establish the correct orientation the next time they do a tape-position or read operation. Some operating systems allow tape devices to be configured with either type of close. NetBackup assumes it is using Berkeley-style close.

Fast-Tape Positioning (locate-block)

For AIT, DLT, Exabyte, DTF, and half-inch tape drives, Media Manager supports the SCSI `locate-block` command for positioning to a specific block on a tape. This approach improves tape-positioning greatly over the alternative method.

Enabling locate-block

NetBackup and Storage Migrator use the `locate-block` command by default if you did not uninstall the `sg passthru` driver. This uninstall procedure is explained in “Understanding the SCSI Passthru Drivers” on page 7. The driver is automatically installed with Media Manager.

Disabling locate-block

VERITAS recommends that you do not disable `locate-block` positioning. If you need to disable `locate-block` positioning, execute the following command:

```
touch /usr/openv/volmgr/database/NO_LOCATEBLOCK
```

With `locate-block` positioning disabled, NetBackup uses the `forward-space-file/record` method and Storage Migrator skips file marks.

No Rewind Device Files

When adding tape drives to a Media Manager configuration, you need only specify a no rewind on close device path. To display the tape device files that are configured on your system, use the `sgscan` command with the `tape` parameter.

```
# /usr/openv/volmgr/bin/sgscan tape
/dev/sg/c0t5l0: (/dev/rmt/0): "HP          C1537A"
/dev/sg/c1t2l0: (/dev/rmt/7): "EXABYTE  EXB-85058HE-0000"
/dev/sg/c1t4l0: (/dev/rmt/9): "EXABYTE  EXB-8900MH000202"
/dev/sg/c2t2l0: (/dev/rmt/10): "Quantum  DLT4000"
/dev/sg/c2t5l0: (/dev/rmt/11): "QUANTUM  DLT7000"
/dev/sg/c4t4l0: (/dev/rmt/4): "Quantum  DLT4000"
/dev/sg/c4t5l0: (/dev/rmt/5): "Quantum  DLT4000"
/dev/sg/c6t5l0: (/dev/rmt/6): "SONY     GY-2120"
/dev/sg/c8t2l0: (/dev/rmt/14): "Quantum  DLT4000"
/dev/sg/c8t4l0: (/dev/rmt/13): "STK      SD-3"
/dev/sg/c9t1l0: (/dev/rmt/15): "Quantum  DLT4000"
```

Note All device types can be displayed in the output using the `all` parameter with `sgscan`. This command can be helpful for associating tape devices with other SCSI devices that may be configured on the same adapter. Usage: `sgscan [all|basic|changer|disk|tape] [conf] [-v]`



No rewind on close device files are in the `/dev/rmt` directory, and have the following format:

```
/dev/rmt/LOGICAL_DRIVE cbn
```

Where:

- ◆ `LOGICAL_DRIVE` is the logical drive id, as shown by the `sgscan` command.
- ◆ `c` indicates compression.
- ◆ `b` indicates Berkeley-style close.
- ◆ `n` indicates no rewind on close.

Examples of No Rewind Device Files

Example 1

Using the `sgscan` output, if an Exabyte 8505C drive is SCSI ID 2 of adapter 1, the device path you use follows:

```
/dev/rmt/7cbn
```

Example 2

Using the `sgscan` output, if a DLT7000 drive is SCSI ID 5 of adapter 2, the device path you use follows:

```
/dev/rmt/11cbn
```

Configuring Nonstandard Tape Drives

Nonstandard drive types may require changes to the kernel before you can use them on some levels of Solaris. The `st.conf` file must be edited and an entry must be added for any drive types you are using that are not supported by Solaris or if you want to use any of the VERITAS lab-tested drive entries. See “Editing the `st.conf` File” on page 19 and “Lab-Tested `st.conf` Entries” on page 20.

Depending on your Solaris system level, you may be able to use some tape drives without editing the entries in this file. Solaris operating systems have built-in defaults for drives that may be used. Note that the drive must be natively supported by Solaris in a manner that is compatible with NetBackup.

Refer to the header section of your `st.conf` file for a list of drives that are natively supported in the Solaris kernel.



Solaris Patches

Some drives (for example, Quantum SDLT600) require Solaris patches for support. In these cases VERITAS lists the required patches for the drive on the VERITAS support web site (<http://www.support.veritas.com>). Device and library compatibility information for a number of vendors and products is available (see the NetBackup Product > Compatibility area of the site).

Configuring Non-QIC Tape Drives

The terms *variable mode* or *fixed mode* refer to the behavior of reads and writes and the way the kernel packs physical tape records into logical tape records for an application. Variable-mode devices allow more flexibility in reading previously written tapes. Many tape devices can be accessed in either mode. NetBackup assumes variable mode for non-QIC drives.

Caution As shown by the `st.conf` entries, you must configure non-QIC tape drives as variable-mode devices, if they are to be used by Media Manager. Otherwise NetBackup is able to write data, but may not be able to read it correctly. During a read, you may see a “not in tar format” error.

Editing the `st.conf` File

Review the following important points when editing this file:

- ◆ Each valid drive entry in the `st.conf` file consists of two sections (the drive-entry-list and the list of data-property-names). The last field of each entry in the drive-entry-list is a link (data-property-name) to the corresponding entry in the list of data-property-names.
- ◆ Each valid entry in the drive-entry-list requires a comma (,) at the end of the line, unless it is the last uncommented drive in the list. In this case, the line must end with a semi-colon (;).

Each valid entry in the list of data-property-names contains a semi-colon (;) at the end of the line.

- ◆ Uppercase and lowercase are significant. For example, using `Hp` instead of `HP` is not valid.
- ◆ Spaces are significant within quoted strings.

Note that the vendor name of the vendor/product field must always be the first eight characters of the field. The following example entry shows the vendor/product field for an HP C1533A drive. The correct vendor name is `HP` + six spaces.

```
"HP      C1533A",
```



If you were to omit four of the spaces in the vendor name as shown in the following example, the drive would not be recognized correctly. The incorrect vendor name used would be HP + 2 spaces + C153.

```
"HP  C1533A",
```

- ◆ The best way to ensure that your entries are accurate is to copy them from the `MediaMgr_DeviceConfig_Guide.txt` file into the `st.conf` file.

See “Considerations When Using This Guide” on page 1.

- ◆ After making any changes, verification with a test backup and restore should be done. Incorrect entries in this file may result in data loss.

Lab-Tested st.conf Entries

The following entries were tested by VERITAS and are known to work, but other settings may also work for these drives in your configuration.

```
tape-config-list =
```

```
"ARCHIVE VIPER 150", "Archive 150 Tape", "ARCHIVE_VIP",
"BNCHMARKDLT1", "Benchmark DLT1", "BM-DLT",
"Compaq DLT8000", "Quantum DLT8000 Tape Drive", "DLT8k-data",
"COMPAQ SuperDLT1", "Compaq SuperDLT", "SDLT-data",
"COMPAQ SDLT320", "COMPAQ SuperDLT drive", "SDLT-320",
"DEC DLT2000", "DEC DLT Tape Drive", "DEC-DLT",
"DEC DLT2700", "DEC DLT Tape Stacker", "DEC-DLT",
"DEC TZ89", "DEC DLT Tape Drive", "Q-DLT7000",
"EXABYTE EXB8500C", "Exabyte EXB-8500C 8mm Helical Scan", "EXB-8500C",
"EXABYTE EXB-8505", "Exabyte EXB-8505 8mm Helical Scan", "EXB-8505",
"EXABYTE EXB-8500", "Exabyte EXB-8500 8mm Helical Scan", "EXB-8500",
"EXABYTE EXB-8900", "Exabyte EXB-8900 Mammoth", "EXB-8900",
"EXABYTE Mammoth2", "Mammoth2 8MM Helical Scan Drive", "EXB-MAMMOTH2",
"FUJITSU M2488", "Fujitsu M2488", "FJ-D3",
"FUJITSU M8100", "Fujitsu M8100 1/2 Inch Cartridge", "FJ-M8100",
"HP HP354", "HP 4mm DAT Drive", "HP-DAT",
"HP C1533A", "HP DAT Autoloader", "HP-DAT",
"HP C1557A", "HP Dat DDS3 Autoloader", "HP-DAT-DDS3",
"HP C5683A", "HP DDS-4 4mm DAT", "HP_DAT_4",
"HP Ultrium", "HP Ultrium", "Ultrium",
"HP Ultrium 2-SCSI", "HP Ultrium", "ULTRIUM2",
"IBM 03590", "IBM 3590 1/2 Inch Cartridge", "IBM-3590",
"IBM 03570", "IBM 3570 1/2 Inch Cartridge", "IBM-3590",
"IBM 03590H", "IBM 3590H 1/2\" Cartridge", "CLASS_3590",
"IBM 03592", "IBM 3592", "CLASS_3592",
"IBM ULTRIUM-TD1", "IBM Ultrium", "CLASS_3580",
"IBM ULT3580-TD1", "IBM 3580 Ultrium", "CLASS_3580",
```



```

"IBM      ULT3580-TD2", "IBM 3580 Ultrium-2", "CLASS_LTO2",
"IBM      Ultrium-TD2", "IBM Ultrium-2", "CLASS_LTO2",
"SEAGATE  ULTRIUM06242-XXX", "Seagate LTO", "SEAGATE_LTO",
"SONY     GY-2120", "Sony DTF Drive", "gy20-data",
"SONY     GY-8240", "DTF2", "gy2120-data",
"SONY     SDX-300C", "SONY 8mm AIT", "SONY_AIT",
"SONY     SDX-400C", "SONY 8mm AIT", "SONY_AIT",
"SONY     SDX-500C", "SONY 8mm AIT2", "SONY_AIT",
"SONY     SDX-700C", "Sony AIT3 8mm", "SONY_AIT3",
"SONY     SDZ-100", "SONY S-AIT", "SONY_SAIT",
"SONY     SDZ-130", "SONY S-AIT FC", "SONY_SAIT",
"SONY     TSL-A300C", "SONY 8mm AIT", "SONY_AIT",
"SONY     TSL-A500C", "SONY 8mm AIT2", "SONY_AIT",
"STK      4781", "STK 1/2 Inch Cartridge (4480)", "STK-4781",
"STK      4791", "STK 1/2 Inch Cartridge (Silverton)", "STK-4791",
"STK      4890", "STK 1/2 Inch Cartridge (Twin Peaks)", "STK-4890",
"STK      9840", "STK 1/2 Inch Cartridge (9840)", "STK-9840",
"STK      T9840B", "STK 1/2 Inch Cartridge (9840B)", "STK-9840",
"STK      T9840C", "STK 1/2 Inch Cartridge (9840C)", "STK-9840",
"STK      T9940A", "STK 60 Gig Tape Drive", "CLASS_STK",
"STK      SD-3", "STK 1/2 Inch Cartridge (Redwood)", "STK-SD-3",
"STK      T9940A", "STK 60 Gig Tape Drive", "CLASS_STK",
"STK      T9940B", "STK 60 Gig Tape Drive", "CLASS_STK",
"SUN      DLT4000", "SUN DLT Tape Drive", "DEC-DLT",
"SUN      DLT7000", "SUN DLT7000 Tape Drive", "Q-DLT7000",
"TANDBERGSLR5 4/8GB", "Tandberg 8 Gig QIC", "TAND-8G-VAR",
"TANDBERGDLT4000", "Tandberg DLT4000", "DEC-DLT",
"TANDBERGDLT7000", "Tandberg DLT7000", "Q-DLT7000",
"TANDBERGDLT8000", "Tandberg DLT8000 Tape Drive", "DLT8k-data",
"TANDBERGSuperDLT1", "TANDBERGSuperDLT1", "SDLT-data",
"Quantum  DLT2000", "Quantum DLT Tape Drive", "DEC-DLT",
"Quantum  DLT4000", "Quantum DLT Tape Drive", "DEC-DLT",
"Quantum  DLT4500", "Quantum DLT Tape Stacker", "DEC-DLT",
"Quantum  DLT4700", "Quantum DLT Tape Stacker", "DEC-DLT",
"QUANTUM  DLT7000", "Quantum DLT7000 Tape Drive", "Q-DLT7000",
"QUANTUM  DLT8000", "Quantum DLT8000 Tape Drive", "DLT8k-data",
"Quantum  DLT2700", "Quantum DLT Tape Stacker", "DEC-DLT",
"QUANTUM  SuperDLT1", "QuantumSuperDLT", "SDLT-data",
"QUANTUM  SDLT320", "Quantum SDLT320-DTE", "SDLT320",
"QUANTUM  SDLT600", "Quantum SDLT", "SDLT-600";

```

Caution Note in the list of data-property-names that the third parameter (variable mode) must be zero. Not using zero causes restores to fail and may result in data loss (the first entry, ARCHIVE_VIP, is the only exception and is 512).

```
ARCHIVE_VIP = 1,0x32,512,0x163a,4,0x0,0x0,0x0,0x0,3;
```



```
BM-DLT = 1,0x38,0,0x18639,4,0x40,0x40,0x40,0x40,3;
CLASS_3580 = 1,0x24,0,0x45863d,2,0x00,0x01,0;
CLASS_3590 = 1,0x24,0,0x1c63d,4,0x0,0x0,0x0,0x0,3;
CLASS_3592 = 1,0x24,0,0x45D639,2,0x00,0x51,0;
CLASS_LTO2 = 1,0x24,0,0x45863d,2,0x00,0x01,0;
CLASS_STK = 1,0x36,0,0x1d639,1,0x00,0;
DEC-DLT = 1,0x36,0,0x9639,4,0x0,0x0,0x0,0x0,3;
DLT8k-data = 1,0x38,0,0x19639,4,0x1a,0x1b,0x41,0x41,3;
EXB-8500C = 1,0x35,0,0x9639,4,0x14,0x15,0x8C,0x00,3;
EXB-8505 = 1,0x35,0,0x9639,4,0x14,0x15,0x8C,0x00,3;
EXB-8500 = 1,0x35,0,0x9639,4,0x14,0x00,0x00,0x15,2;
EXB-8900 = 1,0x35,0,0x9639,4,0x27,0x27,0x27,0x00,3;
EXB-MAMMOTH2 = 1,0x35,0,0x19639,4,0,0x27,0x28,0x7f,2;
FJ-D3 = 1,0x21,0,0xCA19,4,0x09,0x09,0x09,0x09,0;
FJ-M8100 = 1,0x24,0,0x1d63d,4,0x0,0x0,0x0,0x0,3;
gy20-data = 1,0x36,0,0xd659,1,0x00,0;
gy2120-data = 1,0x36,0,0x19659,1,0x00,0;
HP-DAT = 1,0x34,0,0x9639,4,0x0,0x0,0x0,0x0,3;
HP-DAT-DDS3 = 1,0x34,0,0,0x9639,4,0x0,0x8c,0x8c,0x8c,3;
HP_DAT_4 = 1,0x34,0,0x9639,4,0x00,0x8c,0x8c,0x8c,1;
IBM-3590 = 1,0x24,0,0x1c63d,4,0x0,0x0,0x0,0x0,3;
Q-DLT7000 = 1,0x38,0,0x19639,4,0x82,0x83,0x84,0x85,3;
SDLT-data = 1,0x38,0,0x19639,4,0x90,0x91,0x90,0x91,3;
SDLT-320 = 1,0x38,0,0x19639,4,0x92,0x93,0x92,0x93,3;
SDLT320 = 1,0x38,0,0x8639,4,0x90,0x91,0x92,0x93,3;
SDLT-600 = 1,0x38,0,0x19639,4,0x00,0x00,0x00,0x00,3;
SEAGATE_LTO = 1,0x36,0,0x1d639,4,0x00,0x00,0x00,0x00,1;
SONY_AIT = 1,0x36,0,0x9639,4,0x0,0x0,0x0,0x0,0;
SONY_AIT3 = 1,0x36,0,0xd679,4,0x00,0x00,0x00,0x00,0;
SONY_SAIT = 1,0x36,0,0x1d639,4,0x00,0x00,0x00,0x00,0;
STK-4781 = 1,0x24,0,0x1d43d,1,0x00,0;
STK-4791 = 1,0x24,0,0x1d67d,1,0x00,0;
STK-4890 = 1,0x24,0,0x1d67d,1,0x00,0;
STK-9840 = 1,0x36,0,0x1d639,1,0x00,0;
STK-SD-3 = 1,0x24,0,0x1d67d,1,0x00,0;
TAND-8G-VAR = 1,0x37,0,0x963b,4,0xa0,0xd0,0xd0,0xd0,3;
Ultrium = 1,0x36,0,0x19639,4,0x00,0x00,0x00,0x00,3;
ULTRIUM2 = 1,0x36,0,0xd639,4,0x40,0x00,0x00,0x00,3;
```

Note Reboot the system when you have finished changing the `st.conf` file. Use the reconfigure option (`boot -r` or `reboot -- -r`) to allow the kernel's SCSI tape (`st`) driver to recognize the drives as the correct type during system initialization.

Adding Logical Unit Number Entries

If the devices you are adding utilize the logical unit number (LUN) concept, (such as many fibre channel SAN configurations) you may also have to add entries to the following files:

- ◆ `st.conf`
- ◆ `sg.conf`
- ◆ `sg.links`

See the “Configuring SG and ST Drivers” on page 9 for information on `sg.build`, a script that is used to create these files, and examples of the proper syntax to use.

Configuring Optical Disk Drives

Read the following topics if you plan to use optical disk drives.

Configuring HP Optical Disk Drives

To use standalone HP optical-disk drives, the `sg` driver must be installed (see “Understanding the SCSI Passthru Drivers” on page 7). The system must also be configured to recognize the optical drives as disk drives at system boot time.

If you are adding HP 1.2 gigabyte or equivalent model magneto-optical disk drives, the system may not recognize these as disk drives and thus cannot use them. See “Setting the HP Optical Drive Type in Nonvolatile Memory” on page 25 for more information.

The Solaris 8 6/00 release introduced volume manager (`vold`), which attempts to manage all removable media devices. If `vold` manages an optical disk, NetBackup cannot access it.

Edit `/etc/vold.conf` and comment out the following line. Optical disks will then work as they did before this Solaris 8 change.

```
#use rmdisk drive /dev/rdsk/c*s2 dev_rmdisk.so rmdisk%d
```

Creating Device Files

When adding optical disk drives to a Media Manager configuration, you must specify the following device paths:

- ◆ Volume header disk device path (partition 0).
- ◆ Character device path (partition 6).



To display the disk device files that are configured on your system, use the `sgscan` command with the `disk` parameter:

```
# /usr/opensv/volmgr/bin/sgscan disk

/dev/sg/c0t0l0: (/dev/rdisk/c0t0d0): "IBM      DCAS32160SUN2.1G"
/dev/sg/c0t1l0: (/dev/rdisk/c0t1d0): "HP      C1113F"
/dev/sg/c0t2l0: (/dev/rdisk/c0t2d0): "HP      C1113F"
/dev/sg/c0t5l0: (/dev/rdisk/c0t5d0): "HP      C1160F"
/dev/sg/c1t0l0: (/dev/rdisk/c1t0d0): "SONY    SMO-F541"
/dev/sg/c1t1l0: (/dev/rdisk/c1t1d0): "SONY    SMO-F541"
/dev/sg/c1t2l0: (/dev/rdisk/c1t2d0): "SEAGATE ST11200N SUN1.05"
```

Note All device types can be displayed using the `all` parameter when executing `sgscan`. This command can be helpful for associating disk devices with other SCSI devices that may be configured on the same adapter. Usage: `sgscan [all|basic|changer|disk|tape] [conf] [-v]`

Optical disk device files are located in the `/dev` directory and have the following formats.

Volume header device:

```
/dev/rdisk/cADAPTERtTARGETd0s0
```

Character device:

```
/dev/rdisk/cADAPTERtTARGETd0s6
```

Where:

- ◆ `ADAPTER` is the logical adapter number as shown in the `sgscan` output.
- ◆ `TARGET` is the SCSI ID.

Examples of Optical Disk Device Files

Example 1

Using the previous sample `sgscan` output, if the desired optical disk drive connects to SCSI ID 5 of adapter card 0, you would use the following device paths:

Volume header device:

```
/dev/rdisk/c0t5d0s0
```

Character device:

```
/dev/rdisk/c0t5d0s6
```

Example 2

Using the previous sample `sgscan` output, if the desired optical disk drive connects to SCSI ID 0 of S bus 1 adapter card 1, you would use the following device paths:

Volume header device:

```
/dev/rdisk/c1t0d0s0
```

Character device:

```
/dev/rdisk/c1t0d0s6
```

Setting the HP Optical Drive Type in Nonvolatile Memory

To use HP optical disk drives, the system must recognize the optical drives as disk drives at system boot time. If you are adding HP 1.2 gigabyte or equivalent model magneto-optical disk drives, the system may not recognize these as disk drives.

▼ **To recognize these drives**

1. Install the `sg` loadable driver, if it is not already installed. See “Configuring SG and ST Drivers” on page 9 for information on installing this driver.
2. Use the `scsi_command` command to change the device type (stored in the drive’s nonvolatile memory) from optical memory to disk. The format of the command follows.

```
/usr/opensv/volmgr/bin/scsi_command -d /dev/sg/sg_id -disk
```

sg_id is the logical identifier assigned to the optical disk drive for use by the `sg` driver. See “Configuring SCSI Robotic Controls” on page 13 for information on determining the logical identifier.

Note The `/dev` path allows Media Manager to access the optical disk drive through the `sg` driver. This is an exception to the usual case where Media Manager uses the `sg` driver to access robotic controls. Therefore be sure to specify the SCSI ID for the optical disk drive, *not* the SCSI ID for the robotic control.

3. Reboot the system with the reconfigure option (`boot -r` or `reboot -- -r`) to allow the drive to be recognized as a disk drive by the kernel’s SCSI disk (`sd`) driver during system initialization.



Command Summary

The following is a summary of commands that may be useful when configuring and verifying devices. See the procedures in this chapter for examples of their usage.

```
/usr/sbin/modinfo | grep sg
```

Displays whether or not the `sg` driver is installed.

```
/usr/openv/volmgr/bin/driver/sg.install
```

Installs or updates the `sg` driver.

```
/usr/sbin/rem_drv sg
```

Uninstalls the `sg` driver. This command is usually not necessary, since `sg.install` does this before performing a driver update.

```
/usr/openv/volmgr/bin/sg.build all -mt max_target -ml max_lun
```

Updates `st.conf`, `sg.conf`, and `sg.links`, and generates SCSI Target IDs with multiple LUNs.

```
/usr/openv/volmgr/bin/sgscan all
```

Scans all connected devices with a SCSI inquiry and provides correlation between physical and logical devices using all device files in `/dev/sg`.

Also checks for devices connected to the Sun StorEdge Network Foundation HBA that are not configured for use by VERITAS products.

```
/usr/openv/volmgr/bin/scsi_command -d /dev/sg/sg_id -disk
```

Changes the device type (stored in the drive's nonvolatile memory) from optical memory to disk.

`sg_id` is the logical identifier assigned to the optical disk drive for use by the `sg` driver. See "Configuring SCSI Robotic Controls" on page 13 for information on determining the logical identifier.

```
boot -r or reboot -- -r
```

Reboot the system with the reconfigure option (`-r`) to allow a drive to be recognized as a disk drive during system initialization by the kernel's SCSI disk (`sd`) driver.



This chapter explains how to configure storage devices for use with Media Manager running on an IBM AIX system.

After configuring the hardware, use one of the available Media Manager configuration interfaces to add the drives and robots to your Media Manager configuration

The major topics included are as follows:

- ◆ “Before You Start” on page 28
- ◆ “RS6000 AIX Adapter Number Conventions” on page 28
- ◆ “The SCSI Passthru Driver (ovpass)” on page 30
- ◆ “Configuring Robotic Controls” on page 31
- ◆ “Configuring Tape Drives” on page 38
- ◆ “Configuring Optical Disk Drives” on page 45
- ◆ “Command Summary” on page 51



Before You Start

Observe the following points when performing the configurations described in this chapter:

- ◆ The VERITAS support web site (<http://www.support.veritas.com>) contains server platform compatibility information for a number of vendors and products (see the NetBackup Product > Compatibility area of the site). Verify that your server platform is supported before configuring devices.
- ◆ Attach all peripherals and reboot the system before configuring devices. Many of these steps may be accomplished using `smit` (the System Management Interface Tool). See the `smit(1)` man page for more information.
- ◆ For NetBackup to recognize and communicate with connected devices, and for device discovery to discover devices, NetBackup issues SCSI pass-thru commands to the devices in a configuration.

The `ovpass` driver must be properly configured for SCSI-controlled robot discovery, and device files must exist that follow the naming conventions explained in “Configuring Robotic Controls” on page 31, “Configuring Tape Drives” on page 38, and “Configuring Optical Disk Drives” on page 45.

- ◆ Use `smit` and `/usr/sbin/lssdev` to verify that the devices are configured correctly. Make sure you can “see” your devices on the SAN before you install and configure the SSO option.
- ◆ To obtain error and debugging information about devices and robotic software daemons, the `syslogd` daemon must be configured to be active. See `syslogd(1)` for more information.

RS6000 AIX Adapter Number Conventions

The location code for an adapter consists of two pairs of digits with the format *AA-BB*; where *AA* identifies the location code of the drawer containing the adapter card and *BB* identifies both the I/O bus and slot containing the card.

A value of 00 for *AA* means that the adapter card is located in the CPU drawer or system unit, depending on the type of system. Any other value for *AA* indicates that the card is located in an I/O expansion drawer; in which case the value for *BB* identifies the I/O bus and slot number in the CPU drawer that contains the asynchronous expansion adapter. The first digit identifies the I/O bus with 0 corresponding to the standard I/O bus and 1 corresponding to the optional I/O bus. The second digit identifies the slot on the indicated I/O bus.



The first digit of *BB* identifies the I/O bus containing the adapter card. If the card is in the CPU drawer or system unit, this digit will be 0 for the standard I/O bus or 1 for the optional I/O bus. If the card is in an I/O expansion drawer, this digit is 0. The second digit identifies the slot number on the indicated I/O bus (or slot number in the I/O expansion drawer) that contains the card.

A location code of 00-00 is used to identify the Standard I/O Planar.

Examples

00-05 identifies an adapter card that is in slot 5 of the standard I/O bus in either the CPU drawer or system unit, depending on the type of system.

00-12 identifies an adapter card that is in slot 2 of the optional I/O bus in the CPU drawer.

18-05 identifies an adapter card located in slot 5 of an I/O expansion drawer. The drawer is the one connected to the asynchronous expansion adapter located in slot 8 of the optional I/O bus in the CPU drawer.



The SCSI Passthru Driver (ovpass)

Read this topic if you plan to use SCSI-controlled robotic peripherals or HP 1.2 gigabyte or equivalent model magneto-optical disk drives.

If you are using an API robot, such as an IBM Automatic Tape Library (ATL), refer to the NetBackup Media Manager Administration guide for information on configuring the robotic peripheral.

When communicating with SCSI-controlled robotic peripherals on an IBM AIX system, Media Manager utilizes a SCSI passthru driver called `ovpass`.

The SCSI passthru driver and SCSI passthru device paths are required by NetBackup for full feature support. Performance will be degraded if SCSI passthru is not provided. The passthru driver is used

- ◆ By `avrd` and robotic processes to scan drives.
- ◆ By NetBackup and Storage Migrator for locate-block positioning.
- ◆ By NetBackup and Storage Migrator for SAN error recovery.
- ◆ By NetBackup and Storage Migrator for Quantum SDLT performance optimization.
- ◆ By NetBackup and Storage Migrator for SCSI reserve/release.
- ◆ To set the optical drive type (as explained in “Setting the HP Optical Drive Type in Nonvolatile Memory” on page 48).
- ◆ By the NetBackup device configuration GUIs to collect robot and drive information.
- ◆ To collect TapeAlert information from tape devices allowing support of functions such as tape drive cleaning.
- ◆ For WORM tape support.
- ◆ Future NetBackup features and enhancements

The `ovpass` driver is also used to set the optical drive type, as documented in “Setting the HP Optical Drive Type in Nonvolatile Memory” on page 48. `ovpass` is not required if the only device being used is the IBM 3590 B11 tape stacker.

Note You cannot use `smitty` to configure `ovpass` device files.

▼ To install the `ovpass` driver

- ❖ Enter: `/usr/opensv/volmgr/bin/driver/install_ovpass`



▼ **To ensure the driver device files are accessible after a system boot**

- ❖ Add the following command to the system startup script:
`/usr/opensv/volmgr/bin/driver/mkdev_ovpass`

▼ **To remove the ovpass driver**

- ❖ Enter: `/usr/opensv/volmgr/bin/driver/remove_ovpass`

Upgrading The SCSI Passthru Driver

Note The following upgrade procedure is required only if you get an error while trying to configure a FCP SCSI device. See step 5 on page 33 for details.

Some versions of Media Manager before release 4.5 used a version of the passthru driver that did not support FCP SCSI controllers.

Caution Any device files (`/dev/ovpassn`) will be removed and must be re-created.

▼ **To upgrade to the latest passthru driver**

1. Remove the old ovpass driver.

`/usr/opensv/volmgr/bin/driver/remove_ovpass`

2. Install the new ovpass driver.

`/usr/opensv/volmgr/bin/driver/install_ovpass`

Configuring Robotic Controls

Robots are controlled through a SCSI or a network connection.

- ◆ SCSI control is covered in the following section.
- ◆ Configuration for network controlled robotic libraries (for example, ACS robots) is discussed in the appendices of the *VERITAS NetBackup Media Manager System Administrator's Guide for UNIX and Linux* or the *VERITAS NetBackup Media Manager System Administrator's Guide for Windows*.



Configuring SCSI Robotic Controls

Read this topic if you plan to use a robotic storage device that is controlled through a SCSI robotic connection. Information on supported SCSI robots (vendor models) can be found on the VERITAS support web site (see the NetBackup Product > Compatibility area of the site).

▼ To check for and create the necessary device files

1. Install the SCSI passthru driver as explained in “The SCSI Passthru Driver (ovpass)” on page 30.
2. Display which SCSI controllers are physically available on your machine by using the following command:

```
/usr/sbin/lsdev -C | grep I/O
```

In the following sample output, SCSI controller 1 (01) has been assigned the logical identifier `scsi0`:

```
scsi0 Available 00-01 SCSI I/O Controller
```

In the following sample output, FCP SCSI controller 3A-08 has been assigned the logical identifier `fscsi0`:

```
fscsi0 Available 3A-08-01 FC SCSI I/O Controller Protocol Device
```

3. Display the SCSI device files that have already been created by using the following command:

```
/usr/sbin/lsdev -C -s scsi
```

The example output follows:

```
hdisk0 Available 00-01-00-0,0 400 MB SCSI Disk Drive
hdisk1 Available 00-01-00-1,0 400 MB SCSI Disk Drive
rmt0 Available 00-01-00-3,0 Other SCSI Tape Drive
```

This output shows that two disk drives and one tape drive are configured as follows:

- ◆ `hdisk0` is a disk drive at controller 1 (01) and SCSI ID 0 (0,0)
- ◆ `hdisk1` is a disk drive at controller 1 (01) and SCSI ID 1 (1,0)
- ◆ `rmt0` is a tape drive at controller 1 (01) and SCSI ID 3 (3,0)

If the device files for the SCSI robotic control already exist, they appear in the `lsdev` output as `ovpass0`, `ovpass1`, etc. The output for this example does not show any `ovpass` files so you would have to create them as explained in the next step.

4. Display the FCP SCSI device files that have already been created by using the following command:

```
/usr/sbin/lsdev -C -s fcp
```
5. If device files for the desired robotic control SCSI ID do not exist, create the files using the following commands.

Note If you get an error (mkdev error code 0514-0520) while trying to configure a FCP SCSI device, review the topic “Upgrading The SCSI Passthru Driver” on page 31.

```
mkdev -c media_changer -s scsi -t ovpass -p controller -w id,lun
mkdev -c media_changer -s fcp -t ovpass -p controller
      -w scsi_id,lun
```

Where:

- ◆ *controller* is the logical identifier of the drive’s SCSI adaptor, such as *scsi0*, *scsi1* or *vscsi1*.
- ◆ *id* is the SCSI ID of the robotic connection.
- ◆ *scsi_id* is the fibre channel identifier for the N_Port address (D_ID) of the robotic connection.
- ◆ *lun* is the logical unit number of the robotic connection.

Several methods exist for determining the D_ID of the robot as follows:

- ◆ Inspect the name server for the switch (if available). Each vendor uses a unique method to make this information available. Consult the documentation for the switch vendor.
- ◆ Inspect the bridge for mapping information (if available). Each vendor uses a unique method to make this information available. Consult the documentation for the bridge vendor.



- ◆ Inspect the odm database for any tape devices in the robot using the following command:

```
/usr/bin/odmget -q "name=rmtX" CuAt
```

Where *rmtX* is the name of the tape device (for example: rmt0 or rmt1).

The following output shows that rmt0 is at SCSI ID 0x1009ef and the robot might also be at this address:

```
CuAt:
name = "rmt0"
attribute = "scsi_id"
value = "0x1009ef"
type = "R"
generic = "DU"
rep = "s"
nls_index = 6
```

- ◆ Use the smc (Library Medium Changer) entry for the robot to determine the correct SCSI ID and lun values. Inspect the `lsdev` output from step 4 and look for an entry like the following:

```
smc0 Available 14-08-01 IBM 3584 Library Medium Changer
(FCP)
```

If you see an entry for the robot, inspect the odm database using the following command:

```
/usr/bin/odmget -q "name=smc0" CuAt
```

```
CuAt:
name = "smc0"
attribute = "scsi_id"
value = "0x111ca"
type = "R"
generic = "DU"
rep = "s"
nls_index = 25
```

```
CuAt:
name = "smc0"
attribute = "lun_id"
value = "0x10000000000000"
type = "R"
generic = "DU"
rep = "s"
nls_index = 26
```

From the example output, the SCSI ID is 0x111ca and the lun is 1. The lun is derived from the lun ID, by right shifting it 48 bits.



Note Note that the `smc` device file only exists for IBM robots using the Atape driver. If `smc0` device files exist for SCSI-connected IBM silos, remove the `smc0` device files to allow for the use of `ovpass0` files. See the VERITAS support site for a tech note with instructions for removing the `smc0` files. The headline of the tech note is “Install_ovpass script does not appear to work upon AIX reboot”.

6. Display the newly created logical identifier for the device by using one of the following commands:

```
/usr/sbin/lsdev -C -s scsi
/usr/sbin/lsdev -C -s fcp
```

In the following example output, `ovpass0` is a SCSI robotic control device file:

```
hdisk0 Available 00-01-00-0,0 400 MB SCSI Disk Drive
hdisk1 Available 00-01-00-1,0 400 MB SCSI Disk Drive
rmt0 Available 00-01-00-3,0 Other SCSI Tape Drive
ovpass0 Available 00-01-5,0 VERITAS Media Changer
```

The path name for these types of device files has the following form, where *ovpass_id* is the logical identifier assigned to the device.

```
/dev/ovpass_id
```

In this example, you would use the following device file path:

```
/dev/ovpass0
```

Examples of SCSI Robotic Control Device Files

Example 1

For this example, assume this robot is a LUN 0 controlled robot. The `ovpass` driver has been installed and the desired SCSI robotic controller is controller 1 at SCSI ID 5, but the device files do not exist.

1. Determine the logical identifier for the SCSI controller as follows:

```
/usr/sbin/lsdev -C -c adapter | grep SCSI
```

The following output shows that `scsi0` is the logical name for SCSI controller 1.

```
scsi0 Available 00-01 SCSI I/O Controller
```

2. Check if the device files exist for `ovpass` at SCSI ID 5.

```
/usr/sbin/lsdev -C -s scsi
```



The output shows that the device files exist for tape and disk, but not for the SCSI robotic control at controller 1 (scsi0) and SCSI ID 5 (5,0).

```
hdisk0  Available 00-01-00-0,0 400 MB SCSI Disk Drive
rmt0    Available 00-01-00-3,0 Other SCSI Tape Drive
```

3. Create the device files by using the following command:

```
mkdev -c media_changer -t ovpass -s scsi -p scsi0 -w 5,0
```

4. Display the device files by issuing the following `lsdev` command:

```
/usr/sbin/lsdev -C -s scsi
```

```
hdisk0  Available 00-01-00-0,0 400 MB SCSI Disk Drive
hdisk1  Available 00-01-00-1,0 400 MB SCSI Disk Drive
rmt0    Available 00-01-00-3,0 Other SCSI Tape Drive
ovpass0 Available 00-01-5,0    VERITAS Media Changer
```

For this example use the following device file path to configure the SCSI robotic control connected to controller 1 and SCSI ID 5:

```
/dev/ovpass0
```

Example 2

For this example, assume this robot is a LUN 1 controlled robot, rather than LUN 0. The `ovpass` driver has been installed, but the device files for SCSI robotic control at controller 1 with SCSI ID 3 and logical unit number 1 do not exist.

1. Determine the logical identifier for the SCSI controller:

```
/usr/sbin/lsdev -C -c adapter | grep -i SCSI
```

The following output shows that `scsi0` is the logical name for SCSI controller 1:

```
scsi0  Available 00-01    SCSI I/O Controller
```

2. Check if the device files exist for `ovpass` at SCSI ID 5.

```
/usr/sbin/lsdev -C -s scsi
```

The following output shows that the device files exist for tape and disk, but not for the SCSI robotic control at controller 1 (scsi0), SCSI ID 3, and logical unit number 1 (3,1):

```
hdisk0  Available 00-01-00-0,0 400 MB SCSI Disk Drive
rmt0    Available 00-01-00-3,0 Other SCSI Tape Drive
```

3. The device files can now be created using the following command:

```
mkdev -c media_changer -t ovpass -s scsi -p scsi0 -w 3,1
```



4. Display the device files by issuing the `lsdev` command.

```
/usr/sbin/lsdev -C -s scsi
```

```
hdisk0 Available 00-01-00-0,0 400 MB SCSI Disk Drive
hdisk1 Available 00-01-00-1,0 400 MB SCSI Disk Drive
rmt0 Available 00-01-00-3,0 Other SCSI Tape Drive
ovpass0 Available 00-01-3,1 VERITAS Media Changer
```

For this example, the device file to use for the TSD SCSI robotic control connected at controller 1 with SCSI ID 3 and logical unit number 1 would be:

```
/dev/ovpass0
```

Example 3

Assume the robot and drives are connected to a SCSI adapter and the passthru driver has been installed. Assume the drives are at SCSI ID's 4 and 5, and the robotics is at SCSI ID 6.

1. Determine the correct scsi controller.

```
lsdev -C | grep scsi
```

```
scsi0 Available 00-02 SCSI I/O Controller
ascsi0 Available 00-04 Wide SCSI I/O Controller Adapter
vscsi0 Available 00-04-0,0 SCSI I/O Controller Protocol Device
vscsi1 Available 00-04-0,1 SCSI I/O Controller Protocol Device
```

```
lsdev -C -c tape
```

```
rmt2 Available 00-04-01-4,0 Other SCSI Tape Drive
rmt3 Available 00-04-01-5,0 Other SCSI Tape Drive
```

2. The drives are on Adapter 00-04-01. Therefore, `vscsi1` is the correct adapter for making the `ovpass` device file as follows:

```
mkdev -c media_changer -t ovpass -s scsi -p vscsi1 -w 6,0
```

Note Never use the scsi adapter name.

Example 4 (IBM 3570 B-series Robotic Libraries)

If there is one drive in the robotic library, the robotic control is LUN 1 of the drive's SCSI ID. If there are two drives, the robotic control is LUN 1 of the Drive 1 SCSI ID. The SCSI IDs can be set or viewed using the front panel on the robot. The robotic control for the IBM 3570 B01/B02 is TLD, so if there are two drives they may be connected to different host systems.



If this is the case, the host system which is connected to Drive 1 must also have the robotic control. Also, the library should be in RANDOM mode and BASE configuration. See the operator's guide supplied with the unit for information on setting library mode and configuration.

Assume a configuration as follows:

```
lsdev -C -c tape
```

```
rmt0 Available 00-02-01-5,0 Other SCSI Tape Drive
rmt1 Available 00-02-01-6,0 Other SCSI Tape Drive
```

If drive 1 is SCSI ID 5, the robotic control for the robotic library will be LUN 1 of this SCSI ID. Assuming `vscsi1` is the correct adapter, make the passthru device (`ovpass`) as follows:

```
mkdev -c media_changer -t ovpass -s scsi -p vscsi1 -w 5,1
```

Configuring IBM 3590 Stacker Robotic Controls

If you plan to use a Tape Stacker Half-inch (TSH) robotic storage device, see the VERITAS support web site for the vendor model associated with the TSH robot type.

Perform the following steps to check for and create the necessary device files:

1. Display the SCSI tape devices configured in the system using the following command:

```
/usr/sbin/lsdev -C -c tape
```

```
rmt0 Defined 00-02-00-4,0 Other SCSI Tape Drive
rmt1 Available 00-08-00-6,0 2.3 GB 8mm Tape Drive
.
.
rmt12 Available 00-04-01-6,0 IBM 3590 Tape Drive and Medium Changer
```

2. The SCSI robotic path for the IBM 3590 is the same as the no rewind on close tape path. When configuring the TSH SCSI robotic path, the robotic control path for the 3590 would be `/dev/rmt12.1`. The tape drive path would also be `/dev/rmt12.1`.

Configuring Tape Drives

If you are using IBM tape drives, VERITAS recommends that you install the IBM AIX tape driver. Refer to the IBM documentation when using this driver.

If you are using other tape drives, VERITAS recommends that you use the IBM AIX OST (other SCSI tape) driver. Refer to the IBM documentation when using this driver.

Configuring Non-QIC Tape Drives

The terms *variable length block* or *fixed length block* refer to the behavior of reads and writes and the way the kernel packs physical tape records into logical tape records for an application. Variable-mode devices allow more flexibility in reading previously written tapes. Many tape devices can be accessed in either mode. NetBackup assumes variable length for non-QIC drives.

For more information, see `chdev(1)`, `smit(1)` and the system management guide. The `smit` application is the most convenient way to manually change from fixed to variable-length-block devices.

Caution Non-QIC tape drives must be configured as variable-length-block devices if they will be used by Media Manager. Otherwise NetBackup is able to write data but may not be able to read it correctly. During a read, you may see a “not in tar format” error.

Automatic Configuration

When a non-QIC tape drive is configured using NetBackup, NetBackup will automatically issue the `chdev` command to configure the drive as a variable length block device. It is normally not necessary to manually run the `chdev` command, but the details of the command issued by NetBackup are provided (see “Using the `chdev` Command” on page 39).

Using the `chdev` Command

Ensure that the device being used is configured for variable mode by using the `chdev` command as follows:

```
/usr/sbin/chdev -l Dev -a block_size=0
```

Where *Dev* is the logical identifier for the drive (for example: `rmt0` or `rmt1`).

Using Extended-File Marks for Drives

Tape drives must be configured to use extended file marks, if those tape drives are capable of supporting them (for example, 8-mm drives). See `chdev(1)` and `smit(1)` for additional information. Otherwise, NetBackup may not be able to use those drives.



Automatic Configuration

When a tape drive is configured using NetBackup, NetBackup will automatically issue the `chdev` command to configure the drive to use extended file marks. It is normally not necessary to manually run the `chdev` command, but the details of the command issued by NetBackup are provided (see “Using the `chdev` Command” on page 40).

Using the `chdev` Command

Ensure that the device being used is configured for extended file marks as required by Media Manager by using the `chdev` command as follows:

```
/usr/sbin/chdev -l Dev -a extfm=yes
```

Where *Dev* is the logical identifier for the drive (for example: `rmt0` or `rmt1`)

Fast-Tape Positioning (`locate-block`)

For AIT, DLT, Exabyte, and half-inch cartridge tape drives, Media Manager supports the SCSI `locate-block` command for positioning tape to a specific block. This improves tape-positioning greatly over what can be obtained with the alternative.

Media Manager uses the `locate-block` command by default unless you disable it by executing the following:

```
touch /usr/opensv/volmgr/database/NO_LOCATEBLOCK
```

With `locate-block` positioning disabled, NetBackup uses the `forward-space-file/record` method.

Creating No Rewind Device Files

When adding tape drives to a Media Manager configuration, you need only specify a no rewind on close device path. These SCSI device files are in the `/dev` directory and have the following format:

```
/dev/rmtID.1
```

Where *ID* is the logical identifier assigned to the device by the system.

▼ To check for and create the necessary device files

1. Display which SCSI controllers are physically available by using the `lsdev` command as follows:

```
/usr/sbin/lsdev -C | grep I/O
```

This sample output shows that SCSI controller 1 (00-01) has been assigned the logical identifier `scsi0`.

```
scsi0  Available 00-01      SCSI I/O Controller
```

2. Display the SCSI device files that have already been created by using one of the following commands:

```
/usr/sbin/lsdev -C -s scsi
/usr/sbin/lsdev -C -s fcp
```

```
hdisk0  Available 00-01-00-0,0 400 MB SCSI Disk Drive
hdisk1  Available 00-01-00-1,0 400 MB SCSI Disk Drive
rmt0     Available 00-01-00-3,0 Other SCSI Tape Drive
```

This example output shows that two disk drives and one tape drive exist as follows:

- ◆ `hdisk0` is a disk drive at controller 1 (00-01) and SCSI ID 0 (0, 0)
- ◆ `hdisk1` is a disk drive at controller 1 (00-01) and SCSI ID 1 (1, 0)
- ◆ `rmt0` is a tape drive at controller 1 (00-01) and SCSI ID 3 (3, 0)

If the device files for the SCSI tape drives exist, they appear in the output as `rmt0`, `rmt1`, and so on. The previous example output shows `rmt0`.

For `rmt0` and `rmt1`, you would use the following no rewind on close device files:

```
/dev/rmt0.1
/dev/rmt1.1
```

3. If the device files for the SCSI ID of the desired tape drive do not exist, create them using the following command:

```
/usr/sbin/mkdev -c tape -s scsi -t ost -p controller -w id,lun
```

Where:

- ◆ *controller* is the logical identifier of the SCSI adapter for the device, such as `scsi0` or `scsi1`.
- ◆ *id* is the SCSI ID of the drive connection.
- ◆ *lun* is the logical unit number of the drive connection.

An example for an 8-mm drive connected to controller 0 and SCSI ID 5 follows:

```
mkdev -c tape -s scsi -t ost -p scsi0 -w 5,0
```



You can display the newly created logical identifier for the device by using the `lsdev` command.

```
/usr/sbin/lsdev -C -s scsi
```

```
hdisk0 Available 00-01-00-0,0 400 MB SCSI Disk Drive
hdisk1 Available 00-01-00-1,0 400 MB SCSI Disk Drive
rmt0 Available 00-01-00-3,0 Other SCSI Tape Drive
rmt1 Available 00-01-00-5,0 Other SCSI Tape Drive
ovpass0 Available 00-01-6,0 VERITAS Media Changer
```

The `rmt1` device file has been created.

4. If the device files do not exist on a FCP controller, use the following command to create them, where *device* is the controller number from step 1 on page 40. For example, `fscsi0`.

```
/usr/sbin/cfgmgr -l device
```

5. Ensure that the device being used is configured for variable-mode and extended file marks as required by Media Manager by using the `chdev` command as follows, where *Dev* is the logical identifier for the drive (for example: `rmt0` or `rmt1`).

```
/usr/sbin/chdev -l Dev -a block_size=0
/usr/sbin/chdev -l Dev -a extfm=yes
```

No Rewind Device File Example

Assume the device files for the desired SCSI 8-mm tape drive (controller 1, SCSI ID 5) do not exist.

1. Determine the logical identifier for the SCSI controller as follows:

```
/usr/sbin/lsdev -C -c adapter | grep SCSI
```

The following output shows that `scsi0` is the logical name for SCSI controller 1:

```
scsi0 Available 00-01 SCSI I/O Controller
```

2. Check if the device files exist for any device at SCSI ID 5.

```
/usr/sbin/lsdev -C -s scsi
```

The following output shows that some device files exist for tape and disk, but not for the 8-mm tape drive at controller 1 (`scsi0`) and SCSI ID 5 (5,0):

```
hdisk0 Available 00-01-00-0,0 400 MB SCSI Disk Drive
hdisk1 Available 00-01-00-1,0 400 MB SCSI Disk Drive
rmt0 Available 00-01-00-3,0 Other SCSI Tape Drive
```


3. Create the desired device files by using the following command:

```
mkdev -c tape -t ost -s scsi -p scsi0 -w 5,0
```

4. Display the device files by issuing the following `lsdev` command:

```
/usr/sbin/lsdev -C -s scsi
```

```
hdisk0 Available 00-01-00-0,0 400 MB SCSI Disk Drive
hdisk1 Available 00-01-00-1,0 400 MB SCSI Disk Drive
rmt0 Available 00-01-00-3,0 Other SCSI Tape Drive
rmt1 Available 00-01-00-5,0 Other SCSI Tape Drive
```

5. To ensure that the tape device is configured for variable-mode and extended file marks, use the following commands:

```
chdev -l rmt1 -a block_size=0
chdev -l rmt1 -a extfm=yes
```

Enter the following device file path to configure the 8-mm drive connected to controller 1 and SCSI ID 5:

```
/dev/rmt1.1
```

Using Multiple Tape Densities

After creating the necessary device files for your tape drives you may want to use non-default densities on drives that support them (for example, Exabyte 8500C tape drives).

There are two configurable densities available for all tape drives, although not all tape drives support multiple densities. The default density for both density setting 1 and density setting 2 is 0, which means maximum density.

To modify either of the density settings, you can use `smit(1)` or commands similar to the following:

```
chdev -l tapedev -a density_set_1=Density
chdev -l tapedev -a density_set_2=Density
```

Where:

- ◆ *tapedev* is the logical identifier for the drive, such as `rmt0` or `rmt1`.
- ◆ *Density* is the decimal number representing the desired density.



To use density setting 1, use the following no rewind on close device file:

```
/dev/rmt*.1
```

To use density setting 2, use the following no rewind on close device file:

```
/dev/rmt*.5
```

Adding Sony AIT Drives

Sony S-AIT drives have dip switches (SWA and SWB) located on the bottom of the drive. It is important that these switches are set correctly for use in an SSO configuration.

Depending on the serial number of the drive, S-AIT drives are shipped from Sony with one of two switch settings for SWA-1 of SWA.

If your drive has an early serial number, it may have SWA-1 (No Reply Unit Attention After Process Login) set to Off. In this case, you must change the setting to On.

Drives with newer serial numbers have SWA-1 set to On as the default, as shown in the following table (1 = On and 0 = Off). These newer serial numbers are SDZ-130 :01442007 or SDZ-130/L :01200696 and later models, and a date of May 17, 2004.

| Switch | Setting |
|--------|---------|
| SWA-1 | 1 |
| SWA-2 | 0 |
| SWA-3 | 0 |
| SWA-4 | 0 |
| SWA-5 | 0 |
| SWA-6 | 0 |
| SWA-7 | 1 |
| SWA-8 | 0 |

Configuring Optical Disk Drives

When adding optical disk drives to a Media Manager configuration, you specify only a character device path. Optical disk character device files are located in the `/dev` directory and have the following format, where *ID* is the logical identifier assigned to the device by the system.

```
/dev/rhdiskID
```

Note To use HP optical disk drives, the system must recognize the optical drives as disk drives at system boot time. If you are adding HP 1.2 gigabyte or equivalent model magneto-optical disk drives to an AIX system, the system may not recognize them as disk drives, and thus cannot use them. See “Setting the HP Optical Drive Type in Nonvolatile Memory” on page 48 for information on correcting this condition.

Creating Device Files

▼ To check for and create the necessary device files

1. Display which SCSI controllers are physically available on your machine by using the following `lsdev` command:

```
/usr/sbin/lsdev -C -c adapter | grep SCSI
```

This sample output shows that SCSI controller 1 (00-01) has been assigned the logical identifier `scsi0`.

```
scsi0    Available 00-01    SCSI I/O Controller
```

2. Display the SCSI device files that have already been created by using the following `lsdev` command:

```
/usr/sbin/lsdev -C -s scsi
```

The following example output shows that two disk drives and one tape drive exist:

- ◆ `hdisk0` is a disk drive at controller 1 (00-01) and SCSI ID 0 (0,0)
- ◆ `hdisk1` is a disk drive at controller 1 (00-01) and SCSI ID 1 (1,0)
- ◆ `rmt0` is a tape drive at controller 1 (00-01) and SCSI ID 3 (3,0)



If the device files for the SCSI optical disk drives exist, they show up in the output as `hdisk0`, `hdisk1`, and so on.

```
hdisk0  Available 00-01-00-0,0 400 MB SCSI Disk Drive
hdisk1  Available 00-01-00-1,0 400 MB SCSI Disk Drive
rmt0    Available 00-01-00-3,0 Other SCSI Tape Drive
```

For `hdisk0`, you would use the following device path:

```
/dev/rhdisk0
```

3. If the device files for the desired optical drive's SCSI ID do not exist, you can create them with the following command:

```
mkdev -c disk -s scsi -t osdisk -p controller -w id,lun
```

Where:

- ◆ *controller* is the logical identifier of the device's SCSI adapter, such as `scsi0` or `scsi1`.
- ◆ *id* is the SCSI ID of the drive connection.
- ◆ *lun* is the logical unit number of the drive connection.

An example for an optical disk drive on controller 1 and SCSI ID 5 follows:

```
mkdev -c disk -t osdisk -s scsi -p scsi0 -w 5,0
```

4. You can display the newly-created logical identifier for the device by using the following command:

```
/usr/sbin/lsdev -C -s scsi
```

```
hdisk0  Available 00-01-00-0,0 400 MB SCSI Disk Drive
hdisk1  Available 00-01-00-1,0 400 MB SCSI Disk Drive
rmt0    Available 00-01-00-3,0 Other SCSI Tape Drive
hdisk2  Available 00-01-00-5,0 Other SCSI Disk Drive
ovpass0 Available 00-01-6,0   VERITAS Media Changer
```

The device files for `hdisk2` have been created and you can now use them.

Examples of Optical Disk Device Files

Assume the device files for the desired optical disk drive (controller 1, SCSI ID 5) do not yet exist.

1. Determine the logical identifier for the SCSI controller as follows:

```
/usr/sbin/lsdev -C -c adapter | grep SCSI
```

The output shows that `scsi0` is the logical name for SCSI controller 1.

```
scsi0    Available 00-01      SCSI I/O Controller
```

2. Check to see if the device files exist for `ovpass` at SCSI ID 5.

```
/usr/sbin/lsdev -C -s scsi
```

The output shows that some device files exist for tape and disk, but not for the optical disk drive at controller 1 (`scsi0`) and SCSI ID 5 (5,0).

```
hdisk0   Available 00-01-00-0,0 400 MB SCSI Disk Drive
hdisk1   Available 00-01-00-1,0 400 MB SCSI Disk Drive
rmt0     Available 00-01-00-3,0 Other SCSI Tape Drive
```

3. Create device files for the optical disk drive on controller 1 at SCSI ID 5 by using the following command:

```
mkdev -c disk -t osdisk -s scsi -p scsi0 -w 5,0
```

4. Display the device files by issuing the `lsdev` command.

```
/usr/sbin/lsdev -C -s scsi
```

```
hdisk0   Available 00-01-00-0,0 400 MB SCSI Disk Drive
hdisk1   Available 00-01-00-1,0 400 MB SCSI Disk Drive
rmt0     Available 00-01-00-3,0 Other SCSI Tape Drive
hdisk2   Available 00-01-00-5,0 Other SCSI Disk Drive
```

5. Enter the following character device file path to configure the optical disk drive connected to controller 1 and SCSI ID 5:

```
/dev/rhdisk2
```



Setting the HP Optical Drive Type in Nonvolatile Memory

To use HP optical disk drives, the system must recognize the optical drives as disk drives at system boot time. If you are adding HP 1.2 gigabyte or equivalent model magneto-optical disk drives to an AIX system, the system may not recognize them as disk drives and cannot use them.

▼ To detect whether the system recognizes the optical drives

1. Execute the following command after system boot.

```
/usr/sbin/lsdev -C -s scsi
```

2. If you see the appropriate controller and SCSI ID combination for the optical drive listed as Other SCSI Disk Drive, the system recognizes the drive as a disk drive.

```
hdisk0 Available 00-00-0S-0,0 2.2 GB SCSI Disk Drive
rmt0 Available 00-00-0S-3,0 Other SCSI Tape Drive
omd0 Defined 00-00-0S-6,0 Other SCSI Read/Write Optical Drive
ovpass0 Available 00-00-0S-2,0 VERITAS Media Changer
```

▼ To recognize these drives when the operating system does not

1. Install the ovpass driver if it is not already installed. See “The SCSI Passthru Driver (ovpass)” on page 30.
2. Create the ovpass device file for the optical drive so that the driver can be used to communicate with the optical drive.
 - a. Display the SCSI device files that have already been created by using the following command: `/usr/sbin/lsdev -C -s scsi`

The following example output shows that a disk drive, a tape drive, an optical drive, and SCSI robotic control are configured:

- ◆ `hdisk0` is a disk drive at controller 1 (00) and SCSI ID 0 (0,0)
- ◆ `rmt0` is a tape drive at controller 1 (00) and SCSI ID 3 (3,0)
- ◆ `omd0` is an optical drive at controller 1 (00) and SCSI ID 6 (6,0)
- ◆ `ovpass0` refers to the SCSI robotic control for controller 1 (00) and SCSI ID 2 (2,0)

```
hdisk0  Available 00-00-0S-0,0 2.2 GB SCSI Disk Drive
rmt0    Available 00-00-0S-3,0 Other SCSI Tape Drive
omd0    Defined  00-00-0S-6,0 Other SCSI Read/Write Optical
                                           Drive
ovpass0 Available 00-00-0S-2,0 VERITAS Media Changer
```

- b.** Create the device files for the optical drive by using the following command:

```
mkdev -c media_changer -s scsi -t ovpass -p controller
      -w id,lun
```

Where:

controller is the logical identifier of the drive's SCSI adapter, such as `scsi0` or `scsi1`.

id is the SCSI ID of the optical drive (not the robotic connection).

lun is the logical unit number of the optical drive.

For example:

```
mkdev -c media_changer -s scsi -t ovpass -p scsi 0 -w 6,0
```

Use the following command to obtain the logical identifier for the optical drive you just created:

```
/usr/sbin/lsdev -C -s scsi
```

- c.** Verify the temporary `ovpass` device file created in step b.

```
/usr/openv/volmgr/bin/scsi_command -d /dev/ovpass_id -inquiry
```

Where *ovpass_id* is the logical identifier assigned to the temporary device. For example if the temporary `ovpass` device was `ovpass2`, enter the following:

```
/usr/openv/volmgr/bin/scsi_command -d /dev/ovpass2 -inquiry
```

The output shows the following:

```
removable device type c_8h_HP
```



3. Use the following command to change the device type (stored in the drive's nonvolatile memory) from optical memory to disk. The format of the command is as follows, where *ovpass_id* is the logical identifier assigned to the device.

```
/usr/openv/volmgr/bin/scsi_command -d /dev/ovpass_id -disk
```

For example:

```
/usr/openv/volmgr/bin/scsi_command -d /dev/ovpass1 -disk
```

4. Remove the ovpass device files and the optical drive that were created by using `rmdev` command as in the following:

```
rmdev -l ovpass_id -d
rmdev -l optical_drive_id -d
```

Where:

- ◆ *ovpass_id* is the logical identifier assigned to the device.
- ◆ *optical_drive_id* is the optical drive identifier assigned to the optical drive.

For example:

```
rmdev -l ovpass1 -d
rmdev -l omd0 -d
```

5. Reboot the system to allow the drive to be recognized as a disk drive by the kernel's SCSI disk driver during system initialization.

The optical drive should be displayed as: *hdisklogical_number*, where *logical_number* is the logical number assigned to the drive by the system.

For example:

```
/usr/sbin/lsdev -C -s scsi
```

The following example output shows a disk drive, tape drive, robotic control, and optical drive:

```
hdisk0 Available 00-00-0S-0,0 2.2 GB SCSI Disk Drive
rmt0 Available 00-00-0S-3,0 Other SCSI Tape Drive
ovpass0 Available 00-00-0S-2,0 VERITAS Media Changer
hdisk1 Available 00-00-0S-6,0 Other SCSI Disk Drive
```


Command Summary

The following is a summary of commands that may be useful when configuring devices. See the procedures in this chapter for examples of their usage.

```
/usr/opensv/volmgr/bin/driver/install_ovpass
```

Installs the ovpass driver for the first time.

```
/usr/opensv/volmgr/bin/driver/remove_ovpass
```

Removes the ovpass driver.

```
/usr/opensv/volmgr/bin/driver/mkdev_ovpass
```

Place this command in the system startup script to ensure that the ovpass driver device files are accessible after each system boot.

```
/usr/sbin/lsdev -C | grep I/O
```

Displays adapters that are physically available on your server.

```
/usr/sbin/lsdev -C -s filetype
```

Displays the device files that have been created, where *filetype* defines the type of file displayed. *scsi* displays SCSI files and *fc* displays fibre channel files.

```
mkdev -c media_changer -s scsi -t ovpass -p controller -w id,lun
```

Creates device files for the robotic control SCSI ID.

Where *controller* is the logical identifier of the drive SCSI adaptor (such as *scsi0* or *scsi1*), *id* is the SCSI ID of the robotic connection, and *lun* is the logical unit number of the robotic connection.

```
mkdev -c media_changer -s fc -t ovpass -p controller -w scsi_id,lun
```

Creates device files for the robotic control fibre channel SCSI ID.

Where *controller* is the logical identifier of the drive SCSI adaptor (such as *scsi0* or *scsi1*), *scsi_id* is the fibre channel SCSI ID of the robotic connection, and *lun* is the logical unit number of the robotic connection.

```
mkdev -c disk -s scsi -t osdisk -p controller -w id,lun
```

Creates device files for optical disk drives.

Where *controller* is the logical identifier of the drive SCSI adaptor (such as *scsi0* or *scsi1*), *id* is the SCSI ID of the robotic connection, and *lun* is the logical unit number of the robotic connection.



```
mkdev -c tape -s scsi -t ost -p controller -w id,lun
```

Creates device files for tapes.

Where *controller* is the logical identifier of the drive SCSI adaptor (such as *scsi0* or *scsi1*), *id* is the SCSI ID of the robotic connection, and *lun* is the logical unit number of the robotic connection.

```
/usr/sbin/chdev -l dev -a block_size=0
```

Configures the drive with logical identifier specified by *dev* (for example: *rmt0*) to variable mode.

```
/usr/sbin/chdev -l dev -a extfm=yes
```

Configures the drive with logical identifier specified by *dev* (for example: *rmt0*) for extended file marks.

```
/usr/opensv/volmgr/bin/scsi_command -d /dev/ovpass_id -disk
```

Used for HP optical disk drives to change the device type (stored in the drive's nonvolatile memory) from optical memory to disk.

Where *ovpass_id* is the logical identifier assigned to the device.

```
/etc/lsattr -l dev -E -H
```

Displays device information, where *dev* is the name of the device (for example, *rmt1*).

```
/usr/sbin/cfgmgr -l device
```

Creates device files on a FCP controller, where *device* is the controller number (for example, *fscsi0*).

```
/usr/bin/odmget -q "name=rmtX" CuAt
```

Displays the device attributes for the device (*rmtX*). This command can be used to determine SCSI target and lun pairs when configuring fibre channel devices.

Where *rmtX* is the name of the tape device (for example: *rmt0* or *rmt1*).

This chapter explains how to configure storage devices for use with Media Manager running on an HP-UX system.

After configuring the hardware, use one of the available Media Manager configuration interfaces to add the drives and robots to your Media Manager configuration

The major topics included are as follows:

- ◆ “Before You Start” on page 54
- ◆ “Configuring Robotic Controls” on page 55
- ◆ “Configuring Tape Drives” on page 62
- ◆ “Configuring Optical Disk Drives” on page 68
- ◆ “Handling Errors when More Than 10 NetBackup Jobs are Active” on page 69
- ◆ “Command Summary” on page 70



Before You Start

Observe the following points when performing the configurations described in this chapter:

- ◆ The VERITAS support web site (<http://www.support.veritas.com>) contains server platform compatibility information for a number of vendors and products (see the NetBackup Product > Compatibility area of the site). Verify that your server platform is supported before configuring devices.
- ◆ For NetBackup to recognize and communicate with connected devices and for device discovery to discover devices, NetBackup issues SCSI pass-thru commands to the devices in a configuration.

Device files must exist that follow the naming conventions explained in “Configuring Robotic Controls” on page 55, “Configuring Tape Drives” on page 62, and “Configuring Optical Disk Drives” on page 68.

- ◆ Use `/usr/sbin/sam` (HP utility) and `ioscan -f` to verify that the devices are configured correctly. Make sure you can “see” your devices on the SAN before you install and configure the SSO option.
- ◆ Some HP SCSI adapters do not support SCSI pass-thru, so devices on these adapters are not auto-discovered.

If You Are Using NetBackup Server

Portions of this chapter include configuration topics and examples for configurations and options that are not supported in NetBackup Server. It is important to refer to the VERITAS support web site to determine support for NetBackup Server (see the NetBackup Product > Compatibility area of the site), before using this chapter.

Topics Not Applicable to NetBackup Server

- ◆ “Enabling SCSI Reserve/Release” on page 66.
- ◆ “Cautions with Using the HP-UX EMS Tape Device Monitor” on page 66.



Configuring Robotic Controls

Robots are controlled through a SCSI or a network connection. Robot control configuration can be found as follows:

- ◆ SCSI control is covered in the following sections.
- ◆ Configuration of network controlled robotic libraries (for example, ACS robots) is discussed in the appendices of the *VERITAS NetBackup Media Manager System Administrator's Guide for UNIX and Linux* or the *VERITAS NetBackup Media Manager System Administrator's Guide for Windows*.

Configuring SCSI Robotic Controls

Read this topic if you plan to use a robotic storage device that is controlled through a SCSI robotic connection. Information on supported SCSI robots (vendor models) can be found on the VERITAS support web site (see the NetBackup Product > Compatibility area of the site).

Determining Which Passthru Driver to Configure

When communicating with SCSI-controlled robotic peripherals, Media Manager robotic software uses the `sctl` or `spt` SCSI passthru driver. The driver that is used depends on the type of SCSI interface on the system.

- ◆ For devices connected to all other SCSI interface cards (HSC, PCI, or EISA), the `sctl` passthru driver must be configured.

When attaching an autochanger (robotic library) device to a GSC interface and using the `sctl` driver, the `schgr` device driver must also be installed. Without this driver installed, the system will not bind the driver to the device. See the `autochanger(7)` man page.

See “Configuring Device Files for the `sctl` Passthru Driver” on page 56.

- ◆ For devices connected to HPPB SCSI interface cards, the `spt` passthru driver must be configured.

See “Configuring Device Files for the `spt` Passthru Driver” on page 60.

Examples

To determine the type of interface on your system, use the `ioscan -f` command as shown in the following examples.



Example 1: Built-in SCSI interface (sctl driver)

```
ioscan -f
```

| Class | I | H/W Path | Driver | S/W State | H/W Type | Description |
|---------|----|-------------|--------|-----------|-----------|----------------|
| ext_bus | 2 | 10/12/5 | c700 | CLAIMED | INTERFACE | Built-in SCSI |
| target | 11 | 10/12/5.0 | tgt | CLAIMED | DEVICE | |
| tape | 0 | 10/12/5.0.0 | stape | CLAIMED | DEVICE | HP C1533A |
| target | 12 | 10/12/5.2 | tgt | CLAIMED | DEVICE | |
| disk | 6 | 10/12/5.2.0 | sdisk | CLAIMED | DEVICE | TOSHIBA CD-ROM |

In this case, the `ext_bus` entry specifies a `c700` driver. You would configure the `sctl` passthru driver for the SCSI robotic controls on this system (see “Configuring Device Files for the `sctl` Passthru Driver” on page 56).

Example 2: 28655A SCSI Interface (spt driver)

```
ioscan -f
```

| Class | I | H/W Path | Driver | S/W State | H/W Type | Description |
|---------|-------------|----------|--------|-----------|-----------|----------------------------|
| bc | 0 | | root | CLAIMED | BUS_NEXUS | |
| bc | 1 56 | | bc | CLAIMED | BUS_NEXUS | Bus Converter |
| ext_bus | 0 56/52 | | scsi1 | CLAIMED | INTERFACE | HP 28655A - SCSI Interface |
| target | 0 56/52.2 | | target | CLAIMED | DEVICE | |
| tape | 0 56/52.2.0 | | tape2 | CLAIMED | DEVICE | HP HPC1533A |

In this case, the `ext_bus` entry (which designates the bus adapter) specifies a `scsi1` driver. You would configure the `spt` passthru driver for the SCSI robotic controls on this system (see “Configuring Device Files for the `spt` Passthru Driver” on page 60).

Configuring Device Files for the `sctl` Passthru Driver

Use the following procedure to configure these types of device files. See “Determining Which Passthru Driver to Configure” on page 55 to determine if you require these files.

Note You do not have to reconfigure the HP-UX kernel to use the `sctl` passthru driver on HP9000-700 systems, since the generic SCSI driver is part of basic HP-UX.

If the devices do not exist, you can create device files by using the `mknod` command as follows. See the `scsi_ctl(7)` man page.

```
mkdir /dev/sctl
cd /dev/sctl
```

```
/usr/sbin/mknod cCONTROLLERtTARGETlLUN c 203 0xII TL00
```

Where:

- ◆ *CONTROLLER* is the Instance number of the controlling bus. The Instance value is displayed in `ioscan -f` output under column I of the controller entry (ext_bus in the Class column).
- ◆ *TARGET* is the SCSI ID of the robotic control.
- ◆ *LUN* is the SCSI logical unit number.
- ◆ *II* are two hexadecimal digits that identify the controlling bus interface card by its Instance number (same as controller).
- ◆ *T* is one hexadecimal digit representing the SCSI ID.
- ◆ *L* is one hexadecimal digit representing the SCSI LUN.

Using `ioscan` With `sctl` Robots

If the robotic control has its own SCSI ID, it has an entry similar to the following:

```
Class      I  H/W Path  Driver  S/W State H/W Type  Description
=====
unknown  -1  2/0/1.1.0  unknown  UNCLAIMED UNKNOWN  LAGO SYSL-340L
```

The Class, I, and Driver columns may also have invalid information. In these instances the robotics are correct, but `ioscan` returns invalid information.



Examples of Creating Device Files

Example 1

In this example the robotic control for a ADIC Scalar 100 library is on a SCSI bus with a instance number of 7 (ext_bus entry, I column), SCSI ID 2 and LUN 0. The robotic control for an IBM ULT3583-TL library is on the same SCSI bus at SCSI ID 3 and LUN 0.

Use the following procedure to create the robotic device files:

1. Use the `ioscan -f` command to get information on the SCSI bus and the robotic control.

| Class | I | H/W Path | Driver | S/W State | H/W Type | Description |
|---------|----|-------------|--------|-----------|-----------|-------------------------|
| ===== | | | | | | |
| ext_bus | 7 | 0/7/0/1 | c720 | CLAIMED | INTERFACE | SCSI C896 Fast Wide LVD |
| target | 10 | 0/7/0/1.0 | tgt | CLAIMED | DEVICE | |
| tape | 65 | 0/7/0/1.0.0 | stape | CLAIMED | DEVICE | QUANTUM SuperDLT1 |
| target | 11 | 0/7/0/1.1 | tgt | CLAIMED | DEVICE | |
| tape | 66 | 0/7/0/1.1.0 | stape | CLAIMED | DEVICE | QUANTUM SuperDLT1 |
| target | 12 | 0/7/0/1.2 | tgt | CLAIMED | DEVICE | |
| autoch | 14 | 0/7/0/1.2.0 | schgr | CLAIMED | DEVICE | ADIC Scalar 100 |
| target | 13 | 0/7/0/1.3 | tgt | CLAIMED | DEVICE | |
| autoch | 19 | 0/7/0/1.3.0 | schgr | CLAIMED | DEVICE | IBM ULT3583-TL |
| target | 14 | 0/7/0/1.4 | tgt | CLAIMED | DEVICE | |
| tape | 21 | 0/7/0/1.4.0 | atdd | CLAIMED | DEVICE | IBM ULT3580-TD1 |
| target | 15 | 0/7/0/1.5 | tgt | CLAIMED | DEVICE | |
| tape | 19 | 0/7/0/1.5.0 | atdd | CLAIMED | DEVICE | IBM ULT3580-TD1 |

2. The commands to create the device files follow. See the “Command Summary” on page 70 for the `mknod` command format or see the `scsi_ctl(7)` man page.

```
cd /dev/sctl
/usr/sbin/mknod c7t210 c 203 0x072000
/usr/sbin/mknod c7t310 c 203 0x073000
```

This creates the following device files, which you specify to Media Manager during configuration of the ADIC robotic control and IBM robotic control respectively:

```
/dev/sctl/c7t210
/dev/sctl/c7t310
```

Note It is important to also create the passthru driver device files for tape drives. See “Configuring Tape Drives” on page 62.

Example 2

Assume the robotic control for an Exabyte 10i tape stacker (TS8) is on a built-in SCSI bus at SCSI ID 3, LUN 0. Also assume that an `ioscan -f` verifies that the SCSI ID is 3 and shows that the Instance number for the robot's SCSI bus is 1.

The commands to create the device file are

```
cd /dev/sctl
/usr/sbin/mknod c1t310 c 203 0x013000
```

This creates the following device file, which you specify to Media Manager:

```
/dev/sctl/c1t310
```

Example 3

1. Use the `ioscan -f` command to get information on the SCSI bus and the robotic control.

| Class | I | H/W Path | Driver | S/W State | H/W Type | Description |
|---------|---|-------------------|--------|-----------|-----------|---------------------------------|
| ===== | | | | | | |
| ext_bus | 3 | 0/0/0.8.0.0.0 | fcpmux | CLAIMED | INTERFACE | HP A3308 FCP-SCSI MUX Interface |
| target | 0 | 0/0/0.8.0.0.0.0 | tgt | CLAIMED | DEVICE | |
| tape | 0 | 0/0/0.8.0.0.0.0.0 | stape | CLAIMED | DEVICE | QUANTUM DLT7000 |
| target | 1 | 0/0/0.8.0.0.0.1 | tgt | CLAIMED | DEVICE | |
| autoch | 0 | 0/0/0.8.0.0.0.1.0 | schgr | CLAIMED | DEVICE | STK9740 |
| target | 2 | 0/0/0.8.0.0.0.7 | tgt | CLAIMED | DEVICE | |
| ctl | 3 | 0/0/0.8.0.0.0.7.0 | sctl | CLAIMED | DEVICE | Initiator |

With fibre channel and SCSI muxes the hardware paths are a bit longer. If you use the bus H/W Path as a mask and apply it to the other hardware paths for devices on that bus, you are left with *SCSI ID.SCSI LUN* for the device.

This example has a bus with H/W Path of 0/0/0.8.0.0.0, which has an instance number (I column) of 3. Applying the mask shows a DLT 7000 drive at SCSI ID 0, SCSI LUN 0 and a STK 9740 robot at SCSI ID 1, SCSI LUN 0 also on this bus.

When configuring the robotic device file for the STK 9740 robot, you would use `controller=3`, `target=1`, and `lun=0`. To enable the passthru path for the Quantum DLT 7000 drive, you would use `controller=3`, `target=0`, and `lun=0`.

2. The commands to create the device file for the robotic control are as follows:

```
cd /dev/sctl
/usr/sbin/mknod c3t110 c 203 0x031000
```

These commands create the following device file, which you specify to Media Manager during configuration of the robotic control:

```
/dev/sctl/c3t110
```



3. The commands to create the passthru device file for the tape drive follow. See the “Command Summary” on page 70 for the `mknod` command format or see the `scsi_ctl(7)` man page.

```
cd /dev/sctl
/usr/sbin/mknod c3t010 c 203 0x030000
```

These commands create the following passthru device file.

```
/dev/sctl/c3t010
```

Although the passthru device file is used during NetBackup operation, it is not specified during configuration. During Media Manager tape drive configuration, the following no rewind on close device file path is used:

```
/dev/rmt/c3t0d0BESTnb
```

Configuring Device Files for the spt Passthru Driver

Use the following procedure to configure these types of device files. See “Determining Which Passthru Driver to Configure” on page 55 to determine if you require these files.

Note The HP-UX kernel has to be configured to use the spt SCSI passthru driver. Refer to the HP-UX `scsi_pt(7)` man page.

The device files for the spt driver have the following format:

```
/dev/spt/cCONTROLLERtTARGETlUNIT
```

Where:

- ◆ *CONTROLLER* is the Instance number of the controlling bus. The Instance value is displayed in the output of `ioscan -f` in the column labeled I of the controller’s entry (`ext_bus` in the column labeled Class).
- ◆ *TARGET* is the SCSI ID of the robotic control.
- ◆ *UNIT* is the SCSI logical unit number (LUN) of the robot. This is usually 0.

You must create the device files for the spt driver manually, as they are not created automatically when the system boots.

▼ To create these device files

These steps are also documented in the `scsi_pt(7)` man page.

1. Install and configure the driver as described in the man page.
2. Determine the character major number of the spt driver using `lsdev -d spt`.

3. Use the following commands to create the device file for the SCSI robotic control:

```
mkdir /dev/spt
mknod /dev/spt/Name c Major 0xIITL00
```

Where:

- ◆ *Name* is the device name as defined in the format:
cCONTROLLERtTARGETlUNIT
- ◆ *Major* is the character major number (from the `lsdev` command).
- ◆ *Ii* is two hexadecimal digits identifying the controlling bus interface card by its Instance number.
- ◆ *T* is one hexadecimal digit representing the SCSI ID of robotic control.
- ◆ *L* is one hexadecimal digit representing the SCSI LUN of the robotic control.

Example of Creating a Device File

If the robotic control for an HP Optical Disk Library (ODL) is on a secondary SCSI bus at SCSI ID 3, LUN 0, use the following steps to create the device file.

1. Use the `ioscan -f` command to get information on the SCSI bus and the robotic control.

| Class | I | H/W Path | Driver | S/W State | H/W Type | Description |
|---------|---|-----------|--------|-----------|-----------|----------------------------|
| bc | 0 | | root | CLAIMED | BUS_NEXUS | |
| bc | 1 | 56 | bc | CLAIMED | BUS_NEXUS | Bus Converter |
| ext_bus | 1 | 56/16 | scsi1 | CLAIMED | INTERFACE | HP 28655A - SCSI Interface |
| target | 4 | 56/16.3 | target | CLAIMED | DEVICE | |
| spt | 0 | 56/16.3.0 | spt | CLAIMED | DEVICE | HP C1700T |

The Instance number for the robot's SCSI bus is 1. It also confirms that the `spt` driver is attached to the optical robotic control at H/W Path 56/16.3.0.

2. Use `lsdev` to get the character major number for the `spt` driver.

```
lsdev -d spt
```

The output from this command shows that the character major number for the `spt` driver is 137.

| Character | Block | Driver | Class |
|-----------|-------|--------|-------|
| 137 | -1 | spt | spt |

3. Create the `/dev/spt` directory, if it has not already been created.

```
mkdir /dev/spt
```



4. Create the device file as follows:

```
mknod /dev/spt/clt310 c 137 0x013000
```

This command creates the `/dev/spt/clt310` device file. Specify this file as the robot control path when configuring your device under Media Manager.

Configuring Tape Drives

Read the following topics if you plan to use tape drives:

Using Berkeley Style Close

The examples in this section show *Berkeley-style close* for tape drives as indicated by the letter `b` after the compression specification. It is mandatory to specify Berkeley-style close for tape devices that you configure under Media Manager.

The terms *Berkeley-style close* and *AT&T style close* refer to operations where a tape is left logically positioned after a close operation (in relation to a tape mark). One style leaves an application logically positioned before a tape mark and the other leaves it after. Applications must assume where the tape is left after a close in order to establish the correct orientation the next time they do a tape-position or read operation. Some operating systems allow tape devices to be configured with either type of close. NetBackup assumes it is using Berkeley-style close on an HP9000.

Using the Passthru Driver for Tape Drives

The SCSI passthru driver and SCSI passthru device paths are required by NetBackup for full feature support. Performance will be degraded if SCSI passthru is not provided. The passthru driver is used

- ◆ By `avrd` and robotic processes to scan drives.
- ◆ By NetBackup and Storage Migrator for locate-block positioning.
- ◆ By NetBackup and Storage Migrator for SAN error recovery.
- ◆ By NetBackup and Storage Migrator for Quantum SDLT performance optimization.
- ◆ By NetBackup and Storage Migrator for SCSI reserve/release.
- ◆ To set the optical drive type (as explained in “Setting the HP Optical Drive Type in Nonvolatile Memory” on page 25).
- ◆ By the NetBackup device configuration GUIs to collect robot and drive information.

- ◆ To collect TapeAlert information from tape devices allowing support of functions such as tape drive cleaning.
- ◆ For WORM tape support.
- ◆ Future NetBackup features and enhancements

Note Passthru paths are not supported on HP-PB adapters such as HP 28696A - Wide SCSI or HP 28655A - SE SCSI.

Automatic Configuration

Because using the passthru path is so important, NetBackup will automatically create the corresponding passthru path whenever a tape drive is configured with a device file of the format: `/dev/rmt/cCONTROLLERtTARGETdUNITBESTnb`.

These paths are created in the `/dev/sct1` directory, which will also be created if it does not exist. Passthru paths will also be created automatically whenever the NetBackup device configuration wizard is run. In either case, NetBackup will not modify or delete any existing passthru paths. NetBackup assumes that any existing passthru paths were created correctly.

NetBackup does not detect the type of adapter cards installed in the system, so it will also create passthru paths for tape drives connected to adapter cards that do not support passthru. This is expected and will not cause any problems.

It is normally not necessary to manually create passthru paths for tape drives, but the steps for doing so are provided (see “Enabling Passthru Paths” on page 63).

Enabling Passthru Paths

To enable passthru paths, a device file in the directory `/dev/sct1` must exist for the tape drives. Create the device files as shown in the following example.

Note When using the `mknod` command for tape drives, *TARGET* is the SCSI ID of the tape drive *not* the SCSI ID of the robotic control.

Example:

In this example the robotic control for a ADIC Scalar 100 library is on a SCSI bus with a instance number of 7 (`ext_bus` entry, I column), SCSI ID 2 and LUN 0, and the robotic control for a IBM ULT3583-TL library is on the same SCSI bus at SCSI ID 3 and LUN 0.

The ADIC library contains 2 Quantum Super DLT drives, one with SCSI ID 0, SCSI LUN 0 and the other with SCSI ID 1, SCSI LUN 0.



The IBM library contains 2 IBM Ultrium LTO drives, one with SCSI ID 4, SCSI LUN 0 and the other with SCSI ID 5, SCSI LUN 0.

Use the following procedure to create the robotic control device files and the passthru driver tape drive device files:

1. Assume the configuration from `ioscan -f` is as follows:

| Class | I | H/W Path | Driver | S/W State | H/W Type | Description |
|---------|----|-------------|--------|-----------|-----------|-------------------------|
| ===== | | | | | | |
| ext_bus | 7 | 0/7/0/ | c720 | CLAIMED | INTERFACE | SCSI C896 Fast Wide LVD |
| target | 10 | 0/7/0/1.0 | tgt | CLAIMED | DEVICE | |
| tape | 65 | 0/7/0/1.0.0 | stape | CLAIMED | DEVICE | QUANTUM SuperDLT1 |
| target | 11 | 0/7/0/1.1 | tgt | CLAIMED | DEVICE | |
| tape | 66 | 0/7/0/1.1.0 | stape | CLAIMED | DEVICE | QUANTUM SuperDLT1 |
| target | 12 | 0/7/0/1.2 | tgt | CLAIMED | DEVICE | |
| autoch | 14 | 0/7/0/1.2.0 | schgr | CLAIMED | DEVICE | ADIC Scalar 100 |
| target | 13 | 0/7/0/1.3 | tgt | CLAIMED | DEVICE | |
| autoch | 19 | 0/7/0/1.3.0 | schgr | CLAIMED | DEVICE | IBM ULT3583-TL |
| target | 14 | 0/7/0/1.4 | tgt | CLAIMED | DEVICE | |
| tape | 21 | 0/7/0/1.4.0 | atdd | CLAIMED | DEVICE | IBM ULT3580-TD1 |
| target | 15 | 0/7/0/1.5 | tgt | CLAIMED | DEVICE | |
| tape | 19 | 0/7/0/1.5.0 | atdd | CLAIMED | DEVICE | IBM ULT3580-TD1 |

Note Use the IBM atdd driver when configuring IBM tape drives on HP-UX. Configure atdd and BEST device paths according to IBM driver documentation. Do not configure atdd for robotic control of IBM robots. Check the VERITAS support web site for the latest recommended atdd driver version from IBM.

2. The commands to create the robotic device files follow. See the “Command Summary” on page 70 for the `mkknod` command format or see the `scsi_ctl(7)` man page.

```
cd /dev/sctl
/usr/sbin/mknod c7t210 c 203 0x072000
/usr/sbin/mknod c7t310 c 203 0x073000
```

This creates the following device files, which you specify to Media Manager during configuration of the ADIC robotic control and IBM robotic control respectively:

```
/dev/sctl/c7t210
/dev/sctl/c7t310
```

3. The commands to create the passthru device files for the tape drives are as follows:

```
cd /dev/sctl
/usr/sbin/mknod c7t010 c 203 0x070000
/usr/sbin/mknod c7t110 c 203 0x071000
/usr/sbin/mknod c7t410 c 203 0x074000
/usr/sbin/mknod c7t510 c 203 0x075000
```

These commands create the following passthru device files. Although the passthru device files for tape drives are used during NetBackup operation, they are not specified during configuration.

```
/dev/sctl/c7t010
/dev/sctl/c7t110
/dev/sctl/c7t410
/dev/sctl/c7t510
```

During Media Manager tape drive configuration, the following no rewind on close device files are used. See “No Rewind Device Files” on page 67 for instruction on creating no rewind device files.

```
/dev/rmt/c7t0d0BESTnb
/dev/rmt/c7t1d0BESTnb
/dev/rmt/c7t4d0BESTnb
/dev/rmt/c7t5d0BESTnb
```

Fast-Tape Positioning (locate-block)

Locate-block is supported for most drive types in HP9000 for Fast/Wide GSC SCSI adapters. See the VERITAS support web site for a list of drive types that are supported.

Enabling locate-block

NetBackup and Storage Migrator use the locate-block command by default if a passthru path is configured. See “Enabling Passthru Paths” on page 63.

Disabling locate-block

To disable locate-block positioning, execute the following command:

```
touch /usr/opensv/volmgr/database/NO_LOCATEBLOCK
```

With locate-block positioning disabled, NetBackup uses the forward-space-file/record method and Storage Migrator skips file marks.



Enabling SCSI Reserve/Release

This is a NetBackup Enterprise Server topic.

The VERITAS implementation of SCSI reserve/release protects data on a tape from corruption by other applications in a shared drive (SSO) configuration.

▼ To enable SCSI reserve/release

1. Set the kernel parameter `st_ats_enabled` to zero. Using the SAM utility is the easiest way to set this parameter.

Leaving this parameter set to ONE causes conflicts between the operating system and NetBackup or Storage Migrator's use of SCSI reserve/release commands.
2. Reboot your system.

Cautions with Using the HP-UX EMS Tape Device Monitor

This is a NetBackup Enterprise Server topic.

The Tape Device Monitor (`dm_stape`) of the Event Monitoring System (EMS) should be configured to *not* run on hosts participating in a tape SAN configuration. Part of the EMS service periodically polls the tape devices to monitor their condition. When this occurs from one server while another server is using the tape device, it may interfere with backup operations causing those operations to time out and abort.

The problem can be avoided in either of the following ways:

- ◆ If you want to completely disable EMS you can run the `/etc/opt/resmon/sbin/monconfig` tool and select (K) `kill (disable) Monitoring`.
- ◆ If the `POLL_INTERVAL` value in the `/var/stm/config/tools/monitor/dm_stape.cfg` file is set to zero, EMS will still run, but it will not log any events or poll the devices (that is, it will not send any SCSI commands).

No Rewind Device Files

When adding tape drives to the Media Manager configuration, you need only specify a no rewind on close device file path. These device files are found in the `/dev/rmt` directory and have the following format:

```
/dev/rmt/cCONTROLLERtTARGETdUNITBESTnb
```

Where:

- ◆ `CONTROLLER` is the Instance number of the controlling bus. The Instance value is displayed in `ioscan -f` output under the column I of the controllers entry (ext_bus in the Class column).
- ◆ `TARGET` is the SCSI ID of the tape drive.
- ◆ `UNIT` is the SCSI logical unit number (LUN) of the drive. This is usually 0.

If the desired tape device file does not exist, you can create device files using the `sam` utility or with the following `mksf (1M)` command:

```
mksf -C tape -H H/W_Path -b BEST -u -n
```

Where *H/W_Path* is the hardware path of the tape drive as specified by `ioscan`.

No Rewind Device File Example

Assume that the desired 4-mm DDS2 compression tape drive is at SCSI ID 2 and `ioscan -f` shows the following:

| Class | I | H/W Path | Driver | S/W State | H/W Type | Description |
|---------|---|-----------|--------|-----------|-----------|--------------------------|
| ===== | | | | | | |
| bc | 0 | | root | CLAIMED | BUS_NEXUS | |
| bc | 1 | 56 | bc | CLAIMED | BUS_NEXUS | Bus Converter |
| ext_bus | 0 | 56/52 | scsi1 | CLAIMED | INTERFACE | HP 28655A-SCSI Interface |
| target | 0 | 56/52.2 | target | CLAIMED | DEVICE | |
| tape | 0 | 56/52.2.0 | tape2 | CLAIMED | DEVICE | HP HPC1533A |
| . | | | | | | |
| . | | | | | | |
| . | | | | | | |

The Instance number for the controlling bus is 0 and the H/W path for the tape drive is `56/52.2.0`.

The command to create the device file for the drive follows:

```
mksf -C tape -H 56/52.2.0 -b BEST -u -n
```

This creates the following device file, which you specify to Media Manager:

```
/dev/rmt/c0t2d0BESTnb
```



Configuring Optical Disk Drives

When adding optical disk drives to the Media Manager configuration, you need only specify a character device path. Optical disk character device files are found in the `/dev/rdisk` directory and have the following format:

```
/dev/rdisk/cBItTARGETd0
```

Where:

- ◆ *BI* is the bus Instance number of the controlling bus. The Instance value is displayed in `ioscan` output under the column *I* of the `ext_bus` entries.
- ◆ *TARGET* is the SCSI ID of the drive. This ID is in the third position of the H/W Path as displayed by `ioscan`. For example, in 56/52.5.0 the SCSI ID is 5.

You can determine the bus Instance using `ioscan -C ext_bus -f`. The output is similar to the following example:

| Class | I | H/W Path | Driver | S/W State | H/W Type | Description |
|---------|---|----------|--------|-----------|-----------|-------------------------------|
| ===== | | | | | | |
| ext_bus | 0 | 56/52 | scsi1 | CLAIMED | INTERFACE | HP 28655A- SCSI Interface |
| ext_bus | 1 | 56/53 | lpr2 | CLAIMED | INTERFACE | HP 28655A- Parallel Interface |

You can determine the configured drives using `ioscan -C disk -f`. The output is

| Class | I | H/W Path | Driver | S/W State | H/W Type | Description |
|-------|---|-----------|--------|-----------|----------|-------------|
| ===== | | | | | | |
| disk | 1 | 56/52.1.0 | disc3 | CLAIMED | DEVICE | HP C1716T |
| disk | 2 | 56/52.2.0 | disc3 | CLAIMED | DEVICE | HP C1716T |
| disk | 3 | 56/52.5.0 | disc3 | CLAIMED | DEVICE | HP C2490AM |
| disk | 4 | 56/52.6.0 | disc3 | CLAIMED | DEVICE | HP C2490AM |

Example of an Optical Disk Device File

Assume you are using the two optical disk drives at SCSI IDs 1 and 2 as shown in the previous `disk ioscan` example. These drives are on bus 56/52, which as shown in the previous `ext_bus ioscan`, is bus Instance 0.

The character device file paths that you specify to Media Manager follow:

For target 1:

```
/dev/rdisk/c0t1d0
```

For target 2:

```
/dev/rdisk/c0t2d0
```

Using the Configure Storage Devices Wizard with Optical Disk Drives

The Media Manager device configuration wizard can discover and automatically configure optical disk drives that have a `/dev/sct1` SCSI passthru device file.

Note Optical disk drives are not supported in an SSO configuration.

▼ To use the device configuration wizard

1. Create the passthru device files.

See “Configuring Device Files for the sctl Passthru Driver” on page 56 for instructions.

2. Start the wizard from the list of wizards displayed in the right pane of the **Media and Device Management** window of the NetBackup Administration Console.

Select **Configure Storage Devices**.

See the *VERITAS NetBackup Media Manager System Administrator's Guide for UNIX and Linux* or the *VERITAS NetBackup Media Manager System Administrator's Guide for Windows* for more information on using this wizard.

Handling Errors when More Than 10 NetBackup Jobs are Active

If you have an HP-UX master server and more than 10 NetBackup jobs are active, additional jobs may fail with NetBackup 81 errors (the Media Manager volume daemon (vmd) is not active).

This error indicates that the operating system has exceeded the number of processes that can have undo operations pending on a given semaphore. These errors will continue to occur until the number of active jobs falls below 10.

In these cases, VERITAS recommends modifying the HP-UX kernel parameters to increase the value of `semmnu` by at least the number of desired concurrently active jobs greater than 10. (The default value for `semmnu` is 30.)



▼ **To modify the kernel**

The following procedure uses the `/usr/sbin/sam` utility to change the value of `semmnu` to 50. A reboot is necessary for the changes to take effect. See the appropriate HP-UX documentation for information on using this utility.

1. Select **SAM Kernel Configuration**.
2. Select **SAM Configurable Parameters**.
3. Select **semmnu**.
4. Select **Actions** from the menu bar.
5. Select **Modify Configurable Parameter** from the menu.
6. Select **Formula/Value** and enter 50.
7. Select **OK** to save the value.
8. Select **Actions** from the menu bar.
9. Select **Process New Kernel** from the menu to process the kernel modifications and exit the utility.

Command Summary

The following is a summary of commands that may be useful when configuring and verifying devices. See the procedures in this chapter for examples of usage.

```
ioscan -C TYPE -f
```

Shows information about the physical interfaces. Numeric information is displayed in decimal. *TYPE* is the type of interface as follows:

`spt` specifies SCSI robotic controls.

`tape` specifies tape drives.

`disk` specifies optical disks.

`ext_bus` specifies SCSI controllers.

```
mknod /dev/spt/Name c Major 0xIITL00
```

Creates device files for SCSI robotic or tape drive controls.

Name is the device name as defined in the format: *cCONTROLLERtTARGETlUNIT*

Major is the character major number (from the `lsdev` command).

II are the two hexadecimal digits identifying the controlling bus interface card by its Instance number. The Instance value is displayed in the `ioscan` output under the `I` column of the proper `ext_bus` entry.

T is one hexadecimal digit for the SCSI ID of the robotic control.

L is one hexadecimal digit for the SCSI LUN of the robotic control.

```
lsdev -d spt
```

Displays information about the SCSI robotic control drivers.

```
mksf -C tape -H H/W_Path -b BEST -u -n
```

Creates device files for tape drives. Where *H/W_Path* is the hardware path of the tape drive, as specified by `ioscan`.





This chapter explains how to configure storage devices for use with Media Manager running on an HP Alpha system.

After configuring the hardware, use one of the available Media Manager configuration interfaces to add the drives and robots to your Media Manager configuration

The main topics included in this chapter are

- ◆ “Before You Start” on page 74
- ◆ “Configuring Robotic Controls” on page 74
- ◆ “Configuring Tape Drives” on page 75
- ◆ “Command Summary” on page 81



Before You Start

Observe the following points when performing the configurations described in this chapter:

- ◆ The VERITAS support web site (<http://www.support.veritas.com>) contains server platform compatibility information for a number of vendors and products (see the NetBackup Product > Compatibility area of the site). Verify that your server platform is supported before configuring devices.
- ◆ For NetBackup to recognize and communicate with connected devices and for device discovery to discover devices, NetBackup issues SCSI pass-thru commands to the devices in a configuration.

Device files must exist that follow the naming conventions explained in “Configuring Robotic Controls” on page 74 and “Configuring Tape Drives” on page 75. The operating system creates all device files automatically.

- ◆ Use `/sbin/hwmgrr` to verify that the devices are configured correctly. Make sure you can “see” your devices on the SAN before you install and configure the SSO option.

Configuring Robotic Controls

Robots are controlled through a SCSI or a network connection. Robot control configuration is explained as follows:

- ◆ SCSI robotic control is covered in the following section.
- ◆ Configuration for network controlled robotic libraries is discussed in the appendices of the *VERITAS NetBackup Media Manager System Administrator's Guide for UNIX and Linux* or the *VERITAS NetBackup Media Manager System Administrator's Guide for Windows*.

Configuring SCSI Robotic Controls

Read this topic if you plan to use a robotic storage device that is controlled through a SCSI robotic connection. Information on supported SCSI robots (vendor models) can be found on the VERITAS support web site.

When communicating with SCSI-controlled robotic peripherals, Media Manager robotic software utilizes the SCSI passthru capability of the media changer driver. The Tru64 UNIX kernel does not have to be changed to use this driver since this driver is part of basic Tru64 UNIX.

Creating SCSI Robotic Control Device Files

Media Manager requires that device files from the `/dev/changer` directory are used to configure SCSI robotic control. These files are created by the operating system at boot time.

To display devices that are available on the system, use the following command:

```
# hwmgr -view devices
```

| HWID: | Device Name | Mfg | Model | Location |
|-------|--------------------|---------|------------------|--------------------|
| 3: | /dev/kevm | | | |
| 34: | /dev/disk/floppy0c | | 3.5in floppy | fdi0-unit-0 |
| 55: | /dev/disk/cdrom0c | COMPAQ | CDR-8435 | bus-1-targ-0-lun-0 |
| 56: | /dev/disk/dsk0c | DEC | RZ2DD-KS (C) DEC | bus-2-targ-0-lun-0 |
| 57: | /dev/disk/dsk1c | DEC | RZ2DD-KS (C) DEC | bus-2-targ-1-lun-0 |
| 58: | /dev/disk/dsk2c | DEC | RZ2DD-KS (C) DEC | bus-2-targ-2-lun-0 |
| 70: | /dev/changer/mc0 | | C6280-4000 | bus-2-targ-3-lun-0 |
| 71: | /dev/ntape/tape6 | Quantum | DLT4000 | bus-2-targ-4-lun-0 |

Example of SCSI Robotic Control Device File

The previous output from the `hwmgr` command shows an HP C6280 robot connected on bus 2 at SCSI ID 3, lun 0. The corresponding device file is `/dev/changer/mc0`. This file should be used to configure the device in Media Manager.

Configuring Tape Drives

Read the following topics if you plan to use tape drives:

Fast-Tape Positioning (locate-block)

For most drive types, Media Manager supports the SCSI `locate-block` command for positioning a tape to a specific block.

NetBackup uses the `locate-block` command by default unless you disable it by executing the following:

```
touch /usr/opensv/volmgr/database/NO_LOCATEBLOCK
```

With `locate-block` positioning disabled, NetBackup uses the `forward-space-file/record` method of tape positioning.



Adding Standard Tape Drives

Media Manager requires that no rewind on close device files are used to configure tape drives. These files are created by the operating system at boot time. The device files are located in the `/dev/ntape` directory and have the following format:

```
/dev/ntape/tapeID_dDENSITY
```

Where:

- ◆ *ID* is the identification number of the tape device.
- ◆ Values for *DENSITY* can be 0 - 7. Typically, 1 (for high density) is used.

To display devices that are available on the system, use the following command:

```
# hwmgr -view devices
```

| HWID: | Device Name | Mfg | Model | Location |
|-------|--------------------|---------|--------------|------------------------|
| 3: | /dev/kevm | | | |
| 34: | /dev/disk/floppy0c | | 3.5in floppy | fdi0-unit-0 |
| 55: | /dev/disk/cdrom0c | COMPAQ | CDR-8435 | bus-1-targ-0-lun-0 |
| 56: | /dev/disk/dsk0c | DEC | RZ2DD-KS (C) | DEC bus-2-targ-0-lun-0 |
| 57: | /dev/disk/dsk1c | DEC | RZ2DD-KS (C) | DEC bus-2-targ-1-lun-0 |
| 58: | /dev/disk/dsk2c | DEC | RZ2DD-KS (C) | DEC bus-2-targ-2-lun-0 |
| 70: | /dev/changer/mc0 | | C6280-4000 | bus-2-targ-3-lun-0 |
| 71: | /dev/ntape/tape6 | Quantum | DLT4000 | bus-2-targ-4-lun-0 |

No Rewind Device File Example

The previous output from the `hwmgr` command shows a Quantum DLT 4000 tape drive connected on bus 2 at SCSI ID 4, lun 0. The corresponding device file is `/dev/ntape/tape6`.

After adding a density suffix of `_d1` (for high density) the device file is `/dev/ntape/tape6_d1`. This file should be used to configure the device in Media Manager.

Adding Nonstandard Tape Drives

This topic applies to the following drive types:

- ◆ HP LTO
- ◆ Seagate LTO
- ◆ STK 9840

Some types of tape drives require changes to the kernel before you can use them on Tru64.

▼ To change the kernel

Refer to the following man pages for more information on Dynamic Device Recognition (DDR):

- ◆ `ddr.dbase(4)`
- ◆ `ddr_config(8)`

1. Add the appropriate device-specific entries to the `/etc/ddr.dbase` file (see “Device-Specific Entry for HP Ultrium 460” on page 77 and the other device entries that follow).
2. Compile the `/etc/ddr.dbase` file using the `ddr_config` (Dynamic Device Recognition) utility to create the `ddr.db` file.

Device-Specific Entry for HP Ultrium 460

```
#
# Matches "Ultrium"
#
Type = tape
Name = "HP" "Ultrium"
#
PARAMETERS:
TypeSubClass      = lto                # Linear Tape Open
BLockSize         = 262144
TagQueueDepth     = 0
MaxTransferSize   = 0xffffffff        # (16MB - 1)
ReadyTimeSeconds  = 120                # seconds
SyncTransfers     = enabled
WideTransfers     = enabled
InquiryLength     = 0x20

DENSITY:
DensityNumber     = 0,1,2,3,4,5,6,7
OneFileMarkOnClose = yes
```



```
DensityCode          = 0x42
Blocking             = 0
CompressionCode      = 1
Buffered             = 1
Speed                = 0
#
# Ultrium mode select parameters for rewind after reset behavior
#
MODESELECT:
ModeSelectNumber     = 0
SavePage             = No
PageFormat           = scsi2
BlockDescriptor      = yes
TransferLength       = 16
Hdr.Tape.BufferMode  = 0x1
Hdr.MediumType       = 0
Data.UBYTE[0]        = 0x3D      #Vendor Unique Page Code 0x3D
Data.UBYTE[1]        = 0x02
Data.UBYTE[2]        = 0x01
Data.UBYTE[3]        = 0x00
```

Device-Specific Entry for HP Ultrium 230e

```
SCSIDEVICE
Type = tape
Name = "HP          " "Ultrium"

PARAMETERS:
MaxTransferSize = 0xffffffff
ReadyTimeSeconds = 0x2d
InquiryLength = 0x20

DENSITY:
DensityNumber = 0
OneFileMarkOnClose = yes
DensityCode = 0x00
Blocking = 0
CompressionCode = 0x0
Buffered = 0x1
```



```
DENSITY:
DensityNumber = 1
OneFileMarkOnClose = yes
DensityCode = 0x00
Blocking = 0
CompressionCode = 0x1
Buffered = 0x1
```

Device-Specific Entry for Seagate Viper 200 - LTO

```
SCSIDEVICE
Type = tape
Name = "SEAGATE" "ULTRIUM"
```

```
PARAMETERS:
TypeSubClass          = tk
TagQueueDepth         = 0
MaxTransferSize       = 0xffffffff # (16MB - 1)
ReadyTimeSeconds      = 180 # seconds
CMD_PreventAllow      = supported
CMD_ExtReserveRelease = supported
BlockSize            = 0
PwrMgmt_Capable       = false
```

```
DENSITY:
DensityNumber = 0,2,3,4,5,6,7
DensityCode   = default
CompressionCode = 0x0
Buffered      = 0x1
```

```
DENSITY:
DensityNumber = 1
DensityCode   = default
CompressionCode = 0x1
Buffered      = 0x1
```



Device-Specific Entry for STK 9840

```
SCSIDEVICE
Type = tape
Stype = 2
Name = "STK" "9840"
```

```
PARAMETERS:
TypeSubClass      = 3480
BlockSize         = 0
MaxTransferSize   = 0x40000      # 256k
SyncTransfers     = enabled
WideTransfers     = enabled
Disconnects       = enabled
CmdReordering     = disabled
TaggedQueueing    = disabled
TagQueueDepth     = 0
WCE_Capable       = false
PwrMgmt_Capable   = false
LongTimeoutRetry  = disabled
ReadyTimeSeconds  = 240
DisperseQueue     = false
CMD_PreventAllow  = supported
CMD_ExtReserveRelease = supported
```

```
DENSITY:
#
# /dev/tape/tapeX_d0, _d4
#
DensityNumber = 0,4
DensityCode = 0x42
CompressionCode = 0
Buffered = 0x1
#
DENSITY:
#
# /dev/tape/tapeX_d1, _d5
#
DensityNumber = 1,5
DensityCode = 0x42
CompressionCode = 1
#
```



```
DENSITY:
#
# /dev/tape/tapeX_d2, _d6
#
DensityNumber = 2,6
DensityCode = 0x43
CompressionCode = 0
Buffered = 0x1
```

Command Summary

The following is a summary of commands that may be useful when configuring and verifying devices. See the procedures in this chapter for usage examples.

```
hwmgr -view devices
```

Displays all devices on the system.





This chapter explains how to configure devices for use with Media Manager on an Intel host platform running Linux. After configuring the hardware, use one of the available Media Manager configuration interfaces to add the drives and robots to your Media Manager configuration.

The main topics included in this chapter are as follows:

- ◆ “Before You Start” on page 84
- ◆ “Configuring Robotic Controls” on page 86
- ◆ “Configuring Tape Drives” on page 88
- ◆ “Verifying The Device Configuration” on page 89
- ◆ “Other Considerations (Advanced Topics)” on page 89
- ◆ “Utilities to Test SCSI Devices” on page 91
- ◆ “Command Summary” on page 92



Before You Start

Observe the following important points when performing the tasks described in this chapter:

- ◆ The VERITAS support web site (<http://www.support.veritas.com>) contains server platform compatibility information for a number of vendors and products (see the NetBackup Product > Compatibility area of the site). Verify that your server platform is supported before configuring devices.
- ◆ For NetBackup to recognize and communicate with connected devices and for device discovery to discover devices, NetBackup issues SCSI pass-thru commands to the devices in a configuration.

Device files must exist that follow the naming conventions explained in “Configuring Robotic Controls” on page 86 and “Configuring Tape Drives” on page 88. A built-in pass-thru driver (SG) is available.

- ◆ Verify that the st (tape) device driver is installed or loaded in the kernel. This driver allows the use of SCSI tape drives.
- ◆ Verify that the sg device driver is installed or loaded in the kernel. This driver allows passthru commands to SCSI tape drives and control of robotic devices.

Use the `/sbin/lsmmod` command to display and verify that these modules are loaded in the kernel. Example output is as follows:

| Module | Size | Used by |
|--------|-------|---------|
| sg | 14844 | 0 |
| st | 24556 | 0 |

The standard Enterprise Linux releases have these modules available for loading. When running Enterprise Linux, these modules are dynamically loaded as needed. It is also possible to load these modules if they are not in the kernel. Use the following commands:

```
/sbin/modprobe st  
/sbin/modprobe sg
```

- ◆ For Linux distributions using the 2.4 kernel, the binary `/usr/opensv/volmgr/bin/make_scsi_dev` will execute during NetBackup installation (and also at boot time). The binary does the following:
 - ◆ Creates the directories `/dev/sg` and `/dev/st`.
 - ◆ Obtains the device file output generated by the sg and st drivers.
 - ◆ Creates device files for each tape device and library of the format required by Media Manager and places them in these directories.

- ◆ Establishes a default tape driver operating mode. If the operator changes the default mode, NetBackup may be unable to correctly read and write tape media, resulting in data loss.

In particular, never set `MT_ST_ASYNC_WRITES`, or `MT_ST_SYSV` to the value one. Never set `MTSETBLK` to a non-zero value. Do not interfere with the execution of `make_scsi_dev` at system boot (it is called by the `S77netbackup` startup script).

See “Configuring SCSI Robotic Control Device Paths (2.4 kernel)” on page 87 and “Adding Standard Tape Drives (2.4 kernel)” on page 88.

- ◆ For Linux distributions using the 2.6 kernel, `avrd` establishes a default tape driver operating mode. If the operator changes the default mode, NetBackup may be unable to correctly read and write tape media, resulting in data loss
- ◆ Verify that a SCSI low-level driver is installed for each HBA in your system. Refer to your HBA vendor documentation.
 - ◆ Follow the HBA Vendor's installation guide to install or load the driver in the kernel.
 - ◆ Configure the kernel for SCSI tape support, SCSI generic support.
 - ◆ Probe all LUNs on each SCSI device and enable the SCSI low-level driver for the HBA.
 - ◆ Enable multi-LUN support for the kernel according to operating system documentation.
- ◆ Linux kernels previous to 2.4.15 do not support sixteen byte SCSI commands. WORM media is not supported with these HBA's for either LTO-3 or SDLT drives. To override this rule, run:


```
touch /usr/opensv/volmgr/database/SIXTEEN_BYTE_CDB
```
- ◆ Multipath configurations (multiple paths to robots/drives) are supported only with the 2.6 kernel or later, native path (`/dev/nstN`, `/dev/sgN`), and the `sysfs` file system mounted on `/sys`.

Using the Passthru Driver

The SCSI passthru driver and SCSI passthru device paths are required by NetBackup for full feature support. Performance will be degraded if SCSI passthru is not provided. The passthru driver is used

- ◆ By `avrd` and robotic processes to scan drives.
- ◆ By NetBackup and Storage Migrator for locate-block positioning.



- ◆ By NetBackup and Storage Migrator for SAN error recovery.
- ◆ By NetBackup and Storage Migrator for Quantum SDLT performance optimization.
- ◆ By NetBackup and Storage Migrator for SCSI reserve/release.
- ◆ By the NetBackup device configuration GUIs to collect robot and drive information.
- ◆ To collect TapeAlert information from tape devices allowing support of functions such as tape drive cleaning.
- ◆ For WORM tape support.
- ◆ Future NetBackup features and enhancements

Enabling Passthru Paths

Several sg device files are provided by default in the typical Linux installation. If you have more devices than the default number provided, you must create the required device files.

There must be a `/dev/sgN` entry for each device. These entries are needed by `make_scsi_dev`, which is run during the NetBackup installation.

If you have devices that are not being discovered by Media Manager device discovery, it may be because the Linux default number of these entries is not sufficient. You may need to create additional entries.

Configuring Robotic Controls

To use robotics, the following drivers must be configured in the kernel or loaded as modules:

- ◆ Standard SCSI driver.
- ◆ SCSI-adaptor driver.
- ◆ Linux SCSI generic (sg) driver.

Information on supported SCSI robots (vendor models) can be found on the VERITAS support web site.

Configuring SCSI Robotic Control Device Paths (2.4 kernel)

The binary `/usr/opensv/volmgr/bin/make_scsi_dev` creates device files in the `/dev/sg` directory. The names of these files in this directory have the following format:

```
hHOSTcCHANNELtTARGETlLUN
```

Where:

- ◆ *HOST* is the host bus adaptor.
- ◆ *CHANNEL* is channel.
- ◆ *TARGET* is the target ID.
- ◆ *LUN* is the logical unit number.

Use the files in the `/dev/sg` directory for the robotic path when using Media Manager interfaces to configure robots.

There must be a `/dev/sgN` entry (where *N* is a decimal number from 0 to 255) for each device. These entries are needed by `make_scsi_dev`, which is run during the NetBackup installation.

If you have devices that are not being discovered by Media Manager device discovery, it may be because the Linux default number of these entries is not sufficient. You may need to create additional entries.

Create device entries as follows, where *N* is a decimal number from 0 to 255. After creating all entries necessary, rerun `make_scsi_dev`.

```
mknod /dev/sgN c 21 N
```

Examples of SCSI Robotic Control Device Files

```
h10c0t110
h10c0t210
h10c0t310
h25c0t010
h25c0t110
```

Configuring SCSI Robotic Control Device Paths (2.6 kernel)

Robotic control is provided by the SG driver, which includes a device file for each device in the system. These device files have the format `/dev/sgN`, where *N* is a decimal number from 0 to 255.



Configuring Tape Drives

To use SCSI tape drives, the following drivers must be configured in the kernel or loaded as modules:

- ◆ Standard SCSI driver
- ◆ SCSI-adaptor driver
- ◆ SCSI tape (st) driver
- ◆ Linux SCSI generic (sg) driver

▼ To create device entries (2.4 kernel)

1. Run `mknod /dev/sgN c 21 N`. *N* is a decimal number from 0 to 255.
2. Run `make_scsi_dev`.

Adding Standard Tape Drives (2.4 kernel)

`make_scsi_dev` creates device files in the `/dev/st` directory. The names of the no rewind device files in this directory have the following format:

`nhHOSTcCHANNELtTARGETlLUN`

Where:

- ◆ *n* is the no rewind on close device file.
- ◆ *HOST* is the host bus adaptor.
- ◆ *CHANNEL* is channel.
- ◆ *TARGET* is the target ID.
- ◆ *LUN* is the logical unit number.

When adding tape drives to a Media Manager configuration, you need to specify a no rewind on close device path. Use the files in the `/dev/st` directory when configuring tape drives.

Examples of SCSI Tape Device Files

`nh10c0t210`
`nh10c0t310`

Adding Standard Tape Drives (2.6 kernel)

Tape devices have multiple device files. However, NetBackup uses only the `/dev/nstX` file where `X` is a decimal number from 0 to 127.

Verifying The Device Configuration

The file `/proc/scsi/scsi` shows all devices recognized by the SCSI driver. To verify that the operating system can see the devices, run the following command from a terminal window to view this file:

```
cat /proc/scsi/scsi
```

The output displayed should be similar to the following example:

```
Attached devices:
Host: scsi0 Channel: 00 Id: 01 Lun: 00
Vendor: HP          Model: C7200-8000      Rev: 1040
Type:   Medium Changer          ANSI SCSI revision: 03
Host: scsi0 Channel: 00 Id: 02 Lun: 00
Vendor: QUANTUM     Model: DLT8000         Rev: 010F
Type:   Sequential-Access       ANSI SCSI revision: 02
Host: scsi0 Channel: 00 Id: 03 Lun: 00
Vendor: QUANTUM     Model: DLT8000         Rev: 010F
Type:   Sequential-Access       ANSI SCSI revision: 02
```

If the operating system can see your SCSI devices, Media Manager device discovery will also see the devices.

Other Considerations (Advanced Topics)

You may require the following advanced topics.

Support for Additional Tape Devices

The `st` tape driver supports up to 32 tape devices in its default configuration. This configuration provides eight minor device numbers. The driver can be re-configured to support up to 64 tape devices (with four minor device numbers) or up to 128 tape devices (with two minor device numbers).



Since NetBackup uses only one minor number, you can modify the driver and support up to 128 tape devices. The `st.h` source file, found in the Linux source directory `/drivers/scsi`, must be modified to change the number of devices that will be supported as shown in the following table:

| Number of Tape Devices Supported | Original Value | New Value |
|----------------------------------|---|---|
| 64 | <code>#define ST_NBR_MODE_BITS 2</code> | <code>#define ST_NBR_MODE_BITS 1</code> |
| 128 | <code>#define ST_NBR_MODE_BITS 2</code> | <code>#define ST_NBR_MODE_BITS 0</code> |

Improving Performance

The `st` tape driver has internal buffers that have a default size of 32K. Performance may be enhanced if they are set to match the default block size used by `bptm`. The default block size for `bptm` is 64K. Edit the `st_options.h` file as shown in the following table:

| Original Value | New Value |
|--|--|
| <code>#define ST_BUFFER_BLOCKS 32</code> | <code>#define ST_BUFFER_BLOCKS 64</code> |

You also may need to change the following entry to have a smaller value depending on the available system memory:

```
#define ST_MAX_BUFFERS 4
```

Follow the operating system guidelines for incorporating these source changes into your system.

Using the Debug Mode

The `st` tape driver can be put into a debug mode. This mode will echo each command and its result to the syslog. See your operating system documentation for details.

Using an Emulex HBA

If NetBackup is unable to mount tapes when using an Emulex HBA in a fibre channel configuration, it may be necessary to modify the `lpfc.conf.c` file.



Set `lpfc_check_cond_err` to a value of zero. NetBackup is unable to mount tapes if this variable is left at a value of one.

The use of the touch file `/usr/opensv/volmgr/AVRD_DEBUG` on a system with the Emulex HBA driver may cause the system log (syslog) to contain many entries that look like the following. You can ignore these messages.

```
Unknown drive error on DRIVENAME (device N, PATH) sense[0] = 0x70,  
sense[1] = 0x0, sensekey = 0x5
```

Using Persistent Binding

Persistent bindings should be used to lock the mappings between SCSI Targets reported to Linux and specific devices. WWPN binding is often used. If binding is not possible with the HBA in your configuration, then add an `ENABLE_AUTO_PATH_CORRECTION` entry in the `/usr/opensv/volmgr/vm.conf` file on all Linux media servers.

Utilities to Test SCSI Devices

You can manipulate tape devices with the system `mt` command. The man page for `MT(1)` explains how to do this.

Robots can be tested using the `robtest` utility in `/usr/opensv/volmgr/bin`.

There is also a set of SCSI utilities available from the Linux SCSI Generic (sg) driver home page.



Command Summary

The following is a summary of commands that may be useful when configuring devices. See the appropriate sections of this chapter for examples of their usage.

`/sbin/lsmmod`

List loaded modules.

`/sbin/modprobe`

Install loadable kernel modules.

`/usr/sbin/reboot`

Stop and restart the system.

`/bin/mknod /dev/sgN c 21 N`

Create SCSI generic device files. Where *N* is a decimal number from 0 to 255.

`/usr/opensv/volmgr/bin/make_scsi_dev`

Create NetBackup device files for Linux distributions running the 2.4 kernel. For Linux distributions running the 2.6 kernel, this command is not used.

This chapter explains how to configure storage devices and install tape device drivers for use with Media Manager on a platform running Microsoft Windows.

After configuring the hardware, use one of the available Media Manager configuration interfaces to add the drives and robots to your Media Manager configuration

The main topics included in this chapter are the following:

- ◆ “Before You Start” on page 94
- ◆ “Installing Tape Device Drivers on 32 Bit Servers” on page 94
- ◆ “Installing Tape Device Drivers on 64 Bit Servers” on page 96



Before You Start

Observe the following points when performing the configurations described in this chapter:

- ◆ The VERITAS support web site (<http://www.support.veritas.com>) contains server platform compatibility information for a number of vendors and products (see the NetBackup Product > Compatibility area of the site). Verify that your server platform is supported before configuring devices.
- ◆ For NetBackup to recognize and communicate with connected devices and for device discovery to discover devices, NetBackup issues SCSI pass-thru commands to the devices in a configuration.

A tape driver must exist for each tape device. Attached devices appear in the registry.

- ◆ Use the Microsoft Windows device applications to verify that the devices are configured correctly. The device applications available on your server may differ depending on your Windows operating system. Make sure you can “see” your devices on the SAN before you install and configure the SSO option.
- ◆ If you have multiple devices connected to a fibre bridge, Windows may only see one LUN. This will normally be the device with the lowest-ordered LUN.

This limitation occurs because of the default install settings for the device driver for some fibre channel HBAs. See your vendor documentation to verify the settings.

Installing Tape Device Drivers on 32 Bit Servers

When installing NetBackup for the first time, VERITAS recommends that you install the device drivers for your storage device *after* you install NetBackup software and *before* you configure NetBackup.

If you are upgrading NetBackup, you can install the latest tape device drivers before you upgrade NetBackup.

Use the device driver install wizard to install the latest device drivers.

▼ To obtain device driver installation software

If you do not have a CD-ROM, you can download the NetBackup Tape Device Driver installation software from the VERITAS support web site.

<http://www.support.veritas.com>



▼ **To use the Device Driver Installer wizard**

This wizard (located on the NetBackup CD) guides you through the installation of the latest device drivers.

1. Log in as Administrator on the server where you installed NetBackup.

2. Insert the NetBackup CD-ROM in the drive.

On Windows systems with AutoPlay enabled for CD-ROM drives, the NetBackup installation browser starts automatically.

On Windows systems that have AutoPlay for CD-ROM drives disabled, run `Launch.exe` from the top-level directory on the CD-ROM.

3. In the VERITAS CD Browser, click **Additional Products > Additional Product Installations > NetBackup Tape Device Drivers**.

The Device Driver Installer wizard starts.

4. Follow the prompts in the wizard to install device drivers for your storage device.

On the **Choosing tape drivers** screen of the wizard, select **Use VERITAS tape drivers for all tape devices** and **Use Plug and Play drivers**.

Use the **More Information** button for explanations of the available choices.

5. On the **Installing VERITAS drivers** screen of the wizard, a warning message may be displayed when the device drivers are installed indicating that the driver has not been Windows Logo tested to verify its compatibility with Windows.

This is a standard Microsoft Windows warning. System and driver performance will not be affected, and you can safely ignore the messages. VERITAS device drivers go through a similar testing process and they are digitally signed drivers.

6. At the completion of the wizard, be sure to reboot your system.

The drivers are installed in the following Windows directory.

`C:\WINNT\system32\drivers`

▼ **To determine the version of a device driver**

The drivers are installed in the following Windows directory:

`C:\WINNT\system32\drivers`

The device driver files do not have a version number. To determine the version of a device driver file, use the Modified date found in the file Properties dialog (right click on the driver file name).



▼ **To obtain the latest tape device drivers**

Visit the VERITAS support web site.

<http://www.support.veritas.com>

Installing Tape Device Drivers on 64 Bit Servers

VERITAS does not provide device drivers for 64 bit servers. Contact Microsoft or the tape drive vendor to obtain these drivers.

Index

A

- accessibility features xii
- ACS (see Automated Cartridge System)
- AIX (see RS6000)
- AL-PA destination ID, Sun4/SPARC 13
- AT&T style close 16, 62
- atdd driver, HP9000 64
- Automated Cartridge System,
Sun4/SPARC 6

B

- Berkeley-style close
 - HP9000 62
 - Sun4/SPARC 16
- boot -r, Sun4/SPARC 26

C

- cfgmgr command 52
- chdev command 39, 52
- command summary
 - for RS6000 51
 - HP Alpha 81
 - HP9000 70
 - Linux 92
 - Sun4/SPARC 26

D

- D_ID 33
- device configuration sequence 3
- device discovery 3
- device driver install wizard, Windows 94
- device drivers
 - ovpass 30
 - sd, Sun4/SPARC 25
 - sg, Linux 84
 - sg, Sun4/SPARC 13
 - spt (SCSI passthru), HP9000 60
 - st, Linux 84
 - st, Sun4/SPARC 22
 - Windows 94

E

- editing the st.conf file, Sun4/SPARC 19
- extended file marks 39

F

- fabric assigned destination ID,
Sun4/SPARC 13
- fast-tape positioning (see locate-block)
- fibre channel
 - binding process, Sun4/SPARC 12
 - configuration 59
 - drivers 7
- fixed length block 39
- fixed mode devices, Sun4/SPARC 19
- forward-space-file/record, HP9000 65

H

- HP 1.2 GB optical
 - on RS6000 30, 45
- HP Alpha
 - Dynamic Device Recognition 77
 - locate-block 75
 - SCSI robotic controls 74
- HP LTO, HP Alpha 77
- HP optical disk
 - HP9000 68
 - on RS6000 45
 - Sun4/SPARC 23
- HP9000
 - optical disk configuration, make device files 68
 - SCSI robotic controls 55
 - make device files 57, 60
 - spt (SCSI passthru) driver 60
 - tape drive configuration
 - Berkeley-style close 62
 - make device files 67
- hwmgr command, HP Alpha 75, 76



I

- IBM RS6000 (see RS6000)
- install_ovpass script 30, 51
- installing 32 bit tape device drivers, Windows 94
- installing 64 bit tape device drivers, Windows 96
- ioscan command, HP9000 70

K

- kernel changes
 - HP Alpha 77
 - HP9000 66

L

- Linux
 - loading drivers 84
 - verifying the device configuration 89
- locate-block
 - HP Alpha 75
 - on RS6000 40
 - Sun4/SPARC 16
- logical unit numbers, Sun4/SPARC 23
- lsattr command 52
- lsdev command
 - HP9000 71
 - on RS6000 51
- lsmod command
 - Linux 84

M

- make_scsi_dev command
 - Linux 84
- Media Manager Device Configuration wizard, HP9000 63, 69
- mkdev command 51
- mknod command, HP9000 71
- modinfo command, Sun4/SPARC 26
- modprobe command
 - Linux 84
- mt command
 - Linux 91

N

- N_Port address 33
- NetBackup 81 errors 69
- NetBackup Enterprise Server x, 1, 66
- NetBackup Server x, 1, 54

O

- odmget command 52

- optical disk

 - HP9000 68
 - on RS6000 45
 - Sun4/SPARC 23

- ovpass driver 30

P

- passthru driver (see SCSI)
- plug and play drivers, Windows 95

R

- rem_drv command, Sun4/SPARC 26
- remove_ovpass command 31, 51
- robotic controls
 - SCSI
 - on RS6000 32, 38
 - SCSI, HP Alpha 74
 - SCSI, HP9000 55
 - SCSI, Linux (2.4 kernel) 87
 - SCSI, Linux (2.6 kernel) 87
 - SCSI, Sun4/SPARC 13
- robtest utility, Red Hat linux 91
- RS6000
 - adapter numbers 28
 - install_ovpass script 30
 - locate-block 40
 - optical disk configuration
 - make device files 45
 - set in nonvolatile memory 48
 - ovpass driver 30
 - installing 30
 - uninstalling 31
 - upgrading 31
 - passthru driver 30
 - remove_ovpass command 31
 - SCSI robotic controls 32, 38
 - make device files 32, 38
 - smit tool 28, 30
 - tape drive configuration
 - extended file marks 39
 - make device files 40
 - multiple densities 43
 - variable mode devices 39

S

- SAM utility, HP9000 66, 70
- SAN media server x
- schgr device driver, HP9000 55
- scripts
 - install_ovpass 30



-
- remove_ovpass 31
 - sg.install, Sun4/SPARC 8
 - sgscan 13, 17, 26
 - SCSI
 - logical unit numbers, Sun4/SPARC 23
 - passthru driver
 - on RS6000 30
 - Sun4/SPARC 7
 - robotic control
 - HP Alpha 74
 - HP9000 55
 - Linux (2.4 kernel) 87
 - Linux (2.6 kernel) 87
 - on RS6000 32, 38
 - spt (SCSI passthru) driver, HP9000 60
 - SCSI reserve/release
 - data integrity 3
 - disabling 3
 - enabling 66
 - scsi_command
 - on RS6000 52
 - Sun4/SPARC 25, 26
 - sd driver, Sun4/SPARC 25
 - Seagate LTO, HP Alpha 77
 - semmnu 69
 - sg driver
 - Linux 84
 - Sun4/SPARC 13
 - sg.build command, Sun4/SPARC 26
 - sg.install script, Sun4/SPARC 8, 26
 - Shared Storage Option (SSO)
 - optical drives 69
 - SCSI reserve/release 66
 - smit command 39
 - spt driver (see SCSI)
 - st driver
 - Linux 84
 - Sun4/SPARC 22
 - st.conf file, Sun4/SPARC 19
 - STK 9840
 - HP Alpha 77
 - Sun4/SPARC
 - adapter card removal 6
 - locate-block 16
 - optical disk configuration, make device files 23
 - optical disk configuration, set in nonvolatile memory 25
 - SCSI passthru driver 7
 - SCSI robotic controls 13
 - sg driver install or reconfigure 8
 - sg.install script 8
 - st driver 22
 - st.conf file 19
 - tape drive configuration
 - Berkeley-style close 16
 - make device files 17
 - variable mode devices 19
 - using ACS 6
 - switch settings, Sony S-AIT
 - on RS6000 44
- T**
- tape drive configuration
 - HP Alpha 76
 - HP9000 67
 - Linux 88
 - on RS6000
 - make device files 40
 - Sun4/SPARC, make device files 17
 - text version of this guide 2
- U**
- using the passthru driver, capabilities 62, 85
 - using the text version of this guide 2
 - using this guide 1
- V**
- variable length block 39
 - variable-mode devices
 - on RS6000 39
 - Sun4/SPARC 19
 - VERITAS Storage Migrator ix
 - VERITAS support web site 2
 - vold (volume manager), Sun4/SPARC 23
- W**
- world wide node names (WWNN) 13
 - world wide port names (WWPN) 12, 13

