

Sun Storage 2500-M2 Arrays

Hardware Release Notes, Release 6.8



Part No.: E22535-02
July 2011

Copyright © 2011, Oracle and/or its affiliates. All rights reserved.

This software and related documentation are provided under a license agreement containing restrictions on use and disclosure and are protected by intellectual property laws. Except as expressly permitted in your license agreement or allowed by law, you may not use, copy, reproduce, translate, broadcast, modify, license, transmit, distribute, exhibit, perform, publish, or display any part, in any form, or by any means. Reverse engineering, disassembly, or decompilation of this software, unless required by law for interoperability, is prohibited.

The information contained herein is subject to change without notice and is not warranted to be error-free. If you find any errors, please report them to us in writing.

If this is software or related software documentation that is delivered to the U.S. Government or anyone licensing it on behalf of the U.S. Government, the following notice is applicable:

U.S. GOVERNMENT RIGHTS. Programs, software, databases, and related documentation and technical data delivered to U.S. Government customers are "commercial computer software" or "commercial technical data" pursuant to the applicable Federal Acquisition Regulation and agency-specific supplemental regulations. As such, the use, duplication, disclosure, modification, and adaptation shall be subject to the restrictions and license terms set forth in the applicable Government contract, and, to the extent applicable by the terms of the Government contract, the additional rights set forth in FAR 52.227-19, Commercial Computer Software License (December 2007). Oracle America, Inc., 500 Oracle Parkway, Redwood City, CA 94065.

This software or hardware is developed for general use in a variety of information management applications. It is not developed or intended for use in any inherently dangerous applications, including applications which may create a risk of personal injury. If you use this software or hardware in dangerous applications, then you shall be responsible to take all appropriate fail-safe, backup, redundancy, and other measures to ensure its safe use. Oracle Corporation and its affiliates disclaim any liability for any damages caused by use of this software or hardware in dangerous applications.

Oracle and Java are registered trademarks of Oracle and/or its affiliates. Other names may be trademarks of their respective owners.

AMD, Opteron, the AMD logo, and the AMD Opteron logo are trademarks or registered trademarks of Advanced Micro Devices. Intel and Intel Xeon are trademarks or registered trademarks of Intel Corporation. All SPARC trademarks are used under license and are trademarks or registered trademarks of SPARC International, Inc. UNIX is a registered trademark licensed through X/Open Company, Ltd.

This software or hardware and documentation may provide access to or information on content, products, and services from third parties. Oracle Corporation and its affiliates are not responsible for and expressly disclaim all warranties of any kind with respect to third-party content, products, and services. Oracle Corporation and its affiliates will not be responsible for any loss, costs, or damages incurred due to your access to or use of third-party content, products, or services.

Copyright © 2011, Oracle et/ou ses affiliés. Tous droits réservés.

Ce logiciel et la documentation qui l'accompagne sont protégés par les lois sur la propriété intellectuelle. Ils sont concédés sous licence et soumis à des restrictions d'utilisation et de divulgation. Sauf disposition de votre contrat de licence ou de la loi, vous ne pouvez pas copier, reproduire, traduire, diffuser, modifier, breveter, transmettre, distribuer, exposer, exécuter, publier ou afficher le logiciel, même partiellement, sous quelque forme et par quelque procédé que ce soit. Par ailleurs, il est interdit de procéder à toute ingénierie inverse du logiciel, de le désassembler ou de le décompiler, excepté à des fins d'interopérabilité avec des logiciels tiers ou tel que prescrit par la loi.

Les informations fournies dans ce document sont susceptibles de modification sans préavis. Par ailleurs, Oracle Corporation ne garantit pas qu'elles soient exemptes d'erreurs et vous invite, le cas échéant, à lui en faire part par écrit.

Si ce logiciel, ou la documentation qui l'accompagne, est concédé sous licence au Gouvernement des Etats-Unis, ou à toute entité qui délivre la licence de ce logiciel ou l'utilise pour le compte du Gouvernement des Etats-Unis, la notice suivante s'applique :

U.S. GOVERNMENT RIGHTS. Programs, software, databases, and related documentation and technical data delivered to U.S. Government customers are "commercial computer software" or "commercial technical data" pursuant to the applicable Federal Acquisition Regulation and agency-specific supplemental regulations. As such, the use, duplication, disclosure, modification, and adaptation shall be subject to the restrictions and license terms set forth in the applicable Government contract, and, to the extent applicable by the terms of the Government contract, the additional rights set forth in FAR 52.227-19, Commercial Computer Software License (December 2007). Oracle America, Inc., 500 Oracle Parkway, Redwood City, CA 94065.

Ce logiciel ou matériel a été développé pour un usage général dans le cadre d'applications de gestion des informations. Ce logiciel ou matériel n'est pas conçu ni n'est destiné à être utilisé dans des applications à risque, notamment dans des applications pouvant causer des dommages corporels. Si vous utilisez ce logiciel ou matériel dans le cadre d'applications dangereuses, il est de votre responsabilité de prendre toutes les mesures de secours, de sauvegarde, de redondance et autres mesures nécessaires à son utilisation dans des conditions optimales de sécurité. Oracle Corporation et ses affiliés déclinent toute responsabilité quant aux dommages causés par l'utilisation de ce logiciel ou matériel pour ce type d'applications.

Oracle et Java sont des marques déposées d'Oracle Corporation et/ou de ses affiliés. Tout autre nom mentionné peut correspondre à des marques appartenant à d'autres propriétaires qu'Oracle.

AMD, Opteron, le logo AMD et le logo AMD Opteron sont des marques ou des marques déposées d'Advanced Micro Devices. Intel et Intel Xeon sont des marques ou des marques déposées d'Intel Corporation. Toutes les marques SPARC sont utilisées sous licence et sont des marques ou des marques déposées de SPARC International, Inc. UNIX est une marque déposée concédée sous licence par X/Open Company, Ltd.

Ce logiciel ou matériel et la documentation qui l'accompagne peuvent fournir des informations ou des liens donnant accès à des contenus, des produits et des services émanant de tiers. Oracle Corporation et ses affiliés déclinent toute responsabilité ou garantie expresse quant aux contenus, produits ou services émanant de tiers. En aucun cas, Oracle Corporation et ses affiliés ne sauraient être tenus pour responsables des pertes subies, des coûts occasionnés ou des dommages causés par l'accès à des contenus, produits ou services tiers, ou à leur utilisation.



Sun Storage 2500-M2 Arrays Hardware Release Notes

This document contains important release information about Oracle's Sun Storage 2500-M2 Arrays managed by Sun Storage Common Array Manager (CAM), Version 6.8.0. Read this document so that you are aware of issues or requirements that can affect the installation and operation of the array.

The release notes consist of the following sections:

- ["Product Overview" on page 2](#)
- ["About the Management Software" on page 2](#)
- ["Downloading Patches and Updates" on page 3](#)
- ["System Requirements" on page 4](#)
- ["Device Mapper Multipath \(DMMP\) for the Linux Operating System" on page 10](#)
- ["Restrictions and Known Issues" on page 17](#)
- ["Related Documentation" on page 22](#)
- ["Documentation, Support, and Training" on page 23](#)

Product Overview

The Sun Storage 2500-M2 Arrays are a family of storage products that provide high-capacity, high-reliability storage in a compact configuration. The controller tray, with two controller modules, provides the interface between a data host and the disk drives. Three array models are offered:

- The Sun Storage 2540-M2 array provides a Fibre Channel (FC) connection between the data host and the controller tray at 8 Gbit/sec.
- The Sun Storage 2530-M2 array provides a Serial Attached SCSI (SAS) connection between the data host and the controller tray at 6 Gbit/sec.
- The Sun Storage 2501-M2 array expansion tray provides additional storage via SAS interface at 6 Gbit/sec. It is connected to either of the above controller tray models.

The Sun Storage 2500-M2 Arrays are modular and rack-mountable in industry-standard cabinets. The arrays are scalable from a single controller tray configuration to a maximum configuration of one controller tray and three expansion trays. The maximum configuration creates a storage array configuration with a total of 48 drives attached behind the controllers.

Use Sun Storage Common Array Manager version 6.8 (or higher) to manage the array. See [“About the Management Software” on page 2](#) for more information.

About the Management Software

Oracle’s Sun Storage Common Array Manager (CAM) software is a key component for the initial configuration and operation of Sun Storage 2500-M2 Arrays hardware. It is installed on a management host cabled to the array via out-of-band Ethernet.

Note: In-band management is also supported.

To download CAM, follow the procedure in the section [“Downloading Patches and Updates” on page 3](#). Then, review the latest *Sun Storage Common Array Manager Quick Start Guide* and *Sun Storage Common Array Manager Installation and Setup Guide* to begin installation. CAM documentation can be found here:

<http://www.oracle.com/technetwork/documentation/disk-device-194280.html>

Downloading Patches and Updates

To download patches and updates from My Oracle Support, including the CAM management software, follow this procedure.

1. Sign in to My Oracle Support:

<https://support.oracle.com>

2. At the top of the page, click the Patches & Updates tab.

3. Search for software and patches in one of two ways:

- If you have a patch number:
 - a. Under the Patch Search section, click the Search tab.
 - b. In the Patch Name or Number field, enter the patch number. For example, 10272123 or 141474-01.
 - c. Click Search.
 - If you do not have a patch number:
 - a. Under the Patch Search section, click the Search tab, and then click the Product or Family (Advanced Search) link.
 - b. Check Include all products in a family.
 - c. In the Product field, start typing the product name. For example, "Sun Storage Common Array Manager (CAM)".
Select the product name when it appears.
 - d. In the Release field, expand the product name, check the release and patches you want to download, and then click Close.
 - e. Click Search.
- 4. Select the patch you want to download.**
- 5. Click ReadMe for a patch description and installation instructions.**
- 6. Click Download for a single patch, or Add to Plan to download a group of patches.**

System Requirements

The software and hardware products that have been tested and qualified to work with Sun Storage 2500-M2 Arrays are described in the following sections. Sun Storage 2500-M2 Arrays require Sun Storage Common Array Manager, Version 6.8.0 (or higher) software.

- [“Firmware Requirements” on page 4](#)
- [“Supported Disk Drives and Tray Capacity” on page 4](#)
- [“Disk Drive Replacement” on page 5](#)
- [“Array Expansion Module Support” on page 5](#)
- [“Data Host Requirements” on page 5](#)

Firmware Requirements

The Sun Storage 2500-M2 Arrays require firmware version 07.77.xx.xx. This firmware version (or higher) is installed on the array controllers prior to shipment and is also delivered with Sun Storage Common Array Manager (CAM), Version 6.8.0.

Firmware is bundled with the CAM software download package. To download CAM, follow the procedure in [“Downloading Patches and Updates” on page 3](#).

Supported Disk Drives and Tray Capacity

[TABLE 1](#) lists the disk capacity, form factor, spindle speed, interface type, interface speed, and tray capacity for supported SAS disk drives for the Sun Storage 2500-M2 arrays.

TABLE 1 Supported Disk Drives

Drive	Description
SAS-2, 300G15K	300-Gbyte 3.5" 15K-RPM SAS-2 drives (6 Gbits/sec); 3600 Gbytes per tray
SAS-2, 600G15K	600-Gbyte 3.5" 15K-RPM SAS-2 drives (6 Gbits/sec); 7200 Gbytes per tray

Disk Drive Replacement

When inserting a replacement disk drive, be sure the role of the replacement drive is “unassigned” to a virtual disk. All data will be erased before the controller reconstructs the data on the replacement disk drive.



Caution – Potential for data loss—Use care when determining what disk drive to use as a replacement for a failed disk drive. All data on the replacement disk drive will be erased before data reconstruction occurs.

Array Expansion Module Support

The Sun Storage 2530-M2 and 2540-M2 arrays can be expanded by adding Sun Storage 2501-M2 array expansion trays. To add capacity to an array, refer to the following Service Advisor procedures:

- Adding Expansion Trays
- Upgrade Firmware



Caution – To add trays with existing stored data, contact Oracle Support for assistance to avoid data loss.

Data Host Requirements

- [“Multipathing Software” on page 5](#)
- [“Supported Host Bus Adaptors \(HBAs\)” on page 7](#)
- [“Supported FC and Multilayer Switches” on page 9](#)

Multipathing Software

[TABLE 2](#) and [TABLE 3](#) provide a summary of the data host requirements for the Sun Storage 2500-M2 Arrays. You must install multipathing software on each data host that communicates with the Sun Storage 2500-M2 Arrays. For additional information on multipathing software, see the following:

- *Sun StorageTek RDAC Multipath Failover Driver Installation Guide For Linux OS*
- [“Device Mapper Multipath \(DMMP\) for the Linux Operating System” on page 10](#)

Note – Download RDAC multipathing drivers from My Oracle Support at <https://support.oracle.com> using keyword “RDAC” or “MPP”. See “[Downloading Patches and Updates](#)” on page 3 for more information.

Note – Single path data connections are not recommended. For more information, see “[Single Path Data Connections](#)” on page 17.

TABLE 2 Supported Fibre Channel Multipathing Software

OS	Multipathing Software	Minimum Version	Host Type Setting	Notes
Solaris 10	STMS/MPxIO	Update 5 [†]	Solaris with MPxIO	Multipathing software included in Solaris OS 10
Oracle Linux [*] 5.5, 5.6, 6.0	RDAC	09.03.0C02.0453	Linux	
RHEL 5.5, 5.6, 6.0	RDAC	09.03.0C02.0453	Linux	
SLES 10.1, 10.4, 11, and 11.1	RDAC/MPP	09.03.0C02.0453	Linux	
SLES 11, 11.1	DMMP	----->	----->	See “ Device Mapper Multipath (DMMP) for the Linux Operating System ” on page 10.

* Unbreakable Enterprise Kernel not supported for this release.

† Although the minimum is stated, Oracle recommends the latest update be installed.

TABLE 3 Supported SAS Multipathing Software

OS	Multipathing Software	Minimum Version	Host Type Setting	Notes
Solaris 10	MPxIO	Update 9	Solaris with MPxIO	Multipathing software included in Solaris OS 10
Oracle Linux [*] 5.5	RDAC	09.03.0C02.0453	Linux	
RHEL 5.5	RDAC	09.03.0C02.0453	Linux	

* Unbreakable Enterprise Kernel not supported for this release.

Supported Host Bus Adaptors (HBAs)

- HBAs must be ordered separately from Oracle or its respective manufacturers.
- To obtain the latest HBA firmware:
 - For Fibre Channel HBAs, download firmware from My Oracle Support using keyword “HBA”. For download instructions, see [“Downloading Patches and Updates” on page 3](#).
 - For SAS HBAs, go to <http://www.lsi.com/support/sun/>
- You must install multipathing software before you install any OS patches.
- Download OS updates from the web site of the OS company.
- For FC HBA configuration information, see the *Sun Storage Host Bus Adapter Configuration Guide*. For configuration information specific to SAS-1 HBAs, see [“SAS-1 HBA Settings” on page 9](#).

The following tables list supported HBAs by operating system:

- [TABLE 4: Supported Fibre Channel HBAs for Solaris Data Host Platforms](#)
- [TABLE 5: Supported Fibre Channel HBAs for Linux Data Host Platforms](#)
- [TABLE 6: Supported SAS HBAs for Solaris and Linux Data Host Platforms](#)

TABLE 4 Supported Fibre Channel HBAs for Solaris Data Host Platforms

Host OS	Oracle 2-Gbit HBAs	Oracle 4-Gbit HBAs	Oracle 8-Gbit HBAs
Solaris 10u5 (minimum) SPARC	SG-XPCI1FC-QL2 (6767A)	SG-XPCIE1FC-QF4	SG-XPCIE1FC-QF8-Z
	SG-XPCI2FC-QF2-Z (6768A)	SG-XPCIE2FC-QF4	SG-XPCIE2FC-QF8-Z
	SG-XPCI1FC-EM2	SG-XPCIE1FC-EM4	SG-XPCIE1FC-EM8-Z
	SG-XPCI2FC-EM2	SG-XPCIE2FC-EM4	SG-XPCIE2FC-EM8-Z
		SG-XPCI1FC-QF4	SG-XPCIEFCGBE-Q8
		SG-XPCI2FC-QF4	SG-XPCIEFCGBE-E8
		SG-XPCI1FC-EM4	
		SG-XPCI2FC-EM4	
Solaris 10u5 (minimum) x64/x86		SG-XPCIE2FCGBE-Q-Z	
		SG-XPCIE2FCGBE-E-Z	
	SG-XPCI1FC-QL2 (6767A)	SG-XPCIE1FC-QF4	SG-XPCIE1FC-QF8-Z
	SG-XPCI2FC-QF2-Z (6768A)	SG-XPCIE2FC-QF4	SG-XPCIE2FC-QF8-Z
	SG-XPCI1FC-EM2	SG-XPCIE1FC-EM4	SG-XPCIE1FC-EM8-Z
	SG-XPCI2FC-EM2	SG-XPCIE2FC-EM4	SG-XPCIE2FC-EM8-Z
		SG-XPCI1FC-QF4	SG-XPCIEFCGBE-E8
		SG-XPCI2FC-QF4	SG-XPCIEFCGBE-Q8
		SG-XPCI1FC-EM4	
		SG-XPCI2FC-EM4	
		SG-XPCIE2FCGBE-Q-Z	
		SG-XPCIE2FCGBE-E-Z	

TABLE 5 Supported Fibre Channel HBAs for Linux Data Host Platforms

Host OS	Generic HBAs	Oracle 2-Gbit HBAs	Oracle 4-Gbit HBAs	Oracle 8-Gbit HBAs
Oracle Linux 5.5, 5.6, 6.0	QLogic:	SG-XPCI1FC-EM2	SG-XPCIE1FC-QF4	SG-XPCIE1FC-QF8-Z
	QLE 256x	SG-XPCI2FC-EM2	SG-XPCIE2FC-QF4	SG-XPCIE2FC-QF8-Z
RHEL 5.5, 5.6, 6.0	QLE 246x	SG-XPCI1FC-QL2	SG-XPCIE1FC-EM4	SG-XPCIE1FC-EM8-Z
	QLA 246x	SG-XPCI2FC-QF2-Z	SG-XPCIE2FC-EM4	SG-XPCIE2FC-EM8-Z
	QLA 234x		SG-XPCI1FC-QF4	SG-XPCIEFCGBE-Q8
	QLA 2310F		SG-XPCI2FC-QF4	SG-XPCIEFCGBE-E8
	Emulex:		SG-XPCI1FC-EM4-Z	
	LP982/LP9802/ 9802DC		SG-XPCI2FC-EM4-Z	
	LP9002/LP9002DC/ LP952		SG-XPCIE2FCGBE-Q-Z	
	LP10000/10000DC/ LP1050		SG-XPCIE2FCGBE-E-Z	
	Lpe11000/LPe11002/ LPe1150			
	Lpe12000/LPe12002/ LPe1250			
SLES 10.1, 10.4, 11, 11.1	QLogic:	SG-XPCI1FC-EM2	SG-XPCIE1FC-QF4	SG-XPCIE1FC-QF8-Z
	QLE 256x	SG-XPCI2FC-EM2	SG-XPCIE2FC-QF4	SG-XPCIE2FC-QF8-Z
	QLE246x	SG-XPCI1FC-QL2	SG-XPCIE1FC-EM4	SG-XPCIE1FC-EM8-Z
	QLA 246x	SG-XPCI2FC-QF2-Z	SG-XPCIE2FC-EM4	SG-XPCIE2FC-EM8-Z
	QLA 234x		SG-XPCI1FC-QF4	SG-XPCIEFCGBE-E8
	QLA 2310F		SG-XPCI2FC-QF4	SG-XPCIEFCGBE-Q8
	Emulex:		SG-XPCI1FC-EM4	
	LP982/LP9802/ 9802DC		SG-XPCI2FC-EM4	
	LP9002/LP9002DC/ LP952		SG-XPCIE2FCGBE-Q-Z	
	LP10000/10000DC/ LP1050		SG-XPCIE2FCGBE-E-Z	
	LP11000/LP11002/ LP1150			
	Lpe11000/LPe11002/ LPe1150/Lpe12000/ LPe12002/Lpe1250			

TABLE 6 Supported SAS HBAs for Solaris and Linux Data Host Platforms

Host OS	Oracle 3-Gbit HBAs (SAS-1)*	Oracle 6-Gbit HBAs (SAS-2)†
Solaris 10u9 (minimum)	SG-XPCIE8SAS-E-Z	SG(X)-SAS6-EXT-Z
Oracle Linux 5.5	SG-XPCIE8SAS-EB-Z	SG(X)-SAS6-EM-Z
RHEL 5.5		

* See “SAS-1 HBA Settings” on page 9

† See “Restrictions” on page 17

SAS-1 HBA Settings

TABLE 7 lists supported HBA settings for SAS-1 HBA compatibility.

Configuration: Firmware 01.29.06.00-IT with NVDATA 2DC5, BIOS 6.28.00.00, FCode 1.00.49.

TABLE 7 SAS-1 HBA Settings

Host OS	Settings
Solaris 10u9, SPARC	HBA defaults
Solaris 10u9, x86	IODeviceMissingDelay 20 ReportDeviceMissingDelay 20
Oracle Linux 5.5	IODeviceMissingDelay 8
RHEL 5.5	ReportDeviceMissingDelay 144

Supported FC and Multilayer Switches

The following FC fabric and multilayer switches are compatible for connecting data hosts and the Sun Storage 2540-M2 array. See the release notes for your switch hardware for firmware support information.

- Brocade SilkWorm 200E/300/4100/4900/5000/5100/5300/7500/48000/DCX
- Cisco 9124/9134/9216/9216i/9222i/9506/9509/9513
- QLogic SANBox 5602/9000

Device Mapper Multipath (DMMP) for the Linux Operating System

Device Mapper (DM) is a generic framework for block devices provided by the Linux operating system. It supports concatenation, striping, snapshots, mirroring, and multipathing. The multipath function is provided by the combination of the kernel modules and user space tools.

The DMMP is supported on SUSE Linux Enterprise Server (SLES) Version 11 and 11.1. The SLES installation must have components at or above the version levels shown in the following table before you install the DMMP.

TABLE 8 Minimum Supported Configurations for the SLES 11 Operating System

Version	Component
Kernel version	kernel-default-2.6.27.29-0.1.1
Scsi_dh_rdac kmp	lsi-scsi_dh_rdac-kmp-default-0.0_2.6.27.19_5-1
Device Mapper library	device-mapper-1.02.27-8.6
Multipath-tools	multipath-tools-0.4.8-40.6.1

To update a component, download the appropriate package from the Novell website at <http://download.novell.com/patch/finder>. The Novell publication, *SUSE Linux Enterprise Server 11 Installation and Administration Guide*, describes how to install and upgrade the operating system.

Device Mapper Features

- Provides a single block device node for a multipathed logical unit
- Ensures that I/O is re-routed to available paths during a path failure
- Ensures that the failed paths are revalidated as soon as possible
- Configures the multipaths to maximize performance
- Reconfigures the multipaths automatically when events occur
- Provides DMMP features support to newly added logical unit
- Provides device name persistency for DMMP devices under `/dev/mapper/`
- Configures multipaths automatically at an early stage of rebooting to permit the OS to install and reboot on a multipathed logical unit

Known Limitations and Issues of the Device Mapper

- When storage is configured with AVT mode, delays in device discovery might occur. Delays in device discovery might result in long delays when the operating system boots.
- In certain error conditions with `no_path_retry` or `queue_if_no_path` feature set, applications might hang forever. To overcome these conditions, you must enter the following command to all the affected multipath devices: `dmsetup message device 0 "fail_if_no_path"`, where `device` is the multipath device name (for example, `mpath2`; do not specify the path).
- An I/O hang might occur when a volume is unmapped without first deleting the DM device. **Note:** This limitation applies to only the SUSE 11 OS.
- Stale entries might not be noticed in `multipath -ll` output if the volumes are unmapped or deleted without first deleting the DM device and its underlying paths. **Note:** This limitation applies to only the SUSE 11 OS.
- Currently, the `mode select` command is issued synchronously for each LUN. With large LUN configurations, slower failovers for DM multipath devices might occur if there is any delay in completing of the `mode select` command. **Note:** This limitation applies to only the SUSE 11 OS.
- If the `scsi_dh_rdac` module is not included in `initrd`, slower device discovery might occur, and the `syslog` might get populated with buffer I/O error messages.
- If the storage vendor and model are not included in `scsi_dh_rdac` device handler, slower device discovery might be seen, and the `syslog` might get populated with buffer I/O error messages.
- Use of the DMMP and RDAC failover solutions together on the same host is not supported. Use only one solution at a time.

Installing the Device Mapper Multi-Path

1. Use the media supplied by your operating system vendor to install SLES 11.
2. Install the errata kernel 2.6.27.29-0.1.
Refer to the *SUSE Linux Enterprise Server 11 Installation and Administration Guide* for the installation procedure.
3. To boot up to 2.6.27.29-0.1 kernel, reboot your system.
4. On the command line, enter `rpm -qa |grep device-mapper`, and check the system output to see if the correct level of the device mapper component is installed.
 - If the correct level of the device mapper component is installed – Go to [Step 5](#).

- If the correct level of the device mapper component is not installed, install the correct level of the device mapper component or update the existing component. Then, go to [Step 5](#).
5. **On the command line, enter `rpm -qa |grep multipath-tools` and check the system output to see if the correct level of the multipath tools is installed.**
 - If the correct level of the multipath tools is installed, go to [Step 6](#).
 - If the correct level of the multipath tools is not installed, install the correct level of the multipath tools or update the existing multipath tools. Then, go to [Step 6](#).
 6. **Update the configuration file `/etc/multipath.conf`.**

See “[Setting Up the multipath.conf File](#)” on page 12 for detailed information about the `/etc/multipath.conf` file.
 7. **On the command line, enter `chkconfig multipathd on`.**

This command enables multipathd daemon when the system boots.
 8. **Edit the `/etc/sysconfig/kernel` file to add directive `scsi_dh_rdac` to the `INITRD_MODULES` section of the file.**
 9. **Download the KMP package for `scsi_dh_rdac` for the SLES 11 architecture from the website <http://forgeftp.novell.com/driver-process/staging/pub/update/lsi/sle11/common/>, and install the package on the host.**
 10. **Update the boot loader to point to the new initrd image, and reboot the host with the new initrd image.**

Setting Up the multipath.conf File

The `multipath.conf` file is the configuration file for the multipath daemon, `multipathd`. The `multipath.conf` file overwrites the built-in configuration table for `multipathd`. Any line in the file whose first non-white-space character is `#` is considered a comment line. Empty lines are ignored.

Installing the Device Mapper Multi-Path for SLES 11.1

All of the components required for DMMP are included in SUSE Linux Enterprise Server (SLES) version 11.1 installation media. However, users might need to select the specific component based on the storage hardware type. By default, DMMP is disabled in SLES. You must follow the following steps to enable DMMP components on the host.

1. On the command line, type `chkconfig multipath on`.
The multipathd daemon is enabled with the system starts again.
2. Edit the `/etc/sysconfig/kernel` file to add the directive `scsi_dh_rdac` to the `INITRD_MODULES` section of the file.
3. Create a new initrd image using the following command to include `scsi_dh_rdac` into ram disk:

```
mkinitrd -i /boot/initrd-r -rdac -k /bootvmlinuz
```
4. Update the boot leader to point to the new initrd image, and reboot the host with the new initrd image.

Copy and Rename the Sample File

Copy and rename the sample file located at `/usr/share/doc/packages/multipath-tools/multipath.conf.synthetic` to `/etc/multipath.conf`. Configuration changes are now accomplished by editing the new `/etc/multipath.conf` file. All entries for multipath devices are commented out initially. The configuration file is divided into five sections:

- **defaults** – Specifies all default values.
- **blacklist** – All devices are blacklisted for new installations. The default blacklist is listed in the commented-out section of the `/etc/multipath.conf` file. Blacklist the device mapper multipath by WWID if you do not want to use this functionality.
- **blacklist_exceptions** – Specifies any exceptions to the items specified in the section blacklist
- **devices** – Lists all multipath devices with their matching vendor and product values
- **multipaths** – Lists the multipath device with their matching WWID values

Determine the Attributes of a MultiPath Device

To determine the attributes of a multipath device, check the `multipaths` section of the `/etc/multipath.conf` file, then the `devices` section, then the `defaults` section. The model settings used for multipath devices are listed for each storage array and include matching vendor and product values. Add matching storage vendor and product values for each type of volume used in your storage array.

For each UTM LUN mapped to the host, include an entry in the blacklist section of the `/etc/multipath.conf` file. The entries should follow the pattern of the following example.

```

blacklist {
device {
    vendor "*"
    product "Universal Xport"
}
}

```

The following example shows the devices section for LSI storage from the sample `/etc/multipath.conf` file. Update the vendor ID, which is LSI in the sample file, and the product ID, which is INF-01-00 in the sample file, to match the equipment in the storage array.

```

devices {
    device {
        vendor          "LSI"
        product          "INF-01-00"
        path_grouping_policy group_by_prio
        prio             rdac
        getuid_callout    "/lib/udev/scsi_id -g -u -d /dev/%n"
        polling_interval  5
        path_checker      rdac
        path_selector     "round-robin 0"
        hardware_handler  "1 rdac"
        failback          immediate
        features          "2 pg_init_retries 50"
        no_path_retry     30
        rr_min_io         100
    }
}

```

The following table explains the attributes and values in the devices section of the `/etc/multipath.conf` file.

TABLE 9 Attributes and Values in the `multipath.conf` File

Attribute	Parameter Value	Description
<code>path_grouping_policy</code>	<code>group_by_prio</code>	The path grouping policy to be applied to this specific vendor and product storage.
<code>prio</code>	<code>rdac</code>	The program and arguments to determine the path priority routine. The specified routine should return a numeric value specifying the relative priority of this path. Higher numbers have a higher priority.
<code>getuid_callout</code>	<code>"/lib/udev/scsi_id -g -u -d /dev/%n"</code>	The program and arguments to call out to obtain a unique path identifier.

TABLE 9 Attributes and Values in the `multipath.conf` File (*Continued*)

Attribute	Parameter Value	Description
<code>polling_interval</code>	5	The interval between two path checks, in seconds.
<code>path_checker</code>	<code>rdac</code>	The method used to determine the state of the path.
<code>path_selector</code>	"round-robin 0"	The path selector algorithm to use when there is more than one path in a path group.
<code>hardware_handler</code>	"1 rdac"	The hardware handler to use for handling device-specific knowledge.
<code>failback</code>	10	A parameter to tell the daemon how to manage path group failback. In this example, the parameter is set to 10 seconds, so failback occurs 10 seconds after a device comes online. To disable the failback, set this parameter to <code>manual</code> . Set it to <code>immediate</code> to force failback to occur immediately.
<code>features</code>	"2 <code>pg_init_retries</code> 50"	Features to be enabled. This parameter sets the kernel parameter <code>pg_init_retries</code> to 50. The <code>pg_init_retries</code> parameter is used to retry the mode select commands.
<code>no_path_retry</code>	30	Specify the number of retries before queuing is disabled. Set this parameter to <code>fail</code> for immediate failure (no queuing). When this parameter is set to <code>queue</code> , queuing continues indefinitely.
<code>rr_min_io</code>	100	The number of I/Os to route to a path before switching to the next path in the same path group. This setting applies if there is more than one path in a path group.

Using the Device Mapper Devices

Multipath devices are created under `/dev/` directory with the prefix `dm-`. These devices are the same as any other block devices on the host. To list all of the multipath devices, run the `multipath -ll` command. The following example shows system output from the `multipath -ll` command for one of the multipath devices.

```

mpathp (3600a0b80005ab177000017544a8d6b92) dm-0 LSI,INF-01-00
[size=5.0G][features=3 queue_if_no_path
pg_init_retries 50][hwhandler=1 rdac][rw]
\_ round-robin 0 [prio=6][active] \_ 5:0:0:0
sdc 8:32 [active][ready] \_
round-robin 0 [prio=1][enabled] \_ 4:0:0:0 sdb 8:16
[active][ghost]

```

In this example, the multipath device node for this device is `/dev/mapper/mpathp` and `/dev/dm-0`. The following table lists some basic options and parameters for the multipath command.

TABLE 10 Options and Parameters for the multipath Command

Command	Description
<code>multipath -h</code>	Prints usage information
<code>multipath -ll</code>	Shows the current multipath topology from all available information (sysfs, the device mapper, path checkers, and so on)
<code>multipath -f map</code>	Flushes the multipath device map specified by the map option, if the map is unused
<code>multipath -F</code>	Flushes all unused multipath device maps

Troubleshooting the Device Mapper

TABLE 11 Troubleshooting the Device Mapper

Situation	Resolution
Is the multipath daemon, <code>multipathd</code> , running?	At the command prompt, enter the command: <code>/etc/init.d/multipathd status</code> .
Why are no devices listed when you run the <code>multipath -ll</code> command?	At the command prompt, enter the command: <code>#cat /proc/scsi/scsi</code> . The system output displays all of the devices that are already discovered. Verify that the <code>multipath.conf</code> file has been updated with proper settings.

Restrictions and Known Issues

The following are restrictions and known issues applicable to this product release.

- [“Restrictions” on page 17](#)
- [“Controller Issues” on page 18](#)
- [“OS Issues” on page 19](#)

Restrictions

Single Path Data Connections

In a single path data connection, a group of heterogeneous servers is connected to an array through a single connection. Although this connection is technically possible, there is no redundancy, and a connection failure will result in loss of access to the array.




Caution – Because of the single point of failure, single path data connections are not recommended.

SAS Host Ports on the Sun Storage 2540-M2

Although SAS host ports are physically present on the Sun Storage 2540-M2 array controller tray, they are not for use, not supported, and are capped at the factory. [FIGURE 1](#) shows the location of these ports. The Sun Storage 2540-M2 only supports Fibre Channel host connectivity.

FIGURE 1 SAS Host Ports on the 2540-M2



SAS-2 Phase 5++ HBA Unable to Boot from Attached 2530-M2 Volume

Bug 7042226 – SAS-2 HBA device booting is not supported using Phase 5++ HBA firmware. This restriction will be lifted with the Phase 10 HBA firmware.

Controller Issues

I/O Errors Occur During Controller Firmware Download

Configuration:

- Red Hat Enterprise Linux (RHEL) version 6 with kernel 2.6.32 only.
- PowerPC
- Emulex 10N9824 HBA
- Device Mapper Multipath (DMMP) failover driver
- Sun Storage 2500-M2 controller tray
- Sun Storage 6180 controller tray

Note – This problem does not occur in RHEL version 6.0 with kernel 2.6.33.

Problem or Restriction: An I/O error occurs during an online controller firmware upgrade.

Workaround: To avoid this problem, quiesce the host I/O before the performing controller firmware upgrades. To recover from this problem, make sure that the host reports that it has optimal paths available to the storage array controllers, and then resume I/O.

2500-M2 Controller Firmware Panics during Firmware Download

Configuration:

- Sun Storage 2500-M2 controller tray
- Controller firmware version 7.77
- Environmental services monitor (ESM/IOM)

Problem or Restriction: This problem occurs when a firmware download to the controller causes the controller to panic and reboot.

Workaround: Stop all I/O to the array before initiating the firmware download. Once the download is initiated, the controller automatically reboots, recovering the system.



Caution – To avoid potential data loss, stop all I/O to the array before initiating the firmware download.

OS Issues

Linux RDAC 09.03.0C02.0453 - Make Install Dependencies

Configuration:

- Red Hat Enterprise Linux (RHEL) or Oracle Linux version 5.5 or 5.6
- RDAC driver version 09.03.0C02.0453

Bug 7042297 – Before running a “make” on the RDAC driver, the following kernel packages are required:

- kernel-2.6.18-194.el5
- kernel-devel-2.6.18-194.el5.x86_64.rpm
- kernel-headers-2.6.18-194.el5.x86_64.rpm
- glibc-headers-2.5-49.x86_64.rpm
- glibc-devel-2.5-49.x86_64.rpm
- libgomp-4.4.0-6.el5.x86_64.rpm
- gcc-4.1.2-48.el5.x86_64.rpm

Oracle Linux 6 Boots With Messages

Bugs 7038184, 7028670, 7028672 – When booting an Oracle Linux 6.0 host mapped to volumes on Sun Storage 2500-M2 and 6780 arrays, it is possible to receive one of these messages:

“FIXME driver has no support for subenclosures (1)”
“FIXME driver has no support for subenclosures (3)”
“Failed to bind enclosure -19”

Workaround – This is a cosmetic issue with no impact to the I/O path. There is no workaround.

Log Events Using SLES 11.1 With smartd Monitoring Enabled

Bug 7014293 – When a SLES 11.1 host with smartd monitoring enabled is mapped to volumes on either a Sun Storage 2500-M2 or 6780 array, it is possible to receive “IO FAILURE” and “Illegal Request ASC/ASCQ” log events.

Workaround – Either disable smartd monitoring or disregard the messages. This is an issue with the host OS.

Cluster Startup Fails When Devices Are in a Unit Attention State

Configuration:

- Red Hat Enterprise Linux (RHEL) version 6.0 with Native Cluster
- Device Mapper Multipath (DMMP) failover driver

Problem or Restriction: This problem occurs when the DMMP failover driver is used with the RHEL version 6.0 OS. If you try to set up a Red Hat cluster with the DMMP failover driver, cluster startup might fail during the unfencing stage, where each host registers itself with the SCSI devices. The devices are in a Unit Attention state, which causes the SCSI registration command issued by the host during startup to fail. When the cluster manager (cman) service starts, the logs show that the nodes failed to unfence themselves, which causes the cluster startup to fail.

Workaround: To avoid this problem, do not use the DMMP failover driver with RHEL version 6.0. To recover from this problem, open a terminal window, and run:

```
sg_turs -n 5 <device>
```

where *<device>* is a SCSI device that is virtualized by the DMMP failover driver. Run this command on every `/dev/sd` device that the DMMP failover driver manages. It issues a Test Unit Ready command to clear the Unit Attention state and allow node registration on the device to succeed.

Node Unfencing Fails when Automatically Generated Host Keys Are Used during a Red Hat Cluster Suite Services Startup

Operating System: Red Hat Enterprise Linux 6 with Native Cluster

Problem or Restriction: This problem occurs the first time a cluster is set up when the `cluster.conf` file does not have manually defined host keys. When the `cluster.conf` file was first defined to set up a cluster with SCSI reservation fencing, the cluster services were started on the nodes. With SCSI reservation fencing, the hosts try to generate and register a key on the clustered devices as part of the cluster manager's startup. The cluster manager service (cman) fails to start, and the key cannot be zero error message appears in the host log.

Workaround: To avoid this problem, use only power fencing. Do not use SCSI reservation fencing. To recover from this problem, change to manually defined host keys, and restart the cluster services.

Red Hat Cluster Suite Services with GFS2 Mounts Cannot Transfer Between Nodes when the Client Mounts with NFSv4

Operating System: Red Hat Enterprise Linux 6 Native Cluster

Problem or Restriction: This problem occurs during an attempt to transfer a cluster service manually when a client is connected using NFSv4. The Global File System (GFS) 2 mount points failed to unmount, which caused the Red Hat Cluster Suite Services to go to the Failed state. The mount point, and all other mount points exported from the same virtual IP address, becomes inaccessible.

Workaround: To avoid this problem, configure the cluster nodes to not allow mount requests from NFS version 4 (NFSv4) clients. To recover from this problem, restart the failed service on the node that previously owned it.

Host Aborts I/O Operations

Operating System: Red Hat Enterprise Linux version 6.0

Problem or Restriction: This problem occurs during an online controller firmware upgrade. The controller is not responding quickly enough to a host read or write to satisfy the host. After 30 seconds, the host sends a command to abort the I/O. The I/O aborts, and then starts again successfully.

Workaround: Quiesce the host I/O before performing the controller firmware upgrade. To recover from this problem, either reset the server, or wait until the host returns an I/O error.

Host Attempts to Abort I/O Indefinitely

Operating System: Red Hat Enterprise Linux version 6.0 with kernel 2.6.32.

Red Hat Bugzilla Number: 620391

Note – This problem does not occur in Red Hat Enterprise Linux version 6.0 with kernel 2.6.33.

Problem or Restriction: This problem occurs under situations of heavy stress when storage arrays take longer than expected to return the status of a read or write. The storage array must be sufficiently stressed that the controller response is more than

30 seconds, at which time a command is issued to abort if no response is received. The abort will be retried indefinitely even when the abort is successful. The application either times out or hangs indefinitely on the read or write that is being aborted. The messages file reports the aborts, and resets might occur on the LUN, the host, or the bus.

Factors effecting controller response include Remote Volume Mirroring, the controller state, the number of attached hosts, and the total throughput.

Workaround: To recover from this problem, reset the power on the server.

Related Documentation

Product documentation for Sun Storage 2500-M2 Arrays is available at:

<http://www.oracle.com/technetwork/documentation/oracle-unified-ss-193371.html>

Product documentation for Sun Storage Common Array Manager is available at:

<http://www.oracle.com/technetwork/documentation/disk-device-194280.html>

TABLE 12 Related Documentation

Application	Title
Review safety information	<i>Sun Storage 2500-M2 Arrays Safety and Compliance Manual</i> <i>Important Safety Information for Sun Hardware Systems</i>
Review known issues and workarounds	<i>Sun Storage Common Array Manager Release Notes</i>
Prepare the site	<i>Sun Storage 2500-M2 Arrays Site Preparation Guide</i>
Install the support rails	<i>Installing Adjustable Support Rails For 2U 6x90 and 2500-M2 Array Hardware</i>
Install the array	<i>Sun Storage 2500-M2 Arrays Hardware Installation Guide</i>
Get started with the management software	<i>Sun Storage Common Array Manager Quick Start Guide</i>
Install the management software	<i>Sun Storage Common Array Manager Installation and Setup Guide</i>
Manage the array	<i>Sun Storage Common Array Manager Array Administration Guide</i> <i>Sun Storage Common Array Manager CLI Guide</i>

Documentation, Support, and Training

These web sites provide additional resources:

- Documentation
<http://www.oracle.com/technetwork/indexes/documentation/index.html>
- Support
<https://support.oracle.com>
- Training
<https://education.oracle.com>

