

***AutoVue***  
***Desktop Edition***  
***User's Manual***

# Support Information

If you have any questions or require support for AutoVue please contact Cimmetry Systems Corp.

## Contact Information

If at any time you have questions or concerns regarding AutoVue, call or e-mail us.

### General inquiries

**Telephone:** +1 514 735-3219  
**Fax:** +1 514 735-6440  
**E-mail:** [info@cimmetry.com](mailto:info@cimmetry.com)  
**Web Site:** <http://www.cimmetry.com>

### Sales inquiries

**Telephone:** +1 514 735-3219 or 1 800 361-1904  
**Fax:** +1 514 735-6440  
**E-mail:** [sales@cimmetry.com](mailto:sales@cimmetry.com)

### Customer Support

**Telephone:** +1 514 735-9941  
**Web Site:** <http://www.cimmetry.com/support>

# Contents

## SUPPORT INFORMATION

<b>INTRODUCTION .....</b>	<b>1</b>
AutoVue .....	1
Marking Up Documents .....	1
<b>STARTING AUTOVUE .....</b>	<b>2</b>
<b>EXITING AUTOVUE .....</b>	<b>2</b>
<b>HELP ABOUT .....</b>	<b>3</b>
<b>CHANGING THE LOCALE OF AUTOVUE .....</b>	<b>4</b>
<b>ENTERING A NEW LICENSE KEY .....</b>	<b>5</b>
<b>VIEWING AND EXPORTING</b>	
<b>FILE VERSIONS INFORMATION .....</b>	<b>7</b>
Viewing File Versions .....	7
Exporting File Versions .....	7
<b>AUTOVUE BASICS .....</b>	<b>8</b>
Menu Bar .....	8
Toolbars .....	9
Status Bar .....	9
Quick Menus .....	9
<b>OPENING FILES WITH AUTOVUE .....</b>	<b>10</b>
Opening a File .....	10
Opening Multiple Windows .....	10
Viewing Multiple Files at the Same Time .....	10
Browsing Files .....	11
Archive Files .....	11
Viewing File Properties .....	12
Selecting .....	12
Associations .....	13
Creating an Association .....	13
Removing an Association .....	13
Activating an Association .....	13
<b>WORKING WITH 2D FILES .....</b>	<b>14</b>
Searching Text .....	14
Manipulating 2D Views .....	15
Using Birds Eye View .....	18
Using the Magnify Glass .....	18
Using the Magnify Window .....	19
Conversion .....	19

---

Conversion Options .....	20
PDF .....	21
X and Y .....	21
Converting a File .....	22
Changing the Pen Settings .....	22
Batch Conversion .....	23
Measuring in 2D non-vector Files .....	24
Measuring Distance .....	24
Calibrating Distance .....	25
Measuring Area .....	25
Measuring an Angle .....	26
Measuring an Arc .....	26
Calibrating an Arc .....	27
Working with 2D Vector Files .....	27
Manipulating 2D Vector Views .....	28
Drawing Information .....	28
Viewing Details of a Single Entity .....	28
Viewing information for a Set of Entities .....	29
Viewing Tags/Attributes .....	29
Viewing XRefs .....	30
Displaying Details About Missing XRefs .....	30
Layers .....	30
Blocks .....	31
Selecting Views .....	31
Specifying a View Point .....	31
Comparing 2D Files .....	32
Specifying Scale and Offset for a Compare File .....	33
Overlays .....	33
Adding an Overlay .....	33
Modifying an Overlay .....	34
Removing an Overlay .....	34
Measuring in 2D Vector Files .....	35
2D Vector Snapping Modes .....	35
Measuring Distance .....	36
Calibrating Distance .....	37
Measuring Area .....	37
Measuring an Angle .....	38
Measuring an Arc .....	39
Calibrating an Arc .....	40
<b>WORKING WITH EDA FILES .....</b>	<b>41</b>

Navigation Panel .....	41
Components Tab .....	42
Nets Tab .....	42
Bookmarks Tab .....	42
Customizing the Navigation Panel .....	42
Selecting Entities .....	43
Selecting Entities from the Navigation Panel .....	43
Selecting Entities in the Workspace .....	43
Selecting Entities from the Entity Browser .....	44
Filtering Entity Types .....	44
Zooming to a Selected Entity .....	45
Entity Properties .....	45
Viewing the Properties of an Entity .....	46
Showing Net Connectivity .....	46
Displaying the Entity Properties of a Net .....	47
Showing Net Instances .....	47
Design Hierarchy Navigation .....	48
Navigating using Descend Hierarchy .....	48
Navigating using Ascend Hierarchy .....	48
Layers .....	49
Changing the Order of Layers .....	50
Modifying Layer Visibility .....	51
Modifying Visibility for Physical Layers .....	52
Modifying Visibility for Logical Layers .....	52
Setting Printability for Layers .....	52
Changing Layer Color .....	53
Sorting Logical Layers .....	54
Layer Sets .....	55
Viewing Layer Sets .....	55
Creating User-Defined Layer Sets .....	55
Deleting User-Defined Layer Sets .....	56
Saving User-Defined Layer Sets with Markups .....	57
3D View .....	57
Cross Probing .....	58
Cross Probing Between Two or More EDA Files .....	58
Cross Probing Between 2D and 3D Views of the Same File .....	59
Showing the Net Connectivity when Cross Probing .....	60
Zooming when Cross Probing .....	60
Comparing a PCB with Artwork .....	61
Generating a Bill of Material .....	61

---

Design Verification .....	62
Design Rule Checks .....	63
Verifying a Design .....	65
Exporting the Design Verification Results .....	66
Searching Using Entity Browser .....	66
Performing an Entity Type-based Search .....	67
Performing an Attribute-based Search .....	68
Measuring in EDA Files .....	69
EDA Snapping Modes .....	70
Measuring Distance .....	71
Calibrating Distance .....	71
Measuring Minimum Distance .....	72
Measuring Area .....	72
Measuring an Angle .....	73
Measuring an Arc .....	74
Calibrating an Arc .....	75
EDA Terms and Definitions .....	75
<b>WORKING WITH 3D FILES .....</b>	<b>84</b>
Models Tab .....	84
Views Tab .....	84
Bookmarks Tab .....	84
Global Axes .....	85
Selecting Model Parts .....	85
Selecting Model Parts from the Model Tree .....	85
Select Model Parts from the Workspace .....	85
Selecting All Identical Parts of a Model .....	86
Hiding Model Parts .....	86
Re-centering .....	87
Re-centering a Model to a Selected Model Part .....	87
Re-center All .....	87
Re-centering a Model to an Entity .....	87
Expanding/Collapsing the Model Tree .....	88
Creating 3D Mockups .....	89
Deleting Models from a Mockup .....	89
Converting 3D Models to Other Formats .....	90
Conversion Options .....	90
PDF .....	92
Converting a 3D Model .....	92
Manipulating Views .....	92
Display Attributes .....	95

Render Modes .....	95
Changing the Render Mode .....	96
Changing the Visibility .....	96
Changing Model Color .....	96
Adjusting the Transparency .....	97
Changing the Mesh Resolution .....	97
Light Settings .....	98
Setting Ambient Lighting .....	98
Setting Directional Lighting .....	99
Adding a New Light Source .....	99
Changing the Light Color .....	99
Removing a Light Source .....	100
3D Views .....	100
Default View .....	100
Setting Standard or Predefined Views .....	101
Setting Native Views .....	101
Creating a User-defined View .....	101
Displaying the Perspective Projection of a 3D Model .....	102
Viewing a Model from a Particular Viewpoint .....	102
Layers .....	103
Entity Properties .....	103
Viewing Attributes .....	104
Viewing Mass Properties .....	105
Viewing Extents .....	106
PMI Filtering .....	107
Aligning to a PMI Entity .....	108
Go To a displayed PMI Entity .....	108
Manipulators .....	108
Panning a Model Along the X, Y and Z-Axis .....	108
Rotating a Model Along the X, Y and Z-Axis .....	109
Scaling a Model Along the X, Y and Z-Axis .....	110
Part Alignment .....	110
Part Alignment Constraints .....	111
Aligning Model Parts .....	112
Transformation .....	113
Transforming a Model using Illustration Buttons .....	114
Transforming a Model by Setting Values .....	115
Resetting the Transformation of a 3D Model .....	116
Cross Section/Cut-through .....	116
Section Plane Options .....	116

---

Cut Options .....	117
Defining the Section Plane and Cut-through .....	117
Exporting Section Edges .....	118
Exploding .....	119
Explode Options .....	119
Exploding a 3D Model .....	120
Saving an Exploded View of a 3D Model .....	120
User-defined Coordinate Systems .....	121
Position Options .....	121
Orientation Options .....	123
Defining a User Coordinate System .....	124
Modifying a User-defined Coordinate System .....	124
Activating a Coordinate System .....	125
Deleting a User Coordinate System .....	126
Interference Checks .....	126
Interference Check Options .....	126
Performing an Interference Check .....	126
Interference Check Results Options .....	128
Comparing 3D Files .....	129
Comparing Entity Sets .....	130
Generating a Bill of Material .....	132
Entity Search .....	133
Performing a Search .....	134
Performing an Attribute-based Search .....	136
Performing an Advanced 3D Search .....	137
Saving Search Results .....	139
Measuring in 3D Files .....	139
3D Snapping Modes .....	140
Measuring Distance .....	140
Calibrating Distance .....	141
Measuring Minimum Distance .....	142
Measuring an Angle .....	143
Measuring an Arc .....	143
Calibrating an Arc .....	144
Measuring Vertex Coordinates .....	145
Measuring the Length of an Edge .....	145
Measuring Face Surface .....	146
<b>CONFIGURING AUTOVUE .....</b>	<b>147</b>
General Options .....	147
Configuring Options for CAD Files .....	147

Raster Files .....	148
System options .....	148
Configuring Paths .....	148
Measurement .....	151
Configuring the Base Font for Text Files .....	152
Configuring AutoVue for 2D Files .....	152
Snap Settings .....	152
Configuring Colors .....	152
Configuring AutoVue for 3D Files .....	153
Rendering .....	153
Dynamic Rendering .....	154
Model .....	154
PMI Filtering .....	155
Configuring Color .....	155
Miscellaneous .....	157
Configuring AutoVue for EDA Files .....	157
Customizing Selections .....	158
Displaying Tooltips .....	158
Modifying 3D View .....	158
Synchronizing Layers when Comparing Files .....	159
Configuring Zoom Behavior when Cross Probing .....	159
Modifying Colors .....	160
Configuring Background Colors for Graphic Files .....	161
Configuring Background Colors for Desktop Office .....	161
<b>MARKUPS .....</b>	<b>162</b>
Markup Navigation Tree .....	162
Working with Markup Files .....	164
Saved States .....	164
Creating a Markup File .....	164
Entering Markup Information .....	164
Saving a New Markup File .....	165
Opening Markup Files .....	165
Saving an Existing Markup File .....	165
Importing a Markup File .....	166
Exporting a Markup File .....	166
Setting the Active Markup File .....	166
Changing the Active Markup File .....	167
Markup Layers .....	168
Creating a Markup Layer .....	168
Setting the Active Markup Layer .....	168

---

Changing the Active Markup Layer .....	169
Changing the Color of a Markup Layer .....	169
Renaming a Markup Layer .....	170
Toggling Markup Layers .....	170
Deleting a Markup Layer .....	171
Moving a Markup Entity to Another Layer .....	171
Consolidating Markup Files .....	172
Modifying Markup Entities .....	172
“Go To” a Markup Entity .....	174
Selecting Markup Entities .....	174
Moving a Markup Entity .....	174
Editing a Markup Entity .....	174
Grouping Markup Entities .....	175
Ungrouping Markup Entities .....	175
Hiding Markup Entities .....	175
Changing Line Thickness of an Entity .....	175
Changing Line Style of an Entity .....	176
Changing the Arrow Style .....	176
Changing Line Color of an Entity .....	177
Changing Fill Color of an Entity .....	177
Changing Fill Type of an Entity .....	178
Assigning an Entity the Same Color as the Layer .....	178
Deleting Markup Entities .....	179
Modifying Measurement Markup Entities .....	179
Changing Measurement Units and Symbols .....	180
Hiding Markup Measure Entities .....	180
Deleting Markup Measure Entities .....	180
Modifying Markup Entity Properties .....	181
Marking Up 2D Files .....	184
2D Markup Entities .....	184
Creating a Non-contiguous Freestyle Entity .....	187
Creating a Contiguous Freestyle Entity .....	187
Adding a Leader .....	187
Forcing a Line Segment to Become Horizontal or Vertical .....	188
Adding Text .....	188
Adding a Note .....	189
Viewing the List of Notes .....	189
Creating Signoff Entities .....	190
Creating an OLE Markup Entity .....	191
Symbols .....	192

Working with Hyperlinks .....	194
Creating a Hyperlink .....	194
Firing a Hyperlink .....	195
Editing a Hyperlink .....	195
Deleting a Hyperlink .....	196
Viewing List of Hyperlinks .....	196
Viewing History of a Hyperlink .....	196
Creating 2D Non-vector Markup Measure Entities .....	197
Measuring Distance .....	198
Measuring Cumulative Distance .....	198
Calibrating Distance .....	199
Measuring Area .....	199
Measuring an Angle .....	200
Measuring an Arc .....	201
Calibrating an Arc .....	201
Creating 2D Vector Markup Measure Entities .....	202
2D Vector Snapping Modes .....	203
Measuring Distance .....	204
Measuring Cumulative Distance .....	204
Calibrating Distance .....	205
Measuring Area .....	206
Measuring an Angle .....	207
Measuring an Arc .....	208
Calibrating an Arc .....	209
Creating EDA Markup Measure Entities .....	209
EDA Snapping Modes .....	210
Measuring Distance .....	211
Measuring Cumulative Distance .....	212
Calibrating Distance .....	213
Measuring Minimum Distance .....	213
Measuring Area .....	214
Measuring an Angle .....	215
Measuring an Arc .....	216
Calibrating an Arc .....	217
Marking up 3D Files .....	217
3D Snapping Modes .....	218
Attaching a Note .....	218
Attaching Text .....	219
Creating 3D Markup Measure Entities .....	219
Measuring Distance .....	221

---

Calibrating Distance .....	222
Measuring Minimum Distance .....	222
Measuring an Angle .....	223
Measuring an Arc .....	224
Calibrating an Arc .....	225
Measuring Vertex Coordinates .....	225
<b>PRINTING .....</b>	<b>227</b>
Print Options .....	227
Configuring the Print Options .....	229
Print Margins .....	230
Setting the Margins .....	230
Header/Footer .....	231
Adding a Header and Footer .....	231
Watermarks .....	233
Adding a Watermark .....	233
Assigning Pen Settings .....	234
Creating a New Pen Setting .....	235
Deleting a Pen Setting .....	235
Partial Preview of a File .....	236
Previewing a File Before Printing .....	236
Printing a File .....	237
Batch Printing .....	238
<b>CUSTOMIZING AUTOVUE .....</b>	<b>239</b>
Defining the Clipboard .....	239
Copying Information .....	240
Tools .....	240
Adding a Tools Menu Item .....	240
Creating a Hot Key .....	241
Modifying a Tools Menu Item .....	241
Moving a Tools Menu Item .....	241
Deleting a Tools Menu Item .....	242
Customizing Toolbars .....	242
Configuring the Mail Utility .....	242
Activating the Mail Utility .....	243
<b>THUMBNAILS .....</b>	<b>244</b>
Customizing Thumbnails .....	244
Creating a Thumbnail Folder .....	244
Viewing a Thumbnail Folder .....	245
Sorting a Thumbnail Folder .....	245
Viewing a Thumbnail .....	246

Updating Thumbnails .....	246
Viewing the Properties of a Thumbnail .....	247
Converting Thumbnails .....	248
Printing Thumbnails .....	248
<b>FULL TEXT EXTRACTION .....</b>	<b>250</b>
Using the Full Text Extraction Utility .....	250
CAD Information Extraction .....	250
<b>PACKAGE FILES .....</b>	<b>252</b>
Package File Creation Tool .....	252
Markup Import Tool .....	252
DMAIL Component .....	252
Viewing .....	253



# Introduction

Cimmetry Systems Corp. has developed a family of products designed to meet all levels of business and engineering needs. Collectively, our products provide viewing and Markup capabilities, and support the visualization of 2D engineering and office formats.

## AutoVue

AutoVue is a viewing and Markup application that has been developed for both business and technical users.

AutoVue is capable of displaying over 450 different file formats without the authoring application. Supported file types include text, database, graphic and spreadsheet. Even contents of archive files can viewed in AutoVue. Moreover, when you view a file you do not need to specify the file type. AutoVue automatically detects the type of file you are requesting to view — even files with false extensions!

## Marking Up Documents

AutoVue has the ability to create markups for all its readable file formats without the document's authoring application. AutoVue creates markups for different formats without modifying the original file.

You can attach comments, notes and drawings to any file you display in AutoVue. This is called marking up a file, commonly known as annotating or redlining. A **Markup** is an object or entity that you attach to a file. All Markups are saved in a separate file called a **Markup** or a **Markup file**. However, when you display a file with its Markups, the Markups appear to be part of it.

AutoVue provides a variety of flexible, user-friendly entities. To name a few, there are circles, clouds, polygons and leaders. You can also attach text to entities, insert a note for longer comments or add a symbol such as a company logo. In addition, you can create measurement markup entities and hyperlinks that link between the current file and other associated files or applications.

# Starting AutoVue

- 1 From the Windows **Start** menu, select **Programs > AutoVue, Desktop Edition > AutoVue...**

*or...*

From the Windows **Start** menu, select **Run**.



The **Run** dialog appears.

Enter the path and filename for **avwin.exe**.

**Example:** C:\Progra~1\av\avwin\avwin.exe

Click **OK**.


The main AutoVue window appears.

**Note** After starting AutoVue, an AutoVue icon  appears in the system tray located on the far right side of the task bar. This icon is always accessible after exiting AutoVue since AutoVue continues running until you close AutoVue completely. Right-click the AutoVue icon  to access the system tray **Quick Menu**. To resume working with AutoVue, double-click the icon or right-click the icon and select **Restore AutoVue** from the Quick menu.


# Exiting AutoVue

- 1 Select **File > Exit** from the AutoVue main menu.

*or...*

Click the Close button  in the upper right corner of the window.

*or...*

From the system tray, right-click the AutoVue icon  and select **Close AutoVue** from the Quick Menu.

AutoVue closes completely and the icon disappears from the system tray.

---

# Help About


AutoVue provides a **Help** menu that allows you to easily access information on how to use AutoVue.

From the **Help About** dialog, you can see information about your current installation of AutoVue. Information such as the variation of AutoVue you are using, the version, the build number and the current language that AutoVue is running is displayed. You can also enter a new license key and/or change the localization of the AutoVue user interface.


# Changing the Locale of AutoVue

AutoVue supports different localizations for the User Interface. AutoVue supports the following languages: English, French, German, Chinese, Japanese and Korean.

- 1 Select **Help > About** from the AutoVue main menu.  
The **About** dialog appears.



- 2 Click **Change Language**.  
The **Language Change** dialog appears.




- 3 From the **New Language** drop-down list, select the language you want.
- 4 Click **OK**.
- 5 Click **OK** in the **About** dialog.
- 6 Restart AutoVue for the new localization to take effect.

# Entering a New License Key

You can specify a new license key from the **Help > About** dialog. If you have a **DEMO** or an  **EVAL** installed and you would like to switch to a fully functional license, you can do so from this dialog, or if you would like to switch from one variation of AutoVue to another.

- 1 Select **Help > About** from the AutoVue main menu.  
The **About** dialog appears.



- 2 Click **Enter New License Key**.  
The **License Key** dialog appears.



- 3 Enter the **New License Key**.
- 4 Click **OK**.
- 5 Click **OK** in the **About** dialog.
- 6 Restart AutoVue for the new license key to take effect.

**Note** If you are switching from a 2D/Office variation of AutoVue to a 3D/EDA variation, you will be prompted to re-run the installer for AutoVue. Rerun the installer and select **Modify**. AutoVue will install all required components as per your license.

**Note** If your evaluation or Demo license expires, you will not be able to startup AutoVue. When you try to startup AutoVue, it will prompt you for a license key. Enter a license key in order to be able to continue working with AutoVue.

---

# Viewing and Exporting File Versions Information

From the **Help About** dialog, you can view the version, build number and date of the decoder dll files, as well as export the files into a text file.

## Viewing File Versions


- 1 Select **Help > About** from the AutoVue main menu.  
The **About** dialog appears.
- 2 Click **Version Info...**  
The **File Versions** dialog appears.
- 3 When you are finished viewing, click **Close**.

## Exporting File Versions

- 1 Select **Help > About** from the AutoVue main menu.  
The **About** dialog appears.
- 2 Click **Version Info...**  
The **File Versions** dialog appears.
- 3 Click **Export...**  
The **Export** dialog appears.
- 4 Navigate and select the directory you want to export the file to.
- 5 Enter a **File name** with the extension **.txt**.  
**Note:** The file can only be exported to text file.
- 6 Click **Save**.  
The markup file is exported to the selected directory.

# AutoVue Basics

This section introduces you to the basics of working with AutoVue's graphical user interface.



## Menu Bar

The **Menu** bar is the main access to all the menu commands. The selection of commands changes according to the tasks being accomplished by AutoVue. In addition, the **Menu** bar can be configured to include and exclude items via DDE scripting capabilities. For more information, *see the AutoVue API Manual*.


# Toolbars


Toolbars are fully adaptable to individual work preferences and can be easily customized, moved or removed. The **Toolbar** buttons offer easy access to the options presented in the drop-down menus found in the **Menu** bar.

# Status Bar

In both **View** mode and **Markup** mode, there is a **Status** bar located at the bottom of the main window. The fields displayed from left to right on the **Status** bar are: marker, current active filename, file type, zoom factor, current page and total number of pages, current active file size, file creation date and cursor's coordinate position.

In addition to the fields, there are two markers that may be present on the Status bar.

The red light bulb  indicates that the current active file has associated Markups. While in **View** mode, click the red light bulb to view the **Markup Files** dialog, then select a Markup file or group of Markup files to open. By opening a Markup file, Markup mode is automatically launched.

A red circle with an “i”  indicates that some main resources required to properly read the current active file are not available. To identify the missing resources, click the red circle to display the **File Properties** dialog.

# Quick Menus

One of the quickest ways to access options is through **Quick Menus** — or context-sensitive shortcut menus. These are the menus you see when you right-click in the workspace. The **Quick Menu** options available depend on the mode you are in and what is selected prior to right-clicking.

# Opening Files with AutoVue

How to open files depends on the current active mode in AutoVue. In **View** mode, you can open base files. In **Markup** mode, you can open a Markup file for a base file.

You can browse files in a directory, open files simultaneously and view the contents of archive files.

## Opening a File

- 1 Select **File > Open** from the AutoVue main menu.  
The **Open** dialog appears.
- 2 Enter a **File name** or browse to locate the file that you want to open.
- 3 Click **Open**.  
The file appears in the AutoVue workspace.

## Opening Multiple Windows

By default, AutoVue keeps one file open at a time. If you open a new file, the currently opened file is replaced with the new file. However, it is possible to have multiple files open by creating windows within AutoVue.

- 1 Select **Window > New** from the AutoVue main menu.  
A new window appears on top of the opened file.
- 2 Select **File > Open**.  
The **Open** dialog box appears.
- 3 From the **Look in** drop-down list, select the file that you want to open or enter the **File name**.
- 4 Click **Open**.  
The file appears in the new window.  
**Note** You can open as many windows as you like by selecting **Window > New** and repeating steps 2 to 4.


## Viewing Multiple Files at the Same Time



You can arrange the files so you can view them at the same time.

Select **Window > Cascade** if you want the files to appear on top of each other.  
Select **Window > Tile Horizontally** if you want the files to appear side by side.  
Select **Window > Tile Vertically** if you want the files to appear above each other.

## Browsing Files

When you use the **Browse** option, all files and folders in the current directory are displayed in the **Browse** dialog and the last file opened is highlighted.

- 1 Select **File > Browse** from the AutoVue main menu.  
The **Browse** dialog appears listing the files located in the current active directory.  
  
**Note** You can also click the Browse button  on the AutoVue toolbar.
- 2 To change the current active directory, type the full path of the directory in the text field at the top of the **Browse** dialog.  
The list of files contained in the directory appear.
- 3 Select the file that you want to view.  
The file is displayed in the AutoVue workspace.
- 4 Continue selecting and viewing files as often as you like since the **Browse** dialog box floats over the other AutoVue windows.
- 5 Click **Close** to close the **Browse** dialog.  
The last file displayed remains open.

**Note** You can also browse files in the current active directory by selecting **File > Next File** or **Previous File** or by clicking the Next File button   
or the Previous File button  on the AutoVue toolbar.

## Archive Files

The full archive file directory displays in the AutoVue window. It is not necessary to decompress the file. Double-click a file to display it within AutoVue. If you would like to mark up an archive file, the file must be accessible for AutoVue in a format other than archive.

# Viewing File Properties

You can access the file properties from the **File** menu. The **Properties** dialog provides information specific to the current active file, such as filename, file size, date of creation and file type. The file properties that you can view are:

Property	Description
File	Information specific to the current active file, such as filename, file size, date of creation, file type and x, y & z dimensions.
Resource Information	Resources specific to the current active file, such as text font, shape file, line style and external reference files.
Native	Custom properties for file types, such as last person who saved the file, signature verification and author comments.

**Note** The file properties can vary depending on the file format viewed.

- 1 Select **File > Properties** from the AutoVue main menu.  
The **Properties** dialog appears.
- 2 To view file properties, click the **File Properties** tab.  
To view resource information, click the **Resource Information** tab.  
To view native properties, click the **Native Properties** tab.
- 3 Click **OK** to close the dialog.

## Selecting

The **Select** option is available when viewing graphic and non-graphic files. For non-graphic files, you can only select text, click and drag to the select text.

- 1 Select **Edit > Select** from the AutoVue main menu.  
A checkmark appears beside **Select**.
- 2 In the graphic file, click and drag the area you want to select.
- 3 To select a block of text, database or spreadsheet cells, etc., position the cursor at the beginning of the block, then while pressing the **Shift** key click at the end of the block.
- 4 To copy the selected data, select **Edit > Copy** or press **Ctrl+C**.  
The data is sent to the clipboard.  
**Note** To exit **Select** mode, select **Edit > Select**. The checkmark disappears.

# Associations

Files of a particular file extension can be associated with an application other than AutoVue. These files can be opened by the associated application for viewing, editing and printing. For example, you can configure WordPerfect to open all **.wpd** files for viewing and printing, while you are operating AutoVue. If you have a file with a non-standard extension, this option can associate that particular file with AutoVue.

**Note** Since only files and programs of the same type can be associated, select programs that use the same extensions for their files as the current active file.

## Creating an Association

- 1 Select **File > Associate** from the AutoVue main menu.  
A dialog appears with the full path of the current active file displayed in the title bar.
- 2 Enter a description for the association (optional).
- 3 In the **Command Line**, enter the full path or click **Browse** to locate the program that you want to associate with the current file.
- 4 Click **OK**.
- 5 To activate the association, select **File > Launch**.  
The associated program is launched.

## Removing an Association

- 1 Select **File > Associate** from the AutoVue main menu.  
A dialog appears with the full path of the current active file displayed in the title bar.
- 2 Click **Remove**.  
The associated program file disappears.
- 3 Click **OK** to close the dialog.

## Activating an Association

- 1 Open the file that you want to activate an association, then select **File > Launch** from the AutoVue main menu.  
The associated program is launched.

# Working With 2D Files

AutoVue provides easy access to entity information and displays color-coded comparative data for 2D drawings. You can instantly manipulate how the current active file is displayed. You can also modify AutoVue to suit your needs and preferences through a broad range of configuration options.

## Searching Text

You can perform a text search on 2D vector and text-based documents.

**Note** You can not perform a text search on raster files.

AutoVue provides search options that you can use to customize a search. These options are:

Option	Description
Match Whole Word Only	Match a complete word.
Match Case	Search for a word or text string with specific capitalization.
Up	Search backward in the document.
Down	Search forward in the document.




- 1 Select **Edit > Search** from the AutoVue main menu.  
The **Find** dialog appears.
- 2 In the **Find What** text box, enter the word or phrase that you want to find.  
**Note** If you are searching in a vector file, select a text string from the list.
- 3 Customize your search.
- 4 Click **Find Next**.  
AutoVue highlights the text and zooms into the text area.
- 5 Click **Close** to close the **Find** dialog.  
**Note** To repeat the last search criteria, select **Edit > Repeat Search** from the AutoVue main menu.





# Manipulating 2D Views







With the **View** options you can instantly manipulate how the current active file is displayed. You can rotate a file's orientation counterclockwise by 90, 180 or 270 degrees, flip a file's orientation horizontally, vertically or both simultaneously.

AutoVue provides several ways to change the view size of a selected area of a file, display different views, layers and blocks of the current active file. You can also navigate from one page to another page of a multi-page file.

You can access these options from the **View** menu. The options are:

Menu	Option	Description
Zoom	In	Zoom in by a factor of 2. From the toolbar, click the  button.
	Out	Zoom out by a factor of 2. From the toolbar, click the  button.
	Full Resolution	Display the file at full resolution. From the toolbar, click the  button.
	Fit	Adjust the contents of a file along the horizontal or vertical axis to fully display within the current window.  <b>Fit Both</b> - AutoVue finds the best fit for the current file with respect to both its vertical and horizontal dimensions. <b>Note</b> This option is also known as <b>Zoom Fit</b> when right-clicking in the workspace.  <b>Fit Vertical</b> - Fit the image vertically in the active window. The horizontal dimensions of the image are zoomed proportionally but may be too large or small for the window.

Menu	Option	Description
		<p><b>Fit Horizontal</b> - Fit the image horizontally in the active window. The vertical dimensions of the image are zoomed proportionally but may be too large or small for the window.</p> <p><b>Note</b> This option is also know as <b>Zoom Page Width</b> when right-clicking in the workspace.</p>
	Previous	Revert to the previous selected zoom option.
<p><b>Note</b> The <b>Rotate</b> option is disabled for text-based documents and spreadsheets.</p>		
Rotate	0	<p>Set the file to its original position.</p> <p>From the toolbar, click the  button.</p>
	90	<p>Rotate the file 90 degrees anti-clockwise.</p> <p>From the toolbar, click the  button.</p>
	180	<p>Rotate the file 180 degrees anti-clockwise.</p> <p>From the toolbar, click the  button.</p>
	270	<p>Rotate the file 270 degrees anti-clockwise.</p> <p>From the toolbar, click the  button.</p>
<p><b>Note</b> When in <b>Markup</b> mode, you can specify if the rotate is to be applied to the Markups only or to the base file and Markups.</p>		
<p><b>Note</b> The <b>Flip</b> option is disabled for text-based documents and spreadsheets.</p>		
Flip	None	Reset the drawing to its original position.
	Horizontal Axis	Flip the drawing on its horizontal axis.
	Vertical Axis	Flip the drawing on its vertical axis.
	Both Axes	Flip the drawing on its vertical and horizontal axes.
<p><b>Note</b> When in <b>Markup</b> mode, you can specify if the flip is to be applied to the Markups only or to the base file and Markups.</p>		

Menu	Option	Description
<b>Note</b> The <b>Image</b> option is used for black-and-white (monochrome) raster files.		
Image	Contrast	Light, normal, dark and darkest.
	Anti-alias	Enhance the details of monochrome raster files. <b>Note</b> Also known as “Scale to Grey”.
	Invert	Reverse the background and foreground colors.
Page	Next Page	Go to the next page of a multi-page file. From the toolbar, click the  button.
	Previous Page	Go to the previous page of a multi-page file. From the toolbar, click the  button.
	Page Number	Go to the specified page of a multi-page file. From the toolbar, click the  button.
Special View Modes	Birds Eye	Display a close-up view of a particular area of a file while maintaining a view of the entire file. From the toolbar, click the  button. <b>Note</b> The <b>Birds Eye</b> option is disabled for text-based documents and spreadsheets. <b>See</b> <i>Using Bird’s Eye View</i>
	Magnify Glass	Magnify an area of the file that is specified by the cursor location. From the toolbar, click the  button. <b>See</b> <i>Using the Magnifying Glass</i>
	Magnify Window	Magnify a selected area of a file and displays it in the Magnify Window. From the toolbar, click the  button. <b>See</b> <i>Using the Magnifying Window</i>
	Pan	Click and drag to move the drawing. To exit right-click.

Menu	Option	Description
Show Model Tree		Show/hide the <b>Model</b> tree of the current active file.

## Using Birds Eye View

The **Birds Eye** view option allows a close-up view of a particular area of a file while maintaining a full view of the file. The Birds Eye window displays a miniature version of the file. A movable box frame on top of the miniature indicates the area of the file displayed in the AutoVue workspace.

**Note** The **Birds Eye** option is disabled for text-based documents and spreadsheets.

- 1 Select **View > Special View Modes > Birds Eye** from the AutoVue main menu.  
The **Bird's Eye** window appears displaying a full view of the file.
- 2 To view the changes in “real time”, select **Options > Dynamic** from the **Birds Eye** menu.
- 3 To view a close-up of a specific area of the file in the AutoVue workspace, minimize the frame box by clicking and dragging the frame handles.  
To view a different area of the file in the AutoVue workspace, click and drag the frame box to the area that you want to view.  
**Note** If you perform a zoom function in the AutoVue workspace, the area displayed in the workspace is highlighted by the frame box in the **Birds Eye** window.
- 4 Select **Bird's Eye > Exit** to close the **Bird's Eye** dialog.  
The last view performed remains in the AutoVue workspace.

## Using the Magnify Glass

The **Magnify Glass** view option zooms an area specified by the position of the Magnify Glass. You can view the details of a selected area of a file while maintaining a full view of the file.

- 1 Select **View > Special View Modes > Magnify Glass** from the AutoVue main menu.


**Note** You can also click the Magnify Glass button  on the AutoVue toolbar.

- 2 Move the cursor to the area that you want to magnify.
- 3 Click and hold the left mouse button.  
The area is magnified in the Magnify Glass.  
**Note** To view different areas of the file, click and drag the mouse.
- 4 Right-click to exit **Magnify Glass**.

## Using the Magnify Window

The **Magnify Window** option zooms an area specified by the position of the cursor. You can view the details of a select portion of the displayed file while maintaining the display of the full file.

- 1 Select **View > Special View Modes > Magnify Window** from the AutoVue main menu.  
The **Magnify Window** appears.

**Note** You can also click the Magnify Window button  on the AutoVue toolbar.

- 2 Move the cursor to the area that you want to magnify in the current active file.
- 3 Click once.  
The area appears magnified in the **Magnify Window**.
- 4 Right-click to exit the **Magnify Window**.

## Conversion

Sometimes you need to translate a file to be able to use it with an application it was not created from. AutoVue provides several conversion file formats for you.

## Conversion Options

Depending on the conversion type being performed, the available options in the **Convert** dialog will vary. These options are:

---

Option	Description
Color Depth	Select an option from the drop-down list: <ul style="list-style-type: none"><li>• <b>1</b> = Black and white</li><li>• <b>4</b> = 16 colors</li><li>• <b>8</b> = 256 colors</li><li>• <b>24</b> = True color</li><li>• <b>auto</b> = AutoVue selects the color depth that best matches the original file.</li></ul>
Convert to Format	A drop-down list of all the possible types of output file formats currently available for conversion. The available formats are: <ul style="list-style-type: none"><li>• CALS GP4</li><li>• Encapsulated Postscript (Raster)</li><li>• HP Laserjet Printer (HLP)</li><li>• PCX Bitmap</li><li>• PDF</li><li>• Run Length RLC File</li><li>• TIFF</li><li>• Windows Bitmap</li></ul>
Output	Specify the name and path of the file in which the conversion is to be stored. This file is also known as the output file. You can use <b>Browse</b> to provide AutoVue with the file's path.
Sub-Format	The <b>Sub-Format</b> drop-down list appears when you selected <b>HP Laserjet Print</b> or <b>TIFF</b> from the <b>Convert to Format</b> drop-down list. Select a sub-format from the drop-down list..

---

Option	Description
Convert Region	<p>The area of the file to be converted. The available options are:</p> <ul style="list-style-type: none"> <li>• <b>Display</b> - the area displayed in the workspace. For example, if you zoomed in on a particular region of the file, the zoomed portion of the file is converted.</li> <li>• <b>Extent</b> - refers to the entire extents of the file.</li> </ul>
Convert Pages	<p>The number of pages to be converted. The available options are:</p> <ul style="list-style-type: none"> <li>• <b>All</b> - convert all pages</li> <li>• <b>Current</b> - convert the current page</li> <li>• <b>Range</b> - convert the pages indicated in the range</li> </ul>
X and Y	<p>Choose from pixels, inches and millimeters for the units.</p> <p><b>Note</b> With raster files the units are preset as pixels:</p> <ul style="list-style-type: none"> <li>• <b>X</b> indicates the number of horizontal pixels</li> <li>• <b>Y</b> is the number of vertical pixels for the current active file contents.</li> </ul> <p>At times, AutoVue will preset <b>X</b> and <b>Y</b> to match the specifications of the selected conversion file format. Other times, <b>X</b> and <b>Y</b> will be available and may be changed according to your preferences. Your selection here will not affect the current display but will affect the conversion file's resolution.</p>

## PDF

With AutoVue it is possible to convert Office, 2D and EDA formats to PDF. When converted from **Markup Mode**, markups are “burned” onto the PDF. When you open the PDF, you will see the base file along with all markups.

## X and Y

Three factors affect the resolution of an image: the type of image you are scanning, the output device and the acceptable file size. High-resolution scans often require large files, causing longer processing and print time. Note that a high-resolution may not produce a better-quality printed image if your output device does not recognize the higher resolution information stored in the file. To

keep file sizes manageable, select the lowest resolution that provides acceptable quality on your output device.

With some file types, the **Size** option appears giving you a choice between millimeters and inches. Page sizes can be selected from the **Size** drop-down list or you can customize page sizes by configuring the Initialization file. For more information, *see System Administration Guide*.

Technical Drawing Page Sizes	ISO Paper Format
A8.5" X 11.0" (216 mm X 279 mm)	A4 285 mm X 198 mm
B11.0" X 17.0" (279 mm X 432 mm)	A3 396 mm X 273 mm
C17.0" X 22.0" (432 mm X 559 mm)	A2 570 mm X 396 mm
D22.0" X 34.0" (559 mm X 864 mm)	A1 817 mm X 570 mm
E34.0" X 44.0" (864 mm X 1118 mm)	A0 1165 mm X 817 mm

## Converting a File

- 1 Select **File > Convert** from the AutoVue main menu.  
The **Convert** dialog appears.  
**Note** The **Input** area varies according to the type of file. A word-processing file displays the file format; a raster file displays the file format and size; vector and database files display the size, file type and dimensions.
- 2 In the **Save As** text box, enter the path and filename or click **Browse** to locate the directory where you want to save the converted file.  
**Note** If writing on to an existing file, the contents of the output file will be overwritten.
- 3 Specify the conversion options.  
**See Conversion Options**
- 4 Click **OK**. The file is converted and appears in the specified directory.  
**Note** You can convert several selected pages of a multi-page file to a multi-page TIFF.  
**See Also Batch Conversion**

## Changing the Pen Settings

With AutoVue, you can specify a thickness for each pen color.

**Note** This option only applies to vector files.

- 1 Select **File > Convert** from the AutoVue main menu.  
The **Convert** dialog appears.
- 2 Click **Pens**.  
The **Pen Settings** dialog appears.
- 3 In the **From/To**, select the **Color Index** for which you want to modify the thickness.  
**Note** To select more than one **Color Index**, click the **Shift** or **Ctrl** key while selecting.
- 4 From the **Units** drop-down list, select the unit in which you want to set the thickness.
- 5 Click **Thickness**.  
The **Modify Pen Thickness** dialog appears.
- 6 Enter a thickness.
- 7 Click **OK**.  
The new **Thickness** appears beside the selected **Color Index**.
- 8 To save the changes that you made, click **Save As**.  
The **Save As** dialog appears.
- 9 Enter a **Name** for the new pen settings.
- 10 Click **OK**.  
The new pen settings are saved and appear in the **Current Pen Settings** list.  
**Note** To modify an existing **Pen Settings**, select the pen settings from the **Current Pen Settings** drop-down list, make the changes, then click **Save**.
- 11 Click **OK** to close the **Pen Settings** dialog.

## Batch Conversion

You can save time by simultaneously converting files with the same output file format.

- 1 Select **File > Convert** from the AutoVue main menu.  
The **Convert** dialog appears.
- 2 Click **Batch Convert**.  
The **Batch Convert** dialog appears.
- 3 Click **Add**. The **Open** dialog appears.
- 4 Enter the **File name** or browse to locate the file that you want to add, then click **Open**.  
The file appears in the **Input File List**.

**Note** To add more files, repeat steps 3 to 4. To remove a file, select the file from the **Input File List** and click **Remove**.

- 5 Customize the convert options.

**See *Converting a File***





- 6 Click **OK**.

AutoVue stores the newly converted file(s) in the same directory as the first file you entered in the **Input File List**.

## Measuring in 2D non-vector Files

AutoVue provides the ability to perform measurements in 2D files. Measure options vary between vector and non-vector files. For vector files, AutoVue provides the option to “snap” to fixed points on the drawing. For non-vector files, you can only “free snap”.


AutoVue provides several measure options that you can choose from. You can access the measure options from the **Analysis > Measure** menu. The options are:

Name	Description
Angle	Measure the angle between selected points. Click the Angle button  in the toolbar.
Arc	Measure an arc. Click the Arc button  in the toolbar.
Area	Measure a selected area. Click the Area button  in the toolbar.
Distance	Measure the distance between two points. Click the Distance button  in the toolbar.

## Measuring Distance

Use the **Distance** option to measure the distance between two specific points.

- 1 Select **Analysis > Measure** from the AutoVue main menu.  
The **Measurement** dialog appears.

- Note** You can also click the Distance button  on the AutoVue toolbar.
- 2 Click the **Distance** tab.
  - 3 From the **Measured Distance Units** drop-down list, select the unit in which you want to measure the distance.  
**Note** If you want to measure the distance along a path, select **Cumulative**.
  - 4 Click a point on the drawing to define the starting point.
  - 5 Click another point on the drawing to define the end point.  
**Note** If you selected **Cumulative**, continue clicking points along the path that you want to measure.
  - 6 Right-click to complete the measurement.  
The points are joined by a line. The measured distance, Delta-X and Delta-Y appear in the **Measurement** dialog.  
**Note** Click **Reset** to take another measurement.
  - 7 Click **Close** to close the **Measurement** dialog.


## Calibrating Distance

- 1 Measure distance between two points or measure cumulative distance.  
**See *Measuring Distance***
- 2 In the **Measurement** dialog, click **Calibrate**.  
The **Distance Calibration** dialog appears displaying the measured distance.
- 3 From the **Measured Dist.** drop-down list, select the unit to which you want to calibrate the distance.
- 4 Click **Calibrate to** and enter a value if you want to calibrate the distance to a value.  
Click **Set Factor** and enter a value if you want to calibrate the distance by a factor.
- 5 Click **OK**.  
The calibration result appears in the **Measurement** dialog.
- 6 Click **Close** to close the **Measurement** dialog.

## Measuring Area

Use the **Area** option to measure the area and perimeter of a region.


- 1 Select **Analysis > Measure** from the AutoVue main menu. The **Measurement** dialog appears.

**Note** You can also click the Area button  on the AutoVue toolbar.

- 2 Click the **Area** tab.
- 3 From the **Measured Area Units** drop-down list, select the unit in which you want to measure the area.  
From the **Perimeter Units** drop-down list, select the unit in which you want to measure the perimeter.  
**Note** To cumulate a **Net Area Result** of different areas, select **Add** in the **Measurement** dialog. To subtract an area from the **Net Area Result**, select **Subtract**. Select **Clear** to clear the **Net Area Result**.
- 4 Click a point on the drawing to define the starting point.
- 5 Continue clicking points on the drawing to define the area you want to measure.  
Each point is joined by a line. The area and perimeter measurements appear in the **Measurement** dialog.
- 6 Right-click to complete the measurement.  
**Note** Click **Reset** to take another measurement.
- 7 Click **Close** to close the **Measurement** dialog.

## Measuring an Angle


Use the **Angle** option to measure the angle between points on a drawing.

- 1 Select **Analysis > Measure** from the AutoVue main menu.  
The **Measurement** dialog appears.  
**Note** You can also click the Angle button  on the AutoVue toolbar.
- 2 Click the **Angle** tab.
- 3 From the **Measured Angle Units** drop-down list, select the unit in which you want to measure the angle.
- 4 Click points on the drawing to define the angle you want to measure.  
Angle arms appear with an arc connecting them. The angle measurement appears in the **Measurement** dialog.  
**Note** Click **Reset** to take another measurement.
- 5 Click **Close** to close the **Measurement** dialog.

## Measuring an Arc

Use the **Arc** option to define an arc in the drawing and measure its radius, center and diameter.

- 1 Select **Analysis > Measure** from the AutoVue main menu.  
The **Measurement** dialog appears.

**Note** You can also click the Arc button  on the AutoVue toolbar.

- 2 Click the **Arc** tab.
  - 3 From the **Arc Info** drop-down list, select the unit in which you want to measure the arc.
  - 4 From the **Measured Angle Units** drop-down list, select the unit in which you want to measure the angle.
  - 5 Click points on the drawing to define the arc.  
The points are joined by an arc. The measurements for center point coordinates, radius, diameter, arc length, start and end of angle and sweep appear in the **Measurement** dialog.
- Note** Click **Reset** to take another measurement.
- 6 Click **Close** to close the **Measurement** dialog.

## Calibrating an Arc

- 1 Measure an arc in the drawing.  
**See *Measuring an Arc***
- 2 In the **Measurement** dialog, click **Calibrate**.  
The **Radius Calibration** dialog appears displaying the measured distance.
- 3 From the **Measured Rad.** drop-down list, select the unit to which you want to calibrate the distance.
- 4 Click **Calibrate to** and enter a value if you want to calibrate to a value.  
Click **Set Factor** and enter a value if you want to calibrate by a factor.
- 5 Click **OK**.  
The calibration result appear in the **Measurement** dialog.
- 6 Click **Close** to close the **Measurement** dialog.

## Working with 2D Vector Files

In addition to all features that are available for generic 2D files, AutoVue provides the ability to access entity information, access views saved in the drawing and the ability to “intelligent snap” when performing measurements.




AutoVue references various sources to obtain all data required to completely and accurately display vector files. These sources can be internal to the file, like layers and blocks or external reference files that are located outside the file.

## Manipulating 2D Vector Views

With the **View** options you can instantly manipulate how the current active file is displayed. You can rotate a file's orientation counterclock-wise by 90, 180 or 270 degrees, flip a file's orientation horizontally, vertically or both simultaneously.

AutoVue provides several ways to change the view size of a selected area of a file, display different views, layers and blocks of the current active file. You can also navigate from one page to another page of a multi-page file. For more information on how to manipulate views, **see *Manipulating 2D Views***.

For 2D vector files, there are additional **View** options:

Option	Description
Views	Select and display different views of a drawing. From the toolbar, click the  button. <b>See <i>Selecting Views</i></b>
Layers	Select and display different layers of a drawing. From the toolbar, click the  button. <b>See <i>Layers</i></b>
Blocks	Select and display a block from a drawing. From the toolbar, click the  button. <b>See <i>Blocks</i></b>

## Drawing Information

The **Drawing Information** option is available with AutoCAD and MicroStation drawings, and is accessed from **Analysis** of the AutoVue main menu in both **View** and **Markup** modes. The **Drawing Information** options available are: **Select Single Entity**, **List Tags/Attributes** and **Entity Information**.

## Viewing Details of a Single Entity

**Note** This feature is currently not supported with AutoVue Server running on Unix Platforms.

- 1 Select **Analysis > Drawing Information > Select Single Entity** from the AutoVue main menu.
- 2 Click the entity for which you want to view information.  
The **Get Entity Info** dialog appears displaying the information for the selected entity.  
The **XData** button appears if additional information exists for that entity.  
Click **XData** to view the information.  
**Note** If you did not select an entity, a message appears informing you that no entities were found and prompts you to select again.
- 3 Click **OK** to close the **Get Entity Info** dialog.

## Viewing information for a Set of Entities

**Note** This feature is currently not supported with AutoVue Server running on Unix Platforms.

The **Entity Information** option allows you to view information of a set of entities contained in a specific area of a file.

- 1 Select **Analysis > Drawing Information > Entity Information** from the AutoVue main menu.
- 2 Click and drag to draw a box around an area for which you want to view entity information for the list of entities contained inside the area.  
The **List Entities** dialog appears displaying the information of all the selected entities.  
**Note** If there are no entities within the selected area, a message appears informing you that no entities were found and prompts you to select again.
- 3 Click **OK** to close the **List Entities** dialog.

## Viewing Tags/Attributes

**Note** This feature is currently not supported with AutoVue Server running on Unix Platforms.

- 1 Select **Analysis > Drawing Information > List Tags/Attributes** from the AutoVue main menu.
- 2 Click in the area of the file for which you want to view information on block attributes and tags.  
The **Block Attributes** dialog appears displaying the attributes/tags for the selected entity.  
**Note** If there are no entities within the selected box, a message appears informing you that no entities were found and prompts you to select again.

- 3 Click **OK** to close the **Block Attributes** dialog.


## Viewing XRefs




AutoVue references various sources to obtain all the data required to completely and correctly display files. These sources can be internal to the file, like layers and blocks. External reference files or Xrefs are located outside the file.

Use the **XRefs** option to display the external references of the current active file.

- 1 Select **View > XRefs** from the AutoVue main menu.  
The **Select the External References to display** dialog appears listing the external reference files associated with the current active file.
- 2 Select the checkbox beside the **XRefs** that you want to display.  
Clear the checkbox beside the **XRefs** that you want to hide.
- 3 Click **OK**.  
The selected **XRefs** are displayed.

## Displaying Details About Missing XRefs

If a file has missing resources, a red circle with an “i”  appears to the left of the AutoVue status bar.


- 1 Click the Resource icon  on the AutoVue status bar.  
The **Properties** dialog appears.  
**Note** You can also select **File > Properties** from the AutoVue main menu.
- 2 Click the **Resource Information** tab to display details about missing resource information required to properly display this file.  
  
A green check mark  indicates the resources that AutoVue is able to access.  
  
A red  indicates the external reference files or components that are not accessible.
- 3 Click **OK** to close the **Properties** dialog.

## Layers

Use this option to configure the current active file’s layers to display.

- 1 Select **View > Layers** from the AutoVue main menu.

The **Select the layers to display** dialog appears listing the layers and layer visibility for the current active file.


**Note** You can also click the Layers button  on the AutoVue toolbar.

- 2 To sort the list of layers in the dialog, click **Name** to sort alphabetically or numerically, or click **Status** to sort by visibility.
- 3 Select the checkbox beside the layers that you want to set visible.  
Clear the checkbox beside the layers that you want to hide.
- 4 Click **OK**.  
The selected layers are displayed.

## Blocks

Use this option to select a block to display from the current active file.

- 1 Select **View > Blocks** from the AutoVue main menu.  
The **Select a block to display** dialog appears listing the blocks for the current active file.


**Note** You can also click the Block button  on the AutoVue toolbar.

- 2 From the drop-down list, select the block that you want to display.
- 3 Click **OK**.  
The selected block is displayed.

## Selecting Views

The **Views** option allows you to access different named views of a file.

- 1 Select **View > Views** from the AutoVue main menu.  
The **Select a named view** dialog appears.

**Note** You can also click the View button  on the AutoVue toolbar.

- 2 From the drop-down list, select the view that you want to display.
- 3 Click **OK**.  
The selected view is displayed.

## Specifying a View Point

The **View Point** option allow you to render a drawing from a selected viewpoint. The default view point is the one used to create the file.

- 1 Select **View > View Point** from the AutoVue main menu.  
The **View Point** dialog appears.

- 2 Enter the **X**, **Y** and **Z** coordinates for the viewpoint with which you want to render the drawing.
- 3 Click **OK**.  
The drawing is displayed from the selected viewpoint.

## Comparing 2D Files

AutoVue provides the ability to visually compare two files and display color-coded comparative data. When you compare two files, AutoVue displays three windows, the first containing the original file, the second containing the file you compared the original against, and the third containing the comparison results.

In the **Comparison Result** window you can specify whether you want to display only the additions, deletions or unchanged, or any combination of the three. To access these options, right-click in any window and select an option from the pop-up menu.

The comparison results are displayed in different colors to differentiate the results of the file comparison. The comparison options and corresponding colors are:

Option	Color	Description
View Additions	Green	Indicates that something has been added.
View Deletions	Red	Indicates that something has been deleted.
View Unchanged	Blue	Indicates that there is no change.

- 1 View the base file in AutoVue.
- 2 Select **Analysis > Compare** from the AutoVue main menu.  
The **File Open** dialog appears.
- 3 Enter the **File Name** or click **Browse** to select the file that you want to compare with the current active file.
- 4 Click **OK**.  
AutoVue displays three windows, the first displaying the original file, the second displaying the compare file and the third displaying the comparison results.  
**Note** If you apply a change from the **View** menu, all three windows display the synchronized change.
- 5 To access the **Compare** options, right-click in any of the windows.

A pop-up menu appears displaying the **Compare** options.

**Note** To maximize any of the windows, double-click the title bar of the window that you want to maximize. To restore the window, double-click the title bar.

- 6 To exit **Compare** mode, select **File > Exit Compare Mode** from the AutoVue main menu.

The original file appears in the workspace.

**Note** You can also exit **Compare** mode by right-clicking in any of the windows and selecting **Exit Compare Mode** from the pop-up menu.

**See Also** *Specifying Scale and Offset for a Compare File*

## Specifying Scale and Offset for a Compare File

You can scale or translate a file in order to compare files accurately. With the **Scale and Offset** option you can modify the coordinates (**XOffset** and **YOffset**) or enter a scaling factor for the second file.

**Note** **XOffset** and **YOffset** are relative to the base drawing and all options are displayed at their current values.

- 1 In Compare mode, select **View > Scale and Offset** from the AutoVue Main window.

The **Scale and Offset** dialog appears.

- 2 In the **Scale and Offset** dialog, enter the required values for the **Scale Options: XOffset, YOffset and Scale**.

- 3 Click **OK**.

The scaling/offset modifications are applied to the file in the second window.

## Overlays

When working with 2D files, you can overlay other files over the current active file. You can also adjust an overlay, move an overlay, and scale an overlay by defining the X and Y coordinates and the scaling factor.

### Adding an Overlay

**Note** When working with a raster file, it should be used as the base file because raster formats are opaque and would hide files underneath them.

- 1 View the file that you want to use as the base file for the overlay.
- 2 Select **Analysis > Overlays > Select** from AutoVue main menu.

The **File Open** dialog appears.

- 3 Enter the **File Name** or click **Browse** to select the file you want to overlay.
- 4 Click **OK**.

The base file is displayed with the selected overlay file on top of it.

**Note** To lay multiple files over one base file, repeat steps 2 to 4 using the same base file. Overlays are added one at a time.

## Modifying an Overlay

- 1 Select **Analysis > Overlays > Modify** from AutoVue main menu.  
The **Modify Overlay** dialog appears.
- 2 Select the Overlay that you want to modify.
- 3 Click the **Action** that you want to apply to the overlay.
  - Click **Move** if you want to move the overlay.  
Click a point on the base file where you want to set the lower left corner of the overlay. Click another point where you want to set the upper right corner of the overlay.  
**Note** As you select the point to define the position of the upper right corner, you can resize the destination box.
  - Click **Scale** if you want to resize the overlay.  
Enter the **XOffset** and **YOffset** coordinates and/or the **Scale** factor.  
**Note** **XOffset** and **YOffset** are relative to the base drawing and all options are displayed at their current values.
  - Click **Warp** to adjust the overlay.  
Click a point on the overlay and drag the cursor to where you want the overlay starting point. Click another point and drag the cursor to where you want the overlay to end.  
**Note** The overlay's size is scaled to accommodate the origin and destination points you defined.
- 4 Click **OK**.  
The changes are applied to the selected overlay.  
**Note** To modify other overlays, repeat steps 2 to 4.

## Removing an Overlay

- 1 Select **Analysis > Overlays > Modify** from AutoVue main menu.  
The **Modify Overlay** dialog appears.
- 2 Select the Overlay that you want to remove.
- 3 Click **Remove**.  
A confirmation dialog appears.
- 4 Click **Yes**.





The overlay is removed from the list in the **Modify Overlay** dialog and from the display.

## Measuring in 2D Vector Files

AutoVue provides the ability to perform measurements in 2D files. Measurement options vary between vector and non-vector files. For vector files, AutoVue provides the option to “snap” to fixed points on the drawing. For non-vector files, you can only “free snap”.

You can access the measure options from the **Analysis > Measure** menu. These options are:

---





Name	Description
Angle	Measure the angle between selected points. From the toolbar, click the  button.
Arc	Measure an arc entity. From the toolbar, click the  button.
Area	Measure selected area. From the toolbar, click the  button.
Distance	Measure the distance between two points. From the toolbar, click the  button.

---

## 2D Vector Snapping Modes

The **Snapping Modes** available allow you to click to precise geometrical points on a drawing. For example, if you select **Snap to end-point** and you move the cursor over an end-point of a line, the end-point will be highlighted by a snap box.


The **Snapping modes** allow you to snap to the mid, center and end-points of an entity:

Button	Snap to	Description
	End-point	Geometric snap mode where a snap box appears when moving the cursor near a linear component's end point.
	Mid-point	Geometric snap mode where a snap box appears when moving the cursor near the halfway point of a linear component.
	Center-point	Geometric snap mode where a snap box appears when moving the cursor near the center of an elliptical component.
	Free snap	Allow snapping at any point on the drawing.

## Measuring Distance

Use the **Distance** option to measure the distance between two specific points.

- 1 Select **Analysis > Measure** from the AutoVue main menu.  
The **Measurement** dialog appears.

**Note** You can also click the Distance button  on the AutoVue toolbar.

- 2 Click the **Distance** tab.
- 3 Select the **Snapping Modes** that you want to use for measuring.  
To select all **Snapping Modes** click **All On**. To clear all **Snapping Modes** click **All Off**.

**See 2D Vector Snapping Modes**

- 4 From the **Measured Distance Units** drop-down list, select the unit in which you want to measure the distance.  
**Note** If you want to measure the distance along a path, select **Cumulative**.
- 5 Click a point on the drawing to define the starting point.
- 6 Click another point on the drawing to define the end point.  
**Note** If you selected **Cumulative**, continue clicking points along the path that you want to measure.
- 7 Right-click to complete the measurement.

The points are joined by a line. The measured distance, Delta-X and Delta-Y appear in the **Measurement** dialog.

**Note** Click **Reset** to take another measurement.


- 8 Click **Close** to close the **Measurement** dialog.

## Calibrating Distance

- 1 Measure distance between two points or measure cumulative distance.  
**See *Measuring Distance***
- 2 In the **Measurement** dialog, click **Calibrate**.  
The **Distance Calibration** dialog appears displaying the measured distance.
- 3 From the **Measured Dist.** drop-down list, select the unit to which you want to calibrate the distance.
- 4 Click **Calibrate to** and enter a value if you want to calibrate the distance to a value.  
Click **Set Factor** and enter a value if you want to calibrate the distance by a factor.
- 5 Click **OK**.  
The calibration result appears in the **Measurement** dialog.
- 6 Click **Close** to close the **Measurement** dialog.

## Measuring Area


Use the **Area** option to measure the area and perimeter of a region.

- 1 Select **Analysis > Measure** from the AutoVue main menu. The **Measurement** dialog appears.  
**Note** You can also click the Area button  on the AutoVue toolbar.
- 2 Click the **Area** tab.
- 3 Select **Between Points** if you want to measure the area between points on a drawing. **Snapping Modes** are enabled.
- 4 Select the **Snapping Modes** that you want to use for measuring.  
To select all **Snapping Modes** click **All On**. To clear all **Snapping Modes** click **All Off**.  
**See *2D Vector Snapping Modes***
- 5 Select **Shape** if you want to measure the area of a predefined shape on the drawing. **Snapping Modes** are disabled.
- 6 From the **Measured Area Units** drop-down list, select the unit in which you want to measure the area.

- 7 From the **Perimeter Units** drop-down list, select the unit in which you want to measure the perimeter.
- 8 To cumulate a **Net Area Result** of different areas, click **Add**. To subtract an area from the **Net Area Result**, click **Subtract**. Select **Clear** to clear the **Net Area Result**.
- 9 If you selected **Between Points**, click points on the drawing to define the area.  
Each point is joined by a line. The area and perimeter measurements appear in the **Measurement** dialog.
- 10 Right-click to complete the measurement.
- 11 If you selected **Shape**, click the edge of the predefined shape.  
The shape is highlighted and the area and perimeter measurements appear in the **Measurement** dialog.  
**Note** Click **Reset** to take another measurement.
- 12 Click **Close** to close the **Measurement** dialog.

## Measuring an Angle

Use the **Angle** option to measure the angle between points on a drawing.

- 1 Select **Analysis > Measure** from the AutoVue main menu.  
The **Measurement** dialog appears.  
  
**Note** You can also click the Angle button  on the AutoVue toolbar.
- 2 Click the **Angle** tab.
- 3 Select **From 3 Points** if you want to measure the angle between three points. **Snapping Modes** are enabled.
- 4 Select the **Snapping Modes** that you want to use for measuring.  
To select all **Snapping Modes** click **All On**. To clear all **Snapping Modes** click **All Off**.  
**See 2D Vector Snapping Modes**
- 5 Select **Between 2 lines** if you want to measure the angle between two lines. **Snapping Modes** are disabled.
- 6 From the **Measured Angle Units** drop-down list, select the unit in which you want to measure the angle.
- 7 If you selected **From 3 Points**, click three points on the drawing to define the angle.
- 8 If you selected **Between 2 Lines**, click two lines on the drawing to define the angle.  
Angle arms appear with an arc connecting them. The angle measurement appears in the **Measurement** dialog.


**Note** Click **Reset** to take another measurement.

- 9 Click **Close** to close the **Measurement** dialog.

## Measuring an Arc

Use the **Arc** option to define an arc in the drawing and measure its radius, center and diameter.

- 1 Select **Analysis > Measure** from the AutoVue main menu.  
The **Measurement** dialog appears.

**Note** You can also click the Arc button  on the AutoVue toolbar.

- 2 Click the **Arc** tab.
- 3 Select **From 3 Points** if you want to measure the arc between three points.  
**Snapping Modes** are enabled.  
Click the **Snapping Modes** that you want to select as the points for the measurement.

**See 2D Vector Snapping Modes**

**Note** To select all **Snapping Modes** click **All On**. To clear all **Snapping Modes** click **All Off**.

- 4 Select **Arc Entity** if you want to measure a predefined arc. **Snapping Modes** are disabled.
- 5 From the **Arc Info** drop-down list, select the unit in which you want to measure the distance.
- 6 From the **Measure Angle Units** drop-down list, select the unit in which you want to measure the angle.
- 7 If you selected **From 3 Points**, click three points on the drawing to define the arc.

The points are joined by an arc. The measurements for center point coordinates, radius, diameter, arc length, start and end of angle and sweep appear in the **Measurement** dialog.

- 8 If you selected **Arc Entity**, click the edge of the arc that you want to measure.

The arc is highlighted. The measurements for center point coordinates, radius, diameter, arc length, start and end of angle and sweep appear in the **Measurement** dialog.

**Note** Click **Reset** to take another measurement.

- 9 Click **Close** to close the **Measurement** dialog.

## Calibrating an Arc

- 1 Measure an arc in the drawing.  
**See *Measuring an Arc***
- 2 In the **Measurement** dialog, click **Calibrate**.  
The **Radius Calibration** dialog appears displaying the measured distance.
- 3 From the **Measured Rad.** drop-down list, select the unit to which you want to calibrate.
- 4 Click **Calibrate to** and enter a value if you want to calibrate to a value.  
Click **Set Factor** and enter a value if you want to calibrate by a factor.
- 5 Click **OK**.  
The calibration result appears in the **Measurement** dialog.
- 6 Click **Close** to close the **Measurement** dialog.

# Working with EDA Files


In addition to all features that are available for generic 2D files, AutoVue provides intelligent querying for EDA files. You can create/modify layer sets, you can query entity information, generate BOM, verify EDA designs, cross-probe and perform intelligent measurements.

## Navigation Panel

The **Navigation Panel** is displayed on the left-hand side of the AutoVue workspace when you view an EDA drawing. The **Navigation Panel** allows you to navigate through a list of component instances, nets and the associated pins and net nodes (pins connected to a net) present in the current schematic drawing or PCB design.

The columns displayed in the **Navigation Panel** are determined by the profile of the entity types in the current schematic drawing or PCB design. Lists can be sorted in order to group similar component instances.

You can also use the **Navigation Panel** to select (highlight) a component or entity; zoom to a component or entity and query entity information.



## Components Tab

The **Components** tab lists component instances and the associated pins. The top portion of the panel lists all the instances of the currently displayed page of the drawing. The lower portion of the panel lists the associated pins for selected instance(s).

When you select a component, it appears highlighted on the drawing. To select more than one component, press **Shift** or **Ctrl** and then select the desired components. All the components you selected are highlighted. The associated pins for the selected component(s) are displayed.

## Nets Tab

The **Nets** tab lists nets and associated net nodes (pins connected to a net). The top portion of the panel lists all the nets of the currently displayed page of the drawing. The lower portion of the panel lists the associated net nodes for selected net(s).

When you select a net, it appears highlighted on the drawing. To select more than one net, press **Shift** or **Ctrl** and then select the desired nets. You can also click and drag in the **Navigation Panel** list to select multiple nets. All the nets you selected are highlighted. The associated net node list(s) for all the nets you selected are displayed.

## Bookmarks Tab

The **Bookmarks** tab allows you to navigate between PCB and schematic pages or between the 2D and 3D view of a PCB design.

## Customizing the Navigation Panel

In the **Navigation Panel**, you can sort a column, change column order, or hide or show a column.

- 1 To sort a column, click the column heading.
- 2 To change the column order or to show or hide a column, right-click a column heading and select **Customize** from the pop-up menu.  
The **Customize Columns** dialog appears.

- 3 To show or hide a column, select the checkbox beside the column(s) you want to show.  
Clear the checkbox beside the column(s) you want to hide.  
**Note** To show all columns, click **Show All**. To hide all columns, click **Hide All**.
- 4 To change the column order, select the column you want to move, then click **Move Up** to move the column up in the list or click **Move Down** to move the column down in the list.
- 5 Click **OK**.  
The changes appear in the **Navigation Panel**.

## Selecting Entities

Selecting an entity or entities is often the first step to many of the operations that you will perform with EDA files. You can select an entity or entities in an EDA file from the **Navigation Panel** or the workspace. You can also select entities from the **Entity Browser** when you search for entities. To specify which types of entities you can or cannot select, use the **Entity Type Filter** dialog.

Once you have selected an entity, you can zoom to it in the workspace and perform other operations with the EDA file.

## Selecting Entities from the Navigation Panel

Click any components, nets, associated pins or net nodes in the **Navigation Panel** to select them. To select more than one entity, **Shift**-click or **Ctrl**-click.

The selected entity or entities are highlighted in the workspace. If the selected entity is small, a flash box appears indicating the location of the highlighted entity in the workspace.

*See Also **Zooming to a Selected Entity***

## Selecting Entities in the Workspace

Click an entity in the workspace to select it. To select more than one entity, **Shift**-click or **Ctrl**-click the entities.

The selected entity or entities appear highlighted in the workspace and in the **Navigation Panel**. If the selected entity is small, a flash box appears indicating the location of the highlighted entity in the workspace.

You can also apply selection filters when selecting entities in the workspace. For more information, *see **Filtering Entity Types***.

**Note** When you hover the mouse over an entity in the workspace, a tooltip with information about the entity's attributes appears. The tooltip displays whether or not you select the entity.

*See Also **Zooming to a Selected Entity***

## Selecting Entities from the Entity Browser

- 1 Perform an attribute-based or entity type-based search using the **Entity Browser**.  
*See **Entity Browser***
- 2 Select an entity or entities from the **Entity Types** list or the **Attributes** list of the **Entity Browser** dialog.

**Note** To select more than one entity, press the **Shift** or **Ctrl** key while selecting.

The selected entity or entities appear highlighted in the workspace and in the **Navigation Panel**.

**Note** If the selected entity is too small, a flash box appears indicating the location of the highlighted entity in the workspace.


*See Also **Zooming to a Selected Entity***

## Filtering Entity Types

With the **Entity Type Filter** option, you can display certain entity types while hiding others, without having to hide an entire layer. For example, you might want to turn off all entities and display only the component instances.

You can also limit the types of entities you can select in the workspace.

- 1 Select **View > Entity Type Filter** from the AutoVue menu.  
The **Entity Type Filter** dialog appears.

**Note** You can also click the Entity Type Filter button  on the AutoVue toolbar.

- 2 Under the **Visibility** column, select the checkbox beside the entity types you want to display in the workspace.  
Clear the checkbox to hide the entity types.
- 3 Under the **Selection** column, select the checkbox beside the entity types that you want to be able to select in the workspace.  
Clear the checkbox beside the entity types that you do not want to select.

**Note** To select all entity types, select the checkbox in the column header. Clear the checkbox to deselect all entity types.


- 4 Click **Apply** to apply the changes.
- 5 Close **OK** to close the **Entity Type Filter** dialog.  
Only the selected entities types remain displayed in the workspace.  
When you click in the workspace, only the entities types checked in the **Entity Type Filter** dialog will be highlighted.

## Zooming to a Selected Entity

- 1 In the workspace or **Navigation Panel** select the entity, then right-click and select **Zoom selected**.
- 2 In the **Entity Browser** dialog, select the entity from the **Entity Types** list or the **Attributes** list, then right-click and select **Zoom selected**.  
AutoVue zooms to the selected entity in the workspace.

## Entity Properties

The **Entity Properties** dialog displays detailed information about any selected entity in the current schematic drawing or PCB design. To open the **Entity Properties** dialog, you can double-click an entity in the workspace, or right-click an entity in the workspace, **Navigation Panel** or **Entity Browser** dialog, then select **Entity Properties** from the menu.





On the left side of the **Entity Properties** dialog, a tree control displays all the entities associated with the entity you selected. The entity you selected is the root of the tree, and all the associated entities (grouped by their type) are shown as its children.

The attributes of the entity display to the right of the tree, under **Entity Info**. In the tree, select any associated entity to display its attributes under **Entity Info**.

You can also view entity attributes in the workspace. When you hover the mouse over an entity in the workspace, a tooltip with commonly used entity information appears. You can turn these tooltips off or on from the **Configuration** dialog. See **Configuring AutoVue** for more information.

## Viewing the Properties of an Entity

The **Entity Properties** dialog displays detailed information about any selected entity in the current schematic drawing or PCB design.

- 1 Select the entity in the workspace or from the **Navigation Panel** or **Entity Browser**.
- 2 Right-click and select **Entity Properties** from the pop-up menu. The **Entity Properties** dialog appears displaying the selected entity and its associated entities under **Associations**, and its attributes under **Entity Information**.  
**Note** You can also double-click the entity in the workspace for which you want to view its entity information.
- 3 Select any associated entity in the tree to display its attributes under **Entity Information**.
- 4 To view all associated entities for any given entity in the tree, select the entity and click **Expand**.  
**Note** To view the entity properties for the previous entity, click the back  arrow. To return to the entity properties displayed before you clicked the back arrow, click the forward  arrow.
- 5 Click **OK** to close the **Entity Properties** dialog.

## Showing Net Connectivity

- 1 From the **Navigation Panel**, right-click an entity such as a pin, via or trace for which you want to display the net connectivity and select **Show Net Connectivity** from the pop-up menu.

**Note Show Net Connectivity** is disabled when more than one entity is selected.

The graphical entities belonging to the connected nets are highlighted.

## Displaying the Entity Properties of a Net

It is possible to view properties of a net via **Entity Properties**.

**Note Entity Properties** is disabled when more than one net entity is selected.

- 1 Select an entity such as a pin, via or trace from the workspace.  
The corresponding net is highlighted in the workspace.
- 2 Right-click the net and select **Entity Properties** from the pop-up menu.  
The **Entity Properties** dialog appears displaying the properties of the selected net.
- 3 Click **OK** to close the **Entity Properties** dialog.

**Note** You can also select a net from the **Navigation Panel**, right-click and select **Entity Properties**.


## Showing Net Instances

In AutoVue, you can display the instances of a net in a multi-page file.

- 1 From the **Navigation Panel**, click the **Nets** tab and select the net you want to view.  
The net is highlighted in the **Navigation Panel** and in the workspace.
- 2 Select **View > Go To Net Instances** from the AutoVue main menu or right-click the highlighted net from the **Navigation Panel** or workspace and select **Go To Net Instances**.

AutoVue highlights the instance(s) of the selected net.

If the selected net appears on multiple pages the **Go to Net Instances** dialog appears.



- 3 Select the page on which you want to view the net instance, then click **OK**. The selected page is displayed and the instance of the selected net is highlighted.

**Note** If there are no instances for the selected net the option is disabled.

## Design Hierarchy Navigation

AutoVue supports navigation through the hierarchical structure of a schematic drawing. A hierarchical block in a schematic is a symbol that refers to a child schematic. With the **Descend Hierarchy** option, you can navigate to a child schematic. With the **Ascend Hierarchy** option, you can navigate from the child schematic to the parent page.

### Navigating using Descend Hierarchy

- 1 On the parent page, select any hierarchical block in the workspace, then right-click and select **Descend Hierarchy** from the pop-up menu. AutoVue opens the page with the selected child schematic.


**Note** You can also select the hierarchical block in the **Navigation Panel** or in the **Entity Browser** dialog, then right-click and select **Descend Hierarchy**.

### Navigating using Ascend Hierarchy

- 1 On the child page of your schematic's design hierarchy, right click an entity in the workspace and select **Ascend Hierarchy** from the pop-up menu.

AutoVue returns to the parent page.

If you select an entity that has multiple parents, the **Ascend Hierarchy** dialog appears displaying the parent pages.




Select the **Parent page** you want to go to, then click **OK**.

AutoVue returns to the selected parent page.



**Note** You can also select the entity in the **Navigation Panel** or in the **Entity Browser** dialog, then right-click and select **Ascend Hierarchy**.

## Layers

When working with EDA files, AutoVue lets you view all the physical layers and associated logical layers of the EDA drawing. You can view all layer sets for that file, or create your own. You can manipulate certain layer attributes, such as visibility, color, ordering.

You can access the layer settings using the **Layers** dialog. To open the **Layers** dialog, select **View > Layers** from the AutoVue main menu. You can also click the **Layers** button  in the toolbar.

**Note:** For drawings which do not contain layers, the Layers menu option and button are disabled.

The **Layers** dialog has a Physical Layers pane and a Logical Layers pane. You can display and hide these panes using the **Expand**  and **Collapse**  buttons. The Logical Layers pane displays the layers in the order they display in the workspace, whereas the Physical Layers pane displays the layers in the order they appear in the layer stackup when manufactured.

The Physical Layers pane displays a matrix with a mapping of physical layer names to entity types. Each row in the matrix corresponds to a physical layer in

the board. Each column in the matrix lets you control the visibility of an entity type, such as pin, via, trace, and so on. The entity types that display depend on the entities available in the open file. Select a physical layer to change its visibility, printability, layer order, and color. Select or clear a physical layer's entity type to affect its visibility separately from the layer's other entities.

When you select a physical layer from the Physical Layers pane, associated logical layers are also selected in the Logical Layers pane. You can also select individual logical layers from the Logical Layers pane, or **Shift-click** or **Ctrl-click** to select multiple logical layers.

The Logical Layers pane displays a list of logical layers and the layer attribute options you can modify: visibility, printability, order, and color.

To modify these attributes for both physical and logical layers, first select the layers you want to modify, then use the settings to make the changes you want.

When you select physical or logical layers and modify settings from the Layers dialog, a message displays at the bottom of the Layers dialog to indicate your last action.


When you are satisfied with the changes, click **Apply** to make the changes in the workspace. You can also create layer sets to save your modified layer settings to reuse them later.





When you open a file in AutoVue, it displays all layer sets for that file. You can choose the layer set you need, or create your own.

- See [Changing the Order of Layers](#)***
- [Modifying Layer Visibility](#)***
- [Setting Printability for Layers](#)***
- [Changing Layer Color](#)***
- [Sorting Logical Layers](#)***
- [Creating User-Defined Layer Sets](#)***

## Changing the Order of Layers

You can change the order in which layers display in the workspace. That is, you can change the z-order of layers.


- 1 Open the **Layers** dialog by taking one of the following steps:
  - Click the **Layers** button  in the AutoVue toolbar.
  - Select **View > Layers** from the AutoVue main menu.

- 2 If necessary, click the **Expand** button  to open the **Logical Layers** pane.
- 3 Select the layer or layers that you want to move. You can:
  - Select a physical layer from the Physical Layers pane. Logical layers associated with the selected physical layer are selected. When you make changes to a selected physical layer, logical layers associated with it are also affected.
  - Select one or multiple logical layers from the Logical Layers pane. **Shift-click** or **Ctrl-click** to select multiple logical layers.
- 4 Click one of the following buttons:
  - Click the **Bring to Front** button  to move all selected layers to the front in the workspace. In the Logical Layers pane, these layers move to the top of the list.
  - Click the **Up** button  to move selected layers up one layer.
  - Click the **Down** button  to move selected layers down one layer.

**Note** You can also drag and drop selected logical layers in the Logical Layer pane.
- 5 Click **Apply** to see the changes in the workspace.  
The file now displays according to the layer scheme you arranged. Also, logical layers are renumbered in the Logical Layers pane's Order column.
- 6 To save your changes as a user-defined layer set, see **Creating User-Defined Layer Sets**.
- 7 Click **Close** to close the **Layers** dialog.

## Modifying Layer Visibility

Use the Layers dialog to hide or display specific physical and logical layers in the workspace.


- 1 Open the **Layers** dialog by taking one of the following steps:
  - Click the **Layers** button  in the AutoVue toolbar.
  - Select **View > Layers** from the AutoVue main menu.
- 2 Modify the visibility of physical layers and their entities from the **Physical Layers** pane.
- 3 Modify the visibility of individual logical layers from the **Logical Layers** pane.  
**See *Modifying Visibility for Physical Layers***

## Modifying Visibility for Logical Layers

# Modifying Visibility for Physical Layers

In the Physical Layers pane, you can show or hide the following:

- **All physical layers:** Click the **All** column header.
- **One physical layer:** Click the checkbox to the left of the layer name.


You can also select a layer and click the **Visibility** button .



- **One entity type for all physical layers:** Click the column header. For example, click the **Trace** column header to show or hide all trace entities of all physical layers.
- **One entity type for one physical layer:** Click a specific checkbox.

Click **Apply** to view the changes in the workspace. To save your changes as a user-defined layer set, see **Creating User-Defined Layer Sets**.

**Note:** Checkboxes for physical layers can have four states: Checked, unchecked, gray checked, and gray unchecked. Checkboxes that are checked and gray indicate that the entities of a physical layer are neither all visible nor all hidden. Gray checkboxes that you cannot select indicate that there is no entity of that type for that layer.

# Modifying Visibility for Logical Layers





If the **Logical Layers** pane is not open, click the **Expand** button . The Logical Layers pane lets you show or hide the following:

- **One logical layer:** Click the layer's checkbox in the **Visibility** column .
  - **Multiple logical layers:** To select more than one layer, **Shift-click** or **Ctrl-click**, then click the **Visibility** button .
- 4 Click **Apply** to view the changes in the workspace.
  - 5 To save your changes as a user-defined layer set, see **Creating User-Defined Layer Sets**.

# Setting Printability for Layers



You can select which physical or logical layers to print using the Layers dialog.



**Note** You can only print layers that are visible in the workspace. See **Modifying Layer Visibility**.

- 1 Open the **Layers** dialog by taking one of the following steps:
  - Click the **Layers** button  in the AutoVue toolbar.
  - Select **View > Layers** from the AutoVue main menu.
- 2 If necessary, click the **Expand** button  to open the **Logical Layers** pane. In the Logical Layers pane, there is a **Printability** column that lets you see which layers are set to print.
- 3 Select the layer or layers that you want to be able to print. You can:
  - Select a physical layer from the **Physical Layers** pane. Logical layers associated with the selected physical layer are also selected.
  - Select one or multiple logical layers from the Logical Layers pane. **Shift-click** or **Ctrl-click** to select multiple logical layers.
- 4 You can only print layers that are visible, so make sure the layers and entities you want print are visible in the workspace. See **Modifying Layer Visibility**.
- 5 Click the **Printability** button .  
**Note** In the Logical Layers pane, you can also click the checkboxes in the **Printability** column  for each logical layer you want to be able to print.
- 6 Click **Apply**.  
Only the layers selected in the **Printability** column can be printed.
- 7 To save your changes as a user-defined layer set, see **Creating User-Defined Layer Sets**.
- 8 Click **Close** to close the **Layers** dialog.

## Changing Layer Color



You can modify the color of any physical or logical layer from the **Layers** dialog.


- 1 Open the **Layers** dialog by taking one of the following steps:
  - Click the **Layers** button  in the AutoVue toolbar.
  - Select **View > Layers** from the AutoVue main menu.
- 2 If necessary, click the **Expand** button  to open the **Logical Layers** pane.
- 3 Select the layer or layers for which you want to change the color. You can:
  - Select a physical layer from the Physical Layers pane. Logical layers associated with the selected physical layer are also selected.

- Select one or multiple logical layers from the Logical Layers pane. **Shift-click** or **Ctrl-click** to select multiple logical layers.
- 4 Once you have selected a layer, you can modify its attributes.
  - 5 Take one of the following steps:
    - Click the **Color** button . Use this button if you want to change the color of all logical layers associated with a selected physical layer, or to change the color of many selected logical layers at the same time.
    - Double-click a **colored square** in the Color column  of the Logical Layers pane. Use the colored square to change the color of individual logical layers.
- Note** Do not click the Color column heading unless you want to sort the layers in the Logical Layers pane according to color.
- 6 In the menu that appears, select the color that you want.
  - 7 Click **OK**.  
The color of all selected layers changes in the Color column.
  - 8 Click **Apply** to save the changes.  
The display updates in the workspace based on the changes you made to the layer color.
  - 9 To save your changes as a user-defined layer set, see **Creating User-Defined Layer Sets**.
  - 10 Click **Close** to close the **Layers** dialog.

## Sorting Logical Layers

You can sort the list of logical layers in the Logical Layers pane by name, visibility, printability, color, or physical layer.

- 1 Open the **Layers** dialog by taking one of the following steps:
  - Click the **Layers** button  in the AutoVue toolbar.
  - Select **View > Layers** from the AutoVue main menu.
- 2 If the **Logical Layers** pane is closed, click the **Expand** button  to open it.
- 3 Click the column header of an attribute. Layers are sorted according to the attribute header you click.

For example, clicking the Color column header  sorts all logical layers in the pane according to their color.



**Note:** To restore the original sort order, click the **Order** column header.

# Layer Sets

A layer set is comprised of all the physical and logical layers in the drawing. Layer sets differ in the attributes of the different layer(s): z-order, visibility, printability, color, and so on. Define your own layer sets to control which layers you can view and print.

## Viewing Layer Sets

AutoVue lists top, bottom, and default layer sets, as well as any layer set that is stored in the file. You can choose to display any layer set you need. You can also create user-defined layer sets and display them later. To view a layer set, take the following steps:

- 1 Take one of the following steps:
  - Click the **Layers** button  in the AutoVue toolbar. In the Layers dialog that appears, select a layer set from the **Layer Set** drop-down list, then click **Apply**.
  - In the AutoVue main menu, select **View > Layer Sets > x**, where **x** is the layer set you want to see.
  - In the AutoVue toolbar, select a layer set from the drop-down list beside the Layers button .

The selected layer set displays in the workspace.

- 2 To restore the default layer set, select **View > Layer Sets > (Default)** or **(Default)** from the toolbar or in the **Layers** dialog.

**See *Creating User-Defined Layer Sets***


***Deleting User-Defined Layer Sets***


***Saving User-Defined Layer Sets with Markups***

## Creating User-Defined Layer Sets

You can define a layer set and save it for the duration of the session. The layer set you defined is added to the **Layer Set** list in the **Layers** dialog and to the **Layers** drop-down list on the AutoVue toolbar.

By default the **Top**, **Bottom** and **Default** layer sets and any other layer sets belonging to the file are listed in the **Layer Set** drop-down list.

- 1 Open the **Layers** dialog by taking one of the following steps:
  - Click the **Layers** button  in the AutoVue toolbar.


- Select **View > Layers** from the AutoVue main menu.
- 2 Click **Add**.  
The **Add Layer Set** dialog appears.
  - 3 Enter the **Layer Set Name**.
  - 4 Click **OK**.  
The new layer set appears in the **Layer Set** drop-down list.
  - 5 To modify the attributes of the new layer set, select one or more layers and change the **Visibility**, **Printability**, **Order** or **Color**.  
**See *Changing the Order of Layers***  
***Modifying Layer Visibility***  
***Setting Printability for Layers***  
***Changing Layer Color***
  - 6 Click **Apply** to save the changes and to display the new layer set in the workspace.
  - 7 To define more layer sets, repeat steps 2 to 6.
  - 8 Click **Close** to close the **Layers** dialog.  
The new layer set appears in the drop-down list beside the Layers button  on the AutoVue toolbar and is also displayed in the workspace.

**See *Viewing Layer Sets***

***Deleting User-Defined Layer Sets***

***Saving User-Defined Layer Sets with Markups***


## Deleting User-Defined Layer Sets

- 1 Open the **Layers** dialog by taking one of the following steps:
  - Click the **Layers** button  in the AutoVue toolbar.
  - Select **View > Layers** from the AutoVue main menu.
- 2 From the **Layer Set** drop-down list, select the user-defined layer set you want to delete.  
**Note:** You can only delete user-defined layer sets.
- 3 Click **Delete**.  
**Note:** The layer settings of the deleted layer set remain displayed on the screen until you select another layer set.
- 4 Click **Apply** to save the changes.
- 5 Click **Close** to close the **Layers** dialog.  
**See *Creating User-Defined Layer Sets***  
***Viewing Layer Sets***

## *Saving User-Defined Layer Sets with Markups*

# Saving User-Defined Layer Sets with Markups

In AutoVue, you can save custom layer sets using markup files.

- 1 Create custom layer sets.  
**See *Creating User-Defined Layer Sets***
- 2 Enter **Markup** mode by taking one of the following steps:
  - Click the Markup button  in the toolbar.
  - Select **File > Markup** from the AutoVue main menu.
- 3 Create any markup entities that you need.
- 4 Select **File > Save As** from the AutoVue main menu and use the dialog that appears to save the markup file.

The Layer sets you created are saved with the Markup file. When you reopen the file during a different session, you can view the Layer sets when you open the Markup file.

**See *Creating User-Defined Layer Sets***

***Viewing Layer Sets***


***Deleting User-Defined Layer Sets***

***Saving User-Defined Layer Sets with Markups***

***Markups***

## 3D View

For some ECAD formats, AutoVue supports 3D views of PCB boards.

- 1 In the **Navigation Panel**, click the **Bookmarks** tab.
- 2 Select **3D View** from the **Bookmark Tree**.  
The 3D view of the PCB board is displayed in the workspace.  
**Note** You can also display a 3D view by selecting **View > Page > Next Page** or by clicking the Next Page button  on the toolbar.

# Cross Probing

Cross probing is the ability to select elements in the schematic and have them mapped to the corresponding components in the layout drawings and vice versa. You can also cross probe between the 2D and 3D view of the same file.

**See *Cross Probing Between Two or More EDA Files Showing the Net Connectivity when Cross Probing Cross Probing Between 2D and 3D Views of the Same File Zooming when Cross Probing***

## Cross Probing Between Two or More EDA Files

The **Cross Probe** option lets you select entities in the schematic drawing or the PCB and AutoVue highlights what you selected in all the open files.

- 1 Open a file you want to cross probe.
- 2 Select **Analysis > Cross Probe** from the main menu.  
The **Cross Probe** dialog appears.

**Note:** You can also click the **Cross Probe** button  in the toolbar.

- 3 Click **Add File**.
- 4 In the **Open** dialog that appears, enter the **File name** or browse to locate the file you want to cross probe, then click **Open**.
- 5 Repeat steps 3 and 4 for each additional file that you want to open.
- 6 In the **Cross Probe** dialog, click **OK**.



Each file you selected appears in a new window. A dialog appears for each new window which lets you change the view or page for each file.


Each dialog is set to **Automatic** by default. When the **Automatic** option is selected for each dialog, you see different behavior depending on the files you cross probe, as follows:

- If you cross probe a schematic and PCB, one window automatically displays a 2D PCB and the other window displays a schematic. The same is true if either file contains a PCB and a schematic. For example, if files A and B contain both a schematic and a PCB and they are cross probed, one of the files displays the schematic page and the other displays the 2D PCB.
- If you cross probe two PCBs, one window automatically displays a 2D PCB and the other window displays a 3D PCB.
- If you cross probe two schematics, both are set to schematic.

- 7 To change the view of a file in a window, take the following steps:
  - a. Clear the **Automatic** option in the dialog for the window you want to change.
  - b. Select **Schematic**, **PCB**, or **PCB 3D View** from the **Type** menu. These options are available in the Type menu only when the views are present in the file.

The view of the file changes in the window.


- 8 To switch between multiple occurrences of a selected component, take the following steps:
  - a. From the **Navigation** panel, select a component in one file that has multiple component occurrences in the other file.
  - b. From the dialog of the file with multiple component occurrences, select one of the components from the **Occurrence** menu or click the **Next** button  or **Previous** buttons  to switch between component occurrences.



- 9 Select any entity in the schematic drawing.  
The same entity is highlighted in the PCB design(s).

## Cross Probing Between 2D and 3D Views of the Same File

- 1 Select **Analysis > Cross Probe** from the AutoVue main menu. The **Cross Probe** dialog appears.
 

**Note:** You can also click the Cross Probe button  in the toolbar.
- 2 Click **Add File**.
- 3 In the **Open** dialog that appears, select the same file, then click **Open**.
- 4 In the **Cross Probe** dialog, click **OK**.  
The file appears in a new AutoVue window. The views that display in each window depend on the contents of file you are cross probing.

If the file does not contain a schematic, one window shows the 2-dimensional view of the PCB and the other shows the 3-dimensional view of the PCB.

If the file contains a schematic as well as a PCB, the schematic view displays in one window and the 2D PCB view displays in the other window. In this case, take the following steps to see the 2D and 3D views of the PCB:

- a. In the window's dialog, clear the **Automatic** option.
  - b. Select a different view from the **Type** menu. For example, you can switch between **Schematic** and **PCB 3D View**.
- 5 Select an entity in the 3D view.  
The same entity is highlighted in the 2D view of this file.

**Note:** You can select entities in the 2D view or 3D view of the file. The selected entities are highlighted in both open views of this file.

## Showing the Net Connectivity when Cross Probing

- 1 Select an entity or entities in any open file.
- 2 Right-click and select **Show Net Connectivity** from the pop-up menu.  
The net connectivity for the entity or entities that you selected are highlighted in all the files.

## Zooming when Cross Probing

When you are cross probing files, you can zoom in on the entities you select. Zoom in on a selected entity or entities:

- when cross probing between a schematic drawing and a PCB design.
- when cross probing between the 2D and 3D views of the same file.

**To zoom in on a selected entity:**

- 1 Select an entity or entities in either one of the open files or views.  
**Note** If you are cross probing between a schematic drawing or a PCB design, you can select entities in either file. You can also select entities in any open file when cross probing the 2D view and 3D view of the same file.
- 2 Right-click and select **Zoom Selected** from the pop-up menu.  
AutoVue zooms to the same entities in all the open files.  
**See *Configuring Zoom Behavior when Cross Probing***

# Comparing a PCB with Artwork

In AutoVue, you can visually compare PCB designs or schematic drawings. In **Compare** mode for EDA files, EDA options such as **Select Entity**, **Entity Browser** and **Entity Type Filter** are available.

For more information on how to compare files, *see **Comparing 2D Files***.

To compare a PCB with artwork:

- 1 Open the PCB file that you want to compare with the artwork.
- 2 Select **Analysis > Compare** from the AutoVue main menu.  
The **Open** dialog appears.
- 3 Enter the **File name** or browse to locate the artwork file you want to compare with the PCB file.
- 4 Click **Open**.

The **PCB-Artwork Comparison** dialog is displayed.

- 5 From the drop-down list, select the PCB physical layer that represents the artwork. For example: **TOP**, **BOTTOM** or **POWER**.
- 6 Click **OK**.

AutoVue displays three windows, the first displaying the original PCB drawing, the second displaying the Artwork drawing and the third the **Comparison Result** window.

- 7 To exit Compare mode, select **File > Exit Compare Mode** from the AutoVue main menu.

The original file appears in the AutoVue workspace.

**Note** You can right-click in any window and select **Exit Compare Mode**.

**See Also** *Specifying Scale and Offset for a Compare File*

# Generating a Bill of Material

For EDA files, you can obtain a list of the components and parts required for manufacturing the item featured in the schematic drawing or PCB design.


The **Bill of Material** (BOM) report produces a count of the unique components or parts needed for manufacturing. It lists the quantity required, component name, reference designators, value (for resistors and capacitors), size and descriptions. When determining a component's uniqueness, the count considers only the attributes chosen for inclusion in the report output. It includes only those attributes that provide the most accurate, unique component quantities.

To generate a Bill of Material:

- 1 Select **Analysis > BOM** from the AutoVue main menu.

**Note** You can also click the **BOM** button  in the toolbar.

If you are generating a BOM for a schematic with multiple pages, a dialog appears.



Select if you want to generate a **BOM** for the **Current page** or the **Entire design**, then click **OK**.

A dialog appears listing the attributes of the file.

- 2 Select the attributes that you want to appear in the report, then click **Generate**.

The **Bill of Material** dialog appears listing the **Count** for each component or part possessing the attributes you selected. There are also columns displaying the values of the attributes you selected.

**Note** To sort a column by alphanumerical or alphabetical order, click on the column heading.

- 3 To save the Bill of Material, click **Export**. The **Save As** dialog appears. Specify the directory where you want to store the file, the file name and extension, then click **Save**.

**Note** You can specify either **xml** (Product Data Exchange) or **csv** (Common Separated Values) for the extension.

AutoVue automatically saves the results in a file with the format you specified.

- 4 Click **Close** to close the **Bill of Material** dialog.

## Design Verification

Design verifications are operations that check the electrical design of a PCB against a set of rules defining physical and electrical design limitations.

Performing these checks will prevent short circuits and process errors. The types of design rules are:

- **Clearances** - the minimum spacing (air gaps) allowed between two sets of entities in the design. These sets can belong to the same type of entity or to different types.
- **Electrical** - targets certain properties of the nets
- **Manufacturing** - targets the physical properties of a particular entity.

## Design Rule Checks


For design rule checks that have values, you can change the unit of measure and change the value of each check. The available design rule checks are:

Type	#	Design Rule Check	Description
Clearance	1	Min.Clearance (Pad > Pad)	Specify the minimum pad to pad clearance on the same physical layer. <b>Note</b> Only the pad outline is considered.
	2	Min.Clearance (Pad > Trace)	Specify the minimum pad to trace clearance and pads on the same physical layer. <b>Note</b> Only the pad outline is considered. Does not take into account traces connected to a pin (pad) on the same net.
	3	Min.Clearance (Trace > Trace)	Specify the minimum trace to trace clearance on the same physical layer. <b>Note</b> Does not take into account directly connected traces.
	4	Min. Clearance (Comp > Comp)	Specify the minimum component to component clearance on the same physical layer (component top side or component bottom side). <b>Note</b> Only the logical layer that defines the actual outline of the component is considered. <b>Note</b> A component entity is usually made up of geometrics on different logical layers (silkscreen, keepout, etc.), but only the logical layer that defines the actual outline of the component is considered.

Type	#	Design Rule Check	Description
Manufacturing	5	Min. Annular Ring	Specify the distance between the pad outline and the outline of its drill hole on all physical layers. <b>Note</b> The two outlines (geometries) are part of the pin (pad) entity but on different logical layers.
	6	Min. Pad Diameter	Specify the minimum diameter of a pad. <b>Note</b> Only applicable to rounded pads.
	8	Acute Angle (in deg.)	Specify the minimum acute angle between connected traces on the same physical layer. <b>Note</b> Only two traces belonging to the same net should be considered.
	9	Min. Drill Hole Size	Specify the minimum diameter of the drill hole size allowed. <b>Note</b> Only applicable to rounded pads.
	10	Max. Drill Hole Size	Specify the maximum diameter of the drill hole size allowed. <b>Note</b> Only applicable to rounded pads.
Electrical	7	Max. Via Count	Specify the maximum via count allowed for a net.
	11	Min. Route Width	Specify the minimum route (trace) width allowed in the design.
	12	Max. Route Width	Specify the maximum route (trace) width allowed in the design.
	13	Min. Route Length	Specify the minimum route (trace) length allowed in the design.
	14	Max. Route Length	Specify the maximum route (trace) length allowed in the design.
	15	Empty Nets	Select this checkbox if you want to check for any nets that are not connected to any pin, via, trace and power/ground plane.

Type	#	Design Rule Check	Description
	16	Un-routed Traces	Select this checkbox if you want to check for any trace segment that is not connected to another trace segment, pin, via on either end.
	17	Single Connection	Select this checkbox if you want to check for a net connected to only one pin. <b>Exception:</b> power and ground nets.
	18	Short Circuit	Select this checkbox if you want to check for intersections (on the same layer) of traces that belong to different nets. <b>Note</b> Trace entities will be divided into $n$ sets where $n$ is the number of nets in the design.
	19	Unconnected Pin	Select this checkbox if you want to check for any pin (pad) that is not graphically intersected with any traces on the same physical layer.

## Verifying a Design

- 1 Select **Analysis > Verify Design** from the AutoVue main menu. A design dialog appears.  
**Note** You can also click the Verify Design button  on the AutoVue toolbar
- 2 To enable a **Design Rule**, select the checkbox beside the **Design Rule**. To disable a **Design Rule**, clear the checkmark.  
**Note** You can sort the **Design Rules** by **Enabled**, **Description** or **Value** by clicking the column heading.
- 3 To add a value to the selected **Design Rules**, double-click in the value box and enter a value.  
**Note** The **Design Rule** must be enabled to be able to add a value.
- 4 In the **Maximum Violation** text box, enter the maximum number of results you want to display in the **Results** text box.
- 5 From the **Distance Units** drop down list, select the unit you want to use as the unit of measure.

- 6 Click **Verify**.  
**Verify** button changes to **Stop**.  
**Note** To stop the Design Verification process at any point, click **Stop**. When the process is complete, the total number of errors found during the Design Verification process, up to the maximum number specified in the **Maximum Violation** text box, appear in the **Results** list.
- 7 To view the description of a violation result, select the violation from the **Results** list.  
The description appears in the **Description** text box. The description includes information such as the type of violation, the location where it occurs (x- and y-coordinates), the component or entity it affects and the actual value measured.  
**Note** When you select a violation result, AutoVue zooms to the entity or set of entities that were affected and highlights them on the drawing.
- 8 Continue to select violation **Results** to view its description.  
**Note** Click **Reset** to restart a new check.
- 9 Click **Close** to close the dialog.

## Exporting the Design Verification Results

You can export the Design Verification results into a text file.

- 1 Click **Export** in the design dialog.  
An export dialog appears.
- 2 Navigate and select the directory that you want to export the results to.
- 3 Enter a **File name**.  
Click **Save**.  
AutoVue saves the Design Verification results in a **txt** (text) or **csv** (Common Separated Values) file listing each violation result and its description.
- 4 Click **Close** to close the design dialog.


## Searching Using Entity Browser

You can search for an entity in a schematic drawing or a PCB design using the **Entity Browser**. To filter entities, apply attribute or entity type filters as search criteria. You can select entities from the results list to highlight them in the workspace and the **Navigation Panel**. You can also export the search results to a .txt file.


**Note** If the selected entity is small, a flash box appears indicating the location of the highlighted entity in the workspace.

To open the Entity Browser, select **Analysis > Entity Browser** from the AutoVue main menu.

If your schematic has multiple pages, a **Defining Scope** dialog appears.



Select **Current Schematic Page** to browse through only one page. Select **Entire Schematic Design** to browse through all schematic pages.




## Performing an Entity Type-based Search

- 1 Select **Analysis > Entity Browser** from the AutoVue menu. The **Entity Browser** dialog appears.

**Note** You can also click the Entity Browser button  on the AutoVue toolbar.

- 2 Click the **Entity Types** tab.
- 3 From the **Entity Types** drop-down list, select an entity type.  
A list of attributes for the selected entity type appear.  
**Note** To sort the list by attribute, click the attribute column heading that you want to sort by.
- 4 If you want to search by attribute, select an attribute from the **Attribute** drop-down list.  
If you want to search by value, select a value from the **Value** drop-down list.
- 5 Click **Add Filter**.  
The **Attribute** and its **Value** appear in the list.
- 6 Repeat steps 4 and 5 until you have all the filters you want.
- 7 Click **Apply Filter(s)**.  
A list of entities matching the search criteria appear showing the column headers for the entity's available attributes.  
**Note** To remove a filter, select the line in the list containing the **Attribute** and **Value** you do not want to use as a filter, then click **Remove Filter**.
- 8 To save the results, click **Export Result**.  
The **Save As** dialog appears.
- 9 Browse to locate the directory where you want to store the file and enter a **File name**.
- 10 Click **Save**.  
AutoVue saves the results in a **csv** (Comma Separated Values) file.
- 11 To view the properties of an entity, select the entity from the **Types** list or the **Attributes** list, then right-click and select **Entity Properties**.  
The **Entities Properties** dialog appears displaying the properties for the selected entity.
- 12 To show the net connectivity, click the **Attributes** tab, select the entity from the list, then right-click and select **Show Net Connectivity**.  
The net connectivity for the selected entity is highlighted.
- 13 Click **Close** to close the **Entity Browser** dialog.

## Performing an Attribute-based Search

- 1 Select **Analysis > Entity Browser** from the AutoVue menu.  
The **Entity Browser** dialog appears.  
  
**Note** You can also click the Entity Browser button  on the AutoVue toolbar.
- 2 Click the **Attributes** tab.
- 3 From the **Attributes** drop-down list, select an attribute.

The **Owner**, **Type** and **Value** of the selected attribute appear in the list.

**Note** To sort the list by **Owner**, **Type** or **Value**, click the column heading that you want to sort by.

- 4 If you want to search by owner, select an owner from the **Owner filter** drop-down list.

If you want to search by value, select a value from the **Value Filter** drop-down list.

**Note** You can also enter an **Owner filter** or **Value Filter** in the text box.

- 5 Click **Apply Filter(s)**.

A list of entities matching the search criteria appear displaying the **Owner**, **Type** and **Value** columns.

**Note** Select an item in the result list and right-click to access options like **Zoom Selected** and **Entity Properties**.

- 6 To save the results, click **Export Result**.

The **Save As** dialog appears.

- 7 Specify the file name and the directory where you want to store the file, then click **Save**.




AutoVue saves the results in a **csv** (Comma Separated Values) file.



- 8 Click **Close** to close the **Entity Browser** dialog.

## Measuring in EDA Files

In EDA files, you can take measurements of distances, areas, arcs, and so on. When measuring, you have the option to “snap” to geometrical or electrical points on the drawing.

Click **Analysis > Measure** to access the Measurement options. You can also click the measurement buttons in the toolbar, as shown in the following table:








Button	Name	Description
	Angle	Measure the angle between selected points.
	Arc	Measure an arc entity.
	Area	Measure a selected area.

Button	Name	Description
	Distance	Measure the distance between two points.
	Minimum Distance	Measure the minimum distance between entities.

## EDA Snapping Modes

The Snapping Modes allow you to click to precise geometrical or electrical points. For example, when you select **Snap to pin**, move the cursor over the pin you want to select until the pin is highlighted, then click. Highlight and click a second pin to measure the distance between them.


The Snapping Modes allow you to snap to the mid, center and end-points of an entity, as well as a pin, via, and symbol:

Button	Snap to	Description
	End-point	Geometric snap mode where a snap box appears when moving the cursor near the component's end point.
	Mid-point	Geometric snap mode where a snap box appears when moving the cursor near the halfway point of a linear component.
	Center-point	Geometric snap mode where a snap box appears when moving the cursor near the center of an elliptical component.
	Pin	Electrical snap mode where a snap box appears when the cursor touches a pin.
	Via origin	Electrical snap mode where a snap box appears when the cursor touches a via.
	Symbol origin	Electrical snap mode where a snap box appears when the cursor touches the entire component.
	Free snap	Allows snapping at any point on the drawing.

## Measuring Distance

Use the **Distance** option to measure the distance between two specific points.

- 1 Select **Analysis > Measure** from the AutoVue main menu.  
The **Measurement** dialog appears.

**Note** You can also click the Distance button  on the AutoVue toolbar.

- 2 Click the **Distance** tab.
- 3 Select the **Snapping Modes** that you want to use for measuring.  
To select all **Snapping Modes** click **All On**. To clear all **Snapping Modes** click **All Off**.

**See** *EDA Snapping Modes*

- 4 From the **Measured Distance Units** drop-down list, select the unit in which you want to measure the distance.

**Note** If you want to measure the distance along a path, select **Cumulative**.

- 5 Click a point on the drawing to define the starting point.
- 6 Click another point on the drawing to define the end point.

**Note** If you selected **Cumulative**, continue clicking points along the path that you want to measure.

- 7 Right-click to complete the measurement.

The points are joined by a line. The measured distance, Delta-X, Delta-Y and the “Manhattan Distance” appear in the **Measurement** dialog.

**Note** Click **Reset** to take another measurement.

- 8 Click **Close** to close the **Measurement** dialog.

## Calibrating Distance

- 1 Measure the distance between two points or measure cumulative distance.

**See** *Measuring Distance*

- 2 In the **Measurement** dialog, click **Calibrate**.
- 3 The **Distance Calibration** dialog appears displaying the measured distance.
- 4 From the **Measured Dist.** drop-down list, select the unit to which you want to calibrate the distance.
- 5 Click **Calibrate to** and enter a value if you want to calibrate the distance to a value.  
Click **Set Factor** and enter a value if you want to calibrate the distance by a factor.
- 6 Click **OK**.


The calibration results appear in the **Measurement** dialog.


- 7 Click **Close** to close the **Measurement** dialog.

## Measuring Minimum Distance

Use the **Minimum Distance** option to measure the minimum distance between entities. The available entities for snapping are nets, pins, vias and traces.

- 1 Select **Analysis > Measure** from the AutoVue main menu.  
The **Measurement** dialog appears.

**Note** You can also click the Minimum Distance button  on the AutoVue toolbar.


- 2 Click the **Min.Distance** tab.
- 3 Select  **First Set** to select the entities that you want to measure from.
- 4 Select the **Snapping Modes** that you want to select as the entities for the measurement.

**See EDA Snapping Modes**

**Note** If you select **Net**, you cannot select any other type of entity.


- 5 Click the first set of entities on the drawing.  
The entities are highlighted.

**Note** To clear the last set of entities you selected, click **Clear Set**.

- 6 Select  **Second Set** to select the entities that you want to measure to.
- 7 Click the second set of entities on the drawing.  
The entities are highlighted in a different color.
- 8 From the **Measured Min Distance** drop-down list, select the unit in which you want to measure the distance.
- 9 Click **Zoom to Result**, if you want to zoom in to the measurement on the drawing.
- 10 Click **Compute**.  
The minimum distance from the first set of entities to the second set is highlighted by a line. The minimum measured distance, Delta-X, Delta-Y and the Manhattan Distance appear in the **Measure Minimum Distance** dialog.
- 11 Click **Close** to close the **Measurement** dialog.


## Measuring Area

Use the **Area** option to measure the area and perimeter of a region.

- 1 Select **Analysis > Measure** from the AutoVue main menu. The **Measurement** dialog appears.  
**Note** You can also click the Area button  on the AutoVue toolbar.
- 2 Click the **Area** tab.
- 3 Select **Between Points** if you want to measure the area between points on a drawing. **Snapping Modes** are enabled.  
Select the **Snapping Modes** that you want to use for measuring.  
To select all **Snapping Modes** click **All On**. To clear all **Snapping Modes** click **All Off**.  
**See EDA Snapping Modes**
- 4 Select **Shape** if you want to measure the area of a predefined shape on the drawing. **Snapping Modes** are disabled.
- 5 From the **Measured Area Units** drop-down list, select the unit in which you want to measure the area.
- 6 From the **Perimeter Units** drop-down list, select the unit in which you want to measure the perimeter.
- 7 To cumulate a **Net Area Result** of different areas, select **Add** in the **Measurement** dialog.  
To subtract an area from the **Net Area Result**, select **Subtract**.  
Select **Clear** to clear the **Net Area Result**.
- 8 If you selected **Between Points**, click points on the drawing to define the area.  
Each point is joined by a line. The area and perimeter measurements appear in the **Measurement** dialog.
- 9 If you selected **Shape**, click the edge of the predefined shape that you want to measure.  
The shape is highlighted. The area and perimeter measurements appear in the **Measurement** dialog.  
**Note** Click **Reset** to take another measurement.
- 10 Click **Close** to close the **Measurement** dialog.

## Measuring an Angle


Use the **Angle** option to measure the angle between points on a drawing.

- 1 Select **Analysis > Measure** from the AutoVue main menu.  
The **Measurement** dialog appears.  
**Note** You can also click the Angle button  on the AutoVue toolbar.
- 2 Click the **Angle** tab.

- 3 Select **From 3 Points** if you want to measure the angle between three points. **Snapping Modes** are enabled.  
Select the **Snapping Modes** that you want to use for measuring.  
To select all **Snapping Modes** click **All On**. To clear all **Snapping Modes** click **All Off**.  
**See EDA Snapping Modes**
- 4 Select **Between 2 lines** if you want to measure the angle between two lines. **Snapping Modes** are disabled.
- 5 From the **Measured Angle Units** drop-down list, select the unit in which you want to measure the angle.
- 6 If you selected **From 3 Points**, click three points to define the angle.
- 7 If you selected **Between 2 Lines**, click two lines to define the angle.  
Angle arms appear with an arc connecting them. The angle measurement appears in the **Measurement** dialog.  
**Note** Click **Reset** to take another measurement.
- 8 Click **Close** to close the **Measurement** dialog.

## Measuring an Arc

Use the **Arc** option to define or select an arc in the drawing and measure its radius, center and diameter.

- 1 Select **Analysis > Measure** from the AutoVue main menu.  
The **Measurement** dialog appears.  
**Note** You can also click the Arc button  on the AutoVue toolbar.
- 2 Click the **Arc** tab.
- 3 Select **From 3 Points** if you want to measure the arc between three points. **Snapping Modes** are enabled.  
Select the **Snapping Modes** that you want to use for measuring.  
To select all **Snapping Modes** click **All On**. To clear all **Snapping Modes** click **All Off**.  
**See EDA Snapping Modes**
- 4 Select **Arc Entity** if you want to measure a predefined arc. **Snapping Modes** are disabled.
- 5 From the **Arc Info** drop-down list, select the unit in which you want to measure the distance of the arc.
- 6 From the **Measured Angle Units** drop-down list, select the unit in which you want to measure the angle.
- 7 If you selected **From 3 Points**, click three points to define the arc.

The points are joined by an arc. The measurements for center point coordinates, radius, diameter, arc length, start and end of angle and sweep appear in the **Measurement** dialog.

- 8 If you selected **Arc Entity**, click the edge of the arc that you want to measure.

The arc is highlighted. The measurements for center point coordinates, radius, diameter, arc length, start and end of angle and sweep appear in the **Measurement** dialog.

**Note** Click **Reset** to take another measurement.

- 9 Click **Close** to close the **Measurement** dialog.

## Calibrating an Arc

- 1 Measure an arc in the drawing.

**See** *Measuring an Arc*

- 2 In the **Measurement** dialog, click **Calibrate**.
- 3 The **Radius Calibration** dialog appears displaying the measured distance.
- 4 From the **Measured Rad.** drop-down list, select the unit to which you want to calibrate the distance.
- 5 Click **Calibrate to** and enter a value if you want to calibrate to a value. Click **Set Factor** and enter a value if you want to calibrate by a factor.
- 6 Click **OK**.  
The calibration results appear in the **Measurement** dialog.
- 7 Click **Close** to close the **Measurement** dialog.

# EDA Terms and Definitions

## Annular ring

A circular strip of conductive material that remains after a hole has been drilled through the pad of a printed circuit board.

## Anti-copper

An area within a fill zone in which copper cannot be placed.

## Aperture

An opening, similar to the aperture of a camera, that is used for photo-plotting. Apertures are available in various sizes and shapes.

## Aperture list

A text file containing the dimensions for each of the apertures used to photo-plot PCB artwork.

## Clusters

Components that are grouped according to their interrelationships and placed in close proximity on the board. This keeps the connections on the PCB short so that the board is easier to work with.

## Component

An element or a part of a PCB.

## Component density

The quantity of components on a unit area of a PCB.

## Component hole

A hole in the printed circuit board that corresponds to a pin or wire of a component. This hole serves the dual function of attaching the component to the board and establishing the electrical connection between the pin or wire and the remainder of the board circuitry.

## Component library

A computer data file that contains the footprint patterns for a number of components.

## Component side

The uppermost or top layer of a board on which most components are placed.

## Component silkscreen

The silkscreen markings of the printed circuit board that appear on the component side. The silkscreen is applied over the solder mask.

## Component solder mask

The colored, usually translucent, coating applied to the board over the etched copper. It protects the selected areas from the soldering process.

## Connection

An unrouted, partially routed, or completely routed path between two pads. In a net with  $n$  pads, there are exactly  $n-1$  connections.

## Copper pour

A method by which a copper zone is filled with a specified pattern, with objects that cross the zone or lie within the zone being avoided.

## Copper zone

An area on a board designed to be covered by a layer of copper when manufactured. Also known as a "metal zone."

## Cross hatching

The breaking up of large conductive areas by the use of a pattern of lines and spaces in the conductive material.

## Datum

A specific location (a point) that serves as a reference to locate a PCB pattern or layer for manufacture.

## Density

On a PCB, the degree to which components are packed on the board. Generally, the density is given as the number of square inches per equivalent, i.e., a lower number indicates a more dense board.

## Discrete components

Components with three or fewer electrical connections (for example, resistors or capacitors).

## Electrical check

The process of checking the PCB to ensure that the connections they are on match those specified in the net list.

## Fill zone

A zone that defines an area to be filled with copper.

## Fine pitch

A class of surface-mount components that is characterized by pins measuring 0.025 inches or less from pad center to pad center.

## Footprint

The physical description of a component. It consists of three elements: **padstacks**, representing the pads of the component; **obstacles**, representing among other things, the physical outline of the component, silkscreens, keepouts/keepins, and assembly drawing data; and **text** documenting the footprint information (for example, the component name). You may want each project to have its own footprint library containing all the footprints used in that project.

## Ground plane

A large area on the PCB, usually an entire layer, that provides a common ground connection for all component ground pins and other ground connections.

## Heatsink

A mechanical device made of a high thermal conductivity material that dissipates heat generated by a component or assembly.

## Heuristics

A method of routing that consists of repeated attempts to apply very simple routing patterns to unrouted connections in order to complete the routing quickly and cleanly. Typically, heuristics are used for memory and short point-to-point routing.

## Hole

The area where board material must be removed by drilling or milling.

## Isolation

The clearance around a pad, track, zone, or via that defines the nearest approach allowed by conductors of another signal set.

## Jumper wire

A discrete electrical component or wire used to make electrical connections between points that have no copper etch due to board density or some other factor.

## Keepout

An area fill within which no routing is allowed.

## Land

The copper pad needed for a surface mount pin.

## Layer

One in a series of planes in a PCB design on which tracks are arranged to connect components. Vias connect tracks and zones between layers.

## Manual routing

Individual connections, in the form of traces, vertices, arcs, etc., which are entered manually into the PCB design.

## Mounting hole

A hole used for the mechanical support of a PCB or for the mechanical attachment of components to a PCB.

## Multi-layer board

A PCB that has multiple layers, separated by dielectric material, with connectivity between layers established by vias or through-holes. This term usually refers to a board with more than two layers.

## Net

A logical construct (circuit) that originates in a schematic and is transferred to a board to describe required electrical connections. The connections may be completed by using vias, tracks, or zones.

## Net list

List of names of symbols or parts and their connection points which are logically connected in each net of a circuit. A net list can be extracted electronically on a computer from a properly prepared schematic.

## Obstacle

An outline representing an object on the board. It must be taken into account during routing, placement, or copper pour.

## Pad

On a PCB, a copper shape on one or more layers (there may be a hole and an isolation surrounding the copper) used for connecting a component pin to the PCB. The pad indicates where pins of a component are placed.

## Padstack

A numbered list of pad descriptions. Each description contains a pad definition, including layer, style, drill diameter, size, offset, and solder mask guard width.

---

## PCB - Printed Circuit Board

A PCB is a board made up of components affixed to a common surface and connected by copper tracks.

### Pin

The portion of a component to which an electrical connection can be made.

### Ratsnest

A number of unrouted straight-line connections between two or more pads that represent the electrical connections in the netlist. The ratsnest serves as a reminder that the pads must be connected, and that, currently, there is no track on the board to make that connection.

### Reference designator

A character string denoting the type of component and a number that is specific to that component.

### Routing

Placing conductive interconnects between components on a PCB layout. The process of turning nets into tracks.

### Schematic

A graphical description of an electrical circuit.

### Segment

The partial track that exists between two adjacent vertices or between a vertex and a pin. Sometimes the track between two pins is also called a segment, although connection is usually the more appropriate term here.

### Signal

An electrical impulse of a predetermined voltage, current, polarity, and pulse width.

## **Silkscreen**

Text or outlines (in ink) on the solder mask, on the top, and sometimes on the bottom of board modules. A silkscreen is used for component and identification placement on a PCB and usually includes component outlines, reference designators, polarity indicators, pin one markings, part numbers, the company name, and copyright info.

## **SMT - Surface Mount Technology**

PCB technology whereby the leads on the chips and components are soldered onto the surface of the board rather than inserted into it. The use of SMT results in smaller and faster printed circuit boards.

## **Solder mask**

A negative plot of pads with a guard band around the pads. Also, a lacquer applied to prevent solder from adhering to unwanted areas on the PCB.

## **Solder paste**

A pattern that serves as a template for solder paste application when the board is manufactured.

## **Solder side**

The PCB surface opposite the one on which most components are mounted (component side). Also, the bottom layer of the board.

## **Test point**

A special point of access to an electrical circuit that is used for electrical testing purposes.

## **Through-hole via**

A via that connects the surface layers on a PCB.

## Trace (Track)

The copper trails (electrical connection between two or more points) on the PCB and the onscreen representation of that copper.

## Venting patterns

Patterns etched in the board that allow gases formed during fabrication to escape.

## Vertex

A logical point at which a track is ended and restarted. A vertex is located at each change of direction on the track.

## Via (feed-through hole)

A hole connecting layers of a PCB. A **through-hole via** connects the surface layers of a board. On multilayer boards, a via not reaching a surface layer on one side is called a **blind via**, and a via not reaching a surface layer on either side, thus being externally invisible, is called a **buried via**.

## Viastack

A numbered list of via descriptions. Each description contains a via definition, including layer, style, drill diameter, size, offset, and solder mask guard width.

## Via stringer

The copper etch that exists between a SMT pad and a corresponding fanout via.

## Zero-length connection

An unrouted connection between layers where the end points in the connection have the same X- and Y- coordinates.

## Zone

An area on a PCB layer designated as copper or anti-copper. Copper zones may have net names, while anti-copper zones may not.

# Working with 3D Files

From AutoVue's 3D mode, you can select model parts to transform independent of the rest of the model. You can import 3D models into the current window and export files to other formats. The Global Axes inform you of where the X, Y and Z axes are positioned throughout all the operations you perform in AutoVue.

The **Perspective** option shows objects in three dimension with distances, planes and curved surfaces adjusted to give a sense of depth. You have lighting options where you can adjust the overall lighting surrounding a model or just its source light.

In AutoVue's 3D mode, you can customize operations to suit your needs. For example, you can create and save your own views. Define cross sections and cut-throughs of 3D models. Create a customized three-axis coordinate system that you can set as the active coordinate system for your 3D files.

There are also features like Bill of Material (BOM), Interference Checking and Product and Manufacturing Information (PMI) Filtering.

## Models Tab

The **Models** tab displays the model's hierarchy, inter-relation of different parts, assemblies and bodies. With the **Model** tree, you can select different parts and modify their attributes such as color, visibility, render mode or transformation.

## Views Tab

The **Views** tab lists all the standard and user-defined views. You can switch to a standard or user-defined view, as well as add or delete user-defined views.

## Bookmarks Tab

The **Bookmarks** tab lists links to specific views (Draft views, 2D plans) or other files with information related to the model. Navigate between these files and views by clicking the appropriate link. Bookmarks lead to various views of CAD files such as CATIA file Model Space, the 3D model of a file and associated 2D engineering drafts.

If a plus sign appears to the left of a bookmark, click it to expand and view the lower bookmark levels. If a minus sign appears to the left of the bookmark, click it to collapse the lower bookmark levels.

To go to a destination specified by a bookmark, click the bookmark text or the page icon located to the left of the bookmark text.

## Global Axes

By default, there is a three-axis representation in the lower left corner of the workspace. The **X-axis** is red, the **Y-axis** is green and the **Z-axis** is blue. When transforming a model or defining a viewpoint, all operations are applied with respect to these axes.

## Selecting Model Parts

In AutoVue, you can select model parts from the **Model Tree** or from the workspace and have them appear highlighted in the **Model Tree** and on the model. You can also select a model part and have all its identical parts appear highlighted on the model and in the **Model Tree**.

**Note** In AutoVue, you can configure the **Selection Highlight**, see *Configuring AutoVue for 3D Files*.

## Selecting Model Parts from the Model Tree

- 1 Click the **Models** tab.
- 2 Select the part or parts from the **Model Tree**.  
**Note** To select more than one model part, press the **Shift** or **Ctrl** key while selecting.  
The selected part(s) appear highlighted on the model and in the **Model Tree**.

## Select Model Parts from the Workspace

- 1 Select a part or parts on the model in the workspace.  
**Note** To select more than one model part, press the **Shift** or **Ctrl** key while selecting.
- 2 To select the parent entities of a selected part, press the **Shift** key and select the part again.

A pop-up appears listing the parent entities of the selected part. Select an entity from the pop-up list.

The selected part(s) appear highlighted on the model and in the **Model Tree**.

- 3 To select a group of parts, select **Edit > Select**, then click and drag the mouse around the parts.

The entities within the box are selected and highlighted in the **Model Tree**.

**Note** If the selected entity is hidden in the **Model Tree**, the **Model Tree** expands to display the selected entity.

## Selecting All Identical Parts of a Model

- 1 Select a model part in the workspace or from the **Model Tree**, then right-click and select **Select Identical Parts** from the pop-up menu.

All identical parts are highlighted on the model and in the **Model Tree**.

If there are no identical parts found, a message appears indicating **No identical parts found**.

**Note** You can also select sub-assemblies and **Select Identical Parts** to display all identical sub-assemblies.

## Hiding Model Parts

In AutoVue, you can hide specific parts of a model or display specific parts and hide the rest of the model.

- 1 Select the part or parts on the model or from the **Model Tree**.

**Note** To select more than one model part, press the **Shift** or **Ctrl** key while selecting.

The selected part(s) appear highlighted on the model and in the **Model Tree**.

- 2 To hide the selected part(s), right-click a selected part on the model or from the **Model Tree** and select **Hide** from the pop-up menu.

The selected part(s) are hidden on the model.

To display the selected part(s) and hide the rest of the model, right-click a selected part on the model or from the **Model Tree** and select **Hide Rest** from the pop-up menu.

The selected parts are displayed in the workspace and the rest of the model is hidden.

# Re-centering

The **Re-center** option repositions the model back to the center of the View window. You can use a model part as a central reference point to reposition a model. You can select several model parts to use as one collective central reference point.

## Re-centering a Model to a Selected Model Part

**Note** The **Re-Center > Selected** option is only available when one or more model parts are selected.

- 1 Select the model part or parts that you want to use.
- 2 Select **View > Re-Center > Selected** from the AutoVue main menu.  
The model is repositioned using the selected model part or parts as the central reference point.

## Re-center All

The **Re-Center All** option repositions the entire model back to the center of the AutoVue workspace.

- 1 Select **View > Re-Center > All** from the AutoVue main menu.  
The model is repositioned to the center of the workspace.

## Re-centering a Model to an Entity

You can use an entity as a central reference point to reposition a model. The entities are:

---

Entity	Description
Vertex	All vertices are highlighted. Select a vertex to use as the central reference point. <b>Note</b> A snap box appears when moving the mouse over a vertex.
Edge	All edges are highlighted. Select an edge to use as the central reference point. <b>Note</b> A snap box appears when moving the mouse over an edge.

---

Entity	Description
Midedge	Highlight all edges in the model. Select a mid-edge to use as the central reference point.
Arc Center	Highlight all arcs and circles in the model. Select an arc center to use as the central reference point. <b>Note</b> A snap box appears when moving the mouse over an arc or circle, indicating the center of the arc.
Face	Select a face to use as the central reference point. <b>Note</b> When moving the cursor along a model face, the face is highlighted.

- 1 Select **View > Re-Center > Entity** from the AutoVue main menu. The **Re-Center** dialog appears.
- 2 Select the entity that you want to use as the central reference point. All instances of the entity are highlighted.
- 3 Click an instance of the entity. The model is repositioned using the selected entity as the central reference point.
- 4 Close the **Re-Center** dialog.

## Expanding/Collapsing the Model Tree



In AutoVue, you can expand the **Model Tree** to display child entities of a selected node or nodes.

**Note** In AutoVue, you can also can configure the level you want to expand the **Model Tree**. To configure the **Model Tree Level**, see *Configuring AutoVue for 3D Files*.

- 1 Click the **Models** tab.
- 2 From the **Model Tree**, select the node or nodes that you want to expand, then right-click and select **Expand All Children** from the pop-up menu.  
**Note** To select more than one node, press the **Shift** or **Ctrl** key while selecting.

The selected entities are highlighted. The **Model Tree** expands displaying the child entities of the selected node(s).

- 3 To collapse a node(s), select the node(s), then right-click and select **Collapse All Children** from the pop-up menu.  
The **Model Tree** collapses the selected node(s).

**Note** You can also expand a node by clicking . To collapse a node click .

## Creating 3D Mockups

In AutoVue you can import other 3D Models into the current active file.

**Note** The imported files must be 3D and have similar dimensions.

- 1 Select **Analysis > DMU** from the AutoVue main menu.  
The **Import Design** appears.
- 2 Click **Add**.  
The **Import Design Dialog** appears.
- 3 Enter the **File name** or browse to locate the file you want to import.
- 4 Click **Open**.  
The file appears in the **Import Design** dialog.

**Note** To import more than one file, repeat steps 2 to 4.

- 5 Click **OK**.  
The file(s) you imported appear in the workspace.

**Note** Once open, you can position these models in the desired manner using the **Transformation** tool, or align the models using **Part Alignment**, or run **Interference Checks**.

**See Also** *Transformation*

*Part Alignment*

*Performing Interference Checks*

## Deleting Models from a Mockup

- 1 Select **Analysis > DMU** from the AutoVue main menu.  
The **Import Design** dialog appears.
- 2 Select the file(s) that you want to remove.
- 3 Click **Remove**.  
The file(s) are removed from the list.
- 4 Click **OK**.  
The file(s) disappear from the workspace.

# Converting 3D Models to Other Formats

Sometimes you need to translate a 3D model to be able to use it with an application it was not created from. AutoVue provides several conversion file formats for you.

## Conversion Options

Depending on the conversion type being performed, the available options in the **Convert** dialog will vary. These options are:

---

Option	Description
Save As	Specify the name and path of the file in which the conversion is to be stored. This file is also known as the output file. You can use <b>Browse</b> to provide AutoVue with the file's path.
Convert to Format	<p>A drop-down list of all the possible types of output file formats currently available for conversion. The available formats are:</p> <ul style="list-style-type: none"> <li>• CALS GP4</li> <li>• Encapsulated Postscript (Raster)</li> <li>• HP Laserjet Printer (PCL)</li> <li>• Run Length RLC File</li> <li>• PCX Bitmap</li> <li>• PDF</li> <li>• Stereolithography (STL)</li> <li>• TIFF</li> <li>• Virtual Reality Modeling Language (VRML)</li> <li>• Windows Bitmap</li> </ul>
Sub-Format	<p>The <b>Sub-Format</b> drop-down list appears when you select <b>TIFF</b> or <b>STL</b> from the <b>Convert to Format</b> drop-down list.</p> <p>Select the <b>Sub-Format</b> from the drop-down list.</p>

---

---

Option	Description
Color Depth	<p>Select an option from the drop-down list:</p> <ul style="list-style-type: none"><li>• <b>1</b> = Black and white</li><li>• <b>4</b> = 16 colors</li><li>• <b>8</b> = 256 colors</li><li>• <b>24</b> = True color</li><li>• <b>auto</b> = AutoVue selects the color depth that best matches the original file.</li></ul> <p><b>Note</b> Option is not available for <b>STL</b> and <b>VRML</b> formats.</p>
Postive Triangle Values	<p>When selected, the model is translated so that all the vertex coordinate values are positive.</p> <p><b>Note</b> Option is only available when <b>Convert to Format</b> is set to <b>STL</b>.</p>
Convert Region	<p>The area of the file to be converted. The available options are:</p> <ul style="list-style-type: none"><li>• <b>All</b> - converts the entire file</li><li>• <b>Display</b> - converts the image to fit on the output page For example, if you zoomed in on a particular region of the file, the zoomed portion of the file is converted.</li><li>• <b>Extent</b> - converts the entire extents of the file</li><li>• <b>Selected</b> - converts the selected model parts in the file</li></ul> <p><b>Note</b> Options vary depending on the selected format.</p>
Convert Pages	<p>The number of pages to be converted. The available options are:</p> <ul style="list-style-type: none"><li>• <b>All</b> - converts all pages of the file</li><li>• <b>Current</b> - converts the current page of the file</li><li>• <b>Range</b> - converts the pages of the file indicated in the range</li></ul> <p><b>Note</b> Option is only enabled when converting to <b>TIFF</b>.</p>

---

Option	Description
X and Y	<p>Specify <b>X</b> and <b>Y</b> to define the resolution for the converted file. Choose from pixels, inches and millimeters for the units.</p> <ul style="list-style-type: none"> <li>• <b>X</b> indicates the number of horizontal pixels</li> <li>• <b>Y</b> is the number of vertical pixels for the current active file contents</li> </ul> <p><b>Note</b> At times, AutoVue presets <b>X</b> and <b>Y</b> to match the specifications of the selected conversion file format.</p>

## PDF

With AutoVue it is possible to convert Office, 2D and EDA formats to PDF. When converted from **Markup Mode**, markups are “burned” onto the PDF. When you open the PDF, you will see the base file along with all markups.

## Converting a 3D Model

- 1 Select **File > Convert** from the AutoVue main menu. The **Convert** dialog appears.
- 2 In the **Save As** text box, enter the path and filename or click **Browse** to locate the directory where you want to convert the file to, then enter a file name.
- 3 From the **Convert to Format** drop-down list, select the format you want to convert the file to.
 

**Note** The **Output** and **Convert** area options change according to the type of format you choose.
- 4 Select the output and convert options that you want to set for the file.
 





**See Conversion Options**
- 5 Click **OK**.
 



The **Conversion in progress** dialog appears. The dialog disappears when the file is converted successfully.



## Manipulating Views

AutoVue provides the flexibility to manipulate the display of a 3D model. You can rotate, scale or translate a model or any selection of model parts. You can also navigate from one page to another page of a multi-page file.

You can access these options from the **View** menu of the AutoVue main menu. The options are:

Select	Description
Zoom	<p>In Zoom in by a factor of 2.</p> <p>Out Zoom out by a factor of 2.</p> <p>Fit Resize object to fit window. From the toolbar, click the  button or right-click in workspace and select from pop-up menu.</p>
Previous	<p>Return to the previous zoom level. Right-click in workspace and select from pop-up menu.</p>
Selected	<p>Resize the object so that the objects <b>selected</b> fill the window.</p>
Box Mode	<p>Click and drag to draw a box around an object that you want to enlarge to fill the window. From the toolbar, click the  button or right-click in workspace and select from pop-up menu.</p>
Dynamic Mode	<p>Click and drag the cursor up to zoom in or down to zoom out. From the toolbar, click the  button or right-click in workspace and select from pop-up menu.</p>
Pan	<p>Click and drag to reposition the model, then release the mouse button. From the toolbar, click the  button or right-click in the workspace and select from the pop-up menu</p>

Select	Description
Rotate Mode	<p>Click and drag to rotate the model on all three axes, then release the mouse button.</p> <p>From the toolbar, click the  button or right-click in workspace and select from pop-up menu.</p>
Spin Mode	<p>Click and drag the object in the direction you want the object to spin continuously, then release mouse button. To stop the object from spinning, click once anywhere in the workspace.</p> <p><b>Note</b> The spin velocity is determined by the speed at which you drag the mouse.</p> <p>From the toolbar, click the  button.</p>
Re-center	<p>Repositions the model.</p> <p><b>Re-center All</b> - reposition the entire model back to the center of the AutoVue workspace.</p> <p><b>Selected</b> - only available when one or more model parts are selected. The selected part or parts are considered as the central reference point by which the model is repositioned.</p> <p><b>Entity</b> - select a model part or entity as a central reference point to reposition a model.</p> <p><b>See <i>Re-centering</i></b></p>
Next Page	Go to the next page of a multi-page file.
Previous Page	Go to the previous page of a multi-page file.
Page Number	Go to the specified page of a multi-page file.
Perspective	Show objects in three dimensions with the distances, planes and curved surfaces adjusted to give a sense of depth that reflects the desired perspective to the eye.

Select	Description
Views	<p>Display different views of 3D models or create your own.</p> <p>Right-click in workspace and select the view from the pop-up menu.</p> <p><b>See <i>3D Views</i></b></p>
Display Attributes	<p>Display a 3D model in different render modes.</p> <p>From the toolbar, click the  button or right-click in workspace and select from pop-up menu.</p> <p><b>See <i>Displaying Attributes</i></b></p>
Show Tree	<p>Show the <b>Model Tree</b> of the current active file.</p> <p>From the toolbar, click the  button.</p>

## Display Attributes

AutoVue provides several different render methods to display a 3D CAD model. You can also adjust the degree of transparency, change color or visibility, to suit your preferences.

## Render Modes

The choice of render mode varies between the level of detail and the render speed of the model. For example, a shaded model is three-dimensional and highly detailed but requires more time to render. The different render modes are:

Method	Description
Wireframe	A skeletal model constructed using lines and curves that represent the model's "true" edges. All internal lines are visible.
Shaded	A solid model constructed of planes and surfaces. These surfaces are shaded to increase the illusion of three dimensions.
Hidden Line	A wireframe constructed with all internal lines hidden.


Method	Description
Silhouette	A wireframe constructed with all internal lines visible but including additional silhouette edges. These are not "true" edges but help to visualize the model.
Wire Polygons	A skeletal model constructed of unfilled polygons.
Shaded Wire	An outlined solid model constructed of planes and surfaces. The outline is a solid line and the model's surfaces are shaded to increase the illusion of three dimensions.

## Changing the Render Mode

**Note** A checkmark beside the attribute indicates the current render mode.

- From the AutoVue main menu, select **View > Display Attributes** and the render mode that you want to render the model in.

**Note** You can also change the render mode for selected model parts.

**Note** You can also click the Render Mode button  on the AutoVue toolbar or right-click in the workspace and select **Display Attributes**. The model or selected model parts change to the selected render mode.

## Changing the Visibility

In AutoVue, you can show or hide parts of a model.

- From the **Model Tree**, clear the checkbox beside the model part(s) that you want to hide.

Select the checkbox beside the model part(s) that you want to set visible. The selected model part(s) appear or disappear from the model.

**Note** You can also hide model part(s) by selecting them on the model or from the **Model Tree**, then right-clicking and selecting **Hide** from the pop-up menu. Selecting **Hide Rest** displays the selected model part(s) and hides the rest of the model.

## Changing Model Color

In AutoVue, you can change the color of a specific model part or selected model parts.

- Select the model or model parts whose color you want to change.

**Note** If no part is selected, the change is applied to the entire model.

- 2 Select **View > Display Attributes > Color** from the AutoVue main menu. The **Color** dialog appears.
- 3 Select the color that you want to change to.
- 4 Click **OK**.

The selected part(s) change to the selected color.

**Note** To set the model color to its default color, repeat steps 1 to 2 and click **Reset** in the **Color** dialog.

**Note** You can also right-click in the workspace and select **Display Attributes > Color**. In the **Model Tree**, you can select the model part(s), then right-click and select **Display Attributes > Color** from the pop-up menu.

## Adjusting the Transparency

You can adjust the degree of transparency of a model. This function only applies to shaded and shaded wire models.

- 1 Select the model or model parts whose transparency you want to adjust.
- 2 Select **View > Display Attributes > Transparency** from the AutoVue main menu. The **Set Transparency** dialog appears.
- 3 To adjust the transparency, move the slider left or right. Select **Apply Dynamically** if you want the transparency to simultaneously change with the movement of the slider.

**Note** You can also adjust the transparency by entering a **Value** from 0 to 1:  
**0** = opaque  
**1** = transparent
- 4 Click **Close** to apply the changes and close the **Set Transparency** dialog.

**Note** You can also right-click in the workspace and select **Display Attributes > Transparency**. In the **Model Tree**, you can select the model part(s), then right-click and select **Display Attributes > Transparency** from the pop-up menu.

## Changing the Mesh Resolution

**Note** A checkmark beside the mesh option indicates the current mesh resolution.

- 1 Select the parts that you want to change the mesh resolution.

- From the AutoVue main menu, select **View > Display Attributes > Mesh Resolution** and then **High, Medium** or **Low**.

**Note** You can also change the mesh resolution by right-clicking in the workspace and selecting **Display Attributes > Mesh Resolution**. In the **Model Tree**, you can select the model part(s), then right-click and select **Display Attributes > Mesh Resolution** from the pop-up menu.

**Note** Changing the mesh resolution will not affect the default Mesh Resolution set in the **Configuration** dialog.

## Light Settings

The default light setting consists of a white light positioned directly in front of the object as it is displayed. In the **Lighting** dialog it appears as a ball of white light in the center of the larger sphere.

**Ambient lighting** is the overall lighting that surrounds an object. It provides constant illumination to every surface of the model. This type of lighting is particularly effective as a fill-light for surfaces not directly illuminated by a directional light source. You can set the intensity or source position. Too high a setting tends to saturate the image and reduce its clarity.


Using the **Directional lighting** option, you can adjust the position of the light source on an object.

In AutoVue, you can:

- Set the intensity and source position of the ambient light.
- Set the direction of light.
- Add and remove light source.
- Change light color.

## Setting Ambient Lighting

- Select **View > Set Light** from the AutoVue main menu. The **Lighting** dialog appears.

**Note** You can also click the light bulb button  on the AutoVue main toolbar.

- Click and drag the **Ambient Light** sliding bar until you achieve the desired lighting. The lighting automatically changes with the movement of the sliding bar.


**Note** To set the ambient lighting to its default setting, click **Reset**.

- 3 Click **Close** to close the **Lighting** dialog.

## Setting Directional Lighting

Setting the directional lighting adjusts the position of the light source on the model. You can also add a new light source.

- 1 Select **View > Set Light** from the AutoVue main menu.  
The **Lighting** dialog appears.

**Note** You can also click the light bulb button  on the AutoVue main toolbar.

- 2 To change the direction of the light, click and drag the small ball until you achieve the desired lighting.

**Note** You can also drag the white ball outside of the large ball.


The direction of the light reflected on the 3D model automatically changes with the movement of the white ball.

**Note** To set the light direction to its default setting, click **Reset**.

- 3 Click **Close** to close the **Lighting** dialog.

## Adding a New Light Source

- 1 Select **View > Set Light** from the AutoVue main menu.  
The **Lighting** dialog appears.

**Note** You can also click the light bulb button  on the AutoVue main toolbar.

- 2 Right-click inside the square surrounding the ball and select **Create New Light source** from the pop-up menu.

A second small ball appears.

- 3 Click and drag the small ball until you achieve the desired lighting.

**Note** To restore the light source to its default setting, right-click inside the square and select **Restore Default** from the pop-up menu.


- 4 Click **Close** to close the **Lighting** dialog.

**Note** You can add up to eight light sources.

## Changing the Light Color

- 1 Select **View > Set Light** from the AutoVue main menu.

The **Lighting** dialog appears.

**Note** You can also click the light bulb button  on the AutoVue main toolbar.

- 2 To change the color of the light source, right-click directly on the small ball and select **Set Light Color**.

The **Color** dialog appears.

- 3 Select a color.

- 4 Click **OK**.

The small ball changes color and the model reflects the selected light color.


**Note** To set the light color to its default setting, click **Reset** in the **Lighting** dialog.

- 5 Click **Close** to close the **Lighting** dialog.

## Removing a Light Source

- 1 Select **View > Set Light** from the AutoVue main menu.

The **Lighting** dialog appears.

**Note** You can also click the light bulb button  on the AutoVue main toolbar.

- 2 Right-click directly on the small ball that you want to remove and select **Remove Light**.

The small ball disappears and the light change is reflected.

- 3 Click **Close** to close the **Lighting** dialog.

## 3D Views

In AutoVue, you can display different views of 3D Models or create your own views.

### Default View

The **Default View** is the isometric view for three-dimensional CAD models.

This viewpoint has the viewing camera positioned at an equal distance from all three axes and pointing directly at the origin.

## Setting Standard or Predefined Views

Rather than entering Rotation mode, you can view various predefined rotations with the **Views** option from **View** and **Markup** modes.

**Note** A checkmark beside the view option indicates the current pre-defined view you want to display.

- 1 From the AutoVue main menu, select **View > Views** and the pre-defined view you want to display.  
The model changes to the selected view.  
The view options that you can select from are Isometric, Top, Bottom, Front, Back, Left and Right.  
**Note** You can also click the **Views** tab, then click the view from the **Standard Views** tree, or right-click in the workspace and select **Views**.

## Setting Native Views

AutoVue displays views for a 3D file as saved in its native application. The views are listed under **Native Views** from the **Views** tab.

**Note** Native views are present only if the file contains saved views.

- 1 From the AutoVue main menu, select **View > Views > Native Views** and the view you want to display.  
The model re-orientes to the selected view.  
The view options vary depending on the file. Examples of the view options are Last Saved View, Presentation, Front, Back, Left, Right, Top, Bottom, Isometric, Trimetric and Dimetric.  
**Note** You can also right-click in the workspace and select **Views > Native Views**.

## Creating a User-defined View

You may want to create and save your own views. AutoVue allows you to define a view and add it to the **User Defined Views**.

**Note** You can define a user view in **View** or **Markup** mode. Any views you apply to displayed models during **Markup** mode are saved as part of the Markup.

- 1 Apply your own views or transformation to the displayed model.  
**Note** The view states that you can apply and save for your defined view are Extents, Rotation, Model Transformation, Explosion, Render Modes, Color, Transparency, Visibility, Sectioning, Camera Settings and views involving Mockups.

- 2 Select **View > User Defined Views > Add** from the AutoVue menu. The **Add User Defined View** dialog appears.  
**Note** You can also click the **Views** tab, then right-click **User Defined Views** and select **Add** from the pop-up menu or right-click in the workspace and select **Views > User Defined Views**.
- 3 Enter a **View Name** for the view that you want to define.
- 4 Click **OK**.  
The view you defined is saved and appears in the **Views** tree under **User Defined Views**.  
**Note** To see the view you defined, click the **Views** tab and select it from the tree or select **View > Views > User Defined Views**. You can also alternate between **User Defined Views** and **Standard Views** without affecting your personalized views.

## Deleting a User Defined View

- 1 Under the **User Defined Views**, select the view that you want to delete, then right-click and select **Delete**.  
A **Confirmation** dialog appears.
- 2 Click **OK**.  
The view disappears from the **User Defined Views**.

## Displaying the Perspective Projection of a 3D Model

The **Perspective** option shows objects in three dimensions with distances, planes and curved surfaces adjusted to give a sense of depth that reflects the desired perspective to the eye.

**Note** You can use the **Perspective** option in any of the 3D Views since it is a projection mode rather than a viewpoint.

- 1 Select **View > Perspective** from the AutoVue main menu.  
The depth of the model changes.  
**Note** A checkmark beside **Perspective** indicates the view is selected.


## Viewing a Model from a Particular Viewpoint

To view a model from a particular point, you can specify a viewpoint.

- 1 Select **View > Views > View Point** from the AutoVue main menu.
- 2 The **View Point** dialog appears.  
**Note** You can also right-click in the workspace and select **Views > View Point**.
- 3 Enter the coordinates for **X, Y** and **Z**.  
For **Camera Position**, enter the coordinates to determine the position of the camera lens.  
For **Target Position**, enter the coordinates to determine the position of the 3D model viewed through the camera lens.  
For **Up Direction**, change the coordinates to values between 0 and 1 to determine the upward orientation.
- 4 Click **OK**.  
The entity moves to the defined viewpoint. The Global axes and the User Coordinates System change position to reflect the viewpoint.

## Layers

Use this option to configure the current active file's layers to display.

- 1 Select **View > Layers** from the AutoVue main menu.  
The **Select the layers to display** dialog appears listing the layers and layer visibility for the current active file.  
**Note** You can also click the Layers button  on the AutoVue toolbar.
- 2 To sort the list of layers in the dialog, click **Name** to sort alphabetically or numerically, or click **Status** to sort by visibility.
- 3 Select the checkbox beside the layers that you want to set visible.  
Clear the checkbox beside the layers that you want to hide.
- 4 Click **OK**.  
The selected layers are displayed.

## Entity Properties

In AutoVue, you can view properties such as visibility, colors, transparency, mass properties and extents of a model or model parts.

## Viewing Attributes

The **Attributes** tab displays a model or model part's attributes. The list of attributes will vary depending on the model. Some of the viewable **General** attributes are:


Attribute	Description
Color	Color of the selected model part.
Density	The density of the model or selected model part(s).
Mesh Resolution	The number of polygons drawn when displaying a model.
Name	The model part name or the displayed page name of the model.
Render Mode	The dynamic rendering used for displaying model or model part. For example, <b>Shaded</b> , <b>Shaded Wire</b> and <b>Wire-frame</b> .
Transparency	The value between 0 and 1 representing the model or model part's degree of transparency. <b>0</b> = opaque <b>1</b> = transparent
Visibility	The value <b>True</b> (visible) or <b>False</b> (invisible) for a model or model part.

If you are displaying the 3D view of an EDA, AutoVue displays the general attributes mentioned above. In addition, displays attributes specific to the Printed Circuit Board (PCB), such as component name, board side, component class and device type.

If a 3D file has Product and Manufacturing Information (PMI) and a PMI entity is selected, the **PMI** attributes are displayed along with the above general attributes and attributes specific to the PCB board. Some of the viewable **PMI** attributes are X-Axis, Y-Axis, font color, text font name and tolerance type.

- To view the attributes of specific model part(s), select the parts from the model.  
To view the attributes of the entire 3D model, make sure that no parts are selected.
- Select **Analysis > Entity Properties** from the AutoVue main menu.


The **Entity Properties** dialog appears.

**Note** You can also click the Entity Properties button  on the AutoVue toolbar or right-click in the workspace and select **Entity Properties**. In the **Model Tree**, select the model part(s), then right-click and select **Entity Properties** from the pop-up menu.

- 3 Click the **Attributes** tab.  
The attributes of the selected model part(s) are displayed in a hierarchical tree.
- 4 Click **Close** to close the **Entity Properties** dialog.

## Viewing Mass Properties

The **Mass Properties** pane displays the precise measurements for mass, volume, area, center of gravity, moments of inertia and inertia tensor for any model or selection.

- 1 Select the part(s) for which you want to calculate the **Mass Properties**.  
**Note** To view the **Mass Properties** of the entire 3D model, make sure no parts are selected.
- 2 Open the **Entity Properties** dialog by taking one of the following steps:
  - Click the **Entity Properties** button  in the AutoVue toolbar.
  - Double-click a model part or parts in the workspace.
  - Right-click model part or parts in either the **Model Tree** or the workspace, then select **Entity Properties** from the pop-up menu.
  - Select **Analysis > Entity Properties** from the AutoVue main menu.
- 3 Select a model part or parts.
- 4 Click the **Mass Properties** tab to view the Mass properties.  
**Note** When a Mass property cannot be calculated, “N/A” displays in red for that property. When this is the case, you can also click the **Error Report** button for a list of Mass properties that could not be calculated.
- 5 Click **Options** to change the density, change measurement units, or configure computation of inertia tensor.  
The **Options** dialog appears.  
**See *Configuring Mass Properties***
- 6 Click **Close** to close the **Entity Properties** dialog.

## Configuring Mass Properties


From the **Mass Properties** pane, you can change the density, the measurement units or configure the reference point of inertia tensor.

- 1 From the **Mass Properties** pane, click **Options**.  
The **Options** dialog appears.
- 2 To change the **Density**, enter a value.  
To change the **Density** units, select the unit for **Mass** and **Length** from their respective drop-down lists.
- 3 To apply the density to model parts with unknown density, select **Use Only for Parts with Unknown Density**.  
To apply the density to all model parts, select **Use for All Parts**.
- 4 To change the **Display** units, select the unit for **Mass** and **Length** from their respective drop-down lists.
- 5 To compute the inertia tensor based on output coordinate system, select **Output Coordinate System Origin**.  
To compute the inertia tensor based on the center of gravity, select **Center of Gravity**.
- 6 Click **OK**.  
Mass properties are instantly calculated and displayed in the **Mass Properties** panel.  
**Note** When a Mass property cannot be calculated, “N/A” displays for that property. When this is the case, you can also click the **Error Report** button for a list of Mass properties that could not be calculated.
- 7 To save the changes, click **Save As**. The **Save As** dialog appears.  
Specify the path where you want to store the file and enter the **File name**, then click **Save**.  
AutoVue saves the results in a **csv** (Comma Separated Values) file.
- 8 Click **Close** to close the **Entity Properties** dialog.

## Viewing Extents

The **Extents** tab displays the orientation coordinates and center coordinates of the X, Y and Z axes for any model or selection, as well as the width, height and depth measurements.

- 1 Select the part(s) for which you want view **Extents**.  
**Note** To view the **Extents** of the entire 3D model, make sure no parts are selected.
- 2 Select **Analysis > Entity Properties** from the AutoVue main menu.  
The **Entity Properties** dialog appears.

**Note** You can also click the Entity Properties button  on the AutoVue toolbar or right-click in the workspace and select **Entity Properties**. In the **Model Tree**, select the model part or parts, then right-click and select **Entity Properties** from the pop-up menu.

- 3 Click the **Extents** tab.
- 4 Click **Transformed** if you want to view the extents after you have transformed the model.  
Click **UnTransformed** if you want to view the extents of the model without transformation.  
Click **Oriented** if you want to view the X, Y and Z coordinates of the reoriented model or selection.
- 5 Click **Close** to close the **Entity Properties** dialog.

## PMI Filtering

A 3D file's Product and Manufacturing Information (PMI) is composed of annotations that are included in design files. These annotations indicate the limits and constraints that must be observed during the production of the object displayed in the 3D model.

At the highest level, PMI provides information about dimensions, feature control frames, weld specifications, and surface finishes. This information is based upon key design features which are specified through datum targets, measurement points, reference geometry (construction lines, surfaces, objects), or the geometry inherent in the object.

Use **PMI Filtering** to select which types of product and manufacturing information to display.

- 1 Select **View > PMI Filtering** from the AutoVue main menu.  
The **PMI Filtering** dialog appears displaying all PMI types.

**Note** You can also click the PMI Filtering button  on the AutoVue toolbar.

- 2 In the **Tree** column, select the checkbox beside the items that you want to show in the **Model Tree**.  
In the **View** column, select the checkbox beside the items that you want to show on the model.  
Clear the checkbox beside the items that you want to hide.  
**Note** To show or hide all items, click **All** to show all or **None** to hide all.
- 3 Click **OK**.

Only items selected in the **Tree** column are displayed in the **Model Tree**. Only items selected in the **View** column are visible on the 3D model.

**Note** Visibility settings are saved and will be restored the next time you open the **PMI filtering** dialog.

- 4 AutoVue supports default PMI visibility as saved in the file. To restore default PMI visibility, click **Default** in the **PMI Filtering** dialog.

## Aligning to a PMI Entity

From the **Model Tree**, right-click the PMI item that you want to align to and select **Align to** from the pop-up menu.

AutoVue aligns to the selected PMI item.

## Go To a displayed PMI Entity

From the **Model Tree**, right-click the PMI item that you want to go to on the model and select **Go To** from the pop-up menu.

AutoVue zooms to the selected PMI item.


## Manipulators

In AutoVue, you can rotate 3D CAD models along a specific axis. You can scale a model part up and down, as well as translate the model.

Using the **Manipulators**, you can resize, translate and/or rotate selected parts of the model. When you select one or more model parts, AutoVue displays a model-size representation of the Global Axes going through the selected part(s) of the 3D model.

## Panning a Model Along the X, Y and Z-Axis

- 1 Select **Analysis > Manipulators** from the AutoVue main menu. You are now in Manipulators mode.

**Note** You can also click the Manipulators button  on the AutoVue toolbar or right-click in the workspace and select **Manipulators**. In the **Model Tree**, you can select the model part(s), then right-click and select **Manipulators** from the pop-up menu.

- 2 Select the model part or parts that you want to move.


**Note** To select more than one part, press the **Shift** or **Ctrl** key when selecting.

A model-size representation of the Global Axes appears through the model part or parts and are encased by a three-dimensional box.

- 3 Click and hold the mouse button on the arrow at the end of the axis that you want to pan.
  - 4 Drag the mouse to where you want to move the part or parts.
- Note** To remove the Manipulators, click the Manipulators button.

## Rotating a Model Along the X, Y and Z-Axis

- 1 Select **Analysis > Manipulators** from the AutoVue main menu. You are now in Manipulators mode.

**Note** You can also click the Manipulators button  on the AutoVue toolbar or right-click in the workspace and select **Manipulators**. In the **Model Tree**, you can select the model part(s), then right-click and select **Manipulators** from the pop-up menu.

- 2 Select the model part or parts that you want to manipulate.

**Note** To select more than one part, press the **Shift** or **Ctrl** key when selecting.

A model-size representation of the Global Axes appears through the model part or parts and are enclosed by a three-dimensional box.


- 3 Click and hold the mouse button on the sphere at the end of the axis you want to rotate.

Clicking on an axis sphere allows rotation around one of the other two axes.

**Note** The initial mouse movement determines which of the two axes will mark the site of rotation. If the axis you chose does not rotate around the right axis for the rotation that you want to make, click the sphere again and move the mouse in a different direction.

- 4 Move the mouse to rotate the model by the selected axis.

**Note** If you want to rotate the selection freely, as done in Rotate Mode, press the **Ctrl** key during rotation.


- 5 To remove the Manipulators, click the Manipulators button .

**Note** To remove Manipulators, you can also select **Analysis > Manipulators**.

Mouse actions are restored to what they were prior to entering Manipulators mode.

## Scaling a Model Along the X, Y and Z-Axis

- 1 Select **Analysis > Manipulators** from the AutoVue main menu.  
You are now in Manipulators mode.

**Note** You can also click the Manipulators button  on the AutoVue toolbar or right-click in the workspace and select **Manipulators**. In the **Model Tree**, you can select the model part(s), then right-click and select **Manipulators** from the pop-up menu.

- 2 Select the model part or parts that you want to scale.

**Note** To select more than one part, press the **Shift** or **Ctrl** key when selecting.

A model-size representation of the Global Axes appears through the model part or parts and are encased by a three-dimensional box.

- 3 Click and drag a corner cube of the box up or down to scale the selected model part.

**Note** To remove the Manipulators, click the Manipulators button.

## Part Alignment

With the **Part Alignment** option in AutoVue, you can select a point on a model's vertex, edge or face to align a model or model part to another model or part.

The **Mobile** point determines the precise point of alignment for the model part. The **Fixed** point on the model determines the precise fixed point to which the mobile part will align.

With the **Show Preview** option, you can visualize the part alignment before applying the change.

When aligning models parts, you can choose from one of the following **Constraint Types**.

Option	Type	Description
Constraint	Coincident	The <b>Mobile</b> part is positioned so that the selected point on the mobile part coincides with the selected part on the <b>Fixed</b> part.
	Parallel	Align the <b>Mobile</b> point so that it is parallel to the <b>Fixed</b> point.

Option	Type	Description
	Perpendicular	Align the <b>Mobile</b> point so that it is perpendicular to the <b>Fixed</b> point.
	Concentric	Align the <b>Mobile</b> point so that it has the same center as the <b>Fixed</b> point

## Part Alignment Constraints

The table below list the available **Constraint Types** for different combinations of part alignment.

	Point	Line	Arc	Plane	Sphere	Cylinder	Cone
Cone	Coin Con	Par Per	Con	Per Con	Coin Con	Par Con	Coin Con Par
Cylinder	Con	Par Con	Par Con	Per	Coin Con	Par Con	
Sphere	Con	Coin Con	Con	Coin	Coin Con		
Plane	Coin	Per	Coin Par	Coin Par			
Arc	Con	Per Con	Par Con				
Line	Coin	Coin Par					
Point	Coin						

**Note** The letters in the table indicate the **Constraint Type**:

Where:


Coin - **Coincident**


Par - **Parallel**  
 Per - **Perpendicular**  
 Con - **Concentric**

## Aligning Model Parts









**Note** To see a preview of the alignment before applying the change, click **Show Preview**.

- 1 Select **Analysis > Part Alignment** from the AutoVue main menu. The **Part Alignment** dialog appears.

**Note** You can also click the Part Alignment button  on the AutoVue toolbar or right-click in the workspace and select **Part Alignment**. In the **Model Tree**, you can select the model part(s), then right-click and select **Part Alignment** from the pop-up menu.




- 2 Select the **Constraint Type** that you want to perform.  
**See *Part Alignment Constraints***

- 3 Select the **Alignment Type**.  
Select **Aligned** if you want to align the **Mobile** point on the model part to the **Fixed** point on the model.  
Select **Anti-Aligned** if you want to align the **Mobile** point on the model part so that it is opposite to the **Fixed** point on the model.
- 4 Select a model part. The **Mobile** arrow  is enabled.
- 5 Click **Vertex** , **Edge**  or **Face**  to select the type of geometrical point you want to click on the model part to be aligned. All instances of the selected geometrical point appear highlighted.
- 6 Click the geometrical point on the selected model part.  
The geometrical point is highlighted.  
The **Fixed** arrow  is enabled.
- 7 Click **Vertex** , **Edge**  or **Face**  to select the type of geometrical point you want to click on the model part to remain fixed.
- 8 Click the geometrical point on the model.
- 9 Click **Apply**.  
The model part is aligned according to the chosen options. The **Constraint Type** and the types of geometrical points aligned appear under **Constraints**.  
**Note** To remove a constraint, select the **Constraint** that you want to remove, then click **Remove**. To remove all part alignments, click **Remove All**.
- 10 Click **Close** to close the **Part Alignment** dialog.  
**Note** If you did not apply the changes before clicking **Close**, a message appears indicating **Do you wish to apply the constraint(s)?**


## Transformation

With the **Transformation** option, you can rotate, scale or translate a model or any selection of model parts, by using the illustrated buttons or by entering X, Y or Z values.

To access the **Transformation** dialog, you can select **Analysis > Transform**


**> Apply** from the AutoVue menu, or click the Transform button  on the AutoVue toolbar. From the **Model Tree**, you can select the model part(s), then right-click and select **Transform > Apply** from the pop-up menu.

The buttons on the left correspond to the rotational moves along the three axes. The buttons on the right correspond to the translational moves along the three axes and the scaling up and down.



## Transforming a Model using Illustration Buttons

- 1 Select **Analysis > Transform > Apply** from the AutoVue main menu. The **Transformation** dialog appears.



**Note** You can also click the Transform button  on the AutoVue toolbar.

- 2 Select the model part or parts that you want to rotate, translate or scale.

**Note** To select more than one model part, press the **Shift** or **Ctrl** key while selecting.

**Note** If no part is selected, transformation is applied to the entire model.

- Click the direction buttons on the left-hand side to rotate the model in the direction that you want.  
Click the translate buttons on the right-hand side to move the model in the direction that you want.

To scale the model, click  to scale up or click  to scale down.

**Note** To repeat a transformation, continue clicking the illustrated button.


**Note** Click **Reset** to set the model to its original transformation.

- Click **Close** to close the **Transformation** dialog.  
The transformation state remains displayed.

**See Also** *Resetting the Transformation of a 3D Model*

## Transforming a Model by Setting Values

- Select **Analysis > Transform > Apply** from the AutoVue main menu.  
The **Transformation** dialog appears.


**Note** You can also click the Transform button  on the AutoVue toolbar.

- Select the model part or parts that you want to rotate, translate or scale.  
**Note** To select more than one model part, press the **Shift** or **Ctrl** key while selecting.
- To rotate the model by set values, enter the **X**, **Y** and **Z** value.  
To translate the model by set values, enter the **X**, **Y** and **Z** value.
- To view a mirror image, select the checkbox beside the **Mirror** plane.
- To scale the model by a factor, enter a **Scale Factor**.
- Click **OK**.  
To apply absolute transformation instead of incremental, select **Absolute**.
- Click **Apply** in the **Transformation** dialog.
- To repeat a transformation, ensure that **Absolute** is cleared, then continue clicking **Apply**.  
**Note** Click **Reset** to set the model to its original transformation.
- Click **Close** to close the **Transformation** dialog.  
The transformation state remains displayed.

**See Also** *Resetting the Transformation of a 3D Model*

## Resetting the Transformation of a 3D Model

In AutoVue, you can reset a model or selected parts to their original transformation.

- 1 View the transformed 3D Model in AutoVue.
- 2 To reset the entire model to its original transformation, select **Analysis > Transform > Reset All**.  
To reset selected model part(s) to their original transformation, select the part(s) on the model, then select **Analysis Transform > Reset Selected**. The model or selected parts changes to their original transformation.  
**Note** You can also reset selected model part(s), by clearing the checkmark beside the part(s) in the Transformation column  of the **Model Tree**.

## Cross Section/Cut-through

With **Cross Section/Cut-through** feature, you can view the cross-section and cut-through of 3D models. In the **Define Section** dialog you can define the section plane position, section plane orientation and the cut-through.

### Section Plane Options

In the **Define Section** dialog, you can use below options to define the orientation of the section plane.

Option	Description
XY Plane	Section plane is oriented along the XY plane.
YZ Plane	Section plane is oriented along the YZ plane.
XZ Plane	Section plane is oriented along the XZ plane.
From 3 Vertices	Select three vertices on the object to define the orientation of the section plane.
From Face Normal	Select a face on the object to define the orientation of the section plane perpendicular to the face.

Option	Description
From Edge Tangent	Select an edge on the object to define the orientation of the section plane perpendicular to the edge's tangent.
Define a Plane	Define X, Y and Z coordinates to orient the section plane.


## Cut Options

In the **Define Section** dialog, you can use cut-options to define the cut-through of an object.

Option	Description
Don't Cut	Display the object without a cut.
Cut	Object displayed is cut along the section plane.
Invert	Reverse the selection, display the other part of the object.
Show Both	Restore the cut part of the object.
Edges Only	Display only the edges of the object along the section plane.

## Defining the Section Plane and Cut-through

- 1 Select **Analysis > Section > Define** from the AutoVue main menu. The **Define Section** dialog appears.

**Note** You can also click the Define Section button  on the AutoVue toolbar. In the **Model Tree**, you can select model part(s), then right-click and select **Section > Define** from the pop-up menu.

- 2 From the **Section Plane** drop-down list, select the orientation for the section plane.

**See *Section Plane Options***


- 3 From the **Cut Options** drop-down list, select the cut option that you want.

**See *Cut Options***

- 4 To define the plane position, click and drag the **Plane Position** slider to the position you want.  
Click **Dynamic**, if you want the plane to move simultaneously with the slider.
- 5 Select **Show Plane**, if you want the section plane visible.
- 6 Select **Fill**, if you want the section plane filled.  
The section plane is displayed as filled and the **Section Area** is calculated.  
**Note** **Fill** color can be set from the **Configuration** dialog.
- 7 From the **Measured Units** drop-down list, select the unit in which you want to measure the section surface.
- 8 Click **Close** to close the **Define Section** dialog.
- 9 Once you have defined the section plane and closed the **Define Section** dialog, you can access the cut options from the **Section** menu.
- 10 To remove a previously defined section, select **Section > Remove** from the AutoVue main menu.  
The section plane and cut section disappears instantly.

## Exporting Section Edges

In AutoVue, you can export a copy of the section plane and save it as a **.dxf** or **.dwg** file.

- 1 Define a section plane.
- 2 Select **Analysis > Section > Export** from the AutoVue main menu or if the **Define Section** dialog is open, click **Export**.  
The **Export Section As** dialog appears.  
**Note** You can also click the Define Section button  on the AutoVue toolbar. From the **Model Tree**, you can select the model part(s), then right-click and select **Section > Export**.
- 3 From the **Save in** drop-down list, select the directory where you want to export a copy to.
- 4 Enter the **file name**.
- 5 Select the **Save as type** from the drop-down list.  
**Note** You can only save the file in **.dxf** or **.dwg** format.
- 6 Click **Save**.  
**Note** To remove a section plane, select **Section > Remove** from the AutoVue main menu.

# Exploding

In AutoVue, users can use the **Explode** option to better understand the structure of an assembly and to analyze the dismount capability. The user can also save the exploded view, as well as obtain a printed document of the exploded product for further analysis.



## Explode Options

From the **Explode** dialog, you can define how the explosion is to be performed and to visually explode or implode a model. The options that you can set are:

---

Option	Description
Maximum Depth	Define up to which level you want to explode. All entities from the root level to the specified level are exploded. All entities on the other levels will not be exploded. If you are exploding: <ul style="list-style-type: none"><li data-bbox="397 724 982 866">• <b>Whole model</b> - the number of available levels depends on how many explodable levels exist in the model. For example, if there are four levels, with level 2 being the first level under the main assembly, then level 3 and level 4 are added to the drop-down list.</li><li data-bbox="397 871 982 954">• <b>Selected parts</b> - the number of available levels to be added to the drop-down list depends on the selected virtual tree.</li></ul>
Animated	When selected, animation is shown while exploding or imploding the model.
Show Arrows	When selected, arrows are displayed in an explosion assembly. The arrow starts from an exploded entity and points to the center point of its parent.


---

Option	Description
Scroll Explode	<p>Dragging the slider gradually displays the progression of the explosion to show the explosion dynamics.</p> <ul style="list-style-type: none"> <li>• <b>Explode</b> - pressing the  button brings the explosion level to the (n-1) level if current explosion level is between n-1 (inclusive) and n level (exclusive).</li> <li>• <b>Implode</b> - pressing the  button brings the explosion level to the n level if current explosion level is between n-1 (exclusive) and n level (inclusive).</li> </ul>


## Exploding a 3D Model


- 1 Select **Analysis > Explode** from the AutoVue main menu.
- 2 Select the parts that you want to explode.
 

**Note** To select more than one model part, press the **Shift** or **Ctrl** key while selecting.

To explode the entire model, ensure that no parts are selected.
- 3 From the **Maximum Depth** drop-down list, select the level to which you want the model to explode.
- 4 Select **Animated** if you want to see an animated view of the explosion. Set by default.
- 5 Select **Show Arrows** if you want to display the arrows.
- 6 To explode the model, click the  button.  
The whole model or the select model parts explode.
 

**See *Saving an Exploded View of a 3D Model***

**Note** To implode the model, click the  button. To manually change the explosion state, click and drag the scroll bar.
- 7 Click **OK** to close the **Explode** dialog.

The explode state remains displayed and the Transformation column  in the **Model Tree** is updated indicating the exploded parts.

**See Also *Resetting the Transformation of a 3D Model***

## Saving an Exploded View of a 3D Model

From the **Explode** dialog, you can save the exploded view of the 3D model.

- 1 Explode a 3D Model.  
**See *Exploding a 3D Model***
- 2 Click **Save View** in the **Explode** dialog.  
The **Add User Defined View** dialog appears.
- 3 Enter a **View Name**.
- 4 Click **OK**.  
The view is saved and appears in the **Views** tree under **User Defined Views**.
- 5 Click **OK** to close the **Explode** dialog.  
The exploded state is saved.  
**See Also *Resetting the Transformation of a 3D Model***

## User-defined Coordinate Systems

In AutoVue you have the option of creating customized three-axis coordinate systems. As with the **Global Axes** and the **World Coordinate System**, the user-defined axes are represented by a red X-axis, a green Y-axis and a yellow Z-axis.

When you set a User-defined Coordinate System (UCS) as the active axes, operations such as measuring, transforming a model, or defining a viewpoint are applied with respect to these axes.

You can create multiple UCS's for a 3D file. For multiple-page 3D files, you can even set active a different UCS for each page.

## Position Options

When defining a UCS, you can define the point where you want to place the user coordinate system. The options are:

Position	Description
(x, y, z) Coordinates	If selected, enter a value to specify where the three axes are positioned.

---

Position	Description
Vertex	If selected, all vertices are highlighted on the model. A snap box appears when you move the cursor on a vertex. Click the vertex point where you want to place the user coordinate system. The <b>x</b> , <b>y</b> and <b>z</b> coordinate values for the vertex are displayed. The UCS axes move to the new position.
Edge	If selected, all edges are highlighted on the model. A snap box appears when you move the cursor near an edge. Click at a point on an edge where you want to place the user coordinate system. The <b>x</b> , <b>y</b> and <b>z</b> coordinate values for the edge point are displayed. The UCS axes move to the new position.
Midedge	If selected, all edges are highlighted on the model. A snap box appears when you move the cursor near the halfway point of an edge. Click at the mid-edge point where you want to place the user coordinate system. The <b>x</b> , <b>y</b> and <b>z</b> coordinate values for the mid-edge point are displayed. The UCS axes move to the new position.
Arc Center	If selected, all arcs and circles are highlighted on the model. A snap box appears when you move the cursor near the center of a circle or arc. Click on the arc center where you want to place the user coordinate system. The <b>x</b> , <b>y</b> and <b>z</b> coordinate values for the arc center are displayed. The UCS axes move to the new position.
Face	If selected, when you move the cursor along a model face, the face is highlighted. Click at a point on the face where you want to place the user coordinate system. The <b>x</b> , <b>y</b> and <b>z</b> coordinate values for the arc center are displayed. The UCS axes move to the new position.

---

## Orientation Options

When defining a UCS, you can define the orientation for the coordinate system. The options are:

---

Position	Description
(x, y, z) Coordinates	If selected, enter a value to specify the UCS orientation according to one or more of the three axes.
Edge Tangent	If selected, all edges are highlighted on the model. A snap box appears when you move the cursor near an edge. First select the axis that will determine the UCS orientation. Click at a point on an edge to define the orientation. The <b>x</b> , <b>y</b> and <b>z</b> values for the edge point are displayed. The UCS axes are reoriented to the selected edge.
Face Normal	If selected, when you move the cursor along a model face, the face is highlighted. First select the axis that will determine the UCS orientation. Click at a point on a face to define the orientation. The <b>x</b> , <b>y</b> and <b>z</b> values for the face point are displayed. The UCS axes are reoriented to the selected face.
2 Vertices	If selected, all vertices are highlighted on the model. A snap box appears when you move the cursor on a vertex. First select the axis that will determine the UCS orientation. Click two vertex points to define the orientation. The <b>x</b> , <b>y</b> and <b>z</b> values for the vertices are displayed. The UCS axes are reoriented to the selected vertices.
3 Vertices	If selected, all vertices are highlighted on the model. A snap box appears when you move the cursor on a vertex. First select the axis that will determine the UCS orientation. Click three vertex points to define the orientation. The <b>x</b> , <b>y</b> and <b>z</b> values for the vertices are displayed. The UCS axes are reoriented to the selected vertices.

---

## Defining a User Coordinate System

- 1 Select **Analysis > User Coordinate Systems** from the AutoVue main menu.

The **User Coordinate Systems** dialog appears.

**Note** You can also click the User Coordinate Systems button  on the AutoVue toolbar.

- 2 Click **New**.

The name of the User-defined Coordinate System (**UCS1** for the first one) appears in the **Coordinate Systems** box.

- 3 To change the name, type the new **Name** that you want for the UCS.

- 4 Click the **Position** tab to define the origin of the UCS.

- 5 From the **Define from** drop-down list, select the point where you want the UCS axes to appear.

**See *Position Options***

- 6 Click the **Orientation** tab to define the orientation of the UCS.

- 7 From the **Define from** drop-down list, select the point where you want to orient the UCS.

**See *Orientation Options***

- 8 To hide the UCS axes on the model, clear the checkbox beside **Show Trihedron**. Enabled by default.

- 9 Click **OK**.

The newly active trihedral coordinate system appears bolder and larger and its name appears in the User Coordinate Systems drop-down list on the AutoVue toolbar.

**Note** If there is more than one coordinate system for this file, select which coordinate system the new UCS will be **Relative To**. Otherwise, the new UCS will be calculated with respect to the World Coordinate System.


- 10 Click **OK** to close the **User Coordinate Systems** dialog.

## Modifying a User-defined Coordinate System

- 1 Select **Analysis > User Coordinate Systems** from the AutoVue main menu.


The **User Coordinate Systems** dialog appears.


**Note** You can also click the User Coordinate Systems button  on the AutoVue toolbar.

- From the **Coordinate Systems** list, select the UCS that you want to modify.  
The settings you configured for the UCS are displayed.
- To change the **Name**, highlight the name and enter the new name.
- To change the **Position**, click the **Position** tab, then select the point where you want the UCS axes to appear from the **Define From** drop-down list.  
**See *Position Options***
- To change the **Orientation**, click the **Orientation** tab, then select the point where you want to orient the UCS from the **Define From** drop-down list.  
**See *Orientation Options***
- To show the UCS axes, select **Show Trihedron**. To hide the UCS axes, clear the checkmark.
- To change the UCS that it is relative to, select the UCS from the **Relative To** drop-down list.
- Click **OK** to close the **User Coordinate Systems** dialog.  
If you modified the **Position** or **Orientation**, the UCS axes dynamically move to the new position. A change in **Show Trihedron**, will make the UCS axes appear or disappear accordingly. A **Name** change, will display the new name in the **Coordinate Systems** list and in the drop-down list next to the UCS button  on the toolbar.


## Activating a Coordinate System

When you set a user-defined coordinate system (UCS) as the active axes, operations such as measuring, transforming a model or defining a viewpoint are applied with respect to these axes.

- From the **User Coordinate Systems** dialog, select the **Coordinate System** that you want to use.
- Click **Set Active**.
- Click **OK** to close the **User Coordinate Systems** dialog.  
The newly active trihedral coordinate system appears bolder and larger on the model and its name is displayed in the drop-down list next to the UCS button  on the AutoVue toolbar.

**Note** You can also set a different coordinate system from the **User Coordinate Systems** drop-down list next to the UCS button  on the toolbar.

## Deleting a User Coordinate System

- 1 From the **User Coordinate Systems** dialog, select the **Coordinate System** that you want to delete.
- 2 Click **Delete**.  
**Note** The UCS disappears from the list and from the **User Coordinate Systems** drop-down list next to the UCS button  on the toolbar.
- 3 Click **OK** to close the **User Coordinate Systems** dialog.

## Interference Checks

In AutoVue, you can check for spatial interference of any two model parts.

### Interference Check Options


With the **Interference Checking** option, you can perform different interference checks. These checks are:

Check	Description
All Against All	Check for interference of any of the parts in the model.
Set Against the Rest	Check where a model part or set of model parts interfere with other model part(s).
Set Against Itself	Check where a model part or set of model parts interfere with itself.
Set 1 Against Set 2	Check where a model part or set of model parts interfere with another model part or set of model parts.

### Performing an Interference Check

- 1 Select **Analysis > Interference Checking** from the AutoVue main menu.

The **Interference Checking** dialog appears.

**Note** You can also click the Interference Checking button  on the AutoVue toolbar.

- 2 Click the type of interference check that you want to perform.


**See *Interference Check Options***

- 3 If you selected **Set Against the Rest** or **Set Against Itself**, select one or more model parts on the model or from the **Model Tree**.


**Note** To select more than one model part, press the **Shift** or **Ctrl** key while selecting.

The model part(s) appear in the **Selected Set** list and are highlighted on the model and in the **Model Tree**.

**Note** To clear the last set of selected model part(s), click **Clear**.

- 4 If you selected **Set 1 Against Set 2**, click the **Set 1** arrow , then select one or more model parts on the model or from the **Model Tree**. The model part(s) appear in the **Set 1** list and are highlighted on the model and in the **Model Tree**.

**Note** To clear a selected part, press the **Ctrl** key and click on the part on the model. To clear the last set of selected model part(s), click **Clear**.

Click the **Set 2** arrow  then select one or more model parts on the model or from the **Model Tree**.

The model part(s) appear in the **Set 2** list and are highlighted in a different color on the model and in the **Model Tree**.

- 5 Enter a **Minimum Clearance Distance**. Default value is 0.

**Note** Adding a **Minimum Clearance Distance** not only checks if the two model parts interfere, but also checks if they are located within a set minimum distance.

- 6 From the **Units** drop-down list, select the unit for the clearance distance.

- 7 To configure the interference check results, click **Options**.

The **Options** dialog appears.

**See *Interference Check Results Options***

- 8 Click **Compute** in the **Interference Checking** dialog.

**Compute** button changes to **Stop**.

**Note** Section plane is not taken into consideration when computing an interface check.

**Note** To stop the Interference Checking process at any point, click **Stop**.

When the process is complete, all the instances of interfering pairs appear in the **Results** list. The number of interfering pairs found appears in the **Description** box.

**Note** To view a pair's interference information, click the corresponding **Results** line. The information appears in the **Description** box and AutoVue zooms into the interfering area.

- 9 To save the results, click **Export**.  
The **Export Results** dialog appears.
- 10 Specify the file name and the directory where you want to save the file.
- 11 Click **Save**.  
AutoVue saves the results in a **csv** (Comma Separated Values) file.  
**Note** To perform another interference check click **Reset**, then click the type of interference check.
- 12 Click **Close** to close the **Interference Checking** dialog.

## Interference Check Results Options

With AutoVue, you can configure the results of an Interference Check. The configuration options are:





- **Actions** - provides a close-up look at how model parts interfere
- **Selected Pair** - configure if the selected pair from the **Results** list should display opaque, transparent or hidden
- **The Rest** - configure if the other parts of the model should display transparent or hidden while the selected pair is displayed

Option	Select	Description
Actions	Zoom To	Once the interference check is computed and a result set is selected from the list of results, AutoVue zooms to the result.
	Show Intersection	Once the interference check is computed and a result set is selected from the list of results, AutoVue shows where the intersection of model parts occur.
Selected Pair	Opaque	The selected pair from the list of results appear opaque.
	Transparent	The selected pair from the list of results appear transparent.

Option	Select	Description
	Hide	The selected pair from the list of results appear hidden.
The Rest	Transparent	The rest of the model appears transparent while the selected pair is displayed.
	Hide	The rest of the model is hidden while the selected pair is displayed.

## Comparing 3D Files

AutoVue provides the ability to compare two 3D files or two sets of entities from the same file or different files and display color-coded comparative data. When you compare two files, AutoVue displays a **Compare Tree** and three windows, the first containing the base file, the second containing the file you compared the base against, and the third containing the comparison results.



The **Compare Tree** displays the model's hierarchy with a **State** column displaying different icons representing the results of the file comparison. The icons indicate if an model part has been added , modified , moved  deleted .

In the **Comparison Result** window, results are displayed in different colors to differentiate the results of the file comparison. The comparison options and corresponding colors are:

Option	Color	Description
View Additions	<b>Green</b>	Indicates that something has been added.
View Deletions	<b>Red</b>	Indicates that something has been deleted.
View Unchanged	<b>Blue</b>	Indicates that there is no change.

To compare files:

- 1 View the base file in AutoVue.
- 2 Select **Analysis > Compare** from the AutoVue main menu.  
The **Open** dialog appears.


- 3 Enter the **File name** or browse to locate the file you want to compare with the current active file.
- 4 Click **Open**.  
AutoVue displays the **Compare Tree** and three windows. The first window displays the base file, the second displays the compare file and the third displays the comparison results.
- 5 To view the properties of a modified or moved entity in the base file and in the compare file, select the modified  or moved  entity from the **Compare Tree**, then right-click and select **Entity 1 Properties**.  
The **Entity Properties** dialog appears displaying the properties of the entity in the base file.  
**See *Entity Properties***  
Select the entity again, then right-click and select **Entity 2 Properties**.  
The **Entity Properties** dialog display the properties of the entity in the compare file.
- 6 To compare the results of the entity in the base file to the compare file, select the entity from **Compare Tree**, then right-click and select **Compare results**.  
The **Compare results** dialog appears.  
To view the attribute differences, click **Attributes**.  
To view the transformation difference, click **Transformation**.  
**Note** If there are no attribute or transformation differences, the buttons are disabled.
- 7 Click **OK** to close the **Compare results** dialog.
- 8 To exit **Compare** mode, select **File > Exit Compare Mode** from the AutoVue main menu.  
The base file appears in the workspace.  
**Note** You can also exit **Compare** mode by right-clicking in any of the windows and selecting **Exit Compare Mode** from the pop-up menu.


## Comparing Entity Sets

From the file comparison, you can compare a set of entities from one file against a set of entities from the another file. You can also compare sets of entities from the same file.


- 1 Select the files you want to compare.  
**See *Comparing 3D Files***
- 2 Select **File > Compare Sets**.

The **Compare Sets** dialog appears.



- 3 Click  **Set 1**. Set by default.
- 4 Select the entities from either the tree on the left or the tree on the right.
 

**Note** The tree on the left is the base file and the tree on the right is the compare file.

The selected entities appear in the **Set 1** list.
- 5 Click  **Set 2** point.
- 6 Select the entities from the other tree that you did not select for **Set 1**.  
The selected entities appear in the **Set 2** list.
 


**Note** To compare entities from the same file, select the entities for **Set 1** and **Set 2** from either the base file or the compare file.
- 7 Click **OK**.  
The **Compare Tree** and the three windows are updated with the set comparison results.
- 8 To restore the comparison files, select **File > Compare Files**.  
The files appear in the three windows.

# Generating a Bill of Material

For 3D files, you can obtain a list with a count of the parts required for manufacturing the item featured in the file.

To generate a Bill of Material:

- 1 Select **Analysis > Bill of Material** from the AutoVue main menu. The **Bill of Material** dialog appears.



- 2 To sort the list numerically, click the **Count** column header. To sort the list alphabetically, click the **Part Names** column header.
- 3 To view a part or parts on the model, select the part(s) from the **Part Names** list.
 

**Note** To select more than one part, press the **Shift** or **Ctrl** key while selecting.

The parts are highlighted on the model and in the **Model Tree**.
- 4 To save the Bill of Material, click **Export**. The **Save As** dialog appears. Enter a **File name** or browse to locate the directory where you want to store the file, then click **Save**. AutoVue saves the results in a **csv** (Comma Separated Values) or **xml** file.
- 5 Click **Close** to close the **Bill of Material** dialog.

# Entity Search

AutoVue allows you to search for entities in a 3D Model using the **Entity Search** dialog. You can search the whole model or selected entities on the model, apply attributes, entity type or PMI filters as search criteria to filter entities. You can also search for entities by the size of an entity and location or select entities from the results list and have them appear highlighted in the workspace and in the **Model Tree**.


The **Search** options are:

Where	Option	Description
3D Search tab	Selection	Specify if you want to search the entire model or selected parts or parts that are not selected.
	Type	Specify the type of entity you want to search. For example, part, body, assembly or PMI.
	Show PMI parent entity in results	When selected, displays only the parent entity of a PMI entity that matches search criteria. If cleared, displays PMI entities that match search criteria in the <b>Results</b> dialog. <b>Note</b> Option is enabled if <b>Type</b> is set to <b>PMI</b> or <b>All</b> and file has PMI entities.
	PMI Filter	Filters the entities that have PMI information. <b>Note</b> Option is enabled if <b>Type</b> is set to <b>PMI</b> or <b>All</b> .
	PMI Type	Specify the specific PMI attribute you want to search. <b>Note</b> Option is disabled if <b>PMI Filter</b> is set to <b>All</b> .


Where	Option	Description
Attribute Filter dialog	Name	Specify the specific attribute you want to search. The available attributes are: <ul style="list-style-type: none"> <li>• Colour</li> <li>• Density</li> <li>• Display_Mode</li> <li>• Filepath</li> <li>• Layer_ID</li> <li>• Mesh_Resolution</li> <li>• Name</li> <li>• Shading_Style</li> <li>• Translucency</li> <li>• Visibility</li> </ul> <p><b>Note</b> Additional attributes may be available depending on the file selected.</p>
	Any Value	When selected, AutoVue searches for any value of the selected attribute. <p><b>Note</b> The attribute value options are disabled. If cleared, specify the values for the selected attribute you want to search.</p> <p><b>Note</b> The attribute value options correspond to the selected attribute.</p>
Advanced 3D Search tab	Volume	Specify the size of an entity, the minimum and maximum dimensions. The dimensions of an entity boundary box must be between the specified dimensions to meet the search criteria.
	Location	Specify an axes aligned boundary box. The boundary box of an entity must be inside it to meet the search criteria.

## Performing a Search

- 1 Select **Analysis > Entity Search** from the AutoVue menu. The **Entity Search** dialog appears.

**Note** You can also click the Entity Search button  on the AutoVue toolbar.

- Click the **3D Search** tab.



- From the **Selection** drop-down list, specify what parts of the model that you want to search.  
To search the entire model, select **All**.  
To search specific parts of a model, select **Selected** and then select the parts on the model.  
To search the model parts that are not selected, select **Not selected**.
- From the **Type** drop-down list, select the type of entity that you want to search.  
**Note** For 3D Models that have PMI information, the PMI search features are enabled.
- Select the checkbox beside **Show PMI parent entity in results** if you want only the parent entity of the selected PMI entity or entities to appear in the **Results** list.  
Clear the checkmark if you want all PMI entities to appear in the **Results** list.  
**Note** Option is enabled if **Type** is set to **PMI** or **All** and files has PMI entities.
- From the **PMI filter** drop-down list, select the type of entities that you want to search.  
To search all entities, select **All**.

To search entities with PMI, select **With PMI**.

To search entities without PMI, select **Without PMI**.

- From the **PMI type** drop-down list, select the type of entity that you want to search.

**Note** **PMI type** is disabled if **PMI Filter** is set to **All**.


**See** *Saving Search Results*

- Click **Close** to close the **Entity Search** dialog.

## Performing an Attribute-based Search

From the **3D Search** dialog, you can search for entities by their attributes, such as color, density, shading, etc.


- Select **Analysis > Entity Search** from the AutoVue menu.  
The **Entity Search** dialog appears.

**Note** You can also click the 3D Entity Search button  on the AutoVue toolbar.

- Click the **3D Search** tab.
- Select the search criteria that you want to use for your search.

**See** *Performing a Search*

- Click **Add**. The **Attribute Filter** dialog appears.




- From the **Name** drop-down list, select the attribute that you want to search.  
The **Value** group box appears corresponding to the selected attribute.
- Select the checkbox beside the **Any Value** if you want to search by any value. The **Value** options are disabled.

- 7 Clear the checkbox if you want to search by a specific value, then from the **Value** drop-down list(s), select the values that you want to search.
- 8 Click **OK**.  
**Note** To add more than one **Attribute Filter**, repeat steps 4 to 5.
- 9 To edit an **Attribute Filter**, select the filter and click **Edit**.  
The **Attribute Filter** dialog box appears allowing you to edit the filter.
- 10 To disable an **Attribute Filter**, clear the checkbox beside the filter(s) that you want to disable.  
To enable an **Attribute Filter**, select the checkbox beside the filter(s).
- 11 To remove an **Attribute Filter**, select the filter and click **Remove** in the **Entity Search** dialog.  
The **Attribute Filter** disappears from the list.
- 12 In the **Entity Browser**, click **Search**.  
A list of entities matching the search criteria appear in the **Results** list displaying the **Type** and **Name**.  
**See *Saving Search Results***
- 13 Click **Close** to close the **Entity Search** dialog.

## Performing an Advanced 3D Search

From the **3D Search** dialog, you can search for entities using volume or location filters. **Volume** specifies the size of the entity: you can specify the minimum and maximum dimensions an entity must be between. **Location** specifies an axes aligned boundary box: you can specify the dimensions for an axes aligned boundary box that an entity must be inside.

- 1 From the **Entity Search** dialog, click the **Advanced 3D Search** tab.



- 2 To search for entities by **Volume**, select the checkbox beside **Enabled**.  
**Note** If you want to search for entities that match all three dimensions, select the checkbox beside **Completely contained**. If the checkmark is cleared, then an entity only has to match one dimension in order to appear in the **Results** list.
- 3 Enter the **Minimum** and **Maximum Dimensions**.
- 4 From the **Units** drop-down list, select the unit you want to set for the **Volume** dimensions.
- 5 To search for entities by **Location**, select the checkbox beside **Enabled**.  
**Note** If you want to search for entities that match all three dimensions, select the checkbox beside **Fits completely**. If the checkmark is cleared, then an entity only has to match one dimension to appear in the **Results** list.
- 6 From the **Units** drop-down list, select the unit you want to set for the **Location** dimensions.
- 7 Enter the dimensions for **Point 1** and **Point 2**.
- 8 Click the **3D Search** tab.
- 9 Click **Search**.  
A list of entities matching the search criteria appears in the **Results** list.  
**See *Saving Search Results***

10 Click **Close** to close the **3D Search** dialog.




## Saving Search Results





- 1 Perform an 3D entity search.  
**See *Performing a Search***  
*Performing an Attribute-based Search*  
*Performing an Advanced Search*
- 2 Click **Search**.  
A list of entities matching the search criteria appear in the **Results** list displaying the **Type** and **Name**.
- 3 To save the results, click **Export**.  
The **Save As** dialog appears.
- 4 Specify the path where you want to store the file and enter the **File name**, then click **Save**.  
AutoVue saves the results in a **csv** (Comma Separated Values) file.

## Measuring in 3D Files

AutoVue provides the ability to perform measurements in 3D files. When measuring, AutoVue provides the option to “snap” to different entity types on the model.

You can access the measure options from the **Analysis > Measure** menu. The options are:




Button	Name	Description
	Angle	Measure the precise angle between any three vertices or any two edges, planes, faces or any combination of these entity types.
	Arc	Measure the precise radius, length and angle of any arc and calculate the center point.
	Distance	Measure the precise distance between any two vertices, edges, mid-edges, arc centers, faces or any combination of these entity types.

Button	Name	Description
	Minimum Distance	Measure minimum distance between any two vertices, edges, mid-edges, arc centers, faces or any combination of these entity types.
	Edge Length	Measure the precise length of a edge.
	Face Surface	Measure the precise surface area.
	Vertex Coordinates	Provide the coordinates of each vertex.

## 3D Snapping Modes

The **Snapping Modes** available allow you to select or snap to different entity types on a model. For example, if you select **Vertex**, all vertices are highlighted and when you move the cursor over a vertex, a snap box appears.




The **Snapping Modes** allow you to snap to vertices, edges, faces, planes and arcs.

Button	Snap to	Description
	Edge	Edges are highlighted on the model. When moving the cursor over an edge, a snap circle appears.
	Face	Faces are highlighted when you move the cursor over a face and a snap triangle appears.
	Vertex	Vertices are highlighted on the model. When moving the cursor over a vertex, a snap box appears.

## Measuring Distance

Use the **Distance** option to measure the precise distance between two vertices, edges, mid-edges, arc centers, faces or any combination of these entity types.

**Note** When measuring the distance between faces, if the faces are parallel, AutoVue compares the shortest distance between the faces.

- 1 Select **Analysis > Measure** from the AutoVue main menu.  
The **Measurement** dialog appears.  
**Note** You can also click the Distance button  on the AutoVue toolbar.
- 2 Click the **Distance** tab.
- 3 From the **Measured Distance Units** drop-down list, select the unit in which you want to measure.
- 4 Click the **From** arrow  to select the entity type that you want to measure from.
- 5 Select the **Snapping Modes** that you want to use for measuring.  
**See 3D Snapping Modes**  
All entities of the selected entity type are highlighted on the model.
- 6 On the model, select the entity you want to measure from.  
**Note** If you want to take more than one measurement from the same starting point, click **Fix Position**.
- 7 Click the **To** arrow  to select the entity type that you want to measure to.
- 8 Select the **Snapping Modes** that you want to select as the end point for the measurement.  
All entities of the selected entity type are highlighted on the model.
- 9 On the model, select the entity you want to measure to.  
The points are joined by a line. The measured distance, Delta X, Delta Y and Delta Z appear in the **Measurement** dialog.  
**Note** Click **Reset** to take another measurement.
- 10 Click **Close** to close the **Measurement** dialog.

## Calibrating Distance


- 1 Measure a distance.  
**See Measuring Distance**
- 2 In the **Measurement** dialog, click **Calibrate**.
- 3 The **Distance Calibration** dialog appears displaying the measured distance.
- 4 In the **Measured Dist** drop-down list, select the unit to which you want to calibrate the distance.
- 5 Click **Calibrate to** and enter a value if you want to calibrate the distance to a value.  
Click **Set Factor** and enter a value if you want to calibrate the distance by a factor.


- 6 Click **OK**.  
The calibration result appears in the **Measurement** dialog.
- 7 Click **Close** to close the **Measurement** dialog.

## Measuring Minimum Distance

With the **Minimum Distance** option you can measure the minimum distance between model parts, as well as any two points from the selection sets: vertices, edges, mid-edges, arc centers, faces or any combination of entity types.

- 1 Select **Analysis > Measure** from the AutoVue main menu.  
The **Measurement** dialog appears.

**Note** You can also click the Minimum Distance button  on the AutoVue toolbar.

- 2 Click the **Min. Distance** tab.
- 3 Click  **Set 1** point.
- 4 Click **Entity** if you want to measure the distance between model parts.  
**Snapping Modes** are disabled.  
Click **Geometry** if you want to measure the distance between entity types.  
**Snapping Modes** are enabled.
- 5 If you selected **Entity**, select a part or parts on the model.  
The model part(s) appears in the list under **Set 1** and are highlighted on the model and in the **Model Tree**.  
If you selected **Geometry**, select the **Snapping Modes** that you want to use for measuring.


### **See 3D Snapping Modes**

All entities of the selected entity type are highlighted on the model.

Select the entity or entities on the model.

The selected entities appears in the list under **Set 1** and are highlighted on the model.

**Note** To reset a **Set**, click **Clear**. To clear items from a **Set**, select the items and press the **Delete** key. To deselect a part or entity type on the model, press the **Ctrl** key and left-click the part or entity type.

- 6 Click  **Set 2** point.
- 7 Repeat step 5.  
The model part appears in the list under **Set 2**.
- 8 From the **Measured Min Distance** drop-down list, select the unit in which you want to measure the distance.
- 9 Click **Compute**.

The minimum distance from the first set of entities to the second set is highlighted by a line. The measured minimum distance, X, Y and Z coordinates for **Position1** and X, Y and Z coordinates for **Position2** appear in the **Measurement** dialog.


**Note** Click **Reset** to take another measurement.

- 10 Click **Close** to close the **Measurement** dialog.

## Measuring an Angle

Use the **Angle** option to measure the precise angle between any three vertices or any two edges, planes, faces or any combination of these entity types.

- 1 Select **Analysis > Measure** from the AutoVue main menu.  
The **Measurement** dialog appears.

**Note** You can also click the Angle button  on the AutoVue toolbar.

- 2 Click the **Angle** tab.
- 3 Select the **Snapping Modes** that you want to use for measuring.  
Entities of the selected types are highlighted on the model.  
**See 3D Snapping Modes**
- 4 To measure the angle between an entity type and a plane, select the checkbox beside **Plane**, then from the drop-down list select the plane.
- 5 From the **Measured Angle Units** drop-down list, select the unit in which you want to measure the angle.
- 6 Click two points on the model to define the angle.  
If you selected a **Plane**, click the vertex, edge or face whose angle you want to measure between the plane.  
Angle arms appears indicating the angle. The measurement appears in the **Measurement** dialog.


**Note** Click **Reset** to take another measurement.

- 7 Click **Close** to close the **Measurement** dialog.

## Measuring an Arc

Use the **Arc** option to measure the precise radius, length and angles of any arc on the model. You can also calculate the center point location.

- 1 Select **Analysis > Measure** from the AutoVue main menu.  
The **Measurement** dialog appears.

**Note** You can also click the Arc button  on the AutoVue toolbar.

- 2 Click the **Arc** tab.
- 3 Select **Arc Entity** if you want to measure a predefined arc. All arc and circles are highlighted on the model. **Snapping Modes** are disabled.
- 4 Select **From 3 Points** if you want to measure the arc between three points. **Snapping Modes** are enabled. Select the **Snapping Modes** that you want to use for measuring.  
**See 3D Snapping Modes**
- 5 From the **Arc Info Dist. Units** drop-down list, select the unit in which you want to measure the arc distance.
- 6 From the **Angles Units** drop-down list, select the unit in which you want to measure the angle.
- 7 If you selected **From 3 Points**, click three points to define the arc. The points are joined by an arc. The measurements for center point coordinates, radius, diameter, arc length, start and end of angle and sweep appear in the **Measurement** dialog. If you selected **Arc Entity**, click the edge of the arc that you want to measure. The arc is highlighted. The measurements for center point coordinates, radius, ratio, arc length, angles start, end and sweep appear in the **Measurement** dialog.  
**Note** Click **Reset** to take another measurement.
- 8 Click **Close** to close the **Measurement** dialog.


## Calibrating an Arc

- 1 Measure an arc.  
**See Measuring an Arc**
- 2 In the **Measurement** dialog, click **Calibrate**.
- 3 The **Radius Calibration** dialog appears displaying the measured distance.
- 4 From the **Measured Rad.** drop-down list, select the unit to which you want to calibrate the distance.
- 5 Click **Calibrate to** and enter a value if you want to calibrate to a value. Click **Set Factor** and enter a value if you want to calibrate by a factor.
- 6 Click **OK**.  
The calibration results appear in the **Measurement** dialog.
- 7 Click **Close** to close the **Measurement** dialog.

## Measuring Vertex Coordinates

The **Vertex Coordinates** option provides the coordinates of vertices on the model.

- 1 Select **Analysis > Measure** from the AutoVue main menu.  
The **Measurement** dialog appears.

**Note** You can also click the Vertex Coordinates button  on the AutoVue toolbar.

- 2 Click the **Vertex** tab.  
All vertices on the model are highlighted.
- 3 From the **Coordinates Units** drop-down list, select the unit in which you want to measure.
- 4 Move the cursor over the highlighted vertex that you want to measure.  
The **X**, **Y** and **Z** coordinates appear in a tooltip.
- 5 Select the vertex.  
The **X**, **Y** and **Z** coordinates appear in the **Measurement** dialog.


**Note** Click **Reset** to take another measurement.

- 6 Click **Close** to close the **Measurement** dialog.

## Measuring the Length of an Edge

Use the **Edge Length** option to measure the length of any edge on the model.

- 1 Select **Analysis > Measure** from the AutoVue main menu.  
The **Measurement** dialog appears.

**Note** You can also click the Edge Length button  on the AutoVue toolbar.

- 2 Click the **Edge Length** tab.  
All edges on the model are highlighted.
- 3 From the **Units** drop-down list, select the unit in which you want to measure the edge length.

**Note** If you want to cumulate the measurement of more than one edge, click **Cumulative**.

- 4 Click the edge that you want to measure.  
The edge length measurement appears in the **Measurement** dialog.


**Note** Click **Reset** to take another measurement.

- 5 Click **Close** to close the **Measurement** dialog.

## Measuring Face Surface

Use the **Surface** option to measure the surface area of a entity face or an entire entity on the model.

- 1 Select **Analysis > Measure** from the AutoVue main menu.  
The **Measurement** dialog appears.

**Note** You can also click the Face Surface button  on the AutoVue toolbar.

- 2 Click the **Surface** tab.  
Select **Face Surface** if you want to measure the surface area of a face on an entity.  
Select **Entity Surface** if you want to measure the surface area of an entire entity.
- 3 From the **Measure Surface Units** drop-down list, select the unit in which you want to measure the surface.  
**Note** If you want to cumulate the measurement of more than one surface, click **Cumulative**.
- 4 If you selected **Face Surface**, move the cursor on the model to highlight a face surface, then click the face surface that you want to measure.  
The face surface is highlighted. The measured surface appears in the **Measurement** dialog.
- 5 If you selected **Entity Surface**, click the entity that you want to measure.  
The entity, as well as all the faces belonging to the body are highlighted. The measured surface of the body appears in the **Measurement** dialog.
- 6 To measure the face surface of the entity, click on the highlighted body.  
A pop-up list appears displaying the entity and its parents.  
Select the entity or a parent from the pop-up list.  
The selected entity is highlighted and the measured surface appears in the **Measurement** dialog.  
**Note** To measure the face surface of a parent, select the parent from the pop-up list.  
**Note** Click **Reset** to take another measurement.
- 7 Click **Close** to close the **Measurement** dialog.

# Configuring AutoVue

Use the configuration options to configure the AutoVue workspace for different groups of file formats or for all files in general. For example, you can set different background colors for EDA, 2D, 3D, or Office files. You can also set paths to locate external resources such as fonts, symbols, or XREFS, or configure measurement options.

You can access the configuration options using the Configuration dialog. To open the Configuration dialog, select **Options > Configuration** from the AutoVue main menu.

For details on each configuration option, see:

## ***General Options***

### ***Configuring AutoVue for 2D Files***

### ***Configuring AutoVue for 3D Files***

### ***Configuring AutoVue for EDA Files***

### ***Configuring Background Colors for Graphic Files***

### ***Configuring Background Colors for Desktop Office***

## General Options

To access the **General** configuration options, select **Options > Configuration** from the main menu. In the **Configuration** dialog that appears, click **General** in the tree.

## Configuring Options for CAD Files

Configure how you want to display w.r.t. text, dimensions, line styles, and so on for CAD files.

---

<b>Option</b>	<b>Description</b>
Text	<ul style="list-style-type: none"><li>• Select to display text entities.</li><li>• Clear to hide text entities.</li></ul>
Dimensions	<ul style="list-style-type: none"><li>• Select to display all dimensional entities.</li><li>• Clear to hide simple dimension entities.</li></ul>

---

Option	Description
Line Weights	<ul style="list-style-type: none"> <li>Select to display varying line thicknesses.</li> <li>Clear to make all lines appear equal, with a width of 1 pixel. No line weights display for any line.</li> </ul>
Force to Black	<ul style="list-style-type: none"> <li>Select to force all colors of a drawing to black.</li> <li>Clear to display the file in color.</li> </ul>
Line Style	<ul style="list-style-type: none"> <li>Select to display dotted and dashed lines.</li> <li>Clear to display all lines as solid.</li> </ul>
Filling	<ul style="list-style-type: none"> <li>Select to display filled entities as filled rather than just an outline.</li> <li>Clear to hide filling for filled entities.</li> </ul>
Load External References	<ul style="list-style-type: none"> <li>Select to load Xrefs automatically.</li> <li>Clear to keep Xrefs from loading automatically.</li> </ul>

## Raster Files

Select **Full Resolution** to display raster files at full resolution, or select **Fit to Window** to display raster files to fit the current window.

## System options

Select **Enable system tray hibernation** if you want the AutoVue icon to remain in the system tray even after you close AutoVue. Double-clicking this icon lets you quickly reopen AutoVue, access recently-used files, and so on. To completely exit AutoVue when this option is selected, you need to right-click the AutoVue icon in the system tray and select **Close AutoVue**.

Clear **Enable system tray hibernation** if you want AutoVue to quit completely when you close it.

## Configuring Paths

Configure the paths for XRefs, fonts, symbols, or Markups.

When working with files that need external resources, such as fonts or XRefs, you may need to specify the path to these external resources if they do not exist in the same location as the base file.

You may also need to access symbol libraries that are stored in a non-default location or you may need to configure from where AutoVue reads and locates Markup files.

---

Path	Description
XRefs	The directory paths for any external reference files associated with 2D, 3D or EDA files. <b>See <i>Configuring Xref Paths</i></b>
Font	The directory paths for fonts required by AutoVue's vector files. <b>See <i>Configuring Font Paths</i></b>
Symbol	The directory path for symbol libraries used by AutoVue's Markup entities. <b>See <i>Configuring Symbol Paths</i></b>
Markup	The directory paths for Markup files. <b>See <i>Configuring Markup Paths</i></b>

---

## Configuring XRef Paths

**XRef Paths** are the directory paths for any external reference files associated with 2D, 3D or EDA files.

- 1 Select **Options > Configuration** from the main menu.  
The **Configuration** dialog appears.
- 2 Click **General > XRef Paths** in the tree.
- 3 Click the **Add** button  
The **Browse for Folder** dialog appears.
- 4 Enter the directory path, or scroll to locate the directory where the external reference files are located.
  - To make AutoVue locate all subdirectories below the current folder, type two asterisks (\*\*) at the end of the file path.  
For example, if you type C:\samples\\*\*, AutoVue browses all subdirectories below "samples".
  - To make AutoVue locate one subdirectory below the current folder, type one asterisk \* at the end of the file path.  
For example, if you type C:\samples\\*, AutoVue browses one subdirectory below "samples".
- 5 Click **OK**.

The directory path appears.

**Note** To add more than one path to the list, repeat steps 3 to 5.

- 6 To change the order, select the path you want to move, then click **Up** or **Down** to move the path to where you want it in the list.
- 7 To remove a path, select the path and click **Remove**.
- 8 Click **OK** to close the **Configuration** dialog.

## Configuring Font Paths


**Font Paths** are the directory paths for fonts required by 2D, 3D, EDA, or Office files.

- 1 Select **Options > Configuration** from the AutoVue main menu.  
The **Configuration** dialog appears.
- 2 Click the **General > Font Paths** in the tree.
- 3 Click the **Add** button.  
The **Browse for Folder** dialog appears.
- 4 Enter the directory path or scroll to locate the directory where the external font files are located.  
To browse all subdirectories below the current path, type two asterisks **\*\*** at the end of the file path.  
For example, **C:\samples\*\*** will result in browsing all subdirectories below “samples”.  
To browse one subdirectory below the current path, type one asterisk **\*** at the end of the file path.  
For example, **C:\samples\*** will result in browsing one subdirectory below “samples”.
- 5 Click **OK**.  
The directory path appears.  
**Note** To add more than one path to the list, repeat steps 3 to 5.
- 6 To change the order, select the path you want to move, then click **Up** or **Down** to move the path to where you want it in the list.
- 7 To remove a path, select the path and click **Remove**.  
The selected path disappears from the list.
- 8 Click **OK** to close the **Configuration** dialog.

## Configuring Symbol Paths


**Symbol Paths** are the directory paths for symbols libraries used by AutoVue’s Markup entities.

- 1 Select **Options > Configuration** from the AutoVue main menu.

- The **Configuration** dialog appears.
- Click **General > Symbol Paths** in the tree.
  - Select the **Auto** option if you want to use the default directory to store the Symbol libraries.
  - Select the **User-Defined** option if you want to select a directory to store the Symbol libraries. Enter the directory path where you want to store the Symbol files or click the Browse button  to locate the directory.
  - Click **OK** to close the **Configuration** dialog.

## Configuring Markup Paths

**Markup Paths** are the directory paths for Markup files associated with the currently loaded document.

- Select **Options > Configuration** from the AutoVue main menu. The **Configuration** dialog appears.
- Click **General > Markup Paths** in the tree.
- Select the **Auto** option if you want to use the default directory to store the Markup. AutoVue, by default, stores the Markup files in an **avred** subdirectory at the location of the base file.
- Select the **User-Defined** option if you want to select a directory to store the Markup. Enter the directory path where you want to store the Markup, or click the **Browse** button  to locate the directory. All markups will now be saved to and read from this new location.
- Click **OK** to close the **Configuration** dialog.

## Measurement

To access the common **Measurement** configuration options, select **Options > Configuration** from the main menu. In the **Configuration** dialog that appears, click **General > Measurement** in the tree to display the options you need.

The **Measurement** options let you define the default measurement units and the number of decimal places, as follows:

Option	Description
Significant Digits	Lets you specify the number of decimal digits displayed for each measurement. Enter a number from 1 to 18.
Defaults Units	Lets you specify the default unit for measuring.

## Configuring the Base Font for Text Files

- 1 Select **Options > Configuration** from the main menu.  
The **Configuration** dialog appears.
- 2 Select **General > Base Font** from the tree to display the options you need.
- 3 Select a font from the **Font** list.
- 4 Select **Regular, Bold, Italic,** or **Bold Italic** from the **Font Style** list.
- 5 Select a font size from the **Size** list.  
**Note** You can see a preview of the text in the **Sample** area.
- 6 Click **OK** to apply the font change and close the **Configuration** dialog.

## Configuring AutoVue for 2D Files

You can configure background color and snap settings for 2D files. To access the 2D configuration options, select **Options > Configuration** from the main menu. In the **Configuration** dialog that appears, click **2D** in the tree.

### Snap Settings

In measurement mode, when you move the cursor within a predetermined snap radius, the snap box appears for the entity to be selected. To change the snap radius, change the value in the **Snap Radius** field. The snap radius is configured in pixels.

Access this option from the **Configuration** dialog. Select **Options > Configuration** from the main menu, then click **2D** in the tree.

### Configuring Colors

The **Colors** settings let you modify colors for 2D files. In the **Configuration** dialog, select **2D > Colors** in the tree to display the following options:

Option	Description
Background	Change the color of the background for 2D files.
Measurement	Modify the color you want displayed when taking measurements on 2D files.

# Configuring AutoVue for 3D Files

In AutoVue, there are configuration options that you can set to customize the work environment when working with 3D files. To access the 3D configuration options, select **Options > Configuration** from the main menu. In the **Configuration** dialog that appears, click **3D** in the tree.

## Rendering

The **Rendering** options let you modify the manner in which the model is rendered. Changing these options affects the level of detailed displayed. The **Rendering** options are:

Option	Description
Smooth Shading	Set by default. Turning this option off renders curved surfaces of shaded models as a series of flat surfaces. The level of detail is thus reduced but render speed is increased. <b>Note</b> Only affects shaded models.
Back-Face Removal	If selected, instructs AutoVue not to render the back faces of the model being displayed. This increases the render speed but the model appears less realistic while in motion. <b>Note</b> Only affects shaded models.
Precise Hidden Line	Instruct AutoVue to precisely calculate and render all hidden lines in a model. <b>Note</b> Selecting this option decreases render speed.

## Dynamic Rendering

The **Dynamic Rendering** options let you select the rendering mode for a model in motion. The options you can select are:

Menu Option	Description
Fast Frame	Model spins or rotates at a fast rate. The level of detail is reduced, which enables faster rendering when the model is in motion.
Wire Frame	Model is displayed as wire framed during rotation or spinning.
Flat Shading	Smooth shading is not performed on curved surfaces while the model is in motion.
Wire Polygons	Render the model in wire polygon mode while in motion.
Vertex Cloud	Model is displayed as a skeleton of vertices when in motion.
Bounding Box	Model parts are enclosed by bounding boxes when the model is in motion.
Current Render Mode	Model is rendered in the same mode whether moving or static.

## Model

The **Model** configuration options let you specify if you want to load the Model in Mesh Mode or BREP mode and let you control the Mesh Resolution.

To access the Model configuration options, select **Options > Configuration** from the main menu. In the **Configuration** dialog that appears, click **3D > Model** in the tree.

## Loading

Select the **Load Mesh Data** option to load available mesh data. Clear **Load Mesh Data** to load BREP data.

**Note** You need to reload the file for your changes to take effect.

## Default Mesh Resolution

The **Default Mesh Resolution** slider lets you modify the number of polygons drawn when displaying a model. Drag the slider between **Low**, **Medium** and **High** resolution levels.

A low resolution level means fewer polygons are drawn giving lower detail and higher render speed.

**Note** The **Default Mesh Resolution** slider only affects shaded models and wire polygon mode.

## PMI Filtering

In the **Configuration** dialog, select **3D > PMI** in the tree to display the **PMI** options.

The **PMI Filtering** options let you configure which types of product and manufacturing information to display. The checkboxes in the **Tree** column let you select which PMI entity types display in the 3D model tree. The checkboxes in the **View** column let you select which PMI entity types display in the workspace. For more information on PMI Filtering, see **PMI Filtering**.

The following **PMI Text Rendering Style** options let you define the style for the PMI text:

---

Option	Description
Native Setting (from file)	PMI text displays with the default setting.
3D	PMI text displays in 3-dimensions. It may not always face you.
Flat-to-screen	PMI text always faces you.

---

## Configuring Color

With the **Color** options, you can configure the color to allow easier viewing of 3D file details. The Color options are grouped under **Common**, **Section Highlight**, and **Geometry Highlight**, as follows:

## Common

Option	Description
Background	Set the background color for 3D files.
Selection	Set the color when selecting a model or model parts.
Entity Default	Set the default color to use when the model color is not stored in the native file.
Measurement	Set the color for measurements.
Min. Distance Set 1	Set the color of the first set-point when measuring minimum distance.
Min. Distance Set 2	Set the color of the second set-point when measuring minimum distance.

## Section Highlight

Option	Description
Edges	Set the color for the section edges when defining Section Cut Options.
Fill	Set the fill color when defining Section Cut Options.

## Geometry Highlight

Option	Description
Vertex	Set the color for vertices when highlighted during measurement and markup.
Face	Set the color for faces when highlighted during measurement and markup.
Edge	Set the color for edges when highlighted during measurement and markup.

## Miscellaneous

In the Configuration dialog, select **3D > Miscellaneous** in the tree to display the Miscellaneous options.

### Display

The **Show Global Axes** option is active by default. Disable this option to remove the axes that display in the bottom-right corner of the workspace.

### Model Tree

Enter a different value in the **Tree Level** field to define the level at which you want the **Model Tree** to collapse when opening a 3D file. The default is 3 levels.

### Manipulator

Enable the **Align with current UCS** option to automatically align the manipulators with the current User-defined Coordinate System.

### Highlight Selection

The following **Highlight Selection** options let you define how AutoVue indicates that an object is selected.

---

Option	Description
Highlight Bounding Box	Selection is enclosed in a wireframe box.
Highlight Entity	Selection is indicated by changing color.

---

## Configuring AutoVue for EDA Files

In AutoVue, there are configuration options that allow you to customize your work environment when working with EDA files. To access the EDA configuration options, select **Options > Configuration** from the main menu. In the **Configuration** dialog that appears, click **EDA** in the tree.

*See **Customizing Selections***  
***Displaying Tooltips***  
***Modifying 3D View***  
***Synchronizing Layers when Comparing Files***  
***Configuring Zoom Behavior when Cross Probing***  
***Modifying Colors***

## Customizing Selections

Configure how you want selected components to be highlighted. Click **Options > Configuration** to open the Configuration dialog, then click **EDA** in the tree. There are two selection options: Highlight Entity and Dim Unselected.

- **Highlight Entity:** Activate this option to highlight all entities that you select. This option is enabled by default.  
**Note** The default highlight color is yellow. To change the highlight color, see **Modifying Colors**.
- **Dim Unselected:** Activate this option to dim all the entities that are not selected. Selected entities retain their original entity color.

**Note:** You can also select the **Dim Unselected** button  in the main toolbar.

When the Dim Unselected option is enabled, you can set the dimness level for entities that are not selected. Drag the slider to the right to increase the dimness level and to the left to decrease the dimness level. The icon to the right of the dimness settings in the Configuration dialog lets you preview the dimness level.

## Displaying Tooltips

When you hover the mouse over an entity, a tooltip appears to show you information about the entity. You can disable or enable these tooltips.

- 1 Click **Options > Configuration** to open the Configuration dialog.
- 2 Click **EDA** in the tree.
- 3 Under the Mouse Hover heading, select or clear the **Show Entity Information Tooltip** option.
- 4 Click **OK**.

## Modifying 3D View

You can configure the 3D PCB view of EDA files.

**Note** The Default Board Thickness and Component Height values are read-only if the EDA 3D file does not contain board and component information.

- 1 Click **Options > Configuration** to open the Configuration dialog.
- 2 Click **EDA** in the tree.
- 3 Enter a value in the **Default Board Thickness** field to change the board's thickness.

**Note** The Default Board Thickness option only affects boards that have no board thickness defined in the design. If a board has a defined thickness, this option does not affect that board.

- 4 Enter a value in the **Default Component Height** field to change the component height.

**Note** The Default Component Height option affects components that do not have height defined in the design. If a component has a defined height, this option does not affect that component.

- 5 To work with a different unit of measurement, select another unit from the **Default Units** menu. This is the unit of measurement used for values set in the Default Board Thickness and Default Component Height fields.
- 6 Reload the file to see your changes.

## Synchronizing Layers when Comparing Files

When you compare files, you can synchronize all layer settings. When the layer settings are synchronized, changing one setting changes the same setting for both files you are comparing.

- 1 Click **Options > Configuration** to open the Configuration dialog.
- 2 Click **EDA > Analysis** in the tree.
- 3 Activate the **Layers Settings** option to synchronize all layer settings when comparing files.

**Note:** This option is only applicable for PCB drawings.

## Configuring Zoom Behavior when Cross Probing

You can configure the zoom options when you cross probe files.

- 1 Click **Options > Configuration** to open the Configuration dialog.
- 2 Select **EDA > Analysis** in the tree.
- 3 Select one of the following Cross Probe options:

- Click **Keep Current Zoom Level**. When this option is active, the view of the target files remains the same while you cross probe.
  - Click **Zoom Selected** to automatically zoom in on selected entities while you cross probe. This option is enabled by default.
  - Click **Zoom Fit** to automatically adjust the contents of a file along the horizontal or vertical axis to fully display within the current window.
- 4 Click **OK**.

## Modifying Colors

You can configure the colors for EDA files. To access these options, click **Options > Configuration** to open the Configuration dialog, then click **EDA > Colors** in the tree.

In the **Color Options** dialog, the options that you can configure are grouped under **Common** and **3D View** as follows:

### Common

Option	Description
Background	Change the background color for EDA files.
Selection	Configure the color used to highlight entities.
Min. Distance Set 1	Configure the color of the first selection set point when measuring minimum distance.
Min. Distance Set 2	Configure the color of the second selection set point when measuring minimum distance.

---

## 3D View

---

Option	Description
Default Board Color	Configure the color of the board in 3D view.
Default Component Color	Configure the component color in 3D view.

---

## Configuring Background Colors for Graphic Files

Specify background colors for mono raster files and color raster files.

To access these configuration options, select **Options > Configuration** from the main menu. In the **Configuration** dialog that appears, click **Graphics** in the tree.

## Configuring Background Colors for Desktop Office

Specify background colors for the following types of Desktop Office files:


- Document
- Spreadsheet
- Database
- Archive

To access these configuration options, select **Options > Configuration** from the main menu. In the **Configuration** dialog that appears, click **Desktop Office** in the tree.

# Markups

AutoVue has the ability to view over 450 different file formats and to create markups for all its readable file formats without the document's authoring application.

Marking up refers to drawing and writing on an electronic document. AutoVue provides the ability to markup different formats without modifying the original file. When you create a markup for a file, the markup is created on top of the original file. Markups are saved in separate files.

If a file has existing markup files, a red light bulb  appears on the status bar at the bottom of the AutoVue workspace. Clicking this button opens the **Markup Files** dialog allowing you to select markup files to open or create a new markup file. When you open a markup file, AutoVue lays the markup over the original file.

In Markup mode you can:

- create entities such as arcs, boxes, circles, clouds, lines, arrows and polygons
- add a symbol, add information to an entity by adding text or a note
- create, name and color layers to organize your work
- create a new markup file that combines copies of selected layers of different markup files
- create measurement markup entities that can be moved or resized
- navigate markups through a hierarchy tree, view markup properties and sort the tree according to each property
- view markup layers individually or in combination

**Note** Markup capability is only available in certain versions of the AutoVue product. See the **Product Variations Checklist** for more information.

## Markup Navigation Tree

When opening a file in **Markup** mode, a **Markup Navigation Tree** appears to the left of the document. If the **Markup Navigation Tree** does not appear, select **View > Show Model Tree**, then click the **Markups** tab.

The **Markup Navigation Tree** displays a hierarchy tree of markups or comments created by users. You can navigate through the markups. A set of


properties are generated for each markup. You can sort the markups in the tree according to each property by clicking the column headers. These properties are:

Property	Description
Entity	Type of markup entity created.
Author	The name of the user who created the markup.
Last Modified	The date and time the markup was modified.
Page	Page number of the original document on which the markup entity is created.
Layer	Markup layer on which the markup entity is created.

When a markup entity is created, it appears in the **Markup Navigation Tree** and the information is recorded and saved in the markup file.

**Note** Hover your mouse over an entity to see its Author and Date properties appear in a tooltip.

To see more markup properties or to expand the tree, click and drag the **Markup Navigation Tree** window. You can also drag the column headers left or right to resize the columns. Click the column headers to sort the markups in the tree.



# Working with Markup Files

Markup files are divided into uniquely named layers. Create, name and color layers to organize your work. For example, different colors can indicate time priorities and each layer can contain Markups related to a common purpose.


## Saved States

When you create and save a Markup file, you also save the view state, such as the zoom level at which you are working. If you save the Markup file while you are working at your preferred zoom level, the next time you open the Markup it displays at the same zoom level. Some examples of view states include zoom level (extents), rotation and flip settings, transformation, section plane and visibility. When creating Markups for 3D files containing imported models, the imported design becomes part of the view state. For more information on 3D view states, *see **Creating a User-defined View***.

State information is also saved with each markup entity. For instance, if you were at a certain zoom level when you created a markup entity, AutoVue saves the information with the markup entity. To “Go To” the state you were at when you created or modified the markup entity, select the markup entity and select **Go To**.

## Creating a Markup File

- 1 View a file that you want to markup.
- 2 Select **File > Markup** from the AutoVue main menu.

**Note** You can also click the Markup button  in the AutoVue main toolbar.

AutoVue enters **Markup** mode and a new Markup file appears in the Markup Navigation tree.

**See Also** *Creating a Markup Layer*

## Entering Markup Information

In AutoVue, when creating a Markup you can provide user information that you can save with the Markup.


- 1 Select **Markup > Information** from the main menu.  
The **Markup Information** dialog appears.
- 2 Enter a **User** name.

- 3 Enter a **Department**.
- 4 Enter a **Company** name.
- 5 Enter the **Location** of the Company.
- 6 Enter a **Telephone** number.
- 7 Click **OK**.  
The Markup Information is saved.

## Saving a New Markup File

- 1 Select **File > Save As** from the AutoVue main menu.  
The **Save Markup File As** dialog appears.  
The **Markup Information** that you entered when creating the Markup displays in the dialog.
- 2 Enter a **Markup ID** consisting of any combination of characters or numbers.
- 3 Click **OK**.  
The Markup file is saved and remains displayed in the workspace.

## Opening Markup Files

- 1 View a file that has existing markups.
- 2 Click the red lightbulb button  in the bottom-left corner of the status bar.  
**Note:** If this button does not display, the file you opened has no existing markups associated to it.  
The **Markup Files** dialog appears.
- 3 From the **Markup list**, select the checkbox beside the markup(s) that you want to open.  
**Note:** If you select more than one Markup, the **Active Markup** menu lets you select which one of them is initially active.
- 4 Click **OK**.  
The selected markup(s) appear in the workspace on top of the original file.  
**Note:** When you select more than one markup file, the markups display simultaneously.  
**See Also** *Setting the Active Markup File*

## Saving an Existing Markup File

- 1 Modify the markup file.
- 2 Select **File > Save** from the AutoVue main menu.

**Note** If you have multiple markups open that you have modified and want to save them all, select **File > Save All**.

**Note** To save an existing Markup as a new Markup, select **File > Save As**.

## Importing a Markup File

- 1 Select **File > Open** from **Markup** mode.
- 2 In the **Markup Files** dialog that appears, click **Import**.  
The **Select markup file to import** dialog appears.
- 3 Navigate to the markup file that you want to import and select it.
- 4 Click **Open**.  
The imported Markup file appears in the workspace on top of the original file.

## Exporting a Markup File

- 1 In Markup mode, select **File > Save As**.  
**Note** For a new Markup file, select **File > Save**.
- 2 Click **Export**.  
The **Select markup file export to** dialog appears.
- 3 Navigate and select the directory you want to export the markup file to.
- 4 Enter **File name**.
- 5 Click **Save**.  
The markup file is exported to the selected directory.  
**Note** The default format saved is **Markup Files (\*.\*)**, but you can select another one. In the **Save as type** drop-down list, there are six formats to choose from: Markup Files (\*.\*), DXF Output (\*.dxf), AutoCAD DWG R12 (.dwg), AutoCAD DWG R13 (.dwg), AutoCAD DWG 14 (.dwg) and Microstation DGN Output (\*.dgn).

## Setting the Active Markup File

A file can have several markup files. When you open several markup files simultaneously, you can set one of the markups as the active markup. Any changes you make is applied to the current active markup.

- 1 In Markup Mode, select **File > Open**.  
The **Markup Files** dialog appears.
- 2 Click the checkbox beside the markups you want to open.

The **Active Markup** drop-down list appears when you select more than one markup.

- From the **Active Markup** drop-down list, select the markup you want to make active.

**Note:** An active markup displays in bold in the **Markup Navigation Tree**.

- Click **OK**.

The selected markup appears in the AutoVue workspace.


## Changing the Active Markup File

When you have multiple markup files open, you can change the active markup.

**Note:** An active markup displays in bold in the **Markup Navigation Tree**.

Take one of the following steps:

- In the Markup Navigation Tree, right-click the name of the markup file you want to make active, then select **Set Active** from the menu.
- You can set the active markup by selecting a markup from the drop-down list on the Markup toolbar.



- Take the following steps:
  - Select **File > Set Active** from the Markup menu.
  - In the **Set Active Markup** dialog appears, select the markup you want to make active from the **Select Active Markup** drop-down list.
  - Click **OK** to make the selected markup file active.

# Markup Layers


Markup files can be divided into layers with each layer having its own unique name. You can create, name and color layers to organize your work. For example, different colors can indicate time priorities and each layer can contain markups relating to a common purpose.

When working with markup layers, you can view layers individually or in combination, add, rename or delete layers. You can also specify a different color for each layer; default layer color is red.

## Creating a Markup Layer

**Note** Ensure that no markup entity is selected when creating a markup layer.

- 1 Select **Markup > Markup Layers** from the Markup menu.  
The **Markup Layers** dialog appears.

**Note** You can also click the Markup Layers button  on the Markup toolbar.

- 2 In the **Markup Layers** dialog, click **New**.  
The **New Markup Layer** dialog appears.
- 3 Enter the name that you want for the markup layer.
- 4 Click **OK**.  
The new markup layer is added to the list in the **Markup Layers** dialog.
- 5 To change the color of the new layer, click **Color** in the **Markup Layer** dialog.  
The **Layer Color** dialog appears. Select a **Color**, then click **OK**.
- 6 Click **OK** to close the **Markup Layers** dialog.

## Setting the Active Markup Layer

A markup can have several layers and you can set a layer as the active markup layer. When a markup layer is active, all modifications you make are applied to that markup layer.

**Note** Ensure that no markup entity is selected when setting the active markup layer.

- 1 Select **Markup > Markup Layers** from the Markup menu.  
The **Markup Layers** dialog appears.

**Note** You can also click the Markup Layers button  on the Markup toolbar.


- 2 From the **Markup Layers** list, select the checkbox beside the layer you want to make active.
- 3 Click **OK**.  
The selected Markup layer appears in the workspace.

## Changing the Active Markup Layer

When you have multiple markup layers, you can change the active layer to another layer.

- 1 Select **Markup > Markup Layers** from the Markup menu.  
The **Markup Layers** dialog box appears.
- 2 From the **Currently Active Layer** drop-down list, select the layer you want to make active.
- 3 Click **OK**.  
The selected layer appears in the workspace.

You can also change the active layer by selecting the layer from the drop-down list on the Markup toolbar.



## Changing the Color of a Markup Layer


**Note** Ensure that no markup entity is selected when changing the color of a markup layer.

- 1 Select **Markup > Markup Layers** from the Markup menu.  
The **Markup Layers** dialog appears.

**Note** You can also click the Markup Layers button  from the Markup toolbar.

- 2 Select the markup layer that you want to change the color.
- 3 Click **Color**.  
The **Layer Color** dialog appears.
- 4 Select a **Color**.


- 5 Click **OK**.

**Note** Only the entities that were created with the by-layer  color defined in the **Markup Layers** dialog will change color. Any entities that were created using the color options from the Markup toolbar, will override the by-layer color and will not change color.

- 6 Click **OK** to close the **Markup Layers** dialog.

## Renaming a Markup Layer

- 1 Select **Markup > Markup Layers** from the Markup menu.  
The **Markup Layers** dialog appears.

**Note** You can also click the Markup Layers button  from the Markup toolbar.

- 2 Under **Markup Layers**, select the checkbox beside the markup layer you want to rename.
- 3 Click **Rename**.  
The **New Markup Layer** dialog appears.
- 4 Enter the new layer name.
- 5 Click **OK**.  
The markup layer is assigned the new name.
- 6 Click **OK** to close the **Markup Layers** dialog.

## Toggling Markup Layers

From the **Markup Layers** dialog, you can turn a layer's visibility on and off, even if there is only one layer. Turning a layer's visibility off, hides all markups belonging to that layer.

- 1 Select **Markup > Markup Layers** from the Markup menu.  
The **Markup Layers** dialog appears.

**Note** You can also click the Markup Layers button  from the Markup toolbar.

- 2 Under **Markup Layers**, select the layer(s) you want visible.
- 3 Click **Toggle**.  
A checkmark appears beside the selected layers.
- 4 To hide a layer, select the layer(s) with a checkmark, then click **Toggle** again.

**Note** You can also view a layer by selecting the checkbox beside it. To hide a layer, clear the checkmark. To view all the Markup layers, click **All On**. To hide all Markup layers click **All Off**.

- 5 Click **OK**.

The markup entities belonging to the selected layer(s) appear in the workspace on top of the original file.

## Deleting a Markup Layer

- 1 Select **Markup > Markup Layers** from the Markup menu. The **Markup Layers** dialog appears.

**Note** You can also click the Markup Layers button  from the Markup toolbar.

- 2 From the **Markup Layers** list, select the checkbox beside the markup layer you want to delete.


**Note** You can select more than one layer to delete at the same time.

- 3 Click **Delete**.
- 4 Click **OK**.

The layer is deleted along with all entities belonging to the layer.


## Moving a Markup Entity to Another Layer

- 1 Select the entity or entities that you want to move.
- 2 Select **Markup > Markup Layers** from the Markup menu. The **Move to Layer** dialog appears.

**Note** You can also click the Layer button  on the Markup toolbar.

- 3 Select the **Layer** you want to move the entity or entities to.
- 4 Click **OK**.

The selected entity or entities are moved to the selected layer.

**Note** Only the entities that were created with the  **By Layer** color defined in the **Markup Layers** dialog will change color. Any entities that were created using the color options from the Markup toolbar, will override the by-layer color and will not change color.

# Consolidating Markup Files

The **Consolidate** option allows you to create a new markup file that combines copies of selected layers of different markup files. During the review cycle, consolidation simplifies document revisions by providing the author with one combined markup file instead of several markup files.

**Note** The **Consolidate** option is only active when more than one markup file is opened.

- 1 Open the markup files that you want to consolidate.
- 2 Select **File > Consolidate** from the Markup menu.  
The **Consolidate Markups** dialog appears.
- 3 Select the markup layers that you want to consolidate into one file.
- 4 Enter a **Markup ID** for the new markup file.
- 5 If you want to open the newly consolidated markup as the active markup, select the **Open as active markup** option.
- 6 Click **OK**.  
The consolidated markup file is saved. If you selected **Open as active markup**, the consolidated markup opens and is set as the active markup.







# Modifying Markup Entities

With AutoVue, you can assign an entity its own color, the same color as the current active layer or create a custom color. You also have the option of grouping Markup entities. When you group Markup entities, you can manage the group as you would a single entity.

In Markup mode, there are several options for modifying an entity. You can apply these options to selected entities while you specify the change or new entities that you add.

The modify options can be accessed from the **Markup** menu in Markup mode. The options are:

Option	Description
Delete	Delete a selected markup entity or entities.
Delete All	Delete all markup entities.
Delete Dimensions	Delete all markup measure entities. <b>See <i>Deleting Markup Measure Entities</i></b>

Option	Description
Hide Dimensions	Hide all markup measure entities. <b>See <i>Hiding Markup Measure Entities</i></b>
Group or Ungroup	Group or ungroup markup entities. <b>See <i>Grouping Markup Entities</i></b>
Line Style	Change the line style for a selected markup entity or entities. Click the Line Style button  in the toolbar. <b>See <i>Changing the Line Style</i></b>
Line Thickness	Change the line thickness for a selected markup entity or entities. Click the Line Thickness button  in the toolbar. <b>See <i>Changing the Line Thickness</i></b>
Arrow Style	Add an arrow head at one or both ends of a markup line entity. Click the Arrow Style button  in the toolbar. <b>See <i>Changing the Arrow Style</i></b>
Fill Type	Change the transparency for selected markup entity or entities. Click the Fill Type button  in the toolbar. <b>See <i>Changing the Fill Type of An Entity</i></b>
Entity Color	Change the line color, fill color and fill type for a selected markup entity or entities. Click the Line Color button  in the toolbar to change the line color. <b>See <i>Changing the Line Color of An Entity</i></b> Click the Fill Color button  in the toolbar to change the fill color. <b>See <i>Changing the Fill Color of An Entity</i></b>
Markup Entity Properties	Open the Markup Entity Properties dialog, which lets you see and modify markup entity properties from one dialog. <b>See <i>Modifying Markup Entity Properties</i></b>

---

Option	Description
Hide Markups	Hide all markup entities.

---


## “Go To” a Markup Entity

**Go To** restores the view state when a created entity is saved. Opening an existing markup for a file also restores the last saved view state.

- 1 From the **Markup Navigation Tree**, select the markup entity that you want to view.
- 2 Right-click and select **Go To** from the drop-down menu. AutoVue displays the markup page containing the entity.

**Note** If you selected a Markup entity that is on another page of the Markup, the page containing that entity will be displayed.

## Selecting Markup Entities

- 1 Click the Select button  from the Markup toolbar, then from the workspace click the entity's outer edge.

**Note** You can also select the entity from the **Markup Navigation Tree**.

**Note** To select multiple entities, press the **Shift** or **Ctrl** key while selecting.

## Moving a Markup Entity

- 1 In the **Markup Navigation Tree** or in the workspace, select the entity or entities that you want to move.  
**See *Selecting Markup Entities***
- 2 In the workspace, click and drag the selected entity or entities to anywhere in the workspace.

## Editing a Markup Entity

The entities that you can edit are notes, text, dimensions, leaders and hyperlinks.

- 1 In the **Markup Navigation Tree** or from the workspace, double-click the entity that you want to edit. AutoVue zooms in on the entity and the appropriate dialog appears allowing you to make changes to the entity.

**Note** You can also edit an entity by right-clicking it in the **Markup Navigation Tree** and selecting **Edit** from the pop-up menu.

## Grouping Markup Entities

When you group markup entities, you can move, delete, copy and paste, resize, or perform any modification on the group of entities that you would on a single markup entity.

- 1 In the **Markup Navigation Tree** or from the workspace, select the entities that you want to group.  
**See *Selecting Markup Entities***
- 2 Select **Markup > Group** from the Markup menu.  
The group of entities appear on the **Markup Navigation Tree** as a **Group**.
- 3 Perform any modifications.  
The modifications are applied to all the entities in the group.

## Ungrouping Markup Entities

- 1 In the **Markup Navigation Tree** or the workspace, select the **Group** that you want to ungroup.
- 2 Select **Markup > Ungroup** from the Markup menu.  
The group of entities appear on the markup as individual entities.

## Hiding Markup Entities

To hide the Markup entities of a markup file, take one of the following steps:

- In the Markup Navigation Tree, right-click the markup file, then select **Hide**.  
**Note** To show hidden Markups, right-click the file name again and select **Show**.
- Select **Markup > Hide Markups** from the Markup menu.  
The markup entities are hidden on the markup file.  
**Note** To “unhide” markups, select **Markup > Hide Markups** again from the Markup menu.

## Changing Line Thickness of an Entity

**Note** A checkmark beside the thickness option indicates the current line thickness.

- 1 Select the entity or entities for which you want to change the line thickness.  
**See *Selecting Markup Entities***
- 2 From the Markup menu, select **Markup > Line Thickness** and the line thickness that you want.  
The line thickness changes for the selected entity or entities.

**Note** You can also click the Line Thickness button  on the Markup toolbar.

- 3 To define a custom line thickness, select **Modify > Custom Thickness** from the Markup menu.  
The **Custom Thickness** dialog appears.
- 4 Enter an integer value in pixels.
- 5 Click **OK** to close the **Custom Thickness** dialog.  
**Note** Any new entities that you create will have the new line thickness.  
**See Also *Modifying Markup Entity Properties***

## Changing Line Style of an Entity

**Note** A checkmark beside the style option indicates the current line style.


- 1 Select the entity or entities for which you want to change the line style.  
**See *Selecting Markup Entities***
- 2 From the Markup menu, select **Markup > Line Style** and the line style that you want.  
The line style changes for the selected entity or entities.

**Note** You can also click the Line Style button  on the Markup toolbar.

**Note** Any new entities that you create will have the new line style.




**See Also *Modifying Markup Entity Properties***

## Changing the Arrow Style


- 1 Select the line entity or entities for which you want to change the arrow style.  
**See *Selecting Markup Entities***
- 2 Take one of the following steps:
  - Right-click the entity and select **Arrow Style** from the menu.
  - Click the Arrow Style button  in the toolbar.
  - Select **Markup > Arrow Style** from the main menu.


- 3 From the **Arrow Style** drop-down list, select the style of arrow that you want for the entity.  
You have the choice between no arrow heads, an arrow head at either one or the other end of the line entity, or arrow heads at both ends of the line entity. The arrow style changes for the selected line entity or entities.  
**Note** Any new entities that you create will have the new arrow style.  
**See Also** *Modifying Markup Entity Properties*

## Changing Line Color of an Entity


- 1 Select the entity or entities for which you want to change the line color.  
**See** *Selecting Markup Entities*
- 2 Select **Markup > Entity Color** from the Markup menu.  
The **Entity Color** dialog appears.  
**Note** You can also click the **Line Color** button  on the Markup toolbar.
- 3 From the **Line Color** drop-down list, select the color that you want for the entity.  
**Note** Selecting **By Layer**  changes the entity color to the color of the layer.
- 4 To define a custom line color, select **Custom Color**  from the **Line Color** drop-down list.
- 5 From the **Color** dialog that appears, select a color and click **OK**.
- 6 Click **OK** to close the **Entity Color** dialog.  
The line color changes for the selected entity or entities.  
**Note** Any new entities that you create will have the new line color.  
**See Also** *Modifying Markup Entity Properties*

## Changing Fill Color of an Entity

- 1 Select the entity or entities for which you want to change the fill color.  
**See** *Selecting Markup Entities*
- 2 Select **Markup > Entity Color** from the Markup menu.  
The **Entity Color** dialog appears.  
**Note** You can also click the Fill Color button  on the Markup toolbar.


- 3 From the **Fill Color** drop-down list, select the color that you want for the entity.  
**Note** Selecting  **By Layer** changes the entity color to the color of the layer.
- 4 To define your own color, select **Custom Color**  from the **Fill Color** drop-down list.
- 5 From the **Color** dialog that appears, select a color and click **OK**.  
The fill color changes for the selected entity or entities.
- 6 Click **OK** to close the **Entity Color** dialog.  
**Note** Any new entities that you create will have the new fill color.  
**See Also** *Modifying Markup Entity Properties*


## Changing Fill Type of an Entity

- 1 Select the entity or entities for which you want to change the fill type.  
**See** *Selecting Markup Entities*
- 2 Select **Markup > Entity Color** from the Markup menu.  
The **Entity Color** dialog appears.  
**Note** You can also click the Fill Type button  on the Markup toolbar.
- 3 From the **Fill Type** drop-down list, select the fill type that you want for the entity.  
Select **Solid Fill**, if you want the fill color to be solid.  
Select **Transparent Fill**, if you want the fill color to be transparent.  
Select **No Fill**, if you do not want any fill color.
- 4 Click **OK**.  
The fill type changes for the selected entity or entities.  
**Note** Any new entities that you create will have the new fill type.  
**See Also** *Modifying Markup Entity Properties*

## Assigning an Entity the Same Color as the Layer

- 1 Select the entity or entities for which you want to assign the color of the layer that they belong to.  
**See** *Selecting Markup Entities*
- 2 Select **Markup > Entity Color** from the Markup menu.  
The **Entity Color** dialog appears.

- 3 To assign the line color, select the  **BYLAYER** from the **Line Color** drop-down list.

**Note** You can also click the Line Color button  from the Markup toolbar.

- 4 To assign the fill color, select the  **BYLAYER** from the **Fill Color** drop-down list.

**Note** You can also click the Fill Color button  from the Markup toolbar.

- 5 Click **OK**.

The selected entity or entities change to the color of the layer that the entity belongs to.

## Deleting Markup Entities

- 1 Select the entity or entities that you want to delete.

**See** *Selecting Markup Entities*

- 2 Select **Markup > Delete** from the Markup menu.

The selected entity or entities are deleted from the current active file.

**Note** To delete all entities, select **Markup > Delete All** from the Markup menu. **Delete All** will delete all existing entities from the active markup, whether they are visible or not.

## Modifying Measurement Markup Entities

In AutoVue, you can modify the font of a measurement.

- 1 Create the markup measure entity that you want.

**See** *Creating 2D non-vector Markup Measure Entities*

*Creating 2D Vector Markup Measure Entities*

*Creating EDA Markup Measure Entities*

*Creating 3D Markup Measure Entities*

- 2 Double-click the measurement for which you want to modify the font.

The appropriate **Measure** dialog appears.

- 3 Click **Font**. The **Font** dialog appears.

From the **Font** drop-down list, select the type of font.

From the **Size** drop-down list, select the size of font.

- Select the font **Style(s)**, then click **OK**.
- Click **OK** to close the appropriate **Measure** dialog.  
The measurement font is modified.

## Changing Measurement Units and Symbols

In AutoVue, you can change the unit of measure and add a symbol to a measurement and have it appear on the drawing.

- Create the markup measure entity that you want.  
**See** *Creating 2D non-vector Markup Measure Entities*  
*Creating 2D Vector Markup Measure Entities*  
*Creating EDA Markup Measure Entities*  
*Creating 3D Markup Measure Entities*
- Double-click the measurement that you want to change the unit of measure or add a symbol to.  
The appropriate **Measure** dialog appears.
- Clear the checkmark beside **Display Unit** if you want to hide the unit on the drawing. Unit appears by default.
- From the **Units** drop-down list, select the unit that you want to change the measurement to.
- From the **Symbol** drop-down list, select the symbol that you want to add to the measurement.
- Click **OK**.  
The unit of measure changes and the selected symbol is added to the measurement and appears in the workspace.

## Hiding Markup Measure Entities

Select **Markup > Hide Dimensions** from the Markup menu.

The markup measurements are hidden on the markup file.

To “unhide” markups, select **Markup > Hide Markups** from the Markup menu.

## Deleting Markup Measure Entities

Select **Markup > Delete Dimensions** from the Markup menu.

The markup measurements are deleted on the markup file.

## Modifying Markup Entity Properties


In AutoVue, you can use the Markup Entity Properties dialog to modify markup entities.


To open the Markup Entity Properties dialog, select **Markup > Markup Entity Properties** from the Markup menu. You can also right-click a markup entity in the Markup Navigation Tree or the workspace and select **Markup Entity Properties** from the contextual menu.

### Line Color

Change the line color the selected markup entity or entities.

- 1 Select the entity or entities for which you want to change the line color.  
**See *Selecting Markup Entities***
- 2 From the **Line Color** drop-down list, select the color that you want for the entity.

**Note:** Selecting **By Layer**  changes the entity color to the color of the layer.

- 3 To define a custom line color, take the following steps:
  - a. Select **Custom Color**  from the **Line Color** drop-down list.
  - b. From the **Color** dialog that appears, select a color and click **OK**.
- 4 Make other changes you want with the **Markup Entity Properties** dialog, then click **OK** to close it.

The line color changes for the selected entity or entities.

**Note:** Only selected entities that you create will have the new line color. To apply the new line color to any new entity you create, make sure no entity is selected before opening the **Markup Entity Properties** dialog.

**See Also** *Changing the Line Color of An Entity*

### Line Style

Change the line style for a selected markup entity or entities.

- 1 Select the entity or entities for which you want to change the line style.  
**See *Selecting Markup Entities***
- 2 Select the line style that you want from the **Line Style** menu.  
The line style changes for the selected entity or entities.

**Note:** Any new entities that you create will have the new line style.

*See Also* **Changing the Line Style**

## Line Thickness

Change the line thickness for a selected markup entity or entities.

- 1 Select the entity or entities for which you want to change the line thickness.  
**See** **Selecting Markup Entities**
- 2 Select the line thickness that you want from the **Line Thickness** menu.  
The line thickness changes for the selected entity or entities.

To define a custom line thickness, take the following steps:

- 1 Select **Customize** from the **Line Thickness** menu.
- 2 In the **Width (Pixels)** menu, enter the desired width.
- 3 Make other changes you want with the **Markup Entity Properties** dialog, then click **OK** to close it.

The line thickness changes for the selected entity or entities.

**Note:** Any new entities that you create will have the new line thickness.

*See Also* **Changing the Line Thickness**

## Width (Pixels)

Customize the line thickness when **Customize** is selected in the Line Thickness menu. When other line thicknesses are selected, this field displays its value in pixels but cannot be edited.

*See* **Line Thickness**

## Arrow Style

Add an arrow head at one or both ends of a markup line entity.

- 1 Select the line entity or entities for which you want to change the arrow style.  
**See** **Selecting Markup Entities**
- 2 From the **Arrow Style** drop-down list, select the style of arrow that you want for the entity.
- 3 Make other changes you want with the **Markup Entity Properties** dialog, then click **OK** to close it.

The arrow style changes for the selected entity or entities.

**Note:** Any new entities that you create will have the new arrow style.

*See Also* **Changing the Arrow Style**

## Fill Type

Change the transparency for selected markup entity or entities.

- 1 Select the entity or entities for which you want to change the fill type.  
**See *Selecting Markup Entities***
- 2 From the **Fill Type** drop-down list, select the fill type that you want for the entity.
  - Select **Solid Fill**, if you want the fill color to be solid.
  - Select **Transparent Fill**, if you want the fill color to be transparent.
  - Select **No Fill**, if you do not want any fill color.
- 3 Make other changes you want with the **Markup Entity Properties** dialog, then click **OK** to close it.



The fill type changes for the selected entity or entities.

**Note:** Any new entities that you create will have the new fill type.

**See Also *Changing the Fill Type of An Entity***

## Fill Color

Change the line color, fill color and fill type for a selected markup entity or entities.

- 1 Select the entity or entities for which you want to change the fill color.  
**See *Selecting Markup Entities***
- 2 From the **Fill Color** drop-down list, select the color that you want for the entity.  
**Note:** Selecting  **By Layer** changes the entity color to the color of the layer.
- 3 To define you own color, take the following steps:
  - a. Select **Custom Color**  from the **Fill Color** drop-down list.
  - b. From the **Color** dialog that appears, select a color and click **OK**.The fill color changes for the selected entity or entities.
- 4 Make other changes you want with the **Markup Entity Properties** dialog, then click **OK** to close it.

The fill type changes for the selected entity or entities.

**Note:** Any new entities that you create will have the new fill color.

**See Also *Changing the Fill Color of An Entity***

## Markup Layers

When you have multiple markup layers, you can change the active layer to another layer.

- 1 From the **Markup Layers** drop-down list, select the layer you want to make active.
- 2 Make other changes you want with the **Markup Entity Properties** dialog, then click **OK** to close it.

The selected layer appears in the workspace.

**See Also** *Changing the Active Markup Layer*



## Marking Up 2D Files








AutoVue provides a variety of user-friendly markup options that you can use when marking up 2D files. You can create entities such as arcs, boxes, circles, clouds, lines and polygons. You can draw a leader with multi-line segments and add text to it. You can also add a symbol, add text to an entity or add information by adding a note.







**Note** When you are creating a markup entity, you can press **Escape** to cancel.

## 2D Markup Entities

In AutoVue, you can drawing many different types of entities. You can access the entities from the **Entities** menu in Markup mode. The entities are:

Option	Description
<b>Note</b>	Right click to complete an entity.
Arc	Click and drag the mouse to draw an arc. From the toolbar, click the Arc button  .
Box	Click and drag to draw a rectangle. From the toolbar, click the Box button  .
	<b>Note</b> To draw a square instead of a rectangle, press and hold the <b>Shift</b> key while you click and drag.

Option	Description
Closed Polyline	<p>Click and drag to draw a closed Polyline.</p> <p>From the toolbar, click the Closed Polyline button .</p>
Cloud	<p>Click and drag to draw a cloud.</p> <p>From the toolbar, click the Cloud button .</p>
Circle	<p>Click and drag to draw an ellipse.</p> <p>From the toolbar, click the Circle button .</p> <p><b>Note</b> To draw a circle instead of an ellipse, press and hold the <b>Shift</b> key while you click and drag.</p>
Filled Box	<p>Click and drag to draw a filled box. The box is filled with a solid color.</p> <p>From the toolbar, click the Filled Box button .</p> <p><b>Note</b> To draw a square Filled Box instead of a rectangular Filled Box, press and hold the <b>Shift</b> key while you click and drag.</p>
Freestyle	<p>Click, release mouse button, then drag to draw an entity.</p> <p>From the toolbar, click the Freestyle button .</p> <p><b>Note</b> You can create a contiguous or non-contiguous freestyle entity.</p> <p><b>See</b> <i>Creating a Non-contiguous Freestyle Entity</i> <i>Creating a Contiguous Freestyle Entity</i></p>
Highlight	<p>Click and drag to highlight a boxed area.</p> <p>From the toolbar, click the Highlight button .</p> <p><b>Note</b> The highlighted box will be filled with a transparent color.</p>
Leader	<p>Click and drag to draw a leader.</p> <p>From the toolbar, click the Leader button .</p> <p><b>Note</b> To force a line segment in a Leader entity to be aligned to the closer axis, horizontal or vertical axis, hold the <b>Shift</b> key while you click and drag for that line segment.</p> <p><b>See</b> <i>Adding a Leader</i> <i>Forcing a Line Segment</i></p>

Option	Description
Line	<p>Click and drag to draw a line.</p> <p>From the toolbar, click the Line button  .</p> <p><b>Note</b> To draw a line and force it to be aligned to the closer axis, horizontal or vertical, press and hold the <b>Shift</b> key while you click and drag.</p> <p><b>See</b> <i>Forcing a Line Segment</i></p>
Note	<p>Add a note to the Markup.</p> <p>From the toolbar, click the Note button  .</p> <p><b>See</b> <i>Adding a Note</i></p>
OLE	<p>Insert a new or existing OLE entity to the Markup.</p> <p><b>See</b> <i>Creating an OLE Markup Entity</i></p>
Polyline	<p>Click and drag to draw a polyline.</p> <p>From the toolbar, click the Polyline button  .</p> <p><b>Note</b> To force a line segment in a Polyline entity to be aligned to the closer axis, horizontal or vertical, press and hold the <b>Shift</b> key while you click and drag for that line segment.</p> <p><b>See</b> <i>Forcing a Line Segment</i></p>
Signoff	<p>Create an approval stamp containing information about the Markup author, date and time of creation.</p> <p>From the toolbar, click the Signoff button  .</p> <p><b>See</b> <i>Creating Signoff Entities</i></p>
Symbol	<p>Click and drag a symbol to the Markup.</p> <p>From the toolbar, click the Symbol button  .</p> <p><b>See</b> <i>Creating Symbols</i></p>
Text	<p>Add text to the Markup.</p> <p>From the toolbar, click the Text button  .</p> <p><b>See</b> <i>Adding Text</i></p>

## Creating a Non-contiguous Freestyle Entity

- 1 Select **Entities > FreeStyle** from the Markup menu.

**Note** You can also click the Freestyle button  from the Markup toolbar.

- 2 Click a point on the drawing where you want to start the freestyle entity.
- 3 Move the cursor to create the freestyle entity.
- 4 Click a point on the drawing where you want to interrupt the freestyle entity.
- 5 Click another point on the drawing where you want to restart the freestyle entity.

**Note** You can interrupt the freestyle entity as many times as you like by repeating steps 4 and 5.

- 6 Right-click to end the freestyle entity.

## Creating a Contiguous Freestyle Entity


- 1 Select **Entities > FreeStyle** from the Markup menu.

**Note** You can also click the Freestyle button  on the Markup toolbar.

- 2 Click a point on the drawing where you want to start the freestyle entity.
- 3 Move the cursor to create the freestyle entity.
- 4 Right-click to end the freestyle entity.

## Adding a Leader

- 1 Select **Entities > Leader** from the Markup menu.

**Note** You can also click the Leader button  from the Markup toolbar.

- 2 Click a point on the document where you want the leader to start.
- 3 Move the cursor to draw the leader.

**Note** To draw a leader and force it to be aligned to the closest axis, vertical or horizontal, hold the **Shift** key while moving the cursor.

- 4 To draw a leader with multiple line segments, repeat steps 2 and 3 as often as you like. You can click, then drag as often as you like.
- 5 Right-click to end the leader.

The **Text** dialog appears.

- 6 To change the font, click **Font**. The **Font** dialog appears. From the **Font** drop-down list, select the type of font. From the **Size** drop-down list, select the size of font. Select the checkbox beside the font style(s).

Type the text that you want to attach to the leader, then click **OK**.

- 7 Right-click outside the text area to complete the modification.

The leader appears on the drawing and in the **Markup Navigation Tree**.

**Note** To edit the leader text, double-click the leader in the **Markup Navigation Tree** or in the workspace to open the **Text** dialog.

*See Also Forcing a Line Segment*

## Forcing a Line Segment to Become Horizontal or Vertical

You can draw a line segment and force it to be aligned with the closer axis, horizontal or vertical. You can also take an existing line segment and have it align with the closer axis. The types of line segments that you can align are lines, line segments of leaders and polylines, and measure entities.


**Note** This procedure only works for measure entities that are drawn using **Free snap**.

- 1 To draw and force a line segment, press and hold the **Shift** key while you click and drag for that line segment.  
To force an existing line segment, click and hold the left mouse button on the line segment, then press and hold the **Shift** key.
- 2 When you see that the line segment is horizontal or vertical, release the left mouse button, then release the **Shift** key.

## Adding Text

With AutoVue, you can add text entities to a markup.

- 1 Select **Entities > Text** from the Markup menu.

**Note** You can also click the Text button  from the Markup toolbar.

- 2 Click a point on the drawing where you want to add text.  
The **Text** dialog appears.
- 3 To change the font, click **Font**. The **Font** dialog appears.  
From the **Font** drop-down list, select the type of font.  
From the **Size** drop-down list, select the size of font.  
Select the checkbox beside the font style(s).  
Type the text that you want to add, then click **OK**.
- 4 Right-click outside the text area to complete the modification.  
The text appears on the drawing and in the **Markup Navigation Tree**.
- 5 To move the text box click and drag it.


- 6 Click and drag the frame handles to enlarge the text box.

**Note** To edit text, double-click the text in the **Markup Navigation Tree** or in the workspace to open the **Text** dialog.


## Adding a Note

You can attach longer comments and notes to a markup with AutoVue's Markup Control Note Editor. A note is represented by a standard size graphical symbol labelled **Note**. To read the text inside, double-click the entity to open it or move the mouse over the entity to display the tooltip.

- 1 Select **Entities > Note** from the Markup menu.

**Note** You can also click the Note button  from the Markup toolbar.

- 2 Click a point on the document where you want to insert the note.  
The **Markup Control Note Editor** dialog appears.
- 3 Enter the text that you want in the note.
- 4 To modify the text, select **Formatting** and the format you want to apply.
- 5 Select **File > Information**.  
The **Note Information** dialog appears.  
Enter a **Name**, **Author** and **Key Words** for the note, then click **OK**.
- 6 Close the **Markup Control Note Editor** dialog.  
The note appears on the drawing and in the **Markup Navigation Tree**.
- 7 Right-click outside the note area to complete the modification.
- 8 To move the note, click and drag it.

**Note** To edit a note, double-click the note symbol  in the workspace.  
You can also select the note in the **Markup Navigation Tree**, right-click and select **Edit**, or double-click the note.

## Viewing the List of Notes

You can view a list of the notes you added to a file. You can also print the notes or find a note in the workspace.

- 1 Select **Markup > List Notes** from the Markup menu.  
The **List Notes** dialog appears.
- 2 To find a note, select the note from the list and click **Go To**.  
AutoVue zooms into the selected note in the workspace.

**Note** You can also select the note from the **Markup Navigation Tree**, right-click and select **Go To**.

- 3 To print a note, select the note from the list.

**Note** To print more than one note, press the **Shift** or **Ctrl** key while selecting. To print all the notes in the list, click **Select All**.

Click **Print**. The **Note print options** dialog appears.

**Note** To print each selected note on a separate page, select **One note per page**.

Configure the print options, then click **OK**. The selected notes are printed.


- 4 Click **OK** to close the **List Notes** dialog.

## Creating Signoff Entities

The signoff entity is an approval stamp containing information about the Markup author, date and time of creation. You create a signoff entity when the Markup file is finalized.

**Note** If you create an entity after the Signoff, the signoff entity disappears. The Signoff should be the last entity added to a Markup.

- 1 Select **Entities > Signoff** from the Markup menu.

**Note** You can also click the Signoff button  on the Markup toolbar.

- 2 Click and drag to create a box on the drawing where you want the signoff. The **Signoff** dialog appears displaying details of the signoff.
- 3 Click **OK**.

The signoff entity is created and appears on the drawing and in the **Markup Navigation Tree**.

## Rescinding the Signoff

You can rescind a signoff on a drawing.

- 1 Double-click the Signoff on the drawing or from the **Markup Navigation Tree**.

**Note** You can also select **Entities > Signoff** from the Markup menu. The **Signoff** dialog appears.

- 2 Click **Rescind**.

The signoff disappears from the drawing but remains in the **Markup Navigation Tree**.


**Note** To have the signoff re-appear on the drawing, double-click it from the **Markup Navigation Tree**, then click **Approve** in the **Signoff** dialog.

## Viewing the History of a Signoff

- 1 Double-click the Signoff on the drawing or from the **Markup Navigation Tree**.  
**Note** You can also select **Entities > Signoff** from the Markup menu. The **Signoff** dialog appears.
- 2 Click **History**.  
The **Signoff History** dialog appears displaying the author, date and time the signoff was created.
- 3 Click **OK**.
- 4 Click **Cancel** to close the **Signoff** dialog.

## Creating an OLE Markup Entity

In AutoVue, you can insert a new or an existing OLE object.

- 1 Select **Entities > OLE** from the Markup menu.  
**Note** You can also click the OLE button  on the Markup toolbar.
- 2 Click and drag to select the area on the drawing where you want to insert an **OLE** object.  
The **Insert Object** dialog appears.
- 3 Click **Create New** to insert a new object and select the **Object Type** from the list.
- 4 Click **Create from File** to insert an existing object and enter the filename and path or click **Browse** to locate the file.
- 5 To display the object as an icon, click **Display As Icon**.  
The icon that the object will be displayed as appears and the **Change Icon** button.  
To change the icon, click **Change Icon**. The **Change Icon** dialog appears. Select the icon that you want to change to, then click **OK**.  
**Note** The **Change Icon** button is only enabled if icons are available.
- 6 Click **OK** in the **Insert Object** dialog.  
The object appears on the Markup.  
**Note** If you selected **Display as Icon**, the selected icon appears as the object on the Markup.
- 7 Select **Entities > OLE** to exit or right-click in the workspace.  
**Note** To open the object, double-click on it.

## Symbols

A **Symbol** is a graphical entity, such as a company logo. Before a graphic entity can be used as a symbol, it must be added to a **Symbol Library**.

In AutoVue, you can create a Symbol Library and add symbols to it. You can also add or remove symbols from existing libraries.

### Adding a Symbol

A symbol is a graphical entity, such as a company logo. With AutoVue, you can add a symbol to a markup.


- 1 Select **Entities > Symbol** from the Markup menu.  
The **Symbols** dialog appears.

**Note** You can also click the Symbol button  in the Markup toolbar.

- 2 Click the **Symbols** tab.
- 3 From the **Symbol Library** drop-down list, select the library from which you want to select a symbol.  
The symbols appear for the selected library.
- 4 Click **Isotropic** if you want to scale the symbol proportionately.  
Click **Anisotropic** if you want to scale the symbol disproportionately.
- 5 Drag the symbol onto the workspace.  
The symbol appears on the drawing and in the **Markup Navigation Tree**.  
**Note** To add more symbols, repeat steps 3 to 5.
- 6 Close the **Symbols** dialog.

### Creating a New Symbol Library

- 1 Select **Entities > Symbol** from the Markup menu.  
The **Symbols** dialog appears.

**Note** You can also click the Symbol button  in the Markup toolbar.

- 2 Click the **Libraries** tab.
- 3 Click **Create**.  
The **Symbol Library** dialog appears.
- 4 Enter the **Library Name**, **Description**, **Author** and **Keywords**.
- 5 To add a symbol to the library, click **Add**.  
The **Open** dialog appears.
- 6 Browse to locate the symbol you want to add, then click **Open**.  
The file appears in the **Symbol Files** list.

**Note** To add more symbols, repeat steps 4 and 5. To remove a symbol, select the symbol and click **Remove**.

- 7 Close the **Symbols** dialog.


**See Also** *Adding a Symbol to a Library*

*Editing a Symbol Library Information*

*Deleting a Symbol Library*

## Adding a Symbol to a Library

- 1 Select **Entities > Symbol** from the Markup menu.  
The **Symbols** dialog appears.

**Note** You can also click the Symbol button  in the Markup toolbar.

- 2 Click the **Symbols** tab.
- 3 From the **Symbol Library** drop-down list, select the library that you want to add a symbol.
- 4 Click **Add Symbol**.  
The **Symbol Definition** dialog appears.  
Enter the **Source file**, **Symbol Name** and **Description** or click **Browse** to locate the source file.
- 5 Click **OK**.

The symbol appears under **Drag and drop a Symbol onto AutoVue** in the Symbols dialog.


**Note** To add more than one symbol, repeat steps 4 and 5.

- 6 Close the **Symbols** dialog.

## Deleting a Symbol from a Library

- 1 In the **Symbols** dialog, click the **Symbols** tab.
- 2 From the **Symbol Library** drop-down list, select the library which contains the symbol you want to delete.
- 3 The symbols appear in the **Drag and drop a Symbol onto AutoVue** area.
- 4 Select the symbol you want to delete, then click **Delete**.  
The symbol disappears from the library.
- 5 Close the **Symbols** dialog.

## Editing Symbol Library Information

- 1 Select **Entities > Symbol** from the Markup menu.  
The **Symbols** dialog appears.  
**Note** You can also click the  button in the Markup toolbar.
- 2 Click the **Libraries** tab.
- 3 From the **Symbol Libraries** list, select the library that you want edit.
- 4 Click **Edit**.  
The **Symbol Library** dialog appears.
- 5 Edit the information.
- 6 Click **OK**.
- 7 Close the **Symbols** dialog.

## Deleting a Symbol Library

- 1 In the **Symbols** dialog, click the **Libraries** tab.
- 2 From the **Symbol Libraries** list, select the library that you want to delete.
- 3 Click **Delete**.  
The library disappears from the list and from the **Symbol Library** drop-down list under the **Symbols** tab.
- 4 Close the **Symbols** dialog.

## Working with Hyperlinks

A hyperlink is a link between the current file and the new file or application. You can create hyperlinks within your current file so that your files and applications outside AutoVue are only a click away. The main benefit of adding hyperlinks to a file is that you can gather all files of related information into one file with the files kept separate. In other words, the files may be accessible from one location but the information is referenced, not duplicated. This ensures a manageable file size when loading. If changes need to be made to a linked file, they need to be done in one location — to the linked file itself.

## Creating a Hyperlink

- 1 Select **Markup > Hyperlink > Establish** from the Markup menu.
- 2 Click a point on the document where you want to place the hyperlink.  
The **Establish Hyperlink** dialog appears.
- 3 Enter a **Link Name**.

- 4 Enter a **Link Description** (optional).
- 5 From the **Link to** drop-down list, select the type of link.  
For example, **Data File** opens a document file, whereas **Application** open an application other than AutoVue.  
The link change according to the selected link.
- 6 Click **Browse** to locate the **Data file** or application and its path that you want to link to or enter the information manually.  
**Note** For **Application**, ensure that the executable file is selected. For example, mspaint.exe.
- 7 To change the hyperlink icon, click **Set Icon**. The **Open** dialog appears.  
Enter the **file name** or browse to locate the bitmap file that you want to use as the icon, then click **Open**.
- 8 Click **OK** in the **Establish Hyperlink** dialog.  
The hyperlink appears on the Markup.  
**Note** If you changed the icon, the selected icon appears as the hyperlink on the Markup.

## Firing a Hyperlink

- 1 To fire a hyperlink, double-click on it from the workspace.  
The hyperlink file opens in the window you selected in the **Establish Hyperlink** dialog.  
**Note** You can also fire a hyperlink by selecting it, then right-clicking and selecting **Hyperlinks > Fire** from the pop-up menu or selecting **Hyperlink > Fire** from the Markup menu.

## Editing a Hyperlink

- 1 In the **Markup Navigation Tree** or from the workspace, select the hyperlink that you want to edit.
- 2 Select **Markup > Hyperlink > Edit** from the Markup menu.  
The **Establish Hyperlink** dialog appears.  
**Note** You can right-click a hyperlink in the **Markup Navigation Tree** and select **Edit** from the pop-up menu.
- 3 Edit the information that you want.
- 4 Click **OK**.  
The changes are saved.

## Deleting a Hyperlink

- 1 In the **Markup Navigation Tree** or from the workspace, select the hyperlink that you want to delete.
- 2 Select **Markup > Hyperlink > Break** or **Markup > Delete** from the Markup menu.

The hyperlink is deleted from the file.

**Note** You can also delete a hyperlink by right-clicking it in the **Markup Navigation Tree** and selecting **Delete** from the pop-up menu.

## Viewing List of Hyperlinks

- 1 Select **Markup > Hyperlink > List** from the Markup menu.  
The **List Hyperlinks** dialog appears listing the hyperlinks.

**Note** You can right-click in the workspace and select **Hyperlinks > List** from the pop-up menu.

**Note** You can fire a hyperlink by selecting the hyperlink and clicking **Fire**.

- 2 Click **OK**.

## Viewing History of a Hyperlink

AutoVue lets you view information about a hyperlink's path. From a file that is launched from a hyperlink, you can see what document invoked the hyperlink.

- 1 From the hyperlink file, select **File > Markup** from the AutoVue main menu.
- 2 Select **Markup > Hyperlink > History** from the Markup menu.  
The **Hyperlink History** dialog appears listing the path linking the hyperlink file to the file that invoked the hyperlink.
- 3 To jump to the file where you fired the hyperlink from, select the path in the **Hyperlinks History** dialog.
- 4 Click **Jump to**.

**Note** You can also go back by right-clicking in the hyperlink file and selecting **Go Back** from the pop-up menu.

# Creating 2D Non-vector Markup Measure Entities





When marking up 2D non-vector files, in addition to all the markup options available for 2D files, you can create markup measure entities. The measure options in Markup mode work a bit differently than in View mode. For information on marking up 2D files, **see *Marking Up 2D Files***.

When measuring in Markup mode, the specified measurement lines and values are displayed on the current active markup layer as entities. These entities can be moved, resized, hidden or deleted. You can also modify the font of a measure entity, align a “free snap” measure entity to the horizontal or vertical axis, as well as add units of measure and symbols to a measurement and have them appear on the drawing.

**Note** When you are creating a markup entity, you can press **Escape** to cancel.

Measure options vary between vector and non-vector files. For vector files, AutoVue provides the option to “snap” to fixed points on the drawing. For non-vector files, you can only “free snap”.

In Markup mode, you can choose from several measure options to create markup measure entities. You can access the measure options from the **Analysis > Measure** menu. The options are:


Option	Description
Angle	Measure the angle between selected points. From the toolbar, click the Angle button  .
Arc	Measure an arc entity. From the toolbar, click the Arc button  .
Area	Measure a selected area. From the toolbar, click the Area button  .
Distance	Measure the distance between two points. From the toolbar, click the Distance button  .

## Measuring Distance

Use the **Distance** option to measure the distance between two specific points.

**Note** If you want a markup entity for the measurement, you must ensure that **Add Distance** is selected in the **Measurement** dialog.

- 1 Select **Analysis > Measure** from the Markup menu.  
The **Measurement** dialog appears.

**Note** You can also click the Distance button  on the Markup toolbar.

- 2 Click the **Distance** tab.
- 3 From the **Measured Distance Units** drop-down list, select the unit in which you want to measure the distance.
- 4 Click a point on the drawing to define the starting point.
- 5 Click another point on the drawing to define the end point.  
The measured line path appears as an entity on the current active markup.
- 6 Drag to move the measured line path.
- 7 Click on the measured line path.  
The measurement and unit appear as an entity on the current active markup layer. The measured distance, Delta-X and Delta-Y appear in the **Measurement** dialog.
- 8 Click and drag the frame handles to change the size of the box.
- 9 Click **Close** to close the **Measurement** dialog.


**See Also** *Modifying Measurement Markup Entities*

## Measuring Cumulative Distance

Use the **Cumulative Distance** option to measure the distance along a path of multi-faceted (adjoining) points.

**Note** If you want a markup entity for the measurement, you must ensure that **Add Distance** is selected in the **Measurement** dialog.

- 1 Select **Analysis > Measure** from the Markup menu.  
The **Measurement** dialog appears.

**Note** You can also click the Distance button  on the AutoVue toolbar.

- 2 Click the **Distance** tab.
- 3 From the **Measured Distance Units** drop-down list, select the unit in which you want to measure the distance.
- 4 Select **Cumulative**.

- 5 Click a point on the drawing to define the starting point.
- 6 Continue clicking points along the path that you want to measure. Each point is joined by a line.
- 7 Right-click to complete the measurement.  
The measured line path, measurement and unit appear as an entity on the current active markup layer. The cumulated measured distance, Delta-X and Delta-Y appear in the **Measurement** dialog.
- 8 Click and drag the frame handles to change the size of the box.  
**Note** Click **Reset** to take another measurement.
- 9 Click **Close** to close the **Measurement** dialog.  
**See Also** *Modifying Measurement Markup Entities*

## Calibrating Distance


- 1 Measure the distance between two points or measure cumulative distance.  
**See** *Measuring Distance*
- 2 In the **Measurement** dialog, click **Calibrate**.  
The **Distance Calibration** dialog appears displaying the measured distance.
- 3 In the **Distance** drop-down list, select the unit to which you want to calibrate the distance.
- 4 Click **Calibrate to** and enter a value if you want to calibrate the distance to a value.  
Click **Set Factor** and enter a value if you want to calibrate the distance by a factor.
- 5 Click **OK**.  
The calibration result appears in the **Measurement** dialog.
- 6 Click **Close** to close the **Measurement** dialog.

## Measuring Area

Use the **Area** option to measure the area and perimeter of a region.

**Note** If you want a markup entity for the measurement, you must ensure that **Add Area** is selected in the **Measurement** dialog.

- 1 Select **Analysis > Measure** from the Markup menu. The **Measurement** dialog appears.

**Note** You can also click the Area button  on the Markup toolbar.


- 2 Click the **Area** tab.

- 3 From the **Measured Area Units** drop-down list, select the unit in which you want to measure the area.  
From the **Perimeter Units** drop-down list, select the unit in which you want to measure the perimeter.
- 4 To cumulate a **Net Area Result** of different areas, select **Add** in the **Measurement** dialog.  
To subtract an area from the **Net Area Result**, select **Subtract**.  
Select **Clear** to clear the **Net Area Result**.
- 5 Click a point on the drawing to define the starting point.
- 6 Continue clicking points on the drawing to define the area you want to measure.  
Each point is joined by a line.
- 7 Right click to complete the measurement.  
The measured line path, measurement and unit appear as an entity on the current active markup layer. The area and perimeter measurements appear in the **Measurement** dialog.
- 8 Click and drag the frame handles to change the size of the box.  
**Note** Click **Reset** to take another measurement.
- 9 Click **Close** to close the **Measurement** dialog.  
**See Also** *Modifying Measurement Markup Entities*

## Measuring an Angle

Use the **Angle** option to measure the angle between points on a drawing.

**Note** If you want a markup entity for the measurement, you must ensure that **Add dimensions** is selected in the **Measurement** dialog.

- 1 Select **Analysis > Measure** from the Markup menu.  
The **Measurement** dialog appears.  
**Note** You can also click the Angle button  on the Markup toolbar.
- 2 Click the **Angle** tab.
- 3 From the **Measured Angle Units** drop-down list, select the unit in which you want to measure the angle.
- 4 Click points on the drawing to define the angle you want to measure.  
The points are joined by angle arms with an arc connecting them.
- 5 Click again to complete the measurement.  
The measured line path, angle measurement and unit appear as an entity on the current active markup layer and in the **Measurement** dialog.
- 6 Click and drag to change the size of the arc.


- 7 Click and drag the frame handles to change the size of the box.  
**Note** Click **Reset** to take another measurement.
- 8 Click **Close** to close the **Measurement** dialog.  
**See Also** *Modifying Measurement Markup Entities*

## Measuring an Arc

Use the **Arc** option to define an arc in the drawing and measure its radius, center and diameter.

**Note** If you want a markup entity for the measurement, you must ensure that **Add Radius** or **Add Diameter** is selected in the **Measurement** dialog.

- 1 Select **Analysis > Measure** from the Markup menu.  
The **Measurement** dialog appears.

**Note** You can also click the Arc button  on the Markup toolbar.

- 2 Click the **Arc** tab.
- 3 From the **Arc Info** drop-down list, select the unit in which you want to measure the arc.
- 4 From the **Measured Angle Units** drop-down list, select the unit in which you want to measure the angle.
- 5 Select **Add Radius** if you want to measure the radius of the arc.  
Select **Add Diameter** if you want to measure the diameter of the arc.
- 6 Click points on the drawing to define the arc you want to measure.  
The points are joined by an arc.
- 7 Click again to complete the measurement.  
The measured line path, arc measurement and unit appear as an entity on the current active markup layer and in the **Measurement** dialog.
- 8 Click and drag the box anywhere on the drawing.  
Click and drag the frame handles to change the size of the box.  
**Note** Click **Reset** to take another measurement.
- 9 Click **Close** to close the **Measurement** dialog.  
**See Also** *Modifying Measurement Markup Entities*

## Calibrating an Arc

- 1 Measure an arc in the drawing.  
**See** *Measuring an Arc*
- 2 In the **Measurement** dialog, click **Calibrate**.

- The **Distance Calibration** dialog appears displaying the measured distance.
- 3 From the **Distance** drop-down list, select the unit to which you want to calibrate the distance.
  - 4 Click **Calibrate to** and enter a value if you want to calibrate to a value. Click **Set Factor** and enter a value if you want to calibrate by a factor.
  - 5 Click **OK**.  
The calibration result appears in the **Measurement** dialog.
  - 6 Click **Close** to close the **Measurement** dialog.


## Creating 2D Vector Markup Measure Entities




When marking up 2D vector files, in addition to all the markup options available for 2D files, you can create markup measure entities. The measure options in Markup mode work slightly different than in View mode. For information on marking up 2D files, *see **Marking Up 2D Files***.

Measure options vary between vector and non-vector files. For vector files, AutoVue provides the option to “snap” to fixed points on the drawing. For non-vector files, you can only “free snap”.

When measuring in Markup mode, the specified measurement lines and values are displayed on the current active markup layer as entities. These entities can be moved, resized, hidden or deleted. You can also modify the font of a measure entity, align a “free snap” measure entity to the horizontal or vertical axis, as well as add units of measure and symbols to a measurement and have them appear on the drawing.

**Note** When you are creating a markup entity, you can press **Escape** to cancel. In Markup mode, you can choose from several measure options to create markup measure entities. You can access the measure options from the **Analysis > Measure** menu. The options are:





Option	Description
Angle	Measure the angle between selected points. From the toolbar, click the Angle button  .

Option	Description
Arc	Measure an arc entity. From the toolbar, click the Arc button  .
Area	Measure selected area. From the toolbar, click the Area button  .
Distance	Measure the distance between two points. From the toolbar, click the Distance button  .

## 2D Vector Snapping Modes

The **Snapping Modes** available allow you to click to precise geometrical points on a drawing. For example, if you select **Snap to end-point** and you move the cursor over an end-point of a line, the end-point will be highlighted by a snap box.

The **Snapping modes** allow you to snap to the mid, center and end-points of an entity:


Button	Snap to	Description
	End-point	Geometric snap mode where a snap box appears when moving the cursor near a linear component's end point.
	Mid-point	Geometric snap mode where a snap box appears when moving the cursor near the halfway point of a linear component.
	Center-point	Geometric snap mode where a snap box appears when moving the cursor near the center of an elliptical component.
	Free snap	Allow snapping at any point on the drawing.

## Measuring Distance

Use the **Distance** option to measure the distance between two specific points.

**Note** If you want a markup entity for the measurement, you must ensure that **Add Distance** is selected in the **Measurement** dialog.

- 1 Select **Analysis > Measure** from the Markup menu.  
The **Measurement** dialog appears.

**Note** You can also click the Distance button  on the Markup toolbar.

- 2 Click the **Distance** tab.
- 3 Select the **Snapping Modes** that you want to use for measuring.  
To select all **Snapping Modes** click **All On**. To clear all **Snapping Modes** click **All Off**.

**See 2D Vector Snapping Modes**

- 4 From the **Measure Distance Units** drop-down list, select the unit in which you want to measure the distance.
- 5 Click a point on the drawing to define the starting point.
- 6 Click another point on the drawing to define the end point.  
The measured line path appears as an entity on the current active markup.
- 7 Drag to move the measured line path.
- 8 Click on the measured line path.  
The measurement and unit appear as an entity on the current active markup layer. The measured distance, Delta-X and Delta-Y appear in the **Measurement** dialog.
- 9 Click and drag the frame handles to change the size of the box.  
**Note** Click **Reset** to take another measurement.
- 10 Click **Close** to close the **Measurement** dialog.


**See Also** *Modifying Measurement Markup Entities*

## Measuring Cumulative Distance

Use the **Cumulative Distance** option to measure the distance along a path of multi-faceted (adjoining) points.

**Note** If you want a markup entity for the measurement, you must ensure that **Add Distance** is selected in the **Measurement** dialog.

- 1 Select **Analysis > Measure** from the Markup menu.  
The **Measurement** dialog appears.

**Note** You can also click the Distance button  on the Markup toolbar.

- 2 Click the **Distance** tab.
- 3 Select the **Snapping Modes** that you want to use for measuring.  
To select all **Snapping Modes** click **All On**. To clear all **Snapping Modes** click **All Off**.  
**See 2D Vector Snapping Modes**
- 4 From the **Measured Distance Units** drop-down list, select the unit in which you want to measure the distance.
- 5 Select **Cumulative**.
- 6 Click a point on the drawing to define the starting point.
- 7 Continue clicking points along the path that you want to measure.  
Each point is joined by a line.
- 8 Right-click to complete the measurement.  
The measured line path, measurement and unit appear as an entity on the current active markup layer. The cumulated measured distance, Delta-X and Delta-Y appear in the **Measurement** dialog.
- 9 Click and drag the frame handle to change the size of the box.  
**Note** Click **Reset** to take another measurement.
- 10 Click **Close** to close the **Measure Distance** dialog.  
**See Also** *Modifying Measurement Markup Entities*

## Calibrating Distance


- 1 Measure the distance between two points or measure cumulative distance.  
**See** *Measuring Distance*
- 2 In the **Measurement** dialog, click **Calibrate**.  
The **Distance Calibration** dialog appears displaying the measured distance.
- 3 In the **Measured Distance** drop-down list, select the unit to which you want to calibrate the distance.
- 4 Click **Calibrate to** and enter a value if you want to calibrate the distance to a value.  
Click **Set Factor** and enter a value if you want to calibrate the distance by a factor.
- 5 Click **OK**.  
The calibration result appears in the **Measurement** dialog.
- 6 Click **Close** to close the **Measurement** dialog.

## Measuring Area

Use the **Area** option to measure the area and perimeter of a region.

**Note** If you want a markup entity for the measurement, you must ensure that **Add Area** is selected in the **Measurement** dialog.

- 1 Select **Analysis > Measure** from the Markup menu.  
The **Measurement** dialog appears.

**Note** You can also click the Area button  on the Markup toolbar.

- 2 Click the **Area** tab.
- 3 Select **Between Points** if you want to measure the area between points on a drawing. **Snapping Modes** are enabled.  
Select the **Snapping Modes** that you want to use for measuring.  
To select all **Snapping Modes** click **All On**. To clear all **Snapping Modes** click **All Off**.

**See** *2D Vector Snapping Modes*

- 4 Select **Shape** if you want to measure the area of a predefined shape on the drawing. **Snapping Modes** are disabled.
- 5 From the **Measured Area Units** drop-down list, select the unit in which you want to measure the area.
- 6 From the **Perimeter Units** drop-down list, select the unit in which you want to measure the perimeter.
- 7 To cumulate a **Net Area Result** of different areas, select **Add** in the **Measurement** dialog.  
To subtract an area from the **Net Area Result**, select **Subtract**.  
Select **Clear** to clear the **Net Area Result**.
- 8 If you selected **Between Points**, click points on the drawing to define the area, then right click to complete the measurement.  
Each point is joined by a line. The measured line path, measurement and unit appear as an entity on the current active markup layer. The area and perimeter measurements appear in the **Measurement** dialog.
- 9 If you selected **Shape**, click the edge of a predefined shape on the drawing. The shape is highlighted. The measured line path, measurement and unit appear as an entity on the current active markup layer. The area and perimeter measurements appear in the **Measurement** dialog.
- 10 Click and drag the frame handles to change the size of the box.

**Note** Click **Reset** to take another measurement.

- 11 Click **Close** to close the **Measurement** dialog.


**See Also** *Modifying Measurement Markup Entities*

## Measuring an Angle

Use the **Angle** option to measure the angle between points on a drawing.

**Note** If you want a markup entity for the measurement, you must ensure that **Add dimensions** is selected in the **Measurement** dialog.

- 1 Select **Analysis > Measure** from the Markup menu.  
The **Measurement** dialog appears.

**Note** You can also click the Angle button  on the Markup toolbar.


- 2 Click the **Angle** tab.  
Select **From 3 Points** if you want to measure the angle between three points. **Snapping Modes** are enabled.  
Select the **Snapping Modes** that you want to use for measuring.  
To select all **Snapping Modes** click **All On**. To clear all **Snapping Modes** click **All Off**.  
**See 2D Vector Snapping Modes**
- 3 Select **Between 2 lines** if you want to measure the angle between two lines. **Snapping Modes** are disabled.
- 4 From the **Measured Angle Units** drop-down list, select the unit in which you want to measure the angle.
- 5 If you selected **From 3 Points**, click three points on the drawing to define the angle.  
If you selected **Between 2 Lines**, click two lines on the drawing to define the angle.  
Angle arms appear with an arc connecting them.
- 6 Click to complete the measurement.  
The measured line path, measurement and unit appear as an entity on the current active markup layer. The measured angle appears in the **Measurement** dialog.
- 7 Click and drag to change the size of the arc.
- 8 Click and drag the box anywhere on the drawing.
- 9 Click and drag the frame handles to change the size of the box.  
**Note** Click **Reset** to take another measurement.
- 10 Click **Close** to close the **Measurement** dialog.  
**See Also** *Modifying Measurement Markup Entities*

## Measuring an Arc

Use the **Arc** option to define an arc in the drawing and measure its radius, center and diameter.

**Note** To create a markup entity for the measurement, you must ensure that **Add Radius** or **Add Diameter** is selected in the **Measurement** dialog.

- 1 Select **Analysis > Measure** from the Markup menu.  
The **Measurement** dialog appears.

**Note** You can also click the Arc button  on the Markup toolbar.

- 2 Click the **Arc** tab.
- 3 Select **From 3 Points** if you want to measure the arc between three points.  
**Snapping Modes** are enabled.

Select the **Snapping Modes** that you want to use for measuring.

To select all **Snapping Modes** click **All On**. To clear all **Snapping Modes** click **All Off**.

**See 2D Vector Snapping Modes**

- 4 Select **Arc Entity** if you want to measure a predefined arc. **Snapping Modes** are disabled.
- 5 From the **Arc Info** drop-down list, select the unit in which you want to measure the distance.
- 6 From the **Measure Angle Units** drop-down list, select the unit in which you want to measure the angle.
- 7 Select **Add Radius** if you want to measure the radius.  
Select **Add Diameter** if you want to measure the diameter
- 8 If you selected **From 3 Points**, click three points to define the arc, then click to complete the measurement  
The points are joined by an arc.  
If you selected **Arc Entity**, click the edge of the arc that you want to measure. The arc is highlighted.
- 9 Click to complete the measurement.  
The measured line path, measurement and unit appear as an entity on the current active markup layer. The measurements for center point coordinates, radius, diameter, arc length, start and end of angle and sweep appear in the **Measurement** dialog.
- 10 Click and drag the box anywhere on the drawing.
- 11 Click and drag the frame handles to change the size of the box.  
**Note** Click **Reset** to take another measurement.
- 12 Click **Close** to close the **Measurement** dialog.

**See Also** *Modifying Measurement Markup Entities*

## Calibrating an Arc

- 1 Measure an arc in the drawing.  
**See *Measuring an Arc***
- 2 In the **Measurement** dialog, click **Calibrate**.  
The **Radius Calibration** dialog appears displaying the measured distance.
- 3 From the **Measured Rad.** drop-down list, select the unit to which you want to calibrate the distance.
- 4 Click **Calibrate to** and enter a value if you want to calibrate to a value.  
Click **Set Factor** and enter a value if you want to calibrate by a factor.
- 5 Click **OK**.  
The calibration result appears in the **Measurement** dialog.
- 6 Click **Close** to close the **Measurement** dialog.

## Creating EDA Markup Measure Entities






When marking up EDA files, in addition to all the markup options available for 2D files, you can create markup measure entities. The measure options in Markup mode work slightly different than in View mode. For information on marking up 2D files, **see *Marking Up 2D Files***.

**Note** When you are creating a markup entity, you can press **Escape** to cancel.

When measuring in Markup mode, the specified measurement lines and values are displayed on the current active markup layer as entities. These entities can be moved, resized, hidden or deleted. You can also modify the font of a measure entity, align a “free snap” measure entity to the horizontal or vertical axis, as well as add units of measure and symbols to a measurement and have them appear on the drawing.

AutoVue provides the option to “snap” to geometrical or electrical points on the drawing.


In Markup mode, you can choose from several measure options to create markup measure entities. You can access the measure options from the **Analysis > Measure** menu. The options are:







Option	Description
Angle	Measure the angle between selected points. From the toolbar, click the Angle button  .
Arc	Measure arc entity. From the toolbar, click the Arc button  .
Area	Measure a selected area. From the toolbar, click the Area button  .
Distance	Measures the distance between two points. From the toolbar, click the Distance button  .
Minimum Distance	Measure the minimum distance between entities. From the toolbar, click the Minimum Distance button  .

## EDA Snapping Modes

The Snapping Modes allow you to click to precise geometrical or electrical points. For example, when you select **Snap to pin**, move the cursor over the pin you want to select until the pin is highlighted, then click. Highlight and click a second pin to measure the distance between them.

The Snapping Modes allow you to snap to the mid, center and end-points of an entity, as well as a pin, via, and symbol:

Button	Snap to	Description
	End-point	Geometric snap mode where a snap box appears when moving the cursor near the component's end point.


Button	Snap to	Description
	Mid-point	Geometric snap mode where a snap box appears when moving the cursor near the halfway point of a linear component.
	Center-point	Geometric snap mode where a snap box appears when moving the cursor near the center of an elliptical component.
	Pin	Electrical snap mode where a snap box appears when the cursor touches a pin.
	Via origin	Electrical snap mode where a snap box appears when the cursor touches a via.
	Symbol origin	Electrical snap mode where a snap box appears when the cursor touches the entire component.
	Free snap	Allows snapping at any point on the drawing.

## Measuring Distance

Use the **Distance** option to measure the distance between two specific points.

**Note** If you want a markup entity for the measurement, you must ensure that **Add Distance** is selected in the **Measurement** dialog.

- 1 Select **Analysis > Measure** from the Markup menu.  
The **Measurement** dialog appears.

**Note** You can also click the Distance button  on the Markup toolbar.

- 2 Click the **Distance** tab.
- 3 Select the **Snapping Modes** that you want to use for measuring.  
To select all **Snapping Modes** click **All On**. To clear all **Snapping Modes** click **All Off**.

**See** *EDA Snapping Modes*

- 4 From the **Measured Distance Units** drop-down list, select the unit in which you want to measure the distance.
- 5 Click a point on the drawing to define the starting point.


- 6 Click another point on the drawing to define the end point.  
The points are joined by a line. The measured line path appears as an entity on the current active markup.
- 7 Drag to move the measured line path.
- 8 Click on the measured line path.  
The measurement and unit appear as an entity on the current active markup layer. The measured distance, Delta-X, Delta-Y and the “Manhattan Distance” appear in the **Measurement** dialog.
- 9 Click and drag the frame handles to change the size of the box.  
**Note** Click **Reset** to take another measurement.
- 10 Click **Close** to close the **Measurement** dialog.  
**See Also** *Modifying Measurement Markup Entities*

## Measuring Cumulative Distance

Use the **Cumulative Distance** option to measure the distance along a path of multi-faceted (adjoining) points.

**Note** If you want a markup entity for the measurement, you must ensure that **Add Distance** is selected in the **Measurement** dialog.

- 11 Select **Analysis > Measure** from the Markup menu.  
The **Measurement** dialog appears.

**Note** You can also click the Distance button  on the Markup toolbar.

- 12 Click the **Distance** tab.
- 13 Select the **Snapping Modes** that you want to use for measuring.  
To select all **Snapping Modes** click **All On**. To clear all **Snapping Modes** click **All Off**.  
**See** *EDA Snapping Modes*
- 14 From the **Measured Distance Units** drop-down list, select the unit that you want to measure the distance.
- 15 Select **Cumulative**.
- 16 Click the first entity to define the starting point.
- 17 Continue clicking points along the path that you want to measure.  
Each point is joined by a line.
- 18 Right-click to complete the measurement.  
The measured line path, measurement and unit appear as an entity on the current active markup layer. The measured distance, Delta-X, Delta-Y and the “Manhattan Distance” appear in the **Measurement** dialog.
- 19 Click and drag the frame handles to change the size of the box.

**Note** Click **Reset** to take another measurement.

20 Click **Close** to close the **Measurement** dialog.

**See Also** *Modifying Measurement Markup Entities*

## Calibrating Distance

1 Measure the distance between two points or measure cumulative distance.

**See** *Measuring Distance*

2 In the **Measurement** dialog, click **Calibrate**.

3 The **Distance Calibration** dialog appears displaying the measured distance.

4 In the **Measured Distance** drop-down list, select the unit to which you want to calibrate the distance.

5 Click **Calibrate to** and enter a value if you want to calibrate the distance to a value.

Click **Set Factor** and enter a value if you want to calibrate the distance by a factor.

6 Click **OK**.

The calibration result appears in the **Measurement** dialog.

7 Click **Close** to close the **Measurement** dialog.

## Measuring Minimum Distance

Use the **Minimum Distance** option to measure the minimum distance between entities. The available entities for snapping are nets, pins, vias and traces.


**Note** If you want a markup entity for the measurement, you must ensure that **Add Distance** is selected in the **Measurement** dialog.

1 Select **Analysis > Measure** from the Markup menu.

The **Measurement** dialog appears.

**Note** You can also click the Minimum Distance button  on the Markup toolbar.

2 Click the **Min. Distance** tab.

3 Click  **First Set** to select the entities that you want to measure from.

4 Select the **Snapping Modes** that you want to use for measuring.


**See** *EDA Snapping Modes*

**Note** If you select **Net**, you cannot select any other type of entity.

5 Click the first set of entities on the drawing.

The entities are highlighted.

**Note** To clear the last set of entities you selected, click **Clear Set**.

- 6 Click  **Second Set** to select the entities that you want to measure to.
- 7 Click the second set of entities on the drawing.  
The entities are highlighted in a different color.
- 8 From the **Measured Min Distance** drop-down list, select the unit in which you want to measure the distance.
- 9 Click **Zoom to Result**, if you want to zoom in on the measured value on the drawing.
- 10 Click **Compute**.  
The minimum distance from the first set of entities to the second set is highlighted by a line. The measured line path, measurement and unit appear as an entity on the current active markup layer. The measurement, delta-X, delta-Y and the “Manhattan Distance” appear in the **Measurement** dialog.
- Note** Click **Reset** to take another measurement.
- 11 Click **Close** to close the **Measurement** dialog.


**See Also** *Modifying Measurement Markup Entities*

## Measuring Area

Use the **Area** option to measure the area and perimeter of a region.

**Note** If you want a markup entity for the measurement, you must ensure that **Add Area** is selected in the **Measurement** dialog.

- 1 Select **Analysis > Measure** from the Markup menu.  
The **Measurement** dialog appears.

**Note** You can also click the Area button  on the Markup toolbar.

- 2 Click the **Area** tab.
- 3 Select **Between Points** if you want to measure the area between points on a drawing. **Snapping Modes** are enabled.  
Select the **Snapping Modes** that you want to use for measuring.  
To select all **Snapping Modes** click **All On**. To clear all **Snapping Modes** click **All Off**.

**See** *EDA Snapping Modes*


- 4 Select **Shape** if you want to measure the area of a predefined shape on the drawing. **Snapping Modes** are disabled.
- 5 From the **Measured Area Units** drop-down list, select the unit in which you want to measure the area.

- 6 From the **Perimeter Units** drop-down list, select the unit in which you want to measure the perimeter.
- 7 To cumulate a **Net Area Result** of different areas, select **Add** in the **Measurement** dialog.  
To subtract an area from the **Net Area Result**, select **Subtract**.  
Select **Clear** to clear the **Net Area Result**.
- 8 If you selected **Between Points**, click points on the drawing to define the area.  
Each point is joined by a line and the measurement appears in the **Measurement** dialog.
- 9 If you selected **Shape**, click the edge of a predefined shape on the drawing.  
The shape is highlighted.
- 10 Right-click to complete the measurement.  
The measured line path, measurement and unit appear as an entity on the current active markup layer. The area and perimeter measurements appear in the **Measurement** dialog.  
**Note** Click **Reset** to take another measurement.
- 11 Click **Close** to close the **Measurement** dialog.  
**See Also** *Modifying Measurement Markup Entities*

## Measuring an Angle

Use the **Angle** option to measure the angle between points on a drawing.

**Note** If you want a markup entity for the measurement, you must ensure that **Add dimensions** is selected in the **Measurement** dialog.

- 1 Select **Analysis > Measure** from the Markup menu.  
The **Measurement** dialog appears.  
**Note** You can also click the Angle button  on the Markup toolbar.
- 2 Click the **Angle** tab.
- 3 Select **From 3 Points** if you want to measure the angle between three points. **Snapping Modes** are enabled.  
Select the **Snapping Modes** that you want to use for measuring.  
To select all **Snapping Modes** click **All On**. To clear all **Snapping Modes** click **All Off**.  
**See** *EDA Snapping Modes*
- 4 Select **Between 2 lines** if you want to measure the angle between two lines. **Snapping Modes** are disabled.

- 5 From the **Measured Angle Units** drop-down list, select the unit in which you want to measure the angle.
- 6 If you selected **From 3 Points**, click three points to define the angle. If you selected **Between 2 Lines**, click two lines to define the angle. Angle arms appear with an arc connecting them.
- 7 Right-click to complete the measurement. The measured line path, measurement and unit appear as an entity on the current active markup layer. The measured angle appears in the **Measurement** dialog.
- 8 Click and drag to change the size of the arc.
- 9 Click and drag the box anywhere on the drawing.
- 10 Click and drag the frame handles to change the size of the box.  
**Note** Click **Reset** to take another measurement.
- 11 Click **Close** to close the **Measurement** dialog.


**See Also** *Modifying Measurement Markup Entities*

## Measuring an Arc

Use the **Arc** option to define an arc in the drawing and measure its radius, center and diameter.

**Note** To create a markup entity for the measurement, you must ensure that **Add Radius** or **Add Diameter** is selected in the **Measurement** dialog.

- 1 Select **Analysis > Measure** from the Markup menu. The **Measurement** dialog appears.

**Note** You can also click the Arc button  on the Markup toolbar.

- 2 Click the **Arc** tab.
- 3 Select **From 3 Points** if you want to measure the arc between three points. **Snapping Modes** are enabled. Select the **Snapping Modes** that you want to use for measuring. To select all **Snapping Modes** click **All On**. To clear all **Snapping Modes** click **All Off**.  
**See** *EDA Snapping Modes*
- 4 Select **Arc Entity** if you want to measure a predefined arc. **Snapping Modes** are disabled.
- 5 From the **Arc Info** drop-down list, select the unit in which you want to measure the distance of the arc.
- 6 From the **Measured Angle Units** drop-down list, select the unit in which you want to measure the angle.

- 7 Select **Add Radius** if you want measure the radius.  
Select **Add Diameter** if you want to measure the diameter.
- 8 If you selected **From 3 Points**, click three points to define the arc.  
The points are joined by an arc.  
If you selected an **Arc Entity**, click an edge of the arc.  
The arc is highlighted.
- 9 Click to complete the measurement.  
The measured line path, measurement and unit appear as an entity on the current active markup layer. The measurements for center point coordinates, radius, diameter, arc length, start and end of angle and sweep appear in the **Measurement** dialog.
- 10 Click and drag the box anywhere on the drawing.
- 11 Click and drag the frame handles to change the size of the box.  
**Note** Click **Reset** to take another measurement.
- 12 Click **Close** to close the **Measurement** dialog.  
**See Also** *Modifying Measurement Markup Entities*

## Calibrating an Arc

- 1 Measure an arc in the drawing.  
**See** *Measuring an Arc*
- 2 In the **Measurement** dialog, click **Calibrate**.
- 3 The **Distance Calibration** dialog appears displaying the measured distance.
- 4 From the **Measured Rad.** drop-down list, select the unit to which you want to calibrate the distance.
- 5 Click **Calibrate to** and enter a value if you want to calibrate to a value.  
Click **Set Factor** and enter a value if you want to calibrate by a factor.
- 6 Click **OK**.  
The calibration result appears in the **Measurement** dialog.
- 7 Click **Close** to close the **Measurement** dialog.

## Marking up 3D Files




When marking up 3D files, you can attach text or a note, as well as create markup measure entities. The measure options in Markup mode work slightly different than in View mode.

**Note** When you are creating a markup entity, you can press **Escape** to cancel.

## 3D Snapping Modes


The **Snapping Modes** available allow you to select or snap to different entity types on a model. For example, if you select **Vertex**, all vertices are highlighted and when you move the cursor over a vertex, a snap box appears.

The Snapping Modes allow you to snap to vertices, edges, faces, planes and arcs.

Button	Snap to	Description
	Vertex	Vertices are highlighted on the model. When moving the cursor over a vertex, a snap box appears.
	Edge	Edges are highlighted on the model. When moving the cursor over an edge, a snap circle appears.
	Face	Faces are highlighted when you move the cursor over a face and a snap triangle appears.

## Attaching a Note

- 1 Select **Entities > Note** from the Markup menu. The **Attach to** dialog appears.
 

**Note** You can also click the Note button  from the Markup toolbar.
- 2 In the **Attach to** dialog, click the entity type that you want to attach the note to.
 

**See 3D Snapping Modes**
- 3 Select the entity on the model that you want to attach a note to. The **Note** dialog appears.
- 4 Type the text that you want in the note.
- 5 To change the font, select **Font** and font type.
- 6 Close the **Note** dialog.
 


The note symbol appears on the entity and in the **Markup Navigation Tree**.
- 7 Right-click outside the note area to complete the modification.
 

**Note** To edit a note, double-click on the note to open the **Note** dialog.

**Note** Whenever an entity is attached to a 3D model, the anchor point (the point at which the entity is attached) is highlighted by a small square. The square is

visible only when the anchor point is visible. This feature allows you to precisely identify the location of the anchor point and whether the associated entities are visible or hidden.

## Attaching Text

- 1 Select **Entities > Text** from the Markup menu.  
The **Attach to** dialog appears.  
**Note** You can also click the Text button  from the Markup toolbar.
- 2 In the **Attach to** dialog, click the entity type that you want to attach the text.  
**See 3D Snapping Modes**
- 3 Click the entity on the drawing that you want to attach text.  
The **Text** dialog appears.
- 4 To change the font, click **Font**. The **Font** dialog appears.  
From the **Font** drop-down list, select the type of font.  
From the **Size** drop-down list, select the size of font.  
Select the font style and type the text that you want to attach, then click **OK**.  
The text appears on the entity and in the **Markup Navigation Tree**.
- 5 Right-click outside the text area to complete the modification.  
**Note** To edit text, double-click on the text to open the **Text** dialog.

**Note** Whenever an entity is attached to a 3D model, the anchor point (the point at which the entity is attached) is highlighted by a small square. The square is visible only when the anchor point is visible. This feature allows you to precisely identify the location of the anchor point and whether the associated entities are visible or hidden.








## Creating 3D Markup Measure Entities

When marking up 3D files, you can create markup measure entities. The measure options in Markup mode work slightly different than in View mode.

When measuring in Markup mode, the specified measurement lines and values are displayed on the current active markup layer as entities. These entities can be moved, resized, hidden or deleted.

**Note** When you are creating a markup entity, you can press **Escape** to cancel. AutoVue provides the option to “snap” to different entity types on the model.

In Markup mode, you can choose from several measurement options to create markup measure entities. You can access the measurement options from the **Analysis > Measure** menu. The options are:

Name	Description
Angle	<p>Measure the precise angle between three vertices or any two edges, planes or faces.</p> <p>From the toolbar, click the Angle button .</p>
Arc	<p>Measure the precise radius, length and angle of any arc and calculate the center point location.</p> <p>From the toolbar, click the Arc button .</p>
Distance	<p>Measure the precise distance between any two Vertex, Edge, Midedge, Arc Center or Face.</p> <p>From the toolbar, click the Distance button .</p>
Minimum Distance	<p>Measure minimum distance between any two Vertex, Edge, Midedge, Arc Center or Face.</p> <p>From the toolbar, click the Minimum Distance button .</p>
Edge Length	<p>Measure the precise length of an edge.</p> <p>From the toolbar, click the Edge Length button .</p> <p><b>Note</b> You cannot create a Markup measure entity when measuring the length of an edge.</p>
Face Surface	<p>Measure the precise surface area.</p> <p>From the toolbar, click the Face Surface button .</p> <p><b>Note</b> You cannot create a Markup measure entity when measuring surface area.</p>
Vertex Coordinates	<p>Provide the coordinates of each vertex.</p> <p>From the toolbar, click the Vertex Coordinates button .</p>


## Measuring Distance



Use the **Distance** option to measure the precise distance between two vertices, edges, mid-edges, arc centers, faces or any combination of entity types.

**Note** When measuring the distance between faces, if the faces are parallel, AutoVue compares the shortest distance between the parallel faces.

**Note** If you want a markup entity for the measurement, you must ensure that **Add dimensions** is selected in the **Measurement** dialog.

- 1 Select **Analysis > Measure** from the Markup menu.  
The **Measurement** dialog appears.

**Note** You can also click the Distance button  on the Markup toolbar.

- 2 Click the **Distance** tab.
- 3 From the **Measured Distance Units** drop-down list, select the unit in which you want to measure the distance.
- 4 Click the **From** arrow  to select the entity type that you want to measure from.
- 5 Select the **Snapping Modes** that you want to use for measuring.  
**See 3D Snapping Modes**  
All entities of the selected entity types are highlighted on the model.
- 6 On the model, select the entity you want to measure from.  
**Note** If you want to take more than one measurement from the same starting point, click **Fix Position**.
- 7 Click the **To** arrow  to select the entity type that you want to measure to.
- 8 Select the **Snapping Modes** that you want to select as the end point for the measurement.  
All entities of the selected entity types are highlighted on the model.
- 9 On the model, select the entity you want to measure to.
- 10 Click again to complete the measurement.  
The measured line path appears as an entity on the current active markup.
- 11 Drag to move the measured line path.
- 12 Click on the measured line path.  
The measurement and unit appear as an entity on the current active markup layer. The measured distance, Delta-X, Delta-Y and Delta-Z appear in the **Measurement** dialog.
- 13 Click and drag the frame handles to change the size of the box.  
**Note** Click **Reset** to take another measurement.
- 14 Click **Close** to close the **Measurement** dialog.

See Also *Modifying Measurement Markup Entities*

## Calibrating Distance


- 1 Measure the distance between two points.  
**See *Measuring Distance***
- 2 In the **Measurement** dialog, click **Calibrate**.
- 3 The **Distance Calibration** dialog appears displaying the measured distance.
- 4 In the **Measured Distance** drop-down list, select the unit to which you want to calibrate the distance.
- 5 Click **Calibrate to** and enter a value if you want to calibrate the distance to a value.  
Click **Set Factor** and enter a value if you want to calibrate the distance by a factor.
- 6 Click **OK**.  
The calibration result appears in the **Measurement** dialog.
- 7 Click **Close** to close the **Measurement** dialog.


## Measuring Minimum Distance

With the **Minimum Distance** option you can measure the minimum distance between model parts, as well as any two points from the selection sets: vertices, edges, mid-edges, arc centers, faces or any combination of entity types.

**Note** If you want a markup entity for the measurement, you must ensure that **Add dimensions** is selected in the **Measurement** dialog.

- 1 Select **Analysis > Measure** from the AutoVue main menu.  
The **Measurement** dialog appears.

**Note** You can also click the Minimum Distance button  on the AutoVue toolbar.

- 2 Click the **Min. Distance** tab.
- 3 Click  **Set 1** point.
- 4 Click **Entity** if you want to measure the distance between model parts.  
**Snapping Modes** are disabled.  
Click **Geometry** if you want to measure the distance between entity types.  
**Snapping Modes** are enabled.
- 5 If you selected **Entity**, select a part or parts on the model.

The model part(s) appears in the list under **Set 1** and are highlighted on the model and in the **Model Tree**.

If you selected **Geometry**, select the **Snapping Modes** that you want to use for measuring.

**See 3D Snapping Modes**

All entities of the selected entity type are highlighted on the model.

Select the entity or entities on the model.

The selected entities appears in the list under **Set 1** and are highlighted on the model.

**Note** To reset a **Set**, click **Clear**. To clear items from a **Set**, select the items and press the **Delete** key. To deselect a part or entity type on the model, press the **Ctrl** key and left-click the part or entity type.

- 6 Click  **Set 2** point.

- 7 Repeat step 5.

The model part appears in the list under **Set 2**.

- 8 From the **Measured Min Distance Units** drop-down list, select the unit in which you want to measure the distance.

- 9 Click **Compute**.

The minimum distance from the first set of entities to the second set is highlighted by a line. The measured line path, measurement and unit appear as an entity on the current active markup layer. The X, Y and Z coordinates for **Position1** and X, Y and Z coordinates for **Position2** appear in the **Measurement** dialog.

**Note** Click **Reset** to take another measurement.

- 10 Click **Close** to close the **Measurement** dialog.

**See Also** *Modifying Measurement Markup Entities*


## Measuring an Angle

Use the **Angle** option to measure the precise angle between three vertices, any two edges, planes or faces or any combination of entity types.

If you want a markup entity for the measurement, you must ensure that **Add dimensions** is selected in the **Measurement** dialog.

- 1 Select **Analysis > Measure** from the Markup menu.

The **Measurement** dialog appears.

**Note** You can also click the Angle button  on the Markup toolbar.

- 2 Click the **Angle** tab.

- 3 Select the **Snapping Modes** that you want to use for measuring.

**See 3D Snapping Modes**

All entities of the selected entity types are highlighted on the model.

- 4 To measure the angle between an entity type and a plane, select the checkbox beside **Plane**, then from the drop-down list select the plane.
- 5 From the **Measured Angle Units** drop-down list, select the unit in which you want to measure the angle.
- 6 On the model, click points to define the angle.  
Angle arms appear with an arc connecting them.
- 7 Click again to complete the measurement.  
The measured line path, measurement and unit appear as an entity on the current active markup layer. The measurement appears in the **Measurement** dialog.
- 8 Drag to change the size of the arc.
- 9 Click and drag the frame handles to change the size of the box.  
**Note** Click **Reset** to take another measurement.
- 10 Click **Close** to close the **Measurement** dialog.


**See Also** *Modifying Measurement Markup Entities*

## Measuring an Arc

Use the **Arc** option to measure the precise radius, length and angles of any arc on the model. It also calculates the center point location.

**Note** If you want a markup entity for the measurement, you must ensure that **Add dimensions** is selected in the **Measurement** dialog.

- 1 Select **Analysis > Measure** from the Markup menu.  
The **Measurement** dialog appears.

**Note** You can also click the Arc button  on the Markup toolbar.

- 2 Click the **Arc** tab.
- 3 Select **Arc Entity** if you want to measure a predefined arc.  
All arc and circles are highlighted on the model. **Snapping Modes** are disabled.
- 4 Select **From 3 Points** if you want to measure the arc between three points.  
**Snapping Modes** are enabled.  
Select the **Snapping Modes** that you want to use for measuring.

**See 3D Snapping Modes**

All entities of the selected entity types are highlighted on the model.

- 5 From the **Arc Info Dist. Units** drop-down list, select the unit in which you want to measure the arc distance.

- 6 From the **Angles Units** drop-down list, select the unit in which you want to measure the angle.
- 7 If you selected **From 3 Points**, click three points to define the arc.  
The points are joined by an arc.  
If you selected **Arc Entity**, click the edge of an arc.  
The arc is highlighted.
- 8 Click to complete the measurement.  
The measured line path, measurement and unit appear as an entity on the current active markup layer. The measurements for center point coordinates, radius, diameter, arc length, start and end of angle and sweep appear in the **Measurement** dialog.
- 9 Click and drag the box anywhere on the markup.  
Click and drag the frame handles to change the size of the box.  
**Note** Click **Reset** to take another measurement.
- 10 Click **Close** to close the **Measurement** dialog.  
**See Also** *Modifying Measurement Markup Entities*

## Calibrating an Arc

- 1 Measure an arc on the model.  
**See** *Measuring an Arc*
- 2 In the **Measurement** dialog, click **Calibrate**.
- 3 The **Calibration** dialog appears displaying the measured distance.
- 4 From the **Measured Rad.** drop-down list, select the unit to which you want to calibrate the distance.
- 5 Click **Calibrate to** and enter a value if you want to calibrate to a value.  
Click **Set Factor** and enter a value if you want to calibrate by a factor.
- 6 Click **OK**.  
The calibration result appears in the **Measurement** dialog.
- 7 Click **Close** to close the **Measurement** dialog.

## Measuring Vertex Coordinates

The **Vertex Coordinates** option provides the coordinates of vertices on the model.

- 1 Select **Analysis > Measure** from the AutoVue main menu.  
The **Measurement** dialog appears.

**Note** You can also click the Vertex Coordinates button  on the AutoVue toolbar.

- 2 Click the **Vertex** tab.  
All vertices on the model are highlighted.
- 3 Double-click the vertex whose coordinates you want to add to the Markup.  
The **X**, **Y** and **Z** coordinates appear in a tooltip.
- 4 Select the vertex.  
The **X**, **Y** and **Z** coordinates and unit appear as an entity on the current active markup layer and in the **Measurement** dialog.
- 5 Click and drag the box anywhere on the markup.  
Click and drag the frame handles to enlarge the box.
- 6 To remove the highlighted vertices on the model, click **Close** in the **Measurement** dialog.

**Note** You can also remove the highlighted vertices by selecting **Analysis > Measure > Vertex** again.

**See Also** *Modifying Measurement Markup Entities*

# Printing

With AutoVue, you can print and preview files. Original files can be printed on their own or with associated Markups and Overlays. You can also choose which Markup layers to make visible so that they can print.

With the **Batch Print** option, you can send a list of files to print at the same time.

When printing a file, there are print properties that you can define. The properties are:

Option	Description
Print	Define the print options. <b>See <i>Configuring the Print Options</i></b>
Margins	Define the margin settings. <b>See <i>Setting the Print Margins</i></b>
Headers/Footers	Define the headers/footers to be included on every page printed. <b>See <i>Adding a Header/Footer</i></b>
Watermark	Define the watermark to be included on every page printed. <b>See <i>Adding a Watermark</i></b>
Stamps	Define the stamp to be included on every page printed. <b>See <i>Adding a Stamp</i></b>
Pen Settings	Change the thickness assigned to a pen. <b>See <i>Assigning Pen Settings</i></b>

## Print Options


With the **Options** tab, you can define print options for the printed file. The options are:

Option	Type	Description
Print to File		Click to print to file and not to a printer.

Option	Type	Description
Modify		Sets printer properties, such as printer, paper size, orientation, etc.
Scaling	Fit to page	Scales the image to fit on the output page.
	Factor	Scales the image according to the scaling factors that you have manually entered in the input fields. <b>Note</b> Units can be entered as inches, millimeters or pixels.
	Scale	Scales the image according to percentage. You can select a predefined scaling factor or manually enter a customer scaling factor. <b>Note</b> Decimal places are accepted.
Document Pages		Sets the document pages to print: <b>All</b> , <b>Current</b> or <b>Range</b> .
Alignment/Offset		Specifies where the drawing will appear on the print out.
Page Area	Extents	Prints the extents of the document.
	Displayed	Prints the area displayed in the View window.
	Limits	Limits printing to one page when the scaling options selected causes a single document page to span over multiple printer pages. <b>Note</b> Option is only enabled when <b>Current</b> is selected for Document Pages.
	Selected	Prints the area selected in the View window. <b>Note</b> Option will only be enabled when <b>Current</b> is selected for Document Pages.
Force to Black		Forces all colors to black.
Output a single page		Prints file on a single page.
Print Row Headers		Prints row headers. <b>Note</b> Option is only enabled for spreadsheets, archive and database files.

Option	Type	Description
Print Column Headers		Prints column headers. <b>Note</b> Option is only enabled for spreadsheets, archive and database files.
Partial Preview		Displays a view of the printer page, highlighting the printable area.
Number of Copies		Select the number of copies you want to print of the file.

## Configuring the Print Options


- 1 Select **File > Print** from the AutoVue main menu. The **Print Properties** dialog appears.  
**Note** You can also click the Print button  on the AutoVue toolbar.
- 2 Click the **Options** tab.
- 3 Configure the print options.  
**See *Print Options***
- 4 Configure other print options.  
**See *Adding a Header/Footer***  
***Setting the Print Margins***  
***Adding a Watermark***  
***Adding a Stamp***  
***Assigning Pen Settings***
- 5 To view a partial view of the file, click **Partial Preview**. The **Partial Preview** dialog appears.  
**See *Partial Preview of a File***
- 6 Click **OK** to print.  
The **Print** dialog appears indicating the document is printing.  
**See Also *Previewing a File Before Printing***

# Print Margins

With the **Margin** tab, you can define the top, bottom, right and left margins for the printed file. You can define:

Option	Description
Margins	Set the value for the <b>Left, Top, Right</b> and <b>Bottom</b> margins.
Minimum	Sets the acceptable minimum margins for the selected printer.
Override printer-minimum margins	If selected, overrides the minimum margins for the selected printer.
Units	Specify the unit for the margins.

## Setting the Margins

- 1 Select **File > Print** from the AutoVue main menu.  
The **Print Properties** dialog appears displaying the **Options** tab.  
  
**Note** You can also click the Print button  on the AutoVue toolbar.
- 2 Click the **Margins** tab.
- 3 Enter the margin size that you want for **Left, Top, Right** and **Bottom** or click **Minimum** if you want to set the margins to the minimum acceptable for the selected printer.  
Select the checkbox **Override printer-minimum margins** if you want to override the minimum margins set for the printer.  
**Note** When you click **Minimum**, the minimum margins allowable automatically appear in the **Margins**.
- 4 From the **Units** drop-down list, select the unit in which you want to set the margins at.
- 5 Configure other print options.  
**See** *Configuring the Print Options*  
*Adding a Header/Footer*  
*Adding a Watermark*  
*Adding a Stamp*  
*Assigning Pen Settings*
- 6 To view a partial view of the file, click **Partial Preview**.

The **Partial Preview** dialog appears.

**See *Partial Preview of a File***

7 Click **OK** to print.

The **Print** dialog appears indicating the document is printing.

**See Also *Previewing a File Before Printing***

## Header/Footer

From the **Headers/Footers** tab of the **Print Properties** dialog, you can define the headers and footers that you want to print on every page of the document. You can enter the text manually or choose from a list of **Insert Codes**.


The list of insert codes are:

- %f: Full path of document
- %v: Document Drive
- %d: Document Directory
- %b: Document Base name
- %e: Document file extension
- %n: Total document pages
- %p: Current page number
- %N: Total tiled-pages
- %P: Current tile number
- %Y: Date: Year
- %M: Date: Month
- %D: Date: Day
- %W: Date: Day of week
- %H: Time: Hour
- %U: Time: Minute
- %S: Time: Seconds
- %r: New line
- %F: Native Print Settings (Excel)

**Note** A literal percentage mark is entered manually as %%.

## Adding a Header and Footer

In the **Headers/Footers** tab, you can manually enter text or choose from a list of **Insert Codes** to appear in the headers and footers. You can also print system variables.

- 1 Select **File > Print** from the AutoVue main menu.  
The **Print Properties** dialog appears displaying the **Options** tab.  
**Note** You can also click the Print button  on the AutoVue toolbar.
- 2 Click the **Headers/Footers** tab.
- 3 Click in the **Left, Center** or **Right** text box to specify where you want the text to appear in the header and footer, then enter the text.  
**Note** You can have text appear in the **Left, Center** and **Right** of a header and footer.
- 4 To **Insert Code** in the header or footer, click **Left, Center** or **Right**, then select a code from the drop-down list.  
For example, if you select **%n: Total document pages** the total number of pages for the selected file will appear in the header and footer.
- 5 To change the Font, click **Font**. The **Font** dialog appears.  
Configure the font, then click **OK**.
- 6 In the **Print Properties** dialog, configure other print properties.  
**See** *Configuring the Print Options*  
*Setting the Print Margins*  
*Adding a Watermark*  
*Adding a Stamp*  
*Assigning Pen Settings*
- 7 To view a partial view of the file, click **Partial Preview**.  
The **Partial Preview** dialog appears.  
**See** *Partial Preview of a File*
- 8 Click **OK** to print.  
The **Print** dialog appears indicating the document is printing.  
**See Also** *Previewing a File Before Printing*

## Native Print Settings

You can choose to include predefined headers and footers when printing an Excel file from AutoVue.

- 1 From the **Print Properties** dialog, click the **Headers/Footers** tab.
- 2 Under **Headers** and **Footers**, click inside the **Left, Center** and **Right** boxes corresponding to the header or footer position in the original file.
- 3 Select **%F: Native Print Settings (Excel)** from the **Insert Code** drop-down list.
- 4 Click **OK** to print.  
The Excel file's headers and footers are printed.

# Watermarks

With the **Watermark** tab, you can specify a watermark that will appear on a printed file. When printing a watermark, it appears transparent on the file contents. You can choose a horizontally or vertically oriented watermark.

In addition to entering text, you can:

- set the type, size and style of font
- insert Watermark information
- print system variables


To insert Watermark information, AutoVue provides a list of codes that you can choose from. These codes are:

- %f: Full path of document
- %v: Document Drive
- %d: Document Directory
- %b: Document Base name
- %e: Document file extension
- %n: Total document pages
- %p: Current page number
- %N: Total tiled-pages
- %P: Current tile number
- %Y: Date: Year
- %M: Date: Month
- %D: Date: Day
- %W: Date: Day of week
- %H: Time: Hour
- %U: Time: Minute
- %S: Time: seconds
- %r: New line

**Note** A literal percentage mark is entered manually as %%.

## Adding a Watermark

- 1 Select **File > Print** from the AutoVue main menu.  
The **Print Properties** dialog appears displaying the **Options** tab.

**Note** You can also click the Print button  on the AutoVue toolbar.

- 2 Click the **Watermark** tab.
- 3 Enter the **Watermark Text** that you want to appear on the file.

To insert a code in the watermark, select a code from the **Insert Code** drop-down list.

For example, if you select **%n: Total document pages**, the total number of pages for the selected file will appear in the Watermark.


**Note** You can insert more than one code.

- 4 To set the orientation of the watermark, click **Diagonal, Horizontal or Vertical**.
- 5 To change the Font, click **Font**. The **Font** dialog appears. Configure the font, then click **OK**.
- 6 In the **Print Properties** dialog, configure other print properties.  
**See** *Configuring the Print Options*  
*Setting the Print Margins*  
*Adding a Header/Footer*  
*Adding a Stamp*  
*Assigning Pen Settings*
- 7 To view a partial view of the file, click **Partial Preview**. The **Partial Preview** dialog appears.  
**See** *Partial Preview of a File*
- 8 Click **OK** to print.  
 The **Print** dialog appears indicating the document is printing.  
**See Also** *Previewing a File Before Printing*

## Assigning Pen Settings

From the **Pen Settings** tab of the **Print Properties** dialog, you can set the thickness of the color indices for the print file.

**Note** AutoVue uses the default pen color indices of the native document for the vector file being viewed. You will not be able to change the color assigned to a pen with AutoVue.

- 1 Select **File > Print** from the AutoVue main menu.  
 The **Print Properties** dialog appears displaying the **Options** tab.  
**Note** You can also click the Print button  on the AutoVue toolbar.
- 2 Click the **Pen Settings** tab.
- 3 Under **From/To**, select the **Color Index** that you want to assign a new pen thickness.  
**Note** To change more than one color indices, press the **Shift** or **Ctrl** key while selecting.

- 4 From the **Units** drop-down list, select the unit of measure that you want to set the thickness.
- 5 Enter the new thickness.  
The new **Thickness** appears beside the **Color Index**.
- 6 In the **Print Properties** dialog, configure other print properties
- 7 Configure other print options.

**See** *Configuring the Print Options*

*Setting the Print Margins*

*Adding a Header/Footer*

*Adding a Watermark*

*Adding a Stamp*

- 8 To view a partial view of the file, click **Partial Preview**.  
The **Partial Preview** dialog appears.

**See** *Partial Preview of a File*

- 9 Click **OK** to print.

The **Print** dialog appears indicating the document is printing.

**Note** Pen settings are stored in \*.c2t files. The **Current Pen Settings** drop-down list displays all existing \*.c2t files for the current file. The default pen settings are stored in default.c2t and alternate pen settings are stored in alt.c2t.

**See Also** *Previewing a File Before Printing*

## Creating a New Pen Setting

- 1 Set the thickness for the color indices that you want.  
**See** *Assigning Pen Settings*
- 2 Click **Save As**. The **Save As** dialog appears.  
Enter a **File Name** with a .c2t extension, then click **OK**.  
The new pen setting appears in the **Current Pen Settings** drop-down list.
- 3 In the **Print Properties** dialog, click **OK** to print.  
The **Print** dialog appears indicating the document is printing.

## Deleting a Pen Setting

- 1 Select the pen setting that you want to delete from the **Current Pen Settings**.
- 2 Click **Delete**.  
The pen setting disappears from the list.
- 3 Click **Cancel** to close the **Print Properties** dialog.

## Partial Preview of a File

The **Partial Preview** dialog displays the printable area on top of the page area so that users can have a clear idea of what will be printed.


**Note** Option is only enabled when **Current** is selected from **Document Pages**.

- 1 Configure the print properties.  
**See** *Configuring the Print Options*  
*Setting the Print Margins*  
*Adding a Header/Footer*  
*Adding a Watermark*  
*Adding a Stamp*  
*Assigning Pen Settings*
- 2 Click **Partial Preview** in the **Print Properties** dialog.  
The **Partial Print Preview** dialog appears. The **Partial Preview** dialog highlights the area that will be printed. The **Paper size**, **Printable Area** and **Drawing Area** are displayed.
- 3 Click **OK** to close the **Partial Preview** dialog.  
**See Also** *Previewing a File Before Printing*

## Previewing a File Before Printing

You can preview a print copy of the current active file on screen according to your printer's capabilities and the print property settings.

- 1 View the file in AutoVue.
- 2 Select **File > Print Preview** from the AutoVue main menu.  
The **Print Properties** dialog appears.


**Note** You can also click the Print Preview button  on the AutoVue toolbar.

- 3 Configure the print properties.  
**See** *Configuring the Print Options*  
*Setting the Print Margins*  
*Adding a Header/Footer*  
*Adding a Watermark*  
*Adding a Stamp*  
*Assigning Pen Settings*

- 4 Click **OK**.  
The file appears in Print Preview Mode in the **Print Preview** window.  
**Note** You can print the file from the **Print Preview** window by clicking **Print**. You can also zoom in and out of a file, as well as navigate from one page to another of a multi-page file.
- 5 Click **Close** to close the **Print Preview** window.

## Printing a File

In AutoVue you can print original files along with their Markup files and selected Markup layers together so that they appear as one file.

- 1 Open the file you want to print in AutoVue.  
To print the associated Markups, open the Markup file(s) you want to print. If you are printing Markup file(s) and you want to print the visible layers, select **Modify > Markup Layers** from the Markup menu, then from the **Markup Layers** dialog select the Markup layers you want visible.
- 2 Select **File > Print** from the AutoVue main menu.  
The **Print Properties** dialog appears displaying the **Options** tab.  
**Note** You can also click the Print button  on the AutoVue toolbar.
- 3 Configure the print properties.  
**See** *Configuring the Print Options*  
*Setting the Print Margins*  
*Adding a Header/Footer*  
*Adding a Watermark*  
*Adding a Stamp*  
*Assigning Pen Settings*
- 4 To view a partial view of the file, click **Partial Preview**.  
The **Partial Preview** dialog appears.  
**See** *Partial Preview of a File*
- 5 Click **OK** to print.  
The **Print** dialog appears indicating the document is printing.  
**See Also** *Previewing a File Before Printing*

# Batch Printing

With the **Batch Print** option you can send a list of files to print at the same time. You can also generate a batch by simultaneously opening all the files included in the batch print.

- 1 Select **File > Batch Print** from the AutoVue main menu.  
The **Batch Print** dialog appears.
- 2 To add a file to the **List of files to be printed**, click **Add**. The **Open** dialog appears.  
Enter the **File name** or browse to locate the file(s) that you want to add, then click **Open**.  
The file(s) appears in the **List of files to be printed**.  
**Note** To add more files to the list, repeat steps 2 to 4. To remove a file(s), select the file from the **List of files to be printed** and click **Remove**.
- 3 Click **OK** in the **Batch Print** dialog.  
The **Print Properties** dialog appears.
- 4 Configure the print properties.  
**See** *Configuring the Print Options*  
*Setting the Print Margins*  
*Adding a Header/Footer*  
*Adding a Watermark*  
*Adding a Stamp*  
*Assigning Pen Settings*
- 5 Click **OK** to print.  
The **Print** dialog appears indicating the document is printing.

# Customizing AutoVue

There are configuration options that allow you to customize the AutoVue work environment. You can define the type of information copied to the clipboard, create tools to automate a variety of functions, including creating a hot key or access key. You can also customize toolbars and thumbnails to display according to your preferences. You can access the configuration options from the **Options** menu.

## Defining the Clipboard

With the **Clipboard Options** you can define the type of information copied to the clipboard for later transfer to other applications.

The types of information that you can copy for raster, vector, spreadsheet, document and database files are:

Type	Description
DIB	The acronym for Device Independent Bitmap and refers to the hardware information that is used to create a conversion bitmap.
Bitmap	A rectangular array of colors representing a pixel bit map image.
Palette	Refers to color image information.
Metafile	A file storing the commands necessary for a Windows application to recreate a vector format image.
Text	Refers to ASCII formatted text.
RTF	Acronym for Rich Text Format and refers to the formatting information found in documents that allow fonts, margins and tabs to remain in documents.
Include Headings	Refers to displaying the row and column titles for databases and spreadsheets.

To define clipboard options:

- 1 Select **Options > Clipboard** from the AutoVue main menu.

- The **Clipboard Options** dialog appears.
- 2 Under the different file types, click the type of information that you want to copy to the clipboard.
  - 3 Click **OK**.

## Copying Information

- 1 Select **Edit > Select** from the AutoVue main menu.
- 2 Click and drag to select the area you want to copy.
- 3 Select **Edit > Copy**.  
The information is copied to the clipboard.
- 4 Launch the application that you want to copy the information to.
- 5 Paste the information.

## Tools

Tools are shortcuts for commonly repeated tasks. You can create tools to automate a variety of function such as importing objects, files and applications into the user interface; running a script file; connecting AutoVue to Dynamic Data Exchange (DDE) servers and linking to Dynamic Link Library (DLL) loads.

## Adding a Tools Menu Item

- 1 Select **Options > Customize Tools** from the AutoVue main menu.  
The **Add Tool Menu Item** dialog appears.
- 2 Click **Add**.  
The **Configure Tools Menu Item** dialog appears.
- 3 Enter a **Menu Item Name**.
- 4 Click a **Menu Item Action**.
- 5 Click **Application** to launch an outside application.  
Click **Script File** to launch a script file.  
Click **DDE Server** to send DDE commands to a server application.  
Click **DLL** to invoke a DLL.
- 6 Enter the name and path of the executable file, or click **Browse** to locate the specific file or application.  
If you selected **Application**, click **Configure**. The **Link to Application** dialog appears. Enter the **Command Line** to launch an application, then click **OK**.

If you selected **Script File**, click **OK**.

If you selected **DDE Server**, click **Configure**. The **Link to DDE** dialog appears. Enter the **Topic** and **Commands**, click **Start Application**, then click **OK**.

If you selected **DLL Load**, click **Configure**. The **Link to DLL** dialog appears. Enter the **Entry Function** to invoke a DLL, then click **OK**.

7 Enter a **Menu Item Description**.

8 Click **OK**.

The **Menu Item** appears under **Options > Customize Tools**.

9 Click **OK** to close the **Add Tool Menu Item** dialog.

## Creating a Hot Key

1 Select **Options > Customize Tools** from the AutoVue main menu. The **Add Tool Menu Item** dialog appears.

2 Click **Add**.

The **Configure Tools Menu Item** dialog appears.

3 Enter an ampersand (&) before the **Menu Item Name**.

For example, if you entered the menu item name **&Application**. The letter **A** after the **&** will be the hotkey.

4 Click **OK**.

The menu item appears under **Options > Customize Tools** with the letter **A** underlined.

5 Click **OK** to close the **Add Tool Menu Item** dialog.

**Note** To activate the hotkey, hold the **Alt** key while pressing **T** and then **A**.

## Modifying a Tools Menu Item

1 Select **Options > Customize Tools** from the AutoVue main menu. The **Add Tool Menu Item** dialog appears.

2 Under **Menu Contents**, select the item that you want to modify.

3 Click **Modify**.

The **Configure Tools Menu Item** dialog appears.

4 Make the necessary changes.

5 Click **OK**.

6 Click **OK** to close the **Add Tool Menu Item** dialog.

## Moving a Tools Menu Item

1 Select **Options > Customize Tools** from the AutoVue main menu.

- The **Add Tool Menu Item** dialog appears.
- 2 From the **Menu Contents** list, select the item that you want to move.
  - 3 Click **Up** or **Down** to move the item to where you want in the list.
  - 4 Click **OK** to close the **Add Tool Menu Item** dialog.

## Deleting a Tools Menu Item

- 1 Select **Options > Customize Tools** from the AutoVue main menu.  
The **Add Tool Menu Item** dialog appears.
- 2 From the **Menu Contents** list, select the item that you want to delete.
- 3 Click **Delete**.  
The item disappears from the list.
- 4 Click **OK** to close the **Add Tool Menu Item** dialog.

## Customizing Toolbars

In AutoVue, you can customize the toolbars to have them float freely or docked to the window frame. You can also change the background color of the toolbars.

- 1 Select **Options > Customize Toolbars** from the AutoVue main menu.  
The **Toolbar Settings** dialog appears.
- 2 Click the checkbox beside the toolbars that you want to display or clear the checkmark beside the toolbars that you want to hide.
- 3 Click the **Toolbar button size** that you want the buttons to appear on the toolbars.
- 4 Click **OK**.  
The selected toolbars are changed.

## Configuring the Mail Utility

At the time of installation, AutoVue integrates with MAPI compliant mail utilities that are installed on your computer, such as Microsoft Outlook. Electronic mail can then be accessed from within AutoVue, with the option to send a message only, send a message with links to Markup files or send a message with copies of Markup files.

The graphical interface and mailing options that are available to you are determined by the MAPI compliant mail utility you are using. AutoVue automatically attaches the current active file to messages when the **Mail** option is

activated. However, Markup files associated with the original file are left for you to select and attached to your mail message.

To configure the mail utility:

- 1 Select **Options > Configure Mail** from the AutoVue main menu. The **Mail Options** dialog appears.
- 2 From the **Mail using** drop-down list, select the type of MAPI compliant mail utility you are using.
- 3 Click the **Mailing Preferences** that you want.
- 4 Click **OK** to close the **Mail Options** dialog.

## Activating the Mail Utility

At the time of installation, AutoVue integrates with MAPI compliant mail utilities that are installed on your computer, such as Microsoft Outlook.

From AutoVue, you can access electronic mail with the option to send a message only, send a message with links to Markup files or send a message with copies of Markup files, for more information *see **Configuring the Mail Utility***.

To access electronic mail:

- 1 Select **File > Mail** from the AutoVue main menu. The mail utility installed on your computer is launched.  
**Note** When saving a Markup file, you can click **Notify** from the **Save** or **Save As** dialog to launch the mail utility.


# Thumbnails

Thumbnails allow you to build a visual representation of the entire contents of a directory in a thumbnails folder. Miniature visuals of the thumbnails folder file contents is created to help you preview files.

Also available is a generic customized icon that is particularly helpful for identifying files that are more readily acknowledged by their file type. For example, a word-processing document located in a directory where the majority of the files are graphic formats. As files are modified, their thumbnails can be updated quickly and easily. AutoVue stores thumbnails information in the **avwin/folders** directory.

## Customizing Thumbnails

You can customize thumbnails to display according to your preferences.

- 1 Select **Options > Configure Thumbnails** from the AutoVue main menu. The **Configure Thumbnails** dialog appears.  
**Note** You can also configure thumbnails by selecting **Thumbnails > Configuration** from the **Thumbnails** window.
- 2 Select the **Size** in pixels of the thumbnails.  
**Note** You can customize the size of the thumbnails by clicking **Custom** and entering a value.
- 3 Enter the **Space** between thumbnails.  
**Note** The space between thumbnails must be between 2 and 20.
- 4 Click the **File Details** that you want to display in the thumbnail. Click **Full** if you want to display the filename, size, date and time of creation. Click **Partial** if you want to only display the filename.
- 5 Click **OK**.
- 6 To close the **Thumbnails** window, select **Thumbnail > Exit Thumbnails** or click the Exit Thumbnails button .

## Creating a Thumbnail Folder

**Note** If a thumbnails folder already exists for the current directory, the **Thumbnails** window will appear displaying the thumbnails.

- 1 Select **Options > Display Thumbnails** from the AutoVue main menu.

The **New Folder** dialog appears.

**Note** You can also click the Display Thumbnails button  on the AutoVue toolbar.

- 2 Click **Create**.

AutoVue creates the thumbnails folder for the current directory and the **Thumbnails** window appears displaying the thumbnails for that folder.

**Note** This may take a few minutes depending on the size and number of files in the folder. If the thumbnails folder is taking too long to create, you can skip it by clicking **Skip** in the **New Folder** dialog. To resume creating the folder, select **Thumbnail > Update All**.

## Viewing a Thumbnail Folder

You can display thumbnail folders from **View** or **Markup** mode.

**Note** If a thumbnails folder does not exist for the current directory, the **New Folder** dialog appears with the option to create a new folder.

- 1 Select **Options > Display Thumbnails** from the AutoVue main menu. The **Thumbnails** window appears.

**Note** You can also click the Display Thumbnails button  on the AutoVue toolbar.

- 2 Select **Thumbnail > Folder**.

The **Browse for Folder** dialog appears.

- 3 Browse to locate the thumbnails folder that you want to view.
- 4 Click **OK**.

The thumbnails for the selected folder appear in the **Thumbnails** window.

- 5 To close the **Thumbnails** window, select **Thumbnail > Exit**

**Thumbnails** or click the Exit Thumbnails button .


## Sorting a Thumbnail Folder

- 1 Select **Options > Display Thumbnails** from the AutoVue main menu. The **Thumbnails** window appears.

**Note** You can also click the Display Thumbnails button  on the AutoVue toolbar.



- 2 Select **Thumbnail > Folder**.

The **Browse for Folder** dialog appears.

- 3 Browse to locate the thumbnails folder that you want to sort.
- 4 Click **OK**.  
The thumbnails for the selected folder appear in the **Thumbnails** window.
- 5 Select **Thumbnail > Sort** and the option that you want to sort by.  
**Note** A checkmark beside the sort option indicates the current sort order.
- 6 To sort the thumbnails in ascending or descending order, select **Thumbnail > Sort Order** then **Ascending** or **Descending**.
- 7 To close the **Thumbnails** window, select **Thumbnail > Exit Thumbnails** or click the Exit Thumbnails button  .


## Viewing a Thumbnail



Files are instantly accessible from the Thumbnails window.

- 1 Select **Options > Display Thumbnails** from the AutoVue main menu.  
The **Thumbnails** window appears.  
**Note** You can also click the Display Thumbnails button  on the AutoVue toolbar.
- 2 Select **Thumbnail > Folder**.  
The **Browse for Folder** dialog appears.
- 3 Browse to locate the thumbnails folder that you want to view.
- 4 Click **OK**.  
The thumbnails for the selected folder appear in the **Thumbnails** window.
- 5 Select the thumbnail that you want to view.
- 6 Select **Thumbnail > Load File** or click the Load File button  .  
The thumbnail is launched in the AutoVue workspace.  
**Note** You can also launch a thumbnail by double-clicking on the thumbnail.



## Updating Thumbnails

You can update all the thumbnails in the current folder or update one or more thumbnails in the current folder.

- 1 Select **Options > Display Thumbnails** from the AutoVue main menu.  
The **Thumbnails** window appears.  
**Note** You can also click the Display Thumbnails button  on the AutoVue toolbar.

- 2 Select **Thumbnail > Folder**.  
The **Browse for Folder** dialog appears.
- 3 Browse to locate the thumbnails folder that you want to view.
- 4 Click **OK**.  
The thumbnails for the selected folder appear in the **Thumbnails** window.
- 5 Select the thumbnail(s) that you want update.  
**Note** To select more than one thumbnail, press the **Shift** or **Ctrl** key while selecting.
- 6 Select **Thumbnail > Updated Selected**.  
The selected thumbnails are updated in the current folder.  
**Note** To update all thumbnails, select **Thumbnail > Update All** or click the Update All button  on the Thumbnails toolbar.
- 7 To close the **Thumbnails** window, select **Thumbnail > Exit Thumbnails** or click the Exit Thumbnails button .

## Viewing the Properties of a Thumbnail

- 1 Select **Options > Display Thumbnails** from the AutoVue main menu.  
The **Thumbnails** window appears.  
**Note** You can also click the Display Thumbnails button  on the AutoVue toolbar.
- 2 Select **Thumbnail > Folder**.  
The **Browse for Folder** dialog appears.
- 3 Browse to locate the thumbnails folder that you want to view.
- 4 Click **OK**.  
The thumbnails for the selected folder appear in the **Thumbnails** window.
- 5 Select the thumbnail that you want to view the properties.
- 6 Select **Thumbnail > Properties**.  
The **Properties** dialog appears.
- 7 Click **Close**.
- 8 To close the **Thumbnails** window, select **Thumbnail > Exit Thumbnails** or click the Exit Thumbnails button .


# Converting Thumbnails

- 1 Select **Options > Display Thumbnails** from the AutoVue main menu. The **Thumbnails** window appears.

**Note** You can also click the Display Thumbnails button  on the AutoVue toolbar.

- 2 Select **Thumbnail > Folder**. The **Browse for Folder** dialog appears.
- 3 Scroll to locate the thumbnails folder that you want to print.
- 4 Click **OK**. The thumbnails for the selected folder appear in the **Thumbnails** window.
- 5 Select the thumbnail(s) that you want to convert.

**Note** To select more than one thumbnail, press the **Shift** or **Ctrl** key while selecting.

- 6 Select **Thumbnail > Convert**. The **Batch Convert** dialog appears.
- 7 Customize the conversion options.  
**See *Batch Conversion***
- 8 Click **OK**.
- 9 To close the **Thumbnails** window, select **Thumbnail > Exit Thumbnails** or click the Exit Thumbnails button .

# Printing Thumbnails


- 1 Select **Options > Display Thumbnails** from the AutoVue main menu. The **Thumbnails** window appears.

**Note** You can also click the Display Thumbnails button  on the AutoVue toolbar.

- 2 Select **Thumbnail > Folder**. The **Browse for Folder** dialog appears.
- 3 Scroll to locate the thumbnails folder that you want to print.
- 4 Click **OK**. The thumbnails for the selected folder appear in the **Thumbnails** window.
- 5 Select the thumbnail(s) that you want to print.

**Note** To select more than one thumbnail, press the **Shift** or **Ctrl** key while selecting.

- 6 Select **Thumbnail > Print**.

- The **Print Properties** dialog appears.
- 7 Customize the print properties.  
**See *Printing***
  - 8 Click **OK**.
  - 9 To close the **Thumbnails** window, select **Thumbnail > Exit Thumbnails** or click the Exit Thumbnails button  .

# Full Text Extraction

The Full Text Extraction application provides a facility for obtaining all the textual information from a selected file. This may be used by a search engine to provide document indexing services. It eliminates duplicates and enables the search for all type of documents, including CAD.

**Note** Auto Text Extraction is not available for raster files.

## Using the Full Text Extraction Utility

- 1 Select **File > Tools > Auto Text Extraction** from the AutoVue main menu.  
The **Automatic Text Extraction** dialog appears.  
**Note** You can also open the **Auto Text Extraction** dialog by opening the file `Outtext.exe` located in the directory `C:\Program Files\av\avwin`.
- 2 In the **From** text box, enter the path and filename of the file from which the text is to be extracted.
- 3 In the **To** text box, enter the path and filename or click **Browse** to locate the file to which the text is to be copied.  
**Note** File extensions include `.txt` and `.out`. The default is `text.out` located in the `temp` directory. If the file does not exist, the file will be created for you.
- 4 Click **Display Output Contents** if you want to preview the extracted text under **Contents**.
- 5 Click **Extract**.  
The path and filename, and the text appears in the **Output Contents**.
- 6 Click **Close** to close the **Automatic Text Extraction** dialog.

## CAD Information Extraction

This utility allows users to extract XRef information from a CAD file. This is useful for batch importing AutoCAD, MicroStation and various other types of CAD files into a document management system.

- 1 Select **File > Tools > Auto Text Extraction** from the AutoVue main menu.

The **CAD/Doc Text Extraction** dialog appears.

- 2 In the **From** text box, enter the path and filename of the file from which the text is to be extracted.
- 3 In the **To** text box, enter the path and filename or click **Browse** to locate the file to which the text is to be copied.

**Note** File extensions include `.txt` and `.out`. The default is `text.out` located in the `temp` directory. If the file does not exist, the file will be created for you.

- 4 Click **Display Output Contents** if you want to preview the extracted text under **Contents**.
- 5 Click **Extract**.  
The path and filename, and the text appears in the **Output Contents**.
- 6 Click **Close** to close the **CAD/Doc Text Extraction** dialog.

**Note** Examples of integrations can be found in the `Integrat` directory of the AutoVue CD.

# Package Files

AutoVue can retrieve files stored in Package File Format and then load them in AutoVue. The Package File Format includes the base file, external references and Markups. All the basic Markup capabilities are supported: adding a new Markup for a base file, consolidating multiple Markups into a Markup, modifying an existing Markup and saving it as a new one.

AutoVue provides Package File functionality through a:

- Package File Creation Tool
- Markup Import Tool
- Package File DMAPI Component
- Package File Library

## Package File Creation Tool

When a package file is created, the base file's identity is obtained, along with the list of associated files, e.g. Xrefs and Markups. Users have the option to choose which of the associated files to include in the output file.

**Note** The Package File Creation Tool is only available with Vuelink for Documentum.

## Markup Import Tool

Users have the option of choosing which Markup files to import for a package file or whether a file to be imported is to keep its default identity or be imported under another user ID.

**Note** Markup Import Tool is only available with Vuelink for Documentum.

## DMAPI Component

The key component in the package file creation facility is a DMAPI component. This component enables AutoVue to treat package files as DMSes containing one viewable file.

# Viewing

Package files are opened in the same way as ordinary files. Users have access to all the external references and Markups bundled with the base file. Users have the option to modify existing Markups or create new ones to be associated with the package file.



## Numerics

- 2D Files 14
- 2D Vector Files 27
- 3D Files 84

## A

- About Help 3
- Adding an Overlay 33
- Advanced search 3D 137
- Aligning model parts 112
- Ambient lighting 98
  - set 98
- Ascend Hierarchy 48
- Associations 13
  - activate 13
  - create 13
  - remove 13
- Attaching a Note 3D 218
- Attaching Text 219
- Attaching Text 3D 219
- Attribute search 3D 136
- Attributes
  - adjust transparency 97
  - change color 96
  - change mesh resolution 97
  - change visibility 96
  - display 95
  - render modes 95
- AutoVue 1
- AutoVue Basics 8
  - menu bar 8
  - quick menus 9
  - status bar 9
  - toolbars 9

## B

- Batch
  - convert 23

- Bill of Material
  - 3D 132
  - EDA 61
- Birds Eye 17, 18
- Blocks 31
  - view 31
- Bookmarks Tab 84
- Browse Files 11

## C

- CAD Information Extraction 250
- Calibrate
  - Distance Measurement tool 144
- Calibrate Arc
  - 2D non-vector 27
  - 2D vector 40
  - 3D 144
  - EDA 75
- Calibrate Distance
  - 2D non-vector 25
  - 2D vector 37
  - 3D 141
  - EDA 71
- change locale of AutoVue 4
- Changing layer color 53
- Changing the order of layers 50
- Clipboard
  - copy information 240
  - define 239
- Collapsing 88
- Compare
  - 2D 32
    - options 32
    - result window 32
    - scale and offset 33
  - 3D 129
    - options 129
    - result window 129
    - tree 129
- EDA

- PCB with artwork 61
- Compare 3D
  - files 129
- Compare Entity Sets 130
- Configure
  - 2D 152
    - options
      - raster files 148
      - vector files 147
    - snap settings 152
  - 3D 153
    - Manipulator 157
    - Measurement 151
  - EDA 157
    - color options 160
- Configure Paths 148
  - font 150
  - markup 151
  - symbol 150
  - Xrefs 149
- contact Cimmetry Systems 2
- Convert
  - 2D 19
    - batch 23
    - options 20
    - pen settings 22
  - 3D 90
    - options 90
- Cross Probing 58
  - between files 58
  - same file 59
  - show net connectivity 60
- Cross Section 116
- Customizing AutoVue 239
  - clipboard 239
  - thumbnails 244
  - toolbars 242
  - tools 240
- Cut-through 116

## D

- Default View 100
- Defining layer sets 55
- Delete
  - hyperlink 196
  - Markup entities 179
  - Markup layer 171
  - tools menu item 242
- Deleting a Hyperlink 196
- Deleting layer sets 56
- Descend Hierarchy 48
- Design Hierarchy 48
  - ascend 48
  - descend 48
- Design Verification
  - design rules checks 63
- Design Verification 62
  - clearances 63
  - electrical 63
  - manufacturing 63
  - verify design 65
- Directional lighting 98
  - set 99
- DMAPI Component 252
- Drawing Information 28
  - view details of an entity 28
  - view information for a set of entities 29
  - view tags/attributes 29

## E

- EDA Files 41
- enter Markup mode 174
- enter new License Key 5
- Entity
  - view details 28
  - view information 29
- Entity Browser 44, 66
  - attribute search 68

- search 67
- Entity Properties 45, 103
  - net 47
  - view attributes 104
  - view extents 106
  - view mass properties 105
    - configure 106
  - viewing 46
- Entity search 3D 134
- entity sets 129
- Exiting AutoVue 2
- Expanding 88
- Explode 119, 120
  - animated 119
  - maximum depth 119
  - save view 120
  - scroll 120
  - show arrows 119
- Exporting file versions 7

**F**

- File
  - browse 11
- File Properties 12
  - file information 12
  - native 12
  - resource information 12
- File Versions 7
  - exporting 7
  - viewing 7
- Files
  - archive 11
  - open 10
  - view multiple 10
- Filtering entity types 44
- Flip 16
  - both axes 16
  - horizontal axis 16
  - none 16
  - vertical axis 16

- Freestyle
  - contiguous 187
  - non-contiguous 187
- Full Text Extraction 250
- Full Text Extraction Utility 250

## G

- Global Axes 85

## H

- Help About... 3
- Hiding model parts 86
- Hierarchy 48
  - ascend 48
  - descend 48
- Hyperlinks 194
  - create 194
  - delete 196
  - edit 195
  - fire 195
  - view history 196
  - view list 196

## I

- Image 17
  - anti-alias 17
  - contrast 17
  - invert 17
- Implode 120
- Interference Check 126
  - options 126
  - perform 126
  - results options 128
- Introduction 1

## L

- Layer Sets 55
  - delete 56

- save 57
- view 55
- Layers
  - change color 53
  - change order 50
  - EDA 49
  - modify visibility 51
  - set printability 52
  - sort 54
  - view 2D 30
  - view 3D 103
- Layers Sets
  - define 55
- License Key enter new 5
- Light 98
  - add source 99
  - ambient 98
    - set 98
  - change color 99
  - directional 98
    - set 99
  - remove source 100
  - set ambient lighting 98

## M

- Magnify Glass 17, 18
- Magnify Window 17, 19
- Mail Utility 243
  - activate 243
  - configure 242
- Manipulating Views
  - 2D 15
  - 3D 92
  - EDA 28
- Manipulators 108
  - panning 108
  - rotating 109
  - scaling 110
- Marking Up Documents 1
- Marking up Files 162

- Markup
  - 2D 184
    - add leader 187
    - add text 188
    - contiguous freestyle 187
    - create OLE entity 191
    - entities 184
      - arc 184
      - box 184
      - circle 185
      - closed polyline 185
      - cloud 185
      - filled box 185
      - freestyle 185
      - highlight 185
      - leader 185
      - line 186
      - note 186
      - OLE 186
      - polyline 186
      - signoff 186
      - symbol 186
      - text 186
    - non-contiguous freestyle 187
    - note
      - add 189
      - view list 189
    - signoff
      - create 190
      - rescind 190
    - symbols 192
      - add symbol to file 192
      - add symbol to library 193
      - create library 192
      - delete library 194
      - delete symbol from library 193
      - edit library information

- 194
  - 3D 217
    - attach note 218
    - attach text 219
  - change active 167
  - consolidate files 172
  - create file 164
  - export file 166
  - import file 166
  - Navigation Tree 162
  - open file 165
  - save existing file 165
  - save new file 165
  - saved states 164
  - set active 166
  - user information 164
- Markup Calibrate Arc
- 2D non-vector 201
  - 2D vector 209
  - 3D 225
  - EDA 217
- Markup Calibrate Distance
- 2D vector 205
  - 3D 222
  - EDA 213
- Markup entities 172, 181
- arrow
    - change arrow style 176
  - arrow style 173, 182
  - assign same color 178
  - change line color 177
  - color 173, 181, 183
    - change fill color 177
    - change fill type 178
  - delete 172, 179
  - delete all 172
  - edit 174
  - fill type 173, 183
  - go to 174
  - group 173, 175
  - hide 174, 175
  - line style 173, 181
    - change 176
  - line thickness 173, 182
    - change 175
  - move 174
  - select 174
  - ungroup 175
- Markup Import Tool 252
- Markup Layers 168
- change active layer 169
  - change color 169
  - create 168
  - delete 171
  - move entity 171
  - rename 170
  - set active layer 168
  - toggle 170
- Markup Measure
- 2D non-vector 197
  - 2D vector 202
  - 3D 219, 220
  - EDA 209
- Markup Measure Angle
- 2D non-vector 200
  - 2D vector 207
  - 3D 223
  - EDA 215
- Markup Measure Arc
- 2D non-vector 201
  - 2D vector 208
  - 3D 224
  - EDA 216
- Markup Measure Area
- 2D non-vector 199
  - 2D vector 206
  - EDA 214
- Markup Measure Cumulative Distance
- 2D non-vector 198

- 2D vector 204
    - EDA 212
  - Markup Measure Distance
    - 2D non-vector 198
    - 2D vector 204
    - 3D 221
    - EDA 211
  - Markup measure entities
    - change symbols 180
    - change units 180
    - delete 172, 180
    - hide 173, 180
    - modify 179
  - Markup Measure Minimum Distance
    - 3D 222
    - EDA 213
  - Markup Measure Vertex 225
  - Measure
    - 2D non-vector 24
    - 2D vector 35
    - 3D 139
      - edge length 145
      - face surface 146
      - vertex coordinates 145
    - EDA 69
  - Measure Angle
    - 2D non-vector 26
    - 2D vector 38
    - 3D 143
    - EDA 73
  - Measure Arc
    - 2D non-vector 26
    - 2D vector 39
    - 3D 143
    - EDA 74
  - Measure Area
    - 2D non-vector 25
    - 2D vector 37
    - EDA 72
  - Measure Distance
    - 2D non-vector 24
    - 2d vector 36
    - 3D 140
    - EDA 71
  - Measure Edge 145
  - Measure Minimum Distance
    - 3D 142
    - EDA 72
  - Menu bar 8
  - Missing XRefs
    - display details 30
  - Mockups
    - create 89
    - delete 89
  - Models Tab 84
  - Modifying layer visibility 51
  - Modifying on Overlay 34
- ## N
- Native Views
    - set 101
  - Navigation Panel 41
    - customize 42
- ## O
- Open
    - file 10
    - multiple windows 10
  - Overlay
    - add 33
  - Overlays 33
    - modify 34
    - remove 34
- ## P
- Package Files 252
    - creation tool 252
    - viewing 253

Page 17  
  next page 17  
  page number 17  
  previous page 17  
Pan 17  
Part Alignment 110  
  constraint types 110  
  constraints types  
    combinations 111  
  fixed 110  
  mobile 110  
  model parts 112  
paths  
  hyperlink 196  
PMI Filtering 107  
  entity  
    align to 108  
    go to 108  
Predefined Views  
  set 101  
Printing  
  batch 238  
  file 237  
  header/footer  
    add 231  
    insert codes 231  
    native settings 232  
  options 227  
    configure 229  
  partial preview 236  
  pen settings  
    assign 234  
    create 235  
    delete 235  
  preview 236  
  set margins 230  
  watermark  
    add 233  
    insert codes 233

## Q

Quick Menus 9

## R

Re-centering 87  
  entire model 87  
  to a model part 87  
  to an entity 87  
Removing an Overlay 34  
Render Modes 95  
  hidden line 95  
  shaded 95  
  shaded wire 96  
  silhouette 96  
  wire polygons 96  
  wireframe 95  
Resetting the transformation 116  
Rotate 16

## S

Saving an Existing Markup File 165  
Saving layer sets 57  
Saving search results 139  
Scale and Offset 33  
Search  
  2D text 14  
    perform 14  
Search 3D 133  
  advanced 137  
  attribute 136  
  entity 134  
  save 139  
Section plane  
  cut options 117  
  define 117  
  export 118  
  options 116  
Select

- 2D 12
  - 3D
    - model parts 85
  - EDA
    - Entity Browser 44
  - Selecting entities 43
    - entity browser 44
    - navigation panel 43
    - workspace 43
    - zoom to 45
  - Selecting model parts 85
    - identical parts 86
    - model tree 85
    - workspace 85
  - Selecting views 31
  - Setting printability for layers 52
  - Show Tree 18
  - Showing net connectivity 46
  - Showing net instances 47
  - Snap Modes
    - 2D vector 35, 203
    - 3D 140, 218
    - EDA 70, 210
  - Sorting layers 54
  - Standard Views
    - set 101
  - Starting AutoVue 2
  - Status bar 9
  - Symbols 192
    - add symbol to file 192
    - add symbol to library 193
    - create library 192
    - delete library 194
    - delete symbol from library 193
    - edit library information 194
    - scale anisotropic 192
    - scale isotropic 192
- T**
- Thumbnails 244
  - convert 248
  - create folder 244
  - customize 244
  - print 248
  - sort folder 245
  - update 246
  - view 246
  - view folder 245
  - view properties 247
- Toolbars 9
- customize 242
- Tools 240
- add menu item 240
  - create hotkey 241
  - modify menu item 241
  - move menu item 241
- Transformation 113
- reset 116
  - setting values 115
  - using illustration buttons 114
- U**
- User Coordinate Systems 121
    - define 124
    - delete 126
    - modify 124
    - orientation options 123
    - position options 121
    - set active 125
  - User Defined View 101
  - User-defined View
    - creating 101
    - deleting 102
- V**
- Vector\_Distance 36
  - View 3D
    - default 100
  - View Point 2D

- specify 31
- Viewing blocks 31
- Viewing details of an entity 28
- Viewing entity information 29
- Viewing entity properties 46
- Viewing file versions 7
- Viewing layer sets 55
- Viewing layers
  - 2D 30
  - 3D 103
- Viewing List of Hyperlinks 196
- Viewing multiple files 10
- Viewing Tags/Attributes 29
- Viewing Xrefs 30
- Viewpoint 3D 102
- Views 3D 100
  - display perspective projection 102
  - set native 101
  - set standard or predefined 101
  - user-defined 101
  - viewpoint 102
- Views Tab 84

## **X**

- XRefs
  - missing 30
  - view 30

## **Z**

- Zoom 15
  - fit 15
    - both 15
    - horizontal 16
    - vertical 15
  - full resolution 15
  - in 15
  - out 15
  - previous 16