

# *SunFDDI™ SBus Adapter 4.0 User's Guide*



The Network Is the Computer™

**Sun Microsystems Computer Company**

2550 Garcia Avenue  
Mountain View, CA 94043 USA  
415 960-1300 fax 415 969-9131

Part No.: 802-5144-10  
Revision A, November 1995

© 1995 Sun Microsystems, Inc.  
2550 Garcia Avenue, Mountain View, California 94043-1100 U.S.A.

All rights reserved. This product and related documentation are protected by copyright and distributed under licenses restricting its use, copying, distribution, and decompilation. No part of this product or related documentation may be reproduced in any form by any means without prior written authorization of Sun and its licensors, if any.

Portions of this product may be derived from the UNIX<sup>®</sup> and Berkeley 4.3 BSD systems, licensed from UNIX System Laboratories, Inc., a wholly owned subsidiary of Novell, Inc., and the University of California, respectively. Third-party font software in this product is protected by copyright and licensed from Sun's font suppliers.

RESTRICTED RIGHTS LEGEND: Use, duplication, or disclosure by the United States Government is subject to the restrictions set forth in DFARS 252.227-7013 (c)(1)(ii) and FAR 52.227-19.

The product described in this manual may be protected by one or more U.S. patents, foreign patents, or pending applications.

#### TRADEMARKS

Sun, the Sun logo, Sun Microsystems, and Solaris are trademarks or registered trademarks of Sun Microsystems, Inc. in the U.S. and certain other countries. UNIX is a registered trademark in the United States and other countries, exclusively licensed through X/Open, Ltd. OPEN LOOK<sup>®</sup> is a registered trademark of Novell, Inc. PostScript and Display PostScript are trademarks of Adobe Systems, Inc. All other product names mentioned herein are the trademarks of their respective owners.

All SPARC trademarks, including the SCD Compliant Logo, are trademarks or registered trademarks of SPARC International, Inc. SPARCstation, SPARCserver, SPARCengine, SPARCstorage, SPARCware, SPARCcenter, SPARCclassic, SPARCcluster, SPARCdesign, SPARC811, SPARCprinter, UltraSPARC, microSPARC, SPARCworks, and SPARCcompiler are licensed exclusively to Sun Microsystems, Inc. Products bearing SPARC trademarks are based upon an architecture developed by Sun Microsystems, Inc.

The OPEN LOOK and Sun<sup>™</sup> Graphical User Interfaces were developed by Sun Microsystems, Inc. for its users and licensees. Sun acknowledges the pioneering efforts of Xerox in researching and developing the concept of visual or graphical user interfaces for the computer industry. Sun holds a non-exclusive license from Xerox to the Xerox Graphical User Interface, which license also covers Sun's licensees who implement OPEN LOOK GUIs and otherwise comply with Sun's written license agreements.

X Window System is a product of the Massachusetts Institute of Technology.

THIS PUBLICATION IS PROVIDED "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, OR NON-INFRINGEMENT.

THIS PUBLICATION COULD INCLUDE TECHNICAL INACCURACIES OR TYPOGRAPHICAL ERRORS. CHANGES ARE PERIODICALLY ADDED TO THE INFORMATION HEREIN; THESE CHANGES WILL BE INCORPORATED IN NEW EDITIONS OF THE PUBLICATION. SUN MICROSYSTEMS, INC. MAY MAKE IMPROVEMENTS AND/OR CHANGES IN THE PRODUCT(S) AND/OR THE PROGRAM(S) DESCRIBED IN THIS PUBLICATION AT ANY TIME.



Please  
Recycle



Adobe PostScript

## *FCC Class B Notice — United States*

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference.
2. This device must accept any interference received, including interference that may cause undesired operation.

**Note:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/television technician for help.

### **Shielded Cables**

Connections between the workstation and peripherals must be made using shielded cables in order to maintain compliance with FCC radio frequency emission limits.

### **Modifications**

Modifications to this device, not approved by Sun Microsystems, Inc., may void the authority granted to the user by the FCC to operate this equipment.

## *DOC Class B Notice — Canada*

This digital apparatus does not exceed the Class B limits for radio noise emission for a digital apparatus as set out in the Radio Interference Regulations of the Canadian Department of Communications.

## *Avis Concernant les Systèmes Appartenant à la Classe B du DOC — Canada*

Le présent appareil numérique n'émet pas de bruits radioélectriques dépassant les limites applicables aux appareils numériques de la classe B prescrites dans le Règlement sur le brouillage radioélectrique édicté par le ministère des Communications du Canada.

*Japan*

## 第二種VCCI基準に関するお知らせ

この装置は、第二種情報装置（住宅地域またはその隣接した地域において使用されるべき情報装置）で住宅地域での電波障害防止を目的とした情報処理装置等電波障害自主規制協議会（VCCI）基準に適合しております。

この装置は、第一種または第二種ワークステーションのオプションです。本装置を使用する場合、システムとしての適合レベルは下記の通りです。

第一種ワークステーション：第一種情報装置

第二種ワークステーション：第二種情報装置

本装置を使用する第一種ワークステーションは、第一種情報装置（商工業地域において使用されるべき情報処理装置）となります。従って、住宅地域またはその隣接した地域で使用すると、ラジオ、テレビジョン受信機等に受信障害を与えることがあります。

本装置を使用する第二種ワークステーションは、第二種情報装置（住宅地域またはその隣接地域において使用されるべき情報装置）となります。従って、本装置をラジオ、テレビジョン受信機に近接してご使用になると、受信障害の原因となることがあります。

取扱説明書に従って正しい取り扱いをして下さい。

# Contents

---

## *Part 1 —Installing and Configuring SunFDDI*

<b>1. Introducing SunFDDI</b> .....	<b>1</b>
Feature Summary .....	1
Conformance .....	2
<b>2. Hardware Installation</b> .....	<b>3</b>
Device Instances and Device Names .....	4
Installing SunFDDI SBus Cards .....	4
Connecting Fiber Optic Cables .....	6
Connecting Single-Attached Stations and Concentrators ..	7
Connecting Dual-Attached Stations and Concentrators ...	8
Link Status Indicator (Diagnostic LED) .....	8
<b>3. Installing and Configuring SunFDDI     in a Solaris 2.x Environment</b> .....	<b>9</b>
Installation Requirements .....	10
Declaring IP Addresses for SunFDDI .....	10
Installing and Configuring SunFDDI .....	11

---

▼ Load and Mount the CD-ROM .....	11
▼ Install SunFDDI Using pkgadd.....	11
▼ Finish the Installation .....	15
▼ Check the Installation .....	16
Installing SunNet Manager Agents for SunFDDI .....	17
▼ Use nf_install_agents in a Solaris 2.x Environment	17
Removing SunFDDI.....	19
▼ Remove SunFDDI:.....	19
<b>4. Installing and Configuring SunFDDI in a Solaris 1.x Environment .....</b>	<b>21</b>
Installation Requirements.....	22
Declaring IP Addresses for SunFDDI .....	22
Installing and Configuring SunFDDI .....	23
▼ Load and Mount the CD-ROM .....	23
▼ Install SunFDDI Using cdm .....	24
▼ Check the Installation .....	30
Installing SunNet Manager Agents for SunFDDI .....	31
▼ Use nf_install_agents in a Solaris 1.x Environment	31
Removing SunFDDI.....	33
▼ Remove SunFDDI .....	33
<b>5. Improving Network Performance .....</b>	<b>37</b>
High Performance FDDI Networks.....	38
Ring Latency Improvement .....	38
Data Throughput Improvement.....	39

---

Send and Receive Buffers . . . . .	39
Performance Across Bridges. . . . .	39
Target Token Rotation Time (TTRT). . . . .	40
Improving Performance in a Solaris 2.x Environment . . . . .	41
Changing the High and Low Water Marks. . . . .	41
▼ Tune the High Water Mark. . . . .	41
▼ Tune the Low Water Mark . . . . .	42
▼ Tune the High and Low Water Marks at Boot Time . . .	43
▼ Tune the Socket Options. . . . .	44
MTU Path Discovery. . . . .	45
▼ Tune the Maximum Transfer Unit (MTU). . . . .	45
▼ Disable MTU Path Discovery. . . . .	45
▼ Tune the Target Token Rotation Time (TTRT) . . . . .	46
Improving Performance in a Solaris 1.x Environment . . . . .	46
▼ Tune the Send and Receive Buffers . . . . .	46
▼ Tune the Socket Options. . . . .	48
▼ Tune the Maximum Transfer Unit (MTU). . . . .	48
▼ Tune the Target Token Rotation Time (TTRT) . . . . .	50
<b>6. Troubleshooting and Diagnostics . . . . .</b>	<b>53</b>
Troubleshooting Checklist . . . . .	54
▼ Check the Connection to the Station. . . . .	54
▼ Check the Connections Between Stations. . . . .	54
▼ Check the Link Status Indicator. . . . .	54
▼ Check the MAC Address . . . . .	55

---

▼ Check the SunFDDI Driver .....	56
▼ Check the IP Addresses .....	56
▼ Check the IP Routing .....	57
▼ Check the Protocol Statistics .....	57
▼ Check the SMT Traffic.....	58
Solving Common Problems .....	59
Running the Hardware Self-Test Program .....	65
▼ Run the Hardware Self-Test: .....	65
Loading the Device Driver Manually (Solaris 2.x).....	66
▼ Configure and Load the Device Driver.....	66
Loading the Device Driver Manually (Solaris 1.x).....	68
▼ Configure and Load the Device Driver.....	68
 <i>Part 2 —Planning and Implementing SunFDDI Networks</i>	
<b>7. FDDI Network Architecture .....</b>	<b>73</b>
FDDI Network Model .....	74
Physical Media Dependent (PMD) Layer .....	75
Physical (PHY) Layer .....	75
Medium Access Control (MAC) Layer .....	76
Station Management (SMT) Layer .....	77
Communication Between FDDI Layers .....	77
FDDI Network Architecture.....	79
FDDI Stations .....	80
FDDI Concentrators.....	82
FDDI Failure Recovery .....	84

---

Station Wrapping . . . . .	84
Optical Bypass Switches . . . . .	86
FDDI Ring Operation . . . . .	89
Unrestricted Asynchronous Transmission . . . . .	89
FDDI Performance . . . . .	91
<b>8. FDDI Network Topologies . . . . .</b>	<b>93</b>
Basic Dual Ring Network . . . . .	94
Advantages . . . . .	95
Disadvantages . . . . .	95
Stand-alone Concentrator . . . . .	96
Advantages . . . . .	97
Disadvantages . . . . .	97
Concentrators with Dual-Homing . . . . .	98
Advantages . . . . .	99
Disadvantages . . . . .	99
Tree of Concentrators . . . . .	100
Advantages . . . . .	101
Disadvantages . . . . .	101
Ring of Trees . . . . .	102
Advantages . . . . .	103
Disadvantages . . . . .	103
Mixed Fiber/UTP Network . . . . .	104
Advantages . . . . .	105
Disadvantages . . . . .	105

---

Mixed FDDI/Ethernet Networks . . . . .	106
FDDI/Ethernet IP Router . . . . .	106
A Tree of Concentrators in an Ethernet Network . . . . .	107
A Ring of Trees in an Ethernet Network . . . . .	107
Routes in Mixed FDDI/Ethernet Networks . . . . .	108
<b>9. Using the SunFDDI Network Utilities . . . . .</b>	<b>111</b>
Changing the Default MAC Address (nf_macid) . . . . .	112
▼ Change the Default MAC Address With nf_macid . . . . .	112
Displaying SunFDDI Statistics (nf_stat) . . . . .	114
Displaying Local Interface Statistics . . . . .	114
Displaying Statistics from Neighboring Stations . . . . .	120
Monitoring SMT Frames (nf_smtmon) . . . . .	124
SMT Frame Classes and Types . . . . .	126
Filtering Output from nf_smtmon . . . . .	127
Configuring Synchronous FDDI (nf_sync) . . . . .	128
<b>10. Managing FDDI Stations</b>	
<b>Using SunNet Manager . . . . .</b>	<b>131</b>
Installing the SunNet Manager Agents . . . . .	132
▼ Installing the Standard SNM Agents on a Client . . . . .	132
▼ Install the FDDI Schemas on a Client (Solaris 2.x) . . . . .	133
▼ Install the FDDI Schemas on a Client (Solaris 1.x) . . . . .	135
▼ Install the FDDI Schemas on the Console . . . . .	136
Managing FDDI Networks With SunNet Manager . . . . .	139
▼ Set Up the SunNet Manager Console . . . . .	139

---

▼ Use the SunFDDI Local Agent (nf_fddi) . . . . .	140
▼ Use the SunFDDI Proxy Agent (nf_fddismt7_2) . . . . .	142
Interpreting Traps and Errors . . . . .	144
Mac Address Formats . . . . .	147
<b>11. Developing Applications over SunFDDI . . . . .</b>	<b>149</b>
Developing Applications with DLPI (Solaris 2.x) . . . . .	150
DLPI Connectionless Service Primitives . . . . .	151
DLPI Addressing . . . . .	152
Monitoring the Link Layer with NIT (Solaris 1.x) . . . . .	154
<b>12. Setting Up Servers and Diskless Clients . . . . .</b>	<b>155</b>
Summary of Steps . . . . .	155
Setting Up a Solaris 2.x Server and Diskless Clients . . . . .	156
▼ Set Up a Solaris 2.x Server . . . . .	156
▼ Introduce Diskless Clients to a Solaris 2.x Server . . . . .	157
▼ Update the NIS Server . . . . .	162
▼ Installing the SunFDDI Driver for a Diskless Client . . . . .	163
Setting Up a Solaris 1.x Server and Diskless Clients . . . . .	165
▼ Set Up a Solaris 1.x Server . . . . .	165
▼ Update the Name Service . . . . .	166
▼ Introduce Diskless Clients to a Solaris 1.x Server . . . . .	166
Booting a Diskless Client Over SunFDDI . . . . .	167
▼ Boot Manually . . . . .	167
▼ Boot by Default . . . . .	168

---

<b>A. Frequently Asked Questions .....</b>	<b>171</b>
--	------------

## *Figures*

---

Figure 2-1	Removing Metal Adapter Bracket From Front of Card . . . . .	5
Figure 2-2	Removing Plastic Retainer From Rear of Card . . . . .	6
Figure 2-3	Fiber Optic Cable Connector . . . . .	7
Figure 2-4	S-type Connector Profile. . . . .	7
Figure 2-5	B-type, M-type, and A-type Connector Profiles . . . . .	8
Figure 7-1	FDDI Architectural Model . . . . .	74
Figure 7-2	Communication Between FDDI Layers . . . . .	78
Figure 7-3	Basic FDDI Network Architecture . . . . .	79
Figure 7-4	Single-Attached Station (SAS) . . . . .	80
Figure 7-5	Dual-Attached Station (DAS). . . . .	81
Figure 7-6	Single-Attached Concentrator (SAC) . . . . .	82
Figure 7-7	Dual-Attached Concentrator (DAC). . . . .	83
Figure 7-8	Isolating a Single Station Failure. . . . .	84
Figure 7-9	Isolating a Single Cable Failure . . . . .	85
Figure 7-10	Dual-Attached Station in Wrap Mode . . . . .	86
Figure 7-11	Dual Ring Network Divided by Two Faults . . . . .	87

---

Figure 7-12	Optical Bypass Switch. . . . .	87
Figure 7-13	Optical Bypass Switches used in a Network . . . . .	88
Figure 8-1	Basic Dual Ring Network . . . . .	94
Figure 8-2	Basic Dual Ring Network with Two Faults . . . . .	95
Figure 8-3	Stand-alone Concentrator . . . . .	96
Figure 8-4	Stand-alone Concentrator . . . . .	98
Figure 8-5	Hierarchical Tree of Concentrators . . . . .	100
Figure 8-6	Ring of Trees . . . . .	102
Figure 8-7	Mixed Fiber/UTP Network . . . . .	104
Figure 8-8	Cable between End-Stations and the Concentrator . . . . .	105
Figure 8-9	Basic Mixed FDDI/Ethernet Topology . . . . .	106
Figure 8-10	Tree of Concentrators Attached to an Ethernet Network . . . . .	107
Figure 8-11	Ring of Trees Attached to an Ethernet Network . . . . .	107
Figure 8-12	Routing in an FDDI/Ethernet Internetwork . . . . .	108
Figure 9-1	Normal Sequence of PCM States . . . . .	118
Figure 10-1	Quick Dump (Local Statistics) . . . . .	140
Figure 10-2	Quick Dump (Neighbor Statistics) . . . . .	141
Figure 10-3	SunFDDI Proxy Agent . . . . .	142
Figure 10-4	Specifying the Target Station . . . . .	142
Figure 10-5	Quick Dump (SMT Frames) . . . . .	143
Figure 10-6	Single-Attached Station Disconnected . . . . .	144
Figure 10-7	Single-Attached Station Reconnected . . . . .	145
Figure 10-8	Dual-Attached Station Halted . . . . .	146
Figure 10-9	Dual-Attached Station Restarted . . . . .	146
Figure 11-1	DLPI Access to FDDI . . . . .	150

---

Figure 11-2	DLPI Request/Response Negotiation .....	151
Figure 11-3	SunFDDI DLSAP Format .....	152



## *Tables*

---

Table 4-1	Files and Directories (Solaris 1.x) . . . . .	23
Table 6-1	Problems Installing SunFDDI in a Solaris 2.x Environment . .	59
Table 6-2	Problems Installing SunFDDI in a Solaris 1.x Environment . .	60
Table 6-3	Problems Running SunFDDI . . . . .	60
Table 6-4	Problems Using the SNM Agents for SunFDDI . . . . .	64
Table 11-1	DL_INFO_REQ Frame . . . . .	153



# Preface

---

The *SunFDDI™ SBus Adapter 4.0 User's Guide* describes how to turn your SPARCstation™ or SPARCserver™ into an FDDI station attached to an FDDI network. It is intended for experienced network administrators who are familiar with the SunOS™ 4.x and 5.x operating systems.

The *SunFDDI™ SBus Adapter 4.0 User's Guide* is divided into two parts:

- *Part 1 — “Installing and Configuring SunFDDI,”* describes how to turn your machine into a SunFDDI station. It tells you how to install the SunFDDI SBus card, how to install and configure the SunFDDI device driver, and how to tune your FDDI station to get the best performance. It also includes troubleshooting advice to help you detect and resolve problems with your FDDI network.
- *Part 2 — “Planning and Implementing SunFDDI Networks,”* includes a brief overview of the FDDI protocols, and describes common FDDI network topologies. It tells you how to use the SunFDDI network utilities, how to use a SunNet Manager™ Console to manage your SunFDDI stations, how to develop applications over SunFDDI, and how to boot a diskless station across an FDDI connection.

If you are unfamiliar with FDDI network terminology, or if you are implementing an FDDI network for the first time, read Part 2 first.

---

## *How This Book Is Organized*

### *Part 1 — “Installing and Configuring SunFDDI”*

**Chapter 1, “Introducing SunFDDI,”** describes the SunFDDI 4.0 implementation of the FDDI protocols, and includes a list of the specifications to which it conforms.

**Chapter 2, “Hardware Installation,”** tells you where to find detailed instructions on how to install your SunFDDI SBus card in your machine, and describes how to connect the FDDI cable.

**Chapter 3, “Installing and Configuring SunFDDI in a Solaris 2.x Environment,”** describes how to install the SunFDDI device driver and utilities on machines running a Solaris™ 2.x environment. It includes a description of the post-installation scripts that configure your machine as a FDDI station.

**Chapter 4, “Installing and Configuring SunFDDI in a Solaris 1.x Environment,”** describes how to install the SunFDDI device driver and utilities on machines running a Solaris 1.x environment. It includes a description of the post-installation scripts that configure your machine as a FDDI station.

**Chapter 5, “Improving Network Performance,”** describes the configurable network parameters, and provides general advice on how to obtain the best performance from your network.

**Chapter 6, “Troubleshooting and Diagnostics,”** tells you how to detect and resolve problems with your FDDI network.

### *Part 2 — “Planning and Implementing SunFDDI Networks”*

**Chapter 7, “FDDI Network Architecture,”** provides an overview of the FDDI network model, and describes how FDDI networks operate.

**Chapter 8, “FDDI Network Topologies,”** describes various pure FDDI network topologies, and discusses their relative strengths and weaknesses. It also describes how to implement routing between mixed FDDI and Ethernet networks.

**Chapter 9, “Using the SunFDDI Network Utilities,”** describes the network utilities delivered with SunFDDI, and tells you how to use them to recover network statistics.

---

**Chapter 10, “Managing FDDI Stations Using SunNet Manager,”** describes how to install the SunNet Manager agents for SunFDDI, and how to set up the SunNet Manager console to manage them.

**Chapter 11, “Developing Applications over SunFDDI,”** describes how to create applications that run over SunFDDI, using the DLPI interface for a Solaris 2.x environment, and the `ifnet` interface for a Solaris 1.x environment.

**Chapter 12, “Setting Up Servers and Diskless Clients,”** describes how to set up a server so that you can boot and run diskless clients over an FDDI network.

**Appendix A, “Frequently Asked Questions,”** contains a list of common questions and their responses.

## *UNIX Commands*

This document may not include specific software commands or procedures. Instead, it may name software tasks and refer you to operating system documentation or the handbook that was shipped with your new hardware.

The type of information that you might need to use references for includes:

- Shutting down the system
- Booting the system
- Configuring devices
- Other basic software procedures

See one or more of the following:

- *Solaris 2.x Handbook for SMCC Peripherals* contains Solaris™ 2.x software commands. (*If you are incorporating the software commands in your document, delete this sentence.*)
- On-line AnswerBook™ for the complete set of documentation supporting the Solaris 2.x software environment.
- Other software documentation that you received with your system.

---

## Typographic Conventions

The following table describes the typographic changes used in this book.

Typeface or Symbol	Meaning	Example
AaBbCc123	The names of commands, files, and directories; on-screen computer output	Edit your <code>.login</code> file. Use <code>ls -a</code> to list all files. machine_name% You have mail.
<b>AaBbCc123</b>	What you type, contrasted with on-screen computer output	<pre>machine_name% su Password:</pre>
<i>AaBbCc123</i>	Command-line placeholder: replace with a real name or value	To delete a file, type <code>rm filename</code> .
<b><i>AaBbCc123</i></b>	Book titles, new words or terms, or words to be emphasized	Read Chapter 6 in the <i>User's Guide</i> . These are called <i>class</i> options. You <i>must</i> be root to do this.

## Shell Prompts

The following table shows the default system prompt and superuser prompt for the C shell, Bourne shell, and Korn shell.

Shell	Prompt
C shell	machine_name%
C shell superuser	machine_name#
Bourne shell and Korn shell	\$
Bourne shell and Korn shell superuser	#

---

## *Related Documents*

For a more detailed description of FDDI technology and the relevant FDDI protocols, see:.

---

<b>Title</b>	<b>Author/Publisher</b>	<b>Part Number</b>
<i>Handbook of Computer-Communications Standards, Volume 2,</i>	William Stallings, Macmillan Publishing Company, 1987	
<i>FDDI Technology and Applications</i>	Edited by Sonu Mirchandani & Raman Khanna, John Wiley & Sons, 1993	
<i>FDDI A High Speed Network</i>	Amit Shah & G. Ramakrisnan, Prentice Hall, Inc., 1994	
<i>STREAMS DLPI Specification</i>		800-6915

---

## *Ordering Sun Documents*

The SunDocs Order Desk is a distribution center for Sun Microsystems technical documents. You can use major credit cards and company purchase orders. You can order documents in the following ways.

---

**In the U.S.A.**

Fax 1-801-373-6798

Call 1-800-247-0250

---

**Outside the U.S.A.**

Fax 1-801-373-6798

Call 1-801-342-3450

---

**World Wide Web:** <http://www.sun.com/sundocs/catalog.html>

---

---

## *Sun Welcomes Your Comments*

Please use the *Reader Comment Card* that accompanies this document. We are interested in improving our documentation and welcome your comments and suggestions.

If a card is not available, you can email or fax your comments to us. Please include the part number of your document in the subject line of your email or fax message.

- Email: `smcc-docs@sun.com`
- Fax: SMCC Document Feedback  
1-415-786-6443

*Part 1 — Installing and Configuring  
SunFDDI*

---

---

<i>Feature Summary</i>	<i>page 1</i>
<i>Conformance</i>	<i>page 2</i>

This chapter describes the SunFDDI implementation of the FDDI protocols, including a list of the ANSI/FDDI standards to which it conforms.

## *Feature Summary*

SunFDDI is a combination of hardware and software that turns a SPARCstation or SPARCserver into an FDDI station. There are two hardware options:

- **SunFDDI** — Single-Attached Station (SAS) on Fiber
- **SunFDDI Dual** — Dual-Attached Station (DAS) on Fiber

SunFDDI is a high-speed networking product that provides significantly greater bandwidth (up to 10 times) in comparison to 10 megabit Ethernet networks. It is designed for SPARCstations and SPARCservers running either a Solaris 2.x, or a Solaris 1.x, environment.

SunFDDI does the following:

- Implements FDDI single-attached station (SunFDDI) and FDDI dual-attached station (SunFDDI Dual).

- Provides connection to multimode fiber (SunFDDI and SunFDDI Dual) networks.
- Supports data transfer rates of up to 100 Mbps.
- Provides full support for existing SunOS 5.x and 4.x operating system network services and utilities.
- Provides power-up self test and system diagnostic tests.
- Provides high reliability and availability through distributed, automatic recovery.
- Supports up to four SunFDDI SBus cards installed in one SBus and up to eight SunFDDI SBus cards installed in one machine.
- Supports 12.5 Mbps and 25 Mbps SBus transfer rates.
- Supports 62.5/125 micrometer, multimode fiber (MMF).
- Provides SunNet Manager agents for the effective management of FDDI stations and networks from a centralized SunNet Manager Console. (Requires SunNet Manager 2.2 or later in addition to SunFDDI).
- Complies with the ANSI X3T9.5 standard for single-attached LAN fiber rings and with revision 7.3 of the ANSI/FDDI SMT specification.
- Complies with revision 1496-1993 of the IEEE SBus specification.

## *Conformance*

SunFDDI conforms to the following standards and specifications:

- ANSI/FDDI Medium Access Control (MAC) X3.139-1987
- ANSI/FDDI Physical Layer (PHY) X3.148-1988
- ANSI/FDDI Physical Media Dependent (PMD) X3.166-1990
- ANSI/FDDI Station Management (SMT) X3.299 R7.3 (formally R7.2.99)
- IEEE SBus 1496-1993

<i>Device Instances and Device Names</i>	<i>page 4</i>
<i>Installing SunFDDI SBus Cards</i>	<i>page 4</i>
<i>Connecting Fiber Optic Cables</i>	<i>page 6</i>
<i>Link Status Indicator (Diagnostic LED)</i>	<i>page 8</i>

This chapter tells you where to find step-by-step procedures for installing SBus cards. It describes the convention used to assign device names to SunFDDI SBus cards, and tells you how to connect fiber optic cables.



**Warning** – For your personal safety and to protect your machine, please observe the following precautions when you install an SBus card in a SPARC™ workstation or server:

Before opening your machine, always ensure that the power switch is off (O position). When the power is off, the green light on the front of the machine is unlit and the fan in the power supply is not running. Always take care to protect your equipment from the effects of static electricity.

A lithium battery is molded into the NVRAM–TOD chip on the main logic board. This battery is not a customer replaceable part. Do not attempt to disassemble it or recharge it.

## *Device Instances and Device Names*

You can install a SunFDDI SBus card in any available master SBus slot. SunFDDI supports up to four SunFDDI SBus cards installed in one SBus, and up to eight SunFDDI SBus cards installed in one machine.

SunFDDI 4.0 SBus cards are assigned device names of the form `nf<inst>`, where the instance number `<inst>` is determined by the number and relative positions of the cards installed. When you install a SunFDDI card in your machine for the first time, it has instance number 0 and a device name `nf0`. If multiple cards are installed, the device name `nf0` is associated with the card in the lowest numbered slot, the device name `nf1` is associated with the card in the next highest numbered slot, and so on.

Refer to the hardware installation manual that came with your SPARCstation or SPARCserver for detailed instructions on how to identify the SBus slots in your machine.

---

**Note** – For a machine running Solaris 2.x, if a SunFDDI SBus card is moved from its initial slot to a different one, the operating system will find the device in the new slot and assume that it is a new instance of the device. As a result, the operating system will assign the next instance number to it and there will appear to be two devices installed in the machine.

---

## *Installing SunFDDI SBus Cards*



---

**Caution** – The SunFDDI SBus card is sensitive to static electricity. Always use the wrist strap supplied with SunFDDI when handling the card and ensure that the wrist strap is properly grounded. Handle the SunFDDI SBus card by the edges, and avoid touching any of the components.

---

Refer to the hardware installation manual that came with your SPARCstation or SPARCserver for detailed instructions on how to install an SBus card in your machine.

There are no user-configurable jumpers or switches on the SunFDDI SBus card. Altering any of the components on the card may affect its operation adversely and will render any product warranty void.

To install the SunFDDI SBus card, you may have to remove the metal adapter bracket from the front of the card, and the plastic retainer from the rear of the card.

To remove the metal adapter bracket from the front of the card:

1. Use a Phillips screwdriver to remove the two screws that secure the adapter bracket, to the backplate and lift the adapter bracket off.
2. Keep the screws and adapter bracket in a safe place, in case you need them to install the SBus card in another machine.




Figure 2-1 Removing Metal Adapter Bracket From Front of Card

To remove the plastic retainer from the rear of the card:

1. Bend one leg of the plastic retainer slightly to the outside until it unhooks from the card.
2. Unhook the other leg of the plastic retainer from the card.




Figure 2-2 Removing Plastic Retainer From Rear of Card

## Connecting Fiber Optic Cables

Fiber optic cable is fragile and should not be subjected to mechanical stress or impact. Always observe the following precautions when handling fiber optic cable and connectors:

- Fiber optic cable connectors consist of a ceramic or steel ferrule through which the optical fiber passes. Do not touch the tip of the ferrule, as marring its delicate surface will destroy its ability to transmit light.
- Use the protective caps provided on the fiber optic cable connectors and optic data links whenever the cable is not connected.
- Fiber optic cable has a limited turn radius. Do not bend it in a way that could damage the fiber or cause signal loss.

Fiber optic cable connectors can be cleaned if they become contaminated with dirt or dust, which can cause signal noise on the network. Contact your cable vendor for detailed instructions.

Unpack the cable, remove the plastic protective caps or plugs from each end, and remove the plug from the transceiver unit on the card. Fiber optic cables are usually keyed as shown in Figure 2-3 to prevent accidental “crossing” or “twisting” of the ring by connecting two ports of the same type.




Figure 2-3 Fiber Optic Cable Connector

Some cables are supplied with preset keys; other cables are supplied with keys that must be added by the user, according to the desired configuration. These keys are usually small and easily mislaid. Some cables provide a useful recess in the connector housing in which the keys can be stored.

### *Connecting Single-Attached Stations and Concentrators*

An S-key (or *universal key*) denotes a connector that is plugged into the S-port of a single-attached station or concentrator. This type of connector will plug into any FDDI port, so you must take care if you use it to connect to any other type of station or concentrator. The profile of an S-type connector is shown in Figure 2-4.




Figure 2-4 S-type Connector Profile

## Connecting Dual-Attached Stations and Concentrators

A-keys and B-keys denote connectors that are plugged into dual-attached stations. The two ends of the cable must have keys of different types. The B-type connector is plugged into the B-port of one station; the A-type connector is plugged into the A-port of the next station downstream on the ring.

M-keys denote connectors that are plugged into the M-ports on single-attached and dual-attached concentrators. You must never connect two M-ports together, since this would create an illegal topology called the *tree of rings*. Therefore, you should never have a cable with an M-type connector on both ends.

The profiles of B-type, M-type, and A-type connectors are shown in Figure 2-5.




Figure 2-5 B-type, M-type, and A-type Connector Profiles

## Link Status Indicator (Diagnostic LED)

A link status indicator is mounted on the SunFDDI SBus card. The color of the LED indicates the current status of the connection to the FDDI network as follows:

- off**            driver has not been loaded
- red**            driver loaded, interfaces not configured
- amber**        interfaces configured, no connection to active FDDI network
- green**        connection established to active FDDI network

Refer to Chapter 6, “Troubleshooting and Diagnostics” for more information on diagnosing problems with your FDDI network.

# *Installing and Configuring SunFDDI in a Solaris 2.x Environment*

---



<i>Installation Requirements</i>	<i>page 10</i>
<i>Declaring IP Addresses for SunFDDI</i>	<i>page 10</i>
<i>Installing and Configuring SunFDDI</i>	<i>page 11</i>
<i>Installing SunNet Manager Agents for SunFDDI</i>	<i>page 17</i>
<i>Removing SunFDDI</i>	<i>page 19</i>

This chapter assumes that you have already installed the SunFDDI SBus card in your machine and that you are loading the software from a local CD-ROM drive.

This chapter tells you how to install the SunFDDI device drivers, utilities, and SunNet Manager agent schemas in a Solaris 2.x environment. It includes instructions on how to check your installation, and how to remove the SunFDDI software, if necessary.

If your machine is running a Solaris 1.x environment, see Chapter 4, “Installing and Configuring SunFDDI in a Solaris 1.x Environment” for instructions.

## *Installation Requirements*

### *Hardware and Software Platforms*

SunFDDI is designed for SPARCstations and SPARCservers (32 Mbytes RAM minimum) running a Solaris 2.3 environment or later.

### *Disk Space*

You need a machine with 1600 KBytes of disk space to install SunFDDI in a Solaris 2.x environment.

### *Hostnames and IP Addresses*

You must assign a unique hostname and IP address to each SunFDDI device installed in your machine. If you are installing more than one interface in a single machine, each interface must be connected to a different subnetwork.

## *Declaring IP Addresses for SunFDDI*

You must assign a unique IP address to each SunFDDI interface. If you have more than one IP interface installed in your machine—either multiple SunFDDI interfaces, or some other LAN interface (for example, an Ethernet interface)—each interface must be connected to a different subnetwork.

Before installing the SunFDDI software, update the files on your NIS/NIS+ server to assign IP addresses and hostnames for the SunFDDI interfaces that you are going to configure. If you are not using a name service, update the file `/etc/hosts` on each machine in the network to add the IP addresses and hostnames of the stations attached to the FDDI ring.

The installation script updates the file `/etc/hosts` on the local machine to enter IP addresses and hostnames assigned to the SunFDDI interfaces installed in it.

## Installing and Configuring SunFDDI

Use `pkgadd(1M)` to install unbundled software on machines running a Solaris 2.x environment. See the *Solaris 2.4 Software and AnswerBook Packages Administration Guide* for detailed information on installing software products using `pkgadd`.

### ▼ Load and Mount the CD-ROM

To load the CD-ROM in the CD-ROM drive and mount it on a local directory:

1. **Log in as root or become superuser.**
2. **Place the CD-ROM in its caddy and load the caddy into the CD-ROM drive.**
3. **Mount the CD-ROM on a local directory.**
  - If the Volume Manager (`vold`) is running on your machine, then the CD-ROM is mounted automatically under `/cdrom/fddi_4_0`.
  - If the Volume Manager (`vold`) is not running on your machine, create a directory called `/cdrom/fddi_4_0` and mount the CD-ROM manually:

```
# mkdir /cdrom/fddi_4_0
# /usr/sbin/mount_hfs /dev/dsk/c0t6d0s0 /cdrom/fddi_4_0
```

For detailed instructions on how to load software from a CD-ROM drive mounted on a remote directory, see the *Solaris 2.4 Software and AnswerBook Packages Administration Guide*.

### ▼ Install SunFDDI Using `pkgadd`

1. **Log in as root or become superuser.**
2. **Start `pkgadd` by typing:**

```
# /usr/sbin/pkgadd -d /cdrom/fddi_4_0/Solaris_2.x
```

3. Enter the number that corresponds to the package you want to install and press Return. Respond to any prompts that appear on the command-line. There are two packages associated with SunFDDI. They contain the device drivers and utilities used to manage your SunFDDI station.

```
The following packages are available:
 1 SUNWnfr FDDI/S (Driver)
   (sparc) 4.0
 2 SUNWnft FDDI/S (Man Pages/Utilities)
   (sparc) 4.0

Select package(s) you wish to process (or "all" to process all
packages). (default: all) [?,??,q]:
```

▼ **Install the Device Driver (SUNWnfr)**

The package `SUNWnfr` contains the SunFDDI device driver and the SunNet Manager agent daemon and start-up scripts. By default, the base directory `<basedir>` for this package is `.`. You can change the default base directory for this package when you start `pkgadd(1M)` with the `-R` option. This package must be installed on every machine that runs SunFDDI.

An installation script is executed automatically when you install the SunFDDI device driver (`SUNWnfr`). This script checks that the hardware is installed and displays the number of SunFDDI interfaces that it finds. If there is no hardware installed, the script halts the installation process without installing the software.

**1. Indicate whether you are installing the driver for a diskless client.**

Type `y` if you want to install the driver in the `/export/root/<client>` file system for a diskless client, or type `n` if you are installing the driver for the machine on which you are running the script. You must use `pkgadd` with the `-R` option to change the base directory when you install the driver for a diskless client.

```
Is this install for a diskless client [n] [y,n,?]
```

See Chapter 12, “Setting Up Servers and Diskless Clients” for more information on booting diskless clients across an FDDI network.

**2. The script displays the number of SunFDDI interfaces that it finds, and asks you how many interfaces you want to configure.**

Enter a number in the range 1 to 16, or press Return to accept the default proposed by the script.

```
How many FDDI (nf) interfaces do you want to configure?
```

**3. Type the hostname that you want to associate with the interface.**

Each SunFDDI interface is assigned a device name of the form `nf<inst>`, where the instance number `<inst>` is determined by the number and relative positions of the SunFDDI SBus cards installed, for example:

```
What host name do you want to use for nf<inst>: hysop-nf
```

**4. Type the IP address that corresponds to the hostname or press Return to accept the default IP address.**

If there is already an IP address associated with the hostname, either in the NIS/NIS+ database or in the file `/etc/hosts`, the script offers it as a default IP address. You must assign a unique IP address to each SunFDDI interface. If you have multiple IP interfaces installed in one machine, each interface must be attached to a different FDDI subnetwork.

```
What ip address do you wish to use for hysop-nf [<ip_address>]:
```

**5. Repeat Steps 3 and 4 until you have assigned a hostname and IP address to each of the SunFDDI SBus cards installed in your machine.**

**6. Indicate whether you want the SunNet Manager agents for SunFDDI to start automatically when you reboot the machine.**

Type `y` to start the SunNet Manager agents for SunFDDI automatically. Type `n`, or press Return, if you are not using SunNet Manager to manage your network, if you are running the SunNet Manager agents on another machine, or if you want to start the SunNet Manager agents manually.

```
Do you want to start the SunNet Manager daemons for SunLink FDDI/S
at boot time? [n] [y,n,?,q] y
```

**7. Type `y` to accept the execution of the installation scripts with `superuser` permission.**

```
This package contains scripts which will be executed with superuser
permission during the process of installing the package.
```

```
Do you want to continue with the installation [y,n,?] y
```

The script displays a list of the files that it installs, loads the driver, and configures the IP interfaces automatically.

If the installation is successful, your SunFDDI interfaces are now active. The link status indicator (diagnostic LED) will be **amber** (the interface is configured but not connected), or **green** (the interface is configured and connected to an active network).

▼ **Install the Utilities, Man Pages, and SNM Agents (`SUNWnft`)**

The package `SUNWnft` contains the SunFDDI utilities and man pages. By default, the base directory `<basedir>` for this package is `/opt`. You can change the default base directory when you start `pkgadd(1M)` with the `-R` option. This package can be installed on a server and shared between multiple machines, if required.

An installation script is executed automatically when you install the SunFDDI utilities and man pages (`SUNWnft`):

**1. Type `y` to accept the installation of files with `setuid/setgid` permission.**  
If you are installing the `SUNWnft` package for the first time, this step will be omitted.

```
Do you want to install these setuid/setgid files [y,n,?,q] y
```

**2. Type y to accept the execution of the installation scripts with superuser permission.**

```
This package contains scripts which will be executed with superuser
permission during the process of installing the package.
```

```
Do you want to continue with the installation [y,n,?] y
```

▼ **Finish the Installation**

**1. Type q to stop pkgadd when the list of available packages is displayed again.**

```
The following packages are available:
```

- ```
 1 SUNWnfr FDDI/S (Driver)
    (sparc) 4.0
 2 SUNWnft FDDI/S (Man Pages/Utilities)
    (sparc) 4.0
```

```
Select package(s) you wish to process (or "all" to process all
packages). (default: all) [?,??,q]:
```

**2. Eject the CD-ROM from the CD-ROM drive.**

- If Volume Manager (vold) is running on your machine, then the CD-ROM is unmounted automatically when it is ejected:

```
# eject cdrom
```

- If Volume Manager (vold) is not running on your machine, unmount the CD-ROM before you eject it. Remove the directory that you created:

```
# /usr/sbin/umount /cdrom/fddi_4_0
# eject cdrom
# rmdir /cdrom/fddi_4_0
```

**3. Reboot your machine to ensure correct system operation.**

▼ Check the Installation

To check the installation and configuration of your SunFDDI interfaces:

1. Use `netstat(1M)` to check for SunFDDI interfaces.

SunLink FDDI/S  
interface `nf<inst>` ---->

```
% /usr/bin/netstat -i
Name Mtu   Net/Dest Address   Ipkts Ierrs Opkts Oerrs Collis
Queue
lo0  8232   loopback localhost  21    0    21    0    0    0
le0  1500   our-lan  hysop     2146  0    950   1    13   0
nf0  4352   our-fddi hysop-nf  1086  0    907   0    0    0
```

2. Use `ifconfig(1M)` to check the current state of the SunFDDI interfaces.

```
% /usr/sbin/ifconfig nf0
nf0: flags=863<UP,BROADCAST,NOTRAILERS,RUNNING,MULTICAST> mtu 4352
    inet <host_address> netmask <netmask> broadcast <ip_address>
    ether <mac_address>
```

3. Use `ping(1M)` to check that you can send and receive data across the FDDI connection.

If your SunFDDI station is attached to an active FDDI network, try to access a remote station.

```
% /usr/sbin/ping hemlock-nf
hemlock-nf is alive
```

Provided the installation was successful, your SunFDDI station is now active, and you can send and receive data across an FDDI connection.

To obtain optimum performance from your FDDI network, you may need to tune the configurable network parameters. See Chapter 5, “Improving Network Performance” for detailed instructions.

If you have problems configuring or using your SunFDDI station, see Chapter 6, “Troubleshooting and Diagnostics” for help.

## Installing SunNet Manager Agents for SunFDDI

Use `nf_install_agents` to install the SunNet Manager agents for SunFDDI. This script copies the FDDI schema files to the directory in which the standard agents are installed and updates the configuration files for SunNet Manager. Run `nf_install_agents` on each SunNet Manager Console, and on each SunFDDI station you want to manage using SunNet Manager.

### ▼ Use `nf_install_agents` in a Solaris 2.x Environment

1. **Log in as root or become superuser.**
2. **Start `nf_install_agents` by typing:**

```
# /opt/SUNWconn/bin/nf_install_agents
```

3. **Enter the hostnames of Console machine(s) that you want to receive SMT Request Frame (SRF) trap reports from the local station.**

You can send SRF trap reports to more than one Console. Each Console must have the schemas for SunFDDI installed on it, for example:

```
Enter hostnames (if any) to send SRF Trap reports to:
(enter blank to terminate)
enter hostname:opus
enter hostname:rigel
enter hostname:
Hostname of Console ----->
Hostname of Console ----->
Press Return to terminate --->
```

**4. Specify the destination directory for the SunFDDI schemas.**

SunNet Manager expects to find the schemas in the directory `<basedir>/SUNWconn/snm/agents`. The variable `<basedir>` is set to `/opt` by default. If you installed the SunNet Manager agents and libraries on the FDDI station, or if you used `getagents` to recover the agents from the Console, then this directory exists.

Enter the base directory under which you installed the SunNet Manager agents as the destination directory for the SunFDDI schemas.

```
What is the name of the root directory under which the SunNet
Manager is installed? [/opt]: [?]
```

**5. Specify the current location of the SunFDDI schemas.**

This is the base directory under which you installed the SunFDDI software package (SUNWnf) using `pkgadd(1M)`.

```
What is the name of the root directory under which the nf FDDI
software is installed? [/opt]: [?]
```

The script copies the SunFDDI schemas to the destination directory and modifies the local configuration files for SunNet Manager.

**6. Start the SunNet Manager agents for SunFDDI by typing:**

```
# /usr/sbin/nf_snm
```

---

**Note** – If you typed `n` in response to the question “Do you want to start the SunNet Manager daemons for SunFDDI at boot time?” when you installed the SunFDDI software, you must start the SunNet manager agents for SunFDDI manually each time you reboot your machine. Alternatively, you can install the start-up script into the `/etc/rc2.d` directory.

---

```
# cd /opt/SUNWconn/SUNWnf/utilities
# cp nf_fddidaemon /etc/rc2.d/S98nf_fddidaemon
```

## Removing SunFDDI

If you remove the SunFDDI hardware interfaces from your machine, you should also remove the SunFDDI software to prevent the device driver from being started each time you reboot the machine.

Use `pkgrm(1M)` to remove unbundled software from machines running a Solaris 2.x environment. Refer to *Installing Solaris Software* for detailed information on removing software packages using `pkgrm`.

### ▼ Remove SunFDDI:

**1. Log in as root or become superuser.**

**2. Use `pkgrm` to remove SunFDDI.**

The post-remove script removes the modifications made to the system files and updates the package information on your machine.

```
# /usr/sbin/pkgrm SUNWnfr
# /usr/sbin/pkgrm SUNWnft
```

**3. Modify the file `/etc/hosts` to remove the IP addresses and hostnames for the SunFDDI interfaces that were inserted by the post-installation script.**

**4. Reboot the machine to ensure correct system operation.**



# *Installing and Configuring SunFDDI in a Solaris 1.x Environment*



|                                                     |                |
|-----------------------------------------------------|----------------|
| <i>Installation Requirements</i>                    | <i>page 22</i> |
| <i>Declaring IP Addresses for SunFDDI</i>           | <i>page 22</i> |
| <i>Installing and Configuring SunFDDI</i>           | <i>page 23</i> |
| <i>Installing SunNet Manager Agents for SunFDDI</i> | <i>page 31</i> |
| <i>Removing SunFDDI</i>                             | <i>page 33</i> |

This chapter assumes that you have already installed the SunFDDI SBus card in your machine and that you are loading the software from a local CD-ROM.

This chapter tells you how to install the SunFDDI device drivers, utilities, and SunNet Manager agents in a Solaris 1.x environment. It includes instructions on how to check your installation and how to remove the SunFDDI software, if necessary.

If your machine is running a Solaris 2.x environment, see Chapter 2, “Installing and Configuring SunFDDI in a Solaris 2.x Environment” for instructions.

## *Installation Requirements*

### *Hardware and Software Platforms*

SunFDDI was designed for SPARCstations and SPARCservers (32 Mbytes RAM minimum) running a Solaris 1.1.1 environment or later.

### *Disk Space*

You require 3600 KBytes of disk space to install SunFDDI in a Solaris 1.x environment.

### *Hostnames and IP Addresses*

You need to assign a unique hostname and IP address to each SunFDDI device installed in your machine. If you are installing more than one interface in a single machine, each interface must be on a different subnet.

## *Declaring IP Addresses for SunFDDI*

You must assign a unique IP address to each SunFDDI interface. If you have more than one IP interface installed in your machine—either multiple SunFDDI interfaces, or some other LAN interface (for example, an Ethernet interface)—each interface must be connected to a different subnetwork.

Before installing the SunFDDI software, update the files on your NIS/NIS+ server to assign IP addresses and hostnames for the SunFDDI interfaces that you are going to configure. If you are not using a name service, update the file `/etc/hosts` on each machine in the network to add the IP addresses and hostnames of the stations attached to the FDDI ring.

The installation script updates the file `/etc/hosts` on the local machine to enter IP addresses and hostnames assigned to the SunFDDI interfaces installed in it.

## Installing and Configuring SunFDDI

Table 4-1 lists the files and directories created on your machine when you install SunFDDI on a machine running a Solaris 1.x environment:

Table 4-1 Files and Directories (Solaris 1.x)

| Files/Directories              | Description                  |
|--------------------------------|------------------------------|
| /usr/sunlink/nf/install        | Installation script          |
| /usr/sunlink/nf/sys/<arch>/OBJ | Kernel object files          |
| /usr/sunlink/nf/sys/sunif      | Source configuration file    |
| /usr/sunlink/nf/usr/etc        | FDDI utilities               |
| /usr/sunlink/nf/usr/snm        | Product-specific SNM schemas |
| /usr/sunlink/nf/man/man8       | Product-specific man pages   |

The directory <arch> is dependent on the architecture of your machine. Use arch(1B) to display your kernel architecture:

```
% `arch -k`
```

### ▼ Load and Mount the CD-ROM

To load the CD-ROM in the CD-ROM drive and mount it on a local directory:

1. **Log in as root or become superuser.**
2. **Place the CD-ROM in its caddy and load the caddy into the CD-ROM drive.**
3. **Create a directory on which to mount the CD-ROM.**

```
# mkdir /<mnt_dir>
```

4. **Mount the CD-ROM on the local directory.**

```
# /etc/mount -r -t hsfs /dev/sr0 /<mnt_dir>
```

▼ **Install SunFDDI Using cdm**

Use `cdm` to install unbundled software on systems running a Solaris 1.x environment. The `cdm` utility is delivered on the CD-ROM with the SunFDDI software.

To install SunFDDI using `cdm`:

- 1. Log in as root or become superuser.**
- 2. Change to the directory that contains the SunLink FDDI/S software and start `cdm` by typing:**

```
# cd /<mnt_dir>/Solaris_1.x
# ./cdm
```

- 3. Type 1 and press Return to select an application for installation.**

When you start `cdm`, there are no applications selected and the category is set to all.

```
Current program environment:

Application: none
Category: all
Directory: /<mnt_dir>/Solaris_1.x

----->>>> CDM <<<<-----

1. Select Application
2. Show Current Application
3. Install Application
4. Display Application Text File
5. Print Application Text File
6. List Applications
7. List Categories
8. Change Current Category
9. Change Current Directory
10. Show Program Environment

Please enter a number or q to quit: 1
```

- 4. Type 1 and press Return to select SunFDDI (NF) for installation.**  
This is the only application that can be installed from this CD-ROM.

```
Applications available:

    1: NF

Please enter a number or q to quit: 1
```

- 5. Type 2 and press Return to display information about the application you are installing. Press Return to continue.**

```
"NF" selected as new application

----->>>> CDM <<<<<-----

1.  Select Application
2.  Show Current Application
3.  Install Application
4.  Display Application Text File
5.  Print Application Text File
6.  List Applications
7.  List Categories
8.  Change Current Category
9.  Change Current Directory
10. Show Program Environment

Please enter a number or q to quit: 2

Current Application:

    Application name:NF
    Software version:3.0
    Company:          Sun Microsystems, Inc
    OS Required:      SunOS 4.1.3, SunOS 4.1.3_U1, SunOS 4.1.4
    Architectures:    sun4c, sun4m
    Text files:       none
    Install programs: install_SunLink

Press <Return> to continue:
```

**6. Type 3 and press return to install SunFDDI.**

```
----->>>> CDM <<<<<-----  
  
1.  Select Application  
2.  Show Current Application  
3.  Install Application  
4.  Display Application Text File  
5.  Print Application Text File  
6.  List Applications  
7.  List Categories  
8.  Change Current Category  
9.  Change Current Directory  
10. Show Program Environment  
  
Please enter a number or q to quit: 3
```

**7. Type y and press Return to continue the installation.**

This displays a description of the software you are about to install and a copyright message.

If you type n and press Return, the installation process is halted without displaying this information and without installing the software.

**8. Type y and press Return to continue the installation.**

The cdm script calls `extract_unbundled` which extracts the installation scripts from the CD-ROM. From this point on, a history of the installation is logged in `/var/tmp/unbundled/4.0_FDDI_S.log`.

If you type n and press Return, the installation process is halted without extracting the install scripts.

**9. Type y and press Return to display a description of the installation.**

This displays the name of the software you are about to install and a list of the required and optional hardware and software.

If you type n and press Return, the installation continues without displaying this information.

**10. Check that you have enough disk space to install the software and type *y* to continue the installation.**

The installation script displays the current space available in each of the target file systems.

If you type *n* and press Return, the installation is halted without installing the software. The installation scripts and log file are left in `/var/tmp/unbundled`.

**11. Type the system type and press Return to continue the installation.**

You can install SunFDDI on a standalone machine or on a server that will share the software with multiple clients.

```
Enter system type [standalone | server]:
```

By default, SunFDDI is installed under `/usr`. The installation script checks for conflicting files in this directory.

**12. Type *n* and press Return to continue the installation in `/usr`.**

If you type *y* and press Return, you are offered the opportunity to specify a different destination directory.

```
Enter the partition you would like the software installed in:
```

The script checks for an existing version of the software in the destination directory. If the software exists, you are given an opportunity to halt the installation.

**13. Type *y* and press Return to continue the installation.**

If you type *n* and press Return at this stage, the installation is halted without installing the software. The installation scripts extracted from the CD-ROM and the log file are left in `/var/tmp/unbundled`.

**14. The script displays a list of the files that it installs and displays a message to indicate whether the installation was successful.**

If the installation is not successful, refer to Chapter 6, “Troubleshooting and Diagnostics” for help.

```
install_SunLink : **** Installation Completed ****
```

The installation script launches the configuration script automatically.

```
Running configuration script: /usr/sunlink/nf/install/install_nf
```

**15. The configuration script checks that the hardware is installed and displays the number of SunFDDI that it finds.**

If the hardware is not installed, the script halts the configuration process. Install the hardware and launch `install_nf` manually.

**16. Type the hostname that you want to associate with the interface.**

Each SunFDDI interface is assigned a device name of the form `nf<inst>`, where the instance number `<inst>` is determined by the number and relative positions of the SunFDDI SBus cards installed, for example:

```
What host name do you want to use for nf<inst>: hysop-nf
```

**17. Indicate whether you want to use this hostname as the primary (official) IP address for the machine.**

Each machine has a primary IP address, which is usually the IP address assigned to its Ethernet interface. If you want the primary IP address to be assigned to this SunFDDI interface, type `y` in response to the question, otherwise, type `n`.

```
Do you want to use hysop-nf as the official hostname? (y|n) [y]:
```

The script compiles the configuration file and links it with the driver.

**18. Type `y` if you want the SunNet Manager agents for SunFDDI to be started automatically each time you reboot the machine.**

Type `n` if you are not using SunNet Manager to manage your network, or if you want to start the SunNet manager agents manually.

```
Do you want to run the SunNet Manager daemon? (y|n) y
```

The script loads the driver and configures the IP interface. If the installation is successful, your SunFDDI interfaces are now active. The link status indicator (diagnostic LED) will be **amber** (the driver is installed and configured), or **green** (the interface is configured and connected to an active network).

```
FDDI has been installed and configured successfully
```

If the driver is not configured correctly or if the Link Status Indicator is **red**, see Chapter 6, “Troubleshooting and Diagnostics” for help.

**19. Type `q` to quit `cdm` when the installation is finished.**

```
----->>>> CDM <<<<-----  
  
1.  Select Application  
2.  Show Current Application  
3.  Install Application  
4.  Display Application Text File  
5.  Print Application Text File  
6.  List Applications  
7.  List Categories  
8.  Change Current Category  
9.  Change Current Directory  
10. Show Program Environment  
  
Please enter a number or type q to quit: q
```

**20. Unmount the CD-ROM and eject it from the CD-ROM drive.**

```
# /etc/umount /<mnt_dir>  
# eject cdrom
```

**21. Remove the mount directory that you created in Step 3 on page 23.**

```
# rmdir /<mnt_dir>
```

**22. Reboot your machine to ensure correct system operation.**

▼ Check the Installation

To check the installation and configuration of your SunFDDI interfaces:

1. Use `netstat(8C)` to check for SunFDDI interfaces.

SunFDDI interface  
nf<inst> ---->

```
% /usr/ucb/netstat -i
Name Mtu   Net/Dest Address   Ipkts Ierrs Opkts Oerrs Collis
Queue
lo0  8232   loopback localhost  21    0    21    0    0    0
le0  1500   our-lan  hysop     2146  0    950   1    13   0
nf0  4352   our-fddi hysop-nf  1086  0    907   0    0    0
```

2. Use `ifconfig(8C)` to check the current state of the SunFDDI interface.

```
% /etc/ifconfig nf0
nf0: flags=63<UP,BROADCAST,NOTRAILERS,RUNNING,MULTICAST> mtu 4352
    inet <host_address> netmask <netmask> broadcast <ip_address>
```

3. Use `ping(8C)` to check that you can send and receive data across the FDDI connection.

If your SunFDDI station is attached to an active FDDI network, try to access a remote station through its FDDI interface.

```
% /usr/etc/ping hemlock-nf
hemlock-nf is alive
```

Provided the installation was successful, your SunFDDI station is now active, and you can send and receive data across an FDDI connection.

To obtain the optimum performance from your FDDI network, you may need to tune the configurable network parameters. Refer to Chapter 5, “Improving Network Performance” for detailed instructions.

If you have problems configuring or using your SunFDDI station, see Chapter 6, “Troubleshooting and Diagnostics” for help.

## Installing SunNet Manager Agents for SunFDDI

Use `nf_install_agents` to install the SunNet Manager agents for SunFDDI. This script copies the FDDI schema files to the directory in which the standard agents are installed and updates the configuration files for SunNet Manager. Run `nf_install_agents` on each SunNet Manager Console and each SunFDDI station you want to manage using SunNet Manager.

### ▼ Use `nf_install_agents` in a Solaris 1.x Environment

1. **Log in as root or become superuser.**
2. **Start `nf_install_agents` by typing:**

```
# /usr/sunlink/nf/install/nf_install_agents
```

3. **Type the hostnames of Console machines that will receive SMT Request Frame (SRF) trap reports when an event occurs at the local station.**  
You can send SRF trap reports to more than one Console. Each Console must have the schemas for SunFDDI installed on it, for example:

```
Enter hostnames (if any) to send SRF Trap reports to:
(enter blank to terminate)
Hostname of Console----->   enter hostname:opus
Hostname of Console----->   enter hostname:rigel
Press Return to terminate ----> enter hostname:
```

**4. Specify the destination directory for the SunFDDI schemas.**

SunNet Manager expects to find the schemas in the directory `<basedir>/sunlink/nf/sys/snm/agents`. The variable `<basedir>` is set to `/usr` by default. If you installed the SunNet Manager agents and libraries on the client, or if you used `getagents` to recover the agents from the Console, then this directory exists on the client machine.

Enter the base directory under which you installed the SunNet Manager agents as the destination directory for the SunFDDI schemas.

```
What is the name of the root directory under which the SunNet
Manager is installed? [/usr]: [?]
```

**5. Specify the current location of the SunFDDI schemas.**

This is the base directory under which you installed the SunFDDI software using `cdm`.

```
What is the name of the root directory under which the nf FDDI
software is installed? [/usr]: [?]
```

The script copies the SunFDDI schemas to the destination directory and modifies the local configuration files for SunNet Manager.

**6. Start the SunNet Manager agents for SunFDDI start the SunNet Manager agents for SunFDDI by typing:**

```
# /usr/etc/nf_snmd
```

---

**Note** – If you typed `n` in response to the question “Do you want to start the SunNet Manager daemons for SunFDDI at boot time?” when you installed the SunFDDI software, you must start the SunNet manager agents for SunFDDI manually each time you reboot your machine. Alternatively, you can add the following lines to the file `/etc/rc.local`:

---

```
if [ -f /usr/etc/nf_snmd ]; then
    /usr/etc/nf_snmd
fi
```

## Removing SunFDDI

If you remove the SunFDDI hardware interfaces from your machine, you should also remove the SunFDDI software.

The Solaris 1.x version of SunFDDI does not include a script for removing the software. You need to remove the files, directories, and modifications to the system files, manually.

### ▼ Remove SunFDDI

1. **Log in as root or become superuser.**
2. **Remove the directory tree below `/usr/sunlink/nf`.**  
Always take care when you use the `rm(1)` command with the `-r` option. Make sure that you type the name of the directory tree correctly.

```
# rm -r /usr/sunlink/nf
```

3. **Remove the file `/dev/nf.AUTOLOAD` and the links to `/usr/etc/nf.INSTALL`.**

```
# cd /dev
# rm nf.AUTOLOAD
# rm nf.INSTALL nf.LOAD nf.MKDEV nf.RMDEV nf.UNLOAD nf.o
```

- 4. Remove the files associated with the `nf` device driver from `/usr/etc`.**

```
# cd /usr/etc
# rm nf.o nf_macid nf_smtmon nf_stat nf.INSTALL nf_snmd*
```

- 5. Modify the script `/etc/loadable` to remove the references to the `nf` device driver.**

```
if [ -f /dev/nf.LOAD ]; then
  if [ -f /dev/nf.AUTOLOAD ]; then
    /dev/nf.LOAD
  fi
fi
```

- 6. Modify the file `/etc/hosts` to remove the IP addresses and hostnames assigned to the SunFDDI interfaces.**

- 7. Remove the files `/etc/hostname.nf<inst>`.**

```
# rm /etc/hostname.nf*
```

- 8. If you assigned the primary hostname to one of the SunFDDI interfaces, you must modify `/etc/hostname.official` to enter the hostname assigned to the Ethernet interface `le0`**

- 9. Modify the file `/etc/rc.local` to remove the references to `/etc/loadable` and the SunFDDI (`nf`) driver.**

```
if [ `modstat | grep nf | wc -l` -eq 0 ]; then
  echo "The fddi driver has not been properly loaded."
else
  ifconfig nf<inst> <hostname> netmask + -trailers up
fi
```

---

**10. If you installed SunNet Manager agents for SunFDDI, remove the following lines from the file `/etc/rc.local`:**

```
if [-f /usr/etc/nf-snmd]; then
    /usr/etc/nf-snmd
fi
```



|                                                           |                |
|-----------------------------------------------------------|----------------|
| <i>High Performance FDDI Networks</i>                     | <i>page 38</i> |
| <i>Ring Latency Improvement</i>                           | <i>page 38</i> |
| <i>Data Throughput Improvement</i>                        | <i>page 39</i> |
| <i>Performance Across Bridges</i>                         | <i>page 39</i> |
| <i>Target Token Rotation Time (TTRT)</i>                  | <i>page 40</i> |
| <i>Improving Performance in a Solaris 2.x Environment</i> | <i>page 41</i> |
| <i>Improving Performance in a Solaris 1.x Environment</i> | <i>page 46</i> |

This chapter tells you how to obtain the best performance from your FDDI network. It assumes that you are familiar with FDDI network architecture and related terminology. See Chapter 7, “FDDI Network Architecture” for a detailed description of the FDDI protocols, and Chapter 8, “FDDI Network Topologies” for a detailed description of the FDDI network architecture.



---

**Caution** – There are a number of ways to improve network performance, some of which are discussed in this chapter; however, these should be undertaken only by experienced system administrators. Tuning your network incorrectly can affect network performance adversely.

---

## *High Performance FDDI Networks*

Think of an FDDI network as having the potential to carry *more* information, rather than as being a faster connection. If the applications running over the network do not use the available bandwidth efficiently, you will not see much improvement in the performance of your network by using FDDI.

You can obtain optimum performance by balancing the complementary objectives of maximum throughput and minimum access delay:

- **Throughput** is a measure of the ring utilization. Network efficiency is defined as the ratio of actual throughput to theoretical maximum bandwidth (100 Mbps).
- **Access Delay** is the time a station has to wait before it can transmit on the network. This is largely dependent on how fast the permission token rotates around the ring.

For some applications (for example, bulk data transfers), throughput is critical; other applications (for example, voice or video applications) are more sensitive to access delay.

## *Ring Latency Improvement*

The ring latency is the physical delay inherent in the FDDI network. It is dependent on the number of stations in the ring and the overall length of the ring. The speed of the microprocessor in the FDDI station also has a significant effect on ring latency.

The FDDI specifications define a network that supports up to one thousand physical connections with a total ring length of 200 km (100 km per ring in a dual-ring topology). There are two physical connections for each dual-attached station; therefore, in theory, up to five hundred dual-attached stations could be connected in a single ring. In reality, optimum performance is obtained by limiting the number of connections to less than one hundred stations in an unsegmented ring.

It is possible to realize performance improvements by changing the topology of the network, trading off the total number of stations in comparison to the overall length of the ring, and selecting faster machines to act as FDDI stations. However, these modifications are rarely practical in an established network.

---

## *Data Throughput Improvement*

The most significant improvements in throughput are achieved by maximizing the rate at which data is transferred to and from the FDDI network. If you are running TCP/IP or UDP/IP applications you can improve throughput by modifying the parameters that control the rate at which these protocols transfer data to and from the SunFDDI device driver—that is, between user space and kernel space.

### *Send and Receive Buffers*

The maximum rate at which data is transferred between user space and kernel space by applications that use Sockets is controlled by the send and receive buffers. The size of these buffers defines the amount of data that can be transferred at one time.

To optimize performance, consistent values must be assigned for the send and receive buffers. The default value (4 Kbytes) assigned to these parameters is optimized for transmission across Ethernet connections. For applications running over FDDI, the send and receive buffers should be set to 32 Kbytes.

## *Performance Across Bridges*

For each physical layer in the network, there is a *maximum transfer unit* (MTU), which defines the maximum size, in octets, of packets transmitted. A larger MTU means that more data can be transmitted in a single packet. Therefore, a larger MTU usually means higher throughput.

For SunFDDI, the MTU is set to 4352 by default<sup>1</sup>, and for an Ethernet interface, the MTU is 1500. This difference can cause performance problems in mixed FDDI/Ethernet networks.

Packets are transmitted between the two networks across a bridge, which handles the translation between the two protocols. When data is transmitted across the bridge from the FDDI network, the larger FDDI packets need to be

---

1. This value makes allowance for the frame header and has been demonstrated to be the optimum value of MTU for pure FDDI networks (see RFC 1390)

fragmented so that they do not exceed the MTU of the Ethernet network. Some low-cost bridges that do not support fragmentation will reject the 4352 byte packets.

Fragmenting and reassembling the packets introduces a considerable overhead that affects performance. It also increases the risk of out-of-sequence or dropped packets. Therefore, if there is heavy network traffic across the bridge, it may be more efficient to force the MTU in the FDDI network to be 1500 to match the MTU on the Ethernet side of the bridge. The above argument can also be applied to a mixed FDDI/NetWare® network. In this case, the MTU in the NetWare LAN is 4178 octets.

## Target Token Rotation Time (TTRT)



---

**Caution** – Modifying the target token rotation time (TTRT) can affect network performance adversely. In the worst case, it can reduce network throughput to zero. In general, the TTRT should not be set to less than 8000 microseconds (ms).

---

The target token rotation time (TTRT) is the key FDDI parameter used for network performance tuning. In general, increasing the TTRT increases throughput and increases access delay.

For SunFDDI, the TTRT must be between 4000 and 165000 microseconds, and is set to 8000 ms by default. The optimum value for the TTRT is dependent on the application and the type of traffic on the network:

- If the network load is very irregular (*bursty* traffic), the TTRT should be set as high as possible to avoid lengthy queueing at any one station.
- If the network is used for the bulk transfer of large data files, the TTRT should be set relatively high to obtain maximum throughput, without allowing any one station to monopolize the network resources.
- If the network is used for voice, video, or real-time control applications, the TTRT should be set low to decrease access delay.

The TTRT is established during the *claim process*. Each station on the ring bids a value ( $T_{req}$ ) for the operating value of the TTRT ( $T_{opr}$ ) and the station with the lowest bid wins the claim. Setting the value of  $T_{req}$  on a single station does not guarantee that this bid will win the claim process.

## Improving Performance in a Solaris 2.x Environment

The following section describes how to modify the user-configurable network parameters in a Solaris 2.x environment. To obtain optimum network performance, you may need to tune some, or all, of these parameters, depending on your network configuration and the type of network traffic.

### Changing the High and Low Water Marks

The maximum rate at which data is transferred between user space and kernel space by applications that use STREAMS is controlled by the *high water marks*. These parameters define the maximum amount of data that can be queued for transmission to the TCP or UDP STREAMS modules. There are independent send and receive high water marks for TCP and UDP applications.

When the number of bytes queued exceeds the high water mark, transmission is halted temporarily to allow the backlog to be cleared. The *low water mark* specifies the level to which the queue must drop before transmission is restarted.

#### ▼ Tune the High Water Mark

To optimize performance, assign consistent values for the transmit and receive high water marks. The default value (8192) assigned to these parameters is optimized for transmitting across Ethernet connections. For applications running over FDDI, the high water marks should be set to 32 Kbytes.

Use `ndd(1M)` to change the TCP and UDP high water marks:

1. **Log in as root or become superuser.**
2. **Use `ndd -get` (the default) to check the current value of the TCP high water marks (`tcp_xmit_hiwat` and `tcp_recv_hiwat`).**

```
# ndd /dev/tcp tcp_xmit_hiwat
8192
# ndd /dev/tcp tcp_recv_hiwat
8192
```

3. Use `ndd -set` to modify the current value of the TCP high water marks (`tcp_xmit_hiwat` and `tcp_rcv_hiwat`).

For optimum performance over FDDI connections, the TCP high water marks should both be set to 32 Kbytes.

```
# ndd -set /dev/tcp tcp_xmit_hiwat 32768
# ndd -set /dev/tcp tcp_rcv_hiwat 32768
```

4. Use `ndd -get` (the default) to check the current value of the UDP high water marks (`udp_xmit_hiwat` and `udp_rcv_hiwat`).

```
# ndd -get /dev/udp udp_xmit_hiwat
8192
# ndd -get /dev/udp udp_rcv_hiwat
8192
```

5. Use `ndd -set` to modify the current value of the UDP high water marks (`udp_xmit_hiwat` and `udp_rcv_hiwat`).

For optimum performance over FDDI connections, the UDP high water marks should both be set to 32 Kbytes.

```
# ndd -set /dev/udp udp_xmit_hiwat 32768
# ndd -set /dev/udp udp_rcv_hiwat 32768
```

## ▼ Tune the Low Water Mark

By default, the low water mark is set to 2 Kbytes. Provided the high water mark is also tuned, increasing the low water mark can improve the performance slightly. The low water mark must never be set higher than the high water mark.

Use `ndd(1M)` to change the TCP and UDP low water marks:

1. Log in as `root` or become `superuser`.

**2. Use `ndd -set` to modify the current value of the TCP and UDP low water marks (`tcp_xmit_lowat` and `udp_xmit_lowat`).**

For optimum performance over FDDI connections, the TCP and UDP low water marks should both be set to 24 Kbytes.

```
# ndd -set /dev/tcp tcp_xmit_lowat 24576
# ndd -set /dev/udp udp_xmit_lowat 24576
```

## ▼ Tune the High and Low Water Marks at Boot Time

Each time you reboot your machine, the high and low water marks are reset to their default values. If you want to configure your system so that the high water marks are modified automatically each time you reboot the machine, you must put these commands in a start-up script.

An example script is delivered on the SunFDDI CD-ROM. Once installed on your machine, this script sets the TCP and UDP high and low water marks each time you reboot. The TCP and UDP high water marks are set to 32 Kbytes; the TCP and UDP low water marks are set to 24 Kbytes. You can modify the example script to enter your own values, if required.

To install the example script on your machine:

- 1. Log in as `root` or become `superuser`.**
- 2. Place the CD-ROM in the caddy and load the caddy into the CD-ROM drive.**
- 3. Mount the CD-ROM on a local directory.**
  - If the Volume Manager (`vold`) is running on your machine, then the CD-ROM is mounted automatically under `/cdrom/fddi_4_0` when it is loaded in the drive.
  - If the Volume Manager (`vold`) is not running on your machine, then you must create a directory called `/cdrom/fddi_4_0` and mount the CD-ROM manually:

```
# mkdir /cdrom/fddi_4_0
# /usr/sbin/mount -r /dev/dsk/c0t6d0s0 /cdrom/fddi_4_0
```

#### 4. Copy the start-up script to the directory `/etc/rcS.d`.

```
# cd /cdrom/fddi_4_0/Solaris_2.x/examples
# cp ./S31ndd_fddi.sh /etc/rcd.S
```

#### 5. Change the permissions and ownership for this file.

```
# chmod 755 s31ndd_fddi.sh
# chown root s31ndd_fddi.sh
# chgrp sys s31ndd_fddi.sh
```

### ▼ Tune the Socket Options

For applications that use Sockets, the application developer can make more efficient use of the increased bandwidth provided by an FDDI connection by increasing the size of the send and receive buffers used by a specific application. This manipulation is restricted to applications and do not affect the other Socket connections.

Both Solaris 2.x and Solaris 1.x environments support program calls to `getsockopt(3N)` and `setsockopt(3N)`. The options `SO_SNDBUF` and `SO_RCVBUF` are used to set the size of the TCP send and receive buffers for a specified Socket. See the man page for more detailed information.

To optimize performance, assign consistent values for the transmit and receive buffers. The default value (4 Kbytes) assigned to these parameters is optimized for transmitting across Ethernet connections. For applications running over FDDI, the send and receive buffers should be set to 32 Kbytes.

Code examples that demonstrate how `sockopt` can be used to optimize a TCP/IP application for an FDDI network are provided on the SunFDDI CD-ROM. To access the code examples:

◆ **insert the CD-ROM in a CD-ROM drive and mount the CD-ROM on a local directory.**

The Solaris 2.x examples are located in `<mnt_dir>/Solaris_2.x/examples`. Instructions for running the example programs are contained in the `README` file in this directory.

## MTU Path Discovery

Machines running a Solaris 2.x environment support MTU path discovery, which allows the optimum MTU to be negotiated. Under most circumstances, this ensures efficient use of the network resources. However, to enable MTU path discovery to work, the “don't fragment” bit in the packet is set, which causes a problem with some bridges and routers that do not support this feature. In this case, packets are not transmitted across the bridge, and the error messages generated as a result can be very misleading.

Refer to “Disable MTU Path Discovery” for detailed instructions on how to accommodate bridges and routers that do not support this feature.

### ▼ Tune the Maximum Transfer Unit (MTU)

For SunFDDI, the maximum transfer unit (MTU) has been optimized for pure FDDI networks. To change the value of the MTU on a station running SunFDDI in a Solaris 2.x environment:

1. **Log in as root or become superuser.**
2. **Edit the file `/etc/system` to add the following line:**

```
set nf:nf_mtu=<packet_size>
```

The variable `<packet_size>` is set to the desired value for MTU entered in octets. The default value for MTU is 4352 octets. It must be in the range 1 to 4500 octets.

3. **Reboot the machine to apply the changes to the system.**

### ▼ Disable MTU Path Discovery

Many bridges do not support MTU path discovery. To disable this feature in order to transmit packets across a bridge, type:

```
# ndd -set /dev/ip ip_path_mtu_discovery 0
```

MTU path discovery is re-enabled each time the machine is rebooted.

### ▼ Tune the Target Token Rotation Time (TTRT)

The target token rotation time (TTRT) for the network is the lowest value of `T_req` bid during the claim process. To change the value of `T_req` bid by a station running a Solaris 2.x environment:

1. **Log in as root or become superuser.**
2. **Edit the file `/etc/system` to add the following line:**

```
set nf:nf_treq=<bid>
```

3. **Reboot the machine to apply the changes to the system.**

## *Improving Performance in a Solaris 1.x Environment*

The following section describes how to modify the user-configurable network parameters in a Solaris 1.x environment. To obtain optimum network performance, you may need to tune some, or all, of these parameters, depending on your network configuration and the type of network traffic.

### ▼ Tune the Send and Receive Buffers

The maximum rate at which data is transferred between user space and kernel space by applications that use Sockets is controlled by the send and receive buffers. The size of these buffers defines the amount of data that can be transferred at one time.

To optimize performance, consistent values must be assigned for the send and receive buffers. The default value (4 Kbytes) assigned to these parameters is optimized for transmitting across Ethernet connections. For applications running over FDDI, the send and receive buffers should be set to 32 Kbytes.

To change the default size of the TCP send and receive buffers used by all of the TCP/IP applications running on your machine:

1. **Log in as root or become superuser.**

## 2. Edit the file `/sys/netinet/in_proto.c` to modify the following lines:

Set to 32 Kbytes for FDDI ---->  
Set to 32 Kbytes for FDDI ---->

```
/*
 * Default TCP buffer sizes (in bytes)
 */
int  tcp_sendspace = 1024*4*8
int  tcp_recvspace = 1024*4*8
```

## 3. Make a new kernel that is optimized for applications running over FDDI.

For example, to make a new kernel that is based on generic `vmunix`:

```
# cd /sys/\`arch -k\`/conf
# cp GENERIC FDDI
# config FDDI
# cd ../FDDI
# make
# cp /vmunix /vmunix.ether
# cp vmunix /vmunix
```

## 4. Reboot your machine to invoke the changes to the kernel.

### ▼ Patch the Buffer Size

If you want to experiment with various buffer sizes, you can patch the kernel temporarily using the general-purpose debugging tool `adb(1)`. These changes will be lost when you reboot the machine.

To patch the kernel using `adb`:

1. Log in as `root` or become `superuser`.

2. Pass the desired buffer size as input to the debugger.

Enter the value in hexadecimal. For example, to increase the TCP buffer size to 32 Kbytes:

```
# echo "tcp_sendspace/W 0x8000 | adb -w /vmunix /dev/kmem
# echo "tcp_recvspace/W 0x8000 | adb -w /vmunix /dev/kmem
```

## ▼ Tune the Socket Options

For applications that use Sockets, the application developer can make more efficient use of the increased bandwidth provided by an FDDI connection by increasing the size of the send and receive buffers used by a specific application. This manipulation is restricted to the application and does not affect the other Socket connections.

Both Solaris 2.x and Solaris 1.x environments support program calls to `getsockopt(2)` and `setsockopt(2)`. The options `SO_SNDBUF` and `SO_RCVBUF` are used to set the size of the TCP send and receive buffers for a specified Socket. See the man page for more detailed information.

To optimize performance, consistent values must be assigned for the transmit and receive buffers. The default value (4 Kbytes) assigned to these parameters is optimized for transmitting across Ethernet connections. For applications running over FDDI, the send and receive buffers should be set to 32 Kbytes.

Code examples that demonstrates how `sockopt` can be used to optimize a TCP/IP application for an FDDI network is provided on the SunFDDI CD-ROM. To access the code examples:

- ◆ **Insert the CD-ROM in a CD-ROM drive and mount the CD-ROM on a local directory.**

The Solaris 1.x examples are located in

`<mnt_dir>/Solaris_1.x/examples`. Instructions for running the example programs are contained in the `README` file in this directory.

## ▼ Tune the Maximum Transfer Unit (MTU)

For SunFDDI, the maximum transfer unit (MTU) has been optimized for pure FDDI networks. To change the value of the MTU on a station running SunFDDI in a Solaris 1.x environment:

1. **Log in as `root` or become superuser.**

- 2. Edit the file** `/usr/sunlink/nf/sys/sunif/nf_conf.c` **to modify the following line:**

```
int    nf_mtu = <packet_size>
```

The variable `<packet_size>` is set to the desired value for MTU entered in octets. The default value for MTU is 4352 octets. It must be in the range 1 to 4500 octets.

- 3. Change the directory to** `/usr/sunlink/nf/sys/<arch>/OBJ`, **where** `<arch>` **is dependent on your machine architecture.**

```
# cd /usr/sunlink/nf/sys/<arch>/OBJ
```

- 4. Compile the file** `/usr/sunlink/nf/sys/sunif/nf_conf.c` **using the following compile options:**

```
# cc -O -I/sys -DKERNEL -sparc -c ../../sunif/nf_conf.c
```

- 5. Link the object file** `nf_conf.o` **with the other SunFDDI kernel object files:**

```
# ld -r -o nf.o if_nf.o smt.o nf_smtcore.o nf_conf.o
```

If the system has a multicast kernel, link the object file `nf_conf.o` as follows:

```
# ld -r -o nf.o if_nf.mcast.o smt.mcast.o nf_smtcore.o nf_conf.o
```

- 6. Move the SunFDDI driver** `nf.o` **to** `/usr/etc`.

```
# mv nf.o /usr/etc
```

- 7. Reboot the machine to apply the changes to the system.**

▼ Tune the Target Token Rotation Time (TTRT)

The target token rotation time (TTRT) for the network is the lowest value of  $T_{req}$  bid during the claim process. To change the value of  $T_{req}$  bid by a station running SunFDDI (with loadable drivers) in a Solaris 1.x environment:

1. **Log in as root or become superuser.**
2. **Edit the file `/usr/sunlink/nf/sys/sunif/nf_conf.c` to modify the following line:**

```
int    nf_treq = <bid>
```

The variable `<bid>` is set to the desired value for  $T_{req}$  entered in microseconds. The default value for  $T_{req}$  is 8000 microseconds. It must be in the range 4000 to 165000 microseconds.

3. **Change directory to `/usr/sunlink/nf/sys/<arch>/OBJ`, where `<arch>` is `sun4c` or `sun4m` depending on your machine architecture.**

```
# cd /usr/sunlink/nf/sys/<arch>/OBJ
```

4. **Compile the file `/usr/sunlink/nf/sys/sunif/nf_conf.c` using the following compile options:**

```
# cc -O -I/sys -DKERNEL -sparc -c ../../sunif/nf_conf.c
```

5. **Link the object file `nf_conf.o` with the other SunFDDI kernel object files:**

```
# ld -r -o nf.o if_nf.o smt.o nf_smtcore.o nf_conf.o
```

If the system has a multicast kernel, link the object file `nf_conf.o` as follows:

```
# ld -r -o nf.o if_nf.mcast.o smt.mcast.o nf_smtcore.mcast.o nf_conf.o
```

---

**6. Move the SunFDDI driver `nf.o` to `/usr/etc`.**

```
# mv nf.o /usr/etc
```

**7. Reboot the machine to apply the changes to the system.**



|                                                         |                |
|---------------------------------------------------------|----------------|
| <i>Troubleshooting Checklist</i>                        | <i>page 54</i> |
| <i>Solving Common Problems</i>                          | <i>page 58</i> |
| <i>Running the Hardware Self-Test Program</i>           | <i>page 64</i> |
| <i>Loading the Device Driver Manually (Solaris 2.x)</i> | <i>page 65</i> |
| <i>Loading the Device Driver Manually (Solaris 1.x)</i> | <i>page 67</i> |

This chapter describes how to detect and resolve common problems with your FDDI network. It includes instructions on how to load and configure the SunFDDI device driver manually, if required. Note that SunFDDI supports almost all of the standard SunOS network diagnostic utilities, including `snoop(1M)`, `netstat(1M)`, `ping(1M)`, and `etherfind(8C)`.

For a Solaris 2.x environment, the default base directory *<basedir>* is:

```
/opt/SUNWconn/bin
```

For a Solaris 1.x environment, the default base directory *<basedir>* is:

```
/usr/sunlink/nf/usr/etc
```

## *Troubleshooting Checklist*

Use the following checklist to verify the major components of your SunFDDI station, and to check that it is installed, configured, and attached to the network correctly.

### ▼ Check the Connection to the Station

- ◆ **Check that the cable connector is seated firmly into the plug on the SunFDDI SBus card. You should feel the connector “click” into place.**

### ▼ Check the Connections Between Stations

- ◆ **Check that the cables are connected correctly between ports of different types.**

The keys provided with most FDDI cables will help you to avoid “crossing” or “twisting” the ring. See “Connecting Fiber Optic Cables” on page 6 for a more detailed description.

For single-attached stations (SAS), cables should be connected either S↔M (to a concentrator) or S↔S (back-to-back).

For dual-attached stations (DAS), cables should be connected either A↔B B↔A (dual-ring) or A↔M M↔B (dual-homing).

### ▼ Check the Link Status Indicator

- ◆ **Check the current status of the SunFDDI interface by looking at the Link Status Indicator (diagnostic LED) mounted on the backplate of the SunFDDI SBus card.**
- If the LED is **green**, the SunFDDI driver is loaded, the `nf` interface is configured, and the station is attached to an active FDDI network. This is the operating state.
- If the LED is **amber**, the SunFDDI driver is loaded, the `nf` interface is configured, but the station is *not* attached to an active FDDI network.
  - Check the physical connections between the station and the ring, or the station and the concentrator.**

**b. Check the status of the neighboring station.**

If this station is down, it will bring down the link between the stations.

- If the LED is **red**, the SunFDDI driver is loaded, but the `nf` interface is not configured.
  - a. Configure the `nf` interface using an `ifconfig(1M)` command of the form:**

```
# ifconfig plumb nf<inst> <hostname> netmask <mask> up
```

- If the LED is **off**, the SunFDDI driver is not loaded, or is not loaded correctly.
  - a. Check that the software is installed.**
  - b. Remove the existing version, if necessary, and reload the software.**

See Chapter 3, “Installing and Configuring SunFDDI in a Solaris 2.x Environment” or Chapter 4, “Installing and Configuring SunFDDI in a Solaris 1.x Environment” for instructions.

**▼ Check the MAC Address**

By default, the first SunFDDI interface installed in the machine adopts the host-resident MAC address stored on the motherboard. Each subsequent SunFDDI interface takes the card-resident MAC address stored in its IDPROM.

A potential conflict exists between the first SunFDDI 4.0 interface and a SunFDDI 2.0 interface because both of these revisions of the product take the host-resident MAC address. You must change the MAC address assigned to one of these interfaces. See “Changing the Default MAC Address (`nf_macid`)” on page 112 for detailed instructions.

▼ Check the SunFDDI Driver

♦ Use `netstat(1M)` to check that the SunFDDI (`nf`) driver is installed correctly, and to check for an excessive number of errors and collisions:

```

SunFDDI interface
nf<inst>---->
% netstat -i
Name Mtu Net/Dest Address Ipkts Ierrs Opkts Oerrs Collis
Queue
lo0 8232 loopback localhost 21 0 21 0 0 0
le0 1500 our-lan hysop 2146 0 950 1 13 0
nf0 4352 our-fddi hysop-nf 1086 0 907 0 0 0

```

A sudden increase in the number of errors could indicate a noisy connection caused by a dirty cable.

▼ Check the IP Addresses

You must assign a unique IP address to each SunFDDI interface. If you have more than one IP interface installed in your machine—either multiple SunFDDI interfaces, or some other LAN interface (for example, an Ethernet interface)—each interface must be attached to a different subnetwork.

♦ Use `ifconfig(1M)` to check the IP addresses assigned to the two SunFDDI interfaces:

```

# ifconfig -a
nf0: flags=842(UP,BROADCAST,RUNNING,MULTICAST) mtu 4352
    inet 123:123:201:71 netmask ffffffff broadcast
    123:123:201:255
nf1: flags=843(UP,BROADCAST,RUNNING,MULTICAST) mtu 4352
    inet 123:123:201:75 netmask ffffffff broadcast
    123:123:201:255

```

If the two interfaces have the same subnetwork number, as shown in this example, you must change the IP address assigned to one of the interfaces.

Ensure that the IP addresses and hostnames for each SunFDDI interface are entered in the NIS map, or in `/etc/hosts` on the local machine if you are not using NIS/NIS+.

## ▼ Check the IP Routing

### 1. Check the IP routing table using the `netstat(1M)` command:

```
% netstat -nr
```

### 2. Check that the FDDI subnetwork is featured in the routing table.

If the routing table is empty, check that the routing daemon (`in.routed`) is running on your machine.

## ▼ Check the Protocol Statistics

### ♦ Use `netstat(1M)` to check the per-protocol (IP, TCP, UDP, etc.) statistics for errors:

```
# netstat -s
UDP
  udpInDatagrams      = 1423udpInErrors      = 0
  udpOutDatagrams     = 540

TCP tcpRtoAlgorithm      = 4tcpRtoMin          = 200
  tcpRtoMax           = 60000tcpMaxConn     = -1
  tcpActiveOpens      = 38tcpPassiveOpens   = 1
  tcpAttemptFails     = 0tcpEstabResets     = 33
  tcpCurrEstab        = 2tcpOutSegs         = 427
  tcpOutDataSegs      = 264tcpOutDataBytes  = 15917
  tcpRetransSegs      = 38tcpRetransBytes   = 0
  tcpOutAck            = 143tcpOutAckDelayed = 56
  tcpOutUrg           = 1tcpOutWinUpdate    = 0
  tcpOutWinProbe      = 0tcpOutControl       = 111
  tcpOutRsts          = 36tcpOutFastRetrans = 0
  tcpInSegs           = 606
  tcpInAckSegs        = 292tcpInAckBytes     = 15949
  tcpInDupAck         = 62tcpInAckUnsent     = 0
  tcpInInorderSegs    = 311tcpInInorderBytes = 99169
  tcpInUnorderSegs    = 0tcpInUnorderBytes    = 0
.
.
.
```

**▼ Check the SMT Traffic**

If the target station is not running SunFDDI, it does not necessarily support the same set of SMT frames. If the target station receives an SMT request for an unsupported service, it issues a Request Denied Frame (RDF).

◆ Use `nf_smtmon(1M)` to examine the SMT frames:

```
# <basedir>/nf_smtmon [-i nf<inst>] [-x] [-h] [<frameclass>]
```

## Solving Common Problems

Use the following information to diagnose and resolve some of the common problems that can occur when installing, configuring, or running SunFDDI

Table 6-1 Problems Installing SunFDDI in a Solaris 2.x Environment

| Problem                                                                                                                                                 | Action                                                                                                                                                                                                                                                                                                                                                                           |
|---------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| The SunFDDI software package (SUNWnfr) cannot be found.                                                                                                 | Check that you have inserted the CD-ROM in the CD-ROM drive and that the CD-ROM is mounted on a local directory. If the Volume Manager (vold) is running on your machine, the SunFDDI software is located in /cdrom/fddi_4_0/Solaris_2.x. If the Volume Manager (vold) is not running on your machine, you must create a directory and mount the CD-ROM as described on page 11. |
| The configuration script cannot configure the IP address. 'What ip address do you want to use for xyz [] [?] 0.0.0.0 Illegal ip address. . . Try again' | Check that you have entered the valid IP address. The script will keep on prompting you until you enter a valid address.                                                                                                                                                                                                                                                         |
| The configuration script cannot find the hardware devices installed in the machine.                                                                     | Check that the SunFDDI SBus card is installed correctly and is seated firmly in the SBus slot.                                                                                                                                                                                                                                                                                   |
| The configuration script cannot load SunFDDI driver. The procedure fails with the message "no available major numbers"                                  | The number of major numbers—that is, the maximum number of device drivers that can be installed—is limited to 127 in a Solaris 2.3 environment. This number is quickly exhausted by the large number of drivers installed in a typical system. Remove an existing driver before loading SunFDDI. This limitation does not exist in other versions of the operating system.       |
| The configuration script cannot load the device driver.                                                                                                 | Check whether the driver is already installed on the system. If you removed a previous version of the package using pkgrm(1M), you must reboot the system before attempting another add_drv.                                                                                                                                                                                     |
| The configuration script cannot configure the device driver. The procedure fails with the message "Duplicate MAC address".                              | Two or more interfaces have been assigned the same MAC address. The most likely conflict lies between the first SunFDDI 4.0 interface (nf0) and one or more SunFDDI 2.0 (bf) interfaces installed in the same machine                                                                                                                                                            |

Table 6-2 Problems Installing SunFDDI in a Solaris 1.x Environment

| Problem                                                                                                                       | Action                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
|-------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| The device driver cannot be loaded.                                                                                           | Ensure that the following options are enabled in your kernel configuration file <code>/sys/&lt;arch&gt;/conf/&lt;kernel&gt;</code> :<br><br><pre>options  VDDRV      #loadable modules</pre>                                                                                                                                                                                                                                                                                                                               |
| The device driver cannot be loaded.                                                                                           | Ensure that the following options and pseudo devices are enabled in your kernel configuration file <code>/sys/&lt;arch&gt;/conf/&lt;kernel&gt;</code> :<br><br><pre>options  IPCMESSAGE #System V IPC message facility options  IPCSEMAPHORE #System V IPC semaphore facility options  IPCSHMEM    #System V IPC shared-memory facility  pseudo-device  snit      #streams NIT pseudo-device  pf        #packet filter pseudo-device  nbuf      #streams NIT buffering module pseudo-device  clone     #clone device</pre> |
| The configuration script cannot configure the device driver.<br>The procedure fails with the message "Duplicate MAC address". | Two or more interfaces have been assigned the same MAC address. The most likely conflict lies between the first SunFDDI 4.0 interface (nf0) and one or more SunFDDI 2.0 (bf) interfaces installed in the same machine                                                                                                                                                                                                                                                                                                      |

Table 6-3 Problems Running SunFDDI

| Problem                                                   | Action                                                                                                                                                                                  |
|-----------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| The link status indicator (diagnostic LED) remains off.   | Check that the SunFDDI software is installed correctly and that the driver is configured. Check that the SunFDDI SBus card is installed correctly and is seated firmly in the SBus slot |
| The link status indicator (diagnostic LED) remains red.   | Check that the SunFDDI software is installed correctly and that the driver is loaded and configured.                                                                                    |
| The link status indicator (diagnostic LED) remains amber. | Check that the SunFDDI SBus card is connected to the network.                                                                                                                           |

Table 6-3 Problems Running SunFDDI

| Problem                                                                                                                                                                     | Action                                                                                                                                                                                                                                                                                                                                                                                                                                  |
|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| The link status indicator (diagnostic LED) remains amber, even after the local station is connected to the network and the driver is configured and loaded.                 | Check that the other end of the cable is connected and that the neighboring station or concentrator is configured correctly. Some concentrators have diagnostic LEDs that indicate if the ring is operating correctly. Check that the ring is not crossed.                                                                                                                                                                              |
| The SunFDDI interface ( <code>nf</code> ) is not displayed by <code>netstat</code> .                                                                                        | Check that the SunFDDI device driver is loaded, using <code>modinfo(1M)</code> to display information about loaded kernel modules. If the device driver is not loaded, see “Loading the Device Driver Manually (Solaris 2.x)” on page 65 for detailed instructions.                                                                                                                                                                     |
| The SunFDDI interface ( <code>nf</code> ) is not displayed by <code>ifconfig</code> .                                                                                       | Check that the SunFDDI device driver is loaded, using <code>modinfo(1M)</code> to display information about loaded kernel modules. If the device driver is not loaded, see “Loading the Device Driver Manually (Solaris 2.x)” on page 65 for detailed instructions.                                                                                                                                                                     |
| Frequent errors occur when running NFS over FDDI in a Solaris 2.3 environment.                                                                                              | You must install the NFS “jumbo” patch (101344-05) on machines running Solaris 2.3 to run NFS over FDDI. These errors have been fixed in subsequent releases of the operating system.                                                                                                                                                                                                                                                   |
| The local station can reach FDDI stations located on the same subnetwork, but these stations cannot reach the local station.                                                | Check that the IP address and host name of the local station is entered in the NIS map or NIS+ tables (or in <code>/etc/hosts</code> on each remote station if you are not running NIS or NIS+).                                                                                                                                                                                                                                        |
| The local station cannot reach other FDDI stations located on the same subnetwork.                                                                                          | <p>Check that the link status indicator is <b>green</b> (indicating that the SunFDDI interface) is attached to an active network. Use <code>ifconfig(1M)</code> to check that the SunFDDI interface (<code>nf</code>) is up.</p> <p>Check that the IP address and host name of the remote station is entered in the NIS map or NIS+ tables (or in <code>/etc/hosts</code> on the local station if you are not running NIS or NIS+).</p> |
| Running <code>nf_stat</code> without the <code>-m</code> option (to display information about the local station) shows the ring alternating frequently between UP and DOWN. | <p>Check that the link status indicator is <b>green</b> (indicating that the SunFDDI interface) is attached to an active network.</p> <p>Check the connections to the concentrator. Some concentrators have diagnostic LEDs that indicate if the ring is operating correctly.</p>                                                                                                                                                       |

Table 6-3 Problems Running SunFDDI

| Problem                                                                                                                                                               | Action                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                |
|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <p>Running <code>nf_stat</code> without the <code>-m</code> option (to display information about the local station) shows that the ring is <code>ISOLATED</code>.</p> | <p>Check that the link status indicator is <b>green</b> (indicating that the SunFDDI interface is attached to an active network). Check the connections to neighboring stations or the concentrator. Some concentrators have diagnostic LEDs that indicate if the ring is operating correctly.</p> <p>Check that the neighboring stations are configured correctly. If everything else seems to be working, check the cable itself. Fiber optic cable is fragile and should not be subjected to stress or impact. If the turning curve around objects is too tight, the light path is interrupted. Clean the connectors.</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |
| <p>The local station cannot reach FDDI stations located on a remote FDDI network.</p>                                                                                 | <p>Check that the IP address and host name of the remote station is entered in the NIS map or NIS+ tables (or in <code>/etc/hosts</code> on each remote station if you are not running NIS or NIS+).</p> <p>Check that the routing tables using <code>netstat -r</code>. Check for an <code>nf</code> interface that shows a route to a gateway with the flags <code>UG</code> set. If you can reach the local gateway, then the problem probably lies with the IP routing.</p> <p>Try to confirm that the remote station is configured and running, and if possible try to reach the local station from the remote station. If you can, it indicates that the problem lies with the local IP routing.</p> <p>Try to reach the router nearest the remote station. If you can, it indicates that the fault lies between the remote station and the router. If you cannot, try to reach a router that is closer to the local station. Continue in this way until you have isolated the router that is dropping or misrouting packets.</p> <p>If the dynamic routing protocol is not adding routes, try adding a static route to the remote station. This method is not recommended for large networks with a large number of nodes.</p> |

Table 6-3 Problems Running SunFDDI

| Problem                                                                                                                                                                                            | Action                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <p>The local station cannot reach FDDI stations located on a remote Ethernet network.</p>                                                                                                          | <p>Check that the IP address and host name of the remote station is entered in the NIS map or NIS+ tables (or in <code>/etc/hosts</code> on each remote station if you are not running NIS or NIS+).</p> <p>If you are operating in a Solaris 2.x environment, which uses MTU path discovery, check that packets are being transmitted across the bridge between the networks. Many bridges do not yet support MTU path discovery and do not fragment the large packets sent by the FDDI stations. In this case you may need to disable this feature on your station by typing:</p> <pre># ndd -set /dev/ip ip_path_mtu_discovery 0</pre> <p>Check that the routing tables using <code>netstat -r</code>. Check for an <code>nf</code> interface that shows a route to a gateway with the flags <code>UG</code> set. If you can reach the local gateway, then the problem probably lies with the IP routing.</p> <p>Try to confirm that the remote station is configured and running, and if possible try to reach the local station from the remote station. If you can, it indicates that the problem lies with the local IP routing.</p> <p>Try to reach the router nearest the remote station. If you can, it indicates that the fault lies between the remote station and the router. If you cannot, try to reach a router that is closer to the local station. Continue in this way until you have isolated the router that is dropping or misrouting packets.</p> <p>If the dynamic routing protocol is not adding routes, try adding a static route to the remote station. This method is not recommended for large networks with a large number of nodes.</p> |
| <p>Running <code>nf_stat</code> with the <code>-m</code> option (to display information about the neighboring stations) shows frequent <code>error frames</code> and <code>lost frames</code>.</p> | <p>This could indicate a noisy network. For fiber connections, noise is probably caused by dirt or grease on the optical surface or by a damaged cable. Unshielded twisted-pair is sensitive to electrical and electromagnetic interference. Note that the receipt of <code>error frames</code> and <code>lost frames</code> does not give any indication of where the problem is occurring on the ring.</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |

Table 6-3 Problems Running SunFDDI

| Problem                                                                                      | Action                                                                                                                                                                                                                                                                 |
|----------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Running <code>nf_smtmon</code> shows the frequent occurrence of request denied frames (RDF). | The SMT entity on one of the remote stations does not support the same set of SMT services. This should not occur on a station running SunFDDI. You can use this facility to detect problems communicating with a remote station using the SunNet Manager proxy agent. |

Table 6-4 Problems Using the SNM Agents for SunFDDI

| Problem                                                                                                                                               | Action                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        |
|-------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Cannot select <code>nf_fddi</code> or <code>nf_fddismt7_2</code> agent for quick dump.                                                                | Check that the SNM agents for SunFDDI are enabled in the properties window for the proxy station. See “Use the SunFDDI Proxy Agent ( <code>nf_fddismt7_2</code> )” on page 142 for detailed instructions.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| Cannot recover SMT statistics from the proxy agent. The procedure fails with the error message “Cannot create RPC client: program is not registered”. | <p>Check that you specified the hostname or MAC address for the target machine in the properties window for the target station. See “Use the SunFDDI Proxy Agent (<code>nf_fddismt7_2</code>)” on page 142 for detailed instructions.</p> <p>Check that the SNM daemons are started on the proxy and the target machines:</p> <pre># ps -ef   grep snm root &lt;pid&gt; &lt;date&amp;time&gt; &lt;path&gt;/nf_snmd root &lt;pid&gt; &lt;date&amp;time&gt; &lt;path&gt;/nf_snmd root &lt;pid&gt; &lt;date&amp;time&gt; &lt;path&gt;/nf_snmd</pre> <p>On a Solaris 2.x client, you can start the SunNet Manager daemons for SunFDDI by typing:</p> <pre># /usr/sbin/nf_snmd</pre> <p>On a Solaris 1.x client, you can start the SunNet Manager daemons for SunFDDI by typing:</p> <pre># /usr/etc/nf_snmd</pre> |

## Running the Hardware Self-Test Program

If you suspect that there may be a problem with the SunFDDI SBus card, you can use the built-in hardware self-test to check the state of its primary components and the connection to the network.

### ▼ Run the Hardware Self-Test:

1. **Log in as root or become superuser.**
2. **Halt the machine.**

```
# sync;sync;halt
```

3. **At the boot prompt, type:**

```
ok test /sbus/nf

Local MAC Address 0:80:d8:10:3:ed (Canonical)
Interrupt register read/write test .... PASS
CMT Processor read/write test ..... PASS
S Port register test ..... PASS
MAC register test ..... PASS
DMA register test ..... PASS
DMA bus master test ..... PASS
Performing FDDI path test ..... PASS
Connection Management (CMT) test ..... PASS
Local loopback packet test ..... PASS
Network loopback packet test ..... connection not active

/sbus/sbf selftest failed. Return code = -1
```

This example shows that the primary components on the board are working, but that the board is not currently connected to the network.

- a. **For Sun4m systems, at the boot prompt, type:**

```
ok test /iommu/sbus/nf
```

## *Loading the Device Driver Manually (Solaris 2.x)*

Normally, the SunFDDI device driver is loaded and configured by the post-installation script which is launched automatically when the software is installed. If you encounter problems when running this script, or if you want to customize the installation, you may need to load the device driver manually.

### ▼ Configure and Load the Device Driver

- 1. Log in as root or become superuser.**
- 2. Check that there are no partially installed drivers for SunFDDI.**  
Check for existing SunFDDI devices in the /dev directory.

```
# ls /dev | grep nf
nf
# ls /dev | grep smt
smt
```

Use `rem_drv(1M)` to remove any installed SunFDDI devices and remove the device directories.

```
# /usr/sbin/rem_drv smt
# /usr/sbin/rem_drv nf
# /bin/rm -f /dev/smt
# /bin/rm -f /dev/nf
```

Check in the file `/etc/name_to_major` for entries of the form `nf<num>` and `smt<num>` and remove these if they exist.

- 3. Use `add_drv(1M)` to inform the system about the new drivers.**

```
# /usr/sbin/add_drv nf
# /usr/sbin/add_drv smt
```

- 4. Check that the device drivers have been added to the system correctly.**  
Look in the `/devices/pseudo` directory for entries of the form:

```
ls -l /devices/pseudo | grep nf
crw----- 1 root sys 11,119 <date> clone@0:nf
ls -l /devices/pseudo | grep smt
crw----- 1 root sys 11,119 <date> clone@0:smt
```

Look in the `/dev` directory for links to these entries:

```
ls -l /dev | grep nf
lrwxrwxrwx 1 root other <date> nf -> ../devices/pseudo/clone@0:nf
ls -l /dev | grep smt
lrwxrwxrwx 1 root other <date> smt ->
../devices/pseudo/clone@0:smt
```

- 5. Create a file called `/etc/hostname.nf<inst>` for each SunFDDI IP interface that you configure.**

Each file must contain the hostname assigned to the IP interface. These files are used to configure the interfaces when the system is rebooted. If you assign the primary hostname to one of the FDDI interfaces, this hostname must be entered in the file `/etc/nodename`.

- 6. Use `ifconfig(1M)` to configure the SunFDDI IP interfaces (`nf<inst>`).**

The hostname assigned to the IP interface must be entered in the NIS map, NIS+ tables, or in `/etc/hosts` on the local machine. Configure the interface using an `ifconfig` command of the form:

```
# /usr/sbin/ifconfig nf<inst> plumb <hostname> netmask + up
```

Note that the modifier `netmask +` takes the netmask defined in the file `/etc/netmasks`. If this entry is missing, you must specify the netmask explicitly using dot notation.

Provided the installation and configuration was successful, your SunFDDI station is now active and you can send and receive data transparently across an FDDI connection.

## Loading the Device Driver Manually (Solaris 1.x)

Normally, the SunFDDI device driver is loaded and configured by the post-installation script which is launched automatically when the software is installed. If you encounter problems when running this script, or if you want to customize the installation, you may need to load the device driver manually.

### ▼ Configure and Load the Device Driver

1. **Log in as root or become superuser.**
2. **Change directory to /usr/sunlink/nf/sys/<arch>/OBJ, where <arch> is dependent on your machine architecture.**

```
# cd /usr/sunlink/nf/sys/<arch>/OBJ
```

3. **Compile the file /usr/sunlink/nf/sys/sunif/nf\_conf.c using the following compile options:**

```
# cc -O -I/sys -DKERNEL -sparc -c ../../sunif/nf_conf.c
```

4. **Link the object file nf\_conf.o with the other SunFDDI kernel object files:**

```
# ld -r -o nf.o if_nf.o smt.o nf_smtcore.o nf_conf.o
```

If the system has a multicast kernel, link the object file `nf_conf.o` as follows:

```
# ld -r -o nf.o if_nf.mcast.o smt.mcast.o nf_smtcore.mcast.o nf_conf.o
```

5. **Move the SunFDDI driver nf.o to /usr/etc.**

```
# mv nf.o /usr/etc
```

**6. Create the file** `/dev/nf.AUTOLOAD`.

```
# touch /dev/nf.AUTOLOAD
```

**7. Create the following soft links which must point to the script**  
`/usr/etc/nf.INSTALL`.

```
# ln -s /usr/etc/nf.INSTALL /dev/nf.LOAD
# ln -s /usr/etc/nf.INSTALL /dev/nf.UNLOAD
# ln -s /usr/etc/nf.INSTALL /dev/nf.INSTALL
# ln -s /usr/etc/nf.INSTALL /dev/nf.MKDEV
# ln -s /usr/etc/nf.INSTALL /dev/nf.RMDEV
```

**8. Create the script** `/etc/loadable` **which is used to load the driver module.**

```
if [ -f /dev/nf.LOAD ]; then
    if [ -f /dev/nf.AUTOLOAD ]; then
        /dev/nf.LOAD
    fi
fi
```

**9. Execute the script** `/etc/loadable` **to load the driver module.**

**10. Use** `ifconfig(1)` **to configure the SunFDDI IP interfaces** (`nf<inst>`).

The hostname assigned to the IP interface must be entered in the NIS map, or in `/etc/hosts` on the local machine. Configure the interface using an `ifconfig` command of the form:

```
# /usr/etc/ifconfig nf<inst> <hostname> netmask + up
```

Note that the modifier `netmask +` takes the netmask defined in the file `/etc/netmasks`. If this entry is missing, you must specify the netmask explicitly using dot notation.

Provided the installation and configuration was successful, your SunFDDI station is now active and you can send and receive data transparently across an FDDI connection.



*Part 2 — Planning and Implementing  
SunFDDI Networks*

---

---

|                                  |                |
|----------------------------------|----------------|
| <i>FDDI Network Model</i>        | <i>page 74</i> |
| <i>FDDI Network Architecture</i> | <i>page 79</i> |
| <i>FDDI Failure Recovery</i>     | <i>page 84</i> |
| <i>FDDI Ring Operation</i>       | <i>page 89</i> |
| <i>FDDI Performance</i>          | <i>page 91</i> |

This chapter provides a brief introduction to the Fiber Distributed Data Interface (FDDI), and the network architecture described by the following specifications:

- ANSI/FDDI Physical Media Dependent (PMD) X3.166-1990
- ANSI/FDDI Physical Layer (PHY) X3.148-1988
- ANSI/FDDI Medium Access Control (MAC) X.3.139-1987
- ANSI/FDDI Station Management (SMT) X3.299 R7.3 (formally R7.2.99)

## FDDI Network Model

The Fiber Distributed Data Interface (FDDI) provides high-performance, multistation networking at data transfer rates of up to 100 Mbps. It is based on a token-ring network architecture, and provides communication over optical fiber or copper twisted-pair connections.

The ANSI/FDDI specifications define a network model that consists of the following components:

- Physical Media Dependent (PMD) Layer
- Physical (PHY) Layer
- Medium Access Control (MAC) Layer
- Station Management (SMT) Protocol

Figure 7-1 shows the organization of these components, and their relationship with other network protocols that use them.




Figure 7-1 FDDI Architectural Model

## *Physical Media Dependent (PMD) Layer*

This portion of the FDDI network model defines the physical medium used to carry the encoded digital signal. It is also referred to as the *media* layer.

The PMD layer determines the characteristics of the transmitters, receivers, connectors, and cables used to attach the FDDI station to the network. There are a number of PMD options, of which SunFDDI supports the following:

- **Multimode fiber (MMF)**—single and dual-attached
- **Unshielded twisted-pair (UTP)**—single-attached only

### *Multi-Mode Fiber (MMF)*

A fiber optic FDDI connection supports data transmission rates of up to 100 Mbps and, because attenuation in the fiber is very low, larger distances between FDDI stations are possible without the use of repeaters. In addition, fiber does not emit electromagnetic radiation and is electrically nonconductive. Therefore, it neither causes, nor suffers from, problems due to signal interference between adjacent equipment or cabling.

SunFDDI supports 62.5/125 micrometer, multimode fiber (MMF). Multimode fiber cannot support such large distances between FDDI stations as single-mode fiber (SMF), which is not supported by SunFDDI. However, multimode fiber is cheaper, and uses lower cost terminations, connectors, and light-sources.

## *Physical (PHY) Layer*

The physical (PHY) layer handles the efficient encoding and decoding of digital data. It is also referred to as the *signal* layer.

At the transmitting end, the PHY layer encodes the digital data into FDDI *symbols* and passes them to the physical media dependent (PMD) layer for transmission. At the receiving end, the PHY layer decodes the FDDI symbols and passes the digital data to the medium access control (MAC) layer. An FDDI symbol is the basic transmission unit in an FDDI network.

The PHY layer also provides the network synchronization mechanism. It uses a distributed clocking scheme under which each FDDI station has its own local clock to synchronize the transmission of outgoing data. The PHY layer extracts clocking information from incoming data as it is received.

## *Medium Access Control (MAC) Layer*

The medium access control (MAC) layer specifies the access mechanism used to transmit and receive data on the FDDI network. It packages digital data in *frames*.

The MAC layer specifies three classes of digital data traffic:

- Synchronous (guaranteed) traffic
- Asynchronous (priority-based) traffic
- Restricted (dialogue-based) traffic

The MAC layer uses a *timed token rotation protocol* that regulates how much digital data can be sent at one time. This protocol ensures that the network bandwidth is used predictably and efficiently. It also gives the FDDI network its distinctive “ring” topology.

The FDDI stations connected on the network use a token to control the right to transmit data for a predefined time, determined by the local *timed target rotation timer* (TTRT) on each station. When an FDDI station completes transmission it releases the token for use by downstream stations. In this way, the token rotates continuously around the ring.

Each attachment to an FDDI network is identified by a unique MAC address. The first SunFDDI SBus card installed in a machine takes its identity from the host-resident MAC address that is stored in nonvolatile memory on the motherboard of the machine in which it is installed. Each subsequent SunFDDI SBus card takes its identity from the card-resident MAC address stored in its own IDPROM.

Use the `nf_macid(1M)` utility to display the card-resident MAC address. See Chapter 9, “Using the SunFDDI Network Utilities” for detailed instructions.

## *Station Management (SMT) Layer*

The station management (SMT) layer provides services to manage, control, and configure the FDDI network. It is also referred to as the *network management* layer.

At its lowest level, the SMT protocol handles *connection management* (CMT). This includes station initialization, the insertion and removal of stations on the network, and connection compatibility between stations. At a higher level, the SMT protocol handles *ring management* (RMT). This includes the detection of duplicate addresses and the isolation of fault conditions.

The SMT protocol also defines the FDDI *management information base* (MIB). This is a set of managed objects and associated attributes that includes the MAC entity (MAC), data path (PATH), attachment type (ATTACHMENT), and port identifier (PORT).

Communication services are used to exchange objects and information between peer SMT entities in the form of special management frames that are carried at the same time as normal network traffic. This frame-based management is used to:

- Examine and modify FDDI station configuration
- Schedule synchronous (guaranteed) and asynchronous (priority-based) traffic
- Gather network statistics
- Generate status reports

SunFDDI includes SunNet Manager agents that access the SMT entity to collect and return FDDI statistics to a SunNet Manager console. See Chapter 10, “Managing FDDI Stations Using SunNet Manager” for detailed instructions on how to manage FDDI networks using a SunNet Manager console.

## *Communication Between FDDI Layers*

The MAC layer transfers data between peer entities in the form of frames that are encoded as FDDI symbols by the PHY layer. The PMD layer transmits FDDI symbols across the network as a bit stream of light pulses (for fiber connections) or electrical signals (for twisted-pair connections).

The communication between layers in the FDDI architectural model is summarized in Figure 7-2.




Figure 7-2 Communication Between FDDI Layers

## FDDI Network Architecture

A typical FDDI network is based on a dual, counter-rotating ring, as illustrated in Figure 7-3. Each FDDI station is connected in sequence to two rings simultaneously—a primary ring and a secondary ring. Data flows in one direction on the primary ring, and in the other on the secondary ring.




Figure 7-3 Basic FDDI Network Architecture

The secondary ring serves as a redundant path. It is used during station initialization, and may be used as a backup to the primary ring in the event of a station or cable failure. When a failure occurs, the dual-ring is “wrapped” around to isolate the fault and to create a single, one-way ring. The components of a typical FDDI network and the failure recovery mechanism are described in more detail in the following sections.

## FDDI Stations

An FDDI station is any device that can be attached to a fiber or copper twisted-pair FDDI network through an FDDI interface. The FDDI protocols define two types of FDDI station:

- Single-attached station (SAS)
- Dual-attached station (DAS)

### Single-Attached Station (SAS)

A single-attached station (SAS) is attached to the FDDI network through a single connector, called the S-port. The S-port has a primary input ( $P_{in}$ ) and a primary output ( $P_{out}$ ). Data from an upstream station enters through  $P_{in}$  and exits from  $P_{out}$  to a downstream station, as shown in Figure 7-4.

Single-attached stations are normally attached to single- and dual-attached concentrators as described in “FDDI Concentrators” on page 82.




Figure 7-4 Single-Attached Station (SAS)

### Dual-Attached Station (DAS)

A dual-attached station (DAS) is attached to the FDDI network through two connectors, called the A-port and the B-port, respectively. The A-port has a primary input ( $P_{in}$ ) and a secondary output ( $S_{out}$ ); the B-port has a primary output ( $P_{out}$ ) and a secondary input ( $S_{in}$ ).

The primary input/output is attached to the primary ring and the secondary input/output is attached to the secondary ring. The flow of data during normal operation is shown in Figure 7-5.

In order to complete the ring, you must ensure that the B-port of an upstream station is always connected to the A-port of a downstream station. For this reason, most FDDI DAS connectors are keyed to prevent connections between two ports of the same type.




Figure 7-5 Dual-Attached Station (DAS)

## FDDI Concentrators

FDDI concentrators are multiplexers that attach multiple single-attached stations to the FDDI ring. An FDDI concentrator is analogous to an Ethernet hub.

The FDDI protocols define two types of concentrator:

- Single-attached concentrator (SAC)
- Dual-attached concentrator (DAC)

### Single-Attached Concentrator (SAC)

A single-attached concentrator (SAC) is attached to the FDDI network through a single connector, which is identical to the S-port on a single-attached station. It has multiple M-ports, to which single-attached stations are connected as shown in Figure 7-6.




Figure 7-6 Single-Attached Concentrator (SAC)

### Dual-Attached Concentrator (DAC)

A dual-attached concentrator (DAC) is attached to the FDDI network through two ports—the A-port and the B-port, which are identical to the ports on a dual-attached station. It has multiple M-ports, to which single-attached stations are connected as shown in Figure 7-7.

Dual-attached concentrators and FDDI stations are often arranged in a very flexible network topology called the *ring of trees*. This configuration is discussed in more detail in Chapter 8, “FDDI Network Topologies.”




Figure 7-7 Dual-Attached Concentrator (DAC)

## FDDI Failure Recovery

One of the primary advantages of FDDI is its ability to recover reliably from failures in stations and cables. The failure mechanism is implemented and controlled by the station management (SMT) entity described in the section “Station Management (SMT) Layer” on page 76.

A failure could be something as apparently insignificant as someone switching off their workstation, and the ability of FDDI to recover from such an event increases the reliability of the network significantly.

### Station Wrapping

Figure 7-8 shows the effect of a single station failure in a FDDI network which comprises four dual-attached stations connected in a basic ring configuration. When a failure occurs, the SMT entities on the stations on either side of the fault dynamically reconfigure the network to isolate it. In this condition the primary and secondary rings are wrapped on to each other to form a single, one-way ring.




Figure 7-8 Isolating a Single Station Failure

This failure recovery mechanism is only supported by dual-attached stations and concentrators; a single-attached station connected directly to the ring cannot wrap around the fault because it is only connected to one ring at a time.

The effect of a cable or link failure on a basic FDDI network is very similar to a station failure, as shown in Figure 7-9. The SMT entities on the stations on either side of the failed connection reconfigure the network dynamically so that the primary ring is wrapped onto the secondary ring.




Figure 7-9 Isolating a Single Cable Failure

Wrapping occurs within the MAC layer. Figure 7-10 on page 86 illustrates how the dual-attached station is reconfigured to wrap the primary ring onto the secondary ring. Dual-attached concentrators wrap in a similar way. In this case, all of the single-attached stations connected to the concentrator are also wrapped onto the secondary ring.




Figure 7-10 Dual-Attached Station in Wrap Mode

### Optical Bypass Switches

Station wrapping provides effective network recovery in the event of a single station or cable failure. However, two or more failures in the ring will isolate portions of the network as shown in Figure 7-11.

This limitation can be overcome to a certain extent by fitting *optical bypass switches* to the dual-attached stations. As their name suggests, these switches provide an optical connection that bypasses the station in the event of failure, or if the station needs to be removed from the ring. Optical bypass switches can only be used to overcome station faults; they have no effect in the event of a cable fault.

The attenuation in an optical bypass switch is far greater than in a normal FDDI connection; therefore, there is a limit to the number of optical bypass switches that can be connected in series in a single ring.




Figure 7-11 Dual Ring Network Divided by Two Faults

The maximum number of active optical bypass switches that can be connected in series is four. This assumes that the maximum distance between stations in the ring is no more than 400m; otherwise, the aggregate attenuation in the ring exceeds the total optical power budget.

Figure 7-12 shows how connecting an optical bypass switch to a dual-attached station is used to conserve the connection when the station is switched off, or removed from the ring.




Figure 7-12 Optical Bypass Switch

Figure 7-13 shows the occurrence of two different fault conditions in an FDDI network that includes optical bypass switches. The station fault is bypassed effectively to conserve the majority of the network intact; however, the cable fault still causes station wrapping.




Figure 7-13 Optical Bypass Switches used in a Network

---

## *FDDI Ring Operation*

Two types of traffic are allocated bandwidth on an FDDI ring:

- **Asynchronous traffic** (unrestricted and restricted)

The unrestricted asynchronous service allocates bandwidth dynamically based on the *timed token rotation protocol*, and according to the priority assigned to the traffic. It does not guarantee bandwidth; therefore, unrestricted asynchronous traffic may be delayed on a heavily loaded network.

The restricted asynchronous service allocates bandwidth for extended transmission based on *restricted token exchange* between communicating stations. During restricted transmission, the timed token rotation protocol is suspended until the restricted token is released. The use of the restricted asynchronous service is relatively rare.

- **Synchronous traffic**

For synchronous operation, a specific portion of the bandwidth is reserved for synchronous traffic and a boundary is placed on the access delay (the time that a station must wait before being able to transmit). The synchronous service is assigned the highest priority on the ring and is normally used to transfer voice, video, and real-time process control data, where the access delay can have significant impact.

---

**Note** – It is the network user (the application) that requests synchronous service and manages synchronous operation. Synchronous transmission is not supported for SunFDDI running in a Solaris 1.x environment.

---

## *Unrestricted Asynchronous Transmission*

The FDDI network is most commonly used for unrestricted asynchronous traffic. This is the default mode for SunFDDI and is the only mode supported in a Solaris 1.x environment. Access to the FDDI ring is controlled by a *permission token*, or right to transmit. The permission token is a special frame that is passed between stations. Unlike the tokens used in a token ring network, the FDDI permission token contains no additional information.

The station holding the permission token completes transmission either when it has no more packets to transmit, or when its right to hold the token expires. It then releases the token, which is now available for use by the next station on the ring. In this way, the permission token rotates around the ring, at a rate determined by the overall *target token rotation time* (TTRT).

The TTRT is established when the ring is initialized, based on a bidding procedure called the *claim process*. During the claim process, each station puts in a request ( $T_{req}$ ) for the TTRT. The lowest bid—that is, the fastest rotation time—wins the claim process and is stored in 2's complement form as the operating value of TTRT ( $T_{opr}$ ). The maximum value of TTRT ( $T_{max}$ ) allowed by the MAC layer is implementation dependent, but is always in the range ~165 ms. SunFDDI has  $T_{max}=167.874$  ms.

The maximum time for which a station can hold the permission token, and therefore the time for which station can transmit on the ring, is determined by two station timers that work together to maintain the target token rotation time (TTRT), irrespective of the load on the network:

- **Token Rotation Timer (TRT)**

The TRT measures the time between successive arrivals of the token—that is, the time taken for the token to rotate once around the ring. The TRT is reset to the operating value of TTRT ( $T_{opr}$ ) each time the token is received. If the TRT expires before the token arrives, the token is considered late and the flag `Late_Ct` is set. Only synchronous (high priority) traffic can be transmitted when `Late_Ct` is set.

- **Token Hold Timer (THT)**

The THT determines how long a station can hold a token—that is, how long a station can transmit asynchronous traffic. It is loaded with the value remaining in the token rotation timer (TRT) each time the token arrives. Thus, the faster the token rotates, the more transmission time allocated to each station. If the token is delayed—that is, the network is heavily loaded—the amount of transmission time is reduced. If THT expires during transmission, the current transmission is completed before the token is released.

The interaction of these two timers causes token rotation to increase (reduced transmission time per station) in a heavily loaded network, and to decrease (increased transmission time per station) in a lightly loaded network.

## *FDDI Performance*

Although the FDDI standards define a medium that supports data transfer rates of up to 100 Mbps, this does not translate directly into an order of magnitude increase in overall system performance. In fact, it frequently transfers the bottleneck elsewhere, so that the FDDI connection is not used to capacity.

It is better to think of an FDDI ring as having the *potential* to carry more information, than as being a faster connection. If the applications running over the network do not use the available bandwidth efficiently, you will not see much improvement in the performance of your network, above that of traditional Ethernet connections.

Amongst the factors that affect FDDI network performance are:

- Network topology
- Network load
- Network efficiency
- Processor speed (on the FDDI stations)
- Bus architecture

There are a number of ways of improving the overall performance of the network, some of which are discussed in Chapter 5, “Improving Network Performance.” However, the majority of these should only be undertaken by experienced system administrators. Any improvement obtained by modifying the behavior of the FDDI network itself is negligible in comparison to that obtained by making more efficient use of the available bandwidth.



|                                       |                 |
|---------------------------------------|-----------------|
| <i>Basic Dual Ring Network</i>        | <i>page 94</i>  |
| <i>Stand-alone Concentrator</i>       | <i>page 96</i>  |
| <i>Concentrators with Dual-Homing</i> | <i>page 98</i>  |
| <i>Tree of Concentrators</i>          | <i>page 100</i> |
| <i>Ring of Trees</i>                  | <i>page 102</i> |
| <i>Mixed Fiber/UTP Network</i>        | <i>page 104</i> |
| <i>Mixed FDDI/Ethernet Networks</i>   | <i>page 106</i> |

FDDI networks can be arranged a variety of ways, depending on the placement of stations (SAS and DAS) and the use of concentrators (SAC and DAC). The optimum arrangement for a particular installation is dependent on several factors, including:

- Cost
- Network size
- Required Bandwidth
- Type of network traffic
- Fault resistance and network reliability

This chapter describes some of the common FDDI network topologies and discusses the primary advantages and disadvantages of each.

## Basic Dual Ring Network

The dual ring (or dual, counter-rotating ring) is one of the simplest FDDI network topologies. It clearly illustrates the distinctive ring architecture most commonly associated with the FDDI standards, as shown in Figure 8-1. Each station is critical to the operation of the network; therefore, the basic dual ring topology is best adapted to small, stable networks that are not subject to frequent reconfiguration.

In a dual ring network, dual-attached stations are connected directly to the primary and secondary rings. Data, and the token that controls the flow of data, are transmitted in one direction on the primary ring. Data flows in the other direction on the secondary ring, which is used during ring initialization and as a backup in case of a ring failure.




Figure 8-1 Basic Dual Ring Network

## Advantages

The primary advantages of the dual ring network topology are its simplicity and its ability to recover from simple station and line faults. The secondary ring provides an effective backup in the event of a *single* failure in the ring. When a ring fails, the primary ring is wrapped automatically on either side of the fault so that the primary and secondary rings are combined to form a single, one-way ring. This mechanism is described in more detail in “FDDI Failure Recovery” on page 84. A dual ring network does not require a concentrator.

## Disadvantages

Although the dual ring topology is resistant to single failures in the ring, two or more failures break the network into parts. Small fragments of the network can still function, but they are isolated from the other stations. Figure 8-2 shows how two faults in a network with five dual-attached stations isolates two parts of the network. Cable and connection costs can be high in large installations, because there are two cables between each station.




Figure 8-2 Basic Dual Ring Network with Two Faults

## Stand-alone Concentrator

Figure 8-3 shows multiple single-attached stations connected to a single, dual-attached concentrator through its M-ports. The concentrator can also be connected to an external dual ring through its A- and B-ports.

A stand-alone concentrator provides a stable, low-cost alternative for small work groups that do not require the fault recovery facility provided by the dual-ring configuration.




Figure 8-3 Stand-alone Concentrator

The typical ring architecture of the FDDI network is less obvious in this topology because it exists within the concentrator itself. For this reason, this arrangement of stations is usually described as a *tree*, with the concentrator as the root.

## *Advantages*

In this configuration, individual stations have less influence on the operation of the network, which is controlled by the concentrator. Concentrators are inherently more stable than FDDI stations. They do not have monitors, or disk drives, they are subject to more predictable usage, and they are less likely to be switched off. As a result, a stand-alone concentrator provides a more reliable network than the basic dual ring configuration described on page 94.

Concentrators are equipped with built-in electrical-bypass facilities that isolate single station faults. Unlike the station optical bypass facility described on page 86, there is no limit to the number of stations that can be bypassed using the electrical switches in concentrators.

The majority of stations attached to the concentrator are single-attached stations; therefore, only one cable is required for each station.

There is more flexibility allowed in the physical location and wiring configuration. Since the stations do not have to be attached in any fixed order and all cables return to a central concentrator, this configuration is useful at sites where FDDI cable has already been installed.

The A- and B-ports on a concentrator can be used to connect it to an external dual-ring configuration. This is a common configuration called the *ring of trees*, which is discussed on page 102.

## *Disadvantages*

The number of stations that can be attached to a single concentrator is limited by the number of M-ports. This is typically in the range 2 to 32.

The cost of a concentrator is significantly higher than that of a single-attached or dual-attached station; however, there are some low cost concentrators available that do not support all of the SMT management functions.

Although concentrators are more stable than FDDI stations, when the concentrator goes down, the whole network goes down with it.

## Concentrators with Dual-Homing

Figure 8-3 shows two dual-attached stations connected to two dual-attached concentrators in a dual-homing configuration. In this case, each dual-attached station is connected to both DACs. This topology is typically used for connecting critical systems such as file and name servers.




Figure 8-4 Stand-alone Concentrator

Dual-homing provides two independent data paths for each dual-attached station. Under normal conditions, the station communicates on its primary path through the B-port. In the event of a cable or concentrator failure, the station switches to the secondary path connected through the A-port.

---

Dual-homing is equivalent to the *redundant single-attached station* (RSAS) configuration, which was supported by SunLink FDDI/S 2.0. In the RSAS configuration, two single-attached interfaces are used to emulate a dual-attached interface connected in a dual-homing configuration. RSAS is not supported by SunFDDI 4.0.

### *Advantages*

Dual-homing offers the same advantages as a stand-alone concentrator, described on page 96. It also offers improved resistance against cable faults and concentrator failure.

### *Disadvantages*

The number of stations that can be attached to the concentrator is limited by the number of M-ports, which is typically between 2 and 32. Since each dual-homed station requires two M-ports, only a limited number of stations can be connected in this way.

The dual-homing configuration requires a minimum of two concentrators, which are more expensive than single-attached or dual-attached stations.

## Tree of Concentrators

The *tree of concentrators* is an incremental expansion of the stand-alone concentrator topology, described on page 96. Two or more concentrators are connected in a hierarchical topology, with one concentrator designated as the root of the tree as shown in Figure 8-5. This topology is typically used to connect a large number of stations within a single building or office.




Figure 8-5 Hierarchical Tree of Concentrators

---

### *Advantages*

This configuration offers many of the advantages offered by the stand-alone concentrator, described on page 96; however, it allows a much larger number of stations to be connected.

The cumulative length of the network is increased significantly because the limitation on distance occurs between the end-station and the nearest concentrator, and not between the end-station and the root concentrator.

### *Disadvantages*

This configuration suffers from the same disadvantages as the stand-alone concentrator, described on page 96. The number of stations connected to each concentrator is limited by the number of M-ports, and the loss of a concentrator takes down all of the stations attached to it.

## Ring of Trees

The *ring of trees* is a derivative of the tree of concentrators topology described on page 100. The root concentrator is replaced by a dual-ring to which dual-attached concentrators are connected as shown in Figure 8-6. This topology is ideal for connecting a large number of stations in a campus or multiple-building network.




Figure 8-6 Ring of Trees

The dual-ring, and the concentrators attached to it directly, are called the *main distribution frame*. There can be only one main distribution frame in each network.

The second level in the hierarchy is called the *intermediate distribution frame* and consists of the root concentrators in each building, and any stations connected to them directly.

The third level in the hierarchy is called the *horizontal distribution frame* and consists of concentrators connected to distributed stations, usually through wall boxes.

### *Advantages*

The ring of trees configuration combines many of the advantages of the basic dual-ring and the concentrator-based topologies. It offers good fault tolerance and is a very flexible configuration.

Since only a few stations (the root concentrators) are attached to the dual-ring, optical bypass switches can be used to increase the reliability of the main distribution frame, as described in “Optical Bypass Switches” on page 86. The small number of stations and the increased reliability of the concentrators means that the chances of having more than three adjacent stations bypassed at one time are minimal.

The cumulative length of the network can be increased because the limitation on distance occurs between the end-station and the nearest concentrator, and not between the end-station and the root concentrator.

### *Disadvantages*

Only the concentrators attached directly to the dual-ring benefit from its inherent redundancy.

## Mixed Fiber/UTP Network

Unshielded twisted-pair provides a very cost-effective option for local area networks, particularly at sites where high-quality (category 5, data-grade), twisted-pair copper cable has already been deployed.




Figure 8-7 Mixed Fiber/UTP Network

Figure 8-7 shows how a ring of trees topology of the type discussed on page 102 can be implemented using a combination of fiber and UTP. Fiber is deployed between concentrators in the main and intermediate distribution frames, while UTP is used over the typically short distance between concentrators and end-stations in the intermediate and horizontal distribution frames. The maximum distance between an end-station and the concentrator is 100m, divided as shown in Figure 8-8.




Figure 8-8 Cable between End-Stations and the Concentrator

In this example, dual-attached servers have been dual-homed (see page 98) to a cluster of concentrators connected on the reliable fiber optic backbone. This is a common configuration for a large campus or multiple-building network, where high-quality UTP has already been deployed in the individual buildings. The combination of fiber optic backbone and dual-homing ensures reliable access to the central servers, while the UTP links provide low-cost connection to a large number of stations.

## Advantages

This topology combines the advantages of fiber and UTP. It provides a reliable fiber optic backbone, with low-cost connection to a large number of stations.

## Disadvantages

UTP is less reliable than fiber; therefore there is a greater risk of losing individual connections to the network. The UTP connections to the end-stations are more at risk from electromagnetic interference between adjacent cables and equipment. The distance between the concentrator and the end-stations in the horizontal distribution frame is limited by the use of UTP.

## Mixed FDDI/Ethernet Networks

This section concentrates on the implementation of mixed FDDI/Ethernet networks. The same principles could be applied to mixed FDDI/802.3 and mixed FDDI/802.5 (token ring) networks. FDDI and token ring networks are based on a ring topology; Ethernet and 802.3 networks are based on a bus topology.

### FDDI/Ethernet IP Router

The machines at the boundaries between the FDDI and Ethernet networks in the following examples are assumed to be SPARCstations or SPARCservers that have at least one SunFDDI interface and one Ethernet interface installed. These machines operate as IP routers.

No special software is required. The combination of the SunFDDI driver and the SunOS IP routing implementation handles the routing and relaying of packets between FDDI and Ethernet stations. Note that the packets on the FDDI ring can be as long a 4500 octets, whereas Ethernet packets are restricted to a maximum of 1500 octets.

Figure 8-9 illustrates the basic topology of a mixed FDDI/Ethernet network. In this example, there are two FDDI/Ethernet IP routers that represent the boundaries between the three networks.




Figure 8-9 Basic Mixed FDDI/Ethernet Topology

## *A Tree of Concentrators in an Ethernet Network*

A tree of concentrators of the type described on page 102 is attached to an Ethernet network by connecting a SPARCstation to the root concentrator as shown in Figure 8-10




Figure 8-10 Tree of Concentrators Attached to an Ethernet Network

## *A Ring of Trees in an Ethernet Network*

A ring of trees of the type described on page 102 is attached to an Ethernet network by connecting a SPARCstation to one of the concentrators in the main distribution frame as shown in Figure 8-11.




Figure 8-11 Ring of Trees Attached to an Ethernet Network

## Routes in Mixed FDDI/Ethernet Networks

The FDDI/Ethernet IP router is recognized by the IP address and hostname of its FDDI interface by the FDDI network; it is recognized by the IP address and hostname of its Ethernet interface by the Ethernet network. Note an FDDI/Ethernet router usually has the same MAC address on both networks.

In general, stations in an internetwork can be reached via multiple routes. The standard routing daemon (`routed`) included in the SunOS determines the optimum route between stations based on relative hop count, and not based on the speed of the interface. Therefore, in cases where the hop count is equal the use of the faster FDDI network is not guaranteed.




Figure 8-12 Routing in an FDDI/Ethernet Internetwork

For example, in the FDDI/Ethernet internetwork shown in Figure 8-12 on page 108 there are parallel routes between `jill` and `judy` across relatively faster and slower networks.

**Route 1** (across FDDI link):

```
jill→bob-le0→bob-nf→sam-nf→sam-le0→judy
```

**Route 2** (across Ethernet link):

```
jill→bob-le0→bob-le1→sam-le1→sam-le0→judy
```

There is an identical number of hops between the two stations regardless of the route taken; therefore, `routed` may send all of the traffic across the slower Ethernet link in preference to the faster FDDI link.

You can avoid this situation by setting up a static route that forces the traffic between `jill` and `judy` to pass over the FDDI link; however, static routing is not recommended in a network beyond a few nodes in size. For efficient IP routing in large FDDI/Ethernet networks, you should use a routing package which provides routing metrics in addition to hop count. For example, `gated`, which is public domain software made available by the Center for Theory and Simulation in Science, Cornell University.

To improve the end-to-end system performance across the boundary between the networks you may need to alter the default MTU for the FDDI network. (see “Performance Across Bridges” on page 39) or to disable the MTU path discovery feature introduced by the Solaris 2.x environment (see “Improving Performance in a Solaris 2.x Environment” on page 41”).



# Using the SunFDDI Network Utilities



|                                                    |                 |
|----------------------------------------------------|-----------------|
| <i>Changing the Default MAC Address (nf_macid)</i> | <i>page 112</i> |
| <i>Displaying SunFDDI Statistics (nf_stat)</i>     | <i>page 114</i> |
| <i>Monitoring SMT Frames (nf_smtmon)</i>           | <i>page 124</i> |
| <i>Configuring Synchronous FDDI (nf_sync)</i>      | <i>page 128</i> |

This chapter describes the network utilities delivered with SunFDDI. The behavior of the SunFDDI network utilities is identical for both Solaris 2.x and Solaris 1.x environments.

Throughout this chapter, it is assumed that you have installed the SunFDDI software under the default base directory *<basedir>* for your operating system.

For a Solaris 2.x environment, the default base directory *<basedir>* is:

```
/opt/SUNWconn/bin
```

For a Solaris 1.x environment, the default base directory *<basedir>* is:

```
/usr/sunlink/nf/usr/etc
```

## Changing the Default MAC Address (`nf_macid`)

Each attachment to an FDDI network is identified by a unique, 48-bit MAC address. By default, the first SunFDDI SBus card takes the host-resident MAC address, which is stored in nonvolatile memory (NVRAM) on the motherboard of the machine. Each subsequent SunFDDI SBus card adopts the card-resident MAC address stored in its own IDPROM.

In general, this convention is sufficient to ensure that each SunFDDI SBus card installed in the machine has a unique MAC address. However, there may be a conflict with other LAN interfaces that also take the host-resident MAC address—for example, an Ethernet (1e) interface, or a SunFDDI 2.0 (bf) interface. In this event, change the default MAC address assigned to the first SunFDDI SBus card installed in the system.

### ▼ Change the Default MAC Address With `nf_macid`

Use the `nf_macid(1M)` utility to recover the card-resident MAC address, and then modify the system files to override the default MAC address:

1. **Login as root or become superuser.**
2. **Use the `nf_macid(1M)` utility to recover the MAC address from the IDPROM on the SunFDDI interface identified by the instance number `<inst>`.**

```
# <basedir>/nf_macid nf<inst>
<mac_address>
```

3. **Modify the start-up file on your machine so that the MAC address is assigned correctly when the system is rebooted.**

- For a Solaris 2.x environment, edit the file `/etc/rcS.d/S30rootusr.sh` to add the following `if` statement immediately *after* the `ifconfig` command that initializes the interface `nf<inst>`. If you are changing the MAC address of more than one interface, you should add one `if` statement for each interface.

`if` statement to initialize  
interface `nf<inst>` ----->

```
ifconfig $1 plumb
  if [ $1 = "nf<inst>" ]; then
    ifconfig nf<inst> ether <mac_address>
  fi
```

On most systems the file `/etc/rcS.d/S30rootusr.sh` is a hard link to the file `/etc/rootusr`.

- For a Solaris 1.x environment, edit the file `/etc/rc.local` to add the following line immediately *before* the `ifconfig` command that initializes the interface `nf<inst>`. If you are changing the MAC address of more than one interface, you should add one declaration for each interface.

Command to initialize  
interface `nf<inst>` ---->

```
ifconfig nf<inst> ether <mac_address>
ifconfig nf<inst> <hostname> netmask + -trailers up
```

#### 4. Reboot your machine to assign the new MAC address to the SunFDDI interface.

When a SunFDDI SBus card takes the host-resident MAC address, it can be swapped to another system without affecting the existing network. However, once a station starts sending packets on the network, the Address Resolution Protocol (ARP) updates the ARP tables on other stations to include the MAC address of its interface. The ES-IS protocol performs the same function for SunLink OSI running over FDDI. If you swap SunFDDI SBus cards that use the card-resident MAC address, you must wait until the ARP entries time-out, or remove the ARP entries from every active station manually, before packets can be routed correctly.

## Displaying SunFDDI Statistics (nf\_stat)

The `nf_stat(1M)` utility interrogates a specified SunFDDI interface and displays the accumulated statistics. This command must be executed as `root` (or `superuser`) and has the general form:

```
# <basedir>/nf_stat [-m] nf<inst> [<interval>] [<count>]
```

`nf<inst>` specifies the SunFDDI interface

`<interval>` is the elapsed time (in seconds) between interrogations

`<count>` the total number of interrogations

The `nf_stat` utility displays information using column headings that conform to SMT revision 7.3, which differ from SMT revision 5.1 and 4.2 headings in the following cases:

- The heading `ECM` corresponds to the 5.1 heading `MIM`.
- The heading `RMT` does not have an analog in SMT revision 4.2. If you run SunFDDI at revision level 4.2, ignore any data displayed under the `RMT` heading of `nf_stat`.

## Displaying Local Interface Statistics

When you enter the `nf_stat` command *without* the `-m` option, it displays statistics recovered from the local interface `nf<inst>`.

For example, to display the accumulated statistics for the interface `nf0`, type:

```
# <basedir>/nf_stat nf0
Ring   ECM      RMT      PCMS   Ring_OP   XmitP     RecvP
UP      IN    RING_OP  ACTIVE      c        16fde     1862d
```

You can also monitor the interface dynamically (active monitor), by specifying the *interval* (the elapsed time between interrogations) and *count* (the total number of interrogations). This displays the incremental difference between the current state and the previous state. The minimum interval is one second and the accumulated statistics are displayed after every tenth interrogation.

For example, to monitor the interface `nf0` once every 60 seconds for 3 minutes (a total of 3 interrogations), type:

```
# <basedir>/nf_stat nf0 60 3
Ring   ECM           RMT           PCMS   Ring_OP   XmitP   RecvP
UP     IN    RING_OP    ACTIVE   c         131a0   131aa
UP     IN    RING_OP    ACTIVE   0         0       0
UP     IN    RING_OP    ACTIVE   0         1       1
```

### *Interpreting Local Statistics*

Running the `nf_stat` utility *without* the `-m` option displays information about the various SMT state machines and the network to which the local station is attached:

#### *Ring (Ring Status)*

Shows the current state of the physical connection to the FDDI network. The following states may be returned by `nf_stat` under the `Ring` heading:

---

|      |                                                                  |
|------|------------------------------------------------------------------|
| UP   | SunFDDI interface physically connected to active network         |
| DOWN | SunFDDI interface disconnected, or connected to inactive network |

---

#### *ECM (Entity Coordination Management)*

Shows the current state of the Entity Coordination Management state machine, which controls the following features and facilities:

- Media availability
- Trace
- Path Test
- Optical Bypass (optional)
- Hold Policy (optional)

The following states may be returned by `nf_stat` under the ECM heading:

---

|           |                                                                                                                                      |
|-----------|--------------------------------------------------------------------------------------------------------------------------------------|
| OUT       | ECM is inactive and waiting for a connect request (initial state).                                                                   |
| IN        | ECM is active. Normal state after successful connection request.                                                                     |
| TRACE     | ECM is propagating a trace request to the appropriate entity.                                                                        |
| LEAVE     | ECM is closing all connections prior to the station leaving the ring.                                                                |
| PATH_TEST | ECM is entering a path test state following trace completion.                                                                        |
| INSERT    | ECM is sending a request to the optical bypass switch to indicate that the station is entering the ring. This disengages the switch. |
| CHECK     | ECM is verifying that symbols are being received from the network.                                                                   |
| DEINSERT  | ECM is sending a request to the optical bypass switch, to indicate that the station is leaving the ring. This engages the switch.    |

---

### RMT (*Ring Management*)

Shows the current state of the Ring Management state machine which controls the following features and facilities:

- MAC availability
- Detection and resolution of duplicate addresses
- Identification of stuck beacon and initiation of trace

The following states may be returned by `nf_stat` under the RMT heading:

---

|            |                                                                                                                        |
|------------|------------------------------------------------------------------------------------------------------------------------|
| ISOLATED   | RMT is inactive (initial state).                                                                                       |
| NON_OP     | RMT is waiting for an operational ring.                                                                                |
| RING_OP    | RMT is operating normally.                                                                                             |
| DETECT     | RMT is checking for duplicate addresses (transient state during initialization)                                        |
| NON_OP_DUP | RMT has detected that its address is duplicated and is initiating recovery. The ring is not operational in this state. |

---

---

|             |                                                                                                                                      |
|-------------|--------------------------------------------------------------------------------------------------------------------------------------|
| RING_OP_DUP | RMT has detected that the MAC address is duplicated and flagged the error. The ring is operational in this state.                    |
| DIRECTED    | RMT has been beaconing for an extended period of time and is transmitting a stream of directed beacons prior to initiating recovery. |
| TRACE       | RMT has initiated a trace to recover a stuck beacon.                                                                                 |

---

### PCM (*Physical Connection Management*)

Shows the current state of the Physical Connection Management state machine that controls the following features and facilities:

- Connection initialization
- Maintenance support

This heading is modified to indicate the type of port that is being managed:

- PCMS: single-attached station, S-port.
- PCMA: dual-attached station, A-port.
- PCMB: dual-attached station, B-port.

The following states may be returned by `nf_stat` under the PCM heading:

---

|         |                                                                                      |
|---------|--------------------------------------------------------------------------------------|
| OFF     | PCM is inactive (initial state).                                                     |
| BREAK   | PCM is starting the connection synchronization phase.                                |
| CONNECT | PCM is synchronizing the connection end-points prior to the signalling sequence.     |
| NEXT    | PCM is transmitting PDUs prior to entering SIGNAL state.                             |
| SIGNAL  | PCM is transmitting and receiving signal bits (information) following a NEXT state.  |
| JOIN    | First state in the sequence leading to a synchronized connection.                    |
| VERIFY  | Second state in the sequence leading to a synchronized connection.                   |
| ACTIVE  | Final state. Indicates that the port is successfully incorporated in the token path. |
| TRACE   | PCM is localizing a stuck beacon condition.                                          |

---

The normal sequence of PCM states leading to a fully synchronized connection and the port being incorporated into the token path is shown in Figure 8-1. Note that the minimum interval between interrogations is one second and that this is not always fast enough to recover and display the complete sequence of PCM states.




Figure 8-1 Normal Sequence of PCM States

*Ring\_OP (Ring Operational)*

Shows the number of Ring\_OP (Ring Operational) signals received. This signal is generated when the station is incorporated into an operational network.

*XmitP (Transmit Packets)*

Running `nf_stat` *without* an interval and count, displays the total number of packets transmitted since the interface was activated. Running `nf_stat` *with* an interval and count, displays the number of packets transmitted since the last interrogation.

*RecvP (Receive Packets)*

Running `nf_stat` *without* an interval and count displays, the total number of packets received since the interface was activated. Running `nf_stat` *with* an interval and count, displays the number of packets received since the last interrogation.

### Example Local Statistics

The following output was recovered from a single-attached station using the command shown. A temporary fault condition was simulated by disconnecting the FDDI cable from the SunFDDI SBus card and then reconnecting it.

```

Start nf_stat -----> # <basedir>/nf_stat nf0 1 20
Accumulated statistics -> Ring   ECM      RMT      PCMS   Ring_OP   XmitP   RecvP
UP      IN      RING_OP  ACTIVE  2         26      1d
UP      IN      RING_OP  ACTIVE  0         0       0
UP      IN      RING_OP  ACTIVE  0         0       0
UP      IN      RING_OP  ACTIVE  0         0       0
Path disconnected -----> DOWN   IN      ISOLATED  CONNECT  0         1       1
DOWN   IN      ISOLATED  CONNECT  0         0       0
DOWN   IN      ISOLATED  NEXT     0         0       0
Path re-established -----> UP     IN      RING_OP  ACTIVE  1         0       0
(Ring_OP received)      UP     IN      RING_OP  ACTIVE  0         1       1

Accumulated statistics -> Ring   ECM      RMT      PCMS   Ring_OP   XmitP   RecvP
UP      IN      RING_OP  ACTIVE  3         29      20
UP      IN      RING_OP  ACTIVE  0         0       0
UP      IN      RING_OP  ACTIVE  0         1       1
UP      IN      RING_OP  ACTIVE  0         0       0
UP      IN      RING_OP  ACTIVE  0         1       1
Finish nf_stat ----->

```

Note the following items of particular interest highlighted by this example:

1. Accumulated statistics are displayed automatically after every tenth interrogation.
2. The combination of Ring=DOWN and RMT=ISOLATED indicate that the station is disconnected from the network.
3. The minimum interval of one second is not fast enough to recover and display the complete sequence of PCM states during the path re-establishment phase.

4. A Ring\_OP signal is received when the path is re-established indicating that the ring is operational.

The link status indicator on mounted on the SunFDDI SBus card displays the following sequence of events:

**GREEN** (connected) ---> **AMBER** (disconnected) ---> **GREEN** (connected)

### *Displaying Statistics from Neighboring Stations*

When you use the `nf_stat` command *with* the `-m` option, it displays information about the neighboring stations attached to the local interface `nf<inst>` and the frames received from the network.

For example, to display information about the neighboring stations attached to the interface `nf0`, type:

```
# <basedir>/nf_stat -m nf0
PhyS   Frame  Error  Lost      SA          UNA          DNA
      M  b43eb2    0     3  <mac_addr1> <mac_addr2> <mac_addr3>
```

You can also monitor the neighboring stations dynamically (active monitor), by specifying the *interval* (the elapsed time in seconds between interrogations) and *count* (the total number of interrogations). The minimum interval is one second and the accumulated statistics are displayed after every tenth interrogation.

For example, to monitor the stations attached to `nf0` once every 10 seconds for 1 minute (a total of 6 interrogations), type:

```
# <basedir>/nf_stat -m nf0 10 6
PhyS   Frame  Error  Lost      SA          UNA          DNA
      M  c460a6d    0     3  <mac_addr1> <mac_addr2> <mac_addr3>
      M   27224    0     0  <mac_addr1> <mac_addr2> <mac_addr3>
      M   27227    0     0  <mac_addr1> <mac_addr2> <mac_addr3>
      M   27220    0     0  <mac_addr1> <mac_addr2> <mac_addr3>
      M   2722e    0     0  <mac_addr1> <mac_addr2> <mac_addr3>
      M   27223    0     0  <mac_addr1> <mac_addr2> <mac_addr3>
```

## *Interpreting Statistics from Neighboring Stations*

Running `nf_stat` utility *with* the `-m` option, it displays information about the neighboring stations attached to the local interface `nf<inst>`.

### *Phy (Physical Connection)*

Shows the type of physical connection to the FDDI network. This heading is modified to indicate the type of port being managed:

- `PhyS`: single-attached station, port S.
- `PhyA`: dual-attached station, port A.
- `PhyB`: dual-attached station, port B.

The following states may be returned by `nf_stat` under the `Phy` heading:

---

|                   |                                                        |
|-------------------|--------------------------------------------------------|
| <code>NONE</code> | Port disconnected.                                     |
| <code>M</code>    | Port connected to Port M on a concentrator.            |
| <code>S</code>    | Port connected to Port S on a single-attached station. |
| <code>A</code>    | Port connected to Port A on a dual-attached station.   |
| <code>B</code>    | Port connected to Port B on a dual-attached station.   |

---

### *Frame (Frames Received)*

Running `nf_stat` *without* an interval and count displays the total number of SMT frames received since the interface was activated. Running `nf_stat` *with* an interval and count displays the number of SMT frames received since the last interrogation.

More detailed information about the SMT frames can be recovered using the `nf_smtmon(1m)` utility described in section “Monitoring SMT Frames (`nf_smtmon`)” on page 124.

### *Error (Error Frames)*

Running `nf_stat` *without* an interval and count displays the total number of error frames received since the interface was activated. Running `nf_stat` *with* an interval and count displays the number of error frames received since the last interrogation. An error frame is defined as an SMT frame whose `E` (error) bit is set, and whose `E` bit is first detected by the local station. It does

not indicate the location of the cause of the error. Frequent `error` frames can indicate a noise—either dirt (optical fiber) or electrical interference (UTP)—problem on the network.

*Lost (Lost Frames)*

Running `nf_stat` *without* an interval and count displays the total number of `lost` frames since the interface was activated. Running `nf_stat` *with* an interval and count displays the number of `lost` frames since the last interrogation. A `lost` frame is defined as an `SMT` frame whose reception is aborted by the `local` station. It does not indicate the location of the cause of the error. A large number of `lost` frames can indicate a noise—either dirt (optical fiber) or electrical interference (UTP)—problem on the network.

*SA (Station Address)*

Displays the `MAC` address for the local station.

*UNA (Upstream Neighbor Address)*

Displays the `MAC` address for the neighboring station, connected upstream on the ring from the local station.

*DNA (Downstream Neighbor Address)*

Displays the `MAC` address for the neighboring station, connected downstream on the ring from the local station.

## Example Neighbor Statistics

The following output was recovered from a single-attached station using the command shown. A temporary fault condition was simulated by disconnecting the FDDI cable from the SunFDDI SBus card and then reconnecting it.

```

Start nf_stat -----> # <basedir>/nf_stat -m nf0 1 20
                        PhyS      Frame  Error  Lost    SA          UNA          DNA
Accumulated statistics -> M c45d5463    1    1b <mac_addr1> <mac_addr2> <mac_addr3>
                        M      27437    0    0 <mac_addr1> <mac_addr2> <mac_addr3>
                        M      27427    0    0 <mac_addr1> <mac_addr2> <mac_addr3>
                        M      27435    0    0 <mac_addr1> <mac_addr2> <mac_addr3>
Path disconnected -----> NONE    182f1    0    0 <mac_addr1> <mac_addr2> <mac_addr3>
                        NONE      0    0    0 <mac_addr1> <mac_addr2> <mac_addr3>
                        NONE      0    0    0 <mac_addr1> <mac_addr2> <mac_addr3>
Path re-established ----> M      d432    0    7 <mac_addr1> <mac_addr2> <mac_addr3>
(Lost frames indicated) M      2707e    0    0 <mac_addr1> <mac_addr2> <mac_addr3>

                        PhyS      Frame  Error  Lost    SA          UNA          DNA
Accumulated statistics -> M c46e5ce7    1    22 <mac_addr1> <mac_addr2> <mac_addr3>
                        M      27228    0    0 <mac_addr1> <mac_addr2> <mac_addr3>
                        M      27230    0    0 <mac_addr1> <mac_addr2> <mac_addr3>
                        M      27227    0    0 <mac_addr1> <mac_addr2> <mac_addr3>
                        M      2722e    0    0 <mac_addr1> <mac_addr2> <mac_addr3>
                        M      2722c    0    0 <mac_addr1> <mac_addr2> <mac_addr3>
                        M      27228    0    0 <mac_addr1> <mac_addr2> <mac_addr3>
                        M      27231    0    0 <mac_addr1> <mac_addr2> <mac_addr3>
                        M      2722b    0    0 <mac_addr1> <mac_addr2> <mac_addr3>
Finish nf_stat -----> M      27227    0    0 <mac_addr1> <mac_addr2> <mac_addr3>

```

Note the following items of particular interest highlighted by this example:

1. Accumulated statistics are displayed automatically after every tenth interrogation.
2. The combination of PhyS=NONE and the loss of frame activity indicates that the station is disconnected from the network.

## Monitoring SMT Frames (nf\_smtmon)

The `nf_smtmon(1M)` utility is an active monitor that displays the SMT frames received by the local station. It is particularly useful for diagnosing problems communicating with the SunNet Manager proxy agent.

This command must be executed as `root` (or `superuser`) and has the general form:

```
# <basedir>/nf_smtmon [-i nf<inst>] [-x] [-h] [<frameclass>]
```

`-i nf<inst>` specifies the SunFDDI interface

`-x` displays the received SMT frames in hexadecimal

`-h` displays help information, including a list of valid frame classes

`<frameclass>` specifies one or more SMT frame classes (used to filter output)

If you do not specify an interface, `nf_smtmon` returns the SMT frames received by `nf0` and if you do not specify a frame type, `nf_smtmon` displays all the SMT frames that it receives. Use `Ctrl-C` to stop `nf_smtmon`.

To display the encoded SMT frames received by interface `nf1`, type:

```
# <basedir>/nf_smtmon -i nf1
nf1: nif_request v=0x1 t=0xfc03e781 s=10-0-4-48-6f-a5 i=0x28
nf1: nif_response v=0x1 t=0xfc03e781 s=10-0-4-8-24-5c i=0x28
nf1: nif_request v=0x1 t=0xfc00dec6 s=10-0-4-b8-6e-ab i=0x28
nf1: nif_request v=0x1 t=0xfc03e787 s=10-0-4-48-6f-a5 i=0x28
nf1: nif_response v=0x1 t=0xfc03e787 s=10-0-4-8-24-5c i=0x28
```

The elements of the SMT frames are defined as follows:

---

|                         |                                                                     |
|-------------------------|---------------------------------------------------------------------|
| <code>class_type</code> | Identifies the SMT frame class and type (see page 126).             |
| <code>v</code>          | Version ID. Identifies the structure of the SMT information field.  |
| <code>t</code>          | Transaction ID. Used to pair SMT response and request frames.       |
| <code>s</code>          | Station ID. Uniquely identifies the station transmitting the frame. |
| <code>i</code>          | InfoField Length. Defines the length of the SMT information field.  |

---

To display the SMT frames received by interface nf1 in hexadecimal format, type:

```
# <basedir>/nf_smtmon -i nf1 -x
nf1: nif_request v=0x1 t=0x170 s=10-0-4-8-24-5c i=0x28
004DC000 0000004F FFFFFFFF FFFF1000 0408245C 01020001 00000170 00001000
0408245C 00000028 00010008 00001000 04B86EAB 00020004 00010100 00030004
00002100 200B0008 00000001 00000001 76C467A0

nf1: nif_request v=0x1 t=0x5e0f s=10-0-d4-78-42-4d i=0x28
004D0000 0000004F FFFFFFFF FFFF1000 D478424D 01020001 00005E0F 00001000
D478424D 00000028 00010008 00001000 0408245C 00020004 01010208 00030004
00001200 200B0008 0000000B 00000002 A522BBA1

nf1: nif_response v=0x1 t=0xfc00d94a s=10-0-4-8-24-5c i=0x28
004D0000 00000041 100004B8 6EAB1000 0408245C 01030001 FC00D94A 00001000
0408245C 00000028 00010008 00001000 04B86EAB 00020004 00010100 00030004
00002100 200B0008 00000001 00000001 865549E2 0049C020 F0154E4F FFFFFFFF
FFFF1000 04B86EAB 01020001 FC00D94A 00001000 04B86EAB 00000028 00010008
00001000 D478424D 00020004 00010100 00030004 00002000 200B0008 00000001
00000001

nf1: nif_request v=0x1 t=0x5e13 s=10-0-d4-78-42-4d i=0x28
004D0000 0000004F FFFFFFFF FFFF1000 D478424D 01020001 00005E13 00001000
D478424D 00000028 00010008 00001000 0408245C 00020004 01010208 00030004
00001200 200B0008 0000000B 00000002 4AD75A79

nf1: nif_request v=0x1 t=0x5e17 s=10-0-d4-78-42-4d i=0x28
004D0000 0000004F FFFFFFFF FFFF1000 D478424D 01020001 00005E17 00001000
D478424D 00000028 00010008 00001000 0408245C 00020004 01010208 00030004
00001200 200B0008 0000000B 00000002 DCEBADA2

nf1: nif_request v=0x1 t=0x171 s=10-0-4-8-24-5c i=0x28
004DC000 0000004F FFFFFFFF FFFF1000 0408245C 01020001 00000171 00001000
0408245C 00000028 00010008 00001000 04B86EAB 00020004 00010100 00030004
00002100 200B0008 00000001 00000001 127B1D3B

nf1: nif_request v=0x1 t=0x5e1b s=10-0-d4-78-42-4d i=0x28
004D0000 0000004F FFFFFFFF FFFF1000 D478424D 01020001 00005E1B 00001000
D478424D 00000028 00010008 00001000 0408245C 00020004 01010208 00030004
00001200 200B0008 0000000B 00000002 626FA878
```

## *SMT Frame Classes and Types*

SMT frames are used for peer-to-peer (station-to-station) management. They are divided into *classes*, which define the function of the frame. Each class is then divided into up to three *types*, which define whether the frame is an announcement (information only), a request for service, or a response to a request. Refer to the *ANSI/FDDI Station Management (SMT) X3.299 R7.3 Specification* for a detailed description of SMT frames and their functions.

The `nf_smtmon` utility is used to monitor the following SMT frame classes:

### *NIF (Neighbor Information Frames)*

These are the most common frames displayed when you run `nf_smtmon`. As the name suggests, they carry information about a neighboring station (for example, address, description, state, MAC capabilities) and are used as keep-alive notifications that a station is still attached to the ring and functioning. An NIF frame can be an announcement, a request, or a response.

### *SIF (Status Information Frames)*

These frames carry more detailed information about a station. SIF configuration frames describe the station configuration (for example, number of ports, number of MAC entities, connection policy); SIF operation frames describe the current status of the station. A SIF frame can be either a request or a response.

### *ECF (Echo Frames)*

These frames are equivalent to ICMP ping packets and are used to test connectivity between stations. An ECF frame can be either a request or a response.

### *RDF (Request Denied Frame)*

These frames are used to indicate that the request is rejected. If an SMT agent (such as the SunNet Manager proxy agent delivered with SunFDDI) receives an unsupported or unrecognized request, it issues an RDF frame to indicate that the request is rejected. An RDF frame is always a response.

### ESF (*Extended Service Frame*)

These frames are implementation dependent. An ESF frame can be an announcement, a request, or a response.

### PMF (*Parameter Management Frame*)

These frames are used to access remote station attributes. The Parameter Management Protocol supports both `get` (display) and `set` (modify) functions; however, the `nf_smtmon` utility can display only `PMF_get` frames. A `PMF_get` frame can be either a request or a response.

## *Filtering Output from nf\_smtmon*

By default, `nf_smtmon` displays all of the SMT frames received by the local station. You can filter the output generated by `nf_smtmon` by specifying one or more frame classes on the command-line: `nif`, `sif_config`, `sif_operat`, `ecf`, `rdf`, `esf`, `pmf_get`.

For example:

To display only the RDF frames received by interface `nf0`, type:

```
# <basedir>/nf_smtmon rdf
```

To display the SIF configuration and SIF operation frames received by interface `nf1`, type:

```
# <basedir>/nf_smtmon -i nf1 sif_config sif_operat
```

To display the NIF frames, SIF configuration frames, and SIF operation frames received by interface `nf1`, type:

```
# <basedir>/nf_smtmon -i nf1 nif sif_config sif_operat
```

## Configuring Synchronous FDDI (nf\_sync)

---

**Note** – Synchronous FDDI, configured using the `nf_sync(1M)` utility, is only supported when operating in a Solaris 2.x environment.

---

Two types of traffic are allocated bandwidth on an FDDI ring:

- Asynchronous traffic (unrestricted and restricted)
- Synchronous traffic

The unrestricted asynchronous service allocates bandwidth dynamically based on the *timed token rotation protocol* and according to the *priority* assigned to the traffic. It does not guarantee bandwidth.

The restricted asynchronous service allocates bandwidth for extended transmission based on *restricted token exchange* between communicating stations.

For synchronous operation, a specific portion of the bandwidth is reserved for synchronous traffic and a boundary is placed on the access delay (the time that a station must wait before being able to transmit). The synchronous service is normally used to transfer voice, video, and real-time control data, where the access delay can have significant impact. Note that it is the network user (the application) that requests the synchronous service and manages synchronous operation. The FDDI protocols do not provide any mechanism for controlling synchronous allocation directly.

By default, the SunFDDI interface is configured to carry asynchronous traffic only. The `nf_sync(1M)` utility is used to configure SunFDDI interfaces operating in a Solaris 2.x environment to operate in synchronous mode. This command must be executed as `root` (or `superuser`) and has the general form:

```
# nf<inst>[<tsync> <sap>]
```

`nf<inst>` specifies the SunFDDI interface

`<tsync>` synchronous timer (in nanoseconds, 400000 nanoseconds minimum)

`<sap>` service access point (SAP) for synchronous operation

Running `nf_sync` without specifying values for `<tsync>` and `<sap>` returns the current configuration of the interface.

For example, to display the current configuration of the interface `nf0`, type:

```
# <basedir>/nf_sync nf0
Current Bound Saps
  Async: sap=0x800 : sap=0x806
  Sync:
```

This example shows that the interface `nf0` has two SAPs (800 and 806) configured for asynchronous operation and no SAPs configured for synchronous operation. This is the default condition.

For example, to display the current configuration of the interface `nf1`, type:

```
# <basedir>/nf_sync nf1
Current Bound Saps
  Async: sap=0x806
  Sync: sap=800 (tsync=10001040ns)
```

This example shows that the interface `nf1` has one SAP (800) configured for synchronous operation with a clock rate of 1000000 nanoseconds (1 ms), and one SAP (806) configured for asynchronous operation.

To configure the interface `nf1` in this way, type:

```
# <basedir>/nf_sync nf1 1000000 800
```

The required value of `<tsync>` is application dependent; however, you must enter a value that is large enough to transmit at least one full FDDI packet (~0.333 ms). Note that `<tsync>` defaults to the maximum TTRT (`T_MAX`) for SunFDDI (167.874 ms) if you enter a value less than 400000 nanoseconds (0.4ms)

To reconfigure a SAP for asynchronous operation, specify `<tsync>=0`:

```
# <basedir>/nf_sync nf1 0 800
# <basedir>/nf_sync nf1 0 806
```



# Managing FDDI Stations Using SunNet Manager

10 

|                                                   |                 |
|---------------------------------------------------|-----------------|
| <i>Installing the SunNet Manager Agents</i>       | <i>page 132</i> |
| <i>Managing FDDI Networks With SunNet Manager</i> | <i>page 139</i> |

This chapter describes how to configure and start the SunNet Manager agents for SunFDDI on your machine, and how to use a SunNet Manager Console to recover FDDI statistics from the agents.

To use the SunNet Manager agents for SunFDDI you must run SunNet Manager 2.2 or later, and you must install a SunNet Manager Console (or management application) on your network. For instructions on how to install and configure SunNet Manager on the management station, refer to the *SunNet Manager Installation Guide*.

All SPARCstations and SPARCservers (and most other machines that connect to TCP/IP networks) support protocols that enable a SunNet Manager Console to recover basic information and network statistics. In addition, SunNet Manager provides a number of agents that are used to recover more detailed information from the network:

- SunNet Manager SNMP (simple network management protocol) agents are used to gather information and to set parameters on remote machines.
- SunNet Manager proxy agents are installed locally and used to recover information as if they were located on a remote machine.

## *Installing the SunNet Manager Agents*

You must install a SunNet Manager Console (or management application) on your network before installing and configuring the SunNet Manager agents for SunFDDI.

There are two SunNet Manager agents provided for SunFDDI.

- The **SunFDDI local agent** (`nf_fddi`) responds to SNM requests from the Console and returns statistics gathered on the client machine. These statistics are similar to those returned by `nf_stat(1M)`. See “Displaying SunFDDI Statistics (`nf_stat`)” on page 114 for detailed information.
- The **SunFDDI proxy agent** (`nf_fddismt7_2`) responds to SNM requests from the Console and issues SMT Request Frames (SRF) to a specified target station. It then returns the information received from the target station in response to the request. This information is similar to that returned by `nf_smtmon(1M)`. See “Monitoring SMT Frames (`nf_smtmon`)” on page 124 for detailed information.

### ▼ Installing the Standard SNM Agents on a Client

Although you can recover basic information from your FDDI station without installing the standard agents supplied with SunNet Manager, you can manage your network more completely if you install these agents on each machine. You must install the standard agents before installing the agents for SunFDDI.

There are two ways to install the SunNet Manager agents on the client machine:

♦ **Install the package that contains the SunNet Manager agents and libraries on the client machine.**

This method ensures that the system information is updated correctly on Solaris 2.x machines and makes it easier to remove the agents and libraries, if required.

OR

♦ **Mounting the SunNet Manager directory tree from the Console machine and running `getagents(8)` to install the agents in a local directory.**

This is a quick way to distribute the standard agents across a large network, and is the only way to install SNM agents on Solaris 1.x clients.

Both of these methods are described in the *SunNet Manager Installation Guide*.

### ▼ Install the FDDI Schemas on a Client (Solaris 2.x)

Use `nf_install_agents` to install the SunNet Manager agents for SunFDDI. This script copies the FDDI schema files to the directory in which the standard agents are installed and updates the configuration files for SunNet Manager. Run `nf_install_agents` on each SunNet Manager Console and each SunFDDI station you want to manage using SunNet Manager.

To use `nf_install_agents` in a Solaris 2.x environment:

1. **Log in as root or become superuser.**
2. **Start `nf_install_agents` by typing:**

```
# /opt/SUNWconn/bin/nf_install_agents
```

3. **Enter the hostnames of Console machine(s) that you want to receive SRF trap reports from the local station.**

You can send SRF trap reports to more than one Console. Each Console must have the schemas for SunFDDI installed on it.

Hostname of Console ----->  
Hostname of Console ----->  
Press Return to terminate ---->

```
Enter hostnames (if any) to send SRF Trap reports to:  
(enter blank to terminate)  
enter hostname:opus  
enter hostname:rigel  
enter hostname:
```

**4. Specify the destination directory for the SunFDDI schemas.**

SunNet Manager expects to find the schemas in the directory `<basedir>/SUNWconn/snm/agents`. The variable `<basedir>` is set to `/opt` by default. If you installed the SunNet Manager agents and libraries on the FDDI station, or if you used `getagents` to recover the agents from the Console, then this directory exists.

Enter the base directory under which you installed the SunNet Manager agents as the destination directory for the SunFDDI schemas.

```
What is the name of the root directory under which the SunNet
Manager is installed? [/opt]: [?]
```

**5. Specify the current location of the SunFDDI schemas.**

This is the base directory under which you installed the SunFDDI software package (SUNWnf) using `pkgadd(1M)`.

```
What is the name of the root directory under which the nf FDDI
software is installed? [/opt]: [?]
```

The script copies the SunFDDI schemas to the destination directory and modifies the local configuration files for SunNet Manager.

**6. Start the SunNet Manager agents for SunFDDI by typing:**

```
# /sbin/nf_snmd
```

---

**Note** – If you typed `n` in response to the question “Do you want to start the SunNet Manager daemons for SunFDDI at boot time?” when you installed the SunFDDI software, you must start the SunNet manager agents for SunFDDI manually each time you reboot your machine. Alternatively, you can install the start-up script into the `/etc/rc2.d` directory.

---

```
# cd /opt/SUNWconn/SUNWnf/utilities
# cp nf_fddidaemon /etc/rc2.d/S98nf_fddidaemon
```

## ▼ Install the FDDI Schemas on a Client (Solaris 1.x)

Use `nf_install_agents` to install the SunNet Manager agents for SunFDDI. This script copies the FDDI schema files to the directory in which the standard agents are installed and updates the configuration files for SunNet Manager. Run `nf_install_agents` on each SunNet Manager Console and each SunFDDI station you want to manage using SunNet Manager.

To use `nf_install_agents` in a Solaris 1.x environment:

1. **Log in as root or become superuser.**
2. **Start `nf_install_agents` by typing:**

```
# /usr/sunlink/nf/install/nf_install_agents
```

3. **Enter the hostnames of Console machines that will receive SRF trap reports when an event occurs at the local station.**

You can send SRF trap reports to more than one Console. Each Console must have the schemas for SunFDDI installed on it.

Hostname of Console ----->  
 Hostname of Console ----->  
 Press Return to terminate ---->

```
Enter hostnames (if any) to send SRF Trap reports to:
(enter blank to terminate)
      enter hostname:opus
      enter hostname:rigel
      enter hostname:
```

4. **Specify the destination directory for the SunFDDI schemas.**

SunNet Manager expects to find the schemas in the directory `<basedir>/sunlink/nf/sys/snm/agents`. The variable `<basedir>` is set to `/usr` by default. If you installed the SunNet Manager agents and libraries on the client, or if you used `getagents` to recover the agents from the Console, then this directory exists on the client machine.

Enter the base directory under which you installed the SunNet Manager agents as the destination directory for the SunFDDI schemas.

```
What is the name of the root directory under which the SunNet
Manager is installed? [/usr]: [?]
```

**5. Specify the current location of the SunFDDI schemas.**

This is the base directory under which you installed the SunFDDI software using `cdm`.

```
What is the name of the root directory under which the nf FDDI
software is installed? [/usr]: [?]
```

The script copies the SunFDDI schemas to the destination directory and modifies the local configuration files for SunNet Manager.

**6. Start the SunNet Manager agents for SunFDDI by typing:**

```
# /usr/etc/nf_snmd
```

**Note** – If you typed `n` in response to the question “Do you want to start the SunNet Manager daemons for SunFDDI at boot time?” when you installed the SunFDDI software, you must start the SunNet manager agents for SunFDDI manually each time you reboot your machine. Alternatively, you can add the following lines to the file `/etc/rc.local`:

```
if [ -f /usr/etc/nf_snmd ]; then
    /usr/etc/nf_snmd
fi
```

▼ **Install the FDDI Schemas on the Console**

If you install the SunFDDI software on the Console machine, you can run `nf_install_agents` locally. See “Install the FDDI Schemas on a Client (Solaris 2.x)” on page 133 for detailed instructions.

If you do not have a SunFDDI SBus card installed in the Console machine, you must either copy the script and SunFDDI schemas onto the Console machine or NFS mount the `nf_install_agents` script from a client machine and execute it remotely.

To share `nf_install_agents` from a Solaris 2.x client:

1. On the client machine, ensure that the NFS and mount daemons are running:

```
# /usr/lib/nfs/nfs 8
# /usr/lib/nfs/mountd
```

2. On the client machine, share the /opt directory under which you installed SunFDDI.

```
# share -F nfs -o ro /opt
```

3. On the Console machine, NFS mount the /opt directory:

```
# mount <client>:/opt /<mnt_dr>
```

4. On the Console machine, run `nf_install_agents`:

```
# /mnt/SUNWconn/bin/nf_install_agents
```

Follow the directions in “Install the FDDI Schemas on a Client (Solaris 2.x)” on page 133, and specify `<mnt_dir>` as the current location of the SunFDDI schemas.

On a Solaris 2.x client, the SunFDDI schemas are located in the directory `/opt/SUNWconn/SUNWnf/agents` and the `nf_install_agents` script is located in the directory `/opt/SUNWconn/SUNWnf/utilities`.

On a Solaris 1.x client, the SunFDDI schemas are located in the directory `/usr/sunlink/nf/snm/agents` and the `nf_install_agents` script is located in the directory `/usr/sunlink/nf/install`.

On the Console machine, the schemas must be installed in the directory `/opt/SUNWconn/snm/agents`. The `nf_install_agents` script modifies the file `/opt/SUNWconn/snm/struct/elements.schema` to add the definition for the hostname or MAC address of an FDDI station. If you do not run

`nf_install_agents` on the Console machine, you must modify this file to add the following line to each component (workstation, server, or router) definition:

```
string[40]      Name/Mac-Address
```

For example, if you want to be able to specify the hostname or MAC address of an FDDI interface installed in a SPARCstation 10, add the following line to `elements.schema`.

```
#
# Sun workstations
#
record component.ss10 (                # sparcstation 10
    string[64]      Name
    string[40]      IP_Address
    string[40]      User
    string[40]      Location
    string[80]      Description
    string[40]      SNMP_RdCommunity
    string[40]      SNMP_WrCommunity
    string[64]      SNMP_Vendor_Proxy
    int             SNMP_Timeout
    string[40]      Name/Mac-Address
```

Add this line ----->

## Managing FDDI Networks With SunNet Manager

For detailed information on how to use SunNet Manager to manage the various components of your network, refer to the *SunNet Manager User's Guide*.

The SunNet Manager agents for SunFDDI are used to recover FDDI statistics and SMT frame information. For detailed instructions on how to interpret this data, refer to the ANSI/FDDI standards listed in the section “Conformance” on page 2.

### ▼ Set Up the SunNet Manager Console

To gather information about the SunFDDI stations in you network:

1. **Log in as root or become superuser.**
2. **Start the SunNet Manager Console, and initialize the runtime management database (MDB).**

```
# /opt/SUNWconn/bin/snm -i
```

3. **Either use HeadStart to begin discovering the nodes in your network, or use BasicStart to build your own database with the Console's graphical editor.**

Note that the Discover facility will only fully recognize the Ethernet (1e) interfaces in your network.

4. **Modify the component properties of each of the SunFDDI stations in your network.**

Use the scroll-bar to show all of the properties associated with the station. You must enter either the hostname or the MAC address associated with the SunFDDI interface in the last field in the list of properties. If you enter a hostname, it must be registered in the NIS/NIS+ map or in the file `/etc/hosts` on each of the machines in your network. If you enter a MAC address, it must be entered in ring format.

5. **Click SELECT on the check box associated with each of the SunNet Manager agents that you want to use to communicate with the station.** If you enable the SunFDDI proxy agent (`nf_fddismt7_2`), you must also specify the hostname (or MAC address) of the target FDDI station from which the proxy agent will request information.

▼ Use the SunFDDI Local Agent (nf\_fddi)

The SunFDDI local agent (nf\_fddi) responds to SNM requests from the Console and returns statistics gathered on the client machine. These statistics are similar to those returned by nf\_stat(1M). See “Displaying SunFDDI Statistics (nf\_stat)” on page 114 for detailed information.

▼ Gather Local Station Statistics

To use the SunFDDI local agent to recover a snapshot of the current state of the local FDDI station:

1. Click **SELECT** on the icon for the FDDI station that you want to interrogate.
2. Press **MENU** on the Requests menu button and release **MENU** on the Quick Dump item.
3. Choose **nf\_fddi** as the Agent Schema and **if** (interface) as the Group.
4. Click **SELECT** on **Apply** to display local station statistics similar to those shown in Figure 10-1.




Figure 10-1 Quick Dump (Local Statistics)

### ▼ Gather Neighbor Station Statistics

To use the **SunFDDI local agent** to recover a snapshot of the current state of the neighboring FDDI stations:

1. Click **SELECT** on the icon for the FDDI station that you want to interrogate.
2. Press **MENU** on the Requests menu button and release **MENU** on the **Quick Dump** item.
3. Choose `nf_fddi` as the Agent Schema and `route` as the Group.
4. Click **SELECT** on Apply to display neighbor station statistics similar to those shown in Figure 10-2.

```

SunNet Manager Console: Quick Dump Report - arbois
Mon Apr 18 21:49:15 1994 [ arbois ] : Quick Dump: fddi.route

ifname=nf0
Remote_Phy_A=1
Remote_Phy_B=0
T_Max_Value=2097152
T_Max=167.77ms
T_Req_Value=100096
T_Req=8.01ms
TNEG_Value=99840
TNEG=7.99ms
TVX_Value=32768
TVX=2.621ms
Frames=2248622810
Error_Frames=0
Lost_Frames=4
MAC_Address=arbois
UNA=0-1-1b-8-10-92
DNA=rully

```

Figure 10-2 Quick Dump (Neighbor Statistics)

### ▼ Request Information From the Local Agent

- ◆ Use the Console to create a request for data that is sent periodically to the **SunFDDI local agent**.

This is similar to running the `nf_stat(1M)` utility and specifying an `<interval>` and `<count>` as described in “Displaying Local Interface Statistics” on page 114.

The local agent responds with the requested information, which can be saved to file or displayed using the SunNet Manager Grapher.

▼ Use the SunFDDI Proxy Agent (nf\_fddismt7\_2)

The **SunFDDI proxy agent** (nf\_fddismt7\_2) responds to SNMP requests from the Console and issues SMT Request Frames (SRF) to a specified target station. It then returns the information received from the target station in response to the request. The basic operation of the SunFDDI proxy agent is shown in Figure 10-3.




Figure 10-3 SunFDDI Proxy Agent

▼ Specify the Target Station

1. Specify the target machine when you enable the SunFDDI proxy agent in the properties window for the proxy station.
2. Use the scroll bar to display the two SunFDDI agents as shown in Figure 10-4 and enter the hostname of the target station on the input line.





Figure 10-4 Specifying the Target Station

### ▼ Gather Information From the Proxy Agent

To use the SunFDDI proxy agent to recover a SMT information from one of the neighboring FDDI stations:

1. Click **SELECT** on the icon for the FDDI proxy station that you want to interrogate.
2. Press **MENU** on the Requests menu button and release **MENU** on the **Quick Dump** item.
3. Choose `nf_fddismt7_2` as the Agent Schema and one of the SMT frame types or FDDI MIBs as the Group.
4. Click **SELECT** on **Apply** to display SMT information similar to that shown in Figure 10-5.



```
SunNet Manager Console: Quick Dump Report - arbois
Tue Apr 19 22:37:14 1994 [ arbois ] : Quick Dump: nf_fddismt.NIF
FC=65
DA=rully
SA=arbois
Frame_Class=1
Frame_Type=3
Version_Id=1
Transaction_Id=2
Station_Id=0x000010000418cd58
Pad=0
InfoField_Length=40
UN_Param_Type=1
UN_Param_Len=8
UN_Reserved=0
UNA=0-1-1b-8-10-92
SD_Param_Type=2
SD_Param_Len=4
NodeClass=0
MAC_Ct=1
NonMaster_Ct=2
Master_Ct=0
SS_Param_Type=3
SS_Param_Len=4
SS_Reserved=0
Topology=48
DuplAddress=0
FSC_Param_Type=8203
FSC_Param_Len=8
FSC_Pad=0
FSC_Mac_Index=1
FSC_Pad=0
FSC_Value=1
```

Figure 10-5 Quick Dump (SMT Frames)

## Interpreting Traps and Errors

One of the most important functions of the SunNet Manager agent for SunFDDI is to signal the occurrence of faults or errors on the network. Traps are sent to the Consoles that you specified when you ran the script `nf_install_agents` to install the agents on the client machine. See “Install the FDDI Schemas on a Client (Solaris 2.x)” on page 133 for detailed instructions.

When a cable or station fault occurs, it is signalled by the neighboring station and not by the station implicated by the fault; however, the information provided in the trap report sent to the Console allows you to identify the probable source of the problem. Faults often generate a series of trap events, caused as the ring reconfigures itself automatically.

The cause of repeated errors and lost frames is more difficult to identify because the fault is signalled by the first system to receive the error frame, which is not necessarily the station closest to the problem.

The trap report in Figure 10-6 was generated by the upstream neighbor after the cable between a single-attached station and a concentrator was disconnected. All MAC addresses are displayed in *ring* format.




Figure 10-6 Single-Attached Station Disconnected

The trap reports in Figure 10-7 were generated when a single-attached station was reconnected to the ring.

Trap report generated by the upstream station

|                                                     |                                                  |
|-----------------------------------------------------|--------------------------------------------------|
| Source of trap report -----><br>(neighbor to fault) | SRF_Source=rully                                 |
|                                                     | TransitionTimeStamp: Parameter_Type=0x1034       |
|                                                     | Transition_TimeStamp.Hi=102                      |
|                                                     | Transition_TimeStamp.Lo=845593304                |
| Trap indicates change<br>of neighbor ----->         | MAC Neighbor Change Event: Parameter_Type=0x208f |
|                                                     | Mac_Index=1                                      |
|                                                     | Multiple_Occurrence=0                            |
|                                                     | NA_Condition=2                                   |
| Current neighbor ----->                             | Old_UNA=0-1-1b-8-10-92                           |
| Old neighbor returns ----->                         | New_UNA=arbois                                   |
|                                                     | Old_DNA=10-0-4-b8-6e-ab                          |
|                                                     | New_DNA=europe                                   |
|                                                     | Current_path=3                                   |
|                                                     | SMT_Address=rully                                |

Trap report generated by the reconnected station

|                                                       |                                                  |
|-------------------------------------------------------|--------------------------------------------------|
| Source of trap report -----><br>(reconnected station) | SRF_Source=europe                                |
|                                                       | TransitionTimeStamp: Parameter_Type=0x1034       |
|                                                       | Transition_TimeStamp.Hi=1                        |
|                                                       | Transition_TimeStamp.Lo=2482471160               |
| Trap indicates error<br>condition ----->              | MAC Frame Error Condition: Parameter_Type=0x208d |
|                                                       | Mac_Index=1                                      |
|                                                       | Condition_State=0                                |
|                                                       | Frame_Ct=101367280                               |
| Frames lost during<br>fault condition ----->          | Error_Ct=0                                       |
|                                                       | Lost_Ct=8                                        |
|                                                       | Frame_Error_Ratio=0                              |

Figure 10-7 Single-Attached Station Reconnected

The trap report in Figure 10-8 was generated by the upstream neighbor, when a dual-attached station connected directly to the FDDI ring was halted. The neighbor wraps itself around the fault automatically.




Figure 10-8 Dual-Attached Station Halted

The trap report in Figure 10-9 was generated by the upstream neighbor, when a dual-attached station connected directly to the FDDI ring was restarted. It shows a change of neighbor event that occurs as the wrapped station rediscovers the neighbors to which it was connected before the fault.




Figure 10-9 Dual-Attached Station Restarted

---

## *Mac Address Formats*

The MAC address can be represented in one of two formats:

- Canonical format
- Ring format

The MAC address is always displayed in canonical format by the SunFDDI network utilities and hardware self-test program. It is also displayed in canonical format when you reboot your machine.

The SMT information displayed by SunNet Manager always shows the MAC address in ring format. If you specify a target station using a MAC address (instead of a hostname), you must enter it in ring format.



# Developing Applications over SunFDDI

11 

|                                                         |                 |
|---------------------------------------------------------|-----------------|
| <i>Developing Applications with DLPI (Solaris 2.x)</i>  | <i>page 150</i> |
| <i>Monitoring the Link Layer with NIT (Solaris 1.x)</i> | <i>page 154</i> |

This chapter describes how to develop your own applications running over SunFDDI networks. It assumes that you are an experienced programmer who is already familiar with either the DLPI Version 2 interface (Solaris 2.x) or the NIT monitor (Solaris 1.x).

This chapter provides a brief overview of each of the programming environments and concentrates on network addressing and other issues that are specific to the SunFDDI implementation of these interfaces. It does not provide a detailed specification of the interfaces themselves.

DLPI is used to access the services of the SunFDDI link layer of the SunFDDI device driver in a Solaris 2.x environment without the need for specialized knowledge of the underlying protocol. You can obtain a copy of the *STREAMS DLPI Specification* from Sun Microsystems, Inc. (part number 800-6915-10).

NIT is used to monitor and recover information from the `ifnet` interface to the link layer of the SunFDDI device driver in a Solaris 1.x environment.

## Developing Applications with DLPI (Solaris 2.x)

The Data Link Provider Interface (DLPI) Version 2 enables any data link user to access the services of a data link provider without any special knowledge about the underlying protocols involved. In addition to FDDI services, DLPI supports access to X.25, LAPB, LAPD, ISDN, Ethernet, Token Ring, Token Bus, SDLC, BISYNC, and other data link protocols.

The DLPI header file provided in the SunOS 5.x operating system is `<sys/dlpi.h>`. A detailed description of the functions contained in the header is available in the *STREAMS DLPI Specification*.

DLPI defines a STREAMS message set, state table, and conventions that support interaction between a data link service user (for example, IP or ARP) and a data link service provider (for example, the `nf` FDDI driver). Figure 11-1 illustrates the relationship between DLPI and the layers of the FDDI protocol.




Figure 11-1 DLPI Access to FDDI

DLPI primitives are defined in terms of STREAMS messages. All DLPI messages are either type `M_PROTO` or type `M_PCPROTO` and contain the appropriate DLPI message structure. DLPI primitives are exchanged by *confirmed* negotiation—that is, request primitives are issued by the user, which then waits to receive an acknowledge (or error) response primitive from the provider. This type of negotiation is illustrated in Figure 11-2.




Figure 11-2 DLPI Request/Response Negotiation

### *DLPI Connectionless Service Primitives*

Applications developed to run over FDDI use the DLPI connectionless service primitives, which support the following set of operations:

- Attach a STREAM to a given addressable device
- Get and set the physical address of the attached device
- Bind a data link service access point (SAP) to the STREAM
- Transmit and receive data link frames
- Transmit and receive LLC XID/TEST messages
- Enables transmit and receive of multicast addresses
- Enables physical and data link promiscuous mode

## DLPI Addressing

DLPI addressing is implemented as a DLSAP (data link service access point) address. Each DLSAP consists of a physical address plus a service access point (SAP). The format of the DLSAP is provider-dependent. Figure 11-3 shows the general format of the SunFDDI DLSAP.




Figure 11-3 SunFDDI DLSAP Format

If an application is bound with a SAP that is greater than 1500 decimal (0x5dc), the SunFDDI device driver encodes and decodes the DLSAP using LLC and SNAP. However if an application is bound with a SAP that is less than, or equal to, 1500 decimal (0x5dc), the SunFDDI device driver expects that the application will handle the LLC and SNAP encoding and decoding.

This behavior is similar to that of the SunFDDI 2.0 device driver, with one important difference—the critical SAP is 255 and not 1500. Thus if an application is bound with a SAP that is greater than 255 decimal (0xff), the SunFDDI 2.0 device driver encodes and decodes the DLSAP using LLC and SNAP. However if an application is bound with a SAP that is less than, or equal to, 255 decimal (0xff), the SunFDDI 2.0 device driver expects that the application will handle the LLC and SNAP encoding and decoding.

Information returned by the `thDL_INFO_ACK` primitive (in response to a `DL_INFO_REQ`) is used to specify the encoding and decoding rules to insert and extract the DLSAP for a given data link provider. The information returned by the SunFDDI device driver is shown in Table 11-1.

*Table 11-1 DL\_INFO\_REQ Frame*

| <b>Element</b>                     | <b>Value</b>           | <b>Description</b>                   |
|------------------------------------|------------------------|--------------------------------------|
| <code>dl_max_sdu</code>            | 4352 bytes             | Maximum MTU                          |
| <code>dl_min_sdu</code>            | 0 bytes                | Minimum MTU                          |
| <code>dl_addr_length</code>        | 8 bytes                | Length of DLSAP                      |
| <code>dl_mac_type</code>           | <code>DL_FDDI</code>   | FDDI MAC layer                       |
| <code>dl_reserved</code>           | 0                      | Unused                               |
| <code>dl_current_state</code>      | —                      | Current state of data link provider  |
| <code>dl_sap_length</code>         | -2 bytes               | Length of DLSAP                      |
| <code>dl_service_mode</code>       | <code>DL_CLDLS</code>  | Connectionless service               |
| <code>dl_qos_length</code>         | 0                      | Not supported                        |
| <code>dl_qos_offset</code>         | 0                      | Not supported                        |
| <code>dl_range_length</code>       | 0                      | Not supported                        |
| <code>dl_range_offset</code>       | 0                      | Not supported                        |
| <code>dl_provider_style</code>     | <code>DL_STYLE2</code> | Can be cloned                        |
| <code>dl_addr_offset</code>        | 76                     | Offset to address location           |
| <code>dl_version</code>            | 2                      | DLPI Version 2                       |
| <code>dl_brdcst_addr_length</code> | 6                      | Broadcast address length             |
| <code>dl_brdcst_addr_offset</code> | 84                     | Offset to broadcast address location |

Note that the value `dl_sap_length` is set to minus 2, which indicates that the SAP is 2 bytes beyond the physical address.

## *Monitoring the Link Layer with NIT (Solaris 1.x)*

The Network Interface Tap (NIT) is used to monitor and recover information from the `ifnet` interface to the link layer of the SunFDDI device driver in a Solaris 1.x environment. It is composed of several STREAMS modules and drivers that collectively provide link-level network access. Examples of NIT clients include `rarpd(8C)` and `etherfind(8C)`.

NIT consists of the following components:

- `nit_if(4M)` is a STREAMS module that interacts directly with the SunFDDI device driver. After being bound to a specific instance of the SunFDDI device driver, the `nit_if` device transcribes packets that arrive on the interface and delivers messages to the raw packet output code for transmission.
- `nit_pf(4M)` is a STREAMS module that provides packet filtering services to NIT. It discards all unessential incoming packets and automatically forwards all outgoing packets.
- `nit_buf(4M)` is a STREAMS module that buffers incoming messages and reduces the reliance on repeated `read(2V)` system calls.

A detailed description of these components, including generic examples on using the NIT are contained in the associated manual pages for these modules.

# Setting Up Servers and Diskless Clients

12 

|                                                             |                 |
|-------------------------------------------------------------|-----------------|
| <i>Summary of Steps</i>                                     | <i>page 155</i> |
| <i>Setting Up a Solaris 2.x Server and Diskless Clients</i> | <i>page 156</i> |
| <i>Setting Up a Solaris 1.x Server and Diskless Clients</i> | <i>page 165</i> |
| <i>Booting a Diskless Client Over SunFDDI</i>               | <i>page 167</i> |
| <i>Boot by Default</i>                                      | <i>page 168</i> |

This chapter describes how to set up a server so that you can boot and run diskless clients across an FDDI network. It assumes that the server and clients are attached to the same FDDI ring.

## *Summary of Steps*

Setting up a server for a diskless client running over FDDI, requires:

1. Setting up the server so that it can export an operating system for a diskless client, and install the SunFDDI device driver and utilities.
2. Introducing the diskless client to the network.
3. Installing the SunFDDI device driver in the `/export/root/<client>` file system for the diskless client.
4. Booting the diskless client over the network.

## Setting Up a Solaris 2.x Server and Diskless Clients

When you are setting up a Solaris 2.x server so that it can export its operating system, you need to know the number of diskless clients that it will serve. This tells you the amount of disk space you need to reserve in the `/export` file system.

◆ Use `df(1M)` to check the amount of space available. For example, type:

```
% /usr/bin/df -k /export
Filesystem      kbytes  used  avail  capacity  Mounted on
/dev/dsk/c0t3d0s0 24143  17222  4511   79%       /
```

The figure in the `avail` column tells you how much space is available in the file system.

- For each Solaris 2.x client, you will require:
  - 20 Mbytes of disk space under `/export/root`
  - 24 Mbytes (by default) of disk space under `/export/swap`
- For each Solaris 1.x client, you will require:
  - 16 Mbytes of disk space under `/export/root`
  - 16 Mbytes (by default) of disk space under `/export/swap`

In addition, you require 10 Mbytes under `/export/exec` for the Solaris 2.x template files (Sun4, Sun4c, and Sun4m) plus an additional 15 Mbytes under `/export/exec` for each kernel architecture supported (Sun4, Sun4c, and Sun4m).

For example,

If you have five Sun4c diskless clients running Solaris 2.x, you will require:

- $(5 \times 20) = 100$  Mbytes of disk space under `/export/root`
- $(5 \times 24) = 120$  Mbytes of disk space under `/export/swap`
- $(10 + 15) = 25$  Mbytes of disk space under `/export/exec`

### ▼ Set Up a Solaris 2.x Server

To set up a Solaris 2.x server to boot diskless clients across an FDDI connection:

- 1. Install and configure the relevant SunOS operating system on the server so that it can be exported.**

See the *Solaris System Configuration and Installation Guide* for detailed instructions on how to set up an operating system for diskless clients.

- 2. Check that you have sufficient space in the `/export/root`, `/export/swap`, and `/export/exec` file systems.**

- 3. Install and configure the SunFDDI driver and utilities on the server.**

- 4. Ensure that you have an entry for the `sysadmin` group (with a GID of 14) in the group table `/etc/group`.**

You need this entry to be able to use `admintool` to administer remote machines. See Chapter 1, “Setting up User Accounts and Groups” in *Solaris 2.3 Setting up User Accounts, Printers, and Mail*.

---

**Note** – If you are running NIS on your server, you can use `admintool` to update the local `/etc/hosts` and `/etc/ethers` files. You must merge these files manually into the NIS maps afterwards.

---

## ▼ Introduce Diskless Clients to a Solaris 2.x Server

Before you can introduce a diskless client to the network you need to know its hostname, IP address, and Ethernet address. The six-byte Ethernet address is displayed when the machine is switched on. (Note that the Ethernet address of the client is the MAC address stored in NVRAM on its motherboard.)


- 1. Log in as a member of the `sysadmin` group.**

You must log in as a member of the `sysadmin` group to administer remote machines. Do *not* log in as `root` or become `superuser`.

- 2. Start `admintool` by typing:**


```
% /usr/bin/admintool &
```

3. Click **SELECT** on the **Host Manager** icon to display the **Select Naming Service** window.




4. Click **SELECT** on the button corresponding to the naming service used by the server to display list of available hosts.
  - If the server is running NIS+, click **SELECT** on NIS+ and type in your domain name.
  - If the server is running NIS or is not using a naming service, click **SELECT** on None and type in the name of the host on which the files `/etc/hosts` and `/etc/ethers` are located.

5. Click **SELECT** on **Apply** to display the **Host Manager** window.



6. Press **MENU** on the **Edit** menu button and choose the **Add Host...** item to activate the **Add Host** window.



7. Press MENU on the Client Type menu button. Drag and release MENU to display defaults for diskless clients.

**Host Manager: Add Host**

Client Type:

Host Name: \_\_\_\_\_

IP Address: \_\_\_\_\_

Ethernet Address: \_\_\_\_\_

Timezone Region:

Timezone:

File Server:

OS Release:

Root Path:

Swap Path:

Swap Size:

Terminal Type:

Naming Service: None

8. Enter the hostname, IP address, and Ethernet address of the diskless client.  
This information uniquely identifies the diskless client on the network. The six-byte Ethernet (MAC) address has the form x:x:x:x:x:x. It is stored in NVRAM on the motherboard and is displayed when the SPARCstation is booted.
9. Use MENU to set the Timezone Region and Timezone that are relevant for your location.
10. Press MENU on the File Server menu button to display a list of available servers. Drag and release MENU to specify a file server.  
The file server is the machine from which the diskless client will receive its operating system. If you are running admintool on the server, it will be shown as the default.

- 11. Press MENU on the OS Release menu button to display a list of the operating systems available on the server. Drag and release MENU to specify the operating system for the diskless client.**  
Ensure that the operating system you choose is compatible with the architecture of the diskless client.
- 12. Specify the `root` and `swap` paths.**  
By default, these paths are set to `/export/root` and `/export/swap`. If you change these paths, you must ensure that you have sufficient disk space in the file systems you specify.
- 13. Specify the size of the swap space reserved for the diskless client.**  
This is normally set to 24 Mbytes. If you increase the amount of swap space reserved for the diskless client, you must ensure that you have sufficient space under `/export/swap` on the server.
- 14. If you specified a SunOS 4.x operating system release in Step 11, specify the terminal type used by the diskless client.**  
Any type defined in the `terminfo` database is valid. Common terminal types include `sun`, `tvi910+`, `wyse90`, `vt100`, `vt52`, `adm31`, `h19`, `ansi`. The default is a `sun` terminal.
- 15. Click SELECT on the Add button to update the list of recognized hosts.**  
This creates the export file systems for the diskless client on the server and updates the relevant files for the naming service you are using. The operation will take a few minutes. The message “operation completed” appears when the list has been updated and the name of the diskless client is added to the scrolling-list on the Host Manager window.

**Host Manager: Add Host**

Client Type:

Host Name:

IP Address:

Ethernet Address:

Timezone Region:

Timezone:

File Server:

OS Release:

Root Path:

Swap Path:

Swap Size:

Terminal Type:

Naming Service: None

▼ Update the NIS Server

If you are running NIS, you must update the NIS map on the NIS server manually. If you are running NIS+ or you are not using a naming service, proceed to “Installing the SunFDDI Driver for a Diskless Client” on page 163.

To update the NIS map on the NIS server:

**1. On the diskless client’s server (on which you just ran `admintool`), note the new entries created in the following files:**

- `/etc/hosts`
- `/etc/ethers`
- `/etc/timezone`
- `/etc/bootparams`

2. On the NIS server, update the four files with the information taken from the diskless client's server.
3. On the NIS server, remake the NIS map by typing:

```
# cd /var/yp
# make
```

#### *Adding a Solaris 1.x Client Only*

If you are updating the NIS map to add a diskless client running Solaris 1.x, then you need to perform the following additional steps:

4. Change directories to the diskless client's `root` file system.

```
# cd /export/root/<client>
```

5. Update the `yp` map for the diskless client:

```
# mv var/yp- var/yp
```

6. Replace the `noname` entry in the file `/etc/defaultdomain` with the your local NIS domain name.

## ▼ Installing the SunFDDI Driver for a Diskless Client

After you have created the export file systems under `/export/root/<client>` and `/export/swap/<client>` on the server, you must install the SunFDDI device driver for the diskless client.

## ▼ Solaris 2.x Client

1. Use `pkgadd` to install the Solaris 2.x version of SunFDDI so that it is exported to the diskless client.

By default, the SunFDDI software is installed under `/opt`.

2. **To redirect the installation so that the package is installed in the root partition for the diskless client, type:**

```
# pkgadd -R /export/root/<client> -d /cdrom/FDDI_4_0/Solaris_2.x
```

Follow the installation instructions contained in the section “Installing and Configuring SunFDDI” on page 11.

### ▼ Solaris 1.x Client

SunFDDI for Solaris 1.x includes a pre-built kernel to support diskless clients. This kernel is based on the GENERIC kernel configuration and supports all standard devices, plus up to two SunFDDI interfaces.

1. **To use the pre-built kernel for a diskless client, install the Solaris 1.x version of SunFDDI according to the installation instructions contained in the section Chapter 4, “Installing and Configuring SunFDDI in a Solaris 1.x Environment.”**

Use `/export/root/<client>/usr` as the destination directory. Since you are trying to install the 1.x version of the driver on a 2.x system, you may get some error messages. Ignore them and continue with the installation.

2. **Copy the pre-built kernel to the root partition for the diskless client:**

```
# cd /export/root/<client>/usr/sunlink/nf/sys/<arch>/OBJ
# cp ./vmunix /export/root/<client>
```

## Setting Up a Solaris 1.x Server and Diskless Clients

When you are setting up a Solaris 1.x server so that it can export its operating system, you need to know the number of diskless clients that it will serve. This tells you the amount of disk space you need to reserve in the `/export` file system.

◆ Use `df(1V)` to check the amount of space available. For example, type:

```
% /usr/5bin/df -k /export
Filesystem      kbytes  used  avail  capacity  Mounted on
/dev/dsk/c0t3d0s0 24143  17222  4511   79%      /
```

The figure in the `avail` column tells you how much space is available in the file system.

- For each Solaris 2.x client, you will require:
  - 20 Mbytes of disk space under `/export/root`
  - 24 Mbytes (by default) of disk space under `/export/swap`
- For each Solaris 1.x client, you will require:
  - 16 Mbytes of disk space under `/export/root`
  - 16 Mbytes (by default) of disk space under `/export/swap`

In addition, you require 10 Mbytes under `/export/exec` for the Solaris 2.x template files (Sun4, Sun4c, and Sun4m) plus an additional 15 Mbytes under `/export/exec` for each kernel architecture supported (Sun4, Sun4c, and Sun4m).

For example,

If you have five Sun4c diskless clients running Solaris 1.x, you will require:

- $(5 \times 16) = 80$  Mbytes of disk space under `/export/root`
- $(5 \times 16) = 80$  Mbytes of disk space under `/export/swap`
- $(0+15) = 15$  Mbytes of disk space under `/export/exec`

### ▼ Set Up a Solaris 1.x Server

To set up a Solaris 1.x server to boot diskless clients across an FDDI connection:

- 1. Install and configure the relevant SunOS operating system on the server so that it can be exported.**
- 2. Check that you have sufficient space in the `/export/root`, `/export/swap`, and `/export/exec` file systems.**
- 3. Install and configure the SunFDDI driver and utilities on the server.**

### ▼ Update the Name Service

Before introducing clients to the server, you must update the name service to register an IP address, hostname, and Ethernet (MAC) address for each client.

- 1. On the NIS server (or on the diskless client's server if you are not running NIS), modify the following files to enter the relevant information:**

- `/etc/hosts`
- `/etc/ethers`
- `/etc/bootparams`

- 2. On the NIS server, remake the NIS map by typing:**

```
# cd /var/yp
# make
```

- 3. On the diskless client's server, change directories to the diskless client's root file system.**

```
# cd /export/root/<client>
```

### ▼ Introduce Diskless Clients to a Solaris 1.x Server

Before you can introduce a diskless client to the network you need to know its hostname, IP address, and Ethernet address. The six-byte Ethernet address is displayed when the machine is switched on. (Note that the Ethernet address of the client is the MAC address stored in NVRAM on its motherboard.)

- 1. Log in as `root` or become superuser.**

**2. Start `add_client` in interactive mode by typing:**

```
% /usr/etc/install/add_client -i
```

See the *Solaris 1.x System and Network Administration Manual* for detailed instructions on how to use `add_client` to introduce a diskless client.

**3. Modify the file `/etc/rc.local` to enable `rarpd(8C)` for the SunFDDI interface automatically when the machine is rebooted.**

```
if [ -d /tftpboot ]; then
#   rarpd -a;                echo -n ` rarpd` <----- comment out
   rarpd nf<inst>           echo -n ` rarpd` <----- add line
   rpc.bootparamd;        echo -n ` bootparamd`
fi
```

**4. Copy the new kernel to the root partition for the diskless client.**

```
# cp /usr/sunlink/sys/<arch>/OBJ/vmunix /export/root/<client>
```

**5. Reboot the server to invoke the changes to the system.**

## *Booting a Diskless Client Over SunFDDI*

You need to specify the SunFDDI interface when you boot your diskless client over the FDDI network.

### ▼ Boot Manually

- 1. Check that the server is running and that its FDDI interface is up.**
- 2. Switch on the diskless client and press `L1(Stop)-a` to halt the boot procedure.**
- 3. At the boot prompt, enter the appropriate `boot` command for your machine architecture and boot PROM revision.**

- For sun4c clients, type:

```
> b -r /sbus/nf@<slot_number>
```

or

```
ok boot -r /sbus/nf@<slot_number>
```

- For sun4m clients, type:

```
> n  
ok boot -r /iommu/sbus/nf@<slot_number>
```

If you do not specify a slot number, the client boots over the first FDDI interface it detects.

For example, for a sun4c client, type:

```
ok boot -r /sbus/nf
```

## ▼ Boot by Default

To make the SunFDDI interface the default interface for booting:

1. Check that the server is running and that its FDDI interface is up.
2. Switch on the diskless client and press **L1(Stop)-a** to halt the boot procedure.
3. At the boot prompt, enter the appropriate commands to set the default boot device and diagnostic device.

- For sun4c clients, type:

```
ok setenv boot-device /sbus/nf  
ok setenv diag-device /sbus/nf
```

- For sun4m clients, type:

```
> n
ok setenv boot-device /iommu/sbus/nf
ok setenv diag-device /iommu/sbus/nf
```

**4. At the boot prompt, enter the appropriate `boot` command for your machine architecture and boot PROM revision.**

- For sun4c clients, type:

```
> b
```

or

```
ok boot
```

- For sun4m clients, type:

```
> n
ok boot
```



## *Frequently Asked Questions*

---



This appendix contains the responses to some of the questions that are frequently asked about SunFDDI. It also contains references to more detailed information.

**1. The network performance is much lower than I expected. Why can't I transfer data at 100 Mbps over my FDDI connection?**

If the applications running over FDDI don't use the available bandwidth efficiently you will see much lower performance than expected. See Chapter 5, "Improving Network Performance" for advice on how to get the best performance from your SunFDDI station.

**2. Can I connect a dual-attached FDDI station to two different subnetworks?**

No. A dual-attached station must be either connected to the primary and secondary rings in a dual-ring configuration, or connected in a dual-homing configuration. See "Dual-Attached Station (DAS)" on page 81 for more information.

**3. Can I use a dual-attached station in single-attached mode?**

Yes. Simply connect one port to the network. There is no overhead incurred when you operate a dual-attached station in this way.

**4. Can I use SunFDDI 4.0 in an redundant single-attached station (RSAS) configuration?**

No. This configuration, which was supported by SunLink FDDI/S 2.0, provides a redundant connection that is used in the event of a link failure. The equivalent configuration for SunFDDI 4.0 is provided by a dual-attached station connected in dual-homing mode. See “Concentrators with Dual-Homing” on page 98 for more information.

**5. Can I use the SunFDDI 4.0 software with the hardware for earlier versions of the SunLink FDDI products?**

You can use FDDI/S 3.x hardware and software with FDDI/S 4.0. If you are upgrading from either SunLink FDDI/S 1.0 or SunLink FDDI/S 2.0, you must replace the old FDDI SBus card with the one you received for SunFDDI 4.0.

**6. Can I use the SunFDDI 4.0 SBus card with the software for earlier SunLink FDDI products?**

The SunLink FDDI/S 3.0 software and hardware can be used with SunFDDI 4.0. If you are upgrading from either SunLink FDDI/S 1.0 or SunLink FDDI/S 2.0, you must install and configure the SunFDDI 4.0 software.

**7. Can I use the SunFDDI 4.0 software with a hardware interface from a third-party vendor?**

No. The SunFDDI 4.0 software and hardware must be used together. The device driver does not support any third-party hardware products.

**8. Can I mix SunFDDI 4.0 with earlier SunLink FDDI products (1.0 and 2.0) in the same machine?**

Yes. However, you must install and configure both versions of the software to support the different hardware platforms. You may also need to change the MAC address of one of the cards. See “Changing the Default MAC Address (nf\_macid)” on page 112 for detailed instructions.

**9. Can I connect two single-attached stations “back-to-back”, without connecting them to a concentrator?**

Yes. This configuration is supported by the FDDI specifications. You can also connect two single-attached stations and one dual-attached station directly in a ring, but this configuration is not supported by the FDDI specifications and is not recommended.

**10. Can I install SunFDDI 4.0 in an SBus expansion box?**

No. SunFDDI 4.0 is not supported in the SBus expansion box. An SBus expansion box has serious restrictions in both throughput and latency, combined with a significant delay for control between the CPU and SBus boards in general. These restrictions become critical in conjunction with FDDI, which stresses the SBus bandwidth.

**11. What is dual-homing?**

Dual-homing is a special configuration that connects a single dual-attached station to two concentrators so that there is a redundant path, which is used in the event of a link failure. See “Concentrators with Dual-Homing” on page 98 for more information.

**12. What is the MTBF for the various SunFDDI options?**

The mean time before fail (MTBF) for each of the SunFDDI interface cards is:

- SunFDDI (SAS) 750525 hours
- SunFDDI Dual (DAS) 446748 hours

These characteristics were obtained using the standard method for calculating MTBF.

**13. What is the difference between fiber and UTP?**

The FDDI specifications support communication over optical fiber and unshielded twisted-copper pair (UTP). Both physical media support data transfer rates of up to 100 Mbps, but UTP provides a much cheaper solution, particularly where high-quality UTP has been deployed already. However, UTP does not support such large distances between stations and is not suitable in areas that are sensitive to electromagnetic interference.

**14. Why can't I connect port A to port A, or port B to port B?**

This type of configuration is forbidden by the FDDI specifications. It is called “twisting” or “crossing” the ring. If you connect your FDDI station in this configuration, the link status indicator will remain amber to indicate that you are not connected to an active network. See Chapter 8, “FDDI Network Topologies” for a description of the valid network configurations.

**15. Why do I get the error message “duplicate address” or “duplicate macid”?**

By default, the first SunFDDI interface installed in the machine adopts the host-resident MAC address stored on the motherboard. Each subsequent SunFDDI interface takes the card-resident MAC address stored in its IDPROM.

A potential conflict exists between the first SunFDDI 4.0 interface and a SunFDDI 2.0 interface because both of these products take the host-resident MAC address. You must change the MAC address assigned to one of these interfaces. See “Changing the Default MAC Address (`nf_macid`)” on page 112 for detailed instructions.

**16. Why is performance poor when I use NFS over FDDI?**

For a single file transfer, the maximum data transfer rate is limited to 0.5 Mbytes/second when writing to an NFS mounted file system and 1.5 Mbytes/second when reading from an NFS mounted file system. This performance limitation, which affects Ethernet, FDDI, and any other fast network, is due to the NFS version 2 protocol. It will be removed by NFS version 3.

Note that when several NFS operations are performed in parallel (several reads and writes in parallel), the aggregate throughput is much higher with FDDI than it is with Ethernet.

**17. How do I disable the SunFDDI interface?**

Use `ifconfig(1M)` to disable the SunFDDI interface temporarily. It will be reconfigured when you reboot your machine.

```
# ifconfig nf<inst> down
```

To disable the SunFDDI interface so that it is not reconfigured when you reboot the machine, change the name of the file `/etc/hostname.nf<inst>`.

```
# mv /etc/hostname.nf<inst> /etc/oldhostname.nf<inst>
```

**18. How do I disable the Ethernet interface?**

Use `ifconfig(1M)` to disable the Ethernet interface temporarily. It will be reconfigured when you reboot your machine.

```
# ifconfig le<inst> down
```

To disable the Ethernet interface so that it is not reconfigured when you reboot the machine, change the name of the file `/etc/hostname.le<inst>`.

```
# mv /etc/hostname.le<inst> /etc/oldhostname.le<inst>
```

**19. How do I use the hostname assigned to the SunFDDI interface as the primary hostname for my machine?**

In a Solaris 2.x environment, the primary hostname is defined in the file `/etc/nodename`. Normally, this file contains the hostname assigned to the Ethernet interface built-in to your machine. Edit `/etc/nodename` to enter the hostname assigned to the SunFDDI interface.

In a Solaris 1.x environment, the primary hostname is defined in the file `/etc/hostname.official`. Normally, this file contains the hostname assigned to the Ethernet interface built-in to your machine. The configuration script that is launched when you install the SunFDDI software gives you an opportunity to define the hostname assigned to the SunFDDI interface as the primary hostname.

**20. Can I associate several IP addresses with a single SunFDDI interface?**

Yes. To associate multiple IP addresses with a single interface, type:

```
# ifconfig nf0 <ip_address_1> netmask <mask> up
# ifconfig nf0:1 <ip_address_2> netmask <mask> up
# ifconfig nf0:2 <ip_address_3> netmask <mask> up
.
.
.
```

**21. How many SunFDDI 4.0 SBus cards can I install in one machine?**

You can install up to eight SunFDDI 4.0 SBus cards in one machine; however, you cannot use an SBus extender. For example, you can install a maximum of three cards in a SPARCstation 2, but a maximum of eight cards in a SPARCcenter 2000.

**22. What kind of connector can be used to connect SunFDDI 4.0 to optical fiber networks?**

SunFDDI supports the standard Media Interface Connector (MIC), also called the Fixed Shroud Duplex (FSD) connector, for fiber connections. The ST (Straight Tip) connector is not supported; however, many vendors sell plugs that convert ST connectors to MIC. Neither the new ESCON connector (from IBM), nor the SMA connector are supported.

There are four types of MIC/FSD connectors:

- MIC A (Primary In/Secondary Out) and MIC B (Secondary In/Primary Out) connect for dual-attached stations in an FDDI ring. MIC A is connected to the A-port on a dual-attached station. MIC B is connected to the B-port on a dual-attached station. A-ports must be connected to B-ports.
- MIC M connects the M-port on single-attached and dual-attached concentrators to the S-port on a single-attached station. You must never connect two M-ports together.
- MIC S (universal) can be connected to any type of port; however, it is normally used to connect to the S-port on a single-attached station. Take additional care when connecting MIC S to any other type of port as it is easy to twist the ring accidentally.

The SunFDDI (SAS) interface card has a port that accepts MIC S connectors. The SunFDDI Dual (DAS) interface card has two ports that are keyed to accept MIC A and MIC B connectors respectively. These keys may be removed if required; however, you must take additional care to avoid twisting the ring.

See Chapter 2, “Hardware Installation” for a more detailed description of FDDI cables and connectors.

**23. What kind of optical fiber can be used to link SunFDDI 4.0?**

SunFDDI uses a 62.5/125  $\mu\text{m}$  standard twin optical fiber. A compliant link design will have no more than 11 db of end-to-end loss. This includes loss incurred in the fiber (typically 1.2 db/km), the connectors (typically 0.5 db/connector), and any bypass switches (typically 2.5 db/switch). It also allows loss margins for source aging (typically 1 to 3 db), safety (typically 1 to 2 db), and temperature variation (typically 1 db).

**24. Does SunFDDI Dual incorporate an optical bypass?**

No. You must order an optical bypass switch from a third-party vendor.

**25. Why does my optical bypass switch not work when I plug it in?**

Some optical bypass switches require a power cycle to initialize them. Plug in the optical bypass switch, switch off the FDDI station, and then reboot to initialize the station.

**26. How can I increase the distance between two SunFDDI stations?**

SunFDDI support multimode fiber connections only. This limits the maximum distance between stations to two kilometers (1.24 miles). To increase the distance between stations, either:

- Use converters from multi- to single-mode fiber, and a single-mode connection between converters.
- Add more nodes between the stations to act as repeaters.

**27. Does SunFDDI take advantage of the 25 MHz SBus?**

The SunFDDI SBus board operates at the speed of the host SBus; therefore, if it is installed in a machine with a 25 MHz SBus, it will take advantage of the speed. If there is a performance problem, it is more likely to be related to insufficient CPU cycles to handle the data processing, or congestion on the network, than to the speed of the SBus.



## Glossary

---

This appendix contains a glossary of FDDI-related acronyms, abbreviations, and terms.

### ARP

*(Address Resolution Protocol)* A protocol used within local networks that support broadcast (such as Ethernet or FDDI) that binds IP addresses to MAC addresses. View the current contents of a Sun machine's ARP table with the SunOS command `arp -a`. Specified in RFC 826.

### baud

A measure of the rate of data transfer, based on the number of times per second the signal can change states on the transmission line. The transmission line ordinarily uses just two signal states to indicate data transfer, making the baud rate equal the number of bits per second that can be transferred. See also **bps**, **Bps**, **kbps**, and **Mbps**.

### bps

*(bits per second)*. A measure of the rate of data transmission. See also, **baud**, **Bps**, **kbps**, and **mbps**.

### Bps

*(bytes per second)*. A measure of the rate of data transmission. See also, **baud**, **bps**, **kbps**, and **mbps**.

### CFM

*(Configuration Management)*. The portion of CMT that manages the internal configuration of the station's MAC and PHY entities.

---

**CMT**

*(Connection Management)*. The portion of the FDDI SMT that manages the operation of Physical Layer insertion and removal, and the logical connection of PHY entities to the MAC entities.

**DAS**

*(dual-attach station)*. An FDDI station that connects to both primary and secondary rings; a Class A station, capable of dynamic reconfiguration to accommodate certain levels of failure. Two rings are used to interconnect the stations so that the failure of any station or link causes the remaining stations to reconfigure the network to maintain connectivity: wrapping.

**dotted decimal notation**

A way of representing the 32-bit Internet address: four decimal integers separated by decimal points, where each integer is the decimal value of one octet of the Internet address. For example, the 32-bit Internet address (binary) 11000000 00001001 11001001 00000111 is represented as 192.9.201.7 (decimal).

**ECM**

*(Entity Coordination Management)*. The portion of CMT that manages the media interface to the FDDI network, which includes coordinating the activity of all of the PHYs associated with that physical attachment and controlling the optional optical bypass function within the station.

**FDDI**

*(Fiber Distributed Data Interface)*. A standard specified by the American National Standards Institute for fiber optic links of up to 100 Mbits/s.

**gateway**

A dedicated computer that connects to two or more networks and routes packets from one network “community” to the other. Gateways route packets to other gateways until the packets can be delivered directly to their specified destination across one physical network. In general usage, the term identifies any computer that transfers information between networks.

**kbps**

*(kilobits per second)*. A measure of the rate of data transmission. See also, **baud**, **bps**, **Bps**, and **Mbps**.

---

**LLC**

*(Logical Link Control)*. Local area network protocol functions corresponding to the OSI data link layer (layer 2), but providing only service access points (SAP).

**MAC**

*(Media Access Control)*. Local area network protocol functions corresponding to the OSI data link layer (layer 2), but providing the following: 1) on transmission, assemble data into a frame with address and error-detection fields; 2) on reception, disassemble frame, perform address recognition and error detection; 3) link communications management.

**Mbps**

*(millions of bits per second)*. A measure of the rate of data transmission. See also, **baud**, **bps**, **Bps**, and **kbps**.

**NRZI-4B/5B**

*(Non-Return-to-Zero Inverted)*. A differential encoding technique that encodes four-bit data groups as five-bits (data plus a signal element). Satisfies the minimum signal transition requirements to transmit synchronization (clock) within the data stream.

**OSI**

*(Open Systems Interconnection)*. The OSI model is a standard for computer-communications protocols and the implementation of these protocols. The model is a product of the *International Standards Organization* (ISO), and specifies a seven-layer architecture with one or more protocol standards at each layer.

**PCM**

*(Physical Connection Management)*. The portion of CMT that manages a physical connection between the PHY being managed and another PHY, likely in an adjacent station on the FDDI network.

**PHY**

*(Physical Layer Protocol)*. Performs the clock recovery and serial-to-parallel (on receive) or parallel-to-serial (on transmit) of data between the transmission medium and the MAC entity.

**PMD**

*(Physical Medium Dependent)*. Specifies the optical-to-electrical conversion mechanism to conform to FDDI.

---

**RARP**

*(Reverse Address Resolution Protocol)*. A protocol used by diskless machines and their servers within local networks such as Ethernet or FDDI. In a RARP exchange, a diskless machine broadcasts its MAC address. A boot server responds to that client with the client's IP address, enabling the client to begin the boot process.

**RMT**

*(Ring Management)*. The portion of CMT that monitors the MAC. It provides a trace mechanism to handle the stuck beaconing condition, and also detects duplicate addresses on the ring.

**RSAS**

*(redundant single-attach station)*. An FDDI station in which single-attach interfaces are paired, with one active and the other a hot standby. In an RSAS with connections to two different dual-attach concentrators, you enjoy the network availability afforded by concentrators with single-attach connections, plus, for the RSAS itself, the station availability of a dual-attach station.

**SAP**

*(Service Access Point)*. A logical interface between two adjacent protocol layers (such as LLC and IP).

**SAS**

*(single-attach station)*. An FDDI station that attaches to a single FDDI ring, as distinguished from a dual-attach station, which attaches to both rings in a dual ring.

**SMT**

*(Station Management)*. The complete standard of PHY layer and frame-based protocols to be supported by conforming FDDI stations.

**THT**

*(Token-Holding Timer)*. A timer in the FDDI MAC protocol that controls the length of time a station can hold a token for asynchronous transmission.

**timing jitter**

The deviation of clock recovery that can occur when the receiver attempts to recover both clocking and data from the received signal. The PHY specification describes a phase lock loop (PLL) and elasticity buffer to eliminate jitter.

---

**TRT**

*(Token Rotation Timer)*. A timer in the FDDI MAC protocol that measures the time between receipt of tokens. It expires when it reaches a value that exceeds the Target Token Rotation Time (TTRT).

**TTRT**

*(Target Token Rotation Time)*. A parameter in the FDDI MAC protocol that is negotiated by all of the stations on a ring at the time a ring is brought up. FDDI uses the TTRT in conjunction with the TRT and THT to allocate bandwidth to individual stations on the ring. The FDDI MAC protocol guarantees that the worst-case delay a token will experience while circulating the ring will never exceed twice the negotiated TTRT.



# *Index*

---

## **Symbols**

/cdrom/fddi\_4\_0 directory, 11, 43  
/dev/nf.AUTOLOAD file, 33  
/etc/hosts file, 13, 19, 22, 34  
/etc/loadable script, 34  
/etc/rc.local file, 33, 34  
/etc/rc2.d directory, 18  
/etc/rcS.d directory, 44  
/etc/system file, 45  
/sys/netinet/in\_proto.c file, 47  
/usr directory, 27  
/usr/sunlink/nf directory, 33  
/var/tmp/unbundled directory, 27

## **Numerics**

4.0\_FDDI\_S.log file, 26  
802.3 networks, 106  
802.5 networks, 106

## **A**

access delay, 38, 40, 128  
adapter bracket, 5  
adb command, 47  
add\_drv command, 59  
aggregate attenuation, 87

A-keys, 8  
ANSI/FDDI standards, 74  
A-ports, 8, 81  
arch command, 23  
asynchronous  
    service, 89  
    traffic, 89  
attenuation, 75, 86

## **B**

backbone, 105  
backup, 94  
bandwidth, 1, 38, 89, 91, 93, 128  
base directory  
    installing SUNWnfr, 12  
    installing SUNWnft, 14  
basic dual ring, 94  
battery, lithium, 3  
baud, 179  
bidding, 90  
bit stream, 77  
B-keys, 8  
boot test, 65  
B-ports, 8  
bps, 179  
bridges, 39, 63

---

buffers, 39, 46  
bulk data transfers, 38  
bus topology, 106  
bypass switch, 86

## C

cable  
    failure, 79, 85  
    keys, 6, 54  
    specification, 2, 75  
card-resident MAC address, 55  
cdm command, 24  
checking the installation, 16, 30  
checklist, troubleshooting, 54  
claim process, 40, 46, 50, 90  
classes, 126  
cluster of concentrators, 105  
code examples, 44, 48  
combination of fiber and UTP, 105  
commands  
    adb, 47  
    add\_drv, 59  
    arch, 23  
    extract\_unbundled, 26  
    getsockopt, 44, 48  
    ifconfig, 16, 30, 56  
    mount, 23  
    mount\_hsf, 11  
    ndd, 41, 42  
    netstat, 16, 30  
    ping, 16, 30  
    pkgadd, 11, 12, 14  
    pkgrm, 19  
    rm, 33  
    setsockopt, 44, 48  
    umount, 15, 29  
common problems, 53, 59  
concentrators, 82  
configurations  
    dual-ring, 84  
    ring of trees, 83  
conformance, 2

connectionless service primitives, 151  
connectors, 75, 81  
    fiber optic, 6, 54  
console, 132, 136  
copper twisted-pair, 74, 75, 104  
cost, 93  
counter-rotating ring, 79, 94  
CPU speed, 38  
crossing the ring, 6, 54  
cumulative length, 101

## D

DAC, dual-attached concentrator, 80, 82, 83, 93  
daemons  
    in.routed, 57  
    nf\_snmd, 32  
    vold, 15  
DAS, dual-attached station, 80, 81, 85, 93  
data link  
    provider interface, 150  
data queues, 41  
data transfer, 74  
    rate, 2, 39  
declaring IP addresses, 10, 13  
default  
    buffer size, 39, 46  
    IP addresses, 13  
    MAC address, 55  
    target token rotation time, 40  
developing applications, 149  
device  
    drivers, 34, 54  
    names, 4, 28  
diagnostic LED, 8, 14, 29, 54  
dialogue-based traffic, 76  
directories  
    /cdrom/fddi\_4.0, 11  
    /cdrom/fddi\_4\_0, 43  
    /etc/rc2.d, 18  
    /etc/rcS.d, 44  
    /usr, 27

---

- `/usr/sunlink/nf`, 33
    - `/var/tmp/unbundled`, 27
  - disabling MTU path discovery, 45
  - disk space, 10, 22
  - diskless clients, 155
  - distributed clocking scheme, 76
  - distribution frame, 103, 105
  - DL\_INFO\_ACK, 153
  - DL\_INFO\_REQ, 153
  - dl\_sap\_length, 153
  - DLPI, 149
    - addressing, 152
    - header file, 150
    - primitives, 151
    - specification, xxiii
  - DLSAP, 152
  - DNA, 122
  - document structure, xix
  - don't fragment bit, 45
  - dotted decimal notation, 180
  - downstream
    - neighbor address, 122
  - dual ring, 94
  - dual-attached
    - concentrator, 96
    - concentrator (DAC), 80, 82, 83
    - station, 75, 98
    - station (DAS), 1, 54, 80, 81, 85
  - dual-homing configuration, 98, 105
  - dual-ring configuration, 84
  - dynamic routing protocol, 63

## E

- ECF, 126
- echo frames, 126
- ECM, 115
- efficiency, 38
- efficient use of bandwidth, 91
- ejecting the CD-ROM, 15
- electrical-bypass, 97
- electromagnetic radiation, 75

- `elements.schema`, 137
    - encoded digital data, 75
    - end-station, 105
    - entity coordination management, 115
    - error frames, 121
    - ESF, 127
    - etherfind command, 154
    - examples, 43, 44, 48
    - extended service frame, 127
    - extract\_unbundled command, 26

## F

- failure mechanisms, 84
- fault recovery, 96
- faults
  - cable, 85
  - station, 86
- feature list, 1
- fiber optic
  - components, 6
- files
  - `/dev/nf.AUTOLOAD`, 33
  - `/etc/hosts`, 13, 19, 22, 34
  - `/etc/rc.local`, 33, 34
  - `/etc/system`, 45
  - `/sys/netinet/in_proto.c`, 47
  - `4.0_FDDI_S.log`, 26
  - Solaris 1.x installation, 23
- filtering services, 154
- finishing the installation, 15
- frame classes, 124
- frames, 76, 89

## G

- gated daemon, 109
- gateway, 180
- generic vmunix, 47
- getagents script, 18, 32, 132
- getsockopt command, 44, 48
- guaranteed traffic, 76

---

## H

### handling

- fiber optic cable, 6
- Sbus cards, 4

### hardware

- options, 1
- self-test, 65

hierarchical topology, 100

high priority, 90

high water marks, 41

hop count, 108, 109

horizontal distribution frame, 103, 105

hostnames, 10, 13, 22, 138

host-resident MAC address, 55

hubs, 82

## I

IDPROM, 55

ifconfig command, 16, 30, 56

ifnet command, 154

ifnet command, 149

### improving

- ring latency, 38

in.routed daemon, 57

increased transmission time, 90

independent data paths, 98

inherent redundancy, 103

install\_nf script, 28

### installation

- checking the, 16, 30
- requirements, 10, 22
- scripts, 10, 14, 15, 22, 26

### installing

- multiple cards, 4
- SNM agents, 17 to 18, 31 to 33
- the hardware, 4 to 5
- the software, 11 to 15, 23 to 29

### instance

- names, *See* device names
- numbers, 4, 13, 28

interference, 75

intermediate distribution frame, 103, 105

## IP

- addresses, 10, 13, 22, 56
- routing, 106

## J

jumpers, 4

## K

kbps, 180

kernel space, 39, 46

keying, 81

keys, 54

## L

LAN interfaces, 10, 22

Late\_Ct parameter, 90

latency, 38

LED, diagnostic, 8, 14, 29, 54

link status indicator, 8, 14, 29, 54, 61

list of packages, 12

lithium battery, 3

LLC, logical link control, 152, 181

loadable drivers, 50

loading the CD-ROM

- Solaris 1.x installation, 23
- Solaris 2.x installation, 11

local agent, 132, 140

lost frames, 122

low water mark, 41

## M

MAC, 108

- address, 55

MAC, medium access control, 73, 74, 76

main distribution frame, 103

major numbers, 59

master SBus slot, 4

maximizing data throughput, 39

---

maximum
 

- bandwidth, 38
- distance to end-station, 105
- length of ring, 38
- number of bypass switches, 87
- number of cards, 2, 4
- number of stations, 38
- throughput, 38
- transfer unit (MTU), 39, 109

Mbps, 181

media dependent, 73, 74, 75

medium access control (MAC), 2, 73, 74, 76

memory, 10, 22

microprocessor speed, 38

minimum requirements, 10, 22

mixed FDDI/Ethernet networks, 106

M-keys, 8

MMF, multimode fiber, 75

mount command, 23

mount\_hsfis command, 11

moving SBus cards, 4

M-ports, 8

MTU
 

- negotiation, 45
- path discovery, 45

multicast addresses, 151

multimode fiber, 75

multiplexer, 82

**N**

ndd command, 41, 42

negotiated MTU, 45

neighbor information frames, 126

netstat command, 16, 30, 56

network
 

- architecture, 79
- efficiency, 38
- interface tap, 154
- recovery, 86
- reliability, 84, 93
- size, 93
- topologies, 83
- traffic, 93

nf\_fddi agent, 132, 140

nf\_fddismt7\_2 agent, 132, 139, 142

nf\_install\_agents, 136

nf\_install\_agents script, 17, 31

nf\_macid utility, 112

nf\_smtmon command, 58

nf\_snmd daemon, 32

nf\_stat utility, 140

nf\_sync utility, 128

NFS, 136

NIF, 126

NIS/NIS+, 139

NIS/NIS+ servers, 10, 22

NIT monitor, 149, 154

nit\_buf module, 154

nit\_if module, 154

nit\_pf module, 154

noise, causes of, 6

NRZI-4B/5B, 181

number of cards supported, 2, 4

NVRAM—TOD chip, 3

**O**

official hostnames, 28, 34

one-way ring, 79, 84, 95

operating systems, 2

optical
 

- bypass switch, 86, 87, 97
- fiber, 74
- power budget, 86, 87

optimum
 

- performance, 38
- route, 108

OSI, 181

overall system performance, 91, 109

**P**

packages

---

SUNWnF, 59  
 packet  
   filtering services, 154  
   fragmentation, 40  
   size, 39, 45, 49, 106  
 parallel routes, 109  
 parameter management frame, 127  
 parameters  
   SO\_RCVBUF, 44, 48  
   SO\_SNDBUF, 44, 48  
   T\_opr, 40  
   T\_Req, 46  
   T\_req, 40, 46  
   tcp\_recv\_hiwat, 42  
   tcp\_xmit\_hiwat, 42  
   tcp\_xmit\_lowat, 43  
   udp\_recv\_hiwat, 42  
   udp\_xmit\_hiwat, 42  
   udp\_xmit\_lowat, 43  
 patch panel, 105  
 path discovery, MTU, 45, 63  
 PCM, 117  
 peer-to-peer management, 126  
 performance, 1, 89, 91  
 permission token, 38, 89  
 PHY, physical layer, 73, 74, 75, 181  
 physical  
   address, 152  
   connection, 121  
   connection management, 117  
   delay, 38  
   layer, 73, 74, 75  
   media dependent, 74, 75  
   media dependent layer, 73  
   medium, 75  
 physical layer (PHY), 2  
 physical media dependent (PMD), 2  
 Pin, 80, 81  
 ping command, 16, 30  
 pkgadd command, 11, 12, 14  
 pkgrm command, 19  
 placement of stations, 93  
 plastic retainer, 5  
 PMD, 75  
 PMD, physical media dependent, 73, 74, 181  
 PMF, 127  
 PMF\_get, 127  
 port A, 173  
 port B, 173  
 potential performance, 38, 91  
 Pout, 80, 81  
 power budget, 86  
 power-up self test, 65  
 preset keys, 7  
 primary  
   components, 65  
   hostnames, 28, 34  
   input, 80, 81  
   output, 80, 81  
   path, 98  
   ring, 79, 81, 84  
 priority-based traffic, 76  
 product list, 1  
 programming interface, 149  
 proxy agent, 64, 131, 132, 139, 142

**Q**

queues, 41  
 quick dump, 64

**R**

R7.2.99, 2, 73  
 RARP, reverse address resolution protocol, 182  
 rarpd daemon, 154  
 raw packet output, 154  
 RDF, 126  
 RDF, request denied frame, 58, 64  
 read system call, 154  
 rebooting the machine, 15  
 receive buffers, 39, 46  
 receive packets, 118

---

receivers, 75  
recovery, 79, 96  
recovery mechanisms, 84, 86  
RecvP, 118  
reduced transmission time, 90  
relative hop count, 108  
reliability, 84, 93  
relocating SBus cards, 4  
removing the software, 19, 33 to 34  
repeater, 75  
request denied frame, 126  
request denied frame (RDF), 58, 64  
required bandwidth, 93  
restricted  
    token exchange, 89, 128  
    traffic, 89  
retainer, plastic, 5  
RFC 1390, 39  
right to transmit, 89  
ring, 76  
    architecture, 96  
    failure, 94  
    format, 144  
    latency, 38  
    length, 38  
ring management, 116  
ring of trees, 97, 102, 107  
ring of trees configuration, 83  
ring utilization, 38  
Ring\_OP, 118, 120  
rm command, 33  
RMT, 116  
root  
    concentrator, 96, 102  
    of the tree, 100  
rotation time, 90  
routed, 108  
routing metrics, 109  
routing tables, 57  
RSAS, redundant single-attached  
    station, 182

## S

SAC, single-attached concentrator, 80, 82,  
    93  
safety notice, 3, 4  
SAP, 152  
SAS, single-attached station, 80, 93  
Sbus transfer rate, 2  
schemas, 17, 31, 137  
scripts  
    /etc/loadable, 34  
    examples, 43  
    getagents, 18, 32  
    install\_nf, 28  
    installation, 10, 14, 15, 22, 26  
    nf\_install\_agents, 17, 31  
    start-up script for SNM agents, 18, 32  
    to modify water marks, 43  
secondary  
    input, 81  
    output, 81  
    ring, 79, 81, 84  
send buffers, 39, 46  
service access point, 152  
setsockopt command, 44, 48  
SIF, 126  
signal layer, 75  
simple network management  
    protocol, 131  
Sin, 81  
single-attached  
    concentrator (SAC), 80, 82  
    station, 75  
    station (SAS), 1, 54, 80  
single-mode fiber, 75  
S-keys, 7  
SMF, single-mode fiber, 75  
SMT request frame (SRF), 17, 31, 58, 142  
SMT, station management, 73, 84  
SMT, station mangement, 74  
SNMP, simple network management  
    protocol, 131  
SO\_RCVBUF parameter, 44, 48

---

SO\_SNDBUF parameter, 44, 48  
Sockets, 39, 44, 46, 48  
solving common problems, 59  
Sout, 81  
S-ports, 7  
SRF, 31  
SRF, SMT request frame, 17, 31, 58, 135, 142  
stability, 94  
stable network, 94  
stand-alone  
  concentrator, 96  
start-up script for SNM agents, 18, 32  
static electricity, 4  
static routes, 63  
station  
  failure, 79, 84  
  faults, 86  
  initialization, 79  
  management, 73, 74  
  upstream, 80  
  wrapping, 79, 86  
station management (SMT), 2, 84  
status information frames, 126  
STREAMS  
  DLPI specification, xxiii  
  modules, 41  
subnetwork number, 56  
SunNet Manager, 131  
  console, 132, 136  
  daemons, 64  
  proxy agent, 131  
  schemas, 17, 31, 137  
SunOS IP routing, 106  
SUNWnf package, 18, 59  
switches, 4  
symbols, 75, 77  
synchronization, 76  
synchronous  
  FDDI, 128  
  service, 89  
  traffic, 89

sys/dlpi.h file, 150  
system performance, 91

## T

T\_max parameter, 90  
T\_opr parameter, 40, 90  
T\_Req parameter, 46  
T\_req parameter, 40, 46, 90  
target  
  station, 132, 142  
  token rotation time, 40, 46, 90  
TCP  
  applications, 41  
  buffers, 46  
  high water marks, 41  
  low water mark, 42  
  window size, 46  
  window sizes, 39  
TCP/IP networks, 131  
tcp\_recv\_hiwat parameter, 42  
tcp\_xmit\_hiwat parameter, 42  
tcp\_xmit\_lowat parameter, 43  
test, boot, 65  
theoretical  
  maximum bandwidth, 38  
  maximum number of stations, 38  
throughput, 38  
THT, 90, 182  
timed token  
  rotation protocol, 76, 89, 128  
timing jitter, 182  
token, 89  
  ring, 89, 106  
  rotation timer, 90  
total ring length, 38  
traffic, 76  
transceiver unit, 6  
transfer rate, 91  
transmission time, 90  
transmit packets, 118  
transmitters, 75

---

trap reports, 17, 31, 135, 144  
tree of concentrators, 100, 102, 107  
tree of rings, 8  
trees, 96  
troubleshooting checklist, 54  
TRT, 90, 183  
TTRT, 40, 46, 90, 183  
tuning  
    high performance networks, 38  
    the high water marks, 41  
    the low water marks, 42  
    the maximum transfer unit, 45, 48  
    the socket options, 44, 48  
    the target token rotation time, 46, 50  
    the water marks at boot, 43  
twisting the ring, 6, 54  
types, 126  
types of traffic, 40

## U

UDP  
    applications, 41  
    high water marks, 41  
    low water mark, 42  
udp\_recv\_hiwat parameter, 42  
udp\_xmit\_hiwat parameter, 42  
udp\_xmit\_lowat parameter, 43  
umount command, 15, 29  
UNA, 122  
universal key, 7  
unrestricted traffic, 89  
unshielded twisted-pair, 74, 75, 104  
upstream station, 80  
user space, 39, 46  
user-configurable hardware, 4  
utilities  
    nf\_macid, 112  
    nf\_smtmon, 58  
    nf\_stat, 140  
    nf\_sync, 128  
UTP, 74, 104, 105

UTP, unshielded twisted-pair, 75

## V

video applications, 38  
vmunix, 47  
voice applications, 38  
volume manager (vold), 11, 15, 43

## W

wall boxes, 103  
water marks, 41  
window sizes, 39  
work groups, 96  
wrapping, 79, 86

## X

X.3.139-1987, 2, 73  
X3.148-1988, 2, 73  
X3.166-1990, 2, 73  
X3.299 R7.3, 2, 73  
XmitP, 118



Copyright 1995 Sun Microsystems, Inc., 2550 Garcia Avenue, Mountain View, Californie 94043-1100 USA.

Tous droits réservés. Ce produit ou document est protégé par un copyright et distribué avec des licences qui en restreignent l'utilisation, la copie et la décompilation. Aucune partie de ce produit ou de sa documentation associée ne peuvent être reproduits sous aucune forme, par quelque moyen que ce soit sans l'autorisation préalable et écrite de Sun et de ses bailleurs de licence, s'il en a.

Des parties de ce produit pourront être dérivées du système UNIX<sup>®</sup>, licencié par UNIX Systems Laboratories Inc., filiale entièrement détenue par Novell, Inc. ainsi que par le système 4.3. de Berkeley, licencié par l'Université de Californie. Le logiciel détenu par des tiers, et qui comprend la technologie relative aux polices de caractères, est protégé par un copyright et licencié par des fournisseurs de Sun.

LEGENDE RELATIVE AUX DROITS RESTREINTS : l'utilisation, la duplication ou la divulgation par l'administration américaine sont soumises aux restrictions visées à l'alinéa (c)(1)(ii) de la clause relative aux droits des données techniques et aux logiciels informatiques du DFAR 252.227- 7013 et FAR 52.227-19.

Le produit décrit dans ce manuel peut être protégé par un ou plusieurs brevet(s) américain(s), étranger(s) ou par des demandes en cours d'enregistrement.

#### MARQUES

Sun, Sun Microsystems, le logo Sun, Solaris, SunOS, OpenWindows, DeskSet, ONC, SNM, and NFS sont des marques déposées ou enregistrées par Sun Microsystems, Inc. aux Etats-Unis et dans certains autres pays. UNIX est une marque enregistrée aux Etats-Unis et dans d'autres pays, et exclusivement licenciée par X/Open Company Ltd. OPEN LOOK est une marque enregistrée de Novell, Inc., PostScript et Display PostScript sont des marques d'Adobe Systems, Inc.

Toutes les marques SPARC sont des marques déposées ou enregistrées de SPARC International, Inc. aux Etats-Unis et dans d'autres pays. SPARCcenter, SPARCcluster, SPARCcompiler, SPARCdesign, SPARC811, SPARCengine, SPARCprinter, SPARCserver, SPARCstation, SPARCstorage, SPARCworks, microSPARC, microSPARC II et UltraSPARC sont exclusivement licenciées à Sun Microsystems, Inc. Les produits portant les marques sont basés sur une architecture développée par Sun Microsystems, Inc.

Les utilisateurs d'interfaces graphiques OPEN LOOK<sup>®</sup> et Sun<sup>™</sup> ont été développés par Sun Microsystems, Inc. pour ses utilisateurs et licenciés. Sun reconnaît les efforts de pionniers de Xerox pour la recherche et le développement du concept des interfaces d'utilisation visuelle ou graphique pour l'industrie de l'informatique. Sun détient une licence non exclusive de Xerox sur l'interface d'utilisation graphique, cette licence couvrant aussi les licences de Sun qui mettent en place OPEN LOOK GUIs et qui en outre se conforment aux licences écrites de Sun.

Le système X Window est un produit du X Consortium, Inc.

CETTE PUBLICATION EST FOURNIE "EN L'ETAT" SANS GARANTIE D'AUCUNE SORTE, NI EXPRESSE NI IMPLICITE, Y COMPRIS, ET SANS QUE CETTE LISTE NE SOIT LIMITATIVE, DES GARANTIES CONCERNANT LA VALEUR MARCHANDE, L'APTITUDE DES PRODUITS A REPENDRE A UNE UTILISATION PARTICULIERE OU LE FAIT QU'ILS NE SOIENT PAS CONTREFAISANTS DE PRODUITS DE TIERS.

CETTE PUBLICATION PEUT CONTENIR DES MENTIONS TECHNIQUES ERRONEES OU DES ERREURS TYPOGRAPHIQUES. DES CHANGEMENTS SONT PERIODIQUEMENT APPORTES AUX INFORMATIONS CONTENUES AUX PRESENTES, CES CHANGEMENTS SERONT INCORPORES AUX NOUVELLES EDITIONS DE LA PUBLICATION. SUN MICROSYSTEMS INC. PEUT REALISER DES AMELIORATIONS ET/OU DES CHANGEMENTS DANS LE(S) PRODUIT(S) ET/OU LE(S) PROGRAMME(S) DECRITS DANS CETTE PUBLICATION A TOUS MOMENTS.



Adobe PostScript

