



Sun™ Quad FastEthernet PCI Adapter Release Notes

Sun Microsystems, Inc.
www.sun.com

Part No. 805-2901-13
June 2004, Revision A

Submit comments about this document at: <http://www.sun.com/hwdocs/feedback>

Copyright 2004 Sun Microsystems, Inc., 4150 Network Circle, Santa Clara, California 95054, U.S.A. All rights reserved.

Sun Microsystems, Inc. has intellectual property rights relating to technology that is described in this document. In particular, and without limitation, these intellectual property rights may include one or more of the U.S. patents listed at <http://www.sun.com/patents> and one or more additional patents or pending patent applications in the U.S. and in other countries.

This document and the product to which it pertains are distributed under licenses restricting their use, copying, distribution, and decompilation. No part of the product or of this document may be reproduced in any form by any means without prior written authorization of Sun and its licensors, if any.

Third-party software, including font technology, is copyrighted and licensed from Sun suppliers.

Parts of the product may be derived from Berkeley BSD systems, licensed from the University of California. UNIX is a registered trademark in the U.S. and in other countries, exclusively licensed through X/Open Company, Ltd.

Sun, Sun Microsystems, the Sun logo, AnswerBook, Java, the Java Coffee Cup, Sun Quad FastEthernet, Sun Trunking, SunSolve, SunService, and Solaris are trademarks, registered trademarks, or service marks of Sun Microsystems, Inc. in the U.S. and other countries. All SPARC trademarks are used under license and are trademarks or registered trademarks of SPARC International, Inc. in the U.S. and other countries. Products bearing SPARC trademarks are based upon an architecture developed by Sun Microsystems, Inc.

All SPARC trademarks are used under license and are trademarks or registered trademarks of SPARC International, Inc. in the U.S. and in other countries. Products bearing SPARC trademarks are based upon an architecture developed by Sun Microsystems, Inc.

The OPEN LOOK and Sun™ Graphical User Interface was developed by Sun Microsystems, Inc. for its users and licensees. Sun acknowledges the pioneering efforts of Xerox in researching and developing the concept of visual or graphical user interfaces for the computer industry. Sun holds a non-exclusive license from Xerox to the Xerox Graphical User Interface, which license also covers Sun's licensees who implement OPEN LOOK GUIs and otherwise comply with Sun's written license agreements.

U.S. Government Rights—Commercial use. Government users are subject to the Sun Microsystems, Inc. standard license agreement and applicable provisions of the FAR and its supplements.

DOCUMENTATION IS PROVIDED "AS IS" AND ALL EXPRESS OR IMPLIED CONDITIONS, REPRESENTATIONS AND WARRANTIES, INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE OR NON-INFRINGEMENT, ARE DISCLAIMED, EXCEPT TO THE EXTENT THAT SUCH DISCLAIMERS ARE HELD TO BE LEGALLY INVALID.

Copyright 2004 Sun Microsystems, Inc., 4150 Network Circle, Santa Clara, Californie 95054, Etats-Unis. Tous droits réservés.

Sun Microsystems, Inc. a les droits de propriété intellectuels relatants à la technologie qui est décrit dans ce document. En particulier, et sans la limitation, ces droits de propriété intellectuels peuvent inclure un ou plus des brevets américains énumérés à <http://www.sun.com/patents> et un ou les brevets plus supplémentaires ou les applications de brevet en attente dans les Etats-Unis et dans les autres pays.

Ce produit ou document est protégé par un copyright et distribué avec des licences qui en restreignent l'utilisation, la copie, la distribution, et la décompilation. Aucune partie de ce produit ou document ne peut être reproduite sous aucune forme, par quelque moyen que ce soit, sans l'autorisation préalable et écrite de Sun et de ses bailleurs de licence, s'il y en a.

Le logiciel détenu par des tiers, et qui comprend la technologie relative aux polices de caractères, est protégé par un copyright et licencié par des fournisseurs de Sun.

Des parties de ce produit pourront être dérivées des systèmes Berkeley BSD licenciés par l'Université de Californie. UNIX est une marque déposée aux Etats-Unis et dans d'autres pays et licenciée exclusivement par X/Open Company, Ltd.

Sun, Sun Microsystems, le logo Sun, AnswerBook, Java, le logo Java Coffee Cup, Sun Quad FastEthernet, Sun Trunking, SunSolve, SunService, et Solaris sont des marques de fabrique ou des marques déposées, ou marques de service, de Sun Microsystems, Inc. aux Etats-Unis et dans d'autres pays. Toutes les marques SPARC sont utilisées sous licence et sont des marques de fabrique ou des marques déposées de SPARC International, Inc. aux Etats-Unis et dans d'autres pays. Les produits portant les marques SPARC sont basés sur une architecture développée par Sun Microsystems, Inc.

Toutes les marques SPARC sont utilisées sous licence et sont des marques de fabrique ou des marques déposées de SPARC International, Inc. aux Etats-Unis et dans d'autres pays. Les produits portant les marques SPARC sont basés sur une architecture développée par Sun Microsystems, Inc.

L'interface d'utilisation graphique OPEN LOOK et Sun™ a été développée par Sun Microsystems, Inc. pour ses utilisateurs et licenciés. Sun reconnaît les efforts de pionniers de Xerox pour la recherche et le développement du concept des interfaces d'utilisation visuelle ou graphique pour l'industrie de l'informatique. Sun détient une licence non exclusive de Xerox sur l'interface d'utilisation graphique Xerox, cette licence couvrant également les licenciées de Sun qui mettent en place l'interface d'utilisation graphique OPEN LOOK et qui en outre se conforment aux licences écrites de Sun.

LA DOCUMENTATION EST FOURNIE "EN L'ÉTAT" ET TOUTES AUTRES CONDITIONS, DECLARATIONS ET GARANTIES EXPRESSES OU TACITES SONT FORMELLEMENT EXCLUES, DANS LA MESURE AUTORISEE PAR LA LOI APPLICABLE, Y COMPRIS NOTAMMENT TOUTE GARANTIE IMPLICITE RELATIVE A LA QUALITE MARCHANDE, A L'APTITUDE A UNE UTILISATION PARTICULIERE OU A L'ABSENCE DE CONTREFAÇON.



Sun Quad FastEthernet PCI Adapter Release Notes

This document contains the following important information about the Sun™ Quad FastEthernet™ PCI Adapter and the Sun Quad FastEthernet 2.1 driver software:

- “Required Software Patches” on page -2
- “Conflicts With FastEthernet Switches (100BASE-T)” on page -5
- “Increasing Performance on Enterprise Servers with Four Quad FastEthernet Adapters” on page -5
- “Increasing Synchronized Queues to Improve Network Performance” on page -6
- “Disabling IP Forwarding Routing Protocols on Application Servers” on page -6
- “Increasing TCP/IP Performance on Solaris 2.6 Systems” on page -7
- “Editing the `driver_aliases` File on Solaris 2.5.1 Systems” on page -8
- “Avoiding a System Panic While Detaching a PCI Networking Device” on page -9
- “Known Problems With the Installation and User’s Guide” on page -9
- “Avoiding a Failure When Running Ethernet FCode Selftest Diagnostic” on page -17

Note – If your system is running the Solaris™ 2.6 Hardware: 5/98 operating environment, or subsequent compatible versions, do not use the driver on the *Sun Quad FastEthernet 2.1* CD-ROM. The software on the Solaris CD-ROM is more current and replaces previous versions of the driver. For information on this version of the driver, refer to the *Platform Notes: The Sun Quad FastEthernet Device Driver*, which is shipped with the Solaris documentation. For information on patches, see “Sun Quad FastEthernet 2.2 Software Patches” on page -4.



Caution – To avoid a system panic, you *must* follow the hardware and software installation procedures in the *Sun Quad FastEthernet PCI Adapter Installation and User’s Guide* (805-1797-10) and these release notes.

Required Software Patches

To achieve the best performance from the Sun Quad FastEthernet driver software, you must install a patch. Before installing a patch or the software from the *Sun Quad FastEthernet 2.1* CD-ROM, check to see if there is already another version of the Sun Quad FastEthernet driver on your system.

Checking for Installed Sun Quad FastEthernet Software

Previous versions of the Sun Quad FastEthernet driver have been included with other Sun products. Before installing the Sun Quad FastEthernet 2.1 software, check your system for other versions of the Sun Quad FastEthernet driver.

Bundled Sun Quad FastEthernet Drivers

Beginning with the Solaris 2.6 Hardware: 5/98 release, the Sun Quad FastEthernet driver is bundled with the Solaris operating environment. This version of the Sun Quad FastEthernet driver is more current than the one shipped on the *Sun Quad FastEthernet 2.1* CD-ROM.

Note – If your system is running the Solaris 2.6 Hardware: 5/98 environment, or future compatible Solaris releases, do *not* install the software from the *Sun Quad FastEthernet 2.1* CD-ROM.

If your system is running the Solaris 2.6 operating environment, and you are unsure if it is running the Hardware: 5/98 release, check the contents of the `/etc/release` file.

```
% cat /etc/release
      Solaris 2.6 5/98 build_id_name SPARC
      Copyright 1998 Sun Microsystems, Inc. All Rights Reserved.
      Assembled on 24 April 1998
```

If this file exists, and it contains `Solaris 2.6 5/98`, your system is running the Solaris 2.6 Hardware: 5/98 release. See “Installing the Required Quad FastEthernet Software Patches” on page -4 for patch information.

Checking for Quad FastEthernet Software Shipped With Other Products

Other versions of the Sun Quad FastEthernet software have been shipped with an earlier release of the adapter and with the Sun Trunking™ software.

- **To check your system for installed Sun Quad FastEthernet software, type the following at a command prompt:**

```
% pkginfo -x SUNWqfed
SUNWqfed      Sun Quad FastEthernet Adapter Driver
              (sparc) 3.0
```

Use the table below to translate the `pkginfo` output.

TABLE 1 `pkginfo` Output Description

<code>pkginfo -x</code> Output	Description and Action
No output	Your system does not have the Sun Quad FastEthernet software installed. Follow the installation instructions in the <i>Sun Quad FastEthernet 2.1 CD Insert</i> , and then install the patch listed in “Installing the Required Quad FastEthernet Software Patches” on page -4.
1.0	Your system has the Sun Quad FastEthernet 2.0 software installed. You must remove this 2.0 version of the software and install the 2.1 software as described in the <i>Sun Quad FastEthernet 2.1 CD Insert</i> . After installing the software, install the patch listed in “Installing the Required Quad FastEthernet Software Patches” on page -4.
1.1	Your system already has the Sun Quad FastEthernet 2.1 software installed. Install the patch listed in “Installing the Required Quad FastEthernet Software Patches” on page -4.
3.0	Your system has the Sun Quad FastEthernet software installed with the Sun Trunking 1.0 software. Do not install the software from the CD-ROM and do not install any patch listed in these release notes. <i>Note:</i> If you remove this version of the software, you will not be able to use the Trunking 1.0 software.
3.1	Your system has the Sun Quad FastEthernet 2.2 software installed. This version was shipped with the Sun Trunking 1.0.1 software and the Solaris 2.6 Hardware: 5/98 software. Do not install the software from the CD-ROM, but do install the patch listed in “Installing the Required Quad FastEthernet Software Patches” on page -4.

Installing the Required Quad FastEthernet Software Patches

Install the patch, listed below, that is appropriate for the version of the Sun Quad FastEthernet software and the Solaris environment installed on your system. These patches correct panics during dynamic reconfiguration, difficulties with certain FastEthernet switches, and problems with general network performance (refer to these patches' README files for more information).

Sun Quad FastEthernet 2.1 Software Patches

This version of the Sun Quad FastEthernet software is shipped with the *Sun Quad FastEthernet 2.1* CD-ROM. Install the software from this CD before installing the patch.

TABLE 2 Sun Quad FastEthernet 2.1 Patches

Operating Environment	Patch Identification Number
Solaris 2.5.1 Hardware: 4/97, 8/97, and 11/97	105532-x
Solaris 2.6 (prior to Solaris 2.6 Hardware: 5/98)	105541-x

Sun Quad FastEthernet 2.2 Software Patches

This version of the Sun Quad FastEthernet software is shipped with the Sun Trunking 1.0.1 software and the Solaris 2.6 Hardware: 5/98 environment.

TABLE 3 Sun Quad FastEthernet 2.2 Patches

Operating Environment	Patch Identification Number
Solaris 2.5.1 Hardware: 4/97, 8/97, and 11/97	106531-x
Solaris 2.6 Solaris 2.6 Hardware: 5/98	106532-x

The patches listed above are current as of the printing of this document. Future revisions of these patches will also correct problems with this software. These patches may also be included in future jumbo kernel patches.

Note – For information on how to get the latest patches and patch revisions, visit the SunSolve™ website at <http://sunsolve.sun.com>. Otherwise, contact your local SunServiceSM representative for assistance or your local SunService authorized service provider for more information.

Conflicts With FastEthernet Switches (100BASE-T)

There are two FastEthernet (100BASE-T) switches that may present difficulties when working with the Sun Quad FastEthernet PCI adapter:

- Bay Networks model 28115/ADV
- SynOptics model 28115

If you use the adapter with these switches, you will encounter difficulties (refer to bug ID 4071199 for more information). Installing the Quad FastEthernet 2.1 driver patch, as described in “Installing the Required Quad FastEthernet Software Patches” on page -4, will fix these difficulties.

Increasing Performance on Enterprise Servers with Four Quad FastEthernet Adapters

If you have four Sun Quad FastEthernet adapters in an Enterprise server, you may experience slow performance and response times during periods of high network traffic. This poor performance is usually caused by applications that use data buffer and socket buffer sizes greater than 8 Kbytes.

You can achieve better network performance by adjusting your application’s data buffer size and socket buffer size to be less than or equal to 8 Kbytes. Refer to the application’s documentation for instructions on how to set these buffer sizes.

Increasing Synchronized Queues to Improve Network Performance

To increase the size of STREAMS synchronized queues, thereby increasing network performance, add the `sq_max_size` variable to the `/etc/system` file.

```
set sq_max_size=n
```

Set the `sq_max_size` variable to *n*, where *n* is the maximum number of messages that are allowed for each IP queue. A safe value to set this variable is 25 for each 64 Mbytes of RAM in the system. For example, if your system has 64 Mbytes of RAM, you would set the variable to 25 (50 if the system has 128 Mbytes of RAM, 100 if your system has 256 Mbytes of RAM, and so on).

You can be more aggressive if you choose, but you may overrun STREAMS resources.

Refer to the Solaris documentation for more information.

Disabling IP Forwarding Routing Protocols on Application Servers

By default, the Solaris operating environment will configure systems using more than one network interface to be an IP forwarding router. Application servers are typically multihomed, which mean that they contain more than one network interface but do not run IP routing protocols or forward IP packets. If you do not disable the IP forwarding and routing protocols on multihomed application servers, the servers may experience poor performance.

NFS servers and database servers are a couple of examples of multihomed application servers. The purpose of these application servers is to provide a presence on multiple networks. These networks usually contain dedicated routing devices (routers, layer-3 switches, or dedicated Sun systems) in the network infrastructure that provide the IP forwarding routing services.

To maximize the performance of your multihomed desktop or application server, we recommend disabling the IP forwarding and routing protocols. One method of disabling IP forwarding is to create an `/etc/notrouter` file and then reboot your system.

1. As superuser, type:

```
# /usr/bin/touch /etc/notrouter
```

2. Shut down and reboot the system.

3. After rebooting your system, verify that IP forwarding has been disabled in the kernel.

```
# /usr/sbin/ndd /dev/ip ip_forwarding
```

If you receive a 0 result, your system will never forward IP packets. If you receive non-zero result, your system may still forward IP packets.

If you received non-zero result, your system may contain an `/etc/defaultrouter` file. The existence of this file may prevent the `/etc/init.d/inetinit` boot script from detecting the `/etc/notrouter` file. You may want to remove the `/etc/defaultrouter` file or, alternatively, force the `ndd` parameter, `ip_forwarding`, to equal 0.

For more information, refer to the *TCP/IP and Data Communications Administration Guide* shipped with the Solaris documentation.

Increasing TCP/IP Performance on Solaris 2.6 Systems

If you are running your Solaris 2.6 system with a large TCP window, and you experience slowdowns during periods of high network traffic, you should decrease the TCP default maximum retransmission timeout interval variable (`tcp_rexmit_interval_max`) to 60000.

● **As superuser type:**

```
# ndd -set /dev/tcp tcp_rexmit_interval_max 60000
```

The changes are immediate, and they affect all the TCP connections in the system. However, the changes will be lost when you reboot your machine.

Note – You may not need to perform this workaround if you use a smaller TCP window (for example, an 8 Kbyte or a 16 Kbyte window).

To avoid losing the TCP/IP setting, you can put the parameter change in a run control script in the `/etc/rc2.d` directory, similar to the following example.

```
#!/sbin/sh
# Local kernel modifications
#
case "$1" in
'start')
    echo "Setting local kernel parameters...\c"
    ndd -set /dev/tcp tcp_rexmit_interval_max 60000
    echo ""
    ;;
'stop')
    echo "No kernel parameters changed."
    ;;
*)
    echo "Usage: $0 {start|stop}"
    ;;
esac
exit 0
```

Editing the `driver_aliases` File on Solaris 2.5.1 Systems

If your system is running the Solaris 2.5.1 operating environment, versions: Hardware: 4/97, Hardware: 8/97, or Hardware: 11/97, you must add the `pci_pci "pci1011,25"` line to your `/etc/driver_aliases` file before installing the adapter. Refer to page 5 of the *Sun Quad FastEthernet PCI Installation and User's Guide* for instructions on editing the `driver_aliases` file.

Avoiding a System Panic While Detaching a PCI Networking Device

Unloading or detaching a PCI networking device may cause a Solaris 2.5.1 system to crash because of a problem with the PCI (4) nexus driver. Refer to bug ID 4058070 for more information.

Install the 105004-10 patch to fix this bug. This patch is current as of the printing of this document. Future revisions of this patch will also correct the problems described in the 4058070 bug report. This patch may also be included in future jumbo kernel patches.

Note – For information on how to get the latest patches and patch revisions, visit the SunSolve website at <http://sunsolve.sun.com>. Otherwise, contact your local SunService representative for assistance or your local SunService authorized service provider for more information.

Known Problems With the Installation and User's Guide

Configuring the Host Files

Note – “Configuring the Host Files” on page 11 of the *Sun Quad FastEthernet PCI Adapter Installation and User's Guide* contains inaccurate `qfe` interface numbers and `hostname.qfe<num>` file names. The corrected section is shown below.

After installing the Sun Quad FastEthernet driver software, you must create a `hostname.qfe<num>` file for the adapter's Ethernet interfaces. You must also create both an IP address and a host name for its Ethernet interfaces in the `/etc/hosts` file.

1. At the command line, use the `grep` command to search the `/etc/path_to_inst` file for `qfe` devices.

```
# grep qfe /etc/path_to_inst
"/pci@1f,2000/pci@2/SUNW,qfe@0,1" 0 "qfe"
"/pci@1f,2000/pci@2/SUNW,qfe@1,1" 1 "qfe"
"/pci@1f,2000/pci@2/SUNW,qfe@2,1" 2 "qfe"
"/pci@1f,2000/pci@2/SUNW,qfe@3,1" 3 "qfe"
```

In the example above, the four `SUNW,qfe@x,1` instances are from a Sun Quad FastEthernet PCI Adapter installed in slot 2. For clarity, the instance numbers are bold.

2. Create an `/etc/hostname.qfe<num>` file, where `<num>` corresponds to the instance number of each interface you plan to use.

If you wanted to use all of the adapter interfaces in Step 1, you would need to create four files:

TABLE 4 `/etc/hostname.qfe<num>` Files

Filename	Instance Number	Adapter Ethernet Channel
<code>/etc/hostname.qfe0</code>	0	0
<code>/etc/hostname.qfe1</code>	1	1
<code>/etc/hostname.qfe2</code>	2	2
<code>/etc/hostname.qfe3</code>	3	3

Guidelines for `hostname.qfe<num>` Files:

- Do not create `/etc/hostname.qfe<num>` files for Sun Quad FastEthernet PCI Adapter channels you plan to leave unused.
- The `/etc/hostname.qfe<num>` file must contain the host name for the appropriate network interface.
- The host name should have an IP address and should be entered in the `/etc/hosts` file.
- The host name should be different from any other host name of any other interface, for example: `/etc/hostname.hme0` and `/etc/hostname.qfe2` cannot share the same host name.

Using the instance examples in Step 1, the following example shows the four `/etc/hostname.qfe<num>` files required for a system called `zardoz` that has a Sun Quad FastEthernet PCI Adapter (`zardoz-11`, `zardoz-12`, `zardoz-13`, and `zardoz-14`).

```
# cat /etc/hostname.hme0
zardoz
# cat /etc/hostname.qfe0
zardoz-11
# cat /etc/hostname.qfe1
zardoz-12
# cat /etc/hostname.qfe2
zardoz-13
# cat /etc/hostname.qfe3
zardoz-14
```

3. Create an appropriate entry in the `/etc/hosts` file for each active `qfe` channel.

Using the example in Step 1, you will have:

```
# cat /etc/hosts
#
# Internet host table
#
127.0.0.1    localhost
129.144.10.57 zardoz    loghost
129.144.11.83 zardoz-11
129.144.12.41 zardoz-12
129.144.13.67 zardoz-13
129.144.14.30 zardoz-14
```

4. Reboot your system.

Booting a Diskless Client System

Note – This section should be appended to Chapter 3 of the *Sun Quad FastEthernet PCI Adapter Installation and User's Guide*.

In order to boot a diskless client with a local Sun Quad FastEthernet PCI Adapter interface (`qfe`), the following tasks must be performed on the boot server.

1. Go to your client's root partition by typing the following:

```
# cd /export/root/<client name>/etc
```

2. Search the `name_to_major` file for Quad FastEthernet (`qfe`) entries.

```
# grep qfe name_to_major
```

If this file already has a Quad FastEthernet (`qfe`) entry, skip to Step 4.

3. If the `name_to_major` file does not contain a Quad FastEthernet (`qfe`) entry, use a text editor to add an entry for the Sun Quad FastEthernet PCI Adapter device (`qfe`).

If the major device number for the last file entry is n , use $n+1$ for the `qfe` channel major device number. As shown in the example below, if the last entry for the major device number is 108, use 109 for the `qfe` device.

```
. . .
llcl 107
audiocs 108
qfe 109
```

4. Check the `driver_aliases` file for the `pci_pci` line required by the adapter.

```
# grep 'pci_pci "pci1011,25"' driver_aliases
```

If this line already exists in the `driver_aliases` file, you can skip to Step 6. Otherwise, you will need to add this line to the file before installing the adapter.

5. Using a text editor, add the following line to the end of the `driver_aliases` file.

```
pci_pci "pci1011,25"
```

6. Check the `driver_aliases` file for the `qfe` line required by the adapter.

```
# grep 'qfe SUNW,qfe' driver_aliases
```

If this line already exists in the `driver_aliases` file, you can skip to Step 8. Otherwise, you will need to add this line to the file before installing the adapter.

7. Using a text editor, add the following line to the end of the `driver_aliases` file.

```
qfe SUNW,qfe
```

8. Create the following symbolic link.

```
# ln -s <archive_of_arch>/devices/pseudo/clone0:qfe <archive_of_arch>/dev/qfe
```

9. Insert and mount the *Sun Quad FastEthernet 2.1* CD-ROM.

- If your system is running Volume Manager, it should automatically mount the CD-ROM to the `/cdrom/sun_quadfast_2_1` directory.
- If your system is not running Volume Manager, mount the CD-ROM as follows:

```
# mkdir -p /cdrom/sun_quadfast_2_1  
# mount -F hsfs -r /dev/dsk/c0t6d0s2 /cdrom/sun_quadfast_2_1
```

10. Copy the `qfe` driver from the CD-ROM to the client's root partition.

In the steps below, replace *DIR* with the directory where the Solaris software is located on the client system.

a. For Solaris 2.5.1 operating systems, type:

```
# cp /cdrom/sun_quadfast_2_1/Sol_2.5.1+/SUNWqfed/reloc/kernel/drv/qfe \  
DIR/export/exec/kvm/<archive_of_arch>/kernel/drv
```

b. For the Solaris 2.6 operating system, type:

```
# cp /cdrom/sun_quadfast_2_1/Sol_2.6/SUNWqfed/reloc/kernel/drv/qfe \  
DIR/export/exec/kvm/<archive_of_arch>/kernel/drv
```

11. Unmount and eject the CD-ROM as follows:

```
# cd /  
# umount /cdrom  
# eject cdrom
```

12. Create a `hostname.qfe<num>` file for the client in the `/etc` directory of the client's root partition.

See "Configuring the Host Files" on page -9 for more information.

13. Reboot your system.

Updating the Solaris Archive to Use the `qfe` Interface

Note – This section should be appended to Chapter 3 of the *Sun Quad FastEthernet PCI Adapter Installation and User's Guide*.

This section is only applicable if you are installing the Solaris operating environment on a net-install client system *over* the Quad FastEthernet (`qfe`) interface.

Note – The Solaris CD-ROM cannot be used to perform a net-install since it is a read-only medium. Therefore, the Solaris CD image archive is required so you can update certain software files.

1. Determine the directory where the CD image is located on the boot server.

For example, if the Solaris software is located within a directory named *DIR*, change to the `/etc` directory of the client's root partition by typing:

```
# cd DIR/export/exec/kvm/<archive_of_arch>/etc
```

2. Search the `name_to_major` file for Quad FastEthernet (`qfe`) entries.

```
# grep qfe name_to_major
qfe 119
```

If this file already has a Quad FastEthernet (`qfe`) entry, skip to Step 4.

3. If the `name_to_major` file does not contain a FastEthernet (`qfe`) entry, use a text editor to add an entry for the Sun Quad FastEthernet PCI Adapter device (`qfe`).

If the major device number for the last file entry is n then use $n+1$ for the `qfe` channel major device number. As shown in the example below, if the last entry for the major device number is 108, use 109 for the `qfe` device.

```
. . .  
audiocs 108  
qfe 109
```

4. Check the `driver_aliases` file for the `pci_pci` line required by the adapter.

```
# grep 'pci_pci "pci1011,25"' driver_aliases
```

If this line already exists in the `driver_aliases` file, you can skip to Step 6. Otherwise, you will need to add this line to the file before installing the adapter.

5. Using a text editor, add the following line to the end of the `driver_aliases` file.

```
pci_pci "pci1011,25"
```

6. Check the `driver_aliases` file for the `qfe` line required by the adapter.

```
# grep 'qfe SUNW,qfe' driver_aliases
```

If this line already exists in the `driver_aliases` file, you can skip to Step 8. Otherwise, you will need to add this line to the file before installing the adapter.

7. Using a text editor, add the following line to the end of the `driver_aliases` file.

```
qfe SUNW,qfe
```

8. Create the following symbolic link.

```
# ln -s <archive_of_arch>/devices/pseudo/clone@0:qfe <archive_of_arch>/dev/qfe
```

9. Insert and mount the *Sun Quad FastEthernet 2.1* CD-ROM.

- If your system is running Volume Manager, it should automatically mount the CD-ROM to the `/cdrom/sun_quadfast_2_1` directory.
- If your system is not running Volume Manager, mount the CD-ROM as follows:

```
# mkdir -p /cdrom/sun_quadfast_2_1
# mount -F hsfs -r /dev/dsk/c0t6d0s2 /cdrom/sun_quadfast_2_1
```

10. Copy the `qfe` driver from the CD-ROM to the client's root partition.

In the steps below, replace *DIR* with the directory where the Solaris CD image is located on the boot server system.

a. For Solaris 2.5.1 operating systems, type:

```
# cp /cdrom/sun_quadfast_2_1/Sol_2.5.1+/SUNWqfed/reloc/kernel/drv/qfe \
DIR/export/exec/kvm/<archive_of_arch>/kernel/drv
```

b. For the Solaris 2.6 operating system, type:

```
# cp /cdrom/sun_quadfast_2_1/Sol_2.6/SUNWqfed/reloc/kernel/drv/qfe \
DIR/export/exec/kvm/<archive_of_arch>/kernel/drv
```

11. Unmount and eject the CD-ROM as follows:

```
# cd /
# umount /cdrom
# eject cdrom
```

12. On the client system, perform the tasks listed in the section “Booting a Diskless Client System” on page -11.

13. Complete the Solaris client installation.

Refer to your Solaris documentation for detailed instructions.

14. Install the software drivers from the *Sun Quad FastEthernet 2.1* CD-ROM.

See the `cd` insert for more information.

15. Reboot the system.

Avoiding a Failure When Running Ethernet FCode Selftest Diagnostic

You might see a loopback test failure when you are running the Ethernet FCode Selftest on a Sun Quad FastEthernet adapter. This failure is caused by an insufficient delay in 100 Mbps PHY loopback test.

The following error message indicates this failure.

```
Transceiver check -- Using Onboard Transceiver - Link Up.  
passed  
Doing more loopback tests -- Did not receive expected loopback  
packet  
failed
```

This failure is only limited to 100 Mbps PHY loopback test. It doesn't affect any other operation of Sun Quad FastEthernet adapter FCode.

This failure can be avoided by adding the following workaround in NVRAM. This workaround adds a 2 ms delay in loopback tests. The workaround also modifies the selftest so that it does not report a failure when nothing is connected to the channel. However, the selftest will continue to print link status as before.

- 1. Shut down the system.**

2. From the ok prompt, put the following workaround in NVRAM. Set fcode-debug? and use-nvramrc? to true.

```
probe-all install-console banner

: drop-and-wait ( -- ) drop 2 ms ;
: nofind-method ( str,len -- )
  ." Could not find method: " type cr
  ." Set 'fcode-debug?' NVRAM variable to 'true' and reset
before running QFE selftest" cr
;

: patch-qfe-selftest ( -- )
  " name" get-property if exit then
  decode-string 2swap 2drop
  " SUNW,qfe" $= if
    " hme-loopback-test" $find if
      >r ['] 0<= false ['] 10= false r> (patch)
    else
      nofind-method
    then
    " loopback-buffer" $find if
      >r ['] drop-and-wait false ['] drop false r> (patch)
    else
      nofind-method
    then
  then
;

" /" ['] patch-qfe-selftest scan-subtree
```

Note – For more information about how to edit an NVRAM, refer to the *OpenBoot 3.x Command Reference Manual*.

3. Reset and reboot the system.

```
ok reset-all
```