

Sun Datacenter InfiniBand Switch 36

Product Notes for Firmware Version 1.3



Part No.: E23583-05
November 2013, Revision A

Copyright © 2009, 2013 Oracle and / or its affiliates. All rights reserved.

This software and related documentation are provided under a license agreement containing restrictions on use and disclosure and are protected by intellectual property laws. Except as expressly permitted in your license agreement or allowed by law, you may not use, copy, reproduce, translate, broadcast, modify, license, transmit, distribute, exhibit, perform, publish, or display any part, in any form, or by any means. Reverse engineering, disassembly, or decompilation of this software, unless required by law for interoperability, is prohibited.

The information contained herein is subject to change without notice and is not warranted to be error-free. If you find any errors, please report them to us in writing.

If this is software or related software documentation that is delivered to the U.S. Government or anyone licensing it on behalf of the U.S. Government, the following notice is applicable:

U.S. GOVERNMENT RIGHTS Programs, software, databases, and related documentation and technical data delivered to U.S. Government customers are "commercial computer software" or "commercial technical data" pursuant to the applicable Federal Acquisition Regulation and agency-specific supplemental regulations. As such, the use, duplication, disclosure, modification, and adaptation shall be subject to the restrictions and license terms set forth in the applicable Government contract, and, to the extent applicable by the terms of the Government contract, the additional rights set forth in FAR 52.227-19, Commercial Computer Software License (December 2007). Oracle America, Inc., 500 Oracle Parkway, Redwood City, CA 94065.

This software or hardware is developed for general use in a variety of information management applications. It is not developed or intended for use in any inherently dangerous applications, including applications which may create a risk of personal injury. If you use this software or hardware in dangerous applications, then you shall be responsible to take all appropriate fail-safe, backup, redundancy, and other measures to ensure its safe use. Oracle Corporation and its affiliates disclaim any liability for any damages caused by use of this software or hardware in dangerous applications.

Oracle and Java are registered trademarks of Oracle and / or its affiliates. Other names may be trademarks of their respective owners.

AMD, Opteron, the AMD logo, and the AMD Opteron logo are trademarks or registered trademarks of Advanced Micro Devices. Intel and Intel Xeon are trademarks or registered trademarks of Intel Corporation. All SPARC trademarks are used under license and are trademarks or registered trademarks of SPARC International, Inc. UNIX is a registered trademark licensed through X/Open Company, Ltd.

This software or hardware and documentation may provide access to or information on content, products, and services from third parties. Oracle Corporation and its affiliates are not responsible for and expressly disclaim all warranties of any kind with respect to third-party content, products, and services. Oracle Corporation and its affiliates will not be responsible for any loss, costs, or damages incurred due to your access to or use of third-party content, products, or services.

Copyright © 2009, 2013 Oracle et / ou ses affiliés. Tous droits réservés.

Ce logiciel et la documentation qui l'accompagne sont protégés par les lois sur la propriété intellectuelle. Ils sont concédés sous licence et soumis à des restrictions d'utilisation et de divulgation. Sauf disposition de votre contrat de licence ou de la loi, vous ne pouvez pas copier, reproduire, traduire, diffuser, modifier, breveter, transmettre, distribuer, exposer, exécuter, publier ou afficher le logiciel, même partiellement, sous quelque forme et par quelque procédé que ce soit. Par ailleurs, il est interdit de procéder à toute ingénierie inverse du logiciel, de le désassembler ou de le décompiler, excepté à des fins d'interopérabilité avec des logiciels tiers ou tel que prescrit par la loi.

Les informations fournies dans ce document sont susceptibles de modification sans préavis. Par ailleurs, Oracle Corporation ne garantit pas qu'elles soient exemptes d'erreurs et vous invite, le cas échéant, à lui en faire part par écrit.

Si ce logiciel, ou la documentation qui l'accompagne, est concédé sous licence au Gouvernement des Etats-Unis, ou à toute entité qui délivre la licence de ce logiciel ou l'utilise pour le compte du Gouvernement des Etats-Unis, la notice suivante s'applique :

U.S. GOVERNMENT RIGHTS. Programs, software, databases, and related documentation and technical data delivered to U.S. Government customers are "commercial computer software" or "commercial technical data" pursuant to the applicable Federal Acquisition Regulation and agency-specific supplemental regulations. As such, the use, duplication, disclosure, modification, and adaptation shall be subject to the restrictions and license terms set forth in the applicable Government contract, and, to the extent applicable by the terms of the Government contract, the additional rights set forth in FAR 52.227-19, Commercial Computer Software License (December 2007). Oracle America, Inc., 500 Oracle Parkway, Redwood City, CA 94065.

Ce logiciel ou matériel a été développé pour un usage général dans le cadre d'applications de gestion des informations. Ce logiciel ou matériel n'est pas conçu ni n'est destiné à être utilisé dans des applications à risque, notamment dans des applications pouvant causer des dommages corporels. Si vous utilisez ce logiciel ou matériel dans le cadre d'applications dangereuses, il est de votre responsabilité de prendre toutes les mesures de secours, de sauvegarde, de redondance et autres mesures nécessaires à son utilisation dans des conditions optimales de sécurité. Oracle Corporation et ses affiliés déclinent toute responsabilité quant aux dommages causés par l'utilisation de ce logiciel ou matériel pour ce type d'applications.

Oracle et Java sont des marques déposées d'Oracle Corporation et / ou de ses affiliés. Tout autre nom mentionné peut correspondre à des marques appartenant à d'autres propriétaires qu'Oracle.

AMD, Opteron, le logo AMD et le logo AMD Opteron sont des marques ou des marques déposées d'Advanced Micro Devices. Intel et Intel Xeon sont des marques ou des marques déposées d'Intel Corporation. Toutes les marques SPARC sont utilisées sous licence et sont des marques ou des marques déposées de SPARC International, Inc. UNIX est une marque déposée concédée sous licence par X/Open Company, Ltd.

Ce logiciel ou matériel et la documentation qui l'accompagne peuvent fournir des informations ou des liens donnant accès à des contenus, des produits et des services émanant de tiers. Oracle Corporation et ses affiliés déclinent toute responsabilité ou garantie expresse quant aux contenus, produits ou services émanant de tiers. En aucun cas, Oracle Corporation et ses affiliés ne sauraient être tenus pour responsables des pertes subies, des coûts occasionnés ou des dommages causés par l'accès à des contenus, produits ou services tiers, ou à leur utilisation.



Contents

Using This Documentation v

Sun Datacenter InfiniBand Switch 36 Product Notes 1

Known Problems 1

Hardware Information and Issues 3

▼ Undervoltage Condition 3

Supported Fan Configuration 4

Software Information and Issues 4

Firmware Version Numbers 4

Firmware Update Considerations 5

smpartition Command 6

Oracle ILOM Issues 6

Documentation Information and Issues 6

SUN-DCS-IB-MIB MIB and Respective OIDs 6

chassis_led Command Not Supported 7

InfiniBand Node Description 7

Declaration of Conformity 7

SNMP V3 Protocol Passwords 7

Temperature Sensor Thresholds Incorrect 8

Upgrading the Switch Firmware 8

▼ Acquire the Switch Firmware Package (CLI) 8

▼ Upgrade the Switch Firmware (CLI) 10

Using This Documentation

This document provides late-breaking information about the Sun Datacenter InfiniBand Switch 36 firmware version 1.3 from Oracle. This document is written for technicians, system administrators, and authorized service providers who have advanced experience working with similar products..

- “Related Documentation” on page v
 - “Feedback” on page v
 - “Access to Oracle Support” on page vi
-

Related Documentation

Documentation	Links
Sun Datacenter InfiniBand Switch 36	http://docs.oracle.com/cd/E19197-01
Oracle Integrated Lights Out Manager (ILOM) 3.0	http://docs.oracle.com/cd/E19860-01
All Oracle products	http://docs.oracle.com

Feedback

Provide feedback about this documentation at:

<http://www.oracle.com/goto/docfeedback>

Access to Oracle Support

Oracle customers have access to electronic support through My Oracle Support. For information visit <http://www.oracle.com/pls/topic/lookup?ctx=acc&id=info> or visit <http://www.oracle.com/pls/topic/lookup?ctx=acc&id=trs> if you are hearing impaired.

Sun Datacenter InfiniBand Switch 36 Product Notes

These product notes provide last-minute, late-breaking information regarding the Sun Datacenter InfiniBand Switch 36 from Oracle. These notes pertain to the release of the 1.3.5-1 firmware for the switch.

- “Known Problems” on page 1
 - “Hardware Information and Issues” on page 3
 - “Software Information and Issues” on page 4
 - “Documentation Information and Issues” on page 6
-

Known Problems

The following table describes known problems with the switch.

Bug	Description	Workaround
15560533	Setting an alert rule to ipmipet sometimes does not work.	There is no impact to the InfiniBand fabric. Workaround: After setting the alert rule to ipmipet, set the level to disable, and then set the level to the desired value.
15667851	Time zone setting is not preserved.	When upgrading or downgrading between the 1.1.3 and 1.3.5 firmware versions, the time zone setting is lost. Workaround: Reconfigure the time zone setting after the firmware upgrade or downgrade. See <i>Switch User Guide</i> , setting the time.
15679316	snmpd daemon experiences segmentation fault on reboot.	Sometimes when the management controller is rebooted, the snmpd daemon experiences a segmentation fault. In this situation, the daemon automatically restarts. Workaround: Wait a few seconds before accessing the snmpd daemon. Additionally, the segfault message in the /var/log/messages log file can be ignored.

Bug	Description	Workaround
15692350	LDA floods the log file.	If a host InfiniBand driver crashes or the host panics, the SMA is brought down. Though the respective InfiniBand link is still operational, the LDA writes noncritical messages to the /var/log/messages log file, flooding the log file with extraneous information. Workaround: Restart the host InfiniBand driver, or reboot the host.
15692591	error handling too strict in the partitiond daemon.	If the partitiond daemon is unable to signal the Subnet Manager when it transitions from secondary to primary (master), then the partition valid flag of the /conf/configvalid file might be set to false (0). In this situation, the Subnet Manager does not become fully operational. Workaround: Issue this command as the root user of the management controller: # echo "1" > /conf/configvalid
15696509	IP addresses within the Subnet Manager nodes file does not match those assigned by DHCP.	By default, the DHCP server is not assured to assign a consistent IP address to a Subnet Manager node upon reboot. Workaround: Manually configure the DHCP server to assign a specific and unique IP address to each Subnet Manager node.
15696667	IPMI service cannot be disabled.	Though it appears that the user has disabled the IPMI service from either the Oracle ILOM CLI or web interfaces, the service remains enabled. There is no workaround at this time.
15710409	Similarly named MIB files are not identical.	MIB files are included in the firmware download. You also can back up MIB files from the Oracle ILOM interfaces. The MIB files from these sources are not the same. Workaround: Use the MIB files included in the firmware download.
15714344	Incorrect message for full snapshot dataset.	When selecting the full dataset for snapshot in the Oracle ILOM CLI and web interfaces, or selecting diagnostic data for the custom dataset in the Oracle ILOM web interface, the text implies that a host reset might occur. In either case, this text can be ignored.

Bug	Description	Workaround
15714725	Host name property not supported in Oracle ILOM.	Performing a read action on the sysName OID does not return any value. There is no workaround at this time.
15715405	generatetopology command creates incorrect topology file.	The topology file created by the generatetopology command might have an incomplete entry. This situation occurs when the node descriptions for two or more InfiniBand devices are identical. The generatetopology command attempts to append the node GUID to the node description to help discriminate the InfiniBand devices. In rare occurrences, this task is not completed correctly. If the matchtopology command is used to validate the topology file, the command returns an error. There is no simple workaround.
15723865	Using the passwd command is not supported.	Contrary to the switch documentation, the passwd command is not supported. Workaround: As the ilom-admin user of the Oracle ILOM CLI, use this command to set the user's password: -> set /SP/users/username password where <i>username</i> is the name of the user.

Hardware Information and Issues

- “Undervoltage Condition” on page 3
- “Supported Fan Configuration” on page 4

▼ Undervoltage Condition

If a power supply experiences a temporary brownout or undervoltage condition, the checkpower command might indicate an Alert status for the power supply. The Alert does not reset upon supply voltage returning to nominal values. If the checkpower command reports an Alert, yet supplied voltage is known to be sufficient, perform the following task.

- 1. Remove the power cord from the suspect power supply.**
- 2. Remove the power supply from the switch chassis.**
- 3. Wait for 1 minute.**
- 4. Install the power supply into the switch chassis.**

5. Attach the power cord to the power supply.

Note – If the checkpower command still displays an Alert status for the power supply, see *Switch User’s Guide*, troubleshooting the switch, to troubleshoot the power supply.

Supported Fan Configuration

For optimum thermal management, ensure that the three fans shipped with your switch are installed at the central fan slots, Fan 1, Fan 2, and Fan 3. Installing any one of the three fans in fan slots Fan 0 or Fan 4 is not supported.

Software Information and Issues

- “Firmware Version Numbers” on page 4
- “Firmware Update Considerations” on page 5
- “smpartition Command” on page 6
- “Oracle ILOM Issues” on page 6

Firmware Version Numbers

When upgrading the management controller firmware, the procedure uses the variables x , y , z , and w in filename strings to identify the version number. For this release of the firmware, 1.3.5-1, the values are as follows:

- x is 1
- y is 3
- z is 5
- w is 1

Firmware Update Considerations

If you are going to downgrade the firmware to a version earlier than 2.0, you must remove user partitions and depopulate the Subnet Manager nodes list. See *Switch Administration*, removing partitions for firmware downgrade.

If you are going to downgrade from firmware 2.0.x to 1.3.5-1 or earlier, you might see these type of messages in the /var/log/message file after the downgrade:

```
1da: Unknown config parameter: ErrLogCount=100; .
1da: Unknown config parameter: ErrLogTimeInterval=100; .
```

The ErrLogCount and ErrLogTimeInterval configuration parameters introduced in firmware 2.0.x are unknown to firmware version 1.3.5-1 and earlier LDAs. The LDA logs these messages and ignores them from there on. The messages appear once per LDA startup and are harmless.

If you later upgrade from firmware 1.3.5-1 to 2.0.x and the ErrLogCount and ErrLogTimeInterval configuration parameters are absent, the 2.0.x LDA uses the compiled default values. Consequently, no LDA messages regarding these configuration parameters are recorded.

The following is a list of additional timezones supported only in firmware versions 1.3.4-1 and 1.3.5-1. They are not supported in firmware versions 1.1.x, 1.3.3-2, 2.0.4-1, or 2.0.5-2. If you downgrade the firmware to version 1.1.x or 1.3.3-2, or upgrade the firmware to version 2.0.4-1 or 2.0.5-2, you must set the timezone to somewhere other than these:

- America/Argentina/Salta
- America/Argentina/San_Luis
- America/Bahia_Banderas
- America/Kralendijk
- America/Lower_Princes
- America/Matamoros
- America/Metlakatla
- America/North_Dakota/Beulah
- America/Ojinaga
- America/Santa_Isabel
- America/Santarem
- America/Sitka
- Antarctica/Macquarie
- Asia/Ho_Chi_Minh
- Asia/Kathmandu

- Asia/Kolkata
- Asia/Novokuznetsk
- Pacific/Chuuk
- Pacific/Pohnpei

smpartition Command

Though the smpartition command appears in the list of commands displayed by the help command, the smpartition command is not supported at this time.

Oracle ILOM Issues

The following issues exist for the Oracle ILOM implementation in the 1.3.5-1 firmware:

- You must specify the value for the email_custom_sender property of an email alert rule. It does not use the custom_sender property of the /SP/clients/smtp target.

Documentation Information and Issues

- “SUN-DCS-IB-MIB MIB and Respective OIDs” on page 6
- “chassis_led Command Not Supported” on page 7
- “InfiniBand Node Description” on page 7
- “Declaration of Conformity” on page 7
- “SNMP V3 Protocol Passwords” on page 7
- “Temperature Sensor Thresholds Incorrect” on page 8
- “Upgrading the Switch Firmware” on page 8

SUN-DCS-IB-MIB MIB and Respective OIDs

The InfiniBand Management Information Base and respective Object Identifiers are incorrectly identified with the string SUN-DCS-MIB. Replace SUN-DCS-MIB with SUN-DCS-IB-MIB (note the -IB-) in text and command examples.

chassis_led Command Not Supported

Although the `chassis_led` command is documented for the switch, the command is not supported.

InfiniBand Node Description

In the output of some hardware and InfiniBand commands, the switch is identified by its node description. The node description is of the following format:

SUN DCS 36P switch *hostname.domain*

where:

- *hostname* is the host name of the management controller.
- *domain* is the fully qualified domain name where the host name resides.

An example node description might be:

SUN DCS 36P mnm34-97.example.com

Note – Often in the switch documentation, the node description is erroneously displayed with the string 36 and *not* 36P. The correct string is 36P.

Declaration of Conformity

To receive a copy of the latest Declaration of Conformity for the switch, either contact your local Oracle sales representative or create an online request at the following URL:

https://www2.sun.de/dct/forms/reg_us_1607_755_0.jsp

SNMP V3 Protocol Passwords

In sections of *Switch Remote Management*, authentication and privacy passwords are described for SNMP service user accounts and SNMP V3 protocol commands. For the user accounts and commands, the MD5 and SHA authentication passwords are 8 to 12 characters in length, and the DES privacy password must be exactly 8 characters long.

Temperature Sensor Thresholds Incorrect

Some of the temperature sensor thresholds described in the documentation are incorrect. This table provides correct threshold values.

Sensor	Upper Critical Threshold	Upper Nonrecoverable Threshold
/SYS/MB/T_SP	80°C	85°C
/SYS/MB/T_BACK	60°C	65°C
/SYS/MB/T_FRONT	60°C	65°C
/SYS/MB/T_I4A	90°C	95°C

Upgrading the Switch Firmware

In *Switch Remote Management*, firmware version numbers are provided as x.y, x.y.z, and x.y.z-w. Currently, these numbers are 1.3, 1.3.5, and 1.3.5-1 respectively. The following two procedures describe how to acquire and upgrade the firmware through the Oracle ILOM CLI.

Note – The switch must have version 1.1.3 firmware installed before the two following procedures can be used. Refer to *Switch Remote Management*, installing the firmware, for more information.

- “Acquire the Switch Firmware Package (CLI)” on page 8
- “Upgrade the Switch Firmware (CLI)” on page 10

▼ Acquire the Switch Firmware Package (CLI)

1. Open a web browser on a host that is on the same Ethernet network as the management controller to receive the firmware update.
2. Go to this URL.
<http://support.oracle.com>
Oracle’s My Oracle Support page is displayed.
3. Sign in if you already have an account.
The dashboard page is displayed.

Note – If you do not have an account, you must register.

4. From the More... drop-down menu, select Patches & Updates.

The Patches and Updates page is displayed.

5. In the Patch Search window, click the Search tab.

The Patch Search window updates.

6. Click the Product or Family (Advance) link.

The Patch Search window updates.

7. In the Product Is drop-down menu, select Sun Datacenter InfiniBand Switch 36.

**8. In the Release Is drop-down menu, select Sun Datacenter InfiniBand Switch 36
x.y.z.**

Where x.y.z is the version number of the firmware package to be acquired. For example, 1.3.5.

9. Click outside of the drop-down menu.

10. Click Search.

The Patch Search window expands with the search results.

11. In the Patch Name column, click the respective patch number link.

For example, 17567375. The Patch Search window reformats.

12. Click Read Me to display the README file.

13. Click Download.

The File Download window opens.

14. Click the *filename.zip* link to initiate the download.

For example, p17567375_135_Generic.zip.

15. Indicate where the file should be saved.

The file is downloaded and saved.

16. In your receiving directory, decompress the *filename.zip* file.

The firmware is in the SUN_DCS_36p_x.y.z.tar.gz file.

The readme file contains the latest information about the firmware release.

17. Unpack the .gz file:

```
$ gtar -zxvf SUN_DCS_36p_x.y.z.tar.gz
```

The extracted files are displayed.

18. Move the switch firmware package (*filename.pkg*) to a directory on a host that is accessible by Oracle ILOM.

19. Upgrade the switch firmware.

See “[Upgrade the Switch Firmware \(CLI\)](#)” on page 10 or *Switch Remote Administration*, upgrading the switch firmware.

▼ Upgrade the Switch Firmware (CLI)

1. Open an SSH session as user root and connect to the management controller by specifying the controller’s host name as configured with the DHCP server.

For example:

```
% ssh -l root switch_name
root@switch_name's password: password
#
```

where *switch_name* is the host name of the management controller. The name might be the word *hostname*. Initially, the *password* is *changeme*.

2. If the Subnet Manager is running on the management controller, disable it with the `disablesm` command.

```
# disablesm
Stopping partitiond daemon.                                [ OK ]
Stopping IB Subnet Manager..                            [ OK ]
#
```

3. Verify that there is at least 80 MB available in the / filesystem.

```
# df -h /
Filesystem      Size  Used Avail Use% Mounted on
/dev/hda2       471M  287M  161M  65%  /
#
```

In this example, there are 161 MB available. If not enough space is available, you must delete or move files from the / filesystem.

4. Verify that there is at least 120MB available in the /tmp directory.

```
# df -h /tmp
Filesystem           Size  Used Avail Use% Mounted on
tmpfs                250M  240K 249M  1% /tmp
#
```

In this example, there are 249 MB available. If not enough space is available, you must delete files from the /tmp directory.

5. Verify that there is at least 120 MB free memory available.

```
# free -m
      total        used        free      shared  buffers   cached
Mem:       498         104         393          0         12        47
-/+ buffers/cache:        45        453
Swap:        0          0          0
#
```

In the Mem: row of the free column, there should be at least 120 MB free memory. In this example, there are 393 MB available. If not enough memory is available, you must exit nonessential applications that are running.

6. Start the Oracle ILOM shell.

```
# spsh
Sun(TM) Integrated Lights Out Manager
Version ILOM 3.0 r47111
Copyright 2009 Sun Microsystems, Inc. All rights reserved.
Use is subject to license terms.
->
```

You are now in the Oracle ILOM shell.

You can use the exit command to return to the Linux shell.

7. Begin the upgrade process:

```
-> load -source URI/pkgnname
```

where:

URI is the uniform resource indicator for the host where the switch firmware package is located. The FTP and HTTP protocols are supported.

pkgnname is the name of the firmware package in the transfer directory.

For example, using the FTP protocol:

```
-> load -source
ftp://root:changeme@123.45.67.99//tmp/sundcs_36p_repository_1.3.5_1.pkg
Downloading firmware image. This will take a few minutes.
```

The firmware is downloaded. The upgrade begins. A warning is displayed, and you are asked to commit to the upgrade.

NOTE: Firmware upgrade will upgrade the SUN DCS 36p firmware.

ILOM will enter a special mode to load new firmware. No other tasks should be performed in ILOM until the firmware upgrade is complete.

Are you sure you want to load the specified file (y/n) ?

8. Answer **y** to the prompt to commit to the upgrade.

The upgrade begins.

```
Setting up environment for firmware upgrade. This will take approximately 2
minutes.
```

```
Starting SUN DCS 36p FW update
```

```
=====
Performing operation: I4 A
=====
```

```
I4 fw upgrade from 7.2.0(INI:1) to 7.2.300(INI:1):
```

```
Upgrade started...
```

```
Upgrade completed.
```

```
INFO: I4 fw upgrade from 7.2.0(INI:1) to 7.2.300(INI:1) succeeded
```

```
=====
Summary of Firmware update
=====
```

```
I4 status : FW UPDATE - SUCCESS
```

```
I4 update succeeded on : A
```

```
I4 already up-to-date on : none
```

```
I4 update failed on      : none  
=====  
Performing operation: SUN DCS 36p firmware update  
=====  
SUN DCS 36p fw upgrade from 1.1.3-2 to 1.3.5-1:  
Upgrade started...  
Upgrade completed.  
INFO: SUN DCS 36p fw upgrade from 1.1.3-2 to 1.3.5-1 succeeded  
  
Firmware update is complete.  
->
```

9. Exit the Oracle ILOM CLI shell.

```
-> exit  
exit  
#
```

10. Reboot the switch to enable the new firmware.

See *Switch Administration*, restarting the entire switch.

Note – The restart process takes between 4 to 5 minutes to complete. The Oracle ILOM stack requires at least 2 minutes to become operational after a reboot.

11. If previously disabled, log in as the root user and enable the Subnet Manager.

```
% ssh -l root nm2name  
root@nm2name's password: password  
# enablesm  
Starting IB Subnet Manager.          [    OK    ]  
Starting partitiond daemon.          [    OK    ]  
#
```

12. Verify the firmware version.

```
# version
SUN DCS 36p version: 1.3.5-1
Build time: Sep  3 2013 12:47:04
SP board info:
Manufacturing Date: 2011.01.11
Serial Number: "NCD680146"
Hardware Revision: 0x0006
Firmware Revision: 0x0000
BIOS version: SUN0R100
BIOS date: 06/22/2010
#
```

In the first line of the output is SUN DCS 36p version $x.y.z-w$, where $x.y.z-w$ is the version of the firmware upgraded (or downgraded). For example, 1.3.5-1.