

Sun Rack II

Getting Started Guide

This guide describes how to move and set up Oracle's Sun Rack II and provides safety guidelines you must follow when working with the rack. Refer to the *Sun Rack II User's Guide* for the complete rack installation and service procedures at:

<http://www.oracle.com/goto/SUNRACKII/docs>

For specific instructions on installing and cabling servers or equipment in the rack, refer to the equipment documentation.



Observing Safety Guidelines and Cautions

Read the Important Safety and Compliance documents.

Use professional movers when unpacking and installing this rack.

Follow the procedures in the Sun Rack II User's Guide and the Sun Rack II Power Distribution Units User's Guide.

When installing or servicing equipment in the rack, extend the antitilt legs and take antistatic precautions.

Load the heaviest items first from the bottom of the rack up. Secure each item before installing another item.

Ensure that the rack is adequately stabilized before servicing installed equipment, and extend only one piece of equipment out of the rack at a time.

Refer to the online documentation for additional safety guidelines and warnings.

▼ Move the Rack


- ◆ Push the rack from behind and use the rear casters to steer.



Caution – If you have installed equipment into the rack prior to moving it, avoid tipping or rocking the rack as it can fall over and cause serious injury and equipment damage.


▼ Lower the Leveling Feet

- ◆ Stabilize the rack by lowering the four leveling feet to the floor, by using a 12-mm wrench.




▼ Extend the Antitilt Legs

- ◆ Extend both antitilt legs located at the front of the rack first.



▼ Attach an Antistatic Wrist Strap

- ◆ Attach an antistatic wrist strap to an electrostatic discharge ground jack.



Related Documentation

Documentation	Links
All Oracle products	http://docs.oracle.com
Sun Rack II, 1042/1242	http://www.oracle.com/goto/SUNRACKII/docs

Feedback

Provide feedback on this document at: <http://www.oracle.com/goto/docfeedback>

Access to Oracle Support

Oracle customers have access to electronic support through My Oracle Support. For information visit <http://www.oracle.com/pls/topic/lookup?ctx=acc&id=info> or visit <http://www.oracle.com/pls/topic/lookup?ctx=acc&id=trs> if you are hearing impaired.



Part No.: E49141-01
Mfg No.: 7082692
June 2014

