



# Sun StorEdge™ 3900 and 6900 Series 2.0 Site Preparation Guide

---

Sun Microsystems, Inc.  
4150 Network Circle  
Santa Clara, CA 95054 U.S.A.  
650-960-1300

Part No. 816-5256-11  
March 2003, Revision A

Send comments about this document to: [docfeedback@sun.com](mailto:docfeedback@sun.com)

Copyright 2003 Sun Microsystems, Inc., 4150 Network Circle, Santa Clara, California 95054, U.S.A. All rights reserved.

Sun Microsystems, Inc. has intellectual property rights relating to technology embodied in the product that is described in this document. In particular, and without limitation, these intellectual property rights may include one or more of the U.S. patents listed at <http://www.sun.com/patents> and one or more additional patents or pending patent applications in the U.S. and in other countries.

This document and the product to which it pertains are distributed under licenses restricting their use, copying, distribution, and decompilation. No part of the product or of this document may be reproduced in any form by any means without prior written authorization of Sun and its licensors, if any.

Third-party software, including font technology, is copyrighted and licensed from Sun suppliers.

Parts of the product may be derived from Berkeley BSD systems, licensed from the University of California. UNIX is a registered trademark in the U.S. and in other countries, exclusively licensed through X/Open Company, Ltd.

Sun, Sun Microsystems, the Sun logo, AnswerBook2, docs.sun.com, UltraSPARC, Solstice Backup, Sun Professional Services, and Solaris are trademarks or registered trademarks of Sun Microsystems, Inc. in the U.S. and in other countries.

All SPARC trademarks are used under license and are trademarks or registered trademarks of SPARC International, Inc. in the U.S. and in other countries. Products bearing SPARC trademarks are based upon an architecture developed by Sun Microsystems, Inc.

The OPEN LOOK and Sun™ Graphical User Interface was developed by Sun Microsystems, Inc. for its users and licensees. Sun acknowledges the pioneering efforts of Xerox in researching and developing the concept of visual or graphical user interfaces for the computer industry. Sun holds a non-exclusive license from Xerox to the Xerox Graphical User Interface, which license also covers Sun's licensees who implement OPEN LOOK GUIs and otherwise comply with Sun's written license agreements.

U.S. Government Rights—Commercial use. Government users are subject to the Sun Microsystems, Inc. standard license agreement and applicable provisions of the FAR and its supplements.

DOCUMENTATION IS PROVIDED "AS IS" AND ALL EXPRESS OR IMPLIED CONDITIONS, REPRESENTATIONS AND WARRANTIES, INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE OR NON-INFRINGEMENT, ARE DISCLAIMED, EXCEPT TO THE EXTENT THAT SUCH DISCLAIMERS ARE HELD TO BE LEGALLY INVALID.

---

Copyright 2003 Sun Microsystems, Inc., 4150 Network Circle, Santa Clara, California 95054, Etats-Unis. Tous droits réservés.

Sun Microsystems, Inc. a les droits de propriété intellectuelle relatant à la technologie incorporée dans le produit qui est décrit dans ce document. En particulier, et sans la limitation, ces droits de propriété intellectuelle peuvent inclure un ou plus des brevets américains énumérés à <http://www.sun.com/patents> et un ou les brevets plus supplémentaires ou les applications de brevet en attente dans les Etats-Unis et dans les autres pays.

Ce produit ou document est protégé par un copyright et distribué avec des licences qui en restreignent l'utilisation, la copie, la distribution, et la décompilation. Aucune partie de ce produit ou document ne peut être reproduite sous aucune forme, par quelque moyen que ce soit, sans l'autorisation préalable et écrite de Sun et de ses bailleurs de licence, s'il y en a.

Le logiciel détenu par des tiers, et qui comprend la technologie relative aux polices de caractères, est protégé par un copyright et licencié par des fournisseurs de Sun.

Des parties de ce produit pourront être dérivées des systèmes Berkeley BSD licenciés par l'Université de Californie. UNIX est une marque déposée aux Etats-Unis et dans d'autres pays et licenciée exclusivement par X/Open Company, Ltd.

Sun, Sun Microsystems, le logo Sun, AnswerBook2, docs.sun.com, UltraSPARC, Solstice Backup, Sun Professional Services, et Solaris sont des marques de fabrique ou des marques déposées de Sun Microsystems, Inc. aux Etats-Unis et dans d'autres pays.

Toutes les marques SPARC sont utilisées sous licence et sont des marques de fabrique ou des marques déposées de SPARC International, Inc. aux Etats-Unis et dans d'autres pays. Les produits portant les marques SPARC sont basés sur une architecture développée par Sun Microsystems, Inc.

L'interface d'utilisation graphique OPEN LOOK et Sun™ a été développée par Sun Microsystems, Inc. pour ses utilisateurs et licenciés. Sun reconnaît les efforts de pionniers de Xerox pour la recherche et le développement du concept des interfaces d'utilisation visuelle ou graphique pour l'industrie de l'informatique. Sun détient une licence non exclusive de Xerox sur l'interface d'utilisation graphique Xerox, cette licence couvrant également les licenciées de Sun qui mettent en place l'interface d'utilisation graphique OPEN LOOK et qui en outre se conforment aux licences écrites de Sun.

LA DOCUMENTATION EST FOURNIE "EN L'ÉTAT" ET TOUTES AUTRES CONDITIONS, DECLARATIONS ET GARANTIES EXPRESSES OU TACITES SONT FORMELLEMENT EXCLUES, DANS LA MESURE AUTORISÉE PAR LA LOI APPLICABLE, Y COMPRIS NOTAMMENT TOUTE GARANTIE IMPLICITE RELATIVE A LA QUALITE MARCHANDE, A L'APTITUDE A UNE UTILISATION PARTICULIERE OU A L'ABSENCE DE CONTREFAÇON.



# Contents

---

Reference Material	2
Preinstallation Worksheet	2
Customer Obligations	4
Local Facility Safety	4
Handling Precautions	4
Secure Installation Requirements	5
Placement of a Sun Product	5
Facility Requirements	5
Environmental Specifications	6
Electrical and Power Specifications	7
Physical Dimensions	8
Clearance and Service Access	8
Cabling Requirements	9



# Site Preparation and Planning

---

This manual describes the facility planning requirements for installing a Sun StorEdge™ 3900 or 6900 series system.

To determine the total components and storage systems your shipment will include, consult your local Sun sales representative.

This document is organized as follows:

- “Reference Material” on page 2
- “Preinstallation Worksheet” on page 2
- “Customer Obligations” on page 4
- “Local Facility Safety” on page 4
- “Facility Requirements” on page 5
- “Cabling Requirements” on page 9

---

## Reference Material

Follow the guidelines as outlined in this document when planning your installation.

For a product overview and service procedures, refer to the *Sun StorEdge 3900 and 6900 Series 2.0 Reference and Service Manual*.

For installation instructions, refer to the *Sun StorEdge 3900 and 6900 Series Version 2.0 Installation Manual*.

This document and a broad selection of other Sun system documentation is located at the following web sites:

<http://docs.sun.com/documentation>

---

## Preinstallation Worksheet

This worksheet is for gathering and recording the information required to successfully install a Sun StorEdge 3900 or 6900 series system. Use this worksheet to preplan the data and Ethernet connections from the data host and Storage Service Processor.

---

**Note** – The number of IP addresses necessary for your installation depends on the configurations you select. See the *Sun StorEdge 3900 and 6900 Series 2.0 Reference and Service Manual* for the number of IP addresses necessary for each of the supported configurations.

---

Item	Management Host	Application Host	TFTP Host
Host ID			
Host name			
Host IP address			
Gateway IP address			
Array IP address			
Array name			
TFTP host address			
OS/patch revision level			
Primary application			
StorTools™ release			

**Legend:**

Required field	
Optional field	
Not applicable	

---

# Customer Obligations

The customer is obliged to inform Sun Microsystems, Inc. of any and all ordinances and regulations that affect the installation. The customer is responsible for meeting all government codes and regulations concerning facilities. The customer is also responsible for compliance with the following requirements:

1. All local, national, and international codes covered in this specification. The subjects covered include fire and safety, building, and electrical codes.
2. Document and inform Sun Microsystems, Inc. of any deviations from this specification.

---

# Local Facility Safety

Install the Sun StorEdge 3900 and 6900 series systems in accordance with the local safety codes and regulations at the facility site. Make sure you read the safety precautions in the *Sun StorEdge 3900 and 6900 Series 2.0 Regulatory and Safety Compliance Manual*. The following sections contain additional safety information for the local facility:

- “Handling Precautions” on page 4
- “Secure Installation Requirements” on page 5
- “Placement of a Sun Product” on page 5

---

**Note** – Do not make mechanical or electrical modifications to the equipment. Sun Microsystems, Inc. is not responsible for regulatory compliance of a modified Sun product.

---

---

# Handling Precautions



---

**Caution** – A fully configured storage system cabinet can weigh in excess of 1400 pounds (627 kg). Any floor that this system will cross must be able to withstand this load.

---



The cabinet is equipped with wheels so that you can move it. Use enough personnel when moving the cabinet, especially on sloping loading docks and ramps, to gain access to a raised computer room floor. Move the cabinet slowly and deliberately, and make sure the floor is free of foreign objects and cables that the cabinet could roll over.

All personnel who are moving the cabinet should wear protective footwear.

## Secure Installation Requirements

To minimize personal injury in the event of a seismic occurrence, you must securely fasten the cabinet to a rigid structure extending from the floor to the ceiling, or from the walls, of the room in which the cabinet is located.

Install the cabinet on a level surface. At each corner, on the base of the cabinet, there are adjustable nonskid pads. These must be extended when the cabinet is installed to prevent the cabinet from rolling. These pads are not to be used to level the cabinet.

## Placement of a Sun Product

If you have ordered a Sun StorEdge 3960 or 6960 series system without the second cabinet, make sure you allow enough room to install a second cabinet in the event that you want to expand your system.

Do not block or cover the openings of your Sun product. Never place a Sun product near a radiator or heat register. Failure to follow these guidelines can cause overheating and affect the reliability of your Sun product.

Air cools the Sun StorEdge 3900 and 6900 series cabinets from front to back. Air enters at the front, circulates, and is expelled at both the top and bottom rear of the unit. The front and rear door clearances provide sufficient space for cooling. See TABLE 5 for specific clearance specifications.

---

## Facility Requirements

These sections contain the following information about the facility requirements for the Sun StorEdge 3900 and 6900 series:

- “Environmental Specifications” on page 6
- “Electrical and Power Specifications” on page 7

- “Physical Dimensions” on page 8
- “Clearance and Service Access” on page 8

## Environmental Specifications

**TABLE 1** Facility Environmental Specifications

Specifications	Operating	Nonoperating
Temperature	41°F to 95°F (5°C to 35°C)	-41°F to 140°F (-20°C to 60°C)
Relative humidity	20% to 80% RH, noncondensing 80.6°F (27°C) maximum wet bulb	5 to 95% RH noncondensing with maximum gradient 10% per hour
Altitude	-1000 to 10,000 feet (-305 to 3,048 meters)	-1000 to 40,000 feet (-305 to 12,192 meters)

Avoid temperature extremes and keep the work area clean. Maintain the operating conditions described the following table. The storage system should be in a computer room environment that provides control over environmental factors such as temperature, humidity, and airborne dust. A computer room installation can also help protect equipment from fire, flood, or other danger originating in the building.

**TABLE 2** Facility Environmental Specifications

Environmental Factor	Ambient Temperature Range	Ambient Relative Humidity
Operating	70°F to 73.5° F (21°C to 23°C)	45% to 50%

The operating environmental limits in TABLE 1 reflect what the systems have been tested to, in order to meet all functional requirements. The optimum operating condition in TABLE 2 is the recommended operating environment. Operating computer equipment for extended periods of time at or near the temperature or humidity extremes is known to significantly increase the failure rate of hardware components. In order to minimize any chance of downtime due to component failure, it is strongly recommended that customers plan and use the optimal temperature and humidity ranges.

# Electrical and Power Specifications

All Sun StorEdge 3900 and 6900 series system require two independent power sources. Each storage system cabinet has two power conditioners (distribution) for redundancy, which are mounted in the base of the cabinet. To maintain the power redundancy, each conditioner must be connected to independent power sources. TABLE 3 lists the power required for *each* conditioner.

**TABLE 3** Power Specifications for the System Cabinet

Specification	Rating
AC voltage rating	200 to 240 VAC
AC voltage range	180 to 264 VAC
Frequency range	47 to 63 Hz
Current at 240 VAC	32A
Power consumption, maximum:	
• Sun StorEdge 3910 system	4.2 kW
• Sun StorEdge 3960 system	8.4 kW
• Sun StorEdge 6910 system	4.2 kW
• Sun StorEdge 6960 system	8.4 kW

The following is recommended for all installations:

- When specified by local, national, or other applicable government codes and regulations, you must have all AC mains and supply conductors to power distribution boxes for both the cabinet system and the desktop system enclosed in metal conduit. The supply conductors and power distribution boxes (or equivalent metal enclosure) must be grounded at both ends.
- The supplied storage systems require voltages within minimum fluctuation. The facilities voltage supplied by the customer/end user must maintain a voltage of not more than (+/-) 5%.
- The customer facilities must provide suitable surge protection.

# Physical Dimensions

**TABLE 4** Storage System Physical Specifications

Subsystem	Height	Width	Depth	Weight
Sun StorEdge 3900SL storage system single cabinet	75 in. 190.5 cm	23.9 in. 60.7 cm	37 in. 94 cm	1465 lb 665 kg
Sun StorEdge 3900SL storage system with expansion cabinet	75 in. 190.5 cm	47.8 in. 121.4 cm	37 in. 94 cm	2855 lb 1295 kg
Sun StorEdge 3910 storage system	75 in. 190.5 cm	23.9 in. 60.7 cm	37 in. 94 cm	1465 lb 665 kg
Sun StorEdge 3960 storage system	75 in. 190.5 cm	47.8 in. 122 cm	37 in. 94 cm	2855 lb 1295 kg
Sun StorEdge 6910 storage system	75 in. 190.5 cm	23.9 in. 60.7 cm	37 in. 94 cm	1210 lb 549 kg
Sun StorEdge 6910SL storage system	75 in. 190.5 cm	23.9 in. 60.7 cm	37 in. 94 cm	1210 lb 549 kg
Sun StorEdge 6960 storage system	75 in. 190.5 cm	47.8 in. 121.4 cm	37 in. 94 cm	2895 lb 1314 kg
Sun StorEdge 6960SL storage system	75 in. 190.5 cm	47.8 in. 121.4 cm	37 in. 94 cm	2895 lb 1314 kg
<b>Note:</b> The values given in this table are for the maximum hardware configuration available including the Sun StorEdge expansion cabinet in both the Sun StorEdge 3900SL, 3960, 6960, and 6960SL storage systems.				

## Clearance and Service Access

Side access can be required for some service procedures. Refer to the *Sun StorEdge 3900 and 6900 Series 2.0 Reference and Service Guide* for specific service procedures.

**TABLE 5** Clearance and Service Access for Sun StorEdge 3910 and 6910 Series

Location	For Service Access
Front	48 in. 122 cm

**TABLE 5** Clearance and Service Access for Sun StorEdge 3910 and 6910 Series

Location	For Service Access
Rear	36 in. 92 cm
Left	36 in. 92 cm
Right	36 in. 92 cm

## Cabling Requirements

This section contains the cabling requirements for the Sun StorEdge 3900 and 6900 series system. When cabling the system, make sure you follow these guidelines:

- Keep power and interface cables clear of foot traffic. Route cables inside walls, under the floor, through the ceiling, or in protective channels or raceways. Route interface cables (excluding fiber-optic cables) away from motors and other sources of magnetic or radio frequency interference.
- Do not exceed cable length limitations. The following table gives the cable specifications and lengths.

**TABLE 6** Cable Specifications

Cable Type	Connector	Maximum Length
Shielded Ethernet, 10/100BASE-T, category 5	RJ-45	328.084 ft. (100 m)
Serial (available only to qualified field service representatives)	RJ-45	82.021 ft. (25 m)
Power (220V)	Standard	n/a

The power cables are the standard ones shipped with the Sun StorEdge Expansion Cabinet. The cables that connect the two cabinets together are standard Fibre Channel cables.

