

# VCET API Manual

Viewing and Conversion Enabling Technology

**Copyright © 1989, 2008, Oracle and/or its affiliates. All rights reserved.**

Portions of this software Copyright 1996-2007 Glyph & Cog, LLC.

Portions of this software Copyright Unisearch Ltd, Australia.

Portions of this software are owned by Siemens PLM © 1986-2008. All rights reserved.

This software uses ACIS® software by Spatial Technology Inc. ACIS® Copyright © 1994-1999 Spatial Technology Inc. All rights reserved.

Oracle is a registered trademark of Oracle Corporation and/or its affiliates. Other names may be trademarks of their respective owners.

This software and related documentation are provided under a license agreement containing restrictions on use and disclosure and are protected by intellectual property laws. Except as expressly permitted in your license agreement or allowed by law, you may not use, copy, reproduce, translate, broadcast, modify, license, transmit, distribute, exhibit, perform, publish or display any part, in any form, or by any means. Reverse engineering, disassembly, or decompilation of this software, unless required by law for interoperability, is prohibited.

The information contained herein is subject to change without notice and is not warranted to be error-free. If you find any errors, please report them to us in writing.

If this software or related documentation is delivered to the U.S. Government or anyone licensing it on behalf of the U.S. Government, the following notice is applicable:

#### U.S. GOVERNMENT RIGHTS

Programs, software, databases, and related documentation and technical data delivered to U.S. Government customers are "commercial computer software" or "commercial technical data" pursuant to the applicable Federal Acquisition Regulation and agency-specific supplemental regulations. As such, the use, duplication, disclosure, modification, and adaptation shall be subject to the restrictions and license terms set forth in the applicable Government contract, and, to the extent applicable by the terms of the Government contract, the additional rights set forth in FAR 52.227-19, Commercial Computer Software License (December 2007). Oracle USA, Inc., 500 Oracle Parkway, Redwood City, CA 94065.

This software is developed for general use in a variety of information management applications. It is not developed or intended for use in any inherently dangerous applications, including applications which may create a risk of personal injury. If you use this software in dangerous applications, then you shall be responsible to take all appropriate fail-safe, backup, redundancy and other measures to ensure the safe use of this software. Oracle Corporation and its affiliates disclaim any liability for any damages caused by use of this software in dangerous applications.

This software and documentation may provide access to or information on content, products and services from third parties. Oracle Corporation and its affiliates are not responsible for and expressly disclaim all warranties of any kind with respect to third party content, products and services. Oracle Corporation and its affiliates will not be responsible for any loss, costs, or damages incurred due to your access to or use of third party content, products or services.

# Contents

<b>INTRODUCTION.....</b>	<b>7</b>
<b>Introduction .....</b>	<b>8</b>
About this Document.....	9
<b>OVERVIEW.....</b>	<b>14</b>
Overview.....	15
<b>FUNCTIONS .....</b>	<b>18</b>
Function Summary .....	19
Function Descriptions.....	20
PAN_LoadControls() .....	21
PAN_CreateControl() .....	22
PAN_FreeControls().....	24
PAN_GetCtlErrorCode() .....	25
Error codes .....	25
<b>MESSAGES.....</b>	<b>30</b>
<b>Structures and Unions used by Messages.....</b>	<b>31</b>
Structure Summary .....	31
Structure Descriptions .....	33
Command Message Summary .....	50
Purpose .....	50
Command Message Descriptions .....	54
Controls Command Messages .....	54
PM_CTLCLONECONTROL.....	54
PM_CTLDESTROY .....	55
PM_CTLGETCAPS .....	56
PM_CTLGETDIMS .....	58
PM_CTLGETFILE.....	59
PM_CTLGETFILEFMTS .....	60
PM_CTLGETFILETYPE.....	61
PM_CTLGETINFO.....	62
PM_CTLGETMODE .....	63
}PM_CTLGETOPTION.....	63
PM_CTLGETOPTION .....	64
PM_CTLGETSTATUS .....	65
PM_CTLREGEN.....	66
PM_CTLSETCAPS.....	67
PM_CTLSETFILE .....	69
PM_CTLSETFILEEX .....	70
PM_CTLSETMODE.....	74
PM_CTLSETOPTION .....	80
Image-Related Command Messages.....	81
PM_CTLCONVERT .....	81
PM_CTLFLIP.....	83
PM_CTLGETFLIP .....	84

PM_CTLGETROTATION .....	85
PM_CTLGETZOOM .....	86
PM_CTLPAINT, PM_CTLSIZE, PM_CTLHSCROLL, PM_CTLVSCROLL .....	87
PM_CTLROTATE .....	88
PM_CTLSETZOOM .....	89
Coordinates-Related Command Messages .....	90
PM_CTLCARETTOWORLD .....	90
PM_CTLCLEARSELS .....	91
PM_CTLCLIENTTOWORLD .....	92
PM_CTLGETCARETPOS .....	93
PM_CTLSETCARETPOS .....	94
PM_CTLWORLDTOCARET .....	95
PM_CTLWORLDTOCLIENT .....	96
PM_CTLXFRMRECT .....	97
PM_CTLCOPY .....	98
PM_CTLGETCLPBRDFMTS .....	99
PM_CTLGETNUMSELS .....	100
PM_CTLGETSELS .....	101
PM_CTLSETSEL .....	102
PM_CTLSETSELCARET .....	103
Color-Related Command Messages .....	104
PM_CTLGETFGBGCOLOR .....	104
PM_CTLGETPALETTE .....	105
PM_CTLPALETTECHANGED .....	106
PM_CTLQUERYNEWPALETTE .....	107
PM_CTLSETFGBGCOLOR .....	108
PM_CTLSETPALETTE .....	109
Views-Related Command Messages .....	110
PM_CTLGETVIEW .....	110
PM_CTLGETVIEWEXTENTS .....	111
PM_CTLGETVIEWNAMES .....	112
PM_CTLSETVIEW .....	113
PM_CTLSETVIEWEXTENTS .....	114
Blocks-Related Command Messages .....	115
PM_CTLGETBLOCK .....	115
PM_CTLGETBLOCKNAMES .....	116
PM_CTLSETBLOCK .....	117
Entity-Related Command Messages .....	118
PM_CTLGETENTITY .....	118
PM_CTLSHOWENTITY .....	119
Extended Image Data-Related Command Messages .....	120
PM_CTLGETIMAGEEX .....	120
PM_CTLSETIMAGEEX .....	121
Layers-Related Command Messages .....	122
PM_CTLGETLAYERSTATE .....	122
PM_CTLSETLAYERSTATE .....	123
XREF-Related Command Messages .....	124
PM_CTLGETXREFSTATE .....	124
PM_CTLSETXREFSTATE .....	125
Bookmark-Related Command Messages .....	126
PM_CTLGETBOOKMARKS .....	126
Resource-Related Command Messages .....	127
PM_CTLGETRESOURCEINFSTATE .....	127
Offset-Related Command Messages .....	128
PM_CTLGETOFFSET .....	128
PM_CTLSETOFFSET .....	129

Font-Related Command Messages .....	130
PM_CTLGETBASEFONT .....	130
PM_CTLSETBASEFONT .....	131
Database- and Spreadsheet-Related Messages .....	132
PM_CTLGETCOLWIDTH.....	132
PM_CTLGETROWHEIGHT .....	133
PM_CTLSORT.....	134
Page-Related Command Messages.....	135
PM_CTLGETNUMPAGES .....	135
PM_CTLGETPAGE.....	136
PM_CTLGETPAGESIZE .....	137
PM_CTLSETPAGE .....	138
Printing Command Messages .....	139
PM_CTLPRINT .....	139
PM_CTLPRINTPREVIEW.....	140
PM_CTLVALIDATEMARGINS .....	141
Text-Related Command Messages .....	142
PM_CTLGETSTRING.....	142
PM_CTLSEARCH .....	143
Mouse Command Messages .....	144
PM_CTLGETLMBACTION .....	144
PM_CTLSETLMBACTION .....	145
Device Context-Related Message.....	146
PM_CTLRENDERONTODC .....	146
Formatting Device Related Messages.....	147
PM_CTLSETDEVICE .....	147
PM_CTLGETDEVICE .....	148
Notification Messages Summary.....	149
Control Notification Messages .....	151
PNM_CTLDESTROY.....	151
PNM_CTLDROPFILE.....	152
PNM_CTLHELPSTRING.....	153
PNM_CTLSIZE.....	154
PNM_CTLSTATUS .....	155
Image Notification Messages .....	156
PNM_CTLPAINT .....	156
PNM_CTLREGEN.....	157
PNM_CTLSETFOCUS .....	158
PNM_CTLHSCROLL, PNM_CTLVSCROLL.....	159
Printing Notification Messages.....	160
PNM_CTLPRINT .....	160
PNM_CTLPRINTINGPAGE .....	161
PNM_CTLPRINTPROCESSINGPAGE.....	162
Clipboard-Related Notification Message.....	163
PNM_CTLSETSEL.....	163
PNM_CTLRENDERSEL .....	164
Archive-, Database- and Spreadsheet-Specific Notification Messages .....	165
PNM_CTLARCFILE .....	165
PNM_CTLCOLWIDTH.....	166
PNM_CTLROWHEIGHT.....	167
OLE-Related Notification Message.....	168
PNM_CTLOBJECT .....	168
Link-Related Notification Message .....	169
PNM_CTLLINK .....	169
Views-Related Notification Message .....	170
PNM_CTLSETVIEWEXTENTS.....	170

---

<b>Appendix A: Configuration Options .....</b>	<b>171</b>
<b>INDEX .....</b>	<b>175</b>
<b>Index .....</b>	<b>176</b>

# Introduction

# Introduction

---

If your application requires file viewing, printing or conversion, then you need CSI's Multi-format Controls. They provide the most effective way to get your MS-Windows product to market sooner and at lower cost.

Your development team will be able to focus on the functionality of your application, rather than the time consuming (and expensive) coding, testing and debugging needed to support an ever-changing landscape of file types and formats.

CSI has Multi-format Controls to meet all your file viewing, printing and conversion needs, with support for a large number of file formats in the following categories:

- ☐ Word Processors
- ☐ Raster Graphics
- ☐ Spreadsheets
- ☐ Vector Graphics
- ☐ Databases
- ☐ Compressed Files

Their efficient high-level interface makes these controls easy to integrate into your product. They allow your application to:

- ☐ Perform text search and highlighting.
- ☐ View all or part of a file, pan and zoom.
- ☐ Print all or part of a file, with many options.
- ☐ Convert files, with many options.
- ☐ Copy all or part of a file to the clipboard.
- ☐ And more...

And CSI's Multi-format Controls do not rely on filename extensions to determine file type, but rather on file structure. For example, if you name a raster graphics file MY\_FILE.ABC, the control will recognize the file's format ( BMP, PCX, TIFF, GIF, etc.) and treat it accordingly.

CSI's Multi-format Controls can make use of our extensive range of import and export filters, which we are continually updating and expanding. We also provide the tools to add additional file formats. And since new filters are automatically recognized, you won't have to recompile your source code to use them.

## ***Possible applications include:***

- ☐ File viewing utilities.
- ☐ Document management software. Software that manages a large variety of files, provides viewing ability, and possibly indexing.
- ☐ Fax related software that requires the conversion of various files to a common fax format.
- ☐ E-Mail related software, requiring that a large variety of files be distributed electronically and accessed by many users.
- ☐ Other possible areas:
  - CD-ROM
  - Multimedia
  - Peripheral Manufacturers, i.e., printers, scanners, fax cards, etc.




## About this Document

---


This document is designed to give the programmer a quick start with the **CSI Multi-format Controls API**. It contains detailed descriptions of the various functions and messages, as well as summaries of these in order to facilitate lookup. This information is also available in the demo program's online help, which can be accessed separately via *winhelp.exe*.

Please refer to the "README.TXT" file for the latest information about the Multi-format Controls.


*Here are some of the things that you can do with the controls.*




Perform a text search in a word processor file.



Display CAD files normally...



... or zoom in or out.



Display bitmaps normally...



... or zoom in or out.

INVEST.WKS						
	A	B	C	D	E	F
1	Investment Model					
2						
3		Before	After	Annual		
4		tax	tax	asset	Amount	Percent
5	Asset	yield	yield	apprec.	invested	invested
6						
7	Stocks	3.20%	2.27%	9.00%	\$16,000	20.00%
8	Taxable bonds	8.80%	6.44%	3.76%	\$16,000	20.00%
9	Tax-exempt bonds	7.40%	7.80%	2.66%	\$16,000	20.00%
10	Money market	8.80%	6.23%	.00%	\$40,000	40.00%
11						
12	Total				\$96,000	100.00%
13						
14	Total return (we				10.80%	
15						
16						
17	Comments					

Select areas in a spreadsheet or database and copy to the clipboard.

TEST.ZIP						
32020	Implode	20471	37%	11-23-87	08:50	COLUMBIA.DWG
5896	Implode	2183	63%	06-17-93	10:01	INVEST.WKS
132355	Stored	132355	0%	11-28-91	03:10	ASTR.GIF
51200	Implode	15193	71%	01-07-93	04:15	CEL.SCR


View the contents of archives.

## Memo

Research 1, 1995

R.E.: Custom Controls

Copyright 1995 by R.E. Inc. All Rights Reserved. No part of this document may be reproduced without permission in writing from R.E. Inc. This document is the property of R.E. Inc. and is loaned to you for your use only. It is not to be distributed, copied, or otherwise used in any way without the written permission of R.E. Inc.



	A	B	C	D	E
1					
2	100.32		44.1		411
3	253.21		44.1		774
4	523.33		58.1		741
5	45.22		44.1		711
6	88.84		88.1		85
7	172.35		72.1		555

Several controls rendering their contents to a display context for viewing or printing.

# Overview

## Overview

---


**CSI's Multi-format Controls** enable an application to easily display, print or convert the contents of a given file. There are six types of controls: raster, vector, document, database, spreadsheet, and archive, each capable of handling a specific class of file formats. Depending on how a control is created, it may or may not directly manage resize, scroll, mouse, and keyboard events. Once a control has been created, an application communicates with it using the handle of the control window and a set of messages by calling the Windows functions **SendMessage()** and **PostMessage()**.

There are control-specific messages to perform such tasks as obtaining information about a control, enabling and disabling certain capabilities of a control, making a copy of a control, displaying given portions of a file in a control window, copying given portions of a file to the clipboard, searching for a string in a given file and highlighting the result, converting from client to world coordinates and vice versa, printing given portions of a file, etc. There are also messages to render given portions of a file onto a device context or metafile.

Some newer messages include C++ classes such as STL containers, Boost smart pointers and VCET interfaces. Whenever these messages are used, the application should have access to the C++ Standard Template Library and to the Boost C++ Libraries version 1.34.1 (may need to be installed separately).

The process structure is outlined in the following pages.

## Process Structure



**Please refer to the diagram on the preceding page for the discussion that follows:**

A single function call will provide your application with a control it can interact with via a powerful set of command and notification messages. These messages make up the bulk of the Application Programming Interface (API) for the controls. The remainder consists of the control creation function mentioned above, as well as a function to retrieve the last error code.

The control itself is made up of six cores, one for each type of file (word processor, spreadsheet, database, raster graphic, vector graphic, and archive). Each core has viewing, printing, clipboard transfer, and conversion capabilities. Which of the cores is active is determined by the type of file being processed.

The controls read in files through the Import Filter Interface. Import filters, i.e., the File Format Decoders, are individual Dynamic Link Libraries (DLLs), each one specific to a particular file format.



We have included the specifications for this interface within these documents. These specifications allow you to write your own File Format Decoders, which are also compatible with our retail product. Please refer to the PAFS (PANORAMIC! Additional Format Support) section of this document for more information.

The conversion process includes the ability to perform image processing prior to conversion. Capabilities include, but are not limited to, brightness adjustment, contrast adjustment, and gamma correction. A Palette Selection Manager provides for several palette selection methods (expandable).

The number of color reduction methods is also expandable via the Color Reduction Manager.

The conversion itself is achieved through the Export Filter Interface, which makes use of the various File Format Encoder DLLs at its disposal.

# Functions

---

## Function Summary

---

<i>Function Name</i>	<i>Purpose</i>
PAN_CreateControl()	Creates a CSI Multi-format Control.
PAN_FreeControls()	Unloads the CSI Multi-format Control DLLs.
PAN_GetCtlErrorCode()	Returns the error code of the last error.
PAN_LoadControls()	Loads the CSI Multi-format Control DLLs.

---

## Function Descriptions

---

This section provides detailed information on all of the available functions. It includes the function's purpose, syntax, description, what parameters are expected and what values are returned.

### Remarks

An application using the CSI Multi-format Controls should call **PAN\_LoadControls()** once at the start of the execution of the program, and make a single call to **PAN\_FreeControls()** when the program is terminating. While executing, the application uses **PAN\_CreateControl()** to create controls, and sends **PM\_CTLDESTROY** messages followed by **DestroyWindow** (with the handle of the control window as a parameter) calls to remove controls.

A control is not visible immediately after being created, therefore an application can perform any initialization operations on the control before making it visible. To make the control visible, the Windows function **ShowWindow()** is called with the handle of the control window as the first parameter.

A control must be destroyed using the Windows function **DestroyWindow()** with the handle of the control window as the parameter, but only after it has been given a chance to clean up its internal data structures through the sending of a **PM\_CTLDESTROY** message.

**PAN\_LoadControls()**

<b>Purpose</b>	Loads the CSI Multi-format Control DLLs.
<b>Syntax</b>	<b>int PAN_LoadControls(LPCSTR <i>szInifile</i>                           DWORD <i>dwReserved</i>);</b>
<b>Description</b>	The facilities of the CSI Multi-format Controls are provided by a number of dynamically linked libraries. This function, called by the application program, ensures that all the DLLs are made available and are initialized correctly.
<b>Parameters</b>	<p><i>szInifile</i> specifies the initialization file which the controls will use to store and retrieve private information. If <b>NULL</b>, the controls will use pctl.ini.</p> <p><i>dwReserved</i> is a special variable which must be set to zero (0).</p>
<b>Returns</b>	This function returns <b>TRUE</b> if the libraries were successfully loaded, <b>FALSE</b> otherwise..
<b>Example</b>	This code fragment loads the controls.

```
#include "pctl.h"

BOOL LoadOk;           // Boolean indicating if Multi-format
                        // Controls loaded successfully.

int PASCAL WinMain(HINSTANCE hInst, ...)
{
    // Load controls.
    bLoadOk = PAN_LoadControls();

    if (!bLoadOk) {return (0);}

    // Main message loop.
}
```

**PAN\_CreateControl()**

**Purpose** Creates a CSI Multi-format Control.

**Syntax** **HWND PAN\_CreateControl(**  
                   **HWND**          *hwnd*,  
                   **WORD**          *ctlID*,  
                   **LPRECT**        *ctlRect*,  
                   **FARPROC**      *ctlConsumeProc*,  
                   **WNDPROC**      *ctlNotifyProc*);

**Description**

**Parameters** *hwnd* Window handle.

If *hwnd* is **NULL**, *ctlID* is ignored and a stand-alone window of the given size is created (see *CtlRect*). Otherwise, if *ctlID* is greater than zero, a child window of the given size (see *CtlRect* is created). The control manages all resize, scroll, mouse, and keyboard events unless instructed otherwise. See description for **PM\_CTLGETCAPS** and **PM\_CTLSETCAPS**.

Whether or not a control manages resize, scroll, mouse, and keyboard events directly, the API provides control-specific messages to perform such operations.

*ctlID* Control ID. Must be unique for each child control of a given application parent window. See description for *hwnd*.

*ctlRect* Control window rectangle. Specifies origin and extents (left, top, right, bottom) in client coordinates for child windows and in screen coordinates for stand-alone windows.

*ctlConsumeProc* Pointer to procedure.

If *ctlConsumeProc* is not **NULL**, it must be a pointer, obtained using the Windows function **MakeProcInstance()**, to a procedure which will be called by the control during processing in order to yield to other Windows tasks. Within this procedure, the calling application should call the Windows function **PeekMessage()** to remove events from the Windows message queue and then translate/dispatch those messages using the Windows functions **TranslateMessage()** and **DispatchMessage()**. The application can also handle any accelerator key messages by calling the appropriate Windows functions.

*ctlNotifyProc* Pointer to window procedure.

If *ctlNotifyProc* is not **NULL**, it must be a pointer obtained using the Windows function **MakeProcInstance()** to a window procedure which will receive all control notification messages. The **HWND** parameter contains the handle of the control window sending the message and the **UINT** parameter contains the notification message. The **WORD** and **LONG** parameters are used to send message-dependent information.

**Returns** This function returns a handle to the control window on success or **NULL** on failure.

**Example** This code fragment creates a control, sets it up, and then displays it.

```
#include "pctl.h"

HWND hControlWnd;           //Stores the handle to the control.
RECT  CtlRect;              // Size of the control.

SetRect( &CtlRect, 0,0,400,400);

// Create a basic control in a stand-alone window.
hControlWnd=PAN_CreateControl(
    NULL, 1, &CtlRect, NULL, NULL);

// setup the control.
// ...

// Show the control.
ShowWindow( hControlWnd, SW_SHOWNNA);
```

**PAN\_FreeControls()**

<b>Purpose</b>	Unloads the CSI Multi-format Control DLLs.
<b>Syntax</b>	<b>int PAN_FreeControls(void);</b>
<b>Description</b>	Removes the CSI Multi-format Controls from memory. Called by the application before it terminates.
<b>Returns</b>	This function returns <b>TRUE</b> if the libraries were unloaded, <b>FALSE</b> if the data structures required to free them were unavailable..

**Example** This code fragment demonstrates the unloading of the controls, .

```
#include "pctl.h"

BOOL bLoadOk;          // Boolean indicating if Multi-format Controls
                        // loaded successfully.

int PASCAL WinMain(HINSTANCE hInst, ...)
{
    // Load controls.
    bLoadOk = PAN_LoadControls();

    if (!bLoadOk) {
        return (0);
    }

    // Main message loop.
    while (GetMessage(&msg, NULL, 0, 0)) {
        ...
        TranslateMessage(&msg);
        DispatchMessage(&msg);
    }

    PAN_UnloadControls();
}
```



**PAN\_GetCtlErrorCode()**

<b>Purpose</b>	Returns the error code of the last error.
<b>Syntax</b>	<b>int PAN_GetCtlErrorCode(void);</b>
<b>Description</b>	All control-specific error codes begin with the prefix <b>PAN_CTLERR</b> .
<b>Parameters</b>	None.
<b>Returns</b>	Error code of last error (see list below).
<b>Example</b>	This code fragment verifies that no error occurred on the last operation.

```
int    ErrCode;

ErrCode = PAN_GetCtlErrorCode();

if (ErrCode == PAN_CTLERRNONE)
    MessageBox( HWindow, "no errors", "Error Code", MB_OK);
```

## Error codes

**PAN\_CTLERRALREADYINSTALLED**

"Control library already installed."

INTERNAL ERROR: The control library cannot continue because it is already installed.

**PAN\_CTLERRBADCAPS**

"Bad control capability."

The control library encountered an invalid capability.

**PAN\_CTLERRBADCLPBRDFMT**

"Bad Clipboard Format."

The parent application has supplied an invalid clipboard format.

**PAN\_CTLERRBADCTLTYPE**

"Bad control type."

INTERNAL ERROR: The control library encountered an invalid format class.

**PAN\_CTLERRBADDATA**

"Bad data."

INTERNAL ERROR: The control library encountered invalid data.

**PAN\_CTLERRBADINSTANCE**

"Bad instance handle."

INTERNAL ERROR: The control library encountered an invalid instance handle.

**PAN\_CTLERRBADLMBACTION**

"Bad Mouse Action."

The parent application has supplied an invalid mouse action.

**PAN\_CTLERRBADLPARAM**

"Bad **LONG** message parameter."

The last API message invoked by the parent application was passed an invalid **LONG** parameter.

**PAN\_CTLERRBADMESSAGE**

"Bad control message."

The control library encountered an invalid message.

**PAN\_CTLERRBADMODE**

"Bad control mode."

The parent application has supplied an invalid control mode (**PAN\_CTLMODE...**) to an API function or message.

**PAN\_CTLERRBADPARAM**

"Bad function parameter."

The last API function or message invoked by the parent application was passed an invalid parameter.

**PAN\_CTLERRBADWINDOW**

"Bad window handle."

The control library encountered an invalid window handle.

**PAN\_CTLERRBADWPARAM**

"Bad **WORD** message parameter."

The last API message invoked by the parent application was passed an invalid **WORD** parameter.

**PAN\_CTLERRCANNOTADDCTLDATA**

"Cannot add control data."

INTERNAL ERROR: The control library encountered an error while initializing control-specific data.

**PAN\_CTLERRCANNOTALLOCMEM**

"Cannot allocate memory."

INTERNAL ERROR: The control library encountered an error while allocating memory with the Windows **GlobalAlloc** function.

**PAN\_CTLERRCANNOTBEGINFILE**

"Cannot Begin file."

INTERNAL ERROR: A decoder DLL encountered an error while initializing prior to processing a portion of a file.

**PAN\_CTLERRCANNOTCONFIGURETABLE**

"Cannot configure table."

INTERNAL ERROR: The control library encountered a problem while configuring a data table.

**PAN\_CTLERRCANNOTCREATECONTROL**

"Cannot create control."

INTERNAL ERROR: The control library encountered a problem while creating a control.

**PAN\_CTLERRCANNOTCREATECTLDATA**

"Cannot create control data."

INTERNAL ERROR: The control library cannot create control-specific data.

**PAN\_CTLERRCANNOTCREATEDC**

"Cannot create device context."

INTERNAL ERROR: The control library encountered an error while creating a device context with the Windows **CreateDC** function.

**PAN\_CTLERRCANNOTCREATEMETAFILE**

"Cannot Create Metafile."

INTERNAL ERROR: The control library encountered a problem while creating a metafile with the Windows **CreateMetafile** function.

**PAN\_CTLERRCANNOTCREATEOBJECT**

"Cannot create GDI object."

INTERNAL ERROR: The control library encountered an error while creating a Windows GDI object.

**PAN\_CTLERRCANNOTCREATEPALETTE**

"Cannot create palette."

INTERNAL ERROR: The control library encountered an error while creating a Windows palette.

**PAN\_CTLERRCANNOTCREATEWINDOW**

"Cannot create window."

INTERNAL ERROR: The control library encountered a problem while creating a window with the Windows **CreateWindow** function.

**PAN\_CTLERRCANNOTENDFILE**

"Cannot End file."

INTERNAL ERROR: A decoder DLL encountered an error while cleaning up after processing a portion of a file.

**PAN\_CTLERRCANNOTFINDCTLDATA**

"Cannot find control data."

INTERNAL ERROR: The control library cannot find control-specific data.

**PAN\_CTLERRCANNOTFINDDLL**

"Cannot find support DLL."

INTERNAL ERROR: The control library cannot find one of its support DLLs.

**PAN\_CTLERRCANNOTGETDC**

"Cannot get device context."

INTERNAL ERROR: The control library cannot obtain the handle of a device context using the Windows **GetDC** or **BeginPaint** functions.

**PAN\_CTLERRCANNOTGETPROCADDRESS**

"Cannot get procedure address."

INTERNAL ERROR: The control library encountered a problem while fetching the address of a DLL procedure with the Windows **GetProcAddress** function.

**PAN\_CTLERRCANNOTINITTEXT**

"Cannot initialize text"

INTERNAL ERROR: The control library encountered an error while trying to initialize text support.

**PAN\_CTLERRCANNOTLOADDLL**

"Cannot load support DLL."

INTERNAL ERROR: The control library encountered a problem while loading one of its support DLLs.

**PAN\_CTLERRCANNOTLOCKCTLDATA**

"Cannot lock control data."

INTERNAL ERROR: The control library cannot lock control-specific data with the Windows **GlobalLock** function.

**PAN\_CTLERRCANNOTLOCKMEM**

"Cannot lock memory."

INTERNAL ERROR: The control library encountered a problem while locking memory with the Windows **GlobalLock** function.

**PAN\_CTLERRCANNOTMAKEPROCINSTANCE**

"Cannot make procedure instance."

INTERNAL ERROR: The control library encountered a problem while making a procedure instance with the Windows **MakeProcInstance** function.

**PAN\_CTLERRCANNOTOPENCLIPBOARD**

"Cannot Open Clipboard."

INTERNAL ERROR: The control library is unable to open the clipboard

**PAN\_CTLERRCANNOTPROCESSFILE**

"Cannot Process file."

INTERNAL ERROR: A decoder DLL encountered an error while processing a file.

**PAN\_CTLERRCANNOTQUERYFILE**

"Cannot Query file."

INTERNAL ERROR: A decoder DLL encountered an error while initializing prior to processing a file.

**PAN\_CTLERRCANNOTREGISTERCLASS**

"Cannot register window class."

INTERNAL ERROR: The control library encountered a problem while registering a window class with the Windows **RegisterClass** function.

**PAN\_CTLERRCANNOTTERMINATEFILE**

"Cannot Terminate file."

INTERNAL ERROR: A decoder DLL encountered an error while cleaning up after processing a file.

**PAN\_CTLERRDLLFAILED**

"Support DLL failed."

INTERNAL ERROR: One of the support DLLs of the control library encountered an error and cannot continue.

**PAN\_CTLERRINTERNAL**

"Internal error"

INTERNAL ERROR: The control library encountered an error during processing.

**PAN\_CTLERRMISC**

"Undefined error."

An undefined error has occurred.

**PAN\_CTLERRNOBLOCK**

"No blocks found"

The parent application requested a block to be displayed, but no blocks exist for the current page.

**PAN\_CTLERRNOFILESET**

"No file set."

The last API function or message invoked by the parent application required a file to have been set, but none was found.

**PAN\_CTLERRNOLAYERS**

"No layers found"

The parent application requested a layer state to be set, but no layers exist for the page.

**PAN\_CTLERRNONE**

"No error."

No error has occurred.

**PAN\_CTLERRNOSELSET**

"No Selection Set."

There is nothing selected in the control.

**PAN\_CTLERRNOTCOMPATIBLE**

"Function or message not compatible."

The last API function or message invoked by the parent application is not compatible with the format class of the currently loaded file.

**PAN\_CTLERRNOTIMPLEMENTED**

"Function or message not yet implemented."

The last API function or message invoked by the parent application is not yet implemented.

**PAN\_CTLERRNOTINSTALLED**

"Control library not installed."

INTERNAL ERROR: The control library cannot continue because it was not successfully installed.

**PAN\_CTLERRNOTSUPPORTED**

"Control type not supported."

The control library encountered an unsupported format class.

**PAN\_CTLERRNOVIEW**

"No views found"

The parent application attempted to get or set a view, but no views exist for the current page.

**PAN\_CTLERRNOXREFS**

"No XRefs found"

The parent application attempted to set the XRef state, but no XRefs exist for the current page.

# Messages

All control-specific messages begin with either the prefix **PM\_CTL** for command messages, or **PNM\_CTL** for notification messages, and use the Windows message calling convention. All command messages return an indication of success or failure, except where noted. The function **PAN\_GetCtlErrorCode()** can also be used to obtain the error code of the last error.

## Structures and Unions used by Messages

The use of coordinates has been considerably changed from previous versions of the controls. Under version 1.2, all view coordinates are in units that can be used for display and rendering purposes. In previous versions, textual classes used coordinates that were character offset based, which could not easily be used for viewing and printing operations. In version 1.2, all view coordinates for textual classes (archive, database, document, spreadsheet) are in terms of **TWIPS** (twentieth of a point). Raster units remain in pixels, while the vector control retains the use of arbitrary units.

Textual operations that work in terms of a text stream, such as searching, are provided with the new caret based coordinate system. This is similar to the “world” coordinates for document files provided in previous versions of the controls, but has the addition of a “flow” identifier. This field is used to distinguish between the different text flows that can be displayed on the same page in version 1.2.

Converting coordinates between the two coordinate systems can be performed using the new **PM\_CTLCARETTOWORLD** and **PM\_CTLWORLDTOCARET** messages.

A third type of coordinate exists for tabular format classes (archive, database, spreadsheet) that is specified in terms of rows and columns. No operations explicitly exist that use these coordinates, as they can be performed in either of the previously described coordinate systems. A single message, **PM\_CTLGETDIMS**, is available to determine the dimensions of a control in terms of rows and columns.

## Structure Summary

Structure Name	Used by
struct PAN_BOOKMARK	PAN_CTLGETBOOKMARKS
struct PAN_BLOCK	PM_CTLGETBLOCKNAMES messagePAN_CTLGETBLOCKNAMES
struct PAN_CtlCaretPos	PAN_CtlSearchInfo structure
	PM_CARETTOWORLD message
	PM_WORLDTOCARET message
struct PAN_CtlClpbrdFmt	PAN_CtlClpbrdFmtList structure
struct PAN_CtlClpbrdFmtList	PM_CTLGETCLPBRDFMTS message
struct PAN_CtlDimensions	PM_CTLGETDIMS message
struct PAN_CtlEntityInfo	PM_CTLGETENTITY message
	PAN_CtlGetEntityInfo structure
struct PAN_CtlFileFmt	PAN_CtlFileFmtList structure
struct PAN_CtlFileFmtList	PM_CTLGETFILEFMTS message
struct PAN_CtlFileInfo	PM_CTLGETFILE message
struct PAN_CtlGetEntityInfo	PM_CTLGETENTITY message
struct PAN_CtlHandle	PM_CTLGETENTITY message
	PAN_CtlSearchInfo structure
	PAN_CtlEntity structure

	PAN_CtlGetEntityInfo structure
struct PAN_CtlInfo	PM_CTLGETINFO message
struct PAN_CtlPos	PAN_CtlFileInfo structure
	PAN_CtlPrintOptions
	PM_CTLSEARCH message
	PM_CTLCLIENTTOWORLD message
	PM_CTLWORLDTOCLIENT message
	PM_GETOFFSET message
	PM_SETOFFSET message
struct PAN_CtlPrintOptions	PM_CTLVALIDATEMARGINS message
	PM_CTLPRINTPREVIEW message
	PM_CTLPRINT message
struct PAN_CtlPrintPreview	PAN_CtlPrintOptions structure
struct PAN_CtlRange	PAN_CtlSel structure
	PM_CTLGETPAGESIZE message
	PM_CTLSETSEL message
	PM_CTLGETVIEWEXTENTS message
	PM_CTLSETVIEWEXTENTS message
	PM_XFRMRECT message
	PNM_CTLSETVIEWEXTENTS notification message
struct PAN_CtlRenderOptions	PM_CTLRENDERONTODC message
struct PAN_CtlSearchInfo	PM_CTLSEARCH message
struct PAN_CtlSel	PAN_CtlSelList structure
struct PAN_CtlSelList	PM_CTLGETSELS message
struct PAN_CtlShowEntity	PM_CTLSHOWENTITY message
struct PAN_LAYER	PM_CTLGETLAYERSTATE message PM_CTLSETLAYERSTATE message
class IResourceContextInfo	PM_CTLSETFILEEX message
class IPanResourceInfo	PM_CTLSETFILEEX message
function LocateProc	PM_CTLSETFILEEX message
struct PanUserResourceLocate	PM_CTLSETFILEEX message
struct PAN_CtlSetFile	PM_CTLSETFILEEX message
struct PAN_XREF	PM_CTLGETXREFSTATE and PM_CTLSETXREFSTATE messages
struct ResourceInfo	PM_CTLGETRESOURCEINFOSTATE
class IGetResourceInfo	PM_CTLGETRESOURCEINFOSTATE



## Structure Descriptions

---

```

typedef struct {
    unsigned int ID;           // Bookmark information.
                                // OUT: Any application defined ID (It depends on
                                // the formats).
    int level;                 // OUT: Depth level of this bookmark tree (0 := root)
    int fState;                // OUT: State of the bookmark node in bookmark tree.
                                // (0:= closed, 1:= expanded, 2:= leaf)
    wchar_t name[_Max_PATH];  // OUT: Descriptive name of bookmark node.
    char target[1024];         // OUT: Target destination of this bookmark holding
                                // bookmark commands. We support many types of
                                // commands in the target destination of a bookmark
                                // structure. This is the complete list of them:

    // Switch to another page PAGE=<index>
    // <index> - Page index (start from 1)
    // E.g.: "PAGE=2"

    // Link to external file DOC=<Doc name>
    // <Doc name> - file name, the application will launch // a new child frame for
    // this document.
    // E.g.: Local file: "DOC=file.dwg"
    //          URL: "DOC=\"http://www.cimmetry.com/file.dwg\""
    //          or  "DOC=http://www.cimmetry.com/file.dwg"
    //          (without quotes)

    // Set offset POS=<x>,<y>
    // <x> - double value for x offset
    // <y> - double value for y offset
    // E.g.: "POS=10.0,15.0"

    // Set view extents RANGE=<minX>,<minY>,<maxX>,<maxY>
    // <minX> - min. X of view extents
    // <minY> - min. Y of view extents
    // <maxX> - max. X of view extents
    // <maxY> - max. Y of view extents
    // E.g.: "RANGE=-2.0,0.0,10.0,12.0"

    // Set rotation ROTATE=<rotDeg>
    // <rotDeg> - rotation angle in degree
    // E.g.: "ROTATE=90"

    // Set flip FLIP=<type>
    // <type> - type of flipping
    // E.g.: X flip: "FLIP=X"
    //          Y flip: "FLIP=Y"
    //          Flip both: "FLIP=XY"

    // Set zoom ZOOM=<value>
    // <value> - zoom level
    // E.g.: "ZOOM=10.0"

    // Execute an external command APPLICATION=<CmdLine>
    // <CmdLine> - command line to execute

```

```

// E.g.: "APPLICATION=c:\dev\bin32s\avwin.exe"

// Do zoom fit    e.g. "FIT"

// Set Views      VIEW=<index>
// <index> - View index
// E.g.: "VIEW=1"

// Set Views ( by name ) VIEWNAME=<name>
// <name> - name of the view ( listed in the views dialog )
// E.g.: "VIEWNAME=topview"

// Set Page ( by title )   PAGETITLE=<title>
// <title> - title of the page ( listed in the bookmark tree )
// E.g.: "PAGETITLE=Layout1"

// Display Note ( using tooltip )
// NOTE=Subject0x02<Subject>0x01
//       Author0x02<Author>0x01
//       Modified0x02<Time Date>0x01
//       Notes0x02<Notes>

// "seperator" is represented by 0x01
// "is equal to" is represented by 0x02

} PAN_BOOKMARK;

typedef struct PAN_BLOCK{           // Block information.
    unsigned int    id;
    char            name[80];
} PAN_BLOCK;

typedef struct PAN_CtlPos {         // View coordinates.
    Double x, y, z;
} PAN_CtlPos;

typedef struct PAN_CtlRange {       // View range.
    Struct PAN_CtlPos    min;
    struct PAN_CtlPos    max;
} PAN_CtlRange;

typedef struct PAN_CtlCaretPos {    // Caret position coordinate.
    Int                page;
    DWORD              flow;
    DWORD              offset;
} PAN_CtlCaretPos;

```

```
typedef struct PAN_CtlCaretRange {           // Caret-based range.
    Struct PAN_CtlCaretPos  from;
    struct PAN_CtlCaretPos  to;
} PAN_CtlCaretRange;

typedef struct PAN_CtlDimensions {           // Dimensions of Spreadsheet,
    int                     DimWidth;        // Database, or Archive (rows &
    int                     DimHeight;       // columns)
    int                     DimDepth;
} PAN_CtlDimensions;

struct PAN_CtlInfo {
    PAN_FileType            type;           // OUT: type of control
    WORD                    version;       // OUT: version number of control
};

struct PAN_CtlHandle {
    DWORD                   dwLow;
    DWORD                   dwHigh;
};

typedef enum {
    PAN_UnknownFile,
    PAN_RasterFile,
    PAN_VectorFile,
    PAN_DatabaseFile,
    PAN_SpreadsheetFile,
    PAN_DocumentFile,
    PAN_ArchiveFile
} PAN_FileType;
```

```

typedef struct PAN_CtlFileInfo {
    PAN_FileType      type;           // OUT: type of file currently
                                   // opened
    char              name[PAN_MAX_PATH]; // OUT: full pathname
                                   // encoded in MultiByte
                                   // using the local system
                                   // code page
    DWORD             size;           // OUT: file size in bytes
    DWORD             date;           // OUT: file modification date
    char              desc[PAN_CTLMAXDESC]; // OUT:
                                   // format description
    PAN_CtlRange      dimensions;     // OUT: view coordinate extents.
    WORD              colorDepth;     // OUT: color depth
    int               nPages;         // OUT: number of pages
    int               tilex, tiley;   // OUT: Width/height of tiles
                                   // 0 if not applicable.
    DWORD             dwHints;        // OUT: Hints, default 0x0000
    struct {
        PAN_Point     offset;
        PAN_Point     scale;
        PAN_Point     dpi;
        Real           rot;
        WORD           flip;
        } ins;                       // Insertion scaling + offsets.
                                   // Zero if not applicable.
    unsigned long     ClipCount;      // OUT: number of clip regions
                                   // in the current page
    BOOL              loadedFromMetafile; // OUT: true if the file is loaded
                                   // from metafile.
} PAN_CtlFileInfo;

```

```

struct PAN_CtlSearchInfo {
    BOOL                fMulti;           // IN: Find all occurrences, or
                                         // just first.
    BOOL                fDown;           // IN: search downward
    BOOL                fWrap;           // IN: wrap around end of file
    BOOL                fCase;           // IN: match case
    BOOL                fWord;           // IN: match whole word
    LPCSTR              string;          // IN: string to find
    PAN_CtlCaretPos     startPos;        // IN: starting file position
    WORD                fFound;          // OUT: TRUE if string was
                                         // found
    PAN_CtlCaretPos     foundPos;        // OUT: found file position
    HGLOBAL             hFoundPos;      // OUT: handle to global           //memory region
    containing          //list of
                                         // PAN_CtlCaretPos.
    PAN_CtlPos          foundBBox[4];    // OUT: Bounding box's four
                                         // vertices
    PAN_CtlHandle       foundHandle;     // OUT: Handle of found text
                                         // entity
    HGLOBAL             hFoundBBox;     // OUT: Handle to global           // memory region.
    HGLOBAL             hFoundHandle;    // OUT: Handle to global
                                         // memory region.
    HGLOBAL             hFoundBBox;     // OUT: Handle to array of
                                         // PAN_CtlBoundingBox
                                         // structs.
};

typedef struct PAN_CtlEntity {
    int                inslevel;
    PAN_CtlHandle      handle[1];
} PAN_CtlEntity;

```

**Note:** PAN\_CtlEntity is a variable length structure. *Inslevel* corresponds to the insertion level of entities. It is zero for top-level entities. For entities defined within blocks, it is the level of nesting (1, ...). *handle* is a variable length array of size *inslevel+1*. The zeroth entry is the handle of the entity itself. If an entity is defined within blocks, the entries 1, ... correspond to the handles of each insertion entity, from the lowest to the top level.

```

Typedef struct PAN_CtlGetEntityInfo {
    PAN_CtlRange       bbox;           // IN: bound box of search in           // world
    coordinates.
    Int                iThreshold;     // IN: Threshold for search in
                                         // screen coordinates, if           //
    bbox.min == bbox.max
    DWORD              nFound;         // OUT: Number of entities           // found.
    HGLOBAL            hFound;         // OUT: Global buffer of found
    entities.
} PAN_CtlGetEntityInfo, *LPPAN_CtlGetEntityInfo;

```

```

typedef struct PAN_CtlFileFmtList {
WORD          nFmts;          // OUT: number of formats
HGLOBAL       hFmts;          // OUT: global handle to array
                                // of PAN_CtlFileFmt structures
} PAN_CtlFileFmtList;

typedef struct PAN_CtlFileFmt {
char          desc[PAN_CTLMAXDESC]; // OUT: format description
char          exts[PAN_CTLMAXEXTS];  // OUT: file extensions,
                                // e.g., ".bmp.dib"
} PAN_CtlFileFmt;

typedef struct PAN_CtlClpbrdFmtList {
WORD          nFmts;          // OUT: number of formats
HGLOBAL       hFmts;          // OUT: global handle to array
PAN_CtlClpbrdFmt // structures
} PAN_CtlClpbrdFmtList;

typedef struct PAN_CtlClpbrdFmt {
WORD          fmt;            // OUT: clipboard format,
                                // One of PAN_CTLCLPBRD
char          desc[PAN_CTLMAXDESC]; // OUT: format description
} PAN_CtlClpbrdFmt;

typedef struct PAN_CtlSelList {
WORD          nSels;          // OUT: number of selections
HGLOBAL       hSels;          // OUT: global handle to array of
PAN_CtlSel structures
} PAN_CtlSelList;

typedef struct PAN_CtlSel {
int           selType;        // Either PAN_SEL_CARET or
                                // PAN_SEL_VIEW
union {
PAN_CtlRange  vwRange;        // Range specified in view
                                // coordinates.
PAN_CtlCaretRange ctRange;    // Caret based range.
} range;
} PAN_CtlSel;

```

```

typedef struct PAN_CtlPrintPreview {
    int                nPages;           // OUT: number of physical pages
    WORD              nHorzPages;       // OUT: number of physical pages
    horizontally across image
    WORD              nVertPages;       // OUT: number of physical pages
    vertically down the image
    LONGRECT          allPagesRect;     // OUT: rectangle of all pages in device // units
    RECT              deviceRect;       // OUT: page rectangle of the device
    HGLOBAL            imageRecls;      // OUT: global handle to array
    PAN_CtlRange structures: image      // rectangles within page rectangles
    HGLOBAL            clipRecls;       // OUT: global handle to array of RECT
    structures in device units: page    // rectangles excluding margins and
    // header/footers
    int                headerHeight;    // OUT: height of header in // device
    coordinates
    int                footerHeight;    // OUT: height of footer device
    coordinates
    BOOL              systemFontUsed;   // OUT: TRUE if system font is
    // used
    double             scale;           // OUT: relative scaling factor
} PAN_PrintPreview;

```

```

typedef struct PAN_CtlPrintOptions {
    PRINTDLG      *printDlg;    // IN: common dialog options
    WORD          units;        // IN: one of CTLUNIT_*
    double        nImageUnits;  // IN: number of image units
    double        nPaperUnits;  // IN: number of paper units
    PAN_CtlRange  source;       // IN: area to be printed.
    DWORD        mode;          // IN: rendering mode, combination
                                // of PAN_CTLMODE* flags. The //
                                // PAN_CTLMODEOPAQUE flag // is forced when printing.

    PanCtlPrintAlignment  alignment; // IN: enumeration with the
                                // following values:
                                //      Custom
                                //      TopLeft
                                //      TopCenter
                                //      TopRight
                                //      MiddleLeft
                                //      MiddleCenter
                                //      MiddleRight
                                //      BottomLeft
                                //      BottomCenter
                                //      BottomRight

    PHYSPOINT      alignmentCustom; // IN: alignment position if
                                // alignment is set to Custom.
                                // PHYSPOINT is a struct with
                                // two double members: x and y

    struct {
        WORD      units;        // IN: one of CTLUNIT_*
        double    top;
        double    left;
        double    bottom;
        double    right;
        } margins;    // IN: margins

    struct {
// A header string can contain any of the following escape sequences.
        // %f    full pathname
        // %v    drive letter
        // %d    directory name
        // %b    file basename
        // %e    file extension
        // %p    current page
        // %n    number of pages
        // %%    percent sign

        LOGFONT  font;

        LPCSTR   topLeftText;
        LPCSTR   topCtrText;
        LPCSTR   topRightText;
        LPCSTR   botLeftText;
        LPCSTR   botCtrText;
        LPCSTR   botRightText;
        } headers;    // IN: header strings

    LPCSTR      outputFileNames; // IN: output file name

```



```

PAN_CtlPrintPreview    printPreview;    // OUT: preview information

} PAN_CtlPrintOptions;

typedef struct PAN_CtlRenderOptions {

HDC                    hdc;              // Display Context.

PAN_CtlRange           source;           // Region to be rendered.

DWORD                 mode;
                        // Combination of the following modes:
                        // PAN_CTLMODEOPAQUE
                        // (render in opaque mode)
                        // PAN_CTLMODEANISOTROPIC
                        // (no aspect ratio adjustment).
                        // PAN_CTLMODESPREADSHEET_NOHEADERS
                        // (do not render spreadsheet row/column headers).
                        // PAN_CTLMODEMONOCHROME
                        // (render all entities in black. Vector control only).
                        // PAN_CTLMODEPRESERVECLIP
                        // (do not reset DC's clip region).
                        // PAN_CTLMODEPRESERVEPALETTE
                        // (do not select control palette on the DC).
                        // PAN_CTLMODERENDERTOPRINTER
                        // (render as if to a printer, regardless of DC).
                        // PAN_CTLMODERENDERSELECTED
                        // (Render only the selected entities)
                        // PAN_CTLMODE_HIGHLIGHT_DIMMED
                        // (In selected rendering mode use the dimmed          // highlight mode)

RECT                  devRect;           // Rectangle in which to fit selection,
                                           // in device units.

int                   xDevRes;           // Desired resolution. Set to zero for default
int                   yDevRes;
/*
** Buffer to store scale values for fixed width thick lines.
** Used as an additional scale for the line width when rendering.
*/
WORD                  numFixedWidthScale;
Real                  *lpFixedWidthScale;

/*
** Buffer used to store pen thickness (pen index corresponds to entity
** color index). Used to add thickness to entities when rendering.
*/
WORD                  numPens;
LPWORD                lpPenThickness;
} PAN_CtlRenderOptions;

```

```

typedef struct PAN_CtlObject {
    char          ObjectID[16];    // Display Context.
    int           ObjectType;      // Embedded or linked object.

    Char          filename[PAN_MAX_PATH];
                                // File containing data.

    LONG          ObjectOffset;    // Offset to data in file.
    LONG          ObjectSize;      // Size of data in file.

    PAN_CtlRange  source;          // Objects position in view coords.
    RECT          winRect;         // Rectangle in which to fit selection,
                                // in device units.
} PAN_CtlObject;

typedef struct PAN_CtlShowEntity {
    PAN_CtlHandle handle;          // Entity Handle
    DWORD          dwFlags;        // Bit flags: Combination of
                                PAN_CTLSHOWENTITYRESET,
                                PAN_CTLSHOWENTITYSETCOLOR,
                                PAN_CTLSHOWENTITYXOR,
                                PAN_CTLSHOWENTITYBLOCK,
                                PAN_CTLSHOWENTITYXREF
    COLORREF       Color;          // RGB color used to highlight
} PAN_CtlShowEntity;

typedef struct PAN_LAYER {        //Layer information
    unsigned int   id;
    char           name[320];
    COLORREF       color;
    BOOL           bState;
    BOOL           fThawed;
    BOOL           bReadOnly
    BOOL           fNotPrintable;
} PAN_LAYER;

```

```

class IResourceContextInfo // Class providing information about the
// context in which the resource is to be located
{
{
    public:
    virtual const std::(1)wstring & GetBaseDirectory();
        // Returns the directory of the current base file in UNICODE

    virtual const std::(1)wstring & GetProfileName();
        // Returns path of the INI file currently used in UNICODE

    virtual void * GetUserData();
        // Returns the user_data passed in PM_CTLSETFILEEX
};

class IPanResourceInfo // Class providing info about the resource
{
public:
    class Location // Class encapsulating the info about a location
    {
    public:
        class FileStatus // Class holding the file status information
        {
        public:
            FileStatus(const std::(1)wstring & originalPath =
std::(1)wstring(),           // file path
                    size_t fileSize = 0,           // file size (bytes)
                    size_t modifiedTime = 0); // last modified

            FileStatus( const std::(1)wstring & originalPath, //filepath
                    const struct _stat & fileStat);    // _stat

            virtual size_t GetSize() const;
                // Returns the size of the file in bytes.

            virtual size_t GetModifiedTime() const;
                // Returns the last modified time of the file
                // since midnight January 1st, 1970

            virtual const std::(1)wstring & GetOriginalPath() const;
                // Returns the original
                // file path

            virtual bool CompareSignature(const FileStatus & rhs
) const; // Comparator

            virtual void Set( const std::(1)wstring & originalPath,
                    const struct _stat & fileStat);
                // Set the original file name & status

            virtual bool IsEmpty() const;
                // Returns whether the file status was
                // initialized.

```

---

<sup>(1)</sup> Look at Overview section about usage of STL and Boost libraries

```

}; // End of FileStatus

Location(const std::wstring & wsLocatedPath = std::wstring(),
         // file location
         const std::wstring & wsKey = std::wstring(),
         // unique key (optional)
         const FileStatus & fileStatus = FileStatus());
         // file status

Location(const Location & location);
         // Copy Constructor

const std::wstring & GetLocatedPath() const;
         // Returns the absolute path of the located file

const std::wstring & GetKey() const;
         // Returns the key set by application during location

const FileStatus & GetFileStatus() const;
         // Returns the file status

}; // End of Location

class ISelection // Holds the file path of the selected file that
                // need to be downloaded to an accessible location
{
public:
    virtual const std::wstring & GetLocated() const = 0;
        // Returns the selected resource's file path

    virtual void SetLocated(const std::wstring & located) = 0;
        // Sets the downloaded file path
}; // End of ISelection

class SelectionIterator // Selection Iterator
{
public:
    ISelection & operator*();
        // Dereferenced the selection iterator to
        // retrieve the current selection.

    ISelection * operator->();
        // Dereferenced the selection iterator to
        // retrieve the current selection.

    operator bool() const;
        // Bool conversion operator indicating
        // whether the iterator has a valid
        // selection. This will return false after
        // the iterator has reached the end.

    SelectionIterator & operator++();
        // Pre-increment operator, which
        // continues the iteration and moves

```

---

<sup>(1)</sup> Look at Overview section about usage of STL and Boost libraries

```

        // to the next selection.

}; // End of SelectionIterator

virtual ~IPanResourceInfo();           // Destructor

virtual const std::(1)wstring & Name() const;
        // Returns the resource name
        // in UNICODE

virtual unsigned int Type() const;
        // Returns the type of the resource.
        // Can be either of RI_TEXTFONT,
        // RI_LINestyle, RI_SHAPE,
        // RI_VECTOR_EXTERNAL_REFERENCE,
        // RI_RASTER_EXTERNAL_REFERENCE.

virtual const std::(1)wstring & Path() const;
        // Returns the resource file path in
        // UNICODE. The file path may
        // contain wildcard characters
        // such as * and ?

virtual const std::(1)wstring & Pattern() const;
        // Returns the regular expression
        // pattern that matches the found
        // file name

virtual const std::(1)wstring & SearchPaths() const ;

/*
Returns the search paths in the following form:

SearchPaths      := PathEntry [Paths]
PathEntry        := [$(Tag)[/\]] [Path]
Path             := Any file path
Tag              := BASEFILE | MODULE | DIRECT | SUBSTITUTE | SpecialTag
SpecialTag       := Type=IniEntryKey
Type             := PATHS
IniEntryKey      := XREFPATHS | XFONTPATHS | XREFFILES | ...
Tags:
BASEFILE         The folder that the basefile is located in.
MODULE           The folder that AutoVue is installed in.
DIRECT           Search the filename directly.
SUBSTITUTE       Use the provided file as an alternative to the missing file.
SpecialTag       An INI entry under the options section what hold semicolon separated
                  search paths.

E.g.: "C:\samples\resources; $(Direct); $(BaseFile)\;    $(Paths=XRefPaths)\resources;
$(Module)\Font;    $(SUBSTITUTE)C:\temp\substiute.shx".

A search path may contain wildcard characters such as '*' and '?'. Another character
sequence "***" has been added, which indicates that a recursive folder search is requested.

```

<sup>(1)</sup> Look at Overview section about usage of STL and Boost libraries

Example:

“C:\\*\folder” would match  
“C:\one\folder” and “C:\two\folder”.

“C:\\*\*\folder” would match  
“C:\one\folder” and “C:\two\three\folder”.

“C:\?ine\folder” would match  
“C:\nine\folder” and “C:\Fine\folder”.

\*/

```
virtual size_t MaxResults() const;
    // Returns the maximum number
    // of files that need to be returned as
    // located candidates

virtual const std::(1)string & MagicString() const;
    // Returns the sequence of bytes
    // at the beginning of the located
    // file that must match.

virtual void SetLocated(const std::(1)vector<Location> & vLocations)
    // Sets the resulting located files
    // stored in a vector of locations

virtual void GetLocated(std::(1)vector<Location> & vLocations);
    // Fills the locations vector with
    // the located file locations

virtual SelectionIterator GetSelected(); // Get the selected candidates.

virtual bool Download() const;    // Returns whether the resource
    // needs to be downloaded to
    // an accessible location

virtual bool Search() const;    // Returns whether the resource
    // needs to be located

virtual std::(1)wstring Identifier() const; // Get unique ID

}; // End of IPanResourceInfo
```

```
struct PanUserResourceLocate // Encapsulates the user callback function
    // pointer and the user data that will be passed to
    // the callback function as argument
{
    typedef void ( * LocateProc )( std::(1)vector<csi::IPanResourceInfo *> &,
        const IResourceContextInfo &, bool *);
    // User Callback function used in pre- and post-location

    LocateProc pLocateProc; // Callback function's pointer to
```

---

<sup>(1)</sup> Look at Overview section about usage of STL and Boost libraries

```

// user resource location procedure

void * user_data;          // Any user data opaque to VCET.

PanUserResourceLocate();    // Default constructor

PanUserResourceLocate(LocateProc locateProc, void * userData);

};

struct PAN_CtlSetFile
{
std::(1)wstring            file_name;          // File name in Unicode

PanUserResourceLocate user_resource_locate;    // user resource locate

PAN_CtlSetFile();          // Default constructor

PAN_CtlSetFile(std::(1)wstring filename, PanUserResourceLocate locate);
};

typedef struct {
id_type                    id;                  // Unique id
char                       name[_MAX_PATH];    // Logical Name char
                           fname[_MAX_PATH];   // Full filename
BOOL                       bState;              // 1: On, 0: Off,
                                           // -1: Disabled
} PAN_XREF;

struct ResourceInfo {
enum Status {
Missing,          // The resource was not found.
Located,          // The resource was found or replaced
                  // by an equivalent substitute.
Substituted       // The resource was not found but substituted.
};

int                type;
                  // The type of the resource, possible values are:
                  // RI_TEXTFONT, RI_LINestyle, RI_SHAPE,
                  // RI_VECTOR_EXTERNAL_REFERENCE,
                  // RI_RASTER_EXTERNAL_REFERENCE,
                  // and RI_UNKNOWN.

std::(1)wstring    name;
                  // The name of the resource in UNICODE

std::(1)wstring    note;          // The note of the resource

std::(1)wstring    identifier;    // Unique identifier

std::(1)wstring    path;          // Resource file path

Status             eStatus;       // The location status

```

---

(1) Look at Overview section about usage of STL and Boost libraries

```
};

class IGetResourceInfo
{
public:
virtual operator bool() const;           // Check for iteration end

virtual const ResourceInfo & operator*() const;
                                   // Returns the current resource info

virtual IGetResourceInfo & operator++();
                                   // Advance to the next resource info
};
```



## Command Messages

VCET, as an application programming interface (API), itself makes use of the Microsoft Windows API function `SendMessage()` in order to exploit its viewing and conversion capabilities. There is a certain advantage to this method, particularly in the case of a viewing and conversion tool, namely that the end user of your application does not directly access the current file, but rather sends his commands to the window or viewport in which the file is being rendered. This practically eliminates the risk of accidental data modification. This section takes an in-depth look at the command messages which form the core of VCET's functionality.

## Command Message Summary

### Control-Specific Command Messages

Message Name	Purpose
<b>PM_CTLCLONECONTROL</b>	Creates a duplicate of a control and returns its handle.
<b>PM_CTLDESTROY</b>	Prepares a control for destruction.
<b>PM_CTLGETDIMS</b>	Returns the dimensions of the control
<b>PM_CTLGETCAPS</b>	Returns the currently enabled capabilities of a control.
<b>PM_CTLGETFILE</b>	Returns information about the current file.
<b>PM_CTLGETFILEFMTS</b>	Returns file formats supported by a control.
<b>PM_CTLGETFILETYPE</b>	Returns the format class and an index into the list provided by PM_CTLGETFILEFMTS
<b>PM_CTLGETINFO</b>	Returns information about a control.
<b>PM_CTLGETMODE</b>	Returns the currently enabled modes of a control.
<b>PM_CTLGETOPTION</b>	Returns the control options.
<b>PM_CTLGETSTATUS</b>	Returns the current status of a control.
<b>PM_CTLREGEN</b>	Reread the file from disk.
<b>PM_CTLSETCAPS</b>	Modifies the capabilities of a control.
<b>PM_CTLSETFILE</b>	Renders the given file in the control window.
<b>PM_CTLSETMODE</b>	Modifies the modes of a control.
<b>PM_CTLSETOPTION</b>	Set the control options.

### Presentation Command Messages

<b>PM_CTLFLIP</b>	Flips the contents of the control.
<b>PM_CTLGETFLIP</b>	Returns the current flipping state.
<b>PM_CTLGETROTATION</b>	Returns the current rotation set in the control.
<b>PM_CTLGETZOOM</b>	Returns the current zoom factor.
<b>PM_CTLHSCROLL</b>	Similar to WM_HSCROLL.
<b>PM_CTLPAINT</b>	Similar to WM_PAINT.
<b>PM_CTLROTATE</b>	Rotates the contents of the control.
<b>PM_CTLSETZOOM</b>	Sets the zoom factor.
<b>PM_CTLSIZE</b>	Similar to WM_SIZE.
<b>PM_CTLVSCROLL</b>	Similar to WM_VSCROLL.

### Conversion Command Message

<b>PM_CTLCONVERT</b>	Obtain handles to conversion functions.
----------------------	---

### Coordinates-related messages

<b>PM_CTLCARETTOORLD</b>	Returns the view coordinate that corresponds to the specified caret position.
<b>PM_CTLGETCARETPOS</b>	Returns the current position of the caret.
<b>PM_CTLSETCARETPOS</b>	Moves the caret to the specified position.
<b>PM_CTLWORLDTOCARET</b>	Returns the caret position that corresponds to the given world coordinates.
<b>PM_CTLWORLDTOCLIENT</b>	Returns the client area coordinates (i.e., relative to the top, left corner of the client area of the control window) corresponding to the given world coordinates.
<b>PM_XFRMRECT</b>	Applies/Removes current rotation and flipping to/from a world coordinate range.

## Clipboard and selection-related messages

<b>PM_CTLCLEARSELS</b>	Clears all selections.
<b>PM_CTLCOPY</b>	Copy the current selections to the clipboard.
<b>PM_CTLGETCLPBRDFMTS</b>	Returns clipboard formats supported by a control.
<b>PM_CTLGETNUMSELS</b>	Returns the current number of selections.
<b>PM_CTLGETSELS</b>	Returns a list of the current selections.
<b>PM_CTLSETSEL</b>	Sets or removes a selection based on view coordinates.
<b>PM_CTLSETSELCARET</b>	Sets or removes a selection specified using caret positions.

## Color-related messages

<b>PM_CTLGETFGBGCOLOR</b>	Returns the foreground or background color.
<b>PM_CTLGETPALETTE</b>	Returns palette information.
<b>PM_CTLPALETTECHANGED</b>	The calling application must send this message to the control whenever it receives a WM_PALETTECHANGED message.
<b>PM_CTLQUERYNEWPALETTE</b>	The calling application must send this message to the control whenever it receives a WM_QUERYNEWPALETTE message.
<b>PM_CTLSETFGBGCOLOR</b>	Sets the foreground or background color.
<b>PM_CTLSETPALETTE</b>	Sets the color palette.

## Views-related message

<b>PM_CTLGETVIEW</b>	Returns the “active named view” in the control.
<b>PM_CTLGETVIEWEXTENTS</b>	Returns the current view extents of the current file in view coordinates.
<b>PM_CTLGETVIEWNAMES</b>	Returns a buffer of “view” names set by PANX_SetViews().
<b>PM_CTLSETVIEW</b>	Sets the view to use in the control.
<b>PM_CTLSETVIEWEXTENTS</b>	Sets the view extents of the current file in view coordinates.

## Blocks-related messages

<b>PM_CTLGETBLOCK</b>	Gets the “active block” in the control.
<b>PM_CTLGETBLOCKNAMES</b>	Returns a buffer of block names set by PANX_SetBlocks().
<b>PM_CTLSETBLOCK</b>	Sets the “active block” in the control.

## Entities-related

<b>PM_CTLGETENTITY</b>	Retrieves entity handles found within a specified region (vector files).
<b>PM_CTLSHOWENTITY</b>	Sets entity’s drawing color e.g. to highlight a selected entity (vector files).

## Extended Image Data Command Messages

<b>PM_CTLGETIMAGEEX</b>	Retrieves the image’s current contrast/anti-aliasing setting.
<b>PM_CTLSETIMAGEEX</b>	Adjusts the image’s contrast and/or anti-aliasing.

## Layers-Related Command Messages

<b>PM_CTLGETLAYERSTATE</b>	Returns a buffer of layer states set by PANX_SetLayers().
<b>PM_CTLSETLAYERSTATE</b>	Sets the internal buffer of layers in the control.

## XRef-Related Command Messages

<b>PM_CTLGETXREFSTATE</b>	Returns a buffer of XRef states set by PANX_SetXRefs().
<b>PM_CTLSETXREFSTATE</b>	Sets the internal buffer of XRefs in the control.

## Bookmark messages.

<b>PM_CTLGETBOOKMARKS</b>	Returns a buffer of PAN_BOOKMARK struct set by PANX_SetBookMarks.
<b>PM_CTLSETBOOKMARKS</b>	Not implemented

## Resource-Related Command Messages

<b>PM_CTLGETRESOURCEINFSTATE</b>	Returns a buffer of resource information set by PANX_ResourceInfo().
----------------------------------	--

## Offset-Related Command Messages

<b>PM_CTLGETOFFSET</b>	Returns the offset of the origin for the current file in view coordinates.
<b>PM_CTLSETOFFSET</b>	Sets the offset of the origin for the current file in view coordinates.

## Font-Related Command Messages

<b>PM_CTLGETBASEFONT</b>	Returns the base font of the current file.
<b>PM_CTLSETBASEFONT</b>	Sets the base font of the current file.

## Database and Spreadsheet-Related Command Messages

<b>PM_CTLGETCOLWIDTH</b>	Return the width of the specified field/column in the specified units.
<b>PM_CTLSORT</b>	Sorts a specified range in a database.
<b>PM_CTLGETROWHEIGHT</b>	Returns the height of the specified record/row in specified units.

#### Page-Related Command Messages

<b>PM_CTLGETNUMPAGES</b>	Returns the number of pages in the current file.
<b>PM_CTLGETPAGE</b>	Returns the current page number within the current file.
<b>PM_CTLGETPAGESIZE</b>	Returns the size of the specified page in the current file.
<b>PM_CTLSETPAGE</b>	Sets the current page number within the current file.

#### Printing-Related Command Messages

<b>PM_CTLPRINT</b>	Prints the specified extents.
<b>PM_CTLPRINTPREVIEW</b>	Returns the print preview of the specified extents.
<b>PM_CTLVALIDATEMARGINS</b>	Validates the printer margins.

#### Text-Specific Command Messages

<b>PM_CTLGETSTRING</b>	Retrieves a specified string from a control.
<b>PM_CTLSEARCH</b>	Search the current file for a text string.

#### Mouse-Specific Command Messages

<b>PM_CTLGETLMBACTION</b>	Returns the left mouse button control window behavior.
<b>PM_CTLSETLMBACTION</b>	Sets the left mouse button control window behavior.

#### Device Context Command Messages

<b>PM_CTLRENDERONTODC</b>	Renders the specified extents onto the given device context.
---------------------------	--

#### Formatting Device Command Messages

<b>PM_CTLSETDEVICE</b>	Set formatting device for document files.
<b>PM_CTLGETDEVICE</b>	Gets current formatting device for document files.

#### Command Messages dropped from Version 1.1 of VCET Controls

<b>PM_CTLGETBOOKMARK</b>	Returns the bookmark position within the current file.
<b>PM_CTLGETDC</b>	Returns a handle to the device context set by PM_CTLSETDC.
<b>PM_CTLSETBOOKMARK</b>	Positions the bookmark at a given file position.
<b>PM_CTLSETDC</b>	Sets the current device context handle to be used by the control when drawing or converting coordinates.

## Command Message Descriptions

The following section presents a brief description along with the meaning of each parameter and the return value, for each command message, organized by functional category.

### Controls Command Messages

#### PM\_CTLCLONECONTROL

**Purpose** Creates a duplicate of a control and return its handle.

**Description** Create a duplicate of the control and return a handle to the window of the new control. The window of the new control can be a stand-alone window, in which case both *wParam* and *lParam* must be zero; or a child window if *lParam* initially points to a parent window, in which case, *wParam* must contain a unique child identifier greater than zero. The new control is created in a hidden state.

**NOTE:** While view state is preserved between the original and cloned control, the clone control does not inherit the selections that may have been present in the original control.

**Parameters**

<i>wParam:</i>	0 if new control window is to be stand-alone <b>(WORD)</b> child ID, if new control window has a parent
<i>lParam:</i>	0 if new control window is to be stand-alone <b>(HWND *)</b> parent window handle (in) /control window handle (out), if new control window has a parent

**Returns:** error code

**Compatibility:** all control types

#### Example:

```
HWND Clone(HWND ctrlHandle)
/* Create an independent clone of the control pointed to by ctrlHandle */
{
    HWND newHndl; // the new control has no parent
    int err;

    if (ctrlHandle == NULL) return ((HWND) 0);

    err = (int) SendMessage(ctrlHandle, PM_CTLCLONECONTROL, 0,
                           (LPARAM) &newHndl);
    if (err != PAN_CTLERRNONE) return((HWND) 0);
    return newHndl;
}
```

**PM\_CTLDESTROY**

<b>Purpose</b>	Prepares a control for destruction.		
<b>Parameters</b>	<i>wParam:</i>	not used	
	<i>lParam:</i>	not used	
<b>Returns:</b>	error code		
<b>Compatibility:</b>	all control types		
<b>Special Notes:</b>	This message must be sent before destroying the control window with the Windows <b>DestroyWindow()</b> function.		

**PM\_CTLGETCAPS**

**Purpose** Returns the capabilities of a control.

**Description** If *wParam* is zero, return a mask of the currently enabled capabilities of the control in the **DWORD** pointed to by *lParam*. If *wParam* is non-zero, return a mask of all the capabilities of the control. The mask consists of zero, one or more of the following constants ORed together.

<b>PAN_CTLCAPSZOOM</b>	can zoom
<b>PAN_CTLCAPSCOPY</b>	can copy to clipboard
<b>PAN_CTLCAPSSEARCH</b>	can search for string
<b>PAN_CTLCAPSPAGE</b>	can go to page
<b>PAN_CTLCAPSSIZE</b>	can handle resize events
<b>PAN_CTLCAPSHSCROLL</b>	can handle horizontal scroll events
<b>PAN_CTLCAPSVSCROLL</b>	can handle vertical scroll events
<b>PAN_CTLCAPSMOUSE</b>	can handle mouse events
<b>PAN_CTLCAPSKEYBD</b>	can handle keyboard events

<b>Parameters</b>	<i>wParam:</i> <b>Zero</b>  <b>Non-Zero</b>	Get all enabled capabilities of the control.  Get all possible capabilities of the control.
	<i>lParam:</i> ( <b>wParam:Zero</b> )  ( <b>wParam:Non-Zero</b> )	<b>(LPDWORD)</b> mask of all currently enabled capabilities of the control  <b>(LPDWORD)</b> mask of all possible capabilities of the control

**Returns:** error code

**Compatibility:** all control types

**Example:**

```
void ShowCaps(HWND ctrlHandle)
//      Display the current capabilities of the control using 1 if enabled
//      and 0 if disabled.
{
    DWORD caps=0;

    if (ctrlHandle == NULL) return;

    SendMessage(ctrlHandle, PM_CTLGETCAPS, 0, (LPARAM) &caps);
    Output("Zoom   : %d\n",
          (caps&PAN_CTLCAPSZOOM) == PAN_CTLCAPSZOOM);
    Output("Copy    : %d\n",
          (caps&PAN_CTLCAPSCOPY) == PAN_CTLCAPSCOPY);
}
```



```
Output("Search  : %d\n",
      (caps&PAN_CTLCAPSSEARCH) == PAN_CTLCAPSSEARCH);
Output("Page    : %d\n",
      (caps&PAN_CTLCAPSPAGE) == PAN_CTLCAPSPAGE);
Output("Size     : %d\n",
      (caps&PAN_CTLCAPSSIZE) == PAN_CTLCAPSSIZE);
Output("HScroll  : %d\n",
      (caps&PAN_CTLCAPSHSCROLL) == PAN_CTLCAPSHSCROLL);
Output("VScroll  : %d\n",
      (caps&PAN_CTLCAPSVSCROLL) == PAN_CTLCAPSVSCROLL);
Output("Mouse   : %d\n",
      (caps&PAN_CTLCAPSMOUSE) == PAN_CTLCAPSMOUSE);
Output("Keybd   : %d\n",
      (caps&PAN_CTLCAPSKEYBD) == PAN_CTLCAPSKEYBD);
}
```

**PM\_CTLGETDIMS**

<b>Purpose</b>	Returns the dimensions of the control, in terms of rows and columns, in the structure passed. For raster, vector, and document files it returns the dimensions in logical units.
<b>Description</b>	This message is intended primarily for spreadsheet and database controls, which can be measured in terms of rows and columns as well as by view extents. This message returns these dimensions in the <i>PAN_CtlDimensions</i> structure pointed to by <i>lParam</i> .
<b>Parameters</b>	<i>wParam</i> : not used  <i>lParam</i> : ( <b>PAN_CtlDimensions *</b> ) dimensions
<b>Returns:</b>	error code
<b>Compatibility:</b>	all control types
<b>Special Notes:</b>	The dimensions that are returned from a document control do not include the 5mm interpage gaps that are added when the file is displayed.

**Example:**

```

int ShowDimensions(HWND ctrlHandle)
/* Output the dimensions of an archive, database, or spreadsheet control */
/* in terms of rows and columns. */
{
    int err;
    PAN_CtlDimensions dimensions;

    if (ctrlHandle == NULL)
        return PAN_CTLERRMISC;

    // Get control dimensions.
    err = (int)SendMessage(ctrlHandle, PM_CTLGETDIMS, 0, (LPARAM) &dimensions);

    if (err == PAN_CTLERRNONE) {
        Output("Control dimensions = (%d, %d, %d)\n",
            dimensions.DimWidth,
            dimensions.DimHeight,
            dimensions.DimDepth);
    }

    return err;
}

```

**PM\_CTLGETFILE**

**Purpose** Returns information about the current file.

**Description** Return information about the current file in the **PAN\_CtlFileInfo** structure pointed to by *lParam*.

For vector files, if entity information is available the CTL\_FILE\_HINT\_EDAT hint flag will be set in the dwHints field of the returned file information. All other bits of the dwHints field are reserved.

**NOTE:** The dimensions that are returned from a document control do not include the 5mm interpage gaps that are added when the file is displayed.

**Parameters**

<i>wParam</i> :	reserved, must be 0
<i>lParam</i> :	(PAN_CtlFileInfo *) file information

**Returns:** error code

**Compatibility:** all control types

**Example:**

```
void ShowFileInfo(HWND ctrlHandle)
/*
display some file information on the output device. */
{
    PAN_CtlFileInfo fi;

    if (ctrlHandle == NULL) return;

    SendMessage(ctrlHandle, PM_CTLGETFILE, 0, (LPARAM) &fi);
    Output("name: %s\r", fi.name);
    Output("size: %d\r", fi.size);
    Output("date: %d\r", fi.date);
    Output("desc: %s\r", fi.desc);
}
```

<b>PM_CTLGETFILEFMTS</b>
--------------------------

<b>Purpose</b>	Returns file formats supported by a control.
<b>Description</b>	Return a description of each file format supported by the control in the <b>PAN_CtlFileFmtList</b> structure pointed to by <i>lParam</i> .
<b>Parameters</b>	<i>wParam</i> : not used <i>lParam</i> : ( <b>PAN_CtlFileFmtList *</b> ) file formats supported
<b>Returns:</b>	error code
<b>Compatibility:</b>	all control types

**Example:**

```

void ShowFileFmts(HWND ctrlHandle)
/*
Display the supported file formats on the output device. */
{
    PAN_CtlFileFmtList    fl;
    PAN_CtlFileFmt *      f;
    WORD                  i;
    char desc[PAN_CTLMAXDESC];
    char exts[PAN_CTLMAXEXTS];

    if (ctrlHandle == NULL) return;
    SendMessage(ctrlHandle, PM_CTLGETFILEFMTS, 0, (LPARAM) &fl);
    f = (PAN_CtlFileFmt *)GlobalLock(fl.hFmts);
    for (i=0; i<fl.nFmts; i++) {
        _fstrcpy(desc, f[i].desc);
        _fstrcpy(exts, f[i].exts);
        Output("%s (%s)\r", desc, exts);
    }
    GlobalUnlock(fl.hFmts);
}

```

## PM\_CTLGETFILETYPE

**Purpose** Returns the type of control associated with a given file.

**Description** The control types are listed below.

**Parameters**

<i>wParam</i> :	0	The file name encoded in MultiByte using the local system codepage.
	1	The file name encoded in Unicode
<i>lParam</i> :	( <i>wParam</i> = 0)	(LPCSTR) filename
	( <i>wParam</i> = 1)	(wchar_t *) filename

**Returns** A constant of type **PAN\_FileType** is returned in the low word, and an index into the list provided by **PM\_CTLGETFILEFMTS** is returned in the high word. If the format of the given file is not supported or an error occurred, **PAN\_UnknownFile** is returned.

```
typedef enum {
    PAN_UnknownFile,
    PAN_RasterFile,
    PAN_VectorFile,
    PAN_DatabaseFile,
    PAN_SpreadsheetFile,
    PAN_DocumentFile,
    PAN_ArchiveFile
} PAN_FileType;
```

**Compatibility:** all control types

### Example:

```
void ShowFileType(HWND ctrlHandle, LPCSTR fileName)
/* Display the file type of the specified file on the output device. */
{
    WORD lowbyte;

    if (ctrlHandle==NULL) return;
    lowbyte = (WORD) LOWORD(SendMessage(ctrlHandle, PM_CTLGETFILETYPE, 0,
        (LPARAM) fileName));
    switch (lowbyte) {
        case PAN_RasterFile:      Output("File is of type : Raster");
                                break;
        case PAN_VectorFile:     Output("File is of type: Vector");
                                break;
        case PAN_DatabaseFile:   Output("File is of type:
                                Database"); break;
        case PAN_SpreadsheetFile: Output("File is of type:
                                Spreadsheet"); break;
        case PAN_DocumentFile:  Output("File is of type:
                                Document"); break;
        case PAN_ArchiveFile:    Output("File is of type: Archive");
                                break;
        default: Output("Unknown file type or an error
                                occurred");
    } // end switch
}
```

**PM\_CTLGETINFO**

<b>Purpose</b>	Returns information about a control.
<b>Description</b>	Returns information about the control in the <b>PAN_CtlInfo</b> structure pointed to by <i>lParam</i> .
<b>Parameters</b>	<i>wParam</i> : not used <i>lParam</i> : ( <b>PAN_CtlInfo *</b> ) control information
<b>Returns:</b>	error code
<b>Compatibility:</b>	all control types

**Example:**

```
void ShowInfo(HWND ctrlHandle)
/*      Display the current version on the output device. */
{
    int err;
    PAN_CtlInfo i; // info structure

    if (ctrlHandle == NULL) return;

    err = SendMessage(ctrlHandle, PM_CTLGETINFO, 0, (LPARAM) &i);
    if (err != PAN_CTLERRNONE) return;
    Output("Control version: %d", i.version);
}
```

## PM\_CTLGETMODE

**Purpose** Returns the currently enabled modes of a control.

**Description** If *wParam* is zero, return a mask of the currently enabled modes of the control in the **DWORD** pointed to by *lParam*. If *wParam* is non-zero, return a mask of all the modes of the control. The mask consists of zero, one or more of the following constants ORed together.

**PAN\_CTLMODEOPAQUE** control is opaque  
**PAN\_CTLMODENOREDRA** redraws are disabled  
**PAN\_CTLMODEEXCESSSCROLL** scrolling is not constrained  
**PAN\_CTLMODEANISOTROPIC** aspect ratio is not preserved  
**PAN\_CTLMODEDRAGDROP** control accepts dropped files  
**PAN\_CTLMODEINTERRUPTIBLE** control may be interrupted  
**PAN\_CTLMODEMONOCHROME** Draw all entities in black. Only supported by the vector control.  
**PAN\_CTLMODEPRESERVECLIP** Preserve clip region of target device.  
**PAN\_CTLMODEPRESERVEPALETTE** Preserve palette of target device.  
**PAN\_CTLMODEIGNOREMINMARGINS** Ignore printing margins.  
**PAN\_CTLMODERENDERSELECTED** Only render selected entities.  
**PAN\_CTLMODERENDERTOPRINTER** Give the same render output as a printer even the DC is not a printer.  
**PAN\_CTLMODELIMITTOONETILE** Limit to one tile in printing.  
**PAN\_CTLMODE\_HIGHLIGHT\_DIMMED** Dimmed highlight mode.  
**PAN\_CTLMODE\_DISABLE\_FORCETOBLACK\_ONRASTER** Prevents the Force-To-Black from being applied to raster overlays(images) in vector/raster overlays.  
**PAN\_CTLMODE\_TILE** CMF tile mode.  
**PAN\_CTLMODE\_FORCE\_BKG\_PAINT** Paint in force-to-black mode.

**Parameters**

*wParam*: zero or non-zero

*lParam*: (**LPDWORD**) mask of mode flags

**Returns:** error code

**Compatibility:** all control types

### Example:

```
void ShowMode(HWND ctrlHandle)
/*      Display the current control mode settings on the output device. */
{
    WORD mode=0;

    if (ctrlHandle == NULL) return;
    SendMessage(ctrlHandle, PM_CTLGETMODE, 0, (LPARAM)&mode);
    Output("Opaque   : %d\r", (mode&PAN_CTLMODEOPAQUE)!=0);
    Output("NoRedraw  : %d\r", (mode&PAN_CTLMODENOREDRA)!=0);
    Output("Ex Scrl   : %d\r", (mode&PAN_CTLMODEEXCESSSCROLL)!=0);
    Output("Aniso    : %d\r", (mode&PAN_CTLMODEANISOTROPIC)!=0);
    Output("Drag&drop: %d\r", (mode&PAN_CTLMODEDRAGDROP)!=0);
    Output("Interrupt: %d\r", (mode&PAN_CTLMODEINTERRUPTIBLE)!=0);
}
```

**PM\_CTLGETOPTION**

**Purpose** Gets information about different control options.

**Description** Depending on the control type it offers the possibility to read the current display values for different types of file.

**PAN\_CTLCAOPTIONS** Get the control CAD options. The CAD options are used to Enable/Disable. Some features (Text, Line-Styles, Filling...). This option is supported by Vector Control (2D/3D).

**PAN\_CTLOPTDIMLEVEL** Get the current set value for dim highlight level. Dim level, in case dim highlight mode has been selected, controls how much the rest of the drawing dimmed with respect to the highlighted items.

**Parameters** *wParam:* **PAN\_CTLCAOPTIONS** or **PAN\_CTLOPTDIMLEVEL**

*lParam:* (**wParam = PAN\_CTLCAOPTIONS**)

Mask of the following CAD options flags:

**PAN\_CADOPTIONS\_NOTEXT:** Disable the text in the model.  
**PAN\_CADOPTIONS\_NODIMENSIONS** Disable dimensional primitives in the model.  
**PAN\_CADOPTIONS\_NOXREFS:** Disable XRefs in the model.  
**PAN\_CADOPTIONS\_NOFILLS:** Instructs the snapping code to consider snapping filled areas if this flag is not set.  
**PAN\_CADOPTIONS\_NOLINESTYLES:** Disable Line-Styles on all the primitives of the model. They will be drawn using solid lines.  
**PAN\_CADOPTIONS\_NOLINEWEIGHTS:** Don't consider the line thickness for model primitives.  
**PAN\_CADOPTIONS\_FASTDISPLAY:** Enable fast display rendering optimizations: whenever is possible the original model primitives will be displayed using approximation in order to speed up the rendering.  
**PAN\_CADOPTIONS\_FULLDISPLAY:** Disable any kind of rendering optimizations. However, if both full display and fast display flags are specified the fast display will have priority (i.e. the full display flag will be ignored in this case.)

(**wParam = PAN\_OPTDIMLEVEL**)

(**double\***) pointer to the value receiving the dim level.

**Returns:** error code

**Compatibility:** vector-2D

**Example:**

```
/* Get the current dim level*/

double dimLevel = 0.0;
WORD wParam = PAN_CTLOPTDIMLEVEL;
DWORD lParam = (DWORD)&dimLevel;
...
SendMessage (hwndCtl, PM_CTLGETOPTION, wParam, lParam);
...
```



## PM\_CTLGETSTATUS

**Purpose** Returns the current status of a control.

**Description** Return the current status of the control in the **DWORD** pointed to by *lParam*. The status is a mask of the following constants.

**PAN\_CTLSTATUSIDLE** control is idle

**PAN\_CTLSTATUSPROCESSING** control is processing the file

**PAN\_CTLSTATUSREFRESHING** control is refreshing the window

**Parameters** *wParam*: not used

*lParam*: (**LPDWORD**) control status

**Returns:** error code

**Compatibility:** all control types

### Example:

```
void ShowStatus(HWND ctrlHandle)
/*      Display the status of the control on the output device. */
{
    DWORD stat;

    if (ctrlHandle == NULL) return;

    SendMessage(ctrlHandle, PM_CTLGETSTATUS, 0, (LPARAM) &stat);
    if (stat & PAN_CTLSTATUSIDLE)
        Output("GETSTATUS: Idle...\r");
    if (stat & PAN_CTLSTATUSPROCESSING)
        Output("GETSTATUS: Processing...\r");
    if (stat & PAN_CTLSTATUSREFRESHING)
        Output("GETSTATUS: Refreshing...\r");
}
```

<b>PM_CTLREGEN</b>
--------------------

**Purpose** Redraws file using new parameters.

**Description** Causes a redraw of the file. This differs from repainting in that the file is re-read from disk. This message can be used if the contents of a file have changed, or if the user has changed any viewing options.

Note:that the following information is retained:

The page number currently viewed.

The layer states.

The block state.

The current “view” of the file (i.e., for graphics files, the offset and zoom factor, for doc files, the position in the document, for db/ss files the top left and current cell).

**Parameters** *wParam:* (WORD)Can be one of:

**PAN\_CLEARLAYERS** clears layers from file before re-drawing

**PAN\_CLEARBLOCKS** clears blocks from file

**PAN\_CLEARVIEWS** clears views from file

**PAN\_CLEARVIEWEXTENTS** clears view extents from file  
before re-drawing

**PAN\_FITVIEWEXTENTS** re-draw the file to fit the  
current view extents

**Note:** If the user does not provide a *wParam*, the file will be re-drawn as is.

*lParam:* Not used

**Returns:** error code

**Compatibility:** all control types

**Example:**

```
void ShowAllBlocks(HWND ctrlHandle)
/* Force the complete vector drawing to be displayed.. */
{
    int err;

    if (ctrlHandle == NULL) return;

    err = (int) SendMessage(ctrlHandle, PM_CTLSETBLOCK, -1, 0);

    if (err != PAN_CTLERRNONE) {
        Output("Couldn't reset active block.\n");
    }

    // Force re-reading of input file.
    SendMessage(ctrlHandle, PM_CTLREGEN, 0, 0);
}
```

<b>PM_CTLSETCAPS</b>
----------------------

**Purpose** Set the capabilities of a control.

**Description** If *wParam* is zero, enable the capabilities of the control specified in the **DWORD** pointed to by *lParam* (any capabilities not specified are disabled). If *wParam* is non-zero, enable all capabilities supported by the control. The mask consists of zero, one or more of the following constants ORed together.

<b>PAN_CTLCAPSZOOM</b>	can zoom
<b>PAN_CTLCAPSCOPY</b>	can copy to clipboard
<b>PAN_CTLCAPSSEARCH</b>	can search for string
<b>PAN_CTLCAPSPAGE</b>	can go to page
<b>PAN_CTLCAPSSIZE</b>	can handle resize events
<b>PAN_CTLCAPSHSCROLL</b>	can handle horizontal scroll events
<b>PAN_CTLCAPSVSCROLL</b>	can handle vertical scroll events
<b>PAN_CTLCAPSMOUSE</b>	can handle mouse events
<b>PAN_CTLCAPSKEYBD</b>	can handle keyboard events

**Parameters**

<i>wParam:</i>	<b>Zero</b>	enable capabilities specified by the mask (disable those not specified)
	<b>Non-Zero</b>	enable all capabilities supported by the control
<i>lParam:</i>	<b>(wParam:Zero)</b>	<b>(DWORD)</b> mask of capabilities
	<b>(wParam:Non-Zero)</b>	not used

**Returns:** error code

**Compatibility:** all control types

**Example:**

```
void EnableCaps(HWND ctrlHandle, DWORD caps)
/* Try to enable all the capabilities specified in the caps variable.
If one or more capabilities are not supported then none are set.*/
{
    DWORD allCaps;

    if (ctrlHandle == NULL) return;

    // get all caps of control
    SendMessage(ctrlHandle, PM_CTLGETCAPS, 1, (LPARAM) ((LPDWORD)
                                                         &allCaps));

    // enable current cap only if control support it
    if ((allCaps & caps) == caps) {
        DWORD curCaps;
        // get current caps
        SendMessage(ctrlHandle, PM_CTLGETCAPS, 0, (LPARAM)
                    ((LPDWORD) &curCaps));
    }
}
```

```
        curCaps |= caps;
        SendMessage(ctrlHandle, PM_CTLSETCAPS, 0, (LPARAM) curCaps);
    }
}
```

**PM\_CTLSETFILE**

<b>Purpose</b>	Renders the given file in the control window.	
<b>Description</b>	Render the given file in the control window. If <i>wParam</i> is not -1, it must be an index into the list of file formats returned by <b>PM_CTLGETFILEFMTS</b> . Otherwise, the first compatible format will be used.	
<b>Parameters</b>	<i>wParam</i>	file format index or -1
	<i>lParam</i> :	(LPCSTR) filename
<b>Returns:</b>	error code	
<b>Compatibility:</b>	all control types	

**Example:**

```
void ShowFile(HWND ctrlHandle, LPCSTR fileName)
/* Display the named file in the specified control. */
{
    int err;

    if (ctrlHandle == NULL) return;

    err = SendMessage(ctrlHandle, PM_CTLSETFILE, -1, (LPARAM)filename);

    if (err != PAN_CTLERRNONE) {
        Output("Couldn't display specified file\n");
    }
}
```

**PM\_CTLSETFILEEX**

<b>Purpose</b>	Renders the given file in the control window.		
<b>Description</b>	Render the given file in the control window. If <i>wParam</i> is not -1, it must be an index into the list of file formats returned by <b>PM_CTLGETFILEFMTS</b> . Otherwise, the first compatible format will be used.		
<b>Parameters</b>	<i>wParam</i>	file format index or -1	
	<i>lParam</i> :	(PAN_CTLSetFile *) filename and callback	
<b>Returns:</b>	error code		
<b>Compatibility:</b>	all control types		

**Example:**

```

/*
  Setup a user resource location procedure with the file to open in VCET window control
*/

typedef std::vector<IPanResourceInfo *>   ResourceVector;

/**      User Resource Locate Callback method */
void DMSLocateResource(ResourceVector & resources,
                      const IResourceContextInfo & context,
                      bool * pContinue) {
    // Pre-Locate (before VCET tries to locate the files)
    if(pContinue){
        // Perform Localization search
        for (ResourceVector::iterator resIter =
            resources.begin();
            resIter != resources.end(); ++resIter){

            // Find the file and obtain the resolved path
            std::vector<std::wstring> vResult =
                DMSSearch(
                    resIter->Path(),
                    resIter->Pattern(),
                    resIter->SearchPaths(),
                    context.GetBaseDirectory(),
                    context.GetProfileName(),
                    context.GetUserData());

            // Set the resolved path
            resIter->SetLocated(vResult);

            // Set the keys
            std::vector<std::wstring> vKeys =
                DMSGetID(vResults);
            resIter->SetKeys(vKeys);
        }
        // Do not continue because we have found them.
        *pContinue = false;
    }
}

```

```
    }  
}  
  
void OpenFile(const std::wstring & file_name) {  
    // Define the user resource localization structure  
    PanUserResourceLocate user_resource_locate =  
        {DMSLocateResource , my_data};  
  
    // Define the SetFile structure  
    PAN_CtlSetFile set_file = {file_name,user_resource_locate};  
  
    // Set the file  
    SendMessage(hwndCtl, PM_CTLSETFILEEX, -1, &set_file);  
    ...  
    // Load/Render the file  
    SendMessage(hwndCtl, PM_CTLPAINT, wParam, lParam);  
}
```

## Technical Note

As VCET loads the requested basefile, some external resource files may need to be located, which requires searching and possibly downloading. By default, VCET may search folders such as the basefile's directory, VCET's installation folder and XRefPaths provided by the user in the INI profile.

For applications that wish to extend VCET's resource location (beyond the INI XRefPaths customization), a callback mechanism is provided. This callback is invoked every time a resource is requested and allows the application to write their own file location algorithm that better suits their needs.

To activate the extended resource location mechanism, the application should provide a **PanUserResourceLocate**, a members of **PAN\_CtlSetFile** structure, when sending the **PM\_CTLSETFILEEX** message.

The **PanUserResourceLocate** holds two members: the callback function pointer and a void pointer that can be used to hold any user data. The following is the callback function's prototype:

```
typedef void ( * LocateProc )(std::vector<csi::IPanResourceInfo * > & vResourceInfos,
                             const IResourceContextInfo & resourceContext,
                             bool * pContinue);
```

### ResourceInfos:

The **IPanResourceInfo** vector provides information about every resource that needs to be located. Calling the **Search()** and **Download()** methods will give clear indication to what needs to be done with the requested resource.

### ResourceContext:

The resource context provides information about the environment that the resource is to be located in. This context includes that basefile's folder path, the INI profile path and the user data (void pointer) that was initially provided to the **PM\_CTLSETFILEEX** message.

### Continuation:

pContinue is a boolean pointer that can be used to indicate whether VCET should perform its location. The location process has three stages:

- Pre-locate: the application may choose to locate the resource directly without VCET's assistance.
- Core-locate: VCET performs the file searching if pre-locate didn't yield any results.
- Post-locate: the application has the opportunity to find any resources that were not found in the pre- or core-locate stages.

Following these three steps, pContinue controls the the flow of the location process. In pre-locate, the boolean pointer is valid and may receive a value of **true** (default) indicating that VCET should continue and locate the remaining missing resources, effectively enabling the core- and post-locate stages. A value of **false** will stop the location process and will leave the resources' locations dependent on pre-locate's results. This could be used when all the external resources are known to be at a certain location.

Once the core-location procedure has run, post-locate will be invoked on the resources that were not found. This stage is indicated by a **NULL** pointer in place of pContinue. This is the last chance for the resource to be found as VCET will continue loading the basefile regardless of the

---

<sup>(1)</sup> Look at Overview section about usage of STL and Boost libraries



resource location. In some cases, substitutions may be used to replace the missing resources, which may affect the display of the file.

## Locating Resources

If the application chooses to locate the resources itself, the **IPanResourceInfo** interface can be used to get the required information and set the file locations.

The resource requirements can be read from **csi::IPanResourceInfo**'s **Search()** and **Download()** functions. More often than not, both search and download will be needed in the same callback invocation.

The following is the information needed to perform the search.

- The file path indicating the wildcard expression that must match the external file name without the folder structure. The file path can be retrieved by calling the **csi::IPanResourceInfo::Path()** method.
- The pattern accompanies the file name and acts as an added filter. It is a regular expression that needs to match the located file name. It can be retrieved by invoking the **csi::IPanResourceInfo::Pattern()** function.
- The magic string is a sequencedescription of bytes that must match the first characters inside the located file. The magic string is returned by **csi::IPanResourceInfo::MagicString()**.the interface methods.
- The search paths list the folders that need to be searched. They may contain wildcard characters with the addition of the double asterisk. The search paths can be obtained from the **csi::IPanResourceInfo::SearchPaths()** method.  
It should be noted that the searching should stop after every search path and return if there is at lease one file found. A wildcard or recursive search path should be fully searched before returning the results.
- The maximum number of results is used to limit the search. It should be used as an upper bound on the number of files that are found matching the above criteria. This limit can be read from the **IPanResourceInfo::MaxResults()** method.

After the search is complete and the requested files are found, the file locations need to be added through the **csi::IPanResourceInfo::SetLocated** method that receives a vector of **csi::IPanResourceInfo::Locations**.

If the files were found in a folder not accessible to VCET, the resources will need to be copied into a local folder for parsing. This downloading process is required only on the files that have been selected for parsing. The **csi::IPanResourceInfo::ISelection** provides a way to set the downloaded, local file path for the selected files. Its iterator can be obtained from the **csi::IPanResourceInfo::GetSelected()** method.

<b>PM_CTLSETMODE</b>
----------------------

**Purpose**                      Modifies the modes of a control.

**Description**                If *wParam* is zero, enable the modes of the control specified in the mask, i.e., disable any mode which is not specified in the mask. If *wParam* is non-zero, enable all the modes of the control. The mask consists of zero, one or more of the following constants ORed together:

**PAN\_CTLMODEOPAQUE**            control is opaque  
**PAN\_CTLMODENOREDRA**        redraws are disabled (same effect as **WM\_SETREDRAW**)  
**PAN\_CTLMODEEXCESSSCROLL**    scrolling is not constrained (i.e., limited to the extents of the raster or vector image), allowing the control to scroll past the image limits.  
**PAN\_CTLMODEANISOTROPIC**      aspect ratio is not preserved  
**PAN\_CTLMODEDRAGDROP**        control accepts dropped files  
**PAN\_CTLMODEINTERRUPTIBLE**    Enables background processing for the control, allowing display operations to be interrupted while rendering. Please refer to technical note below.  
**PAN\_CTLMODEMONOCHROME**      Draw all entities in black. Only supported by the vector control.  
**PAN\_CTLMODEPRESERVECLIP**    Preserve clip region of target device.  
**PAN\_CTLMODEPRESERVEPALETTE** Preserve palette of target device.  
**PAN\_CTLMODEIGNOREMINMARGINS** Ignore printing margins.  
**PAN\_CTLMODERENDERSELECTED** Only render selected entities.  
**PAN\_CTLMODERENDERTOPRINTER** Give the same render output as a printer even the DC is not a printer.  
**PAN\_CTLMODELIMITTOONETILE** Limit to one tile in printing.  
**PAN\_CTLMODE\_HIGHLIGHT\_DIMMED** Dimmed highlight mode.  
**PAN\_CTLMODE\_DISABLE\_FORCETOBLACK\_ONRASTER** Prevents the Force-To-Black from being applied to raster overlays(images) in vector/raster overlays.  
**PAN\_CTLMODE\_TILE** CMF tile mode.  
**PAN\_CTLMODE\_FORCE\_BKG\_PAINT** Paint in force-to-black mode.

**NOTE:** The current implementation of the raster control does not support transparent or anisotropic modes when displaying monochrome images.

**Parameters**                *wParam:*                    zero or non-zero  
                                  *lParam:* (**DWORD**) mask of mode flags

**Returns:**                    error code

**Compatibility:**            all control types

**Example:**

```
void ToggleMode(HWND ctrlHandle, DWORD flg)
{
    DWORD cflg;
    BOOL   m_aniso,m_drag,m_exscr,m_noredr,m_opaq;

    if (ctrlHandle == NULL) return;
```

```
// Get current mode flags
SendMessage(ctrlHandle, PM_CTLGETMODE, 0, (LPARAM) &cflg);
m_aniso = (cflg&PAN_CTLMODEANISOTROPIC) != 0;
m_drag  = (cflg&PAN_CTLMODEDRAGDROP) != 0;
m_exscr = (cflg&PAN_CTLMODEEXCESSSCROLL) != 0;
m_noredr = (cflg&PAN_CTLMODENOREDRAW) != 0;
m_opaq  = (cflg&PAN_CTLMODEOPAQUE) != 0;

// Toggle flags specified by user
if (m_aniso) cflg |= PAN_CTLMODEANISOTROPIC;
else cflg &= ~PAN_CTLMODEANISOTROPIC;

if (m_drag) cflg |= PAN_CTLMODEDRAGDROP;
else cflg &= ~PAN_CTLMODEDRAGDROP;

if (m_exscr) cflg |= PAN_CTLMODEEXCESSSCROLL;
else cflg &= ~PAN_CTLMODEEXCESSSCROLL;

if (m_noredr) cflg |= PAN_CTLMODENOREDRAW;
else cflg &= ~PAN_CTLMODENOREDRAW;

if (m_opaq)  flg |= PAN_CTLMODEOPAQUE;
else cflg &= ~PAN_CTLMODEOPAQUE;

// Now set with the new mask
SendMessage(ctrlHandle, PM_CTLSETMODE, 0, (LPARAM) cflg);
}
```

## Technical Note

It is important that developers who enable the **PAN\_CTLMODEINTERRUPTIBLE** flag on a control be aware of issues related to background processing under Windows. Windows 3.x operates under a single system-wide message queue. As a result, while one task is processing a message, all other applications "block", and do not receive any messages until this task has finished processing its message and returns control to Windows. As a result messages that take a long time to process (e.g., searches in a database application, reading and decompressing large graphics images, long mathematical calculations, etc.) will temporarily control the CPU, and other tasks will have to wait for the message to complete.

In Windows, background processing is normally implemented by inserting:

```
if (PeekMessage(...)) {  
    GetMessage(...);  
    DispatchMessage(...);  
}
```

into the handling routines for messages that take a lot of time to process.

The Controls provide this as an option if the **PAN\_CTLMODEINTERRUPTIBLE** mode is set.

This allows users, for example, to do operations such as:

- 1- zoom/pan/scroll an image while it is displaying, without having to wait for the display to finish.
- 2- The reading of a file (e.g., a JPEG or CAD drawing) can be interrupted before finished, then another file can be displayed using the **PM\_CTLSETFILE** message.
- 3- The application can also destroy a control while it is reading a file.

The first case is handled, transparently to the application, by the control. The second and third cases *require certain modifications on the application's side*. Note that these modifications are required *only* if the **PAN\_CTLMODEINTERRUPTIBLE** mode is enabled.

To handle the second case (dropping a file while reading), the application must:

- 1- Check the status of the control
- 2- If the control is idle then set the file with **PM\_CTLSETFILE**, and proceed normally.
- 3- If the control is not idle then
  - 3a- Set the file with **PM\_CTLSETFILE**
  - 3b- Post yourself the message to set the file and return immediately.Steps 1..3 will be automatically repeated when Windows processes the message.

The code extract on the following page illustrates this:

```

#define UM_SHOWFILE          WM_USER + 10
HWND      hwndCtl;          /* Handle of the active Control */

LPARAM CALLBACK
WndProc(HWND hWnd, UINT msg, WPARAM wParam, LPARAM lParam)
{
    switch (msg) {
        case WM_SIZE: // ....
            break;
        case WM_PAINT: // ....
            break;
        // ....etc...
        case UM_SHOWFILE:
            {{{
            /*
            ** UM_SHOWFILE is a private message used by the application.
            ** wParam: Not used
            ** lParam: (LPCSTR) fname: String pointer to the file
            **           to display.
            **           If lParam is 0, then the message had been internally
generated when the control was busy.
            ** return:    0
            */

            DWORD          dwStatus = 0L;
            char            fname[_MAX_PATH];

            // If the Control is busy, try later.
            SendMessage(    m_hPanCtl, PM_CTLGETSTATUS,
                            (WPARAM)-1, (LPARAM)&dwStatus);
            if (dwStatus && lParam) {
                /*
                ** Keep a static variable so that the value is not lost when
                ** the variable goes out of context.
                */
                static char fname[_MAX_PATH];
                strcpy(fname, (LPSTR) lParam);
                /*
                ** Set the file
                */
                SendMessage(hwndCtl, PM_CTLSETFILE, (WPARAM)-1,
(LPARAM)fname);
                PostMessage(hWnd, UM_SHOWFILE, 0, 0L);
                return(0);
            } else if (lParam) {
                /*
                ** Set the file
                */
                SendMessage(hwndCtl, PM_CTLSETFILE, (WPARAM)-1,
(LPARAM)lParam);
            }
            /*
            ** Get the name of the file. If lParam is 0, then get the file
            ** name from the control.
            */
            if (lParam) {

```

```

        _fstrcpy(fname, (LPCSTR)lParam);
    } else {
        PAN_CtlFileInfo fileInfo;
        _fmemset(&fileInfo, 0, sizeof(fileInfo));
        SendMessage(hwndCtl, PM_CTLGETFILE, (WPARAM)0,
(LPARAM)&fileInfo);
        _fstrcpy(fname, fileInfo.name);
    }

    /*
    ** Proceed normally:
    */
    // ....
    return (0);
    }}} // case UM_SHOWFILE
} // switch (msg)
}

```

The handling of the third case (destroying a control while reading) is similar to that of setting a new file while reading, except the the modifications are made in the handling of the **WM\_CLOSE** message. The principle of operation remains the same:

- 1- Check the status of the control
- 2- If the control is idle then send the control the **PM\_CTLDESTROY** message and proceed normally in the destruction of the window.
- 3- If the control is not idle then
  - 3a- Send the **PM\_CTLDESTROY** message
  - 3b- Post yourself the **WM\_CLOSE** message and immediately return.
 Steps 1..3 will be automaitcally repeated when Windows processes the posted message.

The code extract on the following page illustrates:

```

HWND    hwndCtl;          /* Handle of the active Control */

LPARAM  CALLBACK
WndProc(HWND hWnd, UINT msg, WPARAM wParam, LPARAM lParam)
{
    switch (msg) {
        case WM_SIZE:
            ....
            break;
        case WM_PAINT:
            ....
            break;
            ....etc...
        case WM_CLOSE:
            {{{
                DWORD          dwStatus = 0L;

                SendMessage(m_hPanCtl, PM_CTLGETSTATUS, 0, (LPARAM)&dwStatus);

                if (hwndCtl && IsWindow(hwndCtl) && GetWindowLong(hwndCtl, 0)) {
                    SendMessage(hwndCtl, PM_CTLGETSTATUS, 0, (LPARAM)&dwStatus);
                    SendMessage(hwndCtl, PM_CTLDESTROY, (WPARAM)hwndCtl, 0);
                }

                if (! dwStatus) {
                    /*
                     ** If (control is idle)
                     **      && (no control || control has been destroyed)
                     */
                    if (hwndCtl && IsWindow(hwndCtl)) {
                        /*
                         ** Let Windows destroy the control
                         */
                        DestroyWindow(hwndCtl);
                    }
                    return TRUE;
                } else {
                    /*
                     ** If the Control is busy, try later.
                     */
                    PostMessage(WM_CLOSE, 0, 0L);
                    return FALSE;
                }
            }}} // case WM_CLOSE
    } // switch (msg)
}

```

**PM\_CTLSETOPTION**

**Purpose** Sets different control options.

**Description** Allows setting of different control options. The value of *wParam* must be one of the following options:

**PAN\_CTLCAOPTIONS** Set file specific CAD options. The CAD options are used to Enable/Disable some features (Text, Line-Styles, Filling...). This option is supported by Vector Control (2D/3D).

**PAN\_CTLOPTDIMLEVEL** Dim level, in case dim highlight mode has been selected, controls how much the rest of the drawing dimmed with respect to the highlighted items.

**Parameters** *wParam*: **PAN\_CTLCAOPTIONS** or **PAN\_CTLOPTDIMLEVEL**

*lParam*: (**wParam** = **PAN\_CTLCAOPTIONS**)  
Mask of the following CAD options flags:

**PAN\_CADOPTIONS\_NOTEXT:** Disable the text in the model.  
**PAN\_CADOPTIONS\_NODIMENSIONS** Disable dimensional primitives in the model.  
**PAN\_CADOPTIONS\_NOXREFS:** Disable XRefs in the model.  
**PAN\_CADOPTIONS\_NOFILLS:** Instructs the snapping code to consider snapping filled areas if this flag is not set.  
**PAN\_CADOPTIONS\_NOLINESTYLES:** Disable Line-Styles on all the primitives of the model. They will be drawn using solid lines.  
**PAN\_CADOPTIONS\_NOLINEWEIGHTS:** Don't consider the line thickness for model primitives.  
**PAN\_CADOPTIONS\_FASTDISPLAY:** Enable fast display rendering optimizations: whenever is possible the original model primitives will be displayed using approximation in order to speed up the rendering.  
**PAN\_CADOPTIONS\_FULLDISPLAY:** Disable any kind of rendering optimizations. However, if both full display and fast display flags are specified the fast display will have priority (i.e. the full display flag will be ignored in this case.)

(**wParam** = **PAN\_OPTDIMLEVEL**)  
(**double\***) pointer to the desired dim level.

**Returns:** error code

**Compatibility:** vector-2D

**Example:**

```
/* Set a new dim level */
double newDimLevel = 0.7;
WORD wParam = PAN_CTLOPTDIMLEVEL;
DWORD lParam = (DWORD)&newDimLevel;

...
SendMessage (hwndCtl, PM_CTLSETOPTION, wParam, lParam);
...
```



## Image-Related Command Messages

### PM\_CTLCONVERT

**Purpose** Obtain handles to conversion related functions

**Description** The control facilitates conversion from one format to another. This message allows the application to obtain the functions related to conversion. For each allowed *wParam*, a different conversion-related function is assigned to *lParam*.

**Parameters**

*wParam*: Handle specifier. One of:

- GET\_PAFSEXPOR\_T\_IDENTIFYIMAGE\_HANDLE
- GET\_PAFSEXPOR\_T\_QUERYIMAGE\_HANDLE
- GET\_PAFSEXPOR\_T\_IDENTIFY\_HANDLE
- GET\_PAFSEXPOR\_T\_QUERYFORMAT\_HANDLE
- GET\_PAFSEXPOR\_T\_QUE\_RYSUBFORMAT\_HANDLE
- GET\_PAFSEXPOR\_T\_CONVERTFILE\_HANDLE
- GET\_PAFSEXPOR\_T\_CONVERT\_HANDLE
- GET\_PAFSEXPOR\_T\_OPTIMIZEPALETTE\_HANDLE
- GET\_PAFSEXPOR\_T\_REDUCECOLORS\_HANDLE

*lParam*: (FARPROC \*) receives pointer to specified function

**Returns:** error code

**Compatibility:** all control types

**Comments:**

The functions that are retrieved by this function can be used to convert a file to a raster or vector output file.

#### GET\_PAFSEXPOR\_T\_IDENTIFYIMAGE\_HANDLE

Returns a pointer to the following function:

```
BOOL PAFSEXPOR_T_IdentifyImageDLL(LPWORD lpNumDlls);
```

This function returns the number of encoder DLLs in the variable pointed to by lpNumDlls.

#### GET\_PAFSEXPOR\_T\_QUERYIMAGE\_HANDLE

Returns a pointer to the following function:

```
BOOL PAFSEXPOR_T_QueryImageDLL(WORD index,
LPWORD lpType, LPSTR lpDesc);
```

This function returns the type and description of the image processing DLL that is associated with the specified index.

#### GET\_PAFSEXPOR\_T\_IDENTIFY\_HANDLE

Returns a pointer to the following function:

```
BOOL PAFSEXPOR_T_Identify(LPWORD wFormats,
LPWORD wSubFormats, LPWORD wOutputType);
```

When *wFormats* is NULL, this function returns the list of sub-formats and/or the list of output types for all export filters. When *wFormats* is not NULL and both other

parameters are NULL, then the number of exporters is returned in *wFormats*. When *wFormats* is not NULL and at least one other parameter is not NULL, then the sub-format and/or output type for the specified format is returned in *wSubFormats* and/or *wOutputType* respectively.

#### GET\_PAFSEXPOR\_QUERYFORMAT\_HANDLE

Returns a pointer to the following function:

```
BOOL PAFSEXPOR_QueryFormat(LONG ID, LPCVTPANX cvcbs, DWORD
dwFormat, LPSTR szModule, LPSTR szDesc);
```

This function returns the name of the export filter and the description of the output format in *szModule* and *szDesc*, respectively, for the format indexed by *dwFormat*.

#### GET\_PAFSEXPOR\_QUERYSUBFORMAT\_HANDLE

Returns a pointer to the following function:

```
BOOL PAFSEXPOR_QuerySubFormat(LONG ID,
LPCVTPANX cvcbs, DWORD dwFormat, DWORD dwSubFormat, LPSTR szDesc,
LPSTR szFilter, LPSTR szExt, LPWORD numDepths, LPWORD *wColorDepths,
LPDWORD dwOutputCaps, LPWORD wUnits, REAL *Width, REAL *Height);
```

This function returns the characteristics associated with the specified format, *dwFormat*, and sub-format, *dwSubformat*.

#### GET\_PAFSEXPOR\_CONVERTFILE\_HANDLE

Returns a pointer to the following function:

```
BOOL PAFSEXPOR_ConvertFile(LONG ID, LPCVTPANX cvcbs, DWORD
dwFormat, DWORD dwSubFormat, LPCSTR szInFileName, LPCSTR
szOutFileName);
```

This function converts the input file, *szInFileName*, to the specified format, *dwFormat* and *dwSubformat*, and outputs to the specified output file, *szOutFileName*.

#### GET\_PAFSEXPOR\_CONVERT\_HANDLE

Returns a pointer to the following function:

```
BOOL PAFSEXPOR_Convert(LPCVTPANX cvcbs, DWORD dwFormat, DWORD
dwSubFormat, LPCSTR szInFileName, LPCSTR szOutFileName);
```

This function calls **PAFSEXPOR\_ConvertFile**, but will first render the file if needed.

#### GET\_PAFSEXPOR\_OPTIMIZEPALETTE\_HANDLE

Returns a pointer to the following function:

```
BOOL PAFSEXPOR_OptimizePalette(LONG index,
HANDLE hDIB, LPRGBQUAD lpColors, WORD nColors);
```

This function constructs a color table with at most *nColors* based on the technique specified by *index* and the colormap associated with *hDIB*. The resulting color-map is returned in the array pointed to by *lpColors*.

#### GET\_PAFSEXPOR\_REDUCECOLORS\_HANDLE

Returns a pointer to the following function:

```
BOOL PAFSEXPOR_ReduceColors(LONG index,
HANDLE hDIBIn, HANDLE hDIBOut);
```

This function maps the pixels stored in *hDIBIn* to correspond with the colors associated with *hDIBOut*. The method used is specified by *index*.

**PM\_CTLFLIP**

**Purpose** Flips the contents of the control.

**Description** Flip the contents of the control depending on the given flag.

**Parameters**            *wParam*            **(WORD)** one of:  
    **PAN\_CTLFLIPNONE**  
    **PAN\_CTLFLIPX**  
    **PAN\_CTLFLIPY**  
    **PAN\_CTLFLIPXY**

*lParam*            not used

**Returns:**            error code

**Compatibility:** raster and vector-2D and controls

**Examples:**

```
int FlipInX(HWND ctrlHandle)
/* This function will flip the contents of the control along the X axis */
{
    if (ctrlHandle == NULL) return PAN_CTLERRMISC;
    return (int) SendMessage (ctrlHandle, PM_CTLFLIP, PAN_CTLFLIPX, 0);
}

int FlipInY(HWND ctrlHandle)
/* This function will flip the contents of the control along the Y axis */
{
    if (ctrlHandle == NULL) return PAN_CTLERRMISC;
    return (int) SendMessage(ctrlHandle, PM_CTLFLIP, PAN_CTLFLIPY, 0);
}

int FlipInXY(HWND ctrlHandle)
{
    if (ctrlHandle == NULL) return PAN_CTLERRMISC;
    return (int)SendMessage(ctrlHandle, PM_CTLFLIP, PAN_CTLFLIPXY, 0);
}

int FlipResetHWND ctrlHandle)
/* This function will reset the contents of the control to its original orientation */
{
    if (ctrlHandle == NULL) return PAN_CTLERRMISC;
    return (int)SendMessage(ctrlHandle, PM_CTLFLIP, PAN_CTLFLIPNONE, 0);
}
```

**PM\_CTLGETFLIP**

**Purpose**           Retrieves the current flipping state.

**Description**   Returns the flipping mode that is currently set in the control

**Parameters**

<i>wParam</i>	not used
<i>lParam</i>	( <b>int *</b> ) flip mode, one of: <b>PAN_CTLFLIPNONE</b> <b>PAN_CTLFLIPX</b> <b>PAN_CTLFLIPY</b> <b>PAN_CTLFLIPXY</b>

**Returns:**       error code

**Compatibility:** raster and vector-2D and controls

**Examples:**

```
int GetFlip(HWND ctrlHandle)
/* Sample code that retrieves the flipping mode */
{
    int flip = 0;
    SendMessage(ctrlHandle, PM_CTLGETFLIP, 0, &flip);
    return flip;
}
```

**PM\_CTLGETROTATION**

**Purpose**           Retrieves the current rotation state.

**Description**    Returns the current rotation angle in degrees set in the control.

**Parameters**

<i>wParam</i>	not used
<i>lParam</i>	<b>(int *)</b> rotation angle. Possible values are 0, 90, 180 and 270.

**Returns:**        error code

**Compatibility:** raster and vector-2D and controls

**Examples:**

```
int GetRotation(HWND ctrlHandle)
/* Sample code that retrieves the rotation angle */
{
    int rotation = 0;
    SendMessage(ctrlHandle, PM_CTLGETROTATION, 0, &rotation );
    return rotation;
}
```

**PM\_CTLGETZOOM**

**Purpose** Returns the current zoom factor.

**Parameters**

<i>wParam:</i>	<b>(WORD)</b> zoom flag, one of: <b>PAN_CTLZOOMX</b> <b>PAN_CTLZOOMY</b> <b>PAN_CTLZOOMBOTH</b>
<i>lParam:</i>	<b>(LPDWORD)</b> zoom factor in 1000th's of a percent

**Returns:** error code

**Compatibility:** all controls

**Example:**

```
void ShowZoomFactors(HWND ctrlHandle)
/*    Display the current zoom factor of the control
   on the output device. */
{
    DWORD fact[2];

    if (ctrlHandle == NULL) return;
    SendMessage(ctrlHandle, PM_CTLGETZOOM,
        PAN_CTLZOOMX, (LPARAM) &fact[0]);
    SendMessage(ctrlHandle, PM_CTLGETZOOM,
        PAN_CTLZOOMY, (LPARAM) &fact[1]);

    Output("zoom X : (%f)%%\n", (float)(fact[0]/1000.0));
    Output("zoom Y : (%f)%%\n", (float)(fact[1]/1000.0));
}
```

**PM\_CTLPAINT, PM\_CTLSIZE, PM\_CTLHSCROLL, PM\_CTLVSCROLL**

**Compatibility:** all control types

Identical to the Windows messages **WM\_PAINT**, **WM\_SIZE**, **WM\_HSCROLL**, and **WM\_VSCROLL**, respectively. Unlike the Windows messages, however, the control-specific messages are always processed, whether or not the control is visible or manages resize and scroll events directly.

The most common situations in which these messages would be used are when hidden controls are being used to format the contents of a file for printing or copying to the clipboard.

**PM\_CTLROTATE**

**Purpose** Rotates the contents of the control.

**Description** Rotate the contents of the control by the given angle in degrees.

**Parameters**            *wParam:*            **(WORD)** rotation angle in degrees.  
Possible values are 0, 90, 180 and 270.

*lParam:*            not used

**Returns:**            error code

**Compatibility:** vector 2D and raster controls

**Example:**

```
void Rotate(HWND ctrlHandle, WORD deg)
{
    if (ctrlHandle == NULL) return;
    SendMessage(ctrlHandle, PM_CTLROTATE, deg, 0);
}
```



**PM\_CTLSETZOOM**

**Purpose** Sets the zoom factor.

**Parameters**

<i>wParam:</i>	<b>(WORD)</b> zoom flag, one of: <b>PAN_CTLZOOMX</b> <b>PAN_CTLZOOMY</b> <b>PAN_CTLZOOMBOTH</b>
<i>lParam:</i>	<b>(DWORD)</b> zoom factor in 1000th's of a percent

**Returns:** error code

**Compatibility:** All

**Special Notes** When the control is in isotropic mode, **PAN\_CTLZOOMX** and **PAN\_CTLZOOMY** flags force the other zoom direction to adjust preserving the X-Y ratio. To change the Raster and Vector-2D controls' isotropic mode, send the **PAN\_CTLMODEANISOTROPIC** flag using the **PM\_CTLSETMODE** message.

**Example:**

```
void SetZoom(HWND ctrlHandle, double zoom, WORD flag)
/* Set the zoom factor. Zoom is in % so a value of 250 corresponds to a 250% zoom. Flag = one of
PAN_CTLZOOMX, PAN_CTLZOOMY, PAN_CTLZOOMBOTH.*/
{
    DWORD fct;

    if (ctrlHandle == NULL) return;

    // The message is sent with the zoom percentage multiplied by 1000.
    fct = (DWORD) (zoom * 1000);
    SendMessage(ctrlHandle, PM_CTLSETZOOM, flag, (LPARAM)fct);
}
```

## Coordinates-Related Command Messages

### PM\_CTLCARETTOWORLD

<b>Purpose</b>	Converts a caret based position to a view position.
<b>Description</b>	Text based operations (searches in particular) tend to return their results in caret based coordinates (page, flow, character offset). To perform view manipulations, world coordinates are required. This message allows the conversion of caret positions to view positions. The return value is a pointer to a static buffer in the control, from which the coordinates can be copied; or <b>NULL</b> if the translation could not be done (non-existent caret position).
<b>Parameters</b>	<p><i>wParam</i>: not used</p> <p><i>lParam</i>: (struct PAN_CtlCaretPos *) lpCaretPos;</p>
<b>Returns:</b>	(struct PAN_CtlPos *) lpViewPos
<b>Compatibility:</b>	archive, database, document, spreadsheet.

#### Example:

```
int GetViewPos(HWND ctrlHandle, struct PAN_CtlCaretPos *lpCaretPos,
               struct PAN_CtlPos *lpPos;)
/* Convert the caret position into a view coordinate. */
{
    int err;
    PAN_CtlPos *lpTmpPos;

    if (ctrlHandle == NULL)
        return PAN_CTLERRMISC;

    lpTmpPos = SendMessage(ctrlHandle, PM_CTLCARETTOWORLD, 0,
                           (LPARAM) lpCaretPos);

    if (lpTmpPos != (struct PAN_CtlPos *) NULL) {
        err = PAN_CTLERRNONE;
        *lpPos = *lpTmpPos;
    } else {
        err = PAN_GetCtlErrorCode();
    }

    return (err);
}
```

**PM\_CTLCLEARSELS**

<b>Purpose</b>	Clears all selections.	
<b>Description</b>	Clear all selections in the current file.	
<b>Parameters</b>	<i>wParam:</i>	not used
	<i>lParam:</i>	not used
<b>Returns:</b>	error code	
<b>Compatibility:</b>	all control types	

**Example:**

```
int ClearSelections(HWND ctrlHandle)
/* Clear all the selections in the control */
{
    int err;

    if (ctrlHandle == NULL)
        return PAN_CTLERRMISC;

    err = (int) SendMessage(ctrlHandle, PM_CTLCLEARSELS, 0, 0);
    return err;
}
```

<b>PM_CTLCLIENTTOWORLD</b>
----------------------------

<b>Purpose</b>	Performs a client to world coordinates conversion.
<b>Description</b>	Returns the world coordinates corresponding to the given client area coordinates (i.e., relative to the top, left corner of the client area of the control window).
<b>Parameters</b>	<i>wParam</i> : not used  <i>lParam</i> : (PAN_CtlPos *) client coordinates
<b>Returns:</b>	error code
<b>Compatibility:</b>	all control types

**Example:**

```

int ClientToWorld(HWND ctrlHandle)
/*      display the world coordinates on the output device. */
{
    PAN_CtlPos cc;
        // structure to hold the returned value,
        // this must be initialized with the values to convert
    int      err;

    if (ctrlHandle == NULL) return PAN_CTLERRMISC;

    err = SendMessage(ctrlHandle, PM_CTLCLIENTTOWORLD, 0, (LPARAM) &cc);
    if (err != PAN_CTLERRNONE)
        return err;

    Output("CLIENTTOWORLD: pt1 = (%f, %f, %f), pt2 = (%f, %f, %f)\n",
          cc.pt1.x, cc.pt1.y, cc.pt1.z,
          cc.pt2.x, cc.pt2.y, cc.pt2.z);

    return PAN_CTLERRNONE;
}

```

**PM\_CTLGETCARETPOS**

<b>Purpose</b>	Returns the current position of the caret within a text stream.
<b>Description</b>	This message allows an application to obtain the current position of the caret in the control.
<b>Parameters</b>	<i>wParam:</i> not used  <i>lParam:</i> <b>(PAN_CtlCaretPos *)</b> caret position
<b>Returns:</b>	error code
<b>Compatibility:</b>	archive, database, document, spreadsheet.

**Example:**

```

void ShowCaretOffset(HWND ctrlHandle)
/*      Display the offset of the file on the output device. */
{
    int          err;
    PAN_CtlCaretPos CaretPos;

    if (ctrlHandle == NULL) return;

    err = (int) SendMessage(PM_CTLGETCARETPOS, 0,
        (LPARAM) ((PAN_CtlCaretPos *) &CaretPos));

    if (err != PAN_CTLERRNONE) {
        Output("Couldn't get caret position\r");
    } else {
        Output("CaretPos = (%d, %ld, %ld)\n",
            CaretPos.page, CaretPos.flow, CaretPos.offset);
    }
    return;
}

```

<b>PM_CTLSETCARETPOS</b>
--------------------------

<b>Purpose</b>	Sets the caret to the specified position
<b>Description</b>	The position is specified as an offset within a flow on a specified page.
<b>Parameters</b>	<i>wParam:</i> not used. <i>lParam:</i> (PAN_CtlCaretPos *) lpCaretPos;
<b>Returns:</b>	error code
<b>Compatibility:</b>	archive, database, document, spreadsheet.

**Example:**

```

void HomeCursor(HWND ctrlHandle)
/* Move the caret to the start of the information stream in the current */
/* information stream and page. */
{
    int err;
    PAN_CtlCaretPos curPos;

    if (ctrlHandle == NULL) return;

    err = SendMessage(ctrlHandle, PM_CTLGETCARETPOS, 0,
        (LPARAM) ((PAN_CtlCaretPos *) &curPos));

    if (err != PAN_CTLERRNONE) {
        Output("Couldn't get current caret position.\n");
        return;
    }

    curPos.offset = 0;

    SendMessage(ctrlHandle, PM_CTLSETCARETPOS, 0,
        (LPARAM) ((PAN_CtlCaretPos *) &curPos));
}

```

**PM\_CTLWORLDTOCARET**

<b>Purpose</b>	Converts a view based position to a caret position..
<b>Description</b>	This message allows the caller to convert a view based coordinate into a caret based position.
<b>Parameters</b>	<i>wParam:</i> not used <i>lParam:</i> (struct PAN_CtlPos *) lpViewPos
<b>Returns:</b>	(struct PAN_CtlCaretPos *) lpCaretPos;
<b>Compatibility:</b>	archive, database, document, spreadsheet.

**Example:**

```

void ShowCaretPos(HWND ctrlHandle, struct PAN_CtlPos *lpPos)
/* Display the caret position that corresponds to the specified view coordinate. */
{
    PAN_CtlCaretPos *lpCtPos;
    int err;

    if (ctrlHandle == NULL)
        return;

    *lpCtPos = SendMessage(ctrlHandle,
        PM_CTLWORLDTOCARET, 0, (LPARAM) lpPos);

    if (*lpPos != (struct PAN_CtlPos *) NULL) {
        Output("Coordinate = page %d, flow %ld, offset %ld\n",
            lpCtPos->page, lpCtPos->flow, lpCtPos->offset);
    }
}

```

**PM\_CTLWORLDTOCLIENT**

<b>Purpose</b>	Performs a world to client coordinates conversion.
<b>Description</b>	Returns the client area coordinates (i.e., relative to the top, left corner of the client area of the control window) corresponding to the given world coordinates.
<b>Parameters</b>	<i>wParam</i> : not used  <i>lParam</i> : ( <b>PAN_CtlPos *</b> ) world coordinates
<b>Returns:</b>	error code
<b>Compatibility:</b>	all control types

**Example:**

```

void ShowWorldToClient(HWND ctrlHandle)
/* Display on the output device (see the Output() function). */
{
    PAN_CtlPos cc;
    Send(PM_CTLCLIENTTOWORLD, 0, (LONG) &cc);
    Output("CLIENT COORD x=%d y=%d\r", cc.x, cc.y);
}

//-----

// Function used by several code examples in this manual.
void Output(char* fmt, ...)
{
    va_list args;
    static char buff[1025];

    strcpy(buff, ""); /* Format message string. */
    va_start(args, fmt);
    vsprintf(buff, fmt, args);
    va_end(args);

    /* Write code to send the buffer to the desired output device*/
}

```



**PM\_CTLXFRMRECT**

<b>Purpose</b>	Apply the current control rotation and flipping transform.
<b>Description</b>	Transforms a world coordinate range by applying current rotation/flipping. Can also perform the inverse operation i.e. Undo rotation/flip transformation..
<b>Parameters</b>	<div><div><div><div><i>wParam:</i></div><div>XFRM_FNC</div><div>Apply transformation</div></div><div><div>XFRM_FNC_RECIPROCAL</div><div>Undo transformation.</div></div></div><div><div><i>lParam:</i></div><div>(PAN_CtlRange *) world coordinates.</div></div></div>
<b>Returns:</b>	error code
<b>Compatibility:</b>	Vector and Raster controls.

**Example:**

```
/* Apply rotation and filling to a world coordinates rectangle */
```

```
PAN_CtlRange rect = ...
```

```
SendMessage (hwndCtl, PM_CTLXFRMRECT, XFRM_FNC, (LPARAM)&rect);
```

**PM\_CTLCOPY**

<b>Purpose</b>	Copy the current selections to the clipboard.
<b>Description</b>	Copy the current selections to the clipboard using the clipboard formats specified in the given mask of <b>PAN_CtlClpbrd</b> constants.
<b>Parameters</b>	<i>wParam:</i> not used <i>lParam:</i> <b>(DWORD)</b> format(s)
<b>Returns:</b>	error code
<b>Compatibility:</b>	all control types

**Example:**

```
void CopyToClipboard(HWND ctrlHandle, DWORD clpbFlgs)
```

```
/*
```

```
Copy the control's contents to the clipboard using the clipboard formats specified by clpbFlgs. First we clear all the
selections, then get the current page size and send the message to copy.*/
```

```
{
    PAN_CtlRange rg;    // structure to hold the page extents
    DWORD        pg;    // page number

    if (ctrlHandle == NULL) return;

    SendMessage(ctrlHandle, PM_CTLGETPAGE, 0, (LPARAM) &pg);
    SendMessage(ctrlHandle, PM_CTLGETPAGESIZE, pg, (LPARAM) &rg);
    SendMessage(ctrlHandle, PM_CTLCLEARSEL, 0, 0);
    SendMessage(ctrlHandle, PM_CTLSETSEL, TRUE, (LPARAM) &rg);
}
```

**PM\_CTLGETCLPBRDFMTS**

<b>Purpose</b>	Returns clipboard formats supported by a control.		
<b>Description</b>	Return a description of each clipboard format supported by the control in the <b>PAN_CtlClpbrdFmtList</b> structure pointed to by <i>lParam</i> .		
<b>Parameters</b>	<i>wParam</i> :	not used	
	<i>lParam</i> : clipboard formats	<b>(PAN_CtlClpbrdFmtList *)</b>	supported
<b>Returns:</b>	error code		
<b>Compatibility:</b>	all control types		

**Example:**

```

void ShowClpbrdFmts(HWND ctrlHandle)
/*      display the list of clipboard formats supported by the control. */
{
    PAN_CtlClpbrdFmtList fl;          // pointer to the fmt list
    PAN_CtlClpbrdFmt * cf; // pointer to the format structure
    WORD                i;
    char                desc[PAN_CTLMAXDESC];

    if (ctrlHandle == NULL) return;
    SendMessage(ctrlHandle, PM_CTLGETCLPBRDFMTS, 0, (LPARAM) &fl);
    cf = (PAN_CtlClpbrdFmt *) GlobalLock(fl.hFmts);
    for (i=0; i<fl.nFmts; i++) {
        Output("%s", cf[i]. desc);      // display format description
    }
    GlobalUnlock(fl.hFmts);
}

```

**PM\_CTLGETNUMSELS**

<b>Purpose</b>	Returns the current number of selections		
<b>Description</b>	Returns the current number of selections in the <b>WORD</b> pointed to by <i>lParam</i> . The number of selections, if any, is always one for vector controls, one for raster and one per page for document. Archive, database and spreadsheet controls can have more than one selection.		
<b>Parameters</b>	<i>wParam</i> :	not used	
	<i>lParam</i> :	<b>(LPWORD)</b> number of selections	
<b>Returns:</b>	error code		
<b>Compatibility:</b>	all control types		

**Example:**

```
void ShowNumSelection(HWND ctrlHandle)
/*      Display the current number of selections on the output device. */
{
    DWORD nsels;

    if (ctrlHandle == NULL) return;

    SendMessage(ctrlHandle, PM_CTLGETNUMSELS, 0, (LPARAM) &nsels);
    Output("Number of selections=%d\n", nsels);
}
```

<b>PM_CTLGETSELS</b>
----------------------

<b>Purpose</b>	Returns a list of the current selections.
<b>Description</b>	Return a list of the current selections for the current file in the <b>PAN_CtlSelList</b> structure pointed to by <i>lParam</i> .
<b>Parameters</b>	<div> <i>wParam</i>: not used </div> <div> <i>lParam</i>: (<b>PAN_CtlSelList *</b>) pointer to selections list </div>
<b>Returns:</b>	error code
<b>Compatibility:</b>	all control types

**Example:**

```

void ShowSelections(HWND ctrlHandle)
/*      Display the list of current selections on the output device. */
{
    PAN_CtlSelList sl;
    PAN_CtlSel *    s;

    if (ctrlHandle == NULL) return;

    SendMessage(ctrlHandle, PM_CTLGETSELS, 0, (LPARAM) &sl);
    s = (PAN_CtlSel *) GlobalLock(sl.hSels);
    for (WORD i = 0; i < sl.nSels; i++) {
        switch (s[i].type) {
            case CTLSEL_VIEW:
                Output(" (VIEW COORDS) = (%f, %f, %f) - (%f, %f, %f)\n",
                    s[i].range.vwRange.pt1.x, s[i].range.vwRange.pt1.y,
                    s[i].range.vwRange.pt1.z,
                    s[i].range.vwRange.pt2.x, s[i].range.vwRange.pt2.y,
                    s[i].range.vwRange.pt2.z);
                break;

            case CTLSEL_CARET:
                Output(" (CARET COORD) “);
                Output(“from = (page %d, flow %d, offset %ld), ”,
                    s[i].range.ctRange.from.page, s[i].range.ctRange.from.flow,
                    s[i].range.ctRange.from.offset);
                Output(“to = (page %d, flow %d, offset %ld)\n”,
                    s[i].range.ctRange.to.page, s[i].range.ctRange.to.flow,
                    s[i].range.ctRange.to.offset);
                break;
        } /* switch */
    } // end for
}

```

**PM\_CTLSETSEL**

<b>Purpose</b>	Sets or removes a selection based on view coordinates.		
<b>Description</b>	If the selection flag is <b>TRUE</b> , set the given selection in the current file, otherwise, remove the given selection if it exists.		
<b>Parameters</b>	<i>wParam</i>	<b>(BOOL)</b>	selection flag
	<i>lParam</i> :	<b>(const PAN_CtlRange *)</b>	selection
<b>Returns:</b>	error code		
<b>Compatibility:</b>	all control types		

**Example:**

```
void SetSelectionRaster(HWND ctrlHandle, WORD x, WORD y, WORD w,
                        WORD h)
{
    PAN_CtlRange rg;

    if (ctrlHandle == NULL)
        return;

    rg.min.x = x;
    rg.min.y = y;
    rg.min.z = 0.0;
    rg.max.x = x + w;
    rg.max.y = y + h;
    rg.max.z = 0.0;
    SendMessage(ctrlHandle, PM_CTLSETSEL, TRUE, (LPARAM)&rg);
}
```

**PM\_CTLSETSELCARET**

**Purpose** Sets or removes a selection based on caret coordinates.

**Description** If the selection flag is **TRUE**, set the given selection in the current file; otherwise, remove the given selection if it exists.

Caret based selection within tabular data works as follows: The from and to flows are converted to (row, column) pairs. The selection is made of all cells between the two specified rows and two columns. Page numbers in the caret range are ignored when used for creating selections in tabular data. By using this technique, all table selections are rectangular regions.

**Parameters**

*wParam:*           **(BOOL)** selection flag

*lParam:*           **(const PAN\_CtlCaretRange \*)** selection

**Returns:** error code

**Compatibility:** archive, database, document, spreadsheet.

**Example:**

```
void SetSelection(HWND ctrlHandle, PAN_CtlCaretPos pt1,
    PAN_CtlCaretPos pt2)
{
    PAN_CtlCaretRange rg;

    if (ctrlHandle == NULL)
        return;

    rg.from = pt1;
    rg.to = pt2;

    SendMessage(ctrlHandle, PM_CTLSETSELCARET, TRUE,
        (LPARAM) &rg);
}
```

## Color-Related Command Messages

### PM\_CTLGETFGBGCOLOR

<b>Purpose</b>	Returns the foreground or background color.		
<b>Description</b>	If <i>wParam</i> is zero, return the current foreground color. If <i>wParam</i> is non-zero, return the current background color.		
<b>Parameters</b>	<i>wParam:</i>	<b>0</b>	Foreground Request
		<b>≠0</b>	Background Request
	<i>lParam:</i>	<b>(LPCOLORREF)</b> color	
<b>Returns:</b>	error code		
<b>Compatibility:</b>	all control types		

#### Example:

```
typedef struct { char R,G,B; } RGB;

int GetFgBgColor(HWND ctrlHandle, RGB* fg, RGB* bg)
/* Return the foreground and background colors of the control */
{
    int err;
    COLORREF c;

    if (ctrlHandle == NULL || fg == NULL || bg == NULL) return PAN_CTLERRMISC;

    // Get foreground color
    err=(int) SendMessage(ctrlHandle, PM_CTLGETFGBGCOLOR, 0, (LPARAM)&c);
    if (err != PAN_CTLERRNONE) return err;
    fg->R = GetRValue(c);
    fg->G = GetGValue(c);
    fg->B = GetBValue(c);

    // Get background color
    err=(int) SendMessage(ctrlHandle, PM_CTLGETFGBGCOLOR, 1, (LPARAM) &c);
    if (err != PAN_CTLERRNONE) return err;
    bg->R = GetRValue(c);
    bg->G = GetGValue(c);
    bg->B = GetBValue(c);

    return PAN_CTLERRNONE;
}
```



**PM\_CTLGETPALETTE**

<b>Purpose</b>	Returns palette information.
<b>Description</b>	Return the color depth of the current file. If <i>lParam</i> points to a <b>LOGPALETTE</b> structure, the size of which corresponds to the number of colors, it is filled with the file's palette, if any.
<b>Parameters</b>	<i>wParam</i> :           not used  <i>lParam</i> : <b>(LOGPALETTE *)</b> logical palette
<b>Returns:</b>	<b>(WORD)</b> color depth on success or -1 on failure
<b>Compatibility:</b>	raster and vector-2D controls

**Example:**

```

void ShowPalette(HWND ctrlHandle, int ncol)
/*      Display the palette used by the displayed file. */
{
    LPLOGPALETTE palette;
    int err, indx;

    if (ctrlHandle == NULL) return;

    palette = fmalloc(sizeof(LOGPALETTE + (255) * sizeof(PALETTEENTRY)));
    if (palette == NULL) {
        Output("Couldn't allocate storage for palette\n");
        return;
    }

    err = SendMessage(ctrlHandle, PM_CTLGETPALETTE, 0, (LPARAM) palette);

    if (err == -1) {
        Output("Couldn't get palette\n");
    } else {
        for (indx = 0; indx <= palette->palNumEntries; indx++) {
            Output("PAL[%d] = (%d, %d, %d)\n", indx,
                palette->palPalEntry[indx].peRed,
                palette->palPalEntry[indx].peGreen,
                palette->palPalEntry[indx].peBlue);
        }
    }
}

```

**PM\_CTLPALETTECHANGED**

<b>Purpose</b>	The calling application must send this message to the control whenever it receives a <b>WM_PALETTECHANGED</b> message.		
<b>Description</b>	The window handle specified in <i>wParam</i> is the same window handle as that specified in <i>wParam</i> for the <b>WM_PALETTECHANGED</b> message. Handled identically as a <b>WM_PALETTECHANGED</b> message.		
<b>Parameters</b>	<i>wParam</i> : the palette.	<b>(HWND)</b> Handle of the window which	changed
	<i>lParam</i> :	not used	
<b>Returns:</b>	error code		
<b>Compatibility:</b>	all control types		

**PM\_CTLQUERYNEWPALETTE**

<b>Purpose</b>	The calling application must send this message to the control whenever it receives a <b>WM_QUERYNEWPALETTE</b> message. Handled identically to <b>WM_QUERYNEWPALETTE</b> message. Useful for debugging purposes.		
<b>Parameters</b>	<i>wParam:</i>	<b>(HWND)</b> Handle of window for which to realize the new palette.	
	<i>lParam:</i>	not used	
<b>Returns:</b>	error code		
<b>Compatibility:</b>	all control types		

**PM\_CTLSETFGBGCOLOR**

<b>Purpose</b>	Sets the foreground or background color.
<b>Description</b>	Sets the foreground/background color. Can be done with or without updating the control window.
<b>Parameters</b>	<i>wParam:</i> 0      Set foreground color and update window. 1      Set background color and update window. 2      Set foreground color without updating. 3      Set background color without updating.  <i>lParam:</i> <b>(const COLORREF *)</b> color
<b>Returns:</b>	error code
<b>Compatibility:</b>	all control types

**Example:**

```
// use these defines to initialize which for SetColor below
#define SET_FOREGROUND 0
#define SET_BACKGROUND 1

void SetColor(HWND ctrlHandle, char r, char g, char b, int which)
{
    COLORREF color = RGB(r, g, b);

    if (ctrlHandle == NULL) return;
    SendMessage(ctrlHandle, (WPARAM) which, (LPARAM) &color);
}
```

**PM\_CTLSETPALETTE**

<b>Purpose</b>	Sets the color palette.
<b>Description</b>	Set the color palette of the current file.
<b>Parameters</b>	<i>wParam:</i> not used <i>lParam:</i> ( <b>LOGPALETTE *</b> ) logical palette
<b>Returns:</b>	error code
<b>Compatibility:</b>	raster and vector-2D controls

**Example:**

```
extern LOGPALETTE *lp;  
  
void Reset8Palette(HWND ctrlHandle)  
{  
    if (ctrlHandle == NULL) return;  
  
    SendMessage(ctrlHandle, PM_CTLSETPALETTE, 0, lp);  
}
```

## Views-Related Command Messages

### PM\_CTLGETVIEW

<b>Purpose</b>	Gets the “active named-view” being displayed by the control.	
<b>Parameters</b>	<i>wParam:</i>	Not used
	<i>lParam:</i>	(PAN_VIEW *) current view
<b>Returns:</b>	(BOOL) FALSE means no view defined, TRUE indicates valid view being used.	
<b>Compatibility:</b>	vector.	

#### Example:

```
void ShowViewName(HWND ctrlHandle)
/*      Display the name of the view currently being viewed. */
{
    BOOL ViewStatus;
    PAN_VIEW curView;

    if (ctrlHandle == NULL) return;

    ViewStatus = SendMessage(ctrlHandle, PM_CTLGETVIEW, 0,
                             (LPARAM) (PAN_VIEW *) &curView);
    if (ViewStatus) {
        Output("Current view name = %s\r", curView.name);
    } else {
        Output("No named view currently defined\n");
    }
}
```

## PM\_CTLGETVIEWEXTENTS

<b>Purpose</b>	Returns the current view extents of the current file in view coordinates.
<b>Description</b>	In order to get the same values as were set with <b>PM_CTLSETVIEWEXTENTS</b> , the control's mode has to be set to anisotropic.
<b>Parameters</b>	<p><i>wParam:</i> not used</p> <p><i>lParam:</i> (<b>PAN_CtlRange *</b>) extents</p>
<b>Returns:</b>	error code
<b>Compatibility:</b>	all control types

### Example:

```

/* Display the view extents of the current page on the output device */
void ShowViewExtents(HWND ctrlHandle)
{
    PAN_CtlRange rg;

    if (ctrlHandle == NULL) return;
    SendMessage(ctrlHandle, PM_CTLGETVIEWEXTENTS, 0, (LPARAM)
        Output("VIEWEXTENTS: min = (%f, %f, %f)\n", rg.min.x, rg.min.y,
        Output("VIEWEXTENTS: max = (%f, %f, %f)\n", rg.max.x, rg.max.y,
        rg.max.z);
    &rg);
    rg.min.z);
}

```

**PM\_CTLGETVIEWNAMES**

<b>Purpose</b>	Returns the buffer of “view” names set by <b>PANX_SetViews()</b> .
<b>Description</b>	Vector files can define view names which the decoder passes to the core using the <b>PANX_SetViews</b> callback. This message provides a means for the application of obtaining this information from the control.
<b>Parameters</b>	<i>wParam:</i> <b>(int)</b> number of views to return  <i>lParam:</i> <b>(PAN_VIEW *)</b> view buffer
<b>Returns:</b>	Number of views returned in buffer pointed to by <i>lParam</i> , 0 for now views, -1 on failure.
<b>Compatibility:</b>	vector.

**Example:**

```
void ShowAvailViews(HWND ctrlHandle)
/*      Display a list of up to the first 64 available named views. */
{
    int numAvail;
    PAN_VIEW ViewBuf[64];

    if (ctrlHandle == NULL) return;

    numAvail = SendMessage(ctrlHandle, PM_CTLGETVIEWNAMES, 64,
                           (LPARAM) ((PAN_VIEW *) ViewBuf));
    if (numAvail <= 0) {
        Output("No named views available.\r");
    } else {
        int indx;
        for (indx = 0; indx < numAvail; indx++) {
            Output("View %d = %s\r", indx, ViewBuf[indx].name);
        }
    }
}
```



**PM\_CTLSETVIEW**

**Purpose** Sets the view to use in the control.

**Description** If a vector decoder supports different views, it can determine which view to render through the **PANX\_GetView** callback. This message allows the application to choose the view that will be decoded.

If view number -2 is specified, the application is specifying a user-defined view that may be set through the view info parameter. View number -1 indicates that the default view should be used. Other view numbers should specify views that are defined within the file.

**Parameters**

*wParam:*           **(WORD)** view number

*lParam:*           **(PAN\_VIEW \*)** view info

**Returns:** error code

**Compatibility:** vector.

**Example:**

```
void ShowView(HWND ctrlHandle, int newView, PAN_VIEW *nViewSpecs)
/*      Display the specified view. */
{
    int err;
    PAN_VIEW *oldViews;

    if (ctrlHandle == NULL) return;

    if (newView >= 0) {
        oldViews = fmalloc((newView + 1) * sizeof(PAN_VIEW));
        if (oldViews == (PAN_VIEW *) NULL) {
            Output("Couldn't allocate space for views list\n");
            return;
        }

        err = SendMessage(ctrlHandle, PM_CTLGETVIEWS, newView + 1,
            (LPARAM) oldViews);

        if (err != PAN_CTLERRNONE) {
            Output("Couldn't get specified view parameters\n");
            return;
        }

        *nViewSpecs = *(oldViews + newView);
    }

    err = (int) SendMessage(ctrlHandle, PM_CTLSETVIEW, newView,
        nViewSpecs);

    if (err != PAN_CTLERRNONE) {
        Output("Couldn't set specified view\n");
    }
}
```

## PM\_CTLSETVIEWEXTENTS

<b>Purpose</b>	Sets the view extents of the current file in view coordinates.	
<b>Description</b>	Set the view extents of the current file in view coordinates. If the width member is zero, then only the x, y (, z) members are used to position the top-left corner of the control window. This message can also be used to zoom in or out for controls with zooming capability.	
<b>Parameters</b>	<i>wParam:</i>	not used
	<i>lParam:</i>	(const PAN_CtlRange *) extents
<b>Returns:</b>	error code	
<b>Compatibility:</b>	all control types	

### Example:

```
typedef struct {
double m_x, m_y, m_width, m_height;
} EXTENTS;

void SetViewExtent(HWND ctrlHandle, EXTENTS dlg)
{
    PAN_CtlRange rg;

    rg.min.x = dlg.m_x;
    rg.min.y = dlg.m_y;
    rg.min.z = 0.0;

    rg.max.x = dlg.m_x + dlg.m_width;
    rg.max.y = dlg.m_y + dlg.m_height;
    rg.max.z = 0.0;

    SendMessage(ctrlHandle, PM_CTLSETVIEWEXTENTS, 0,
                (LPARAM) &rg);
}
```

## Blocks-Related Command Messages

### PM\_CTLGETBLOCK

<b>Purpose</b>	Gets the “active block” from the control.	
<b>Description</b>	Get the current “active block” for the current page and set it in the <b>long</b> pointed to by <i>lParam</i> .	
<b>Parameters</b>	<i>wParam:</i>	Not used
	<i>lParam:</i>	<b>(long *)</b> current block. Set to zero if the page contains no blocks or if the whole page is active.
<b>Returns:</b>	error code	
<b>Compatibility:</b>	vector	
<b>Example:</b>		

```
void OutputCurBlock(HWND ctrlHandle)
/* Display the ID of the currently active block */
{
    long    activeBlock;

    if (ctrlHandle == NULL) return;

    int err = SendMessage(ctrlHandle, PM_CTLGETBLOCK, 0,
                          (LPARAM) &activeBlock);

    if (err != PAN_CTLERRNONE) {
        Output("Incompatible control\n");
    } else {
        Output("Current block = %ld\n", activeBlock);
    }
    return;
}
```

<b>PM_CTLGETBLOCKNAMES</b>
----------------------------

<b>Purpose</b>	Returns the buffer of block names set by the decoder.
<b>Description</b>	Get the names of the number of blocks specified in <i>wParam</i> and set them in the location specified by <i>lParam</i> .
<b>Parameters</b>	<i>wParam</i> : (WORD) number of block names to retrieve.  <i>lParam</i> : (PAN_BLOCK *) block structure
<b>Returns:</b>	Number of blocks returned Number of total blocks if <i>lParam</i> is NULL 0 if no blocks exist -1 if error
<b>Compatibility:</b>	vector
<b>Restrictions:</b>	All blocks will be returned if more than the total is requested.

**Example:**

```

void ShowBlockNames(HWND ctrlHandle)
/* Outputs a list of block names. */
{
    LONG        NumBlocks;
    PAN_BLOCK    Blocks[64];

    if (ctrlHandle == NULL) return;

    NumBlocks = SendMessage(ctrlHandle, PM_CTLGETBLOCKNAMES, 64, (LPARAM) Blocks);

    switch (NumBlocks) {
    case -1:
        Output("Incompatible control type\n");
        break;

    case 0:
        Output("No blocks defined\n");
        break;

    default:
        Output("%ld Blocks:\n", NumBlocks);
        for (LONG indx = 0; indx < NumBlocks; indx++) {
            Output("Block %ld = %s\n", indx, Blocks[indx].name);
        }
    }

    return;
}

```

**PM\_CTLSETBLOCK**

<b>Purpose</b>	Sets the “active block” in the control.
<b>Description</b>	Vector decoders may offer the capability of decoding blocks of a file. This message allows the application to set the block number that will be returned to the decoder when it calls the <b>PANX_GetBlock</b> callback.
<b>Parameters</b>	<i>wParam:</i> <b>(WORD)</b> block number, 0 for the whole page  <i>lParam:</i> not used
<b>Returns:</b>	error code
<b>Compatibility:</b>	vector
<b>Special Notes:</b>	This message will force a repaint, If an invalid block is specified, the last block will be set.

**Example:**

```
void ShowBlock(HWND ctrlHandle, WORD blockNo)
/* Display the specified block */
{
    if (ctrlHandle == NULL) return;

    int err = SendMessage(ctrlHandle, PM_CTLSETBLOCK, blockNo, 0);

    if (err != PAN_CTLERRNONE) {
        Output(“Couldn’t set active block\n”);
        return;
    }

    SendMessage(ctrlHandle, PM_CTLREGEN, 0, 0);
}
```

## Entity-Related Command Messages

### PM\_CTLGETENTITY

<b>Purpose</b>	Used with CAD decoders to obtain identifiers to objects within a specified region of the viewed drawing.
<b>Description</b>	<p>When displaying a vector file that supports entities, this message provides a means of obtaining all handles within a specified region.</p> <p>The region may be defined as a bounding box in world coordinates, or by specifying a single point in world coordinates (by setting the minimum equal to the maximum point of the bounding box) and a radius in terms of screen coordinates.</p>
<b>Parameters</b>	<p><i>wParam</i>: unused</p> <p><i>lParam</i>: (PAN_CtlGetEntityInfo *) lpGetEntity</p>
<b>Returns:</b>	error code
<b>Compatibility:</b>	Vector controls when viewing files that support entity handles. This may be determined by checking the CTL_FILE_HINT_EDAT bit within the hints flag obtained using PM_CTLGETFILE.

#### Example:

```
int ShowEntities(HWND ctrlHandle, PAN_CtlRange where)
/* Output the dimensions of an archive, database, or spreadsheet control */
/* in terms of rows and columns. */
{
    int err;
    struct PAN_CtlEntity myEntities;

    if (ctrlHandle == NULL)
        return (PAN_CTLERRMISC);

    myEntities.bbox = where;
    myEntities.iThreshold = 0;

    // Get control dimensions.
    err = (int) SendMessage(ctrlHandle, PM_CTLGETENTITY, 0,
        (LPARAM) (struct PAN_CtlEntity *) &dimensions);

    if (err == PAN_CTLERRNONE) {
        Output("Number of entities in region = %d\n", myEntities.nFound);
        GlobalFree(myEntities.hFound);
    }
    return (err);
}
```

**PM\_CTLSHOWENTITY**

<b>Purpose</b>	Used with CAD decoders to set the drawing color of a given entity e.g. to highlight a selected entity.
<b>Description</b>	The message can be used to modify the drawing color/mode of an entity. It can also be used to restore the entity's original color.
<b>Parameters</b>	<p><i>wParam:</i> Negative of the number of elements pointed to by <i>lParam</i>. 0 or -1 indicate 1 element in the list.</p> <p><i>lParam:</i> (<b>PAN_CtlShowEntity *</b>) pShowEntity NULL indicates that all current selections should be removed.</p>
<b>Returns:</b>	error code
<b>Compatibility:</b>	vector-2D
<b>Restrictions:</b>	This functionality is only available when viewing files that support entity handles. This may be determined by checking the CTL_FILE_HINT_EDAT bit within the hints flag obtained using PM_CTLGETFILE.

## Extended Image Data-Related Command Messages

### PM\_CTLGETIMAGEEX

<b>Purpose</b>	Retrieves the current contrast/anti-aliasing setting of an image.
<b>Description</b>	This message only applies to monochrome raster images. All other image classes return <b>PAN_CTLERRNOTCOMPATIBLE</b> .
<b>Parameters</b>	<p><i>wParam</i>:           <b>(WORD)</b> input, one of <b>PAN_IMAGE_CONTRAST</b>, <b>PAN_IMAGE_ANTIALIAS</b> or <b>PAN_IMAGE_INVERT</b>.</p> <p><i>lParam</i>: <b>(wParam = PAN_IMAGE_CONTRAST)</b>  <b>(int*)</b>   output receiving a contrast value between -100 to 100.  <b>(wParam = PAN_IMAGE_ANTIALIAS)</b>  <b>(BOOL*)</b> output receiving <b>TRUE</b> or <b>FALSE</b> indicating the current anti-aliasing mode.  <b>(wParam = PAN_IMAGE_INVERT)</b>  <b>(BOOL*)</b> output receiving <b>TRUE</b> or <b>FALSE</b> indicating the current inversion mode.</p>
<b>Returns</b>	error code
<b>Compatibility:</b>	raster and vector-2D controls
<b>Restrictions</b>	<b>PAN_IMAGE_CONTRAST</b> and <b>PAN_IMAGE_INVERT</b> are only used for monochrome raster images either in the raster control or overlaid onto a vector-2D format.

#### Example:

```
void ShowMonoOptions(HWND ctrlHandle)
/* Show the options being used to display a monochrome raster image. */
{
    int err=0;
    int contrast;
    BOOL antialias;

    if (ctrlHandle == NULL)
        return;

    err = (int)SendMessage(ctrlHandle, PM_CTLGETIMAGEEX, PAN_IMAGE_CONTRAST, (LPARAM)
        ((int_far *) &contrast));

    if (err != PAN_CTLERRNONE) return;
    Output("Contrast for current image = %d\n", contrast);

    err = (int)SendMessage(ctrlHandle, PM_CTLGETIMAGEEX,
        PAN_IMAGE_ANTIALIAS, (LPARAM) ((int_far *) &antialias));

    if (err != PAN_CTLERRNONE) return;
    Output("Antialiasing is %s\r", antialias ? "enabled" : "disabled");}
```



<b>PM_CTLSETIMAGEEX</b>
-------------------------

<b>Purpose</b>	Adjusts the contrast/anti-aliasing setting on an image.
<b>Description</b>	This message only applies to monochrome raster images. All other image classes return <b>PAN_CTLERRNOTCOMPATIBLE</b> .
<b>Parameters</b>	<p><i>wParam</i>:           <b>(WORD)</b> input, one of:                            <b>PAN_IMAGE_CONTRAST</b>,                            <b>PAN_IMAGE_ANTIALIAS</b> or           <b>PAN_IMAGE_INVERT</b>.</p> <p><i>lParam</i>: <b>(wParam = PAN_IMAGE_CONTRAST)</b>                    <b>(int)</b>     input, contrast setting -100 (darkest) to 100 (lightest),                                default:0                    <b>(wParam = PAN_IMAGE_ANTIALIAS)</b>                            <b>(BOOL)</b> input, anti-aliasing, <b>TRUE</b>                                        (on) or <b>FALSE</b> (off), default: off.                    <b>(wParam = PAN_IMAGE_INVERT)</b>                            <b>(BOOL)</b> input, color inversion, <b>TRUE</b>                                        (on) or <b>FALSE</b> (off), default: off.</p>
<b>Returns</b>	error code
<b>Compatibility</b>	raster and vector-2D controls
<b>Restrictions</b>	<b>PAN_IMAGE_CONTRAST</b> and <b>PAN_IMAGE_INVERT</b> are only used for monochrome raster images either in the raster control or overlaid onto a vector-2D format.

**Example**

```
void ResetMonoOpts(HWND ctrlHandle)
/* Resets the monochrome rendering options to a contrast of 0, and */
/* disables anti-aliasing. */
{
    int err;

    if (ctrlHandle == NULL) return;

    err = SendMessage(ctrlHandle, PM_CTLSETIMAGEEX,
        PAN_IMAGE_CONTRAST, 0);
    if (err != PAN_CTLERRNONE) {
        Output("Couldn't reset contrast\n");
        return;
    }

    SendMessage(ctrlHandle, PM_CTLSETIMAGEEX,
        PAN_IMAGE_ANTIALIAS, FALSE);
}
```

## Layers-Related Command Messages

### PM\_CTLGETLAYERSTATE

<b>Purpose</b>	Returns the buffer of layer states set by the decoder .
<b>Description</b>	As a vector decoder interprets a file, it may report different layers to the core. This message provides a means for the application to obtain a copy of the layer information that has been accumulated.
<b>Parameters</b>	<p><i>wParam</i>:           <b>(LOWORD)</b> number of layer structures to retrieve  <b>(HIWORD)</b> reserved, must be set to 0</p> <p><i>lParam</i>:           <b>(PAN_LAYER *)</b> layers</p>
<b>Returns:</b>	Number of layers copied to <i>lParam</i> , current layer count if <i>lParam</i> == NULL, 0 if no layers, -1 on failure.
<b>Compatibility:</b>	vector
<b>Restrictions:</b>	All layers will be returned if more than the total is requested.

#### Example:

```
void ShowLayerStates(HWND ctrlHandle)
/*      Display the states of up to the first 64 layers. */
{
    int numLayers;
    PAN_LAYER layers[64];

    if (ctrlHandle == NULL) return;

    numLayers = SendMessage(ctrlHandle, PM_CTLGETLAYERSTATE, 64,
                           (LPARAM) layers);

    if (numLayers < 0) {
        Output("Error occurred when retrieving layer states\n");
        return;
    }

    if (numLayers == 0) {
        Output("No layers defined\n");
        return;
    }

    for (int indx = 0; indx < numLayers; indx++) {
        Output("Layer %d: ", indx);
        Output("%s %s\n", layers[indx].name,
              (layers[indx].bState ? "On" : "Off"));
    }
}
```

<b>PM_CTLSETLAYERSTATE</b>
----------------------------

<b>Purpose</b>	Set the parameters of the layer state buffer.
<b>Description</b>	Sets the internal buffer of layers in the control. Any following <b>PANX_GetLayer</b> call references this buffer.
<b>Parameters</b>	<p><i>wParam:</i>           <b>(LOWORD)</b> number of layers                          <b>(HIWORD)</b> reserved, must be set to 0</p> <p><i>lParam:</i>           <b>(PAN_LAYER *)</b> layer information.                          If NULL, the default layers are restored.</p>
<b>Returns:</b>	error code
<b>Compatibility:</b>	vector
<b>Restrictions:</b>	If the number of layers to be set is larger than the number of existing layers, then only the number of existing layers is set.
<b>Special Notes:</b>	This message will force a repaint.

**Example:**

```
void ShowEvenLayers(HWND ctrlHandle)
// Display half of the layers in a vector drawing. Assumes 256 or less layers in drawing.
{
    int numLayers;
    PAN_LAYER layers[256];

    if (ctrlHandle == NULL) return;

    numLayers = SendMessage(ctrlHandle, PM_CTLGETLAYERSTATE, 256, (LPARAM) layers);

    if (numLayers <= 0) {
        Output("No layers defined to manipulate\n");
        return;
    }

    for (int indx = 0; indx < numLayers; indx++) {
        layers[indx].bState = (indx & 1) ? TRUE : FALSE;
    }

    // Reset states of layers.
    SendMessage(ctrlHandle, PM_CTLSETLAYERSTATE, numLayers,
        (LPARAM) layers);

    // Force update of drawing.
    SendMessage(ctrlHandle, PM_CTLREGEN, 0, 0);
}
```

## XREF-Related Command Messages

### PM\_CTLGETXREFSTATE

<b>Purpose</b>	Returns the buffer of XRef states set by the decoder.
<b>Description</b>	As a vector decoder interprets a file, it may report different XRefs to the core. This message provides a means for the application to obtain a copy of the Xref information that has been accumulated.
<b>Parameters</b>	<p><i>wParam</i>:            number of XRef structures to retrieve.</p> <p><i>lParam</i>:            <b>(PAN_XREF *)</b> lpXRefs</p>
<b>Returns:</b>	Number of XRefs copied to <i>lParam</i> , Xref count if <i>lParam</i> == NULL, 0 if no XRefs, -1 on failure.
<b>Compatibility:</b>	vector-2D
<b>Restrictions</b>	All XRefs will be returned if more than the total is requested.

#### Example:

```
void ShowXRefStates(HWND ctrlHandle)
/*      Display the states of up to the first 64 XRefs. */
{
    int numXRefs, indx;
    PAN_XREF xrefs[64];

    if (ctrlHandle == NULL) return;

    numXRefs = SendMessage(ctrlHandle, PM_CTLGETXREFSTATE, 64,
        (LPARAM) ((PAN_XREF *) &xrefs));

    if (numXRefs < 0) {
        Output("Probably not a vector file\n");
        return;
    }

    if (numXRefs == 0) {
        Output("No XRefs defined\n");
        return;
    }

    for (indx = 0; indx < numXRefs; indx++) {
        Output("XRef %d: ", indx);
        Output("%s %s\n", xrefs[indx].name,
            (xrefs[indx].bState == 1 ? "On" : "Off"));
    }
}
```

**PM\_CTLSETXREFSTATE**

<b>Purpose</b>	Set the parameters of the XRef state buffer.
<b>Description</b>	Sets the internal buffer of XRefs in the control. Any following <b>PANX_GetXRefs</b> call references this buffer.
<b>-2DParameters</b>	<i>wParam:</i> <b>(WORD)</b> number of XRefs <i>lParam:</i> <b>(PAN_XREF *)</b> XRef info
<b>Returns:</b>	error code
<b>Compatibility:</b>	vector--2D
<b>Restrictions</b>	If <i>wParam</i> is larger than the number of existing XRefs, then only the number of existing XRefs is set.
<b>Special Notes</b>	This message will force a repaint.

**Example:**

```

void ShowEvenXRefs(HWND ctrlHandle)
// Display half of the XRefs in a vector drawing. Assumes 20 or less XRefs in drawing.
{
    int numXRefs;
    PAN_XREF xrefs[20];

    if (ctrlHandle == NULL) return;

    numXRefs = SendMessage(ctrlHandle, PM_CTLGETXREFSTATE, 20,
        (LPARAM) ((PAN_XREF *) xrefs));

    if (numXRefs <= 0) {
        Output("No XRefs defined to manipulate\n");
        return;
    }

    for (indx = 0; indx < numXRefs; indx++) {
        xrefs[indx].bState = (indx & 1) ? TRUE : FALSE;
    }

    // Reset states of XRefs.
    SendMessage(ctrlHandle, PM_CTLSETXREFSTATE, numXRefs,
        (LPARAM) ((PAN_XREF *) xrefs));

    // Force update of drawing.
    SendMessage(ctrlHandle, PM_CTLREGEN, 0, 0);
}

```

## Bookmark-Related Command Messages

### PM\_CTLGETBOOKMARKS

<b>Purpose</b>	Returns the buffer of PAN_BOOKMARK struct set by the decoder.
<b>Description</b>	Any decoder can store a tree of bookmarks in the control. This tree is stored in a list of bookmarks. This message provides a means for the application to obtain a copy of the bookmark information that has been accumulated.
<b>Parameters</b>	<p><i>wParam</i>:            number of Bookmark structures to retrieve.</p> <p><i>lParam</i>:            (<b>PAN_BOOKMARK *</b>) lpBMarks</p>
<b>Returns:</b>	Number of Bookmarks copied to <i>lParam</i> , Bookmark count if <i>lParam</i> == NULL, 0 if no Bookmarks, -1 on failure.
<b>Compatibility:</b>	all

#### Example:

```
void OutputBookMarks(HWND ctrlHandle)
/*      Output the number of leaf bookmarks stored in the control */
{
    // Get the total number of bookmarks stored in the control
    long nBookMarks = SendMessage(ctrlHandle, PM_CTLGETBOOKMARKS, 0, NULL);
    // Allocate the buffer that will receive the bookmarks
    pan_bookmark * pBookmarks = new pan_bookmark[nBookmarks];

    // Request the bookmarks stored in the control
    nBookmarks = SendMessage(ctrlHandle, pm_ctlgetbookmarks, 0, pBookmarks);

    // Process the bookmark buffer
    if( nBookmarks < 0 ){
        Output("An error occurred in the control\r");
        return;
    }
    int nLeafBookmarks = 0;
    for( long iBookmark = 0; iBookmark < nBookmarks; iBookmark++){
        if( pBookmarks[iBookmark].fState == 0 ) nLeafBookmarks ++;
    }

    Output("%d leafs in the bookmark tree\r", nLeafBookmarks);

    // Clear the bookmark buffer
    delete [] pBookmarks;
}
```

## Resource-Related Command Messages

### PM\_CTLGETRESOURCEINFOSTATE

<b>Purpose</b>	Returns the buffer of resource information set by the decoder.
<b>Description</b>	As a decoder interprets a file, it may report different resources used to the core. This message provides a means for the application to obtain a copy of the resource information that has been accumulated.
<b>Parameters</b>	<p><i>wParam</i>: <math>\geq 0</math>                      number of resource info structures to retrieve.  <math>-1</math>                                      the resource iterator is requested.</p> <p><i>lParam</i>: <b>(<i>wParam</i> <math>\geq 0</math>)</b> (<b>PAN_RESOURCEINFO *</b>) lpResourceInfo  <b>(<i>wParam</i> <math>= -1</math>)</b>  <b>(boost::<sup>(1)</sup>shared_ptr&lt;IGetResourceInfo&gt; *)</b> resource iterator</p>
<b>Returns:</b>	Number of entries copied to <i>lParam</i> , resource count if <i>lParam</i> == NULL, 0 if no resources, -1 on failure.
<b>Compatibility:</b>	document, spreadsheet and vector controls

```
void ShowResources(HWND ctrlHandle)
/*      Get the resource iterator      */
{
    std::auto_ptr<csi::IGetResourceInfo> pResIter;

    if (ctrlHandle == NULL)
        return;

    SendMessage(PM_CTLGETRESOURCEINFOSTATE, -1, (LPARAM) & pResIter);

    if (!pResIter.get())
        return;

    csi::IGetResourceInfo & resourceIterator = *pResIter;
    while (resourceIterator) {
        const csi::ResourceInfo & resourceInfo = *resourceIterator;
        DisplayResource(resourceInfo);
        ++resourceIterator;
    }
}
```

<sup>(1)</sup> Look at Overview section about usage of STL and Boost libraries

## Offset-Related Command Messages

### PM\_CTLGETOFFSET

<b>Purpose</b>	Get the ofigin offset.
<b>Description</b>	Returns the offset of the origin for the current file in world coordinates.
<b>Parameters</b>	<i>wParam</i> : not used  <i>lParam</i> : ( <b>PAN_CtlPos *</b> ) origin offset
<b>Returns:</b>	error code
<b>Compatibility:</b>	all control types

#### Example:

```
void ShowOffset(HWND ctrlHandle)
/*      Display the offset of the file on the output device. */
{
    PAN_CtlPos fp;

    if (ctrlHandle == NULL)
        return;

    SendMessage(PM_CTLGETOFFSET, 0, (LPARAM) &fp);

    Output("Offset = (%f, %f, %f)\n", fp.x, fp.y, fp.z);
}
```



**PM\_CTLSETOFFSET**

<b>Purpose</b>	Set the origin offset.
<b>Description</b>	Sets the offset of the origin for the current file in world coordinates.
<b>Parameters</b>	<i>wParam</i> : not used <i>lParam</i> : (PAN_CtlPos *) origin offset
<b>Returns:</b>	error code
<b>Compatibility:</b>	all control types

**Example:**

```
void SetDocumentRasterOffset(HWND ctrlHandle, double x, double y)
/* Set the current position at (x, y). */
{
    PAN_CtlPos p;

    if (ctrlHandle == NULL) return;

    p.x = x;
    p.y = y;
    p.z = 0.0;
    SendMessage(ctrlHandle, PM_CTLSETOFFSET, 0, (LPARAM) &p);
}
```

## Font-Related Command Messages

### PM\_CTLGETBASEFONT

<b>Purpose</b>	Returns the base font of the current file.
<b>Parameters</b>	<i>wParam</i> : not used  <i>lParam</i> : <b>(LPLOGFONT)</b> base font
<b>Returns:</b>	error code
<b>Compatibility:</b>	document, database, spreadsheet, and archive controls

#### Example:

```
char* GetBaseFontName(HWND ctrlHandle)
/* Return a pointer to the font name */
{
    // keep the structure valid so we can use the returned pointer
    static LOGFONT    bf;
    int               err;

    if (ctrlHandle == NULL) return NULL;

    err = (int) SendMessage(ctrlHandle, PM_CTLGETBASEFONT, 0, (LPARAM)&bf);

    if (err != PAN_CTLERRNONE) return NULL;
    return bf.lfFaceName;
}
```

## PM\_CTLSETBASEFONT

<b>Purpose</b>	Sets the base font of the current file.
<b>Parameters</b>	<i>wParam</i> : not used <i>lParam</i> : <b>(const LOGFONT *)</b> base font
<b>Returns:</b>	error code
<b>Compatibility:</b>	document, database, spreadsheet, and archive controls

### Example:

```
void UserChangeFont(HWND ctrlHandle)
/* Allow the user to change the font being used in a specified control. */
{
    CHOOSEFONT cf;
    LOGFONT      lf;

    if (ctrlHandle == NULL) return;

    /* Set all structure fields to zero. */
    memset(&cf, 0, sizeof(CHOOSEFONT));

    cf.lStructSize = sizeof(CHOOSEFONT);
    cf.hwndOwner = ctrlHandle;
    cf.lpLogFont = &lf;
    cf.Flags = CF_SCREENFONTS | CF_EFFECTS;
    cf.nFontType = SCREEN_FONTTYPE;

    ChooseFont(&cf);

    if (!SendMessage(ctrlHandle, PM_SETBASEFONT, 0,
        (LPARAM) ((LOGFONT *) lf))) {
        Output("Couldn't change font\r");
    } else {
        Output("Base font changed\r");
    }
}
```

## Database- and Spreadsheet-Related Messages

### PM\_CTLGETCOLWIDTH

<b>Purpose</b>	Return the width of the specified field/column.
<b>Description</b>	Return the width, in the specified units, of the given field/column in the current page. Specifying the zero'th column returns the width of the row header.
<b>Parameters</b>	<i>wParam</i> <b>(WORD)</b> unit type to use.  <i>lParam</i> <b>(DWORD)</b> field/column
<b>Returns:</b>	<b>(LRESULT)</b> width on success or -1 on failure
<b>Compatibility:</b>	database and spreadsheet controls

#### Example:

```
WORD GetColWidthPixels(HWND ctrlHandle, DWORD who)
/* Return the width in pixels of the given field/column specified by who.
   Assume that ctrlHandle refers to a database or spreadsheet file
*/
{
    if (ctrlHandle == NULL) return 0;
    return (WORD) SendMessage(ctrlHandle, PM_CTLGETCOLWIDTH, CTLUNIT_PIXELS, (LPARAM)
                               who);
}
```

**PM\_CTLGETROWHEIGHT**

<b>Purpose</b>	Returns the height of the given record/row in specified units.
<b>Description</b>	Return the height, in the specified units, of the given record/row in the current page. Specifying the zero'th row returns the height of the column headers.
<b>Parameters</b>	<i>wParam:</i> <b>(WORD)</b> unit type to use  <i>lParam:</i> <b>(DWORD)</b> record/row
<b>Returns:</b>	<b>(LONG)</b> height on success or -1 on failure
<b>Compatibility:</b>	database and spreadsheet controls

**Example:**

```
LONG GetRowHeightTwips(HWND ctrlHandle, DWORD who)
/* Return the height in TWIPS of the given field/column specified by who.
   Assume that ctrlHandle refers to a database or spreadsheet file.*/
{
    if (ctrlHandle == NULL) return 0;
    return (LONG) SendMessage(ctrlHandle,
        PM_CTLGETROWHEIGHT, CTLUNITS_TWIPS, (LPARAM) who);
}
```

**PM\_CTLSORT**

<b>Purpose</b>	Sorts a specified region of a database control.
<b>Description</b>	Allows an application to sort the rows or columns of a specified region based on their contents.  <b>Not implemented in initial release of version 1.2.</b>
<b>Parameters</b>	<i>wParam:</i> not used  <i>lParam:</i> ( <b>PAN_CtlSortOptions *</b> ) sort options
<b>Returns:</b>	error code
<b>Compatibility:</b>	Database.

## Page-Related Command Messages

### PM\_CTLGETNUMPAGES

<b>Purpose</b>	Returns the number of pages in the current file.
<b>Description</b>	Return the number of pages in the current file in the <b>int</b> pointed to by <i>lParam</i> .
<b>Parameters</b>	<p><i>wParam</i>: not used</p> <p><i>lParam</i>: <b>(LPINT)</b> number of pages, signed integer giving the number of pages in the file. If the number is positive, this is the total number of pages in the file. If the number is negative, the file may be multi-page, but it contains at least this many pages (in absolute value).</p> <p>This is necessary, since certain file formats (e.g. CGM) do not report the number of pages in the file (for reasons of efficiency). Once the control has determined the number of pages in the file, the <b>PM_CTLGETNUMPAGES</b> message will return a positive number.</p>
<b>Returns:</b>	error code
<b>Compatibility:</b>	all control types

#### Example:

```
void ShowNumPages(HWND ctrlHandle)
/*      Display the current number of pages on the output device. */
{
    DWORD pages;

    if (ctrlHandle == NULL) return;

    SendMessage(ctrlHandle, PM_CTLGETNUMPAGES, 0, (LPARAM) &pages);
    if (pages > 0) {
        Output("The file contains %d pages\n", pages);
    } else {
        Output("The file contains at least %d pages\n", -pages);
    }
}
```

**PM\_CTLGETPAGE**

<b>Purpose</b>	Returns the current page number within the current file	
<b>Description</b>	Return the current page number in the current file in the <b>WORD</b> pointed to by <i>lParam</i> .	
<b>Parameters</b>	<i>wParam</i>	not used
	<i>lParam</i> :	<b>(LPWORD)</b> current page number
<b>Returns:</b>	error code	
<b>Compatibility:</b>	all control types	

**Example:**

```

void DisplayCurrentPage(HWND ctrlHandle)
/*      Display the number of the current page within the file being viewed on the
        output device. */
{
    int err;
    WORD curPage;

    if (ctrlHandle == NULL) return;

    err = SendMessage(ctrlHandle, PM_CTLGETPAGE, 0,
        (LPARAM) ((LPWORD) &curPage));

    if (err != PAN_CTLERRNONE) {
        Output("Couldn't get current page\n");
    } else {
        Output("Page %d is the current page\n", curPage);
    }
}

```



**PM\_CTLGETPAGESIZE**

**Purpose** Returns the size of the specified page in the current file.

**Description** This message provides the mechanism by which applications can determine the view extents of a page of a document. The range structure returns the extents as a pair of points that bound the page.

For vector, raster, archive, database and spreadsheet controls, the returned value always represents the maximum extents of the current page.

**Parameters**

<i>wParam:</i>	<b>(WORD)</b> page number for document control. Not used by other controls.
<i>lParam:</i>	<b>(PAN_CtlRange *)</b> page size

**Returns:** error code

**Compatibility:** all control types

**Example:**

```
void ShowPageSize(HWND ctrlHandle, WORD pagenum)
/* Display the specified page size in view coordinates on the output device. */
{
    PAN_CtlRange rg;

    if (ctrlHandle == NULL) return;

    SendMessage(ctrlHandle, PM_CTLGETPAGESIZE, pagenum, (LPARAM)&rg);
    Output("Page Size = (%f, %f, %f)\n",
          abs(rg.max.x - rg.min.x),
          abs(rg.max.y - rg.min.y),
          abs(rg.max.z - rg.min.z));
}
```

**PM\_CTLSETPAGE**

<b>Purpose</b>	Sets the current page number within the current file.
<b>Description</b>	Set the current page number for the current file based on the value specified by the <b>WORD</b> passed as the <i>wParam</i> .
<b>Parameters</b>	<i>wParam</i> : <b>(WORD)</b> current page number  <i>lParam</i> :           not used
<b>Returns:</b>	error code
<b>Compatibility:</b>	all control types

**Example:**

```
void SetFirstPage(HWND ctrlHandle)
/* Display the first page of the file. */
{
    int err;

    if (ctrlHandle == NULL) return;

    err = SendMessage(ctrlHandle, PM_CTLSETPAGE, 1, 0);

    if (err != PAN_CTLERRNONE) {
        Output("Couldn't change to page 1.\n");
    }
}
```

## Printing Command Messages

### PM\_CTLPRINT

<b>Purpose</b>	Prints the specified extents.		
<b>Description</b>	Print the specified extents using the options specified in the <b>PAN_CtlPrintOptions</b> structure pointed to by <i>lParam</i> .		
<b>Parameters</b>	<i>wParam</i> :	( <b>WORD</b> ) -1 for vector and raster control.	
	<i>lParam</i> :	( <b>const PAN_CtlPrintOptions *</b> ) printing options	
<b>Returns:</b>	error code		
<b>Compatibility:</b>	all control types		

#### Example:

```
int Print(HWND ctrlHandle, PRINTDLG * prnDlg)
/*      Print the control using default values */
{
    int          err=0;
    PAN_CtlPrintOptions printOptions;

    if (ctrlHandle == NULL) return 0;

    memset(&printOptions, 0, sizeof(PAN_CtlPrintOptions));
    printOptions.printDlg = prnDlg;

    // fill structure with default values
    printOptions.units = CTLUNIT_INCH;

    printOptions.margins.units = CTLUNIT_INCH;
    printOptions.margins.top  = 0.75;
    printOptions.margins.left = 0.75;
    printOptions.margins.bottom= 0.75;
    printOptions.margins.right = 0.75;

    // all the header default to null strings */

    err= (int) SendMessage(ctrlHandle, PM_CTLPRINT, (WORD) -1,
                           (LPARAM) &printOptions);

    return err;
}
```

**PM\_CTLPRINTPREVIEW**

<b>Purpose</b>	Returns the print preview of the specified extents.
<b>Description</b>	Return the printing preview of the specified extents using the options specified in the <b>PAN_CtlPrintOptions</b> structure pointed to by <i>lParam</i> . All member variables and structures (except <b>printPreview</b> ) of the given <b>PAN_CtlPrintOptions</b> structure must be properly initialized.
<b>Parameters</b>	<i>wParam</i> :           not used  <i>lParam</i> : <b>(PAN_CtlPrintOptions *)</b> preview information
<b>Returns:</b>	error code
<b>Compatibility:</b>	all control types

**Example:**

```

int PrintPreview(HWND ctrlHandle, PRINTDLG * prnDlg)
/* Generates the print preview rectangles for the control */
/* using default values */
{
    int      err;
    PAN_CtlPrintOptions printOptions;

    if (ctrlHandle == NULL) return 0;

    memset(&printOptions, 0, sizeof(PAN_CtlPrintOptions));
    printOptions.printDlg = prnDlg;

    // fill structure with default values
    printOptions.units = CTLUNIT_INCH;
    printOptions.margins.units = CTLUNIT_INCH;
    printOptions.margins.top  = 0.75;
    printOptions.margins.left = 0.75;
    printOptions.margins.bottom = 0.75;
    printOptions.margins.right = 0.75;

    // all the header default to null strings */
    err = (int) SendMessage(ctrlHeader, PM_CTLPRINTPREVIEW, 0,
                           (LPARAM) &printOptions);

    if (err == PAN_CTLERRNONE) {
        Output("%d pages needed arranged (%d horz, %d vert)\n",
              printOptions.printPreview.nPages,
              printOptions.printPreview.nHorzPages,
              printOptions.printPreview.nVertPages);

        // ... other information may be displayed.
    }

    return err;
}

```

**PM\_CTLVALIDATEMARGINS**

<b>Purpose</b>	Validates the printer margins.
<b>Description</b>	This message is used to allow the control to ensure that the printer margins in the given <b>PAN_CtlPrintOptions</b> structure are at least the minimum size supported by the printer.
<b>Parameters</b>	<i>wParam</i> : not used <i>lParam</i> : ( <b>PAN_CtlPrintOptions *</b> ) print options
<b>Returns:</b>	error code
<b>Compatibility:</b>	all control types
<b>Restrictions:</b>	<p>This message requires that the <b>hDC</b> member of the <b>printDlg</b> structure contained in the <b>PAN_CtlPrintOptions</b> structure be a valid printer device context handle.</p> <p>The margins specified in the print options will not be adjusted if the <b>mode</b> member of the <b>PAN_CtlPrintOptions</b> structure has the <b>PAN_CTLMODEIGNOREMINMARGINS</b> flag set.</p>

**Example:**

```

void SetupPrintMargins(HWND ctrlHandle
    PAN_CtlPrintOptions *printOptions, UINT units,
    double top, double bottom, double left, double right)
/* Set up the margins for a print operation */
{
    printOptions->margins.units = units;
    printOptions->margins.top = top;
    printOptions->margins.left = left;
    printOptions->margins.bottom = bottom;
    printOptions->margins.right = right;

    // Make sure print margins are at least the minimum required
    // by printer.
    SendMessage(ctrlHandle, PM_CTLVALIDATEMARGINS, 0,
        (LPARAM) printOptions);
}

```

## Text-Related Command Messages

### PM\_CTLGETSTRING

<b>Purpose</b>	Returns the number of retrievable strings from a control, or a specified string itself.
<b>Description</b>	PM_CTLGETSTRING allows an application to retrieve strings that were decoded from the displayed file.
<b>Parameters</b>	<p><i>wParam</i>:        -1: To return the total number of strings.                   0..numstrings-1: To return the specified string.</p> <p><i>lParam</i>:        if wParam == -1 then (LPDWORD) nStrings.                   if wParam &gt; 0 then (LPSTR) lpBuffer.</p>
<b>Returns:</b>	error code
<b>Compatibility:</b>	vector files with entity support.

#### Example:

```

/* Display the status of the control on the output device. */
void ShowStrings(HWND ctrlHandle)
{
    DWORD numstrings;
    DWORD ii;
    char    szBuffer[PAN_MAX_STR];

    if (ctrlHandle == NULL) return;

    err = SendMessage(ctrlHandle, PM_CTLGETSTRING, -1,
                      (LPARAM) &numstrings);

    if (PAN_CTLERRNONE == err) {
        for (ii = 0; ii < numstrings; ii++) {
            SendMessage(ctrlHandle, PM_CTLGETSTRING, (WPARAM) ii,
                      (LPARAM) &szBuffer);
            Output("String %d: %s\n", ii, szBuffer);
        }
    }
}

```

<b>PM_CTLSEARCH</b>
---------------------

**Purpose** Search the current file for a text string.

**Description** Search for the string given in the **PAN\_CtlSearchInfo** structure pointed to by *lParam* in the current file. The string in the current file is returned in the structure if the search is successful.

This message may also be used to locate all occurrences of a given string in the document by setting the *wParam* variable to **TRUE**.

A major change from version 1.1 of the controls is the handling of a NULL search string. In version 1.1, this would result in a search dialog being presented to the user to allow the search string to be specified. This facility has been removed in version 1.2.

Searches can now be performed on vector files which support entity operations (indicated by the CTL\_FILE\_HINT\_EDAT bit in the dwHints field of the PAN\_CtlFileInfo structure from PM\_CTLGETFILE). The results of these searches include the bounding vertices of matching strings (if the found occurrence is a sub-string, the bounding box of the full string is returned), as well as the entity handle. If all occurrences of a string are requested, the second and following matches will be stored in the memory regions specified by the hFoundBBox and hFoundHandle of the PAN\_CtlSearchInfo structure.

**Parameters** *wParam*: Not used.

*lParam*: (**PAN\_CtlSearchInfo \***) MultiByte search information.

**Returns:** error code

**Compatibility:** vector, document, database, spreadsheet, and archive controls

**Example:**

/\* Search the file for the specified string, starting at the beginning of the first page of the document. NOTE: ctrlHandle is of type Document, Database, Spreadsheet or Archive \*/

```
void SearchString(HWND ctrlHandle, LPCSTR string)
{
    PAN_CtlSearchInfo si;

    if (ctrlHandle == NULL) return;

    si.startPos.page = 1;
    si.startPos.flow = FLOW_MAIN;
    si.startPos.offset = 0;
    si.fDown = TRUE;           // search downward
    si.fWrap = TRUE;           // wrap around file
    si.fCase = FALSE;          // case sensitive
    si.fWord = FALSE;          // whole word
    si.string = string;
    // Find only the first occurrence.
    SendMessage(ctrlHandle, PM_CTLSEARCH, FALSE, (LPARAM) &si);
}
```

## Mouse Command Messages

### PM\_CTLGETLMBACTION

**Purpose** Returns the left/right mouse button control window behavior.

**Description** Return, in the **WORD** pointed to by *lParam*, the action taken when clicking and dragging with the left mouse button in the control window. The action can be one of the following constants.

<b>PAN_CTLLLMBNONE:</b>	does nothing
<b>PAN_CTLLLMBSELECT:</b>	selects a portion of the current file
<b>PAN_CTLLLMBZOOM:</b>	zooms in on a portion of the current file

**Parameters**

<i>wParam</i>	0 => LMB action 1 => RMB action
<i>lParam:</i>	<b>(LPARAM)</b> LMB action

**Returns:** error code

**Compatibility:** all control types

#### Example:

```
void ShowLMBAction(HWND ctrlHandle)
/*      Display the current left mouse button action on the output device. */
{
    WORD lmb;

    if (ctrlHandle == NULL) return;
    SendMessage(ctrlHandle, PM_CTLGETLMBACTION, 0, (LPARAM) &lmb);
    switch (lmb) {
        case PAN_CTLLLMBNONE: Output("Left Mouse Button action= NONE"); break;
        case PAN_CTLLLMBSELECT: Output("Left Mouse Button action= SELECT"); break;
        case PAN_CTLLLMBZOOM: Output("Left Mouse Button action= ZOOM"); break;
    }
}
```



**PM\_CTLSETLMBACTION**

**Purpose** Sets the left/right mouse button control window behavior.

**Description** Set the action taken when clicking and dragging with the left mouse button in the control window. The action can be one of the following constants:

<b>PAN_CTLLMBNONE</b>	does nothing
<b>PAN_CTLLMBSELECT</b>	selects a portion of the current file
<b>PAN_CTLLMBZOOM</b>	zooms in on a portion of the current file

**Parameters** *wParam:* **(WORD)** MB action

*lParam:* 0 => LMB action.  
1 => RMB action.

**Returns:** error code

**Compatibility:** all control types

**Examples:**

```
void DisableLeftMouseButton(HWND ctrlHandle)
{
    if (ctrlHandle == NULL) return;

    SendMessage(ctrlHandle, PM_CTLSETLMBACTION, (WPARAM)PAN_CTLLMBNONE, 0L);
}

void ChangeLeftMouseButtonState(HWND ctrlHandle, WORD action)
{
    if (ctrlHandle == NULL) return;

    SendMessage(ctrlHandle, PM_CTLSETLMBACTION, action, 0L);
}
```

**Device Context-Related Message****PM\_CTLRENDERONTODC**

**Purpose** Renders the specified extents onto the given device context.

**Description** This message may be used to implement printing or for combining the contents of a control with graphical elements from other sources.

**NOTE:** The page number included in the source specification of the options is ignored. The currently viewed page is used.

**Parameters**

<i>wParam:</i>	Not used
<i>lParam:</i>	(PAN_CtlRenderOptions *) options

**Returns:** error code

**Compatibility:** all control types

**Example:**

```
void RenderOnToDc(HWND ctrlHandle, HDC dc, RECT mapRect)
/*    Render the current view in the control to the supplied device context
      (dc), mapping it so that it will fit the mapRect rectangle.
*/
{
    PAN_CtlRange curView;
    PAN_CtlRenderOptions ro;

    if (ctrlHandle == NULL) return;

    SendMessage(ctrlHandle, PM_CTLGETVIEWEXTENTS, 0, (LPARAM) &curView);

    memset(&ro, 0, sizeof(PAN_CtlRenderOptions));
    ro.source = curView;
    ro.mode = PAN_CTLMODEOPAQUE;
    ro.hdc = dc;    // device context handle

    // Destination range.
    ro.devRect.left = mapRect.left;
    ro.devRect.top = mapRect.top;
    ro.devRect.right = mapRect.right;
    ro.devRect.bottom = mapRect.bottom

    // Source range.
    ro.source = curView;

    SendMessage(ctrlHandle, PM_CTLRENDERONTODC, 0, (LPARAM) &ro);
}
```

## Formatting Device Related Messages

### PM\_CTLSETDEVICE

<b>Purpose</b>	Sets the formatting device for document files.
<b>Description</b>	Sets the device used by the document control for text formatting. Fonts not supported by the device are adapted. <i>wParam</i> specifies the type of device: screen, printer with description given in <i>lParam</i> , or the standard device specified in WIN.INI.
<b>Parameters</b>	<div><div><i>wParam:</i> Device type which can be one of the following: PAN_CTLDEVICESTANDARD, PAN_CTLDEVICEPRINTER, PAN_CTLDEVICESCREEN.</div><div><i>lParam:</i> if <i>wParam</i> == PAN_CTLDEVICEPRINTER, <i>lParam</i> must point to a string containing the device description specified in the same format used in WIN.INI: "Name,Driver,Port". Otherwise, <i>lParam</i> must be set to NULL.</div></div>
<b>Returns:</b>	error code
<b>Compatibility:</b>	Document control.

**PM\_CTLGETDEVICE**

<b>Purpose</b>	Gets the formatting device for document files.				
<b>Description</b>	Returns the device used by the document control for text formatting.				
<b>Parameters</b>	<table><tr><td><i>wParam:</i></td><td>Size of buffer passed in lParam to hold device description if current device type is PAN_CTLDEVICEPRINTER.</td></tr><tr><td><i>lParam:</i></td><td>Buffer to hold device description if current device type is PAN_CTLDEVICEPRINTER. If NULL description is not returned</td></tr></table>	<i>wParam:</i>	Size of buffer passed in lParam to hold device description if current device type is PAN_CTLDEVICEPRINTER.	<i>lParam:</i>	Buffer to hold device description if current device type is PAN_CTLDEVICEPRINTER. If NULL description is not returned
<i>wParam:</i>	Size of buffer passed in lParam to hold device description if current device type is PAN_CTLDEVICEPRINTER.				
<i>lParam:</i>	Buffer to hold device description if current device type is PAN_CTLDEVICEPRINTER. If NULL description is not returned				
<b>Returns:</b>	Type of current device: PAN_CTLDEVICESTANDARD, PAN_CTLDEVICEPRINTER, or PAN_CTLDEVICESTANDARD.				
<b>Compatibility:</b>	Document control.				

## Notification Messages Summary

This section presents a summary of the notification messages sent by the controls, as well as a brief description, parameters and return values.

(Messages names prefixed with “\*” are new to version 1.2 of the controls.)

### Controls-Related Notification Messages

Message Name	Purpose
<b>PNM_CTLDESTROY</b>	A control sends this message prior to its destruction.
<b>PNM_CTLDROPFILE</b>	Sent when a file has been dropped on the control window.
<b>PNM_CTLHELPSTRING</b>	This message returns a help string describing the current state of the control, e.g., reading file... The calling application can use such help strings to provide feedback to the user, for example.
<b>PNM_CTLSIZE</b>	Sent when the control window has changed size.
<b>PNM_CTLSTATUS</b>	Sent when a controls' status changes.

### Image-Manipulation Related

<b>PNM_CTLPAINT</b>	Sent when the control window has been repainted.
<b>PNM_CTLREGEN</b>	Sent when the control has been regenerated.
<b>PNM_CTLSETFOCUS</b>	Sent when a control obtains the focus.
<b>PNM_CTLHSCROLL</b>	Sent when the control window has been horizontally scrolled
<b>PNM_CTLVSCROLL</b>	Sent when the control window has been vertically scrolled.

### Printing Notification Messages

<b>PNM_CTLPRINT</b>	A control sends this message when it has completed a print job initiated with PM_CTLPRINT.
<b>PNM_CTLPRINTINGPAGE</b>	A control sends this message when printing a given page during a print job.
<b>PNM_CTLPRINTPROCESSINGPAGE</b>	A control sends this message when processing (reading) a given page during a print job.

### Clipboard-Related Message

<b>PNM_CTLSETSEL</b>	A control sends this message whenever the selection has changed.
<b>PNM_CTLRENDERSEL</b>	Sent while selection is being copied to the clipboard to allow the application to append its own data.

## Archive/Database/Spreadsheet specific

<b>PNM_CTLARCFILE</b>	An archive control sends this message when an entry has been double-clicked in the control window.
<b>*PNM_CTLCOLWIDTH</b>	When the width of a column in a archive / database / spreadsheet control has changed, this message is sent to inform the parent of the range of changed columns.
<b>*PNM_CTLROWHEIGHT</b>	When the height of a row in a archive / database / spreadsheet control, this message is sent to inform the parent of the range of rows changed.

## OLE-Related Notification Message

<b>PNM_CTLOBJECT</b>	Sent when an OLE object marker has been double clicked.
----------------------	---

## Link Notification Message

<b>PNM_CTLLINK</b>	Sent when the mouse is moved on top of a hot link or when a hot link is double clicked
--------------------	--

## Views Notification Message

<b>PNM_CTLSETVIEWEXTENTS</b>	Sent when the view extents have changed.
------------------------------	--

**Control Notification Messages****PNM\_CTLDESTROY**

**Purpose** A control sends this message prior to its destruction.

**Parameters** *wParam:* not used

*lParam:* not used

**PNM\_CTLDROPFILE**

**Purpose** A control send this message whenever a file has been dropped on the control window.

**Parameters** *wParam:* **(WORD)** file index in sequence of files dropped

*lParam:* **(LPCSTR)** filename



**PNM\_CTLHELPSTRING**

<b>Purpose</b>	This message returns a help string describing the current state of the control, e.g., reading file... The calling application can use such help strings to provide feedback to the user, for example.	
<b>Parameters</b>	<i>wParam:</i>	not used
	<i>lParam:</i>	(LPCSTR) help string

**PNM\_CTLSIZE**

**Purpose** A control sends this message when the control window has changed size.

**Parameters**

<i>wParam:</i>	not used
<i>lParam:</i>	<b>(const RECT *)</b> new size

**PNM\_CTLSTATUS**

**Purpose** A control sends this message whenever its status changes.

**Parameters**

<i>wParam:</i>	not used
<i>lParam:</i>	( <b>DWORD</b> ) status (see <b>PM_CTLGETSTATUS</b> )

## **Image Notification Messages**

### **PNM\_CTLPAINT**

**Purpose** A control sends this message whenever the control window has been repainted.

**Parameters**

<i>wParam:</i>	not used
<i>lParam:</i>	<b>(const RECT *)</b> area repainted in client coordinates

**PNM\_CTLREGEN**

**Purpose** A control sends this message whenever the control has been regenerated.

**Parameters** *wParam:* not used

*lParam:* not used

**PNM\_CTLSETFOCUS**

**Purpose** A control sends this message whenever it obtains the focus.

**Parameters** *wParam:* **(HWND)** handle of window losing focus

*lParam:* not used

**PNM\_CTLHSCROLL, PNM\_CTLVSCROLL**

**Purpose** A control sends these messages whenever the control window has been scrolled.

**Parameters** *wParam:* **(WORD)** scroll amount in pixels

*lParam:* not used

## **Printing Notification Messages**

### **PNM\_CTLPRINT**

**Purpose**                      A control sends this message when it has completed a print job initiated with **PM\_CTLPRINT**.

**Parameters**                *wParam:*                      not used  
  
                                 *lParam:*                      not used



**PNM\_CTLPRINTINGPAGE**

**Purpose** A control sends this message when printing a given page during a print job. The contents of the array are the same as for **PNM\_CTLPRINTPROCESSINGPAGE**.

**Parameters** *wParam:* **(WORD)** number of page number entries in array  
(always 4)

*lParam:* **(LPWORD)** array of page numbers

The array contains the following information:

offset 0 current physical page number  
offset 1 number of physical pages  
offset 2 current logical page number  
offset 3 number of logical pages

**PNM\_CTLPRINTPROCESSINGPAGE**

**Purpose** A control sends this message when processing (reading) a given page during a print job.

**Parameters**

*wParam:*           **(WORD)** number of page number  
                          entries in array   (always 4)

*lParam:*           **(LPWORD)** array of page numbers

The array contains the following information.

offset 0 current physical page number  
offset 1 number of physical pages  
offset 2 current logical page number  
offset 3 number of logical pages

**Clipboard-Related Notification Message****PNM\_CTLSETSEL**

**Purpose** A control sends this message whenever the selection has changed.

**Parameters**

<i>wParam:</i>	not used
<i>lParam:</i>	( <b>const PAN_CtlSel *</b> ) new selection

**PNM\_CTLRENDERSEL**

<b>Purpose</b>	A control sends this message while the selection is being copied to the clipboard to allow the application to append its own data.	
<b>Parameters</b>	<i>wParam:</i>	not used
	<i>lParam:</i>	( <b>PAN_CtlRenderOptions *</b> ) options
<b>Compatibility</b>	Raster and Vector controls.	

**Archive-, Database- and Spreadsheet-Specific Notification Messages****PNM\_CTLARCFILE**

<b>Purpose</b>	An archive control sends this message when an entry has been double-clicked in the control window.		
<b>Parameters</b>	<i>wParam:</i>	not used	
	<i>lParam:</i>	<b>(LPCSTR)</b> name of temporary file in which contents of extracted file are placed followed by name of extracted file at offset <b>PAN_MAX_PATH</b>	

**PNM\_CTLCOLWIDTH**

**Purpose**                      Informs the controls parent that the width of a range of columns has been changed.

**Parameters**                *wParam:*                **(int)** starting changed column number

*lParam:*                **(int)** ending changed column number

**PNM\_CTLROWHEIGHT**

**Purpose**                      Informs the control's parent that the row height has been changed.

**Parameters**                *wParam:*                **(int)** first changed row number

*lParam:*                **(int)** last changed row number

**OLE-Related Notification Message****PNM\_CTLOBJECT**

**Purpose** A control sends this message when an OLE Object marker is double clicked.

**Parameters**

<i>wParam:</i>	not used
<i>lParam:</i>	(PAN_CtlObject *) object descriptor.



## Link-Related Notification Message

### PNM\_CTLLINK

**Purpose** A control sends this message when the mouse cursor is moved on top of a hot-link or when a hot link is double clicked.

**Parameters** *wParam:* PAN\_CTLLINKSETCURSOR (mouse moved) or PAN\_CTLDBLCLICKED (left mouse button was double clicked).

*lParam:* (PAN\_Link \*) link descriptor.

**Views-Related Notification Message****PNM\_CTLSETVIEWEXTENTS**

**Purpose** A control sends this message when the view extents have changed.

**Parameters**

<i>wParam</i>	not used
<i>lParam</i>	(const PAN_CtlRange *) new view extents

---

## Appendix A: Configuration Options

---

The default behaviour of the C.S.I. VCET Controls can be affected by setting options in an initialization file, i.e., INI file. This INI file is normally named "PCTL.INI" and is located in the Windows directory. The name and location of this file can be changed by specifying it to the function PAN\_LoadControls(). Refer to the VCET document for further information.

All the following options may be specified in the "Options" section of the initialization file.

### Vector Viewing Options

**SHOWTEXT**=<0|1>

Show text entities.

**Default:**1

**SHOWLINESTYLE**=<0|1>

Show linestyle patterns.

**Default:**0

**SHOWDIMENSION**=<0|1>

Show dimension entities.

**Default:**1

**SHOWFILL**=<0|1>

If *ON*, display filled entities (solids, fat polylines, etc).

If *OFF*, show the outline of these entities.

**Default:**0

**SHOWXREFS**=<0|1>

Show external reference files.

**Default:**1**VectorCustomMeta**=(0|1)*If VectorCusomMeta is set to 1, a high resolution metafile is used for manipulating images.**If 0, a Windows metafile is used for backing storage.***Default:**1**Compatibility:** Vector formats

## Raster Viewing Options

**CONTRAST**=*contrast\_level**contrast\_level* can be between -100 to 100 to specify low to high contrasts.**Default:**0**Compatibility:** Monochrome Raster formats**ANTIALIAS**=<0|1>If *antialias* is 1 then the image is anti-aliased using a scale-to-gray algorithm.**Default:**0**Compatibility:** Monochrome Raster formats

## Path Settings

**XREFPATHS**=*paths**paths* specifies a semicolon-delimited list of directories to search for external references, for AutoCAD and Intergraph/Microstation drawings:e.g., **XREFPATHS**=D:\acad13\blocks;E:\ustation\cells**Default:**none**Compatibility:** Vector formats**XFONTPATHS**=*paths**paths* specifies a semicolon delimited list of directories to search for AutoCAD shx fonts,e.g., **XFONTPATHS**=C:\acad13\fonts;C:\acad12\support**Default:**none**Compatibility:** Vector formats

## Document Viewing Options

**USESTORAGE=<0/1>**

Use page storage management or not. Enables viewing of long documents.

**Default:** 1

**INMEMPAGETOL=*n\_pages***

*n\_pages* specifies the number of pages on each side of the visible range that page storage management should attempt to keep in memory.

**Default:** 4

### Spreadsheet/Database/Archive Options

**ONEBPECALL=<0/1>**

Determines strategy used to read files. Should be left at default value for initial release of VCET 1.2.

**Default:** 0

### Miscellaneous Options

**RasterMemLimit=*n\_kbytes***

*n\_kbytes* is a numeric value indicating a memory threshold. If Windows' Global memory heap falls below this amount AutoVue will begin swapping raster data to disk.

**Default:** 6000

**Compatibility:** Raster formats

**VectorMemLimit=*n\_kbytes***

*n\_kbytes* is a numeric value indicating a memory threshold. If Windows' Global memory heap falls below this amount AutoVue will begin swapping vector data to disk.

**Default:** 4096

**Compatibility:** Vector formats

### Microstation/DGN Viewing Options

**DGNCOLOR\_TBL=*color\_table\_filename***

*color\_table\_filename* specifies the default color table file to be used by the Microstation/DGN decoder.

**Default:** color.tbl, located in the same directory as PFVC\_DGN.DLL

**Compatibility:** PFVC\_DGN.DLL

**DGNLSTYLERSC=*linestyle\_resource\_filename***

*color\_table\_filename* specifies the linestyle resource file to be used by the Microstation/DGN decoder. This file is used to render extended linestyle patterns for lines, multi-lines *etc.*

**Default:** lstyle.rsc, located in the same directory as PFVC\_DGN.DLL

**Compatibility:** PFVC\_DGN.DLL

## Postscript Viewing Options

### **PSMinDPI=*nDPI***

*nDPI* is a numeric value indicating the *minimum* resolution (in dots-per-inch) to use in rendering Postscript files. The VCET controls automatically calculate the rendering resolution, based on the resolution of the output device. If the user finds this to be too low (for example, details seem jagged on the output), this resolution can be increased. Note that if the rendering resolution calculated by the VCET controls is greater than that specified by this option, then the greater resolution (i.e., VCET's) will be used.

**Default:** 0

**Compatibility:** PFVC\_PS.DLL

# Index

# Index

## —A—

anti-aliasing, 53, 121, 122

## —B—

Background, 52, 59, 105, 109

Base font, 53, 131, 132

Bookmark, 54

## —C—

Capabilities, 15, 50, 57, 68

Child window, 22, 55

Client area coordinates, 51, 93, 97

Clipboard, 13, 15, 38, 51, 57, 68, 99, 100

Color, 36, 52, 59, 105, 106, 109, 110

Command Message Descriptions, 55

Command Message Summary, 50, 54

Command Messages, 50

contrast, 53, 121, 122

Control ID, 22

Control window rectangle, 22

Convert, 8, 15, 51, 82

Copy, 13, 15, 51, 57, 68, 99

**ctlConsumeProc**, 22

**ctlNotifyProc**, 22

## —D—

DestroyWindow, 20, 80

Device context, 15, 27, 54, 142, 147, 165

Duplicate, 50, 55

## —E—

Error codes, 25

## —F—

File, 10, 15, 26, 27, 28, 29, 36, 37, 38, 40, 50, 51, 52, 53, 54, 60, 61, 62, 66, 70, 71, 92, 93, 96, 97, 102, 103, 104, 106, 110, 112, 114, 115, 121, 129, 130, 131, 132, 136, 137, 138, 139, 144, 145, 146, 150, 153, 154, 166

Flip, 84, 85, 86

Foreground, 52, 59, 105, 109

Formats, 15, 38, 50, 51, 61, 70, 71, 99, 100

Function summary, 19

## —H—

Height, 39, 54, 134

## —I—

Index, 177

Information, 9, 15, 20, 22, 41, 50, 52, 60, 63, 106, 141, 144, 162, 163

initialization files, 172

Introduction, 8, 9

## —K—

Keyboard, 15, 22, 57, 68

## —M—

Margins, 39, 40, 54, 142

Metafile, 15

Mode, 26, 50, 64, 75

monochrome, 121, 122

Mouse, 15, 22, 54, 57, 68, 145, 146

## —N—

Notification Messages, 150

## —O—

Offset, 40, 53, 129, 130, 162, 163, 166

Overview, 15

## —P—

Page, 36, 39, 40, 54, 57, 68, 133, 134, 136, 137, 138, 139, 150, 162, 163

Paint, 50, 88

Palette, 27, 52, 106, 107, 108, 110

**PAN\_CreateControl()**, 20, 21, 22, 24

**PAN\_CTLMODEINTERRUPTIBLE**, 77

**PAN\_FreeControls()**, 20

**PAN\_IMAGE\_ANTIALIAS**, 121, 122

**PAN\_IMAGE\_CONTRAST**, 121, 122

**PAN\_LoadControls()**, 20, 21, 172

Path Settings, 173

**PM\_CTLCARETTOWORLD**, 91

**PM\_CTLCLEARSELS**, 92

**PM\_CTLCLIENTTOWORLD**, 93

**PM\_CTLCLONECONTROL**, 55

**PM\_CTLCONVERT**, 82

**PM\_CTLCOPY**, 99

**PM\_CTLDESTROY**, 20, 56, 79, 80

**PM\_CTLFLIP**, 84, 85, 86

**PM\_CTLGETBASEFONT**, 131

**PM\_CTLGETBLOCK**, 116

**PM\_CTLGETBLOCKNAMES**, 117



PM\_CTLGETBOOKMARKS, 127  
 PM\_CTLGETCAPS, 57  
 PM\_CTLGETCARETPOS, 94  
 PM\_CTLGETCLPBRDFMTS, 100  
 PM\_CTLGETCOLWIDTH, 133  
 PM\_CTLGETDEVICE, 149  
 PM\_CTLGETDIMS, 59  
 PM\_CTLGETENTITY, 119  
 PM\_CTLGETFGBGCOLOR, 105  
 PM\_CTLGETFILE, 60  
 PM\_CTLGETFILEFMTS, 61  
 PM\_CTLGETFILETYPE, 62  
**PM\_CTLGETIMAGEEX**, 53, 121  
 PM\_CTLGETINFO, 63  
 PM\_CTLGETLAYERSTATE, 123  
 PM\_CTLGETLMBACTION, 145  
 PM\_CTLGETMODE, 64  
 PM\_CTLGETNUMPAGES, 136  
 PM\_CTLGETNUMSELS, 101  
 PM\_CTLGETOFFSET, 129  
 PM\_CTLGETOPTION, 65  
 PM\_CTLGETPAGE, 137  
 PM\_CTLGETPAGESIZE, 138  
 PM\_CTLGETPALETTE, 106  
 PM\_CTLGETRESOURCEINFOSTATE, 128  
 PM\_CTLGETROWHEIGHT, 134  
 PM\_CTLGETSELS, 102  
 PM\_CTLGETSTATUS, 66  
 PM\_CTLGETSTRING, 143  
 PM\_CTLGETVIEW, 111  
 PM\_CTLGETVIEWEXTENTS, 112  
 PM\_CTLGETVIEWNAMES, 113  
 PM\_CTLGETXREFSTATE, 125  
 PM\_CTLGETZOOM, 87  
 PM\_CTLHSCROLL, 88  
 PM\_CTLPAINT, 88  
 PM\_CTLPALETTECHANGED, 107  
 PM\_CTLPRINT, 140  
 PM\_CTLPRINTPREVIEW, 141  
 PM\_CTLQUERYNEWPALETTE, 108  
 PM\_CTLREGEN, 67  
 PM\_CTLRENDERONTDC, 147  
 PM\_CTLROTATE, 89  
 PM\_CTLSEARCH, 144  
 PM\_CTLSETBASEFONT, 132  
 PM\_CTLSETBLOCK, 118  
 PM\_CTLSETCAPS, 68  
 PM\_CTLSETCARETPOS. *See*  
 PM\_CTLSETDEVICE, 148  
 PM\_CTLSETFGBGCOLOR, 109  
 PM\_CTLSETFILE, 70, 71  
**PM\_CTLSETIMAGEEX**, 53, 122  
 PM\_CTLSETLAYERSTATE, 124  
 PM\_CTLSETLMBACTION, 146  
 PM\_CTLSETMODE, 75  
 PM\_CTLSETOFFSET, 130  
 PM\_CTLSETOPTION, 81  
 PM\_CTLSETPAGE, 139  
 PM\_CTLSETPALETTE, 110  
 PM\_CTLSETSEL, 103  
 PM\_CTLSETSELCARET, 104  
 PM\_CTLSETVIEW, 114

PM\_CTLSETVIEWEXTENTS, 115  
 PM\_CTLSETXREFSTATE, 126  
 PM\_CTLSETZOOM, 90  
 PM\_CTLSHOWENTITY, 120  
 PM\_CTLSIZE, 88  
 PM\_CTLSORT, 135  
 PM\_CTLVALIDATEMARGINS, 142  
 PM\_CTLVSCROLL, 88  
 PM\_CTLWORLDTOCARET, 96  
 PM\_CTLWORLDTOCLIENT, 97  
 PM\_CTLXFRMRECT, 98  
 PNM\_CTLARCFIELD, 166  
 PNM\_CTLCOLWIDTH, 167  
 PNM\_CTLDESTROY, 152  
 PNM\_CTLDROPFILE, 153  
 PNM\_CTLHELPSTRING, 154  
 PNM\_CTLHSCROLL, 160  
 PNM\_CTLLINK, 170  
 PNM\_CTLOBJECT, 169  
 PNM\_CTLPAINT, 157  
 PNM\_CTLPRINT, 161  
 PNM\_CTLPRINTINGPAGE, 162  
 PNM\_CTLPRINTPROCESSINGPAGE, 163  
 PNM\_CTLREGEN, 158  
 PNM\_CTLRENDERSEL, 165  
 PNM\_CTLROWHEIGHT, 168  
 PNM\_CTLSETFOCUS, 159  
 PNM\_CTLSETSEL, 164  
 PNM\_CTLSETVIEWEXTENTS, 171  
 PNM\_CTLSIZE, 155  
 PNM\_CTLSTATUS, 156  
 PNM\_CTLVSCROLL, 160  
 Print, 15, 54, 140, 141, 142, 150, 161, 162, 163

## —R—

Raster Viewing Options, 173  
 Render, 15, 50, 54, 70, 71, 147  
 Rotate, 50, 89

## —S—

Scroll, 15, 22, 57, 68, 88, 160  
 Search, 10, 37, 54, 57, 68, 144  
 Selections, 38, 41, 42, 51, 54, 91, 92, 96, 99, 101, 102, 140, 141, 164  
**ShowWindow**, 20  
 Sort, 135  
 Sorting, 135  
 Stand-alone window, 22, 55  
 Status, 50, 66, 150, 156  
 struct PAN\_CtlClpbrdFmt, 38  
 struct PAN\_CtlClpbrdFmtList, 38  
 struct PAN\_CtlFileFmt, 38  
 struct PAN\_CtlFileFmtList, 38  
 struct PAN\_CtlFileInfo, 36  
 struct PAN\_CtlInfo, 35  
 struct PAN\_CtlObject, 42  
 struct PAN\_CtlPos, 34  
 struct PAN\_CtlPrintOptions, 40  
 struct PAN\_CtlPrintPreview, 39

struct PAN\_CtlRange, 34, 35  
struct PAN\_CtlRenderOptions, 41  
struct PAN\_CtlSearchInfo, 37  
struct PAN\_CtlSel, 38  
struct PAN\_CtlSelList, 38  
Structure Descriptions, 33  
Structure Summary, 31




Text search, 10




Validate, 142  
Vector Viewing Options, 172

View extents, 52, 112, 115, 151, 171



Width, 54, 115, 133

World coordinates, 15, 51, 52, 53, 93, 97, 112, 115, 129,  
130



Zoom, 11, 12, 50, 57, 68, 87, 90, 115