

Part Number:313433501

Shared Virtual Array SVA Path

Version 3.1

HP-UX

User's Guide

Proprietary Information Statement

The information in this document is confidential and proprietary to Storage Technology Corporation and may be used only under the terms of the product license or nondisclosure agreement. The information in this document, including any associated software program, may not be disclosed, disseminated, or distributed in any manner without the written consent of Storage Technology Corporation.

Limitations on Warranties and Liability

This document neither extends nor creates warranties of any nature, expressed or implied. Storage Technology Corporation cannot accept any responsibility for your use of the information in this document or for your use of any associated software program. You are responsible for backing up your data. You should be careful to ensure that your use of the information complies with all applicable laws, rules, and regulations of the jurisdictions in which it is used.

Warning: No part or portion of this document may be reproduced in any manner or in any form without the written permission of Storage Technology Corporation.

Restricted Rights

Use, duplication, or disclosure by the U.S. Government is subject to restrictions as set forth in subparagraph (c)(1)(ii) of the Rights in Technical Data and Computer Software clause at DFARS 252.227–7013 or subparagraphs (c)(1) and (2) of the Commercial Computer Software—Restricted Rights at 48 CFR 52.227–19, as applicable.

Trademarks

StorageTek is a registered trademark, and Shared Virtual Array and SVA are trademarks of Storage Technology Corporation.

UNIX is a registered trademark of The Open Group.

Other terms and product names used herein may be trademarks of their respective owners.

First Edition (1.0) March 2001

This edition applies to Version 3.1 of the SVA Path for HP-UX product and to all subsequent modifications of that program until otherwise indicated in new editions or revision pages. If there are changes in the program or improvements in the information about the program, this document will be revised and reissued.

Comments concerning the contents of this manual should be directed to:

Storage Technology Corporation
Manager, Enterprise Disk Information Development
One StorageTek Drive
Louisville, CO 80028-2201

© Copyright Storage Technology Corporation 2001. All rights reserved.

© Copyright Dot Hill Systems Corp. 2001. All rights reserved.

Table of Contents

Who Should Read This Guide	vii
Shared Virtual Array Documentation	vii
How to Obtain Software Documentation	vii
SVA Administrator for HP-UX Library	viii
Related SVA Software Publications	viii
SVA Hardware Publications	ix
Chapter 1. SVA Path Overview	1
Failover/Failback Data Paths	1
Load Balancing	1
Dynamic Allocation of Device Resources	2
How SVA Path Works	2
Supported SVA Path Configurations	3
System Requirements	3
SAM Support	3
Summary of SVA Path Benefits	4
Document Overview	4
Chapter 2. SVA Path Hardware Setup	5
Fibre Addressing Concepts	5
Host Bus Adapters/Initiators	5
Domains in Fibre Channel Connection	5
Domain Numbering	6
Domain Numbering with Fibre and SVA Path	7
Configuration in a Mixed SCSI/Fibre Environment	8
Hardware Preparation	9
Configuring an HP System to See New Devices	9

Chapter 3. SVA Path Operation	11
The setsp Command	11
The spmon Command	14
Configuring Load Balancing	14
How to Verify Load Balancing	16
Adding FDevs to an Existing Lun	19
The sppath Command	20
Display Options for sppath	21
Ignoring and Reclaiming Devices with sppath	22
Understanding the setsp -a Screen	23
Changing the Configuration	25
Specifying a Device for setsp	25
Assigning a New Primary Path	26
Turning the Exclusion Setting Off and On	26
Redefining the Buffer Pointer Allocation	27
Turning Load Balancing On and Off	27
Changing the Retry Count and Retry Delay	27
Turning Failback Off and On	28
Dynamic Device Detection	28
 Chapter 4. SVA Path Installation	 31
Installing SVA Path on HP-UX	31
Installing SVA Path with SVA Administrator	33
Uninstalling SVA Path	34
Installed Files	35
SVA Path Device Naming on HP-UX	37
How Device Filenames Are Chosen	38
Devices without Redundant Paths to the Host	40
Logical Volume Manager	40
Definitions of Common Terms	41
Preparing the Volume Group	42
Creating the Physical Volume	43
Creating the Volume Group	43
Creating Logical Volumes	44
Reconfiguration for Existing Applications	46
Reconfiguration for Existing Logical Volumes	46

Chapter 5. Diagnosing Errors	51
Comparing setsp -a with System Events	51
Cable Failure Errors	52
Failover Error Reporting	53
Recovering from a Failure	54

Preface

This guide describes how to use the SVA Path Intelligent Data Path Management software. SVA Path provides improved performance and data accessibility for the StorageTek Shared Virtual Array (SVA).

Who Should Read This Guide

This guide is for data administrators, capacity planners, performance specialists, and system administrators. This guide assumes that you are familiar with Shared Virtual Array operations and HP-UX system administration.

Shared Virtual Array Documentation

This section lists software and hardware documentation for the Shared Virtual Array products.

How to Obtain Software Documentation

All of the Shared Virtual Array software publications are available from the following sources:

- On the SVA Software Publications CD-ROM (part number 3112953nn). To order a copy, contact StorageTek Publication Sales and Service at 800-436-5554 or send a fax to 303-661-7367.

- Online (for viewing and printing), at the StorageTek Customer Resource Center (CRC) website at: www.support.storagetek.com. Click on Software and go to the Shared Virtual Array Software list.



Note: Access to the CRC site requires a password. To obtain a password, call StorageTek Customer Support at 800-678-4430.

SVA Administrator for HP-UX Library

- *Shared Virtual Array Administrator for HP-UX Command Quick Reference*
- *Shared Virtual Array Administrator for HP-UX Installation Guide*
- *Shared Virtual Array Administrator for HP-UX Messages*
- *Shared Virtual Array Administrator for HP-UX Quick Start Guide*
- *Shared Virtual Array Administrator for HP-UX User's Guide*

Related SVA Software Publications

For SVA SnapShot for HP-UX:

- *Shared Virtual Array SnapShot for HP-UX User's Guide*
- *Shared Virtual Array SnapShot for HP-UX Quick Start Guide*

For SVA Console for Windows NT (SVAC):

- *Shared Virtual Array Console for Windows NT Quick Start Guide*

For any StorageTek software:

- *Requesting Help from Software Support*

SVA Hardware Publications

Shared Virtual Array hardware publications are available from the following sources:

- On the SVA Hardware Publications CD-ROM (part number 3118447nn). To order a copy, contact StorageTek Publication Sales and Service at 800-436-5554 or send a fax to 303-661-7367.
- Online (for viewing and printing), at the StorageTek Customer Resource Center (CRC) website at: www.support.storageitek.com. Click on Disk Subsystems.



Note: Access to the CRC site requires a password. To obtain a password, call StorageTek Customer Support at 800-678-4430.

The 9500 SVA library consists of:

- *9500 Shared Virtual Array Introduction*
- *9500 Shared Virtual Array Operation and Recovery*
- *9500 Shared Virtual Array Physical Planning*
- *9500 Shared Virtual Array Planning, Implementation, and Usage*
- *9500 Shared Virtual Array Reference*
- *9500 Shared Virtual Array System Assurance*

Chapter 1. SVA Path Overview

This chapter provides an overview of SVA Path Intelligent Data Path Management software and its features.

SVA Path offers a new level of data accessibility and improved performance for the SVA 9500. It eliminates the point of failure represented by a single input/output (I/O) path between servers and storage systems and permits I/O to be distributed across multiple paths.

Failover/Failback Data Paths

By providing alternate I/O paths from the server to the SVA, SVA Path provides uninterrupted access to mission-critical data. This substantially insulates server applications from I/O path failures.

In the event of a failed host bus adapter (HBA), interface cable, or channel I/O card within the SVA, SVA Path automatically reroutes I/O traffic to an alternate data path. Failover is essentially transparent, ensuring continuous access to data stored on the SVA. When configured in the recommended failback mode, SVA Path automatically restores the primary data path and system redundancy once the defective component is replaced.

Load Balancing

SVA Path supports up to 32 data paths between a host and any SVA logical device. Since only two data paths are required for path failover capability, multiple data paths can be used to improve performance in one of three ways:

1. by allowing SVA Path to uniformly distribute primary paths among all available I/O paths. This is the default behavior of SVA Path.
2. by manually assigning I/O traffic for a logical drive to a particular path. The administrator with an understanding of the I/O load patterns of his or her applications can optimize performance through an intelligent choice of paths.
3. by enabling automatic load balancing. In this mode of operation SVA Path monitors the load on each path and sends I/O requests through the path with the lightest load.

Dynamic Allocation of Device Resources

In SVA configurations with multiple servers attached to the same storage device, SVA Path allows the system administrator to assign a logical drive to one server and prevent the other servers in the SVA from accessing that same logical drive.

How SVA Path Works

SVA Path's filter driver resides between the file system drivers and the device drivers, within the layered driver architecture. I/O requests are passed from the file system through the drivers and ultimately to the hardware.

SVA Path monitors the flow of I/O requests through the layered driver architecture. When it detects a failure along an I/O path, it automatically reroutes the request to an alternate path. Failover to the redundant I/O path is transparent to server applications and permits continuous access to the information stored on the disk array(s). To the operating system, there is only a slight delay in normal I/O operations during path failover; existing drive numbers and device access functions continue to work as expected.

Supported SVA Path Configurations

SVA Path supports single server configurations.

System Requirements

Before proceeding to the next chapter, you should verify that your site meets the following minimum requirements (Table 1-1, “SVA Path Minimum System Requirements”).

Table 1-1 SVA Path Minimum System Requirements

Host hardware:	All 9000 series computers
Host software:	HP-UX 10.20 and HP-UX 11.x, 32 and 64 bit
HBA	10.2, 11.0 HSC HP A3404B 10.2, 11.0 PCI HP A3740A
Host software	X Windows
Host disk space:	5 MB free space in the <code>root</code> filesystem and 1 MB free space in the <code>/var</code> directory.
SVA Subsystem Microcode:	K05.04.08
Extended SCSI Attach Feature:	One Extended SCSI Attach (microcode S358) per redundant SCSI path

SAM Support

Version 3.1 of SVA Path for HP-UX does not provide SAM support.

Summary of SVA Path Benefits

- Increases potential subsystem throughput by directing I/O through multiple host adapters and SVA channels. Logical drives can be assigned to host bus adapters, manually balancing the I/O load across paths.
- Provides continuous access to mission-critical data by insulating server applications from I/O path failures.
- Installs easily and is transparent to server applications.
- Allows you to limit access to devices in a multi-initiator (SVA) environment using LUN (logical unit number) exclusion.

Document Overview

This manual describes how to install and configure SVA Path on systems running the HP-UX operating system.

- Chapter 2 describes configuring your hardware in preparation for installing SVA Path.
- Chapter 3 explains configuring and operation SVA Path.
- Chapter 4 contains the instructions for installing SVA Path.
- Chapter 5 offers assistance in diagnosing error messages.

Note that user documentation for products used with SVA Path, including HP-UX documentation, is referenced throughout this manual. Have your hardware and operating system manuals available for quick reference.

Chapter 2. SVA Path Hardware Setup

Fibre Addressing Concepts

Host Bus Adapters/Initiators

The terms “host bus adapter” and “initiator” mean essentially the same thing. Typically, the HBA is a card within the host that, in its role as initiator, issues commands on the Fibre channel.

Domains in Fibre Channel Connection

StorageTek uses the concept of “domains” to allow open systems hosts access to blocks of logical devices (the domains) within an SVA. A domain is an additional layer of device addressing, but one that is manually configured by the CSE in the SVA. This layer of addressing divides the SVA into “domains of access.” There can be up to 16 (0–15) domains per SVA, with each domain having one target with 255 LUNs. There is a limit of 1024 total devices available within an SVA.¹

Each open systems host initiator is connected with Fibre cables to a controller card port, giving it access to the devices that have been configured within its domain. (An open systems host cannot see devices in domains other than the one to which it is attached.)

Full SVA Path functionality requires that redundant initiators can access the SVA over redundant data paths.

1. Using all allowed domains, targets, and LUNs, there are more than 1024 logical devices, but the SVA has a limit of 1024 logical devices.

Figure 2-1 shows two data paths connecting the open systems platform to the attached SVA using Fibre cables.




Figure 2-1 Fibre Paths from the Host to the SVA



Note: In the above figure, a domain can represent up to 255 logical devices (1 Target \times 255 LUNs = 255 Logical Devices). There is a limit of 1024 logical devices with an SVA.

Domain Numbering

Using Fibre connection, the domain number is configured at the SVA operator panel by the StorageTek Customer Service Engineer.

The domain number is never seen by the open systems host; from its point of view, just a target and logical unit number are involved in an I/O operation.

Domain Numbering with Fibre and SVA Path

It is not normally advisable to have more than one path from a single host set to the same domain number to a given SVA (in case two hosts attempt to share the same LUN and so corrupt the data stored on it). SVA Path requires exactly this configuration for failover to work.

SVA Path manages multiple paths from a single host, using identical domain numbers.

Configuration in a Mixed SCSI/Fibre Environment

Failover can only be accomplished from one SCSI interface to another, or from one Fibre interface to another.

Figure 2-2 shows SCSI and Fibre data paths connecting the open systems platform to the attached SVA.




Figure 2-2 Mixed SCSI and Fibre Paths from the Host to the SVA

Hardware Preparation

Configuring an HP System to See New Devices



Perform the following steps on the HP host:

Note: If any of the following steps do not produce the expected result, refer to your HP-UX system administrator documentation for instructions on setting up the host platform correctly.

1. For Fibre channel connection, contact your Customer Service Engineer to set domain addresses in the SVA 9500. For SCSI, manually set the domain addresses on the SVA's XSAs to the required configuration and reboot the XSAs.
2. Log in as `root`.
3. Open a console or terminal window.
4. Run `ioscan` and verify that the new storage resource is recognized by the system:

```
# ioscan -fn
```

5. Each of the three disk devices in our example is seen twice, once on the first controller (`c1`) and again on the second controller (`c2`).

Verify that all of the new device(s) you have defined are included in the display. They are identified with a type of `STK-9200-nnnn`.

Write down the first six characters (the controller, target, and device numbers) of the new device(s). This information looks something like:

```
c1t0d0
```

Class	I	H/W Path	Driver	S/W State	H/W Type	Description
=====						
disk	0	0/0/1/1.2.0	sdisk	CLAIMED	DEVICE	SEAGATE ST39103LC
			/dev/dsk/clt2d0		/dev/rdisk/clt2d0	
disk	1	0/0/2/0.2.0	sdisk	CLAIMED	DEVICE	SEAGATE ST39103LC
			/dev/dsk/c2t2d0		/dev/rdisk/c2t2d0	
disk	2	0/0/2/1.2.0	sdisk	CLAIMED	DEVICE	HP DVD-ROM 6x/32x
			/dev/dsk/c3t2d0		/dev/rdisk/c3t2d0	
disk	3	0/6/0/0.0.0	sdisk	CLAIMED	DEVICE	STK 9500
			/dev/dsk/c6t0d0		/dev/rdisk/c6t0d0	
disk	4	0/6/0/0.1.0	sdisk	CLAIMED	DEVICE	STK 9500
			/dev/dsk/c6t1d0		/dev/rdisk/c6t1d0	
disk	5	0/6/0/0.2.0	sdisk	CLAIMED	DEVICE	STK 9500
			/dev/dsk/c6t2d0		/dev/rdisk/c6t2d0	
disk	6	0/6/0/0.3.0	sdisk	CLAIMED	DEVICE	STK 9500

Figure 2-3 Example format Output for a Dual -Path System

Chapter 3. SVA Path Operation

This chapter describes SVA Path commands and configuration options.

There are three basic commands in SVA Path

- `setsp` is used to examine and configure the system's operating parameters, and as such is the command most often invoked by the user.
- `spmon` monitors path states and implements load balancing.
- `sppath` identifies devices to be placed under SVA Path's control.

The `setsp` Command

The `setsp` command is used for most configuration tasks.

Table 3-1, “`setsp` Command Options”, on the next page gives a brief explanation of `setsp` command options. Those used to configure SVA Path device parameters are covered in some detail in “Changing the Configuration”, beginning on page 25. In these cases, the pages containing more detailed explanations of command options are noted parenthetically.

The output of `setsp -a` is also used in conjunction with the event listings in `/var/adm/syslog/syslog.log` to determine the nature and physical location of failures. This is covered in “Diagnosing Errors” starting on page 51.

Command options that take arguments (shown in braces after the command) *require* an argument and should not be run without one.

Table 3-1 *setsp Command Options*

Option	Effect
-a	show current device configuration and state
-b{0 1}	set load balancing for a logical drive. (pages 24 and 27). -b0 disables load balancing for the device; -b1 enables it Must be used with -l
-d<n>	set a retry delay of <i>n</i> for a logical drive, where <i>n</i> is the interval between retries in milliseconds (page 24 and 27)
-e{0 1}	set exclusion for a logical drive (pages 24 and 26). -e0 includes the device; -e1 excludes it; excluded devices are not accessible by user applications; devices are excluded by default Must be used with -l
-f{0 1}	set failback for a logical drive. -f0 disables failback for the device; -f1 enables it (pages 25 and 28) Must be used with -l
-g	generate configuration files after an <code>sppath</code> command (Page 21)
-i	show contents of driver configuration files

Table 3-1 setsp Command Options

Option	Effect
-L <parameter>	show current device configuration according to condition(s) defined by <code>setsp</code> command option parameter(s) (e.g., <code>setsp -L -e1</code> lists all excluded devices; <code>setsp -L -b0 -f1</code> lists all devices that have load balancing disabled and failback enabled); acceptable parameters are: -l, -e, -p, -b, -r, -d, and -f
-l {<n> all}	specify a logical drive for the command, where; <i>n</i> is the drive's <code>spd</code> number ; all specifies all devices (page 25)
-N	runs a command to change the configuration files without affecting the running system (changes will take effect at the next boot)
-n<n>	allocate <i>n</i> buffer pointers for a logical drive, where <i>n</i> should be a number approximately equal to the device's maximum queue depth. (pages 24 and 27) Must be used with -l.
-p<n>	select primary path <i>n</i> . Must be used with -l.
-r<n>	set a retry count of <i>n</i> for a logical drive, where <i>n</i> is the number of times a command will be retried (pages 24 and 27)
-S	start the <code>spd</code> driver
-T	terminate the <code>spd</code> driver

Table 3-1 setsp Command Options

Option	Effect
-u{0 1 2}	show devices by their configuration status: -u0 shows all available devices; -u1 shows configured disks; -u2 shows unconfigured disks
-v	runs a command in verbose mode

The spmon Command

The `spmon` command is primarily associated with load monitoring and balancing of SVA Path functional devices (FDevs). FDev is a logical disk as viewed by the host operating system, the applications and the users. An Fdev can emulate one of a variety of SCSI and count-key-data (CKD) disk devices.

Note: For optimum performance when striping data across multiple LUNs, disable load balancing on the devices being striped using the `setsp -b0` option.

Configuring Load Balancing

Load balancing is enabled or disabled using `setsp -l all -b0` (disable) or `setsp -l all -b1` (enable) commands, with the default setting being load balancing is enabled. Parameters for load balancing are stored in the configuration file `/etc/spmon.conf`. This file is read automatically after each modification at the end of the expiration of the last measurement interval.

Following is a listing of available parameters in `/etc/spmon.conf`:

- **balance-threshold *percentage***

This parameter is used to specify the maximum difference in load on the high and low paths that is permitted before the paths will be considered imbalanced. The load balancing

equation must be less than the percentage value of `balance-threshold` to be considered balanced.

- **`reassignment-threshold percentage`**

This parameter determines whether or not a reassignment will be considered worthwhile.

- **`measurement-interval time`**

This parameter accepts an positive integer value with a suffix of "s" (seconds), "m" (minutes), or "h" (hours). A reasonable minimum value will be based on the CPU load presented to the system by the algorithm and the maximum value is based on the amount of time that can pass before the driver's internal counters overflow.

- **`reassignment-limit number`**

This parameter specifies the maximum number of devices that should be moved in one pass of the algorithm. The default value is equal to or one half of the FDevs. If the path group includes one or more multi-FDev LUNs, each FDev is considered a separate device.

- **`read-overhead μs -per-cmd μs -per-sector`**

This parameter is used to specify how bus connect time overhead is estimated for read commands. The first value specifies the number of microseconds estimated for read command overhead, while the second is an estimate of connect time required for each 512 bytes of data requested. For each read operation, the sum of the command overhead and the product of the transfer length and the per-sector overhead is added to a counter that is used to estimate overall bus utilization on a per-FDev and per-channel basis.

- **`write-overhead μs -per-cmd μs -per-sector`**

This parameter is analogous to the read-overhead statement. Sample values for these two statements are:

```
read-overhead 1000 120
write-overhead 1000 160
```

How to Verify Load Balancing

In Figure 3-4, “Example setsp -a Output in Determining Load Balancing”, there are four SVA Path devices; spd0, spd1, spd2 and spd3.

```
# setsp -a
=====
spd  Path/disk      Status Primary Exclude Buf Balance RtrCnt  RtrDly FailBack
=====
  0   c0t1d0        Good  X           32    1    20    3000    1
      c3t0d0        Excluded           X
spd0 = c83t0d0          ID = "STK 9500 0000000010390000"
=====
  1   c0t1d1        Good           32    1    20    3000    1
      c3t0d1        Good    X
spd1 = c83t0d1          ID = "STK 9500 0000000010390001"
=====
  2   c0t1d2        Good  X           32    1    20    3000    1
      c3t0d2        Good
spd2 = c83t0d2          ID = "STK 9500 0000000010390002"
=====
```

Figure 3-4 Example setsp -a Output in Determining Load Balancing

- **status** shows the current state of the path. Good paths are functioning normally. Bad paths have failed. Excluded paths are unavailable to applications on this host.

In our example, the following command will show that each device in Figure 3-4, “Example setsp -a Output in Determining Load Balancing” is accessible via four paths, using HBAs "glm3", "glm4", "lpfc0" and "lpfc1”:

```
# spmon show
```

```
# spmon show
Total I/O load across monitored HBAs = 103.2s

  HBA Device      I/O Load  %load
  -----
c1  glm3          40.1s   38.8%
c2  glm4          20.8s   20.2%
c4  lpfc0         21.2s   20.6%
c5  lpfc1         21.1s   20.5%

Device c6t0d0 [STK 9500 0000000010850000]
FDev      Path                      I/O Load  HBA Load
-----
spd0:0    0/glm3/sd66                    9.9s      40.1s   24.8%

Device c6t0d1 [STK 9500 0000000010850001]
FDev      Path                      I/O Load  HBA Load
-----
spd1:0    0/glm3/sd67                    10.1s     40.1s   25.1%
spd1:1    3/lpfc1/sd190                  21.2s     21.1s  100.0%

Device c6t0d2 [STK 9500 0000000010850002]
FDev      Path                      I/O Load  HBA Load
-----
spd2:0    0/glm3/sd68                    9.9s      40.1s   24.7%
spd2:1    1/glm4/sd90                    20.9s     20.8s  100.0%
spd2:2    2/lpfc0/sd147                  21.2s     21.2s  100.0%

Device c6t0d3 [STK 9500 0000000010850222]
FDev      Path                      I/O Load  HBA Load
-----
spd3:0    0/glm3/sd69                    10.0s     40.1s   24.9%
```

Figure 3-5 Example spmon show Output

The column headings describe the various fields on the screen:

- **FDev** identifies the SVA Path device and the zero-based index of the FDev within the device, separated by a colon.
- **Path** identifies the current path assigned to the FDev and the name of the host bus adapter used by that path.
- **I/O Load** estimates channel utilization time during the current measurement interval. The I/O Load may be expressed as one of the following formats:

milliseconds (with an "ms" suffix) if it is less than one second. For example, 350ms = 350 milliseconds

seconds (with an "s" suffix) if it is less than 300 seconds.
For example, 18.1s = 28.1 seconds

hours:minutes:seconds (hh:mm:ss) if it is more than
59 minutes. For example, 0:12:42 = 0 hours, 12 minutes, and
42 seconds.

- **HBA Load** identifies the I/O load contributed by traffic to/from this FDev as a percentage of all I/O though the current HBA used to access this FDev. The figure in the right-hand column is a ratio I/O Load / HBA Load, expressed as a percentage.

In this example, all four paths have about the same load on them except for c1, which has nearly double the load of the other paths.

Shortly after this command was run, the following message appeared in the system log file

/var/adm/syslog/syslog.log:

```
spmon daemon: moving spd2:0 from glm3 to lpfcl  
spmon daemon: moving spd3:0 from glm3 to glm4
```

Figure 3-6 Example Output of spmon Daemon

When the command, `spmon show`, is run again (Page 19), the output shows the load is redistributed among the four paths and the maximum load on c1 is significantly reduced from 38.8% to 32.5%:

```

# spmon show
Total I/O load across monitored HBAs = 105.1s

  HBA Device      I/O Load  %load
  -----
c1  glm3          34.1s  32.5%
c2  glm4          31.3s  29.8%
c4  lpfc0         19.1s  18.1%
c5  lpfc1         20.6s  19.6%

Device c6t0d0 [STK 9500 0000000010850000]
  FDev      Path                I/O Load  HBA Load
  -----
spd0:0     0/glm3/sd66                16.9s     34.1s  49.5%

Device c6t0d1 [STK 9500 0000000010850001]
  FDev      Path                I/O Load  HBA Load
  -----
spd1:0     0/glm3/sd67                17.3s     34.1s  50.5%
spd1:1     3/lpfc1/sd190              10.2s     20.6s  49.6%

Device c6t0d2 [STK 9500 0000000010850002]
  FDev      Path                I/O Load  HBA Load
  -----
spd2:0     3/lpfc1/sd191              10.4s     20.6s  50.4%
spd2:1     1/glm4/sd90                15.4s     31.3s  49.3%
spd2:2     2/lpfc0/sd147              19.1s     19.1s 100.0%

Device c6t0d3 [STK 9500 0000000010850222]
  FDev      Path                I/O Load  HBA Load
  -----
spd3:0     1/glm4/sd91                15.9s     31.3s  50.7%

```

Figure 3-7 Example spmon show Output, Next Interval

Adding FDevs to an Existing Lun

After adding new FDevs to an existing lun via the “Add FDev” button on the SVA console, run the following command:

```
# spmon update-fdevs
```

This enables spmon to load balance the new FDevs separately from the rest of the FDevs that make up the LUN. If this command is not run, the FDevs will be treated as if they belonged to the last original FDev and will be prevented from being assigned to different paths. For example, if a LUN was originally composed of two FDevs spd0:0 and spd0:1 and the user adds three FDevs using the SVA console, the new FDevs are assigned to spd0:1.

The `sppath` Command

The `sppath` command is run automatically at boot after SVA Path is installed. `sppath`'s main function is to create the configuration file that identifies devices to be put under SVA Path's control. Its command options are used to display or modify this device set.

`sppath` examines disk devices attached to the system to determine whether any physical devices are accessible via redundant paths and whether those devices should be put under the control of the SVA Path driver. Qualifying devices are written to the `/etc/sppath.conf` file. This file should not normally be modified directly by the user.

To qualify, devices must have appropriate inquiry data.

The vendor ID must match one of:

- STK
- IBM
- RSBA

The product ID must match one of:

- 9200
- 9393
- 9500

`sppath`'s command options are used to display or modify this device set.

Table 3-2, “sppath Command Options” gives a synopsis of sppath options. They are explained in greater detail below.

Table 3-2 sppath Command Options

Option	Effect
-d	display debug information
-D	clear the list of ignored devices. Should be followed by <code>setsp -g</code> (see note below)
-I{cXtYdZ}	ignore the device or group of devices specified; devices are specified in the form cX, cXtY, or cXtYdZ. all devices that match will be ignored; Should be followed by <code>setsp -g</code> (see note below)
-v	display the contents of <code>/etc/sppath.conf</code> after writing the file



Note: After running sppath with options -I or -D, you must run `setsp -g` in order for the changes to be reflected in SVA Path’s configuration file `/etc/spd.conf`. Changes will take effect at the next system reboot.

Display Options for sppath

The -v option causes sppath to display the contents of `/etc/sppath.conf` after updating it (Figure 3-8, “Using sppath in Verbose Mode”).

```
# sppath -v
LUN=0 c5t0d0 dev=32,3840 type=2 SANID="STK 9500 000000001038000E"
LUN=0 c6t0d0 dev=32,4800 type=2 SANID="STK 9500 000000001038000E"
LUN=1 c5t0d1 dev=32,3848 type=2 SANID="STK 9500 000000001038000F"
LUN=1 c6t0d1 dev=32,4808 type=2 SANID="STK 9500 000000001038000F"
LUN=2 c1t0d0 dev=32,240 type=2 SANID="STK 9500 000000001038000C"
LUN=3 c1t0d5 dev=32,2192 type=2 SANID="STK 9500 000000001038021C"
LUN=4 c1t1d5 dev=32,2248 type=2 SANID="STK 9500 000000001038021D"
LUN=5 c2t0d6 dev=32,3040 type=2 SANID="STK 9500 00000000103802F4"
LUN=6 c2t1d6 dev=32,3096 type=2 SANID="STK 9500 00000000103802F5"
```

Figure 3-8 Using sppath in Verbose Mode

The `-d` option displays inquiry data in raw format and is generally used only for debugging.

Ignoring and Reclaiming Devices with `sppath`

The `-I` option accepts symbolic device names corresponding to controllers or specific disks and omits them from `/etc/sppath.conf`.

This prevents them from being put under SVA Path's control.

If a device is to be ignored, all of its paths should be specified with `-I` options. Multiple devices can be specified in a single `sppath` command, but each device specified must be preceded by `-I`. Once specified, the ignored device is remembered in `/etc/sppath.conf` and will be ignored until the list of ignored devices is cleared with `setsp` using the `-D` option. Ignored devices will be seen as UNKNOWN by `setsp -a`. The ignored devices will behave like standard disk drives not under the control of SVA Path.

Run the following commands to ignore a device:

```
# setsp -T -l<spdX>
# sppath -I
# setsp -g
```

Alternately, you can also run `sppath -I`, followed by a reboot of the host, in order for the operating system to recognize the ignored device.



Note: The `sppath -I` (ignore) command should not be confused with the `setsp -e` (exclude) command. The former removes the device completely from SVA Path's control, treating it exactly as though it is incompatible with SVA Path and could not be recognized and claimed. The `setsp -e` command is intended chiefly for multiple host configurations and prevents particular logical devices from being accessed by a host.

The `-D` option clears the entire list of ignored devices, allowing any eligible device to be placed under SVA Path's control upon the next reconfiguration reboot.

Understanding the setsp -a Screen

Use the `setsp -a` command to display the default path configurations.

```
# setsp -a
=====
spd  Path/disk      Status Primary Exclude Buf Balance RtrCnt  RtrDly FailBack
=====
  0   c0t1d0         Good   X      X      32    1    20    3000    1
     c3t0d0         Good   X      X
spd0 = c83t0d0          ID = "STK 9500 0000000010390000"
=====
  1   c0t1d1         Good   X      X      32    1    20    3000    1
     c3t0d1         Good   X      X
spd1 = c83t0d1          ID = "STK 9500 0000000010390001"
=====
  2   c0t1d2         Good   X      X      32    1    20    3000    1
     c3t0d2         Good   X      X
spd2 = c83t0d2          ID = "STK 9500 0000000010390002"
=====
```

Figure 3-1 Sample Output of `setsp -a` Command

The column headings identify the various fields on this screen, the last seven of which are user-configurable parameters for the device. The `setsp -a` output fields (with their default values, when applicable) are described below. The commands used to change the default settings are described in the following section.

- **spd** is the SVA Path driver number, an ID assigned to the device by SVA Path and the name of the spd special device file created by SVA Path to access the storage. The spd device is displayed in the form `spdN = cXtYdZ`, and provides the spd number (*N* in the `spdN` field) and the virtual device name (in the format `cXtYdZ`). This device number also appears in errors reported in the `/var/adm/syslog/syslog.log` file.
- **Path/disk** shows the device names and disk numbers for each of the redundant physical paths to the device. Their appearance in the `setsp -a` output facilitates interpreting these events in terms of the spd device names by which applications access devices. This field shows the disk number in the form of `cXtYdZ`.

- **Status** shows the current state of the path. Good paths are functioning normally. Bad paths have failed.
- **Primary** shows which of the physical I/O paths connecting the device to the host's host bus adapters (or controllers) is defined as primary (marked by an x). Initially, primary path assignments are distributed evenly among the available paths. Figure 3-1, "Sample Output of `setsp -a` Command" shows this as an alternating pattern in a dual-path configuration: `spd0` has a primary path to controller 7, `spd1` uses its path to controller 8 as primary, and `spd2` alternates back to controller 7. The device's duplicate path(s) are not used unless the primary path fails or the load balancing option is selected for that device.
- **Exclude** indicates the exclusion setting, which is used to keep particular servers from seeing particular logical drives. As a safety measure, SVA Path excludes all devices from host access by default, giving them an exclusion setting of 1. Excluded devices are marked by an x in this column.
- **Buf** is the number of buffer pointers (or buffer structures) pre-allocated for each logical device. For peak performance, **Buf** should be approximately equal to the maximum useful queue depth of the logical unit. Values between 1 and 100 are permitted. The default value is 32.
- **Balance** indicates whether dynamic load balancing is enabled for the device. When load balancing is enabled, SVA Path tracks the volume of I/O on each path and automatically sends I/O requests to the path with the lightest I/O load. 1 means load balancing enabled. 0 means load balancing not enabled.
- **RtrCnt** is the number of times a failed I/O will be retried on the primary path after it has tried unsuccessfully to use its alternate path(s) and returned again to the primary. When the specified number of retries have failed, the I/O fails. The default value is 20. The highest value allowed is 100.
- **RtrDly** is the time interval, in milliseconds, between the retry attempts described in the preceding parameter. The

default value is 3000 ms. This value can not be set above 100,000 ms (100s).

- **FailBack** indicates whether failback is enabled for the logical device. When failback is enabled (the default setting of 1), SVA Path will keep testing a path that has failed and return it to service (as the primary path or in sequential load balancing) as soon as the path has been restored.

If the default configuration is satisfactory, no reconfiguration of SVA Path is necessary.

In addition to the information defined by the `setsp -a` output's column headings, the last part of the last line for each device (ID=) shows the physical device's unique identifier, which is derived from the device's inquiry data.

Changing the Configuration

The information displayed by `setsp -a` is stored in the configuration file `/etc/spd.conf`, which should *never* be edited directly. User-configurable parameters must be changed exclusively through the `setsp` command options provided for that purpose and are described in more detail in the following sections.

Specifying a Device for `setsp`

To name a specific device in any `setsp` command, use the `-l` option (note that this is a lowercase letter L, and not the number 1) followed by the device's `spd` number, as expressed in the syntax illustrations used in the remainder of this chapter as `-l<x>`. A device's `spd` number is listed in the first column of the `setsp -a` output (See `setsp -a` example on page 16).

Leaving out the `-l` option will apply the command to all of the devices. However, more than one device must never be explicitly specified in a given command. Also, whether you are applying the configuration command to a single device or to all the devices, only one parameter can be changed per command.

Assigning a New Primary Path

The syntax for changing an SVA LUN's primary data path is

```
setsp -l<x> -p<n>
```

where <x> is the `spd` number (see above) and <n> is the number of the new path. The path number can be obtained by simply counting down `setsp`'s list of physical paths (in the `Path/disk` column), starting from zero.

The command to change the primary path shown in Figure 3-1, on page 23, for the SVA device with the `spd` ID of 0 from its default path through controller 7 to the path through controller 8, then, would be:

```
# setsp -l0 -p1
```

If you run a `setsp` command with the verbose option (`-v`), the configuration change will be displayed on screen (below)

```
# setsp -v -l0 -p1
=====
  spd  Path/disk      Status Primary Exclude Buf Balance RtrCnt  RtrDly FailBack
=====
    0   c7t0d0/sd66   Good          X          32    0     20    3000     1
       c8t0d0/sd88   Good          X          32    0     20    3000     1
  spd0 = c3t0d0                                ID = "STK 9500 0000000010390000"
=====
```

Figure 3-2 Using `setsp -p` in Verbose Mode

Turning the Exclusion Setting Off and On

The syntax for changing the exclusion setting for a device is

```
setsp -l<x> -e{0|1}
```

where <x> is the `spd` number and the `-e` option takes one of two arguments:

- `-e0` turns exclusion off (makes the device visible to the host);
- `-e1` turns exclusion on (excludes the device).

In a single-host configuration all devices should be visible to the host. Devices can be included (or unexcluded) by using the command.

```
# setsp -l all -e0
```

All devices may be included, as they present no conflicts. However, in a multiple-host environment, where all spds are visible to SVA Path on all hosts, spds must be either excluded or included so that a host shares no spds. Use the ID number under the `spd` column on the `setsp -a` output to identify devices. Do not use the `spdX` number.

Redefining the Buffer Pointer Allocation

The syntax for changing the number of buffer pointers pre-allocated for a given device is

```
setsp -l<x> -n<n>
```

where `<x>` is the `spd` number (see “Specifying a Device for `setsp`” on page 25) and `<n>` is the new value. The system must be rebooted for this change to take effect. The number of buffer pointers recommended for a given device is approximately equal to the logical unit’s maximum useful queue depth; the default value of 32 should suit most SVA devices.

Turning Load Balancing On and Off

The syntax for changing a device's load balancing mode is

```
setsp -l<x> -b{0|1}
```

where `<x>` is the `spd` number and the `-b` option takes one of two arguments:

- `-b0` turns load balancing off;
- `-b1` turns load balancing on.

Changing the Retry Count and Retry Delay

The syntax for changing the retry count for a device is

```
setsp -l<x> -r<n>
```

where `<x>` is the numerical element of the `spd` number (see “Specifying a Device for `setsp`” on page 25) and `<n>` is the number of times a failed I/O will be retried on the primary path (after its alternate paths have been tried unsuccessfully) before the path is marked as failed (with a `Status` of `Bad`).

The syntax for changing the retry delay for a device is

```
setsp -l<x> -d<n>
```

where *<x>* is the numerical element of the *spd* number and *<n>* is the interval between the retries specified by the retry count parameter.

Turning Failback Off and On

The syntax for changing the a device's failback mode is

```
setsp -l<x> -f{0|1}
```

where *<x>* is the *spd* number (see “Specifying a Device for *setsp*” on page 25) and the *-f* option takes one of two arguments:

- *-f0* turns failback off;
- *-f1* turns failback on.

Dynamic Device Detection

You may be able to add new storage devices and place them under SVA Path's control without requiring a reboot of the host. This is also known as dynamic LUN allocation.

To add a fibre channel device to an existing path perform the following steps after the devices are connected:

1. Run *ioscan* and verify that the new storage resource is recognized by the system:

```
# ioscan -fn
```

2. Run the *insf* command to generate the special device files for the new storage:

```
# insf -e
```

3. Have SVA Path scan the new device for alternate paths:

```
# sppath -v
```

4. Create a SVA Path configuration file that includes the new device:

```
# setsp -g
```

```
# setsp -T -l <new_spd_number>
```

5. Start the new SVA Path device with:
`# setsp -s -1 <new_spd_number>`
6. Unexclude the new device:
`# setsp -e0 -1 <new_spd_number>`

Chapter 4. SVA Path Installation

This chapter describes how to install SVA Path for use with SVA 9500.

Installation of SVA Path in HP-UX is managed by the SD-UX software management commands. Many of these tools (e.g., `swinstall` and `swremove`) can be run either from the command line or from a Graphical User Interface (GUI). The following instructions illustrate using the command line. However, the same tasks can be accomplished through the GUI. For more information on this alternative consult your HP-UX documentation for `swinstall` and `swremove`.



Note: If your system contains current logical volumes, please read the section titled "Reconfiguration for Existing Logical Volumes" beginning on page 46 before installing SVA Path.

Installing SVA Path on HP-UX

Follow these steps to install the SVA Path driver and its supporting files.

1. Domain addresses must be automatically configured to be set to zero (refer to "SVA Path Hardware Setup", beginning on page 5).
2. Log in as `root` on the host on which you are installing SVA Path.

3. Before installing SVA Path, it is imperative that the host is able to see and access all storage devices through all available paths. For example, if you have two HBAs and redundant paths to your storage system, each logical drive should be displayed twice by the command:

```
# ioscan -fnC disk
```

If you can't see all available storage devices through every path, verify that you have the latest fibre channel or SCSI HBA drivers loaded on your system.

4. If a previous version of SVA Path is installed on your system, remove it before continuing with this installation. To determine if an older version of SVA Path is present on your system examine the output of the `swlist` command:

```
# /usr/sbin/swlist SVAPath
```

5. To install the software insert the CD-ROM distribution and log on as `root`. Mount the CD-ROM with the command:

```
# /usr/sbin/mount /dev/dsk/cXtYdZ/SD_CDROM
```

where `/dev/dsk/cXtYdZ` is the device special filename of your CD-ROM.

6. Before proceeding, refer to the `README` file in the directory `/SD_CDROM` for information on any changes to the software or installation procedure that may have occurred after this manual was printed.



Caution: Before continuing, be aware that running `swinstall` will rebuild your system kernel. You will have to reboot in order to use SVA Path devices.

7. Install SVA Path by becoming `root` and, from the `SD_CDROM` directory, issue the `./install` command.

Follow the onscreen instructions to completion.



Caution: The `swinstall` takes approximately 2.5 minutes to complete. To ensure that the `swinstall` has adequate time to

complete all active processes, **wait 3 minutes** before pressing the “Finish” button on the last panel of the install screens, and before rebooting and unmounting the CDROM. (To monitor active processes, type `ps -ef | grep install` and wait until all processes have ended before rebooting the machine and unmounting the CD.)

8. Enter the appropriate system command to eject the CDROM.
9. Reboot the host.
10. Verify that all available drives are seen by SVA Path by running the command:

```
# setsp -a
```

11. Edit any other application-specific files to reflect the new device names. New device files— identical to the pre-installation device files, except for their controller numbers—are generated during SVA Path installation for all SVA devices (including those accessible by only a single path). Any applications already configured to use the older device files to access SVA LUNs must be reconfigured to use the new pathnames (an example of this is given in the instructions below for installing SVA Path with SVA Administrator).

The installation is now complete.

Installing SVA Path with SVA Administrator

SVAA uses a designated LUN on the SVA for administrative commands (rather than data storage) and a particular character special device file (e.g., `/dev/rdisk/c1t0d0s2`) to access that LUN. This is SVAA’s Extended Control and Monitoring (ECAM) facility, and the LUN designated for its use is the ECAM device. *Before SVA Path is installed, make a note of this device name.*



Note: If SVA Path is installed after SVAA, SVA Path will claim the SVAA device. Run the following commands, which will cause SVA Path to ignore the specified device:

```
# sppath -I(cXtYdZ)  
  
# setsp -T -l(n)  
  
# setsp -g
```

Changes will take effect only after the next reboot of the host.

After SVA Path is installed, in addition to its physical path(s) (e.g., /dev/rdisk/c1t0d0s2 and /dev/rdisk/c2t0d0s2), a virtual path to the ECAM device will have been created along with an additional device name (e.g., /dev/rdisk/c3t0d0s2), which SVAA must be configured to use instead of the original ECAM device name. To discover the new name for the ECAM device, run `setsp -a` and look for the original device name among the listings in the second column; the new device name appears in the first column of the same entry, below the `spd` number. (An example of `setsp -a` output is shown in Figure 3-4 on page 16.)

Consult your SVAA documentation for details on running SVAA's `sibconfig` command to reconfigure the ECAM device name.

Uninstalling SVA Path

1. To remove SVA Path you need only enter the package remove command from the root directory:

```
# /usr/sbin/swremove SVAPath
```
2. Restore any application-specific files that were modified during the installation procedure.
3. Restore the hardware configuration.
4. Reboot the system.



Note: To remove the install files, remove the directory /opt/storagetek/svopath.

Installed Files

During installation, the files listed in Table 4-1, “Installed SVA Path Files” are placed in your system.

All of these files will be removed if SVA Path is uninstalled.

Table 4-1 *Installed SVA Path Files*

File	Description
/sbin/spckd	Script to start spcheck
/usr/conf/master.d/spd	SVA Path driver
/usr/conf/lib/libusrdrv.a	archive file in which spd is stored
/etc/sppath.conf	sppath configuration file
/etc/spd.conf	spd configuration file
/sbin/spcheck	Daemon to monitor change in paths
/sbin/sppath	qualifies and claims SVA storage devices for SVA Path control
/sbin/setsp	configures SVA Path parameters
/sbin/init.d/spdaemon	script to start and stop the spmon daemon
/etc/rc.config.d/svpath	SVA Path startup configuration file
/sbin/spmon	monitors device paths and implements load balancing
/sbin/rc1.d/S099spdaemon	symbolic link to /sbin/init.d/spdaemon

SVA Path Device Naming on HP-UX

Disk device filenames in HP-UX 10.x and higher have names in the following format:

```
/dev/dsk/cXtYdZ
```

```
/dev/rdisk/cXtYdZ
```

The *controller instance number (X)*, the disk drive's *SCSI ID number (Y)* and the *SCSI LUN number (Z)* can all be obtained from the **I** and the **H/W Path** columns of `ioscan -fn`:

```
# ioscan -fn
```

Class	I	H/W Path	Driver	S/W State	H/W Type	Description
bc	2	10	ccio	CLAIMED	BUS_NEXUS	I/O Adapter
ext_bus	0	10/0	c720	CLAIMED	INTERFACE	GSC Fast/Wide SCSI Interface
target	0	10/0.1	tgt	CLAIMED	DEVICE	
disk	13	10/0.1.0	sdisk	CLAIMED	DEVICE	STK 9500
			/dev/dsk/c0t1d0		/dev/rdisk/c0t1d0	
disk	14	10/0.1.1	sdisk	CLAIMED	DEVICE	STK 9500
			/dev/dsk/c0t1d1		/dev/rdisk/c0t1d1	
ext_bus	3	10/8	c720	CLAIMED	INTERFACE	GSC Fast/Wide SCSI Interface
target	5	10/8.0	tgt	CLAIMED	DEVICE	
disk	5	10/8.0.0	sdisk	CLAIMED	DEVICE	STK 9500
			/dev/dsk/c3t0d0		/dev/rdisk/c3t0d0	
disk	6	10/8.0.1	sdisk	CLAIMED	DEVICE	STK 9500
			/dev/dsk/c3t0d1		/dev/rdisk/c3t0d1	
ba	0	10/12	bus_adapter	CLAIMED	BUS_NEXUS	Core I/O Adapter
ext_bus	5	10/12/0	CentIf	CLAIMED	INTERFACE	Built-in Parallel Interface
			/dev/c5t0d0_lp			
ext_bus	4	10/12/5	c720	CLAIMED	INTERFACE	Built-in SCSI
target	7	10/12/5.2	tgt	CLAIMED	DEVICE	
disk	3	10/12/5.2.0	sdisk	CLAIMED	DEVICE	TOSHIBA CD-ROM XM-4101TA
			/dev/dsk/c4t2d0		/dev/rdisk/c4t2d0	

In a typical, single-path disk storage system, each physical disk is represented in the host's `/dev` directory by two special device files representing the character and block mode device instances. For simplicity, we will discuss this set of device files as a single device filename and disregard the first part of the pathnames that distinguish between raw and block modes.

As a layered driver that runs on top of the standard HP-UX disk driver (`sdisk`), SVA Path creates its own device files for devices, and it is through these filenames that applications access the underlying devices. When multiple paths to a single device are present, so would multiple device files be present, one for each path via the native disk driver. In these cases, which are typical of

SVA Path installations, SVA Path creates a single additional device filename for applications to access the device and manages the original device files transparently to those applications.



Note: It is the virtual device file that will be used by applications to access that device. The original, redundant data paths should never be used to access the device, or the data it contains could be corrupted.

For example, an SVA might present a single physical disk device to the HP-UX host as `c1t0d0` and `c2t0d0`. SVA Path creates a third device file named `c81t0d0` that is used by applications to access the storage. It blocks applications' access to the original two device files.

How Device Filenames Are Chosen

In order to provide interoperability with complementary storage management software (e.g., Logical Volume Manager), SVA Path uses standard HP-UX device names in the form `cXtYdz`, where `X` represents a controller or HBA number, `Y` represents a SCSI target number, and `Z` represents a SCSI LUN.

When SVA Path adds new device files to the system and changes the device names by which pre-existing devices must be accessed, the new device files, in order to be as easily understood as possible, retain the SCSI target and LUN from the original device files.

For example, a set of physical devices might originally be accessible via HBAs `c1` and `c2`. SVA Path will create new, virtual disk device files whose names start with `c81` and which have the same target and LUN numbers as the original device files. Therefore, a device originally accessible via the fibre channel or SCSI disk driver device files `c1t4d0` and `c2t4d0` will, after SVA

Path is installed, be accessed through the SVA Path device file `c81t4d0` (Figure 4-1).




Figure 4-1 SVA Path Device Filename Management

If the target and LUN numbers assigned to the device are different on each physical path, SVA Path uses the target and LUN number associated with the lowest numbered HBA. If a device is originally accessible as `c1t4d0` and `c2t2d1`, for example, the `c1t4d0` device name has the lower controller number (`c1`) and thus SVA Path takes the target (`t4`) and LUN (`d0`) number from it to construct the new device name, `c81t4d0`.

If there are more than one set of redundant paths, there could be more than one device with a given target and LUN number. For this reason, SVA Path creates a different virtual HBA for each set of redundant physical HBAs. For example, if one device is accessible via `c1t0d0` and `c2t0d0`, and another device is accessible via `c3t0d0` and `c4t0d0`, SVA Path would create two new device files `c81t0d0` (for `c1t0d0` and `c2t0d0`) and `c83t0d0` (for `c3t0d0` and `c4t0d0`).

Devices without Redundant Paths to the Host

SVA Path creates virtual device files for all supported devices and blocks access to them through their original device filenames whether or not they are accessible via redundant paths. Virtual device files are created for devices that have only one physical path for two reasons:

1. a device could actually have more than one path but only one was functional at the time that SVA Path was installed
2. the device could be part of a SAN configuration where it is necessary to prohibit applications on the local host from accessing the device because the device was assigned to another host on the SAN.

Logical Volume Manager

Logical Volume Manager (LVM) is a disk management system provided by HP in all versions of HP-UX 10.x and HP-UX 11.x. The LVM allows you to manage storage as logical volumes. This section of the manual describes some concepts used by the LVM and explains how to create and expand logical volumes. For more detailed information, please consult the man pages for `lvm(7)` and the *HP-UX System Administration Tasks* manual.

As with many systems administration tasks you can use the HP-UX System Administration Manager (SAM) to create and maintain some logical volumes. However, because SAM cannot recognize SVA Path devices, you must use the LVM commands `pvcreate`, `vgcreate` and `lvcreate`.

This section shows how to create a new volume group and add a disk drive to it, using example screens from an HP 800 system running HP-UX 11.00.

Definitions of Common Terms

The following terms will be used throughout this section:

- **Volume Group.** Volume groups are HP-UX's method for dividing and allocating disk storage space. Volume groups can be used to partition a disk drive into smaller logical volumes (see below). There is a default limit of 10 volume groups per system; see the *HP-UX System Administration Tasks* manual for information on increasing this limit. The number of logical volumes in a volume group is limited to 255.
- **Logical Volume.** Each volume group is divided into logical volumes, which can be accessed as either character or block devices and which contain their own filesystems.
- **Physical Volume.** In volume groups, the physical disk drives are designated as physical volumes.
- **Physical Extent.** Each physical volume is divided into units called physical extents; these units are 4 MB by default, and can range in size from 1 MB to 256 MB. The size of physical extents is a property of the volume group and is the same for all physical volumes in the volume group.

Preparing the Volume Group

Device files for each volume group on an HP 9000 system reside in directories with names `/dev/vg*`. The following example lists the volume groups on an HP800 system running HP-UX 11.00

```
# ls -l /dev/vg*

/dev/vg00:
total 0
crw-rw-rw- 1 rootroot 64 0x000000 Dec 23 15:23 group
brw-r-----1 root root 64 0x000001 Dec 23 15:23 lv011
brw-r-----1 rootroot 64 0x000002 Dec 23 15:23 lv012
brw-r-----1 root root 64 0x000003 Dec 23 15:23 lv013
crw-r-----1 root root 64 0x000001 Dec 23 15:23 rlv011
crw-r-----1 root root 64 0x000002 Dec 23 15:23 rlv012
crw-r-----1 root root 64 0x000003 Dec 23 15:23 rlv013
/dev/vg01:
total 0
crw-rw-rw- 1 root root 64 0x010000 Jan 11 14:15 group
brw-r-----1 root root 64 0x000001 Jan 23 15:23 lv011
crw-r-----1 root root 64 0x000001 Jan 23 15:23 rlv011
```

Two volume groups, `vg00` and `vg01`, already exist on this system. To prepare to create a new volume group:

Create the device directory that will contain the logical volume, using the next available volume group number. In this example, the next volume group number is 2, so the group should be named `/dev/vg02`:

```
# cd /dev
# mkdir vg02
```

Use `mknod` to create a device file named `group` in the new directory:

```
# mnokod /dev/vg02/group c 64 0x020000
# ls -lg /dev/vg02
total 0
crw-rw-rw- 1 sys64 0x020000 May 18 15:51 group
```

In the above example, the `mknod` command has the following arguments:

- the full pathname to the new device file group;
- the letter `c` to indicate a character device file;
- the number `64`, which is the major number for the driver that manages volume groups;

- a minor number of the form 0xNN0000, where NN is the two-digit hexadecimal representation of the volume group number (here, 02).

Creating the Physical Volume

Before you create a volume group, the disk drive you want to add to the group must be made a physical volume with `pvcreate`:

```
# pvcreate /dev/rdisk/c0t2d0

Physical volume "/dev/rdisk/c0t2d0" has been
successfully created
```

Creating the Volume Group

To create the volume group and associate the physical volume with it, use the `vgcreate` command:

```
# vgcreate /dev/vg02 /dev/dsk/c0t2d0

Increased the number of physical extents per
physical volume to 2167.

Volume group "/dev/vg02" has been successfully
created

Volume Group configuration for /dev/vg02 has
been saved in /etc/lvmconf/vg02.conf
```

`vgcreate` takes as its first argument the pathname of the volume group directory, and as its second argument the full pathname of the block device file (not the character device file, which was used to create the physical volume) of the disk drive.

To verify the creation and view the volume group characteristics, use the `vgdisplay` command:

```
# vgdisplay vg02

--- Volume groups ---
VG Name                /dev/vg02
VG Write Access        read/write
VG Status               available
Max LV                 255
Cur LV                0
Open LV                0
Max PV                 16
Cur PV                1
Act PV                 1
Max PE per PV         2167
VGDA                   2
PE Size (Mbytes)       4
Total PE               2167
Alloc PE               0
Free PE                2167
Total PVG              0
```

In the output of `vgdisplay`, the `Total PE` field gives the number of physical extents in the volume group. The size of each physical extent is given in the `PE Size` field (the default is 4 MB), so the total capacity of this volume group is $2167 \times 4 \text{ MB} = 8668 \text{ MB}$. The `Alloc PE` field shows the number of physical extents allocated to logical volumes. At this point, the `Alloc PE` field is zero because we have not assigned any of this volume group's capacity to logical volumes.

Please refer to the man page for `vgcreate` for more information on creating volume groups.

Creating Logical Volumes

To create a logical volume within the volume group, use the `lvcreate` command with the `-L` option to specify the size of the logical volume in megabytes. The logical volume size should be a

multiple of the physical extent size that is 4 MB by default. In the example below, a volume group of 4092 MB is created:

```
# lvcreate -L 4092 /dev/vg02
Logical volume "/dev/vg02/lvol1" has been
successfully created with character device
"/dev/vg02/rlvol1".
Logical volume "/dev/vg02/lvol1" has been
successfully extended.
Volume Group configuration for /dev/vg02 has
been saved in /etc/lvmconf/vg02.conf
```

In the example, `lvcreate` is followed on the command line by the `-L` option and the size of the logical volume in megabytes, then by the pathname of the volume group directory.

Both character and block device files for the new logical volume are created in the volume group directory:

```
# ls /dev/vg02
group  lvol1  rlvol1
```

Use these names to access the logical volumes. For example, to create an hfs filesystem on logical volume `lvol1` in volume group `vg02`, you would use the following command:

```
# /etc/newfs -F hfs /dev/vg02/rlvol1
```

The `Free PE` field in the `vgdisplay` output shows that the number of free physical extents in the volume group has decreased:

```
# vgdisplay vg02
--- Volume groups ---
VG Name                /dev/vg02
VG Write Access        read/write
VG Status              available
Max LV                 255
Cur LV                1
Open LV                1
Max PV                 16
Cur PV                1
Act PV                 1
Max PE per PV         2167
VGDA                   2
PE Size (Mbytes)      4
Total PE               2167
Alloc PE               1023
Free PE                1144
Total PVG              0
```

You can continue to create logical volumes with the `lvcreate` command until the `Free PE` field is 0, which indicates that the volume group has been completely allocated to logical volumes.

Reconfiguration for Existing Applications

Any physical device supported by SVA Path and in use prior to SVA Path installation will, from the perspective of host applications, be renamed during SVA Path installation. Applications will need to be redirected to the new filenames, by modifying the configuration of the individual application to reflect the new device names.

SVA Path does not support the LVM feature of alternative links to physical volumes (`pv-links`). If you have an existing volume group that was created with alternative links you must re-import it using the SVA Path device names of the physical volumes as explained below. SVA Path will provide the same level of protection against the failure of a single path.

Reconfiguration for Existing Logical Volumes

Since physical devices are renamed during SVA Path installation, if those physical devices are part of existing logical volumes, your system will not be able to locate the physical devices after SVA Path is installed. You will need to follow the steps listed below to

first export the volume group and then import it using the new special device filenames that SVA Path assigns.

In the following example there are two logical volumes in a volume group, `vg02`.

1. Make note of the minor number of the filename group for the volume group:

```
# ls -l /dev/vg02/group
crw-rw-rw- 1 root sys 64 0x020000 Jun 23 13:02 /dev/vg02/group
```

You will need this information to recreate the volume group later in this process. In this example the minor number for logical volume `vg02` is `0x020000`.

2. Determine the names of physical volumes that make up this volume group. Examine the last part of the output of the `vgdisplay` command, where the physical volumes that make up the volume group are listed. In this example, only the pertinent output is shown:

```
# vgdisplay -v /dev/vg02
--- Volume groups ---
VG Name                /dev/vg02

--- Physical volumes ---
  PV Name                /dev/dsk/c6t0d0
  PV Status              available
  Total PE               16747
  Free PE                16497

  PV Name                /dev/dsk/c6t0d1
  PV Status              available
  Total PE               16749
  Free PE                16749
```

The volume group is composed of physical volumes `/dev/dsk/c6t0d0` and `/dev/dsk/c6t0d1`.

- Unmount all of the logical volumes in the volume group and deactivate the volume group by entering the following command:

```
# vgchange -a n /dev/vg02
```

- Remove the volume group from the system configuration file and delete the associated device files for the logical volumes:

```
# vgexport /dev/vg02
```

- Recreate the directory and the device filename for the volume group using the same minor number of the original volume group:

```
# mkdir /dev/vg02
# mknod /dev/vg02/group c 64 0x020000
```

- Activate the SVA Path devices with:

```
# setsp -s
```

- Display the SVA Path device names with:

```
# setsp -a
=====
  spd  Path/disk  Status Primary Exclude Buf Balance RtrCnt  RtrDly FailBack
=====
    0  c6t0d0    Good   X           32    0    20    3000    1
       c7t0d0    Good
  spd0 = c86t0d0          ID = "STK 9500 0000000010390000"
=====
    1  c6t0d1    Good   X           32    0    20    3000    1
       c7t0d1    Good
  spd1 = c86t0d1          ID = "STK 9500 0000000010390001"
```

8. Select the SVA Path devices that correspond to the original device filenames of the physical volumes of the volume group. In this example they are `/dev/dsk/c86t0d0` and `/dev/dsk/c86t0d1`. Use these filenames in the `vgimport` command to recreate the configuration information for the volume group:

```
# vgimport -v /dev/vg02 /dev/dsk/c86t0d0
/dev/dsk/c86t0d1
    Beginning the import process on Volume Group
"/dev/vg02".
    Logical volume "/dev/vg02/lvol1" has been
successfully created with lv number 1.
    Logical volume "/dev/vg02/lvol2" has been
successfully created with lv number 2.
    Volume group "/dev/vg02" has been successfully
created.
    Warning: A backup of this volume group may not
exist on this machine.
    Please remember to take a backup using the
vgcfgbackup command after activating the volume group.
```

9. Activate the volume group and backup the configuration:

```
# vgchange -a y /dev/vg02
    Activated volume group
    Volume group "/dev/vg02" has been successfully changed.
# vgcfgbackup -u /dev/vg02
    Volume Group configuration for /dev/vg02 has been saved in
/etc/lvmconf/vg02.conf
```

You can now remount your filesystems and restart the applications that use them.

Chapter 5. Diagnosing Errors

Comparing `setsp -a` with System Events

SVA Path necessarily interfaces with system components at the I/O path level, which does not support sophisticated device error reporting. The application reports failed I/O to `/var/adm/syslog/syslog.log` as well as when:

- a data path is found to have stopped functioning
- I/O is redirected to an alternate path
- the failed path resumes functioning.

Whether a path failure is intermittent or is caused by a hardware failure can usually be deduced from the events listed in `/var/adm/syslog/syslog.log`, and a faulty device can be located physically by cross referencing the output of `setsp -a`.

Figure 5-1, “Example `setsp -a` Output for a Fully Functioning System” shows the example configuration used in this section.

```
# setsp -a
=====
spd  Path/disk      Status Primary Exclude Buf Balance RtrCnt  RtrDly FailBack
=====
    0  c6t0d0        Good   X          32    0    20    3000    1
       c7t0d0        Good
spd0 = c86t0d0          ID = "STK 9500 0000000010390000"
=====
    1  c6t0d1        Good   X          32    0    20    3000    1
       c7t0d1        Good
spd1 = c86t0d1          ID = "STK 9500 0000000010390001"
=====
    2  c6t0d2        Good   X          32    0    20    3000    1
       c7t0d2        Good
spd2 = c86t0d2          ID = "STK 9500 0000000010390002"
=====
```

Figure 5-1 Example `setsp -a` Output for a Fully Functioning System

Cable Failure Errors

Figure 5-2, “Messages Generated When a Cable Is Pulled” illustrates error messages that will occur in the file `/var/adm/syslog/syslog.log`. The hardware path of the affected fibre channel interface is identified as “0/5/0/0”. Using the output of the `ioscan` command in Figure 5-3, “Excerpt of `ioscan -fn` output”, the affected devices can be identified. In this example they are `/dev/dsk/c6t0d0`, `/dev/dsk/c6t0d1`, and `/dev/dsk/c6t0d2`.

```
Jun 30 14:54:36 n4000 vmunix: ALERT: fcT1 (1, 712251, 0/5/0/0) Fibre
Channel Driver received an interrupt indicating a Link Failure. The Frame
Manager Status Register is 0x980010D0.
Jun 30 14:55:58 n4000 vmunix: ALERT: fcT1 (1, 720484, 0/5/0/0) Fibre
Channel Driver received an interrupt indicating a Link Failure. The Frame
Manager Status Register is 0x980010D0.
Jun 30 14:56:28 n4000 vmunix: ALERT: fcT1 (1, 735458, 0/5/0/0) Fibre
Channel Driver received an interrupt indicating a Link Failure. The Frame
Manager Status Register is 0x980010D0.
Jun 30 14:57:31 n4000 vmunix: spd0: path 0 error
```

Figure 5-2 Messages Generated When a Cable Is Pulled

In the final message above, `spd0` can be located in the output from `setsp -a` to determine that the affected device is `c6t0d0`. The message also calls out `path 0` which corresponds to `c6t0d0/sd66` in the `setsp` output, which matches the device name (`sd66`) called out in the earlier messages. (The paths associated with a SVA Path device [`spd`] are numbered from 0 to $n-1$ and are listed in that order in the `setsp -a` output, so, for example, `spd2 path 1` is `c8t0d2` in the `setsp -a` output above).

```
# ioscan -fn
fc          0 0/5/0/0          fcT1      CLAIMED   INTERFACE
HP Fibre Channel Mass Storage Adapter
target      5 0/5/0/0.8.0.255.0.0  tgt       CLAIMED   DEVICE
disk        50 0/5/0/0.8.0.255.0.0.0  sdisk     CLAIMED   DEVICE STK 9500
                                                    /dev/dsk/c6t0d0  /dev/rdisk/c6t0d0
disk        51 0/5/0/0.8.0.255.0.0.1  sdisk     CLAIMED   DEVICE STL 9500
                                                    /dev/dsk/c6t0d1  /dev/rdisk/c6t0d1
disk        60 0/5/0/0.8.0.255.0.0.2  sdisk     CLAIMED   DEVICE STK 9500
```

Figure 5-3 Excerpt of `ioscan -fn` output

Errors for other `spd` devices, representing the same physical I/O path that was interrupted by the pulled cable, will be reported, as shown in Figure 5-4, “Additional Messages for the Same Pulled Cable”.

```
Jun 30 14:58:28 n4000 vmunix: ALERT: fcT1 (1, 735458, 0/5/0/0) Fibre
Channel Driver received an interrupt indicating a Link Failure. The Frame
Manager Status Register is 0x980010D0.
Jun 30 14:58:31 n4000 vmunix: spd2: path 0 error
Jun 30 14:58:36 n4000 vmunix: ALERT: fcT1 (1, 712251, 0/5/0/0) Fibre
Channel Driver received an interrupt indicating a Link Failure. The Frame
Manager Status Register is 0x980010D0.
Jun 30 14:58:40 n4000 vmunix: spd1: path 0 error
```

Figure 5-4 Additional Messages for the Same Pulled Cable

Even when an `spd` device is idle, a SCSI Test Unit Ready command is sent periodically to the device to confirm that it is functioning. A failure of this test is reported in the `syslog.log` file as illustrated in Figure 5-4, “Additional Messages for the Same Pulled Cable”.

Failover Error Reporting

`/var/adm/syslog/syslog.log` records failover events as well..

```
Jun 29 13:53:44 n4000 vmunix: spd0: path failover from 0 to 1.
```

Figure 5-5 The Failover Event

The event in Figure 5-5, “The Failover Event” records that I/O for the device `spd0` will be redirected from path 0 (`c6t0d0`) to path 1 (`c7t0d0`), the alternate path. The output from `setsp -a` (Figure 5-6, “`setsp -a` Output after the Failed Path Is Detected”) now

shows that every device's path 0 (those corresponding to device filenames beginning c7) have a Status designation of Bad.

```
# setsp -a
=====
spd  Path/disk      Status Primary Exclude Buf Balance RtrCnt  RtrDly FailBack
=====
  0  c6t0d0         Good   X          32    0    20    3000    1
     c7t0d0         Good
spd0 = c86t0d0          ID = "STK 9500 0000000010390000"
=====
  1  c6t0d1         Bad   X          32    0    20    3000    1
     c7t0d1         Good
spd1 = c86t0d1          ID = "STK 9500 0000000010390001"
=====
  2  c6t0d2         Bad   X          32    0    20    3000    1
     c7t0d2         Good
spd2 = c86t0d2          ID = "STK 9500 0000000010390002"
=====
```

Figure 5-6 *setsp -a* Output after the Failed Path Is Detected

Recovering from a Failure

Path failures generate a lot of output, resulting primarily from the disk driver's attempts at error recovery.

Finally, when the cable is plugged back in, SVA Path will detect that the primary I/O path for `spd0` is back to normal and redirect data over that path (Figure 5-7, "The Failback Event").

```
Jun 30 15:29:31 n4000 vmunix: spd1: path 0 ok
Jun 30 15:29:31 n4000 vmunix: spd2: path 0 ok
Jun 30 15:29:31 n4000 vmunix: spd3: path 0 ok
Jun 30 15:29:31 n4000 vmunix: spd1: path failover from 1 to 0.
```

Figure 5-7 *The Failback Event*

The other paths are returned to Status Good, as well.

The output of `setsp -a` will return to normal (Figure 5-1, on page 51).

**READER'S
COMMENT
FORM**

Manual Name: _____

Manual PN: _____

Please check or fill in the items; adding explanations/comments in the space provided.

Which of the following terms best describes your job?

- | | | | |
|---|--|---|--|
| <input type="checkbox"/> Field Engineer | <input type="checkbox"/> Manager | <input type="checkbox"/> Programmer | <input type="checkbox"/> Systems Analyst |
| <input type="checkbox"/> Engineer | <input type="checkbox"/> Mathematician | <input type="checkbox"/> Sales Representative | <input type="checkbox"/> Systems Engineer |
| <input type="checkbox"/> Instructor | <input type="checkbox"/> Operator | <input type="checkbox"/> Student/Trainee | <input type="checkbox"/> Other (explain below) |

How did you use this publication?

- | | | | |
|--|---|--|--|
| <input type="checkbox"/> Introductory text | <input type="checkbox"/> Reference manual | <input type="checkbox"/> Student/Trainee | <input type="checkbox"/> Instructor text |
| <input type="checkbox"/> Other (explain) _____ | | | |

Did you find the material easy to read and understand? Yes No (explain below)

Did you find the material organized for convenient use? Yes No (explain below)

Specific criticisms (explain below):

Clarifications on pages _____

Additions on pages _____

Deletions of pages _____

Errors on pages _____

Explanations and other comments:

Note: Staples can cause problems with automated mail sorting equipment. Please use pressure sensitive or other gummed tape to seal this form. If you would like a reply, please supply your name and address on the reverse side of this form.

Thank you for your cooperation. No postage stamp necessary if mailed in the U.S.A.

TO COMPLY WITH POSTAL REGULATIONS, FOLD EXACTLY ON DOTTED LINES AND TAPE (DO NOT STAPLE)




NO POSTAGE
NECESSARY
IF MAILED
IN THE
UNITED STATES

BUSINESS REPLY MAIL

FIRST CLASS PERMIT NO. 2 LOUISVILLE, CO U.S.A.

POSTAGE WILL BE PAID BY ADDRESSEE

STORAGE TECHNOLOGY CORPORATION
ENTERPRISE DISK INFORMATION DEVELOPMENT
ONE STORAGETEK DRIVE
LOUISVILLE CO 80028-2201



FOLD HERE AND TAPE

DO NOT STAPLE

FOLD HERE AND TAPE

If you would like a reply, please print:

Your Name: _____

Company Name: _____ Department: _____

Street Address: _____

