

Oracle® Life Sciences Data Hub
Application Programming Interface Guide
Release 2.2
E18794-01

May 2011

Copyright © 2011, Oracle and/or its affiliates. All rights reserved.

This software and related documentation are provided under a license agreement containing restrictions on use and disclosure and are protected by intellectual property laws. Except as expressly permitted in your license agreement or allowed by law, you may not use, copy, reproduce, translate, broadcast, modify, license, transmit, distribute, exhibit, perform, publish, or display any part, in any form, or by any means. Reverse engineering, disassembly, or decompilation of this software, unless required by law for interoperability, is prohibited.

The information contained herein is subject to change without notice and is not warranted to be error-free. If you find any errors, please report them to us in writing.

If this is software or related documentation that is delivered to the U.S. Government or anyone licensing it on behalf of the U.S. Government, the following notice is applicable:

U.S. GOVERNMENT RIGHTS Programs, software, databases, and related documentation and technical data delivered to U.S. Government customers are "commercial computer software" or "commercial technical data" pursuant to the applicable Federal Acquisition Regulation and agency-specific supplemental regulations. As such, the use, duplication, disclosure, modification, and adaptation shall be subject to the restrictions and license terms set forth in the applicable Government contract, and, to the extent applicable by the terms of the Government contract, the additional rights set forth in FAR 52.227-19, Commercial Computer Software License (December 2007). Oracle America, Inc., 500 Oracle Parkway, Redwood City, CA 94065.

This software or hardware is developed for general use in a variety of information management applications. It is not developed or intended for use in any inherently dangerous applications, including applications that may create a risk of personal injury. If you use this software or hardware in dangerous applications, then you shall be responsible to take all appropriate fail-safe, backup, redundancy, and other measures to ensure its safe use. Oracle Corporation and its affiliates disclaim any liability for any damages caused by use of this software or hardware in dangerous applications.

Oracle and Java are registered trademarks of Oracle and/or its affiliates. Other names may be trademarks of their respective owners.

Intel and Intel Xeon are trademarks or registered trademarks of Intel Corporation. All SPARC trademarks are used under license and are trademarks or registered trademarks of SPARC International, Inc. AMD, Opteron, the AMD logo, and the AMD Opteron logo are trademarks or registered trademarks of Advanced Micro Devices. UNIX is a registered trademark licensed through X/Open Company, Ltd.

This software or hardware and documentation may provide access to or information on content, products, and services from third parties. Oracle Corporation and its affiliates are not responsible for and expressly disclaim all warranties of any kind with respect to third-party content, products, and services. Oracle Corporation and its affiliates will not be responsible for any loss, costs, or damages incurred due to your access to or use of third-party content, products, or services.

Contents

Preface	xiii
Audience	xiii
Documentation Accessibility	xiii
Finding Information and Patches on My Oracle Support	xiii
Finding Oracle Documentation	xv
Related Documents	xvi
Conventions	xvi

Part I Essential Information

1 Using Application Programming Interfaces

1.1	About APIs.....	1-1
1.2	Calling APIs from Outside the Oracle Life Sciences Data Hub	1-3
1.2.1	Security Setup Required	1-3
1.2.2	Calling the Security API Package.....	1-3
1.2.3	Calling APIs from SAS.....	1-4
1.2.4	Using a Permanent Schema for Deploying Programs that Call APIs	1-4
1.3	Calling APIs from Defined Programs	1-4
1.4	Code Example Using Security and Error Message APIs.....	1-5

2 Reference Information

2.1	CDR Naming Version Object Type	2-1
2.2	CDR Base Object Type.....	2-3
2.3	CDR Object-Specific Database Object Types	2-3
2.4	Retrieving Reference Codelist Names and Values.....	2-4
2.5	Retrieving the Instance Domain ID	2-4
2.6	Standard Parameters	2-5

Part II Object APIs

3 Application Areas

3.1	Define and Modify Application Areas.....	3-1
3.1.1	Create an Application Area.....	3-1
3.1.2	Modify an Application Area	3-2

3.1.3	Remove an Application Area.....	3-2
3.1.4	Copy Objects into an Application Area.....	3-3
3.1.5	Move Objects into an Application Area	3-3

4 Business Areas

4.1	Define and Modify Business Areas	4-1
4.1.1	Create a Business Area.....	4-1
4.1.2	Modify a Business Area	4-3
4.1.3	Check out a Business Area	4-3
4.1.4	Undo a Business Area Checkout	4-4
4.1.5	Check in a Business Area.....	4-5
4.1.6	Remove a Business Area.....	4-5
4.2	Create and Modify Business Area Hierarchies.....	4-6
4.2.1	Create a Business Area Hierarchy	4-6
4.2.2	Modify a Hierarchy and a Hierarchy Column	4-6
4.2.3	Reorder a Hierarchy Column.....	4-7
4.2.4	Remove a Hierarchy Column	4-8
4.2.5	Remove a Business Area Hierarchy	4-8
4.3	Create and Modify Business Area Joins	4-9
4.3.1	Create a Join.....	4-9
4.3.2	Modify a Join and a Join Column.....	4-10
4.3.3	Remove a Join Column	4-11
4.3.4	Remove a Join.....	4-11
4.4	Public APIs and Naming Views for Generic Visualization Adapter (GVA).....	4-12
4.4.1	Initialize a Generic Visualization Business Area Instance.....	4-12
4.4.2	Reset a Generic Visualization Business Area.....	4-13
4.4.3	Get Possible Blinding Types of a Business Area Instance	4-13
4.4.4	Get Snapshot Labels Common to all Tables in a BA Instance for a Given Blinding AccessType	4-13
4.4.5	Naming Views.....	4-14

5 Data Marts

5.1	Define and Modify Work Areas.....	5-1
5.1.1	Create a Data Mart.....	5-1
5.1.2	Check In a DataMart Definition	5-3
5.1.3	Modify a Data Mart	5-3
5.1.4	Check Out a Data Mart	5-4
5.1.5	Remove a Data Mart.....	5-4

6 Domains

6.1	Define and Modify Domains.....	6-1
6.1.1	Create a Domain	6-1
6.1.2	Modify a Domain.....	6-2
6.1.3	Copy a Domain	6-2
6.1.4	Move Objects into a Domain.....	6-3
6.1.5	Copy Objects into a Domain	6-4

6.1.6	Copy Objects into a Domain and Check in	6-4
6.1.7	Remove a Domain	6-5

7 Setup Utilities

7.1	Initialize APIs	7-1
7.1.1	Initialize a Package	7-1
7.1.2	Verify Whether an API is Enabled	7-2
7.1.3	Enable an API.....	7-2
7.1.4	Disable an API.....	7-3
7.2	Define and Modify Adapters	7-3
7.2.1	Create an Adapter Domain	7-3
7.2.2	Create an Adapter Area	7-4
7.2.3	Populate a Tech Type Table	7-4
7.3	Host Definition Constants	7-5
7.4	Get Factory Support.....	7-5
7.4.1	Get a Naming Version Object	7-5
7.4.2	Get a User ID	7-5
7.4.3	Get a User Name.....	7-6
7.5	Get Factory Utilities.....	7-6
7.5.1	Get a Base Object Type.....	7-6
7.5.2	Get a Company ID.....	7-7
7.6	Get Factory Validations.....	7-7
7.6.1	Validate a Namespace.....	7-7
7.6.2	Validate a Reference	7-8
7.7	Get Data from Naming Tables	7-9
7.7.1	Get the Latest Version	7-9
7.7.2	Get a Maximum Version.....	7-10
7.7.3	Get the Type of a Naming Object.....	7-10
7.7.4	Get an Object's Naming Version	7-11
7.7.5	Get an Object's Subtype ID.....	7-11
7.7.6	Get an Object's Checkout Status.....	7-12
7.7.7	Get Checkout Properties	7-12
7.7.8	Get a Naming Object's Parent.....	7-13
7.7.9	Get a Parent Naming Object.....	7-13
7.7.10	Get the Latest Version of the Parent Object	7-14
7.7.11	Get the Naming Status of a Parent Object.....	7-14
7.7.12	Get the Validation Status of a Parent Object.....	7-15
7.7.13	Get a Definition Object.....	7-15
7.7.14	Get a Lookup Meaning	7-16
7.7.15	Find Whether an Object is an Instance	7-16
7.7.16	Find Whether Checked Out By Current User.....	7-17
7.7.17	Find Whether a Checkout is User-Specific.....	7-17
7.7.18	Find Whether Checkout is Implicit.....	7-18
7.8	Read Messages.....	7-18
7.8.1	Get a Message.....	7-19
7.8.2	Get a Message Count.....	7-19
7.8.3	Initialize a Message Stack	7-20

8 Load Sets

8.1	Define and Modify Load Sets.....	8-1
8.1.1	Create a Load Set	8-1
8.1.2	Check Out a Load Set Definition	8-3
8.1.3	Modify a Load Set.....	8-3
8.1.4	Check in a Load Set Definition	8-4
8.1.5	Remove a Load Set	8-5

9 Parameter Sets

9.1	Create and Modify Parameter Sets.....	9-1
9.1.1	Create a Parameter Set Definition	9-1
9.1.2	Check out a Parameter Set Definition.....	9-2
9.1.3	Modify a Parameter Set Definition.....	9-3
9.1.4	Modify a Parameter Set Detail	9-4
9.1.5	Check in a Parameter Set Definition	9-4
9.1.6	Remove a Parameter Set Definition	9-5

10 Planned Outputs

10.1	Create and Modify Planned Outputs.....	10-1
10.1.1	Create a Planned Output	10-1
10.1.2	Get a New Position Number	10-2
10.1.3	Get a Planned Output Object	10-3
10.1.4	Modify a Planned Output.....	10-3
10.1.5	Identify whether a SAS Object.....	10-4
10.1.6	Remove a Planned Output Object.....	10-4

11 Programs

11.1	Create and Modify Programs.....	11-1
11.1.1	Create a Program	11-1
11.1.2	Copy Objects Into a Program	11-3
11.1.3	Modify a Program.....	11-3
11.1.4	Check In a Program Definition	11-4
11.1.5	Check Out a Program Definition.....	11-4
11.1.6	Remove a Program	11-5
11.1.7	Create a Planned Output for a Log File.....	11-6
11.1.8	Assign a Planned Output	11-6
11.1.9	Modify a Manual Validation Flag Value.....	11-7

12 Report Sets

12.1	Create and Modify Report Set Entries	12-1
12.1.1	Create a Report Set Entry	12-2
12.1.2	Add and Modify an Entry	12-3
12.1.3	Copy a Report Set Entry into Another.....	12-4
12.1.4	Modify a Report Set Entry	12-5
12.1.5	Move a Report Set Entry into Another	12-5

12.1.6	Reorder Report Set Entries in a Parent Report Set.....	12-6
12.1.7	Find if a Report Set is Checked Out	12-7
12.1.8	Check Unique and Strict Numbering in a Report Set	12-7
12.1.9	Identify if a Report Set Contains Child Entries	12-8
12.1.10	Find if a User has Modify Permission	12-8
12.1.11	Remove an Object from a Report Set Entry	12-9
12.1.12	Remove a Report Set Entry.....	12-10
12.1.13	Get a Report Set Name	12-10
12.1.14	Get a Title	12-11
12.1.15	Get a Chapter Number.....	12-11
12.1.16	Get a Parent Number	12-12
12.1.17	Get a List of Report Set Entry Titles	12-12
12.1.18	Get All RSE Titles in a Report Set.....	12-13
12.1.19	Get Attribute Values Derived from a Parent	12-13
12.1.20	Get the Lowest Entry Number.....	12-14
12.1.21	Get the Total Number of Report Set Entries	12-15
12.1.22	Create a Narrative.....	12-15
12.1.23	Update a Narrative	12-16
12.1.24	Delete a Narrative.....	12-17
12.1.25	Check if Copying Retains Valid Numbering in a Target Report Set.....	12-17
12.1.26	Check if a Move Retains Valid Numbering in a Target Report Set.....	12-18
12.1.27	Check if a Move Retains Valid Numbering in the Parent Report Set	12-19
12.1.28	Check if Removal Retains Valid Numbering in a Parent Report Set	12-19
12.1.29	Check if Reordering Retains Valid Numbering in a Parent Report Set.....	12-20
12.1.30	Unassign a Planned Output	12-20
12.2	Create and Modify Report Sets	12-21
12.2.1	Create a Report Set	12-21
12.2.2	Check Out a Report Set	12-22
12.2.3	Undo a Report Set Checkout.....	12-23
12.2.4	Copy Objects Into a Report Set	12-24
12.2.5	Get a Summary Output Validation Status	12-25
12.2.6	Modify a Report Set.....	12-25
12.2.7	Move Objects into a Report Set.....	12-26
12.2.8	Remove Objects from a Report Set.....	12-27
12.2.9	Check In a Report Set	12-27
12.2.10	Remove a Report Set Definition	12-28
12.2.11	Remove a Report Set	12-28
12.3	Create and Modify Overlay Template Definitions	12-29
12.3.1	Create an Overlay Template Definition	12-29
12.3.2	Modify an Overlay Template Definition File Definition	12-30
12.3.3	Get an Overlay Template Definition File as a BLOB	12-30
12.3.4	Remove an Overlay Template Definition File Definition	12-31
12.4	Report Set Overlay Template	12-31
12.4.1	Create an Overlay Template	12-32
12.4.2	Check Out an Overlay Template	12-33
12.4.3	Undo an Overlay Template Checkout.....	12-33
12.4.4	Copy Objects Into an Overlay Template	12-34

12.4.5	Modify an Overlay Template.....	12-34
12.4.6	Check In an Overlay Template	12-35
12.4.7	Remove an Overlay Template	12-35

13 Software Source Codes

13.1	Create and Modify Source Code.....	13-1
13.1.1	Create a Source Code Object	13-1
13.1.2	Get a Source Code CLOB.....	13-3
13.1.3	Modify Source Code.....	13-3
13.1.4	Set the Primary Flag to Yes.....	13-5
13.1.5	Update a Shareable Flag	13-5
13.1.6	Remove a Source Code Object	13-6

14 Tables

14.1	Create and Modify Tables.....	14-1
14.1.1	Create a Table Definition	14-1
14.1.2	Create a Table Instance	14-2
14.1.3	Create a Temporary Blob.....	14-4
14.1.4	Create a Table Column.....	14-4
14.1.5	Create a Table Constraint	14-5
14.1.6	Modify a Table Definition	14-6
14.1.7	Modify a Table Descriptor.....	14-7
14.1.8	Modify a Table Instance.....	14-7
14.1.9	Reorder a Column.....	14-8
14.1.10	Upload a Table Descriptor or Column	14-9
14.1.11	Check in a Table Object.....	14-9
14.1.12	Remove a Single Object.....	14-10

15 Parameters

15.1	Define and Modify Parameters.....	15-1
15.1.1	Create a Parameter	15-1
15.1.2	Check Out a Parameter	15-3
15.1.3	Check In a Parameter	15-4
15.1.4	Get Displayed Parameter Values.....	15-4
15.2	Define Parameter Relations	15-5
15.2.1	Create a Parameter Relation Collection.....	15-5
15.2.2	Get Parameter Instances for Value Passing	15-6
15.2.3	Remove Parameter Relations	15-7

16 Variables

16.1	Create and Modify Variables	16-1
16.1.1	Create a Variable.....	16-1
16.1.2	Check Out a Variable	16-2
16.1.3	Modify a Variable	16-3
16.1.4	Check In a Variable.....	16-3
16.1.5	Remove a Variable.....	16-4

17 Work Areas

17.1	Define and Modify Work Areas.....	17-1
17.1.1	Create a Work Area	17-1
17.1.2	Install a Work Area.....	17-2
17.1.3	Check in a Work Area	17-3
17.1.4	Modify a Work Area.....	17-4
17.1.5	Clone a Work Area	17-4
17.1.6	Copy Objects into a Work Area	17-5
17.1.7	Clone an Object	17-6
17.1.8	Remove a Work Area	17-7
17.1.9	Get the Usage Intent RC of a Work Area	17-7
17.1.10	Update a Work Area's Usage Intent	17-8
17.1.11	Install a Program.....	17-8

18 Workflows

18.1	Create and Modify Workflows	18-1
18.1.1	Create a Workflow	18-1
18.1.2	Check Out a Workflow Definition	18-3
18.1.3	Create a Workflow Transition.....	18-3
18.1.4	Create a Workflow Structure Instance.....	18-4
18.1.5	Modify a Workflow	18-4
18.1.6	Modify a Workflow	18-5
18.1.7	Check in a Workflow Definition.....	18-5
18.1.8	Remove a Transition.....	18-6
18.1.9	Remove a Workflow Activity	18-6
18.1.10	Remove a Workflow Instance	18-7
18.1.11	Remove a Workflow Definition.....	18-7

19 Workflow Notifications

19.1	Create and Modify Notifications	19-1
19.1.1	Create a Notification	19-1
19.1.2	Create a Notification Recipient.....	19-2
19.1.3	Create a Notification Link	19-3
19.1.4	Check Out a Notification Definition	19-3
19.1.5	Modify a Notification Definition	19-4
19.1.6	Modify a Notification Instance	19-5
19.1.7	Send a Notification	19-5
19.1.8	Check in a Notification Definition	19-5
19.1.9	Remove a Notification Link	19-6
19.1.10	Remove a Notification Recipient.....	19-6
19.1.11	Remove a Notification.....	19-7

Part III Common APIs

20 Execution Setups

20.1	Create and Modify Execution Setups.....	20-1
20.1.1	Create an Execution Setup.....	20-1
20.1.2	Check Out an Execution Setup	20-2
20.1.3	Modify an Execution Setup	20-3
20.1.4	Modify a Parameter	20-3
20.1.5	Modify an Execution Setup Parameter	20-4
20.1.6	Load Parameter Details.....	20-4
20.1.7	Copy an Execution Setup.....	20-5
20.1.8	Check In an Execution Setup	20-5
20.1.9	Submit an Execution Setup	20-6
20.1.10	Submit an Execution Setup for Instances	20-7
20.1.11	Upgrade an Execution Setup.....	20-8
20.1.12	Upgrade All Execution Setups.....	20-8
20.1.13	Make an Execution Setup Active.....	20-9
20.1.14	Remove an Execution Setup.....	20-9

21 Mappings

21.1	Create and Modify Mappings	21-1
21.1.1	Map a Column.....	21-1
21.1.2	Map a Table Descriptor to a Table Instance.....	21-2
21.1.3	Create a Table Descriptor from a Table Instance	21-3
21.1.4	Create a Table Instance from a Table Descriptor	21-3
21.1.5	Modify a Mapping Column	21-4
21.1.6	Modify a Mapping at the Table Descriptor Level.....	21-4
21.1.7	Get a PRREF_ID for an Executable in a Workflow	21-5
21.1.8	Get a PRREF_ID for an Object in a Work Area	21-6
21.1.9	Get a PRREF_ID for a Program in a Report Set.....	21-6

22 Outputs

22.1	Generate Outputs.....	22-1
22.1.1	Submit a Print Request.....	22-1
22.1.2	Get an Output's BLOB	22-2
22.1.3	Get an Output's CLOB	22-2

23 Version Labels

23.1	Modify Version Labels	23-1
23.1.1	Update a Version Label.....	23-1

24 Classification

24.1	Classify Objects	24-1
24.1.1	Classify an Object.....	24-1
24.1.2	Declassify an Object.....	24-2

24.2	Classify Subtypes	24-2
24.2.1	Get a Subtype Classification Level	24-3
24.2.2	Get an Object Classification Value	24-3
24.2.3	Get a Parent Term	24-4
24.3	Create and Modify Classification Hierarchy Values	24-4
24.3.1	Insert a Classification Value	24-5
24.3.2	Update a Classification Value	24-5
24.3.3	Delete a Classification Value	24-6
25	Job Execution	
25.1	Create and Execute Output Jobs	25-1
25.1.1	Create a Binary Output	25-1
25.1.2	Upload an Output BLOB	25-2
25.1.3	Upload an Output Clob	25-2
25.1.4	Upload a LOB to a Temporary Table	25-3
25.1.5	Download a Job Output BLOB	25-4
25.1.6	Queue a Job	25-4
25.1.7	Wait for a Job to Complete	25-5
25.1.8	Generate an XML Payload	25-5
25.2	Retrieve Information about Ongoing Jobs	25-7
25.2.1	Get an Ongoing Job ID	25-7
25.2.2	Get Currently Executing Parameters	25-7
25.2.3	Get Information About a Job	25-8
25.2.4	Get Job Information (Overloaded)	25-8
25.3	Set Execution Statuses	25-9
25.3.1	Set a User-specific Completion Status	25-9
25.3.2	Set a Customized Output Title	25-10
25.3.3	Set a Customized Output Subtitle	25-10
25.3.4	Set an Output Parameter	25-11
25.3.5	Get a Completion Status	25-11
25.4	Submit Messages	25-11
25.4.1	Submit a Message	25-12
25.5	Create Submission Records	25-12
25.5.1	Start a Job	25-12
25.5.2	Create a Submission	25-13
25.5.3	Create a Submission from a Job	25-14
25.5.4	Add a Job Log	25-14
26	Security Policy	
26.1	Create and Modify Security Policies	26-1
26.1.1	Create a Subtype	26-2
26.1.2	Copy a Subtype	26-2
26.1.3	Modify a Subtype	26-3
26.1.4	Assign Roles to a Subtype Operation	26-3
26.1.5	Assign Operations to a Subtype Role	26-3
26.1.6	Remove a Subtype	26-4

26.1.7	Create a Role.....	26-4
26.1.8	Modify a Role	26-5
26.1.9	Add a Group Role.....	26-5
26.1.10	Get Roles for a User	26-6
26.1.11	Remove a Role.....	26-6
26.1.12	Remove a Group Role	26-7
26.1.13	Create a User Group.....	26-7
26.1.14	Add Users to a Group	26-7
26.1.15	Remove Users from a Role in a User Group.....	26-8
26.1.16	Assign a User Group to an Object	26-8
26.1.17	Copy a User Group.....	26-9
26.1.18	Copy a User Group with its Users	26-9
26.1.19	Modify a User Group	26-10
26.1.20	Remove All Group Roles from a User Group.....	26-10
26.1.21	Remove All Users in a Group	26-11
26.1.22	Revoke a User Group From an Object	26-11
26.1.23	Undo a Revoke a User Group Action	26-12
26.1.24	Remove a User Group.....	26-12
26.1.25	Unassign a User Group From an Object.....	26-13
26.1.26	Unassign Roles from an Operation on an Object's Subtype.....	26-13
26.1.27	Unassign Operations on an Object Subtype's Role.....	26-14

27 Validation

27.1	Validate Objects.....	27-1
27.1.1	Update an Object's Validation Status	27-1
27.2	Create and Modify Validation Supporting Documents	27-2
27.2.1	Create a Validation Supporting Document	27-2
27.2.2	Update a Validation Supporting Document.....	27-2
27.2.3	Obsolete a Validation Supporting Document	27-3

Preface

This book contains information on public Application Programming Interfaces (APIs) that can be used to interface with Oracle Life Sciences Data Hub.

This preface contains the following topics:

- "Audience" on page xiii
- "Documentation Accessibility" on page xiii
- "Finding Information and Patches on My Oracle Support" on page xiii
- "Finding Oracle Documentation" on page xv
- "Related Documents" on page xvi
- "Conventions" on page xvi

Audience

This manual is intended for programmers with an understanding of Oracle technology.

Documentation Accessibility

For information about Oracle's commitment to accessibility, visit the Oracle Accessibility Program website at
<http://www.oracle.com/pls/topic/lookup?ctx=acc&id=docacc>.

Access to Oracle Support

Oracle customers have access to electronic support through My Oracle Support. For information, visit
<http://www.oracle.com/pls/topic/lookup?ctx=acc&id=info> or visit
<http://www.oracle.com/pls/topic/lookup?ctx=acc&id=trs> if you are hearing impaired.

Finding Information and Patches on My Oracle Support

Your source for the latest information about Oracle Clinical is Oracle Support's self-service Web site My Oracle Support (formerly MetaLink).

Before you install and use Oracle Clinical, always visit the My Oracle Support Web site for the latest information, including alerts, White Papers, installation verification (smoke) tests, bulletins, and patches.

Creating a My Oracle Support Account

You must register at My Oracle Support to obtain a user name and password account before you can enter the Web site.

You must register at My Oracle Support to obtain a user name and password account before you can enter the Web site.

To register for My Oracle Support:

1. Open a Web browser to <https://support.oracle.com>.
2. Click the **Register** link to create a My Oracle Support account. The registration page opens.
3. Follow the instructions on the registration page.

Signing In to My Oracle Support

To sign in to My Oracle Support:

1. Open a Web browser to <https://support.oracle.com>.
2. Click **Sign In**.
3. Enter your user name and password.
4. Click **Go** to open the My Oracle Support home page.

Finding Information on My Oracle Support

There are many ways to find information on My Oracle Support.

Searching by Article ID

The fastest way to search for information, including alerts, White Papers, installation verification (smoke) tests, and bulletins is by the article ID number, if you know it.

To search by article ID:

1. Sign in to My Oracle Support at <https://support.oracle.com>.
2. Locate the Search box in the upper right corner of the My Oracle Support page.
3. Click the sources icon to the left of the search box, and then select **Article ID** from the list.
4. Enter the article ID number in the text box.
5. Click the magnifying glass icon to the right of the search box (or press the Enter key) to execute your search.

The Knowledge page displays the results of your search. If the article is found, click the link to view the abstract, text, attachments, and related products.

Searching by Product and Topic

You can use the following My Oracle Support tools to browse and search the knowledge base:

- **Product Focus** — On the Knowledge page under Select Product, type part of the product name and the system immediately filters the product list by the letters you have typed. (You do not need to type "Oracle.") Select the product you want from the filtered list and then use other search or browse tools to find the information you need.

- **Advanced Search** — You can specify one or more search criteria, such as source, exact phrase, and related product, to find information. This option is available from the **Advanced** link on almost all pages.

Finding Patches on My Oracle Support

Be sure to check My Oracle Support for the latest patches, if any, for your product. You can search for patches by patch ID or number, or by product or family.

To locate and download a patch:

1. Sign in to My Oracle Support at <https://support.oracle.com>.
2. Click the **Patches & Updates** tab. The Patches & Updates page opens and displays the Patch Search region. You have the following options:
 - In the **Patch ID or Number** field, enter the number of the patch you want. (This number is the same as the primary bug number fixed by the patch.) This option is useful if you already know the patch number.
 - To find a patch by product name, release, and platform, click the **Product or Family** link to enter one or more search criteria.
3. Click **Search** to execute your query. The Patch Search Results page opens.
4. Click the patch ID number. The system displays details about the patch. In addition, you can view the Read Me file before downloading the patch.
5. Click **Download**. Follow the instructions on the screen to download, save, and install the patch files.

Finding Oracle Documentation

The Oracle Web site contains links to all Oracle user and reference documentation. You can view or download a single document or an entire product library.

Finding Oracle Health Sciences Documentation

To get user documentation for Oracle Health Sciences applications, go to the Oracle Health Sciences documentation page at:

<http://www.oracle.com/technetwork/documentation/hsgbu-154445.html>

Note: Always check the Oracle Health Sciences Documentation page to ensure you have the latest updates to the documentation.

Finding Other Oracle Documentation

To get user documentation for other Oracle products:

1. Go to the following Web page:

<http://www.oracle.com/technology/documentation/index.html>

Alternatively, you can go to <http://www.oracle.com>, point to the Support tab, and then click **Documentation**.

2. Scroll to the product you need and click the link.
3. Click the link for the documentation you need.

Related Documents

This section lists the documents in the Oracle Life Sciences Data Hub documentation set, followed by their part number. The most recent version of each guide is posted on Oracle Technology Network; see ["Finding Oracle Documentation"](#) on page xv.

- *Oracle Life Sciences Data Hub Installation Guide* (Part E22743-01)
- *Oracle Life Sciences Data Hub Implementation Guide* (Part E22744-01)
- *Oracle Life Sciences Data Hub System Administrator's Guide* (Part E22745-01)
- *Oracle Life Sciences Data Hub Application Developer's Guide* (Part E22746-01)
- *Oracle Life Sciences Data Hub User's Guide* (Part E22747-01)
- *Oracle Life Sciences Data Hub Application Programming Interface Guide* (Part E18794-01)

Conventions

The following text conventions are used in this document:

Convention	Meaning
boldface	Boldface type indicates graphical user interface elements associated with an action, or terms defined in text or the glossary.
Initial Capitalization for defined objects	User-defined objects in Oracle LSH such as Tables, Source Code, and Variables, have initial capitalization to distinguish them from generic tables, source code, and variables, for example.
<i>italic</i>	Italic type indicates book titles, emphasis, or placeholder variables for which you supply particular values.
<code>monospace</code>	Monospace type indicates commands within a paragraph, URLs, code in examples, text that appears on the screen, or text that you enter.

Part I

Essential Information

This part of the Oracle Life Sciences Data Hub (Oracle LSH) API guide contains the basic information you need on running APIs.

Part I contains the following chapters:

- [Chapter 1, "Using Application Programming Interfaces"](#)
- [Chapter 2, "Reference Information"](#)

Using Application Programming Interfaces

This section contains the following topics:

- [Section 1.1, "About APIs"](#)
- [Section 1.2, "Calling APIs from Outside the Oracle Life Sciences Data Hub"](#)
- [Section 1.3, "Calling APIs from Defined Programs"](#)
- [Section 1.4, "Code Example Using Security and Error Message APIs"](#)

Views All Oracle Life Sciences Data Hub (Oracle LSH) views are public and have names that begin with "cdr_". You can see them in SQL Developer or a similar tool, or query for them using the string `cdr_`

Note: During its initial development, Oracle LSH was known as CDR. Therefore many internal names contain the string `cdr`. Please think of CDR as a synonym for LSH.

1.1 About APIs

Oracle LSH includes a set of APIs that enable you to do most of the things you can do through the user interface, including creating, modifying, and installing objects.

You can call Oracle LSH APIs from source code in a defined Program in Oracle LSH. In this case, no additional security or setup is required.

If you have an Oracle LSH database account with certain privileges, you can also develop programs that call APIs in a tool outside of Oracle LSH; such as SAS, Oracle SQL Developer, or SQL*Plus. You can then see views of all the Oracle LSH data you need, including data from both the LSH (CDR) schema and, for classification data, the TMS schema. You can make the programs you write available to other people from the external tool. See ["Calling APIs from Outside the Oracle Life Sciences Data Hub"](#) on page 1-3.

Example 1: Using APIs to Perform Multiple Tasks at Once You can write a package that calls multiple APIs to do with one execution what it would take many tasks in the user interface (UI) to do; for example, create a Domain, an Application Area inside the Domain, a Work Area inside the Application Area, and multiple Load Sets, Tables, and Programs, each with a definition in the Application Area and an instance in the Work Area, and install the Work Area. If you have a standard structure for Project/Therapeutic Area Domains, for example, you may want to work this way. However, remember that you can also copy a Domain and all its contents at once in the user interface.

Using APIs is even more attractive when you want to create, for example, multiple objects with variations or large complex objects such as Report Sets. You can create a spreadsheet to store all the variable information and load its data into an Oracle LSH Table instance using a Text Load Set. In your program, use a loop to read all the spreadsheet data and call the relevant Oracle LSH APIs to create the objects.

Example 2: Calling APIs from an External System's UI You may want to allow people in your company to perform actions on Oracle LSH objects from an external system.

For example, instead of requiring that SAS developers check out Source Code in Oracle LSH before opening the SAS IDE from an Oracle LSH Program, you may want to add a button to the SAS user interface that calls the API for checking out the Source Code object when clicked. Then, if the program is located in a schema with Execute privileges on the security API, any user with SAS, a database account in Oracle LSH, and normal Oracle LSH object security privileges on the Source Code definition, can check out the Source Code definition directly from SAS.

Understand Oracle LSH Functionality To use Oracle LSH APIs, you must understand basic Oracle LSH functionality including:

- **Object Ownership.** You must create container objects before creating the objects they contain, because to create any object you must identify its namespace (parent, or container) object. For example, begin by defining a Domain, then an Application Area, then a Work Area, and then create a Table definition in the Application Area and an instance of it in the Work Area. You can use a single API to create both the Table definition and an instance of it. For details, see "Object Ownership" in the *Oracle Life Sciences Data Hub Application Developer's Guide*.
- **Installation.** You must create an instance of an object definition and install it before you can execute or otherwise use the object.
- **Mapping.** All executable objects must contain at least one Table Descriptor, each of which must be mapped to an installed Table instance. For details, see "Defining and Mapping Table Descriptors" in the *Oracle Life Sciences Data Hub Application Developer's Guide*.
- **Checking Objects In and Out.** You must check objects out to modify them and check them in before you install and use them. For details, see "Understanding Object Versions and Checkin/Checkout" in the *Oracle Life Sciences Data Hub Application Developer's Guide*.
- **Security.** All objects require user group assignments to control user access. For details, see "Applying Security to Objects and Outputs" in the *Oracle Life Sciences Data Hub Application Developer's Guide*.
- **Classification.** To enable objects to appear in the Reports tab of the user interface for end users to run them and view their outputs, you must classify them. Classifications can also be used in searching for objects. For details, see "Classifying Objects and Outputs" in the *Oracle Life Sciences Data Hub Application Developer's Guide*.
- **Validation.** Objects should be validated according to your company policy whether they are created in the user interface or with APIs. For details, see "Validating Objects and Outputs" in the *Oracle Life Sciences Data Hub Application Developer's Guide*.
- **Object-Specific Information.** Further information on each object type is included in other chapters of the *Oracle Life Sciences Data Hub Application Developer's Guide*.

1.2 Calling APIs from Outside the Oracle Life Sciences Data Hub

This section contains the following topics:

- [Section 1.2.1, "Security Setup Required"](#)
- [Section 1.2.2, "Calling the Security API Package"](#)
- [Section 1.2.3, "Calling APIs from SAS"](#)
- [Section 1.2.4, "Using a Permanent Schema for Deploying Programs that Call APIs"](#)

1.2.1 Security Setup Required

To run any API package from a tool outside of Oracle LSH, such as SAS, SQL Developer, or SQL*Plus, your system administrator needs to do the following:

1. Set up an Oracle LSH database account linked to your LSH user account; see "Creating Database Accounts" in the *Oracle Life Sciences Data Hub System Administrator's Guide*.
2. Grant your Oracle LSH database account Execute privileges on the API security package `cdr_pub_api_initialization`.

In addition, to run APIs that insert, delete, or modify classification hierarchy terms, you need security access to the Oracle Thesaurus Management System (TMS) instance that is installed as part of Oracle LSH. The Oracle LSH classification system is based on TMS. Ask your system administrator to use the script `tmsadduser.sql` to do the following:

3. Create a TMS user account with the same name as your Oracle LSH database account so that your account is entered in the `TMS_ACCOUNTS` and `OPA_ACCOUNTS` tables.
4. Give your TMS user account superuser privileges in the `TMS_ACCOUNTS` table.
5. Grant your TMS user account the `TMS_MAINTAIN_PRIV` database role.

1.2.2 Calling the Security API Package

For every program that you run from outside Oracle LSH to call an Oracle LSH API, you must first call a special security API: `cdr_pub_api_initialization`. This API contains three functions:

- `EnableApis`
- `DisableApis`
- `AreApisEnabled`

When you initialize any API, the `AreApisEnabled` function of the security API, `cdr_pub_api_initialization`, is called to check the calling program. If the program does not have the `EnableApis` flag set to True, the initialization fails.

To set the `EnableApis` flag to True, call the `EnableApis` function of the same security API from your program. To call the `EnableApis` function, you need a schema/user account with an Execute privilege on the `cdr_pub_api_initialization` API granted by a system administrator.

Therefore, when you write a program that calls an API and is intended for use outside Oracle LSH, set the `EnableApis` flag to True in your program and then set it to False at the end to force the security check on the schema the next time the program is run:

1. Begin the body with the following code to call the function to enable APIs:

```
call cdr_pub_api_initialization.enableApis (arguments);
```

The arguments are described in `cdr_pub_api_initialization` itself.

2. At the end of the body, disable APIs with the following code:

```
cdr_pub_api_initialization.disableApis (arguments);
```

See [Example 1-1, "Program that Calls the API to Define a Work Area and Calls the Security and Error Message APIs"](#) on page 1-5.

1.2.3 Calling APIs from SAS

If you need to call multiple APIs from SAS, you may want to use a PL/SQL wrapper around the API calls so that you only call PL/SQL once. The *Oracle Life Sciences Data Hub Application Developer's Guide* has two examples. In the Report Sets chapter, see "Passing Values from a Program Instance to the Report Set for Post-Processing" and in the Programs chapter see "Calling an API to Capture Output Parameter Values."

1.2.4 Using a Permanent Schema for Deploying Programs that Call APIs

When you develop a program outside Oracle LSH that will call Oracle LSH APIs, you can use your own schema in the external tool (such as SQL*Plus, SQL Developer, or SAS) to run and test the program, if you have Execute privileges on `cdr_pub_api_initialization`. When you are ready to allow other people to run it, copy it into a different location.

Oracle recommends setting up one or more permanent, publicly available schemas in the Oracle LSH database for the purpose of compiling and storing programs that call Oracle LSH APIs. Grant each schema Execute privileges on `cdr_pub_api_initialization`. This approach has the following advantages:

- If a user manually runs your program, he or she must enter the program location and name explicitly. This will be much easier if the user knows which schema contains such programs.
- If you set up the program to run automatically when a user clicks a button in the external system's user interface, for example, you must hardcode the program's name and location into the code.
- You can grant Execute on `cdr_pub_api_initialization` to a controlled number of schemas.

1.3 Calling APIs from Defined Programs

If you develop and run a Program that calls an API within Oracle LSH—that is, in the defined Source Code of a defined Program object—no security is required beyond normal Oracle LSH object security. You do not need Execute privileges on the `cdr_pub_api_initialization` API, and you do not need to enable APIs in your Program code.

Note: Within Oracle LSH, the calls to `cdr_pub_api_initialization` are unnecessary and in fact a program that includes such a call will not compile because the Work Area schema does not have Execute privileges on `cdr_pub_api_initialization`.

You do need to install the Program before you can run it, as you do any defined Program in Oracle LSH.

You can write packages in an Oracle LSH Program that do anything with APIs that you could do in a package outside Oracle LSH. For example, you could create an instance of a Program definition whose Source Code created a Work Area, several Load Sets, and a Program to merge the data, instead of defining the Work Area, Load Sets and Program through the Oracle LSH user interface.

1.4 Code Example Using Security and Error Message APIs

There are two utility Oracle LSH APIs that you call in conjunction with other Oracle LSH APIs:

- **cdr_pub_api_initialization.** This API is required for developing and running programs that call any Oracle LSH API from outside Oracle LSH. See [Section 1.2.2, "Calling the Security API Package"](#) for further information.
- **cdr_pub_msg_pub.** This API returns error messages from other Oracle LSH APIs called in the same package.

The following code provides an example of calling the API to define a Work Area and each of the utility APIs.

Example 1–1 Program that Calls the API to Define a Work Area and Calls the Security and Error Message APIs

```
CDR_PUB_DF_WORKAREA.CREATEWORKAREA (
    P_API_VERSION=>1,
    P_INIT_MSG_LIST=>CDR_PUB_DEF_CONSTANTS.G_FALSE,
P_COMMIT=>CDR_PUB_DEF_CONSTANTS.G_FALSE,
    P_VALIDATION_LEVEL=>CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
X_RETURN_STATUS => X_RETURN_STATUS,
X_MSG_COUNT     => X_MSG_COUNT,
X_MSG_DATA      => X_MSG_DATA,
PIO_SOURCECDRNAMING =>VARWANSOBJ,
PIO_WORKAREAOBJTYPE =>VARWAOBJ,
PI_DEFCLASSIFICATIONCOLL => NULL);
    IF X_RETURN_STATUS <> 'S' THEN
        DBMS_OUTPUT.PUT_LINE('ERROR FOUND IN CREATEPROGRAM');
    END IF ;
    X_MSG_COUNT := CDR_PUB_MSG_PUB.COUNT_MSG (
        P_API_VERSION=>1,
        P_INIT_MSG_LIST=>CDR_PUB_
DEF_CONSTANTS.G_FALSE,
P_COMMIT=>CDR_PUB_DEF_CONSTANTS.G_FALSE,
        P_VALIDATION_LEVEL=>CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL
    );
    IF X_MSG_COUNT >= 1 THEN
        FOR I IN 1..X_MSG_COUNT LOOP
            IF I =1 THEN
                X_MSG_DATA := CDR_PUB_MSG_PUB.GET(
                    P_API_VERSION=>1,
                    P_INIT_MSG_LIST=>CDR_PUB_DEF_CONSTANTS.G_FALSE,
P_COMMIT=>CDR_PUB_DEF_CONSTANTS.G_FALSE,
                    P_VALIDATION_LEVEL=>CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
P_MSG_INDEX =>CDR_PUB_MSG_PUB.G_FIRST,
P_ENCODED =>CDR_PUB_DEF_CONSTANTS.G_FALSE);
                ELSIF I = X_MSG_COUNT THEN
                    X_MSG_DATA := CDR_PUB_MSG_PUB.GET(
                        P_API_VERSION=>1,
                        P_INIT_MSG_LIST=>CDR_PUB_DEF_CONSTANTS.G_FALSE,
P_COMMIT=>CDR_PUB_DEF_CONSTANTS.G_FALSE,
                        P_VALIDATION_LEVEL=>CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
```

```
P_MSG_INDEX =>CDR_PUB_MSG_PUB.G_LAST,
P_ENCODED =>CDR_PUB_DEF_CONSTANTS.G_FALSE);
    ELSE
        X_MSG_DATA := CDR_PUB_MSG_PUB.GET(
            P_API_VERSION=>1,
            P_INIT_MSG_LIST=>CDR_PUB_DEF_CONSTANTS.G_FALSE,
P_COMMIT=>CDR_PUB_DEF_CONSTANTS.G_FALSE,
            P_VALIDATION_LEVEL=>CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
P_MSG_INDEX =>CDR_PUB_MSG_PUB.G_NEXT,
P_ENCODED =>CDR_PUB_DEF_CONSTANTS.G_FALSE);
    END IF ;
    DBMS_OUTPUT.PUT_LINE('MESSAGE:' || I || ' : ' || X_MSG_DATA);
END LOOP;
END IF;
CDR_PUB_API_INITIALIZATION.DISABLEAPIS(
    P_API_VERSION=>1,
    P_INIT_MSG_LIST=>CDR_PUB_DEF_CONSTANTS.G_FALSE,
P_COMMIT=>CDR_PUB_DEF_CONSTANTS.G_FALSE,
    P_VALIDATION_LEVEL=>CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
X_RETURN_STATUS => X_RETURN_STATUS,
X_MSG_COUNT      => X_MSG_COUNT,
X_MSG_DATA       => X_MSG_DATA);
EXCEPTION
WHEN OTHERS THEN
    CDR_PUB_API_INITIALIZATION.DISABLEAPIS(
        P_API_VERSION=>1,
        P_INIT_MSG_LIST=>CDR_PUB_DEF_CONSTANTS.G_FALSE,
P_COMMIT=>CDR_PUB_DEF_CONSTANTS.G_FALSE,
        P_VALIDATION_LEVEL=>CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
X_RETURN_STATUS => X_RETURN_STATUS,
X_MSG_COUNT      => X_MSG_COUNT,
X_MSG_DATA       => X_MSG_DATA);
END MY_PROCEDURE;

BEGIN -- PACKAGE INIT BLOCK
CDR_PUB_API_INITIALIZATION.ENABLEAPIS(
    P_API_VERSION=>1,
    P_INIT_MSG_LIST=>CDR_PUB_DEF_CONSTANTS.G_FALSE,
P_COMMIT=>CDR_PUB_DEF_CONSTANTS.G_FALSE,
    P_VALIDATION_LEVEL=>CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
X_RETURN_STATUS => X_RETURN_STATUS,
X_MSG_COUNT      => X_MSG_COUNT,
X_MSG_DATA       => X_MSG_DATA);
END MY_PACKAGE;
```

Reference Information

This section contains the following topics:

- [Section 2.1, "CDR Naming Version Object Type"](#)
- [Section 2.2, "CDR Base Object Type"](#)
- [Section 2.3, "CDR Object-Specific Database Object Types"](#)
- [Section 2.4, "Retrieving Reference Codelist Names and Values"](#)
- [Section 2.5, "Retrieving the Instance Domain ID"](#)
- [Section 2.6, "Standard Parameters"](#)

2.1 CDR Naming Version Object Type

Object information is stored in two tables in the Oracle LSH database: `cdr_namings`, which contains one row for each defined Oracle LSH object, and `cdr_naming_versions`, which contains one row for each version of each defined Oracle LSH object. Information from these two tables is stored in two composite database object types: `cdr_naming_version_obj_type` and `cdr_base_obj_type`.

For both the composite object types, the attributes `company_id`, `obj_id`, `obj_ver`, `namespace_obj_id`, and `namespace_obj_ver` form a composite primary key. You can refer to any existing object using this primary key.

Parameters of type `cdr_naming_version_obj_type` are required in APIs for creating and modifying an object.

The attributes of `cdr_naming_version_obj_type` are:

- **company_id**. To get your company ID, use `CDR_PUB_DEF_FACTORY_UTILS.GetCompanyId`.
- **obj_id** is the unique ID of the object. Oracle LSH generates this ID when you create a new object.
- **obj_ver** is the object's version number.

Note: The attributes `company_id`, `obj_id`, `obj_ver`, `namespace_obj_id`, and `namespace_obj_ver` together constitute an object's primary key.

- **namespace_obj_id**. The unique ID of the object's parent object; for example, a Table instance is always contained in a Work Area, so its `namespace_obj_id` is the object ID of its Work Area.
- **namespace_obj_ver**. The version number of the object's parent object.

Note: You can create a child object only in the latest version of its parent object. If you pass a namespace version number that is not the latest when creating a child object, the system ignores the value you pass and creates the child in the latest version of the parent.

- **namespace_start_obj_ver.** This attribute contains the version number of the parent object at the time the version represented by **obj_ver** of the object represented by **obj_id** was created.
- **namespace_end_obj_ver.** This attribute contains the version number of the parent object at the time when the version represented by **obj_ver** of the object represented by **obj_id** was superseded by a higher version. If the object is still the most current version, then this attribute contains the value 999999.
- **object_type_rc** This attribute defines what type of object you are creating or modifying. This value is mandatory for creating objects, but not for modifying objects. See ["Retrieving Reference Codelist Names and Values"](#) on page 2-4 for information on retrieving valid values.
- **name.** This is the name of the object.
- **owning_location_rc.** This attribute is entered in the system at LSH installation time and is stored as a profile in the system. The system automatically sets this value to the profile value for all objects.
- **checked_out_flag_rc.** This value indicates whether the object is currently checked out or not. The possible values are \$YESNO\$YES and \$YESNO\$NO.
- **checked_out_id** is the user ID of the person who checked out the object, if it is currently checked out.
- **object_subtype_id.** This attribute specifies the ID of the object's subtype. Use CDR_PUB_DF_NAMING_UTIL.GetObjectSubtypeID to retrieve an object's subtype ID.
- **description.** This is an optional attribute but it is highly recommended that you provide a description for future reference. You can modify the description using appropriate API for the object.
- **ref_company_id.** If the object is an instance object, this attribute contains the company ID of the source definition.
- **ref_obj_id.** If the object is an instance object, this attribute contains the object ID of the source definition.
- **ref_obj_ver.** If the object is an instance object, this attribute contains the object version number of the source definition.
- **copied_from_company_id.** If the object is a copy of another object, this attribute contains the company ID of the original object.
- **copied_from_obj_id.** If the object is a copy of another object, this attribute contains the object ID of the original object.
- **copied_from_obj_ver.** If the object is a copy of another object, this attribute contains the object version number of the original object.
- **object_version_number.** This attribute is for Oracle LSH internal use only. Never enter a value for this attribute.

- **status_rc.** This attribute contains the current status of the object. See ["Retrieving Reference Codelist Names and Values"](#) on page 2-4 for information on retrieving valid values.
- **validation_status_rc.** This attribute contains the current validation status of the object. See ["Retrieving Reference Codelist Names and Values"](#) on page 2-4 for information on retrieving valid values.
- **version_label.** This attribute stores the version label of the object, if any.

2.2 CDR Base Object Type

For some operations on objects, only the identification contained in a CDR base object type (`cdr_base_obj_type`) is required. Some APIs allow you to operate on multiple objects at the same time by using a parameter based on a collection of CDR base object types called `cdr_base_obj_coll`.

A CDR Base Object Type contains a subset of the information contained in a CDR naming Version Object Type (see ["CDR Naming Version Object Type"](#) on page 2-1).

2.3 CDR Object-Specific Database Object Types

Each Oracle LSH object type has its own unique attributes beyond what is included in the CDR Naming Version Object Type and CDR Base Object Type. These unique attributes are included in a view for each object type. The view includes information on both definitions and instances of a particular object type. In the case of Tables, it includes Table Descriptors as well as Table definitions and instances.

APIs that are used to create or modify Oracle LSH defined objects contain parameters based on these supplementary database object types. You can set values for the object-specific attributes using these parameters.

For example, the supplementary database object type for Oracle LSH Programs is called `cdr_program_obj_type`. In the Create Program API, the parameter `pi_cdrprgobjtype` is of this type. Its attributes are:

- **company_id.** To get your company ID, use `CDR_PUB_DEF_FACTORY_UTILS.GetCompanyId`.
- **obj_id.** The unique ID of the Program.
- **obj_ver.** The Program's version number.
- **tech_type_id.** Different executable object types have different technology types, which can be queried using the view `cdr_tech_types_v`. Use the column `program_type_rc` to see which tech type is valid for a particular object type. In the case of Programs, only the tech types whose value in the `program_type_rc` column is `$PROGRAMTYPES$PROGRAM` and which are present in the lookup type `cdr_tech_types` are allowed. They are: `$TECHTYPES$SAS`, `$TECHTYPES$SASCATALOGS`, `$TECHTYPES$SASFORMATS`, `$TECHTYPES$PLSQL`, `$TECHTYPES$REPORTS`.

Note: Tech types that are not included in the lookup type `cdr_tech_types` are used internally only and should not be used with public APIs.

- **manual_validation_flag_rc.** This flag determines whether a Program's outputs receive their validation status from their Execution Setup or must be validated manually. The valid values are: `$YESNO$YES` and `$YESNO$NO`.

See the chapter on "Defining Programs" in the *Oracle Life Sciences Data Hub Application Developer's Guide* for information about these attributes. Each object type has its own chapter in this manual where its attributes are described.

2.4 Retrieving Reference Codelist Names and Values

Some database object type attributes (those ending in the string `_rc`) have a fixed set of allowed values stored in a lookup (reference codelist). These attributes correspond to fields in the user interface with a drop-down or pop-up list of values. To supply or change one of these values you must enter the exact string stored in the reference codelist, with the codelist name surrounded by dollar signs and followed by a codelist value.

For example, the API to create any object includes a parameter of type `cdr_naming_version_obj_type`, one of whose attributes is `object_type_rc`. You must enter the correct string for the type of object you want to create.

Reference codelists are stored in a table you access through the view `cdr_lookups`. The following columns contain the following information:

- **lookup_type:** reference codelist names
- **lookup_code:** reference codelist values
- **meaning:** the text that is displayed in the user interface
- **description:** additional information (sometimes)

If you have LSH Setup Admin privileges you can look up reference codelists in the Applications user interface; see "Querying and Viewing Lookups" in the *Oracle Life Sciences Data Hub System Administrator's Guide*.

You can browse the view in a tool like SQL Developer to find these values. However, it is not always easy to guess the name of the reference codelist. In that case, you can go into the Oracle LSH user interface to where they are displayed and note one of the allowed values, then query.

For example, object types are displayed in the Add drop-down list in the Work Area Properties screen. You can see that one object type is Business Area, so you can use the following query:

```
select lookup_type, lookup_code, meaning from cdr_lookups where
meaning like '%Business Area%';
```

Now you know that the `lookup_type` for object types is `CDR_OBJECT_TYPES` and you can use the following query to get all the other values:

```
select distinct lookup_code, meaning from cdr_lookups where
lookup_type = 'CDR_OBJECT_TYPES';
```

2.5 Retrieving the Instance Domain ID

While working with classification-related APIs, you may need the domain ID for the Oracle LSH environment you are working in. This is the ID for your Oracle LSH instance, which is created during installation. It has nothing to do with user-defined Domains that contain Application Areas.

Use the following query to find the domain ID of your Oracle LSH environment:

```
SELECT def_domain_id FROM tms.tms_def_domains WHERE name = 'cdr_
user_hier';
```

2.6 Standard Parameters

Some or all of the following standard Oracle Applications parameters are included in each function and procedure:

P_API_VERSION (Mandatory) Enter the current version of the API you are calling. <Add: "The version number is displayed at the top of this page." or whatever is true for where the user can see the version number.> The API compares the version numbers of incoming calls to its current version number and returns an error if they are incompatible.

P_INIT_MSG_LIST (Optional) Accept the default value (FND_API.G_FALSE) to ensure that this individual API does not initialize the message list upon completion. Pass FND_API.G_TRUE to override the default behavior.

P_COMMIT_LIST (Optional) Accept the default value (FND_API.G_FALSE) to ensure that this individual API does not commit upon completion. Pass FND_API.G_TRUE to override the default behavior.

P_VALIDATION_LEVEL (Optional) Accept the default value to perform full validation. No other values are currently supported.

X_RETURN_STATUS This output parameter returns the end status of the API: (S) Success, (E) Error or (U) Unexpected Error.

X_MSG_COUNT This output parameter returns the count of error messages if the return status is other than Success.

X_MSG_DATA This output parameter returns the text of the error message, if the message count is 1. If there are more than one messages, use `cdr_pub_msg_pub.get` to retrieve the messages.

Part II

Object APIs

This part of the Oracle Life Sciences Data Hub (Oracle LSH) API guide contains APIs that you can use to create, modify, check in or out, delete, copy, and move defined Oracle LSH objects. You can also perform object-specific tasks using these APIs.

Part II contains the following chapters:

- [Chapter 3, "Application Areas"](#)
- [Chapter 4, "Business Areas"](#)
- [Chapter 5, "Data Marts"](#)
- [Chapter 6, "Domains"](#)
- [Chapter 7, "Setup Utilities"](#)
- [Chapter 8, "Load Sets"](#)
- [Chapter 9, "Parameter Sets"](#)
- [Chapter 10, "Planned Outputs"](#)
- [Chapter 11, "Programs"](#)
- [Chapter 12, "Report Sets"](#)
- [Chapter 13, "Software Source Codes"](#)
- [Chapter 14, "Tables"](#)
- [Chapter 15, "Parameters"](#)
- [Chapter 16, "Variables"](#)
- [Chapter 17, "Work Areas"](#)
- [Chapter 18, "Workflows"](#)
- [Chapter 19, "Workflow Notifications"](#)

Application Areas

This is a public interface for Application Area-related operations— creating, modifying, and removing Application Areas; as well as copying and moving object definitions into an Application Area.

3.1 Define and Modify Application Areas

This section contains the following topics:

- [Section 3.1.1, "Create an Application Area"](#)
- [Section 3.1.2, "Modify an Application Area"](#)
- [Section 3.1.3, "Remove an Application Area"](#)
- [Section 3.1.4, "Copy Objects into an Application Area"](#)
- [Section 3.1.5, "Move Objects into an Application Area"](#)

3.1.1 Create an Application Area

Use this API to create a new Application Area.

Name CDR_PUB_DF_APPLICATIONAREA.CREATEAPPLICATIONAREA

Signature:

```
PROCEDURE CREATEAPPLICATIONAREA(
  P_API_VERSION IN NUMBER,
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
  X_RETURN_STATUS OUT VARCHAR2,
  X_MSG_COUNT OUT NUMBER,
  X_MSG_DATA OUT VARCHAR2,
  PIO_SOURCECDRNAMING IN OUT CDR_NAMING_VERSION_OBJ_TYPE,
  PI_DEFCLASSIFICATIONCOLL IN CDR_CLASSIFICATIONS_COLL
);
```

Parameters: This API has standard (see ["Standard Parameters"](#) on page 5) as well as the following parameters:

- **PIO_SOURCECDRNAMING** (Mandatory) This is a parameter of table type CDR_NAMING_VERSION_OBJ_TYPE that contains object attributes. Enter values for the Application Area you want to create.

The following attributes are required: company_id, namespace_obj_id, namespace_obj_ver, object_type_rc. for object_type_rc enter \$objtypes\$appliance.

- **PI_DEFCLASSIFICATIONCOLL**(Optional) By default the new Application Area is classified according to the subtype you assigned it in the CDR_NAMING_VERSION_OBJ_TYPE. If you want to override the default classifications for one or more classification levels, use this parameter. This is a collection of CDR_CLA_OBJ_TYPES, which have 5 attributes, including CLA_LEVEL_ID and CLASSIFICATION_ID. If you want the Application Area to inherit its classifications for a particular level from its parent Domain, enter the classification level ID and, for the CLASSIFICATION_ID, enter 0 (zero). If you want to explicitly assign one or more terms for a particular level, initialize a CDR_CLA_OBJ_TYPE for each term, entering the classification level ID and, for the CLASSIFICATION_ID, the term ID. The PAR_ attributes are not relevant to Application Areas. Do not enter any values for them.

3.1.2 Modify an Application Area

Use this API to modify the name or description of an existing Application Area.

Name CDR_PUB_DF_APPLICATIONAREA.MODIFYAPPLICATIONAREA

Signature

```
PROCEDURE MODIFYAPPLICATIONAREA (  
    P_API_VERSION IN NUMBER,  
    P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,  
    P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,  
    P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,  
    X_RETURN_STATUS OUT VARCHAR2,  
    X_MSG_COUNT OUT NUMBER,  
    X_MSG_DATA OUT VARCHAR2,  
    PIO_SOURCEDRNAMING IN OUT CDR_NAMING_VERSION_OBJ_TYPE  
);
```

Parameters This API has standard (see ["Standard Parameters"](#) on page 5) as well as the following:

PIO_SOURCEDRNAMING (Mandatory) This is a parameter of table type CDR_NAMING_VERSION_OBJ_TYPE that contains object attributes. Enter values to identify the Application Area you want to modify and for the attributes you want to modify. You can modify the name and description. All attributes are required.

3.1.3 Remove an Application Area

Use this API to remove one or more Application Areas and all its/their contents.

Name CDR_PUB_DF_APPLICATIONAREA.REMOVEAPPLICATIONAREAS

Signature

```
PROCEDURE REMOVEAPPLICATIONAREAS (  
    P_API_VERSION IN NUMBER,  
    P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,  
    P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,  
    P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,  
    X_RETURN_STATUS OUT VARCHAR2,  
    X_MSG_COUNT OUT NUMBER,  
    X_MSG_DATA OUT VARCHAR2,
```

```
PI_BASEOBJCOLL IN OUT CDR_BASE_OBJ_COLL
);
```

Parameters This API has standard (see ["Standard Parameters"](#) on page 5) as well as the following parameters:

PI_BASEOBJCOLL (Mandatory) This is a collection of CDR_BASE_OBJ_TYPEs. For each Application Area that you want to remove (including all its contents), initialize a CDR_BASE_OBJ_TYPE and then extend the collection.

The following attributes are required: COMPANY_ID, OBJ_ID, OBJ_VER, OBJECT_VERSION_NUMBER, NAMESPACE_OBJ_ID, NAMESPACE_OBJ_VER.

3.1.4 Copy Objects into an Application Area

Use this API to copy object definitions into an Application Area.

Name CDR_PUB_DF_APPLICATIONAREA.COPYOBJECTINTOAA

Signature

```
PROCEDURE COPYOBJECTINTOAA (
  P_API_VERSION IN NUMBER,
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
  X_RETURN_STATUS OUT VARCHAR2,
  X_MSG_COUNT OUT NUMBER,
  X_MSG_DATA OUT VARCHAR2,
  PI_CDRBASEOBJCOLL IN OUT CDR_BASE_OBJ_COLL,
  PI_CDRTARGETCONTAINEROBJECT IN OUT CDR_BASE_OBJ_TYPE,
  PI_CHECKINFLAG IN VARCHAR2
);
```

Parameters This API has standard (see ["Standard Parameters"](#) on page 5) as well as the following parameters:

- **PI_CDRBASEOBJCOLL** (Mandatory). This is a collection of CDR_BASE_OBJ_TYPEs. For each object that you want to copy into the Application Area, initialize a CDR_BASE_OBJ_TYPE and then extend the collection.

The following attributes are required: COMPANY_ID, OBJ_ID, OBJ_VER, OBJECT_VERSION_NUMBER, NAMESPACE_OBJ_ID, NAMESPACE_OBJ_VER.

- **PI_CDRTARGETCONTAINEROBJECT** (Mandatory). This is a parameter of table type CDR_BASE_OBJ_TYPE that contains object attributes. Enter values to identify the Application Area into which you want to copy objects.

The following attributes are required: COMPANY_ID, OBJECT_ID, OBJECT_VER, NAMESPACE_OBJ_ID, NAMESPACE_OBJ_VER, OBJECT_VERSION_NUMBER.

- **PI_CHECKINFLAG** (Mandatory). Enter \$YESNO\$NO if you want any checked-out copied objects to remain checked out, or \$YESNO\$YES if you want the system to check them in after the copy operation.

3.1.5 Move Objects into an Application Area

Use this API to move LSH objects into an Application Area.

Name CDR_PUB_DF_APPLICATIONAREA.MOVEOBJECTINTOAA

Signature

```
PROCEDURE MOVEOBJECTINTOAA(  
  P_API_VERSION IN NUMBER,  
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,  
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,  
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,  
  X_RETURN_STATUS OUT VARCHAR2,  
  X_MSG_COUNT OUT NUMBER,  
  X_MSG_DATA OUT VARCHAR2,  
  PI_CDRBASEOBJCOLL IN OUT CDR_BASE_OBJ_COLL,  
  PI_CDRTARGETCONTAINEROBJECT IN OUT CDR_BASE_OBJ_TYPE  
);
```

Parameters This API has standard (see ["Standard Parameters"](#) on page 5) as well as the following parameters:

- **PI_CDRBASEOBJCOLL** (Mandatory) This is a collection of CDR_BASE_OBJ_TYPES. For each object that you want to move into the Application Area, initialize a CDR_BASE_OBJ_TYPE and then extend the collection.

The following attributes are required: COMPANY_ID, OBJ_ID, OBJ_VER, OBJECT_VERSION_NUMBER, NAMESPACE_OBJ_ID, NAMESPACE_OBJ_VER.

- **PI_CDRTARGETCONTAINEROBJECT** (Mandatory) This is a parameter of table type CDR_BASE_OBJ_TYPE that contains object attributes. Enter values to identify the Application Area into which you want to move objects.

The following attributes are required: COMPANY_ID, OBJ_ID, OBJ_VER, OBJECT_VERSION_NUMBER, NAMESPACE_OBJ_ID, NAMESPACE_OBJ_VER.

Business Areas

This section contains the following topics:

- [Section 4.1, "Define and Modify Business Areas"](#)
- [Section 4.2, "Create and Modify Business Area Hierarchies"](#)
- [Section 4.3, "Create and Modify Business Area Joins"](#)
- [Section 4.4, "Public APIs and Naming Views for Generic Visualization Adapter \(GVA\)"](#)

4.1 Define and Modify Business Areas

This is a public interface for Business Area-related APIs, including creating, modifying, and removing Business Areas. It also includes APIs for checking Business Areas in and out, and undoing a Business Area checkout.

This section contains the following topics:

- [Section 4.1.1, "Create a Business Area"](#)
- [Section 4.1.2, "Modify a Business Area"](#)
- [Section 4.1.3, "Check out a Business Area"](#)
- [Section 4.1.4, "Undo a Business Area Checkout"](#)
- [Section 4.1.5, "Check in a Business Area"](#)
- [Section 4.1.6, "Remove a Business Area"](#)

4.1.1 Create a Business Area

Use this API to create a new Business definition, a new instance of an existing Business Area definition, or a new definition and an instance of it.

Name CDR_PUB_DF_BUSINESSAREA.CREATEBUSIAREA

Signature

```
PROCEDURE CREATEBUSIAREA(
    P_API_VERSION IN NUMBER,
    P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
    P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
    P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
    X_RETURN_STATUS OUT VARCHAR2,
    X_MSG_COUNT OUT NUMBER,
    X_MSG_DATA OUT VARCHAR2,
```

```
PIO_SOURCECDRNAMING IN OUT CDR_NAMING_VERSION_OBJ_TYPE,  
PI_CDRPRGOBJTYPE IN CDR_BUSAREA_OBJ_TYPE,  
PI_CREATEOBJECT IN VARCHAR2,  
PI_INSTANCE_SUBTYPE_ID IN CDR_NAMINGS.OBJECT_SUBTYPE_ID%TYPE,  
PI_DEFCLASSIFICATIONCOLL IN CDR_CLASSIFICATIONS_COLL,  
PI_INSTCLASSIFICATIONCOLL IN CDR_CLASSIFICATIONS_COLL  
);
```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

- **PIO_SOURCECDRNAMING** (Mandatory) This is a parameter of table type CDR_NAMING_VERSIONS_OBJ_TYPE that contains CDR Naming Version attributes.

If you are creating a new definition only or a new definition and an instance of it, enter values for the new definition.

If you are creating an instance of an existing definition, enter values to identify the definition. For OBJECT_TYPE_RC enter \$OBJTYPES\$BUSAREA if you are creating a definition only; \$OBJTYPES\$BUSAREAREF if you are creating an instance of an existing definition; and NULL if you are creating a new definition and an instance of it.
- **PI_CDRPRGOBJTYPE** (Optional) This is a parameter of table type CDR_BUSAREA_OBJ_TYPE that contains object attributes specific to Business Areas.

If you are creating a new definition, enter values for the new Business Area.

The following attributes are required: ADAPTER_COMPANY_ID, ADAPTER_OBJ_ID, ADAPTER_OBJ_VER.

If you are creating an instance of an existing Business Area, do not enter any values here.
- **PI_CREATEOBJECT** (Mandatory) Enter DEFN to create a definition only; INST to create a instance of an existing definition; or BOTH to create a new definition and an instance of it.
- **PI_INSTANCE_SUBTYPE_ID** (Optional) If you are creating a new instance, enter the ID for the subtype you want to give the instance.

If you are creating a definition only, do not enter a value for this parameter.
- **PI_DEFCLASSIFICATIONCOLL** (Optional) By default, the new definition is classified according to the subtype you assigned it in the CDR_NAMING_VERSION_OBJ_TYPE.

If you want to override the default classifications for one or more classification levels, use this parameter. This is a collection of CDR_CLA_OBJ_TYPES, which have 5 attributes, including CLA_LEVEL_ID and CLASSIFICATION_ID.

If you want the definition to inherit its classifications for a particular level from its parent, enter the classification level ID and, for the CLASSIFICATION_ID, enter 0 (zero).

If you want to explicitly assign one or more terms for a particular level, initialize a CDR_CLA_OBJ_TYPE for each term, entering the classification level ID and, for the CLASSIFICATION_ID, the term ID. The PAR_ attributes are not relevant to Business Areas. Do not enter any values for them.

- **PI_INSTCLASSIFICATIONCOLL** (Optional) By default, the new instance is classified according to the subtype you assigned it in the PI_INSTANCE_SUBTYPE_ID.

If you want to override the default classifications for one or more classification levels, use this parameter. This is a collection of CDR_CLA_OBJ_TYPES, which have 5 attributes, including CLA_LEVEL_ID and CLASSIFICATION_ID.

If you want the instance to inherit its classifications for a particular level from its parent Work Area, enter the classification level ID and, for the CLASSIFICATION_ID, enter 0 (zero).

If you want to explicitly assign one or more terms for a particular level, initialize a CDR_CLA_OBJ_TYPE for each term, entering the classification level ID and, for the CLASSIFICATION_ID, the term ID. The PAR_ attributes are not relevant to Business Areas. Do not enter any values for them.

4.1.2 Modify a Business Area

Use this API to modify a Business Area definition or instance.

Note: If you are modifying a definition, you must first check it out.

Name CDR_PUB_DF_BUSINESSAREA.MODIFYBUSIAREADETAILS

Signature

```
PROCEDURE MODIFYBUSIAREADETAILS(
  P_API_VERSION IN NUMBER,
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
  X_RETURN_STATUS OUT VARCHAR2,
  X_MSG_COUNT OUT NUMBER,
  X_MSG_DATA OUT VARCHAR2,
  PIO_CDRNAMING IN OUT CDR_NAMING_VERSION_OBJ_TYPE
);
```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameter:

PIO_CDRNAMING (Mandatory) This is a parameter of table type CDR_NAMING_VERSION_OBJ_TYPE that contains object attributes. Enter values to identify the Business Area and enter new values for the attributes you want to modify.

You can change the name, description, or version label for either a definition or instance. For an instance, you can also change to a different underlying source definition by entering values for the new definition in the three REF attributes. All attributes are required.

4.1.3 Check out a Business Area

Use this API to check out a Business Area definition either directly or through an instance of it.

Name CDR_PUB_DF_BUSINESSAREA.CHECKOUTBUSIAREA

Signature

```
PROCEDURE CHECKOUTBUSIAREA(  
  P_API_VERSION IN NUMBER,  
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,  
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,  
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,  
  X_RETURN_STATUS OUT VARCHAR2,  
  X_MSG_COUNT OUT NUMBER,  
  X_MSG_DATA OUT VARCHAR2,  
  PIO_BASEOBJECT IN OUT CDR_BASE_OBJ_TYPE,  
  PI_COMMENT IN VARCHAR2,  
  PI_ISINSTONLY IN VARCHAR2  
);
```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

- **PIO_BASEOBJECT** (Mandatory) This is a parameter of table type CDR_BASE_OBJ_TYPE that contains object attributes. Enter values to identify the Business Area that you want to do check out.

If you are checking out the Business Area definition directly, enter values to identify the definition.

If you are checking out a Business Area definition through an instance of it, enter values to identify the instance.

The following attributes are required: COMPANY_ID,OBJ_ID,OBJ_VER,OBJECT_VERSION_NUMBER,NAMESPACE_OBJ_ID,NAMESPACE_OBJ_VER.

- **PI_COMMENT** Enter the reason you are checking out the Business Area.
- **PI_ISINSTONLY** (Mandatory) Enter \$YESNO\$NO.

4.1.4 Undo a Business Area Checkout

Use this API to undo the checkout of a Business Area definition, discarding any changes that have been made.

Name CDR_PUB_DF_BUSINESSAREA.UNCHECKOUTBUSIAREA

Signature

```
PROCEDURE UNCHECKOUTBUSIAREA(  
  P_API_VERSION IN NUMBER,  
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,  
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,  
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,  
  X_RETURN_STATUS OUT VARCHAR2,  
  X_MSG_COUNT OUT NUMBER,  
  X_MSG_DATA OUT VARCHAR2,  
  PIO_BASEOBJECT IN OUT CDR_BASE_OBJ_TYPE  
);
```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

PIO_BASEOBJECT (Mandatory) This is a parameter of table type CDR_BASE_OBJ_TYPE that contains object attributes. Enter values to identify the Business Area whose checkout you want to undo.

The following attributes are required: COMPANY_ID,OBJ_ID,OBJ_VER,OBJECT_VERSION_NUMBER,NAMESPACE_OBJ_ID,NAMESPACE_OBJ_VER.

4.1.5 Check in a Business Area

Use this API to check in a Business Area definition.

Name CDR_PUB_DF_BUSINESSAREA.CHECKINBUSIAREADEFINITION

Signature

```
PROCEDURE CHECKINBUSIAREADEFINITION(
  P_API_VERSION IN NUMBER,
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
  X_RETURN_STATUS OUT VARCHAR2,
  X_MSG_COUNT OUT NUMBER,
  X_MSG_DATA OUT VARCHAR2,
  PIO_BASEOBJECT IN OUT CDR_BASE_OBJ_TYPE,
  PI_COMMENT IN VARCHAR2
);
```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

- **PIO_BASEOBJECT** (Mandatory) This is a parameter of table type CDR_BASE_OBJ_TYPE that contains object attributes. Enter values to identify the Business Area that you want to check in.

The following attributes are required: COMPANY_ID,OBJ_ID,OBJ_VER,OBJECT_VERSION_NUMBER,NAMESPACE_OBJ_ID,NAMESPACE_OBJ_VER.

- **PI_COMMENT** (Optional) Enter the reason you are checking in the Business Area.

4.1.6 Remove a Business Area

Use this API to remove one or more Business Area definitions or instances.

Name CDR_PUB_DF_BUSINESSAREA.REMOVEBUSIAREA

Signature

```
PROCEDURE REMOVEBUSIAREA(
  P_API_VERSION IN NUMBER,
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
  X_RETURN_STATUS OUT VARCHAR2,
  X_MSG_COUNT OUT NUMBER,
  X_MSG_DATA OUT VARCHAR2,
  PIO_CDRBASEOBJCOLL IN OUT CDR_BASE_OBJ_COLL
);
```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameter:

- **PIO_CDRBASEOBJCOLL** (Mandatory) This is a collection of CDR_BASE_OBJ_TYPES.

For each Business Area that you want to remove, initialize a CDR_BASE_OBJ_TYPE and then extend the collection.

The following attributes are required: COMPANY_ID,OBJ_ID,OBJ_VER,OBJECT_VERSION_NUMBER,NAMESPACE_OBJ_ID,NAMESPACE_OBJ_VER.

4.2 Create and Modify Business Area Hierarchies

This is a public interface for all Business Area hierarchy-related operations, including creating, modifying, and removing Business Area hierarchies and hierarchy columns.

This section contains the following topics:

- [Section 4.2.1, "Create a Business Area Hierarchy"](#)
- [Section 4.2.2, "Modify a Hierarchy and a Hierarchy Column"](#)
- [Section 4.2.3, "Reorder a Hierarchy Column"](#)
- [Section 4.2.4, "Remove a Hierarchy Column"](#)
- [Section 4.2.5, "Remove a Business Area Hierarchy"](#)

4.2.1 Create a Business Area Hierarchy

Use this API to create a hierarchy in a Business Area. To define the hierarchy's columns, use ModifyBusAreaHierAndHierCol.

Name CDR_PUB_DF_BUSINESSAREA_HIER.CREATEBUSINESSAREAHIER

Signature

```
PROCEDURE CREATEBUSINESSAREAHIER (  
    P_API_VERSION IN NUMBER,  
    P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,  
    P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,  
    P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,  
    X_RETURN_STATUS OUT VARCHAR2,  
    X_MSG_COUNT OUT NUMBER,  
    X_MSG_DATA OUT VARCHAR2,  
    PIO_SOURCECDRNAMING IN OUT CDR_NAMING_VERSION_OBJ_TYPE  
);
```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

PIO_SOURCECDRNAMING (Mandatory) This is a parameter of table type CDR_NAMING_VERSION_OBJ_TYPE that contains object attributes.

Enter values for the new hierarchy. Use the NAMESPACE attributes to identify the Business Area in which you want to create the hierarchy.

The following attributes are required: OBJECT_TYPE_RC,NAME,NAMESPACE_OBJ_ID,NAMESPACE_OBJ_VER,OBJECT_SUBTYPE_ID. For OBJECT_TYPE_RC enter \$OBJTYPES\$BUSAREAHIER.

4.2.2 Modify a Hierarchy and a Hierarchy Column

Use this API to modify Business Area Hierarchies and Hierarchy Columns. You can change name and description, add Columns, and change their Group With Previous setting. Use the Remove Columns API to remove Columns.

Name CDR_PUB_DF_BUSINESSAREA_HIER.MODIFYBUSAREAHIERANDHIERCOL

Signature

```
PROCEDURE MODIFYBUSAREAHIERANDHIERCOL (
  P_API_VERSION IN NUMBER,
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
  X_RETURN_STATUS OUT VARCHAR2,
  X_MSG_COUNT OUT NUMBER,
  X_MSG_DATA OUT VARCHAR2,
  PIO_NAMING IN OUT CDR_NAMING_VERSION_OBJ_TYPE,
  PI_BUS_HIERCOLUMNS_COLL IN OUT CDR_BUSAREA_HIER_COLS_COLL
);
```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

- **PIO_NAMING** (Mandatory) This is a parameter of table type CDR_NAMING_VERSION_OBJ_TYPE that contains object attributes.
Enter values to identify the Business Area Hierarchy that you want to modify and enter new values for the attributes you want to modify. You can modify only the Name and Description. All attributes are required.
- **PI_BUS_HIERCOLUMNS_COLL** (Mandatory) This is a collection of CDR_BUSAREA_HIER_COLS_OBJ_TYPES.
Initialize a CDR_BUSAREA_HIER_COLS_OBJ_TYPE for each Column in their position order with the values you want to change, and then extend the collection. All attributes are required.

4.2.3 Reorder a Hierarchy Column

Use this API to reorder the Columns of a Business Area Hierarchy.

Note: The API enforces validation rules for Column sequence.

Name CDR_PUB_DF_BUSINESSAREA_HIER.REORDERHIERCOLS

Signature

```
PROCEDURE REORDERHIERCOLS (
  P_API_VERSION IN NUMBER,
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
  X_RETURN_STATUS OUT VARCHAR2,
  X_MSG_COUNT OUT NUMBER,
  X_MSG_DATA OUT VARCHAR2,
  PIO_BUS_HIERCOLUMNS_COLL IN OUT CDR_BUSAREA_HIER_COLS_COLL
);
```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

- **PIO_BUS_HIERCOLUMNS_COLL** (Mandatory) This is a collection of CDR_BUSAREA_HIER_COLS_OBJ_TYPES. For each Column, initialize a CDR_BUSAREA_HIER_COLS_OBJ_TYPE, providing the new value for POSITION NUMBER relative to

the other Columns, and then extend the collection. You must initialize all existing Columns.

The following attributes are required: COMPANY_ID,HIER_OBJ_ID,HIER_OBJ_VER,TD_COMPANY_ID,TD_OBJ_ID,TD_COL_COMPANY_ID,TD_COL_OBJ_ID,POSITION,GROUP_WITH_PREVIOUS_RC.

4.2.4 Remove a Hierarchy Column

Use this API to remove Business Area Hierarchy Columns.

Note: You cannot remove a Column that is currently part of a Join. If you remove a Column, and if the next Column's Group By Previous setting is Yes, then that setting is changed to No.

Name CDR_PUB_DF_BUSINESSAREA_HIER.REMOVEHIERCOLUMNS

Signature

```
PROCEDURE REMOVEHIERCOLUMNS(  
    P_API_VERSION IN NUMBER,  
    P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,  
    P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,  
    P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,  
    X_RETURN_STATUS OUT VARCHAR2,  
    X_MSG_COUNT OUT NUMBER,  
    X_MSG_DATA OUT VARCHAR2,  
    PIO_BUS_HIERCOLUMNS_COLL IN OUT CDR_BUSAREA_HIER_COLS_COLL  
);
```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameter:

PIO_BUS_HIERCOLUMNS_COLL (Mandatory) This is a collection of CDR_BUSAREA_HIER_COLS_OBJ_TYPES. For each Column that you want to remove, initialize a CDR_BUSAREA_HIER_COLS_OBJ_TYPE and then extend the collection.

The following attributes are required: COMPANY_ID,HIER_OBJ_ID,HIER_OBJ_VER,TD_COMPANY_ID,TD_OBJ_ID,TD_COL_COMPANY_ID,TD_COL_OBJ_ID,POSITION,GROUP_WITH_PREVIOUS_RC.

4.2.5 Remove a Business Area Hierarchy

Use this API to remove one or more Business Area Hierarchies, including all their Columns.

Name CDR_PUB_DF_BUSINESSAREA_HIER.REMOVEHIERS

Signature

```
PROCEDURE REMOVEHIERS(  
    P_API_VERSION IN NUMBER,  
    P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,  
    P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,  
    P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,  
    X_RETURN_STATUS OUT VARCHAR2,  
    X_MSG_COUNT OUT NUMBER,  
    X_MSG_DATA OUT VARCHAR2,
```

```
PI_BASEOBJCOLL IN OUT CDR_BASE_OBJ_COLL
);
```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameter:

PI_BASEOBJCOLL (Mandatory) This is a collection of CDR_BASE_OBJ_TYPEs. For each Hierarchy that you want to remove, initialize a CDR_BASE_OBJ_TYPE and then extend the collection.

The following attributes are required: COMPANY_ID,OBJ_ID,OBJ_VER,OBJECT_VERSION_NUMBER,NAMESPACE_OBJ_ID,NAMESPACE_OBJ_VER.

4.3 Create and Modify Business Area Joins

This is a public interface for Business Area Join-related operations, including creating, modifying, and removing Business Area Joins and Join Columns.

This section contains the following topics:

- [Section 4.3.1, "Create a Join"](#)
- [Section 4.3.2, "Modify a Join and a Join Column"](#)
- [Section 4.3.3, "Remove a Join Column"](#)
- [Section 4.3.4, "Remove a Join"](#)

4.3.1 Create a Join

Use this API to create a Business Area Join.

Name CDR_PUB_DF_BUSINESSAREA_JOIN.CREATEBUSINESSAREAJOIN

Signature

```
PROCEDURE CREATEBUSINESSAREAJOIN(
  P_API_VERSION IN NUMBER,
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
  X_RETURN_STATUS OUT VARCHAR2,
  X_MSG_COUNT OUT NUMBER,
  X_MSG_DATA OUT VARCHAR2,
  PIO_SOURCECDRNAMING IN OUT CDR_NAMING_VERSION_OBJ_TYPE,
  PI_BUSAREAJOINSOBJTYPE IN CDR_BUSAREA_JOINS_OBJ_TYPE
);
```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

- **PIO_SOURCECDRNAMING** (Mandatory) This is a parameter of table type CDR_NAMING_VERSION_OBJ_TYPE that contains object attributes. Enter values for the Join that you want to create. Use the NAMESPACE attributes to identify the Business Area in which you want to create the Join.

The following attributes are required: OBJECT_TYPE_RC,NAME,NAMESPACE_OBJ_ID,NAMESPACE_OBJ_VER,OBJECT_SUBTYPE_ID. For OBJECT_TYPE_RC enter \$OBJTYPES\$JOIN.

- **PI_BUSAREAJOINSOBJTYPE** (Mandatory) This is a parameter of table type CDR_BUSAREA_JOINS_OBJ_TYPE that contains object attributes specific to Joins. Enter values for the Join that you want to create.

The following attributes are required: TD_COMPANY_ID,TD_OBJ_ID,FK_TD_COMPANY_ID,FK_TD_OBJ_ID,TD_OUTERJOIN_RC,FK_TD_OUTERJOIN_RC. For TD_OUTERJOIN_RC and FK_TD_OUTERJOIN_RC enter \$YESNO\$NO to define an inner join on the side of the corresponding Table Descriptor, or \$YESNO\$YES to define an outer join. Be sure to define an outer join on only one side, if any.

4.3.2 Modify a Join and a Join Column

Use this API to modify Business Area Joins and Join Columns. You can change the name and description of the Join and change either side to an inner or outer join (but be careful not to make both sides into outer joins). You can add Join Columns and pair them with a different Column from the other Table Descriptor.

Note: Do not change the operator. EQUAL TO is the only operator currently supported.

Name CDR_PUB_DF_BUSINESSAREA_JOIN.MODIFYBUSAREAJOINANDJOINCOL

Signature

```
PROCEDURE MODIFYBUSAREAJOINANDJOINCOL (
  P_API_VERSION IN NUMBER,
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
  X_RETURN_STATUS OUT VARCHAR2,
  X_MSG_COUNT OUT NUMBER,
  X_MSG_DATA OUT VARCHAR2,
  PIO_NAMING IN OUT CDR_NAMING_VERSION_OBJ_TYPE,
  PI_BUSINESS_JOIN IN OUT CDR_BUSAREA_JOINS_OBJ_TYPE,
  PI_BUS_JOINCOLUMNS_COLL IN OUT CDR_BUSAREA_JOIN_COLS_COLL
);
```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

- **PIO_NAMING** (Mandatory) This is a parameter of table type CDR_NAMING_VERSION_OBJ_TYPE that contains object attributes. Enter values to identify the Join that you want to modify and for the attributes you want to change.
The following attributes are required: COMPANY_ID,OBJ_ID,OBJ_VER,OBJECT_VERSION_NUMBER,NAMESPACE_OBJ_ID,NAMESPACE_OBJ_VER.
- **PI_BUSINESS_JOIN** (Mandatory) This is a parameter of table type CDR_BUSAREA_JOINS_OBJ_TYPE that contains object attributes specific to Joins. Enter values to identify the Join that you want to modify and the values you want to modify. All attributes are required.
- **PI_BUS_JOINCOLUMNS_COLL** (Mandatory) This is a collection of CDR_BUSAREA_JOIN_COLS_TYPES. For each Join Column that you want to modify, initialize a CDR_BUSAREA_JOIN_COLS_TYPE and then extend the collection.

The following attributes are required: COMPANY_ID,JOIN_OBJ_ID,JOIN_OBJ_VER,TD_COL_COMPANY_ID,TD_COL_OBJ_ID,FK_TD_COL_COMPANY_ID,FK_TD_COL_OBJ_ID,POSITION. You can change the joined columns but you cannot modify the operator, which is always Equal To.

4.3.3 Remove a Join Column

Use this API to remove one or more Columns from a Join.

Name CDR_PUB_DF_BUSINESSAREA_JOIN.REMOVEJOINCOLUMNS

Signature

```
PROCEDURE REMOVEJOINCOLUMNS (
  P_API_VERSION IN NUMBER,
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
  X_RETURN_STATUS OUT VARCHAR2,
  X_MSG_COUNT OUT NUMBER,
  X_MSG_DATA OUT VARCHAR2,
  PIO_BUS_JOIN_COLUMNS_COLL IN OUT CDR_BUSAREA_JOIN_COLS_COLL
);
```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameter:

PIO_BUS_JOIN_COLUMNS_COLL (Mandatory) This is a collection of CDR_BUSAREA_JOIN_COLS_TYPES. For each Join Column that you want to remove, initialize a CDR_BUSAREA_JOIN_COLS_TYPE and then extend the collection.

The following attributes are required: COMPANY_ID,JOIN_OBJ_ID,JOIN_OBJ_VER,TD_COL_COMPANY_ID,TD_COL_OBJ_ID,FK_TD_COL_COMPANY_ID,FK_TD_COL_OBJ_ID,POSITION.

4.3.4 Remove a Join

Use this API to remove one or more Joins, with all their Columns, from a Business Area.

Name CDR_PUB_DF_BUSINESSAREA_JOIN.REMOVEJOINS

Signature

```
PROCEDURE REMOVEJOINS (
  P_API_VERSION IN NUMBER,
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
  X_RETURN_STATUS OUT VARCHAR2,
  X_MSG_COUNT OUT NUMBER,
  X_MSG_DATA OUT VARCHAR2,
  PI_BASEOBJCOLL IN OUT CDR_BASE_OBJ_COLL
);
```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameter:

PI_BASEOBJCOLL (Mandatory) This is a collection of CDR_BASE_OBJ_TYPES.

For each Join that you want to remove from the Business Area, initialize a CDR_BASE_OBJ_TYPE and then extend the collection.

The following attributes are required: COMPANY_ID,OBJ_ID,OBJ_VER,OBJECT_VERSION_NUMBER,NAMESPACE_OBJ_ID,NAMESPACE_OBJ_VER.

4.4 Public APIs and Naming Views for Generic Visualization Adapter (GVA)

This is a public interface for operations related to Generic Visualization Business Areas including initializing and resetting them.

This section contains the following topics:

- [Section 4.4.1, "Initialize a Generic Visualization Business Area Instance"](#)
- [Section 4.4.2, "Reset a Generic Visualization Business Area"](#)
- [Section 4.4.3, "Get Possible Blinding Types of a Business Area Instance"](#)
- [Section 4.4.4, "Get Snapshot Labels Common to all Tables in a BA Instance for a Given Blinding AccessType"](#)
- [Section 4.4.5, "Naming Views"](#)

4.4.1 Initialize a Generic Visualization Business Area Instance

Use this API to initialize a particular Generic Visualization Business Area Instance of a given currency and blinding access type. If the currency and the blinding access type values are null, the default types of the BA instance are used.

You can invoke this API multiple times in the same instance in a single user session to change the type of access to the data. You can also invoke it multiple times to read data from more than one Business Area Schema as long as all the data across all the Business Areas is uniformly either real or dummy.

If you initialize a new Business Area schema changes blinding access, the API errors out, directing you to reset access to all Business Areas using the RESETBAACCESS API.

Name CDR_PUB_API_GVA.SETINITIALIZEBA

Signature

```
PROCEDURE SETINITILIZEBA(  
  PI_COMPANYID IN CDR_NAMINGS.COMPANY_ID%TYPE,  
  PI_OBJID      IN CDR_NAMINGS.OBJ_ID%TYPE,  
  PI_OBJVER     IN CDR_NAMING_VERSIONS.OBJ_VER%TYPE,  
  PI_VCURRENCY  IN VARCHAR2,  
  PI_VBLINDINGACCESSTYPEIN VARCHAR2,  
  X_RETURN_STATUS OUT NOCOPY VARCHAR2,  
  X_MSG_COUNT     OUT NOCOPY NUMBER,  
  X_MSG_DATA      OUT NOCOPY VARCHAR2
```

Parameters This API has the following parameters:

PI_COMPANYID. Enter the Business Area Instance Company ID.

PI_OBJID. Enter the Business Area Instance Object ID.

PI_OBJVER. Enter the Business Area Instance Company ID.

PI_VCURRENCY. Enter the Currency status.

PI_VBLINDINGACCESSTYPE. Enter the Blinding Access Type.

X_RETURN_STATUS.

X_MSG_COUNT.

X_MSG_DATA.

4.4.2 Reset a Generic Visualization Business Area

Use this API to clear all the initializations of Business Area schemas. It is equivalent to logging out and logging back in to the system. Use this API when you want to change blinding access type from blinded to unblinded or vice-versa.

Name CDR_PUB_API_GVA.RESETBAACCESS

4.4.3 Get Possible Blinding Types of a Business Area Instance

Use this API to get the possible Blinding Access Types of a Business Area Instance, which is in turn based on the blinding statuses of underlying Business Area Table instances and the user's privileges.

Name CDR_PUB_API_GVA.GETBAVALIDBLINDINGACCESSTYPES

Signature

```
FUNCTION GETBAVALIDBLINDINGACCESSTYPES(
PI_COMPANYID IN CDR_NAMINGS.COMPANY_ID%TYPE,
PI_OBJID      IN CDR_NAMINGS.OBJ_ID%TYPE,
PI_OBJVER     IN CDR_NAMING_VERSIONS.OBJ_VER%TYPE) RETURN BLINDINGACCESSTYPESCOLL
PIPELINED;
```

Return A collection of the possible blinding access types.
BLINDINGACCESSTYPESCOLL is TABLE TYPE OF VARCHAR2(30);

Parameters This API has the following parameters:

PI_COMPANYID. Enter the Business Area Instance Company ID.

PI_OBJID. Enter the Business Area Instance Object ID.

PI_OBJVER. Enter the Business Area Instance Company ID.

BLINDINGACCESSTYPESCOLL. This is the list of possible blinding access types.

4.4.4 Get Snapshot Labels Common to all Tables in a BA Instance for a Given Blinding AccessType

Use this API to get the snapshot labels common to all Tables within a Business Area Instance for a given blinding access type.

Name CDR_PUB_API_GVA.GETSNAPSHOTLABELS

Signature

```
FUNCTION GETSNAPSHOTLABELS(
PI_COMPANYID IN CDR_NAMINGS.COMPANY_ID%TYPE,
PI_OBJID      IN CDR_NAMINGS.OBJ_ID%TYPE,
PI_OBJVER     IN CDR_NAMING_VERSIONS.OBJ_VER%TYPE,
```

```
PI_VBLINDINGACCESSTYPE IN VARCHAR2) RETURN CURRENCYCOLL PIPELINED;
```

Return A collection of the snapshot labels for a particular blinding access type in the Business Area instance common to all Tables within a Business Area Instance.
CURRENCYCOLL is TABLE TYPE OF VARCHAR2(200);

Parameters This API has the following parameters.

PI_COMPANYID. Enter the Business Area Instance Company ID.

PI_OBJID. Enter the Business Area Instance Object ID.

PI_OBJVER. Enter the Business Area Instance Company ID.

PI_VBLINDINGACCESSTYPE . Enter the Blinding Access Type.

4.4.5 Naming Views

CDR_PUB_GENERIC_BA_V

Use this naming view to retrieve all the Generic Visualization Business Area Instances on which a user has privileges to read data.

CDR_PUB_GENERIC_BA_TABLES_V Use this view to retrieve the Table instance details for a given GV BAI.

This is a public interface for creating, modifying, and removing Data Marts.

5.1 Define and Modify Work Areas

This section contains the following topics:

- [Section 5.1.1, "Create a Data Mart"](#)
- [Section 5.1.2, "Check In a DataMart Definition"](#)
- [Section 5.1.3, "Modify a Data Mart"](#)
- [Section 5.1.4, "Check Out a Data Mart"](#)
- [Section 5.1.5, "Remove a Data Mart"](#)

5.1.1 Create a Data Mart

Use this API to create a new Data Mart definition, a new instance of an existing Data Mart definition, or a new definition and an instance of it.

Name CDR_PUB_DF_DATAMART.CREATEDATAMART

Signature

```
PROCEDURE CREATEDATAMART(
  P_API_VERSION IN NUMBER,
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
  X_RETURN_STATUS OUT VARCHAR2,
  X_MSG_COUNT OUT NUMBER,
  X_MSG_DATA OUT VARCHAR2,
  PIO_SOURCECDRNAMING IN OUT CDR_NAMING_VERSION_OBJ_TYPE,
  PI_CDRDATAMARTOBJTYPE IN CDR_DATA_MART_OBJ_TYPE,
  PI_CREATEOBJECT IN VARCHAR2,
  PI_INSTANCE_SUBTYPE_ID IN CDR_NAMINGS.OBJECT_SUBTYPE_ID%TYPE,
  PI_DEFCLASSIFICATIONCOLL IN CDR_CLASSIFICATIONS_COLL,
  PI_INSTCLASSIFICATIONCOLL IN CDR_CLASSIFICATIONS_COLL
);
```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

- **PIO_SOURCECDRNAMING** (Mandatory) This is a parameter of table type CDR_NAMING_VERSIONS_OBJ_TYPE that contains CDR Naming Version attributes.

If you are only creating a new definition or a new definition and an instance of it, enter values for the new definition. If you are creating a definition enter \$OBJTYPES\$DATAMART for OBJECT_TYPE_RC. Enter NULL if you are creating a new definition and an instance of it.

If you are creating an instance of an existing definition, enter values to identify the definition. If you are creating an instance of an existing definition enter \$OBJTYPES\$DATAMARTREF for OBJECT_TYPE_RC.
- **PI_CDRDATAMARTOBJTYPE** (Optional) This is a parameter of table type CDR_DATA_MART_OBJ_TYPE that contains object attributes specific to Data Marts.

If you are creating a new definition, enter values for the new Data Mart. The following attributes are required: COMPANY_ID, ADAPTER_COMPANY_ID, ADAPTER_OBJ_ID, ADAPTER_OBJ_VER.

If you are creating an instance of an existing Data Mart, do not enter any values here.
- **PI_CREATEOBJECT** (Mandatory) Enter DEFN to create a definition only; INST to create a instance of an existing definition; or BOTH to create a new definition and an instance of it.
- **PI_INSTANCE_SUBTYPE_ID** (Optional) If you are creating a new instance, enter the ID for the subtype you want to give the instance. If you are creating a definition only, do not enter a value for this parameter.
- **PI_DEFCLASSIFICATIONCOLL** (Optional) By default the new definition is classified according to the subtype you assigned it in the CDR_NAMING_VERSION_OBJ_TYPE. If you want to override the default classifications for one or more classification levels, use this parameter. This is a collection of CDR_CLA_OBJ_TYPES, which have 5 attributes, including CLA_LEVEL_ID and CLASSIFICATION_ID.

If you want the definition to inherit its classifications for a particular level from its parent, enter the classification level ID and, for the CLASSIFICATION_ID, enter 0 (zero).

If you want to explicitly assign one or more terms for a particular level, initialize a CDR_CLA_OBJ_TYPE for each term, entering the classification level ID and, for the CLASSIFICATION_ID, the term ID. The PAR_ attributes are not relevant to Data Marts. Do not enter any values for them. If you are not creating a new definition, do not enter values here.
- **PI_INSTCLASSIFICATIONCOLL** The definition is classified according to the subtype you assigned it in the PI_INSTANCE_SUBTYPE_ID. If you want to override the default classifications for one or more classification levels, use this parameter. This is a collection of CDR_CLA_OBJ_TYPES, which have 5 attributes, including CLA_LEVEL_ID and CLASSIFICATION_ID. If you want the instance to inherit its classifications for a particular level from its parent Work Area, enter the classification level ID and, for the CLASSIFICATION_ID, enter 0 (zero). If you want to explicitly assign one or more terms for a particular level, initialize a CDR_CLA_OBJ_TYPE for each term, entering the classification level ID and, for the CLASSIFICATION_ID, the term ID. The PAR_ attributes are not relevant to Data Marts. Do not enter any values for them. If you are not creating a new instance, do not enter values here.

5.1.2 Check In a DataMart Definition

Use this API to check in a Data Mart definition.

Name CDR_PUB_DF_DATAMART.CHECKINDATAMARTDEFINITION

Signature

```
PROCEDURE CHECKINDATAMARTDEFINITION(
  P_API_VERSION IN NUMBER,
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
  X_RETURN_STATUS OUT VARCHAR2,
  X_MSG_COUNT OUT NUMBER,
  X_MSG_DATA OUT VARCHAR2,
  PIO_BASEOBJECT IN OUT CDR_BASE_OBJ_TYPE,
  PI_COMMENT IN VARCHAR2
);
```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

- **PIO_BASEOBJECT** (Mandatory) This is a parameter of table type CDR_BASE_OBJ_TYPE that contains object attributes. Enter values to identify the Data Mart definition that you want to check in. The following attributes are required: COMPANY_ID,OBJ_ID,OBJ_VER,OBJECT_VERSION_NUMBER,NAMESPACE_OBJ_ID,NAMESPACE_OBJ_VER.
- **PI_COMMENT** (Optional) Enter the reason you are checking in the Data Mart.

5.1.3 Modify a Data Mart

Use this API to modify a Data Mart definition or instance. You can modify the name and description. If you are modifying an instance object, you can also change the 3 REF attribute values to select a different source definition.

Note: If you are modifying a definition, you must first check it out.

Name CDR_PUB_DF_DATAMART.MODIFYDATAMART

Signature

```
PROCEDURE MODIFYDATAMART(
  P_API_VERSION IN NUMBER,
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
  X_RETURN_STATUS OUT VARCHAR2,
  X_MSG_COUNT OUT NUMBER,
  X_MSG_DATA OUT VARCHAR2,
  PIO_CDRNAMING IN OUT CDR_NAMING_VERSION_OBJ_TYPE
);
```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

PIO_CDRNAMING (Mandatory) This is a parameter of table type CDR_NAMING_VERSION_OBJ_TYPE that contains object attributes. Enter values to identify the Data Mart and enter new values for the attributes you want to modify. You can change the name or description for either a definition or instance. For an instance you can also

change to a different underlying source definition by entering values for the new definition in the three REF attributes. All attributes are required.

NOTE: Use separate APIs for modifying the validation status and the version label: CDR_PUB_VL_VALIDATION. UpdateValStatus and CDR_PUB_DF_NAMING. UpdateVersionLabel.

5.1.4 Check Out a Data Mart

Use this API to check out a Data Mart definition, either directly or through an instance of it.

Name CDR_PUB_DF_DATAMART.CHECKOUTDATAMART

Signature

```
PROCEDURE CHECKOUTDATAMART(  
  P_API_VERSION IN NUMBER,  
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,  
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,  
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,  
  X_RETURN_STATUS OUT VARCHAR2,  
  X_MSG_COUNT OUT NUMBER,  
  X_MSG_DATA OUT VARCHAR2,  
  PIO_BASEOBJECT IN OUT CDR_BASE_OBJ_TYPE,  
  PI_COMMENT IN VARCHAR2,  
  PI_ISINSTONLY IN VARCHAR2  
);
```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

- **PIO_BASEOBJECT** (Mandatory) This is a parameter of table type CDR_BASE_OBJ_TYPE that contains object attributes. Enter values to identify the Data Mart that you want to do check out. I

If you are checking out the Data Mart definition directly, enter values to identify the definition. If you are checking out a Data Mart definition through an instance of it, enter values to identify the instance.

The following attributes are required: COMPANY_ID, OBJ_ID, OBJ_VER, OBJECT_VERSION_NUMBER, NAMESPACE_OBJ_ID, NAMESPACE_OBJ_VER.

The following attributes are required: COMPANY_ID, OBJ_ID, OBJ_VER. For OBJECT_TYPE_RC enter \$OBJTYPES\$WORKAREA. By default, new Work Areas receive a Usage Intent value of Development.

- **PI_COMMENT** (Optional) Enter the reason you are checking out the Data Mart.
- **PI_ISINSTONLY** (Mandatory) Enter \$YESNO\$NO.

5.1.5 Remove a Data Mart

Use this API to remove one or more Data Mart definitions or instances.

Name CDR_PUB_DF_DATAMART.REMOVEDATAMART

Signature

```
PROCEDURE REMOVEDATAMART(  
  P_API_VERSION IN NUMBER,
```

```

P_INIT_MSG_LIST IN    VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
P_COMMIT IN      VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
P_VALIDATION_LEVEL IN    NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
X_RETURN_STATUS OUT    VARCHAR2,
X_MSG_COUNT OUT      NUMBER,
X_MSG_DATA OUT      VARCHAR2,
PIO_CDRBASEOBJCOLL IN OUT    CDR_BASE_OBJ_COLL
);

```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

PIO_CDRBASEOBJCOLL (Mandatory) This is a collection of CDR_BASE_OBJ_TYPES. For each Data Mart that you want to remove, initialize a CDR_BASE_OBJ_TYPE and then extend the collection.

The following attributes are required: COMPANY_ID,OBJ_ID,OBJ_VER,OBJECT_VERSION_NUMBER,NAMESPACE_OBJ_ID,NAMESPACE_OBJ_VER.

This is a public interface for Domain-related operations, including creating, modifying, and removing Domains. It also includes functions for copying and moving objects into Domains.

6.1 Define and Modify Domains

This section contains the following topics:

- [Section 6.1.1, "Create a Domain"](#)
- [Section 6.1.2, "Modify a Domain"](#)
- [Section 6.1.3, "Copy a Domain"](#)
- [Section 6.1.4, "Move Objects into a Domain"](#)
- [Section 6.1.5, "Copy Objects into a Domain"](#)
- [Section 6.1.6, "Copy Objects into a Domain and Check in"](#)
- [Section 6.1.7, "Remove a Domain"](#)

6.1.1 Create a Domain

Use this API to create a new Domain.

Name CDR_PUB_DF_DOMAIN.CREATEDOMAIN

Signature

```
PROCEDURE CREATEDOMAIN(
  P_API_VERSION IN NUMBER,
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
  X_RETURN_STATUS OUT VARCHAR2,
  X_MSG_COUNT OUT NUMBER,
  X_MSG_DATA OUT VARCHAR2,
  PIO_SOURCECDRNAMING IN OUT CDR_NAMING_VERSION_OBJ_TYPE,
  PO_DEFCLASSIFICATIONCOLL IN CDR_CLASSIFICATIONS_COLL
);
```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

- **PIO_SOURCECDRNAMING** (Mandatory) This is a parameter of table type CDR_NAMING_VERSIONS_OBJ_TYPE that contains CDR Naming Version attributes. For OBJECT_TYPE_RC enter \$OBJTYPES\$LIBDOMAIN.
- **PO_DEFCLASSIFICATIONCOLL** (Optional) By default the new Domain is classified according to the subtype you assigned it in the CDR_NAMING_VERSION_OBJ_TYPE.

If you want to override the default classifications for one or more classification levels, use this parameter. This is a collection of CDR_CLA_OBJ_TYPES, which have 5 attributes, including CLA_LEVEL_ID and CLASSIFICATION_ID. I

f you want the definition to inherit its classifications for a particular level from its parent, enter the classification level ID and, for the CLASSIFICATION_ID, enter 0 (zero).

If you want to explicitly assign one or more terms for a particular level, initialize a CDR_CLA_OBJ_TYPE for each term, entering the classification level ID and, for the CLASSIFICATION_ID, the term ID. The PAR_ attributes are not relevant to Domains. Do not enter any values for them.

6.1.2 Modify a Domain

Use this API to modify a Domain.

Name CDR_PUB_DF_DOMAIN.MODIFYDOMAIN

Signature

```
PROCEDURE MODIFYDOMAIN(  
  P_API_VERSION IN NUMBER,  
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,  
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,  
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,  
  X_RETURN_STATUS OUT VARCHAR2,  
  X_MSG_COUNT OUT NUMBER,  
  X_MSG_DATA OUT VARCHAR2,  
  PIO_SOURCECDRNAMING IN OUT CDR_NAMING_VERSION_OBJ_TYPE  
);
```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

PIO_SOURCECDRNAMING (Mandatory) This is a parameter of table type CDR_NAMING_VERSION_OBJ_TYPE that contains object attributes. Enter values to identify the Domain and enter new values for the attributes you want to modify. The COMPANY_ID, OBJ_ID and OBJ_VER of the domain to be modified should be initialized.

Note: Use separate APIs for modifying the validation status and the version label: CDR_PUB_VL_VALIDATION.UPDATEVALSTATUS and CDR_PUB_DF_NAMING.UPDATEVERSIONLABEL.

6.1.3 Copy a Domain

Use this API to make a copy of a Domain.

Name CDR_PUB_DF_DOMAIN.COPYDOMAIN

Signature

```
PROCEDURE COPYDOMAIN(
  P_API_VERSION IN NUMBER,
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
  X_RETURN_STATUS OUT VARCHAR2,
  X_MSG_COUNT OUT NUMBER,
  X_MSG_DATA OUT VARCHAR2,
  PI_CDRBASEOBJCOLL IN OUT CDR_BASE_OBJ_COLL
);
```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

PI_CDRBASEOBJCOLL (Mandatory) This is a collection of CDR_BASE_OBJ_TYPES. For each Domain that you want to copy, initialize a CDR_BASE_OBJ_TYPE and then extend the collection.

The following attributes are required: COMPANY_ID,OBJ_ID,OBJ_VER,NAMESPACE_OBJ_ID,NAMESPACE_OBJ_VER, OBJECT_VERSION_NUMBER.

6.1.4 Move Objects into a Domain

Use this API to move subdomains, Application Areas, and object definitions from one Domain or Application Area, into another Domain.

Name CDR_PUB_DF_DOMAIN.MOVEOBJECTSINTODOMAIN

Signature

```
PROCEDURE MOVEOBJECTSINTODOMAIN(
  P_API_VERSION IN NUMBER,
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
  X_RETURN_STATUS OUT VARCHAR2,
  X_MSG_COUNT OUT NUMBER,
  X_MSG_DATA OUT VARCHAR2,
  PI_CDRBASEOBJCOLL IN OUT CDR_BASE_OBJ_COLL,
  PI_CDRTARGETCONTAINEROBJECT IN OUT CDR_BASE_OBJ_TYPE
);
```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

- **PI_CDRBASEOBJCOLL** (Mandatory) This is a collection of CDR_BASE_OBJ_TYPES. For each object that you want to move, initialize a CDR_BASE_OBJ_TYPE and then extend the collection.

The following attributes are required: COMPANY_ID,OBJ_ID,OBJ_VER,OBJECT_VERSION_NUMBER,NAMESPACE_OBJ_ID,NAMESPACE_OBJ_VER

- **PI_CDRTARGETCONTAINEROBJECT** (Mandatory) This is a parameter of CDR_BASE_OBJ_TYPE and contains basic naming details about the Domain into which you want move objects.

The following attributes are required: COMPANY_ID,OBJ_ID,OBJ_VER, NAMESPACE_OBJ_ID, NAMESPACE_OBJ_VER, and OBJECT_VERSION_NUMBER).

6.1.5 Copy Objects into a Domain

Use this API to copy objects into a Domain. You can copy subdomains, Application Areas, and object definitions from other Domains or Application Areas.

Name CDR_PUB_DF_DOMAIN.COPYOBJECTSINTODOMAIN

Signature

```
PROCEDURE COPYOBJECTSINTODOMAIN(  
  P_API_VERSION IN NUMBER,  
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,  
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,  
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,  
  X_RETURN_STATUS OUT VARCHAR2,  
  X_MSG_COUNT OUT NUMBER,  
  X_MSG_DATA OUT VARCHAR2,  
  PI_CDRBASEOBJCOLL IN OUT CDR_BASE_OBJ_COLL,  
  PI_CDRTARGETCONTAINEROBJECT IN OUT CDR_BASE_OBJ_TYPE  
);
```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

- **PI_CDRBASEOBJCOLL** (Mandatory) This is a collection of CDR_BASE_OBJ_TYPES. For each object that you want to copy, initialize a CDR_BASE_OBJ_TYPE and then extend the collection.

The following attributes are required: COMPANY_ID, OBJ_ID, OBJ_VER, OBJECT_VERSION_NUMBER, NAMESPACE_OBJ_ID, NAMESPACE_OBJ_VER.

- **PI_CDRTARGETCONTAINEROBJECT** (Mandatory) This is a parameter of CDR_BASE_OBJ_TYPE and contains basic naming details about the Domain into which you want copy objects.

The following attributes are required: COMPANY_ID, OBJ_ID, OBJ_VER, NAMESPACE_OBJ_ID, NAMESPACE_OBJ_VER, and OBJECT_VERSION_NUMBER).

6.1.6 Copy Objects into a Domain and Check in

Use this overloaded API to check in the objects copied into a Domain (if they are checked out in the source Domain).

Name CDR_PUB_DF_DOMAIN.COPYOBJECTSINTODOMAIN

Signature

```
PROCEDURE COPYOBJECTSINTODOMAIN(  
  P_API_VERSION IN NUMBER,  
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,  
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,  
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,  
  X_RETURN_STATUS OUT VARCHAR2,  
  X_MSG_COUNT OUT NUMBER,  
  X_MSG_DATA OUT VARCHAR2,  
  PI_CDRBASEOBJCOLL IN OUT CDR_BASE_OBJ_COLL,  
  PI_CDRTARGETCONTAINEROBJECT IN OUT CDR_BASE_OBJ_TYPE,  
  PI_CHECKINFLAG IN VARCHAR  
);
```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

- **PI_CDRBASEOBJCOLL** (Mandatory) This is a collection of CDR_BASE_OBJ_TYPES. For each object that you want to copy, initialize a CDR_BASE_OBJ_TYPE and then extend the collection.

The following attributes are required: COMPANY_ID,OBJ_ID,OBJ_VER,OBJECT_VERSION_NUMBER,NAMESPACE_OBJ_ID,NAMESPACE_OBJ_VER.

- **PI_CDRTARGETCONTAINEROBJECT** (Mandatory) This is a parameter of CDR_BASE_OBJ_TYPE and contains basic naming details about the Domain into which you want copy objects.

The following attributes are required: COMPANY_ID,OBJ_ID,OBJ_VER, NAMESPACE_OBJ_ID, NAMESPACE_OBJ_VER, and OBJECT_VERSION_NUMBER).

- **PI_CHECKINFLAG** (Mandatory) Enter \$YESNO\$YES if you want to check in the copied objects, if they are checked out, and \$YESNO\$NO if you do not want to check in the copied objects.

6.1.7 Remove a Domain

Use this API to delete a Domain.

Name CDR_PUB_DF_DOMAIN.REMOVEDOMAIN

Signature

```
PROCEDURE REMOVEDOMAIN(
  P_API_VERSION IN NUMBER,
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
  X_RETURN_STATUS OUT VARCHAR2,
  X_MSG_COUNT OUT NUMBER,
  X_MSG_DATA OUT VARCHAR2,
  PIO_DOMAIN IN OUT CDR_BASE_OBJ_TYPE
);
```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

PIO_DOMAIN (Mandatory) This is a parameter of CDR_BASE_OBJ_TYPE and contains basic naming details about the Domain you want to delete.

The following attributes are required: COMPANY_ID, OBJ_ID,OBJ_VER, NAMESPACE_OBJ_ID, NAMESPACE_OBJ_VER, and OBJECT_VERSION_NUMBER).

Setup Utilities

This is a public interface for operations related to the setting up of utilities in Oracle LSH.

This section contains the following topics:

- [Section 7.1, "Initialize APIs"](#)
- [Section 7.2, "Define and Modify Adapters"](#)
- [Section 7.3, "Host Definition Constants"](#)
- [Section 7.4, "Get Factory Support"](#)
- [Section 7.5, "Get Factory Utilities"](#)
- [Section 7.6, "Get Factory Validations"](#)
- [Section 7.7, "Get Data from Naming Tables"](#)
- [Section 7.8, "Read Messages"](#)

7.1 Initialize APIs

This is a public interface that is used internally to initialize all other Oracle LSH external API packages. See ["Calling the Security API Package"](#) on page 1-3 for details. See ["Code Example Using Security and Error Message APIs"](#) on page 1-5 for an example of a program that calls the initialization API.

This section contains the following topics:

- [Section 7.1.1, "Initialize a Package"](#)
- [Section 7.1.2, "Verify Whether an API is Enabled"](#)
- [Section 7.1.3, "Enable an API"](#)
- [Section 7.1.4, "Disable an API"](#)

7.1.1 Initialize a Package

This is used internally to initialize external Oracle LSH API packages.

Name CDR_PUB_API_INITIALIZATION.INITIALIZATION

Signature

```
PROCEDURE INITIALIZATION(
  P_API_VERSION IN NUMBER,
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
```

```
P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
X_RETURN_STATUS OUT VARCHAR2,
X_MSG_COUNT OUT NUMBER,
X_MSG_DATA OUT VARCHAR2,
PI_VPKGNAME IN VARCHAR2
);
```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameter:

PI_VPKGNAME This is used internally to pass the external API package name.

7.1.2 Verify Whether an API is Enabled

Use this API to find out whether or not the API you want to use is enabled.

Name CDR_PUB_API_INITIALIZATION.ISAPIENABLED

Signature

```
FUNCTION ISAPIENABLED(
  P_API_VERSION IN NUMBER,
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL
) RETURN BOOLEAN;
```

Return BOOLEAN

True, if the API is enabled or False, if it is disabled.

Parameters This API has standard parameters. See ["Standard Parameters"](#) on page 5 for details.

7.1.3 Enable an API

Use this API to enable LSH APIs that you want to use in a session. This API must be called at the beginning of each Program that uses LSH APIs.

Name CDR_PUB_API_INITIALIZATION.ENABLEAPIS

Signature

```
PROCEDURE ENABLEAPIS(
  P_API_VERSION IN NUMBER,
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
  X_RETURN_STATUS OUT VARCHAR2,
  X_MSG_COUNT OUT NUMBER,
  X_MSG_DATA OUT VARCHAR2
);
```

Parameters This API has standard parameters. See ["Standard Parameters"](#) on page 5 for details.

7.1.4 Disable an API

Use this API to disable LSH APIs that you have used in a session. Call this API at the end of each Program that uses LSH APIs.

Name CDR_PUB_API_INITIALIZATION.DISABLEAPIS

Signature

Return BOOLEAN

True, if the API is enabled or False, if it is disabled.

Parameters This API has standard parameters. See ["Standard Parameters"](#) on page 5 for details.

7.2 Define and Modify Adapters

This package is used to create adapter domains and adapter areas for user defined adapters.

This section contains the following topics:

- [Section 7.2.1, "Create an Adapter Domain"](#)
- [Section 7.2.2, "Create an Adapter Area"](#)
- [Section 7.2.3, "Populate a Tech Type Table"](#)

7.2.1 Create an Adapter Domain

Use this API to create an Adapter Domain.

Name CDR_PUB_ATK_ADAPTER.CREATEADAPTERDOMAIN

Signature

```
PROCEDURE CREATEADAPTERDOMAIN(
  P_API_VERSION IN NUMBER,
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
  X_RETURN_STATUS OUT VARCHAR2,
  X_MSG_COUNT OUT NUMBER,
  X_MSG_DATA OUT VARCHAR2,
  PIO_ADAPTERDOMAINNAMING IN OUT CDR_NAMING_VERSION_OBJ_TYPE
);
```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameter:

PIO_ADAPTERDOMAINNAMING (Mandatory) This is a parameter of table type CDR_NAMING_VERSION_OBJ_TYPE that contains object attributes. Enter values for the Adapter Domain that you are creating. For OBJECT_TYPE_RC enter \$OBJTYPES\$ADAPTERDOMAIN.

The following attributes are required: COMPANY_ID,NAME

7.2.2 Create an Adapter Area

Use this API to create an Adapter Area.

Name CDR_PUB_ATK_ADAPTER.CREATEADAPTERAREA

Signature

```
PROCEDURE CREATEADAPTERAREA(  
    P_API_VERSION IN NUMBER,  
    P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,  
    P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,  
    P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,  
    X_RETURN_STATUS OUT VARCHAR2,  
    X_MSG_COUNT OUT NUMBER,  
    X_MSG_DATA OUT VARCHAR2,  
    PIO_ADAPTERAREANAMING IN OUT CDR_NAMING_VERSION_OBJ_TYPE,  
    PIO_ADAPTERAREAROW IN OUT CDR_ADAPTER_AREAS%ROWTYPE  
);
```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

- **PIO_ADAPTERAREANAMING** (Mandatory) This is a parameter of table type CDR_NAMING_VERSION_OBJ_TYPE that contains object attributes. Enter values for the adapter area that you are creating.
- **PIO_ADAPTERAREAROW** (Mandatory) This is a parameter of row type CDR_ADAPTER_AREAS table that contains object attributes. Enter values specific for the adapter area that you are creating. For OBJECT_TYPE_RC enter \$OBJTYPES\$ADAPTERAREA.

The following attributes are required: COMPANY_ID,NAME

7.2.3 Populate a Tech Type Table

Use this API to populate a Tech Type Table.

Name CDR_PUB_ATK_ADAPTER.POPULATETECHTYPES

Signature

```
PROCEDURE POPULATETECHTYPES(  
    P_API_VERSION IN NUMBER,  
    P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,  
    P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,  
    P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,  
    X_RETURN_STATUS OUT VARCHAR2,  
    X_MSG_COUNT OUT NUMBER,  
    X_MSG_DATA OUT VARCHAR2,  
    PIO_TECHTYPEROW IN OUT CDR_TECH_TYPES%ROWTYPE  
);
```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameter:

PIO_TECHTYPEROW (Mandatory) This is a parameter of row type cdr_tech_types table that contains object attributes. Enter values specific for the tech type that you are creating.

7.3 Host Definition Constants

This is a public interface that hosts definition constants for Oracle LSH APIs.

Name CDR_PUB_DEF_CONSTANTS

7.4 Get Factory Support

This is a public interface that hosts utility APIs for other packages.

This section contains the following topics:

- [Section 7.4.1, "Get a Naming Version Object"](#)
- [Section 7.4.2, "Get a User ID"](#)
- [Section 7.4.3, "Get a User Name"](#)

7.4.1 Get a Naming Version Object

Use this API to retrieve a valid CDR_NAMING_VERSION_OBJ_TYPE parameter by passing the primary keys COMPANY_ID, OBJ_ID, and OBJ_VER to it.

Name CDR_PUB_DEF_FACTORY_SUPPORT.GETNAMINGOBJECT

Signature

```
FUNCTION GETNAMINGOBJECT (
  P_API_VERSION IN NUMBER,
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
  PI_NCOMPANYID IN CDR_NAMINGS.COMPANY_ID%TYPE,
  PI_NOBJID IN CDR_NAMINGS.OBJ_ID%TYPE,
  PI_NOBJVER IN CDR_NAMING_VERSIONS.OBJ_VER%TYPE,
  PO_CDRNAMING OUT CDR_NAMING_VERSION_OBJ_TYPE
) RETURN BOOLEAN;
```

Return BOOLEAN

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

- **PI_NCOMPANYID** (Mandatory) Enter the COMPANY_ID of the object.
- **PI_NOBJID** (Mandatory) Enter the OBJ_ID of the object.
- **PI_NOBJVER** (Mandatory) Enter the OBJ_VER of the object.
- **PO_CDRNAMING** (Mandatory) This is the output from the API.

7.4.2 Get a User ID

Use this API to retrieve a user ID.

Name CDR_PUB_DEF_FACTORY_SUPPORT.GETUSERID

Signature

```
FUNCTION GETUSERID (
  P_API_VERSION IN NUMBER,
```

```
P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,  
P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,  
P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL  
) RETURN CDR_DF_NAMING_V.CHECKED_OUT_ID%TYPE;
```

Return CDR_DF_NAMING_V.CHECKED_OUT_ID%TYPE

Boolean

Parameters This API has standard parameters. See ["Standard Parameters"](#) on page 5 for details.

7.4.3 Get a User Name

Use this API to retrieve the current user name.

Name CDR_PUB_DEF_FACTORY_SUPPORT.GETUSERNAME

Signature

```
FUNCTION GETUSERNAME(  
  P_API_VERSION IN NUMBER,  
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,  
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,  
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,  
  PI_USERID IN NUMBER  
) RETURN VARCHAR2;
```

Return Type VARCHAR2

Description VARCHAR2.

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameter:

PI_USERID (Mandatory) Enter the User ID. Use CDR_PUB_DEF_FACTORY_SUPPORT.GETUSERID to get the ID of the current user.

7.5 Get Factory Utilities

This is a public interface that hosts utility APIs for other packages.

This section contains the following topics:

- [Section 7.5.1, "Get a Base Object Type"](#)
- [Section 7.5.2, "Get a Company ID"](#)

7.5.1 Get a Base Object Type

Use this API to retrieve all details of an object from CDR_BASE_OBJ_TYPE table, by passing the object's primary key values: COMPANY_ID, OBJ_ID, and OBJ_VER.

Name CDR_PUB_DEF_FACTORY_UTILS.GETCDRBASEOBJECT

Signature

```
FUNCTION GETCDRBASEOBJECT(  
  P_API_VERSION IN NUMBER,  
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
```

```

P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
PI_COMPANYID IN CDR_NAMINGS.COMPANY_ID%TYPE,
PI_OBJID IN CDR_NAMINGS.OBJ_ID%TYPE,
PI_OBJVER IN CDR_NAMING_VERSIONS.OBJ_VER%TYPE
) RETURN CDR_BASE_OBJ_TYPE;

```

Return Type CDR_BASE_OBJ_TYPE

Description CDR_BASE_OBJ_TYPE

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

- **PI_COMPANYID** (Mandatory) Enter the COMPANY_ID of the object
- **PI_OBJID** (Mandatory) Enter the OBJ_ID of the object
- **PI_OBJVER** (Mandatory) Enter the OBJ_VER of the object

7.5.2 Get a Company ID

Use this API to retrieve the COMPANY_ID of a given object. The object is identified from the context that this API is used in.

Name CDR_PUB_DEF_FACTORY_UTILS.GETCOMPANYID

Signature

```

FUNCTION GETCOMPANYID(
  P_API_VERSION IN NUMBER,
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL
) RETURN NUMBER;

```

Return Type NUMBER

Description number Returns Company ID from the context

Parameters This API has standard parameters. See ["Standard Parameters"](#) on page 5) for details.

7.6 Get Factory Validations

This is a public interface that hosts APIs for checking object validation on various objects. These APIs are tools to automatically validate objects without having to manually set their attributes to validate them.

This section contains the following topics:

- [Section 7.6.1, "Validate a Namespace"](#)
- [Section 7.6.2, "Validate a Reference"](#)

7.6.1 Validate a Namespace

Use this API to validate whether a given object is created in a valid parent; for example, you may want to check if a Program Definition is a valid parent of a Table Descriptor.

Name CDR_PUB_DEF_FACTORY_VALIDATE.VALIDATENAMESPACE

Signature

```
FUNCTION VALIDATENAMESPACE(  
  P_API_VERSION IN NUMBER,  
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,  
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,  
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,  
  PIO_SOURCECDRNAMING IN OUT CDR_NAMING_VERSION_OBJ_TYPE  
) RETURN BOOLEAN;
```

Return Type BOOLEAN

Description boolean

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameter:

PIO_SOURCECDRNAMING (Mandatory) This is a parameter of table type CDR_NAMING_VERSIONS_OBJ_TYPE that contains CDR Naming Version attributes.

For OBJECT_TYPE_RC enter the appropriate value for the object for which you want to validate a reference.

Other required attributes are: COMPANY_ID,OBJ_ID,OBJ_VER,OBJECT_TYPE_RC,NAMESPACE_OBJ_ID,NAMESPACE_OBJ_VER,REF_COMPANY_ID,REF_OBJ_ID,REF_OBJ_VER

7.6.2 Validate a Reference

Use this API to validate the definition specified for the given object id.

Name CDR_PUB_DEF_FACTORY_VALIDATE.VALIDATEREFERENCE

Signature

```
FUNCTION VALIDATEREFERENCE(  
  P_API_VERSION IN NUMBER,  
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,  
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,  
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,  
  PIO_SOURCECDRNAMING IN OUT CDR_NAMING_VERSION_OBJ_TYPE  
) RETURN BOOLEAN;
```

Return Type BOOLEAN

Description boolean

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameter:

PIO_SOURCECDRNAMING (Mandatory) This is a parameter of table type CDR_NAMING_VERSIONS_OBJ_TYPE that contains CDR Naming Version attributes.

For OBJECT_TYPE_RC enter the appropriate value for the object for which you want to validate a reference.

Other required attributes are: COMPANY_ID,OBJ_ID,OBJ_VER,OBJECT_TYPE_RC,NAMESPACE_OBJ_ID,NAMESPACE_OBJ_VER,REF_COMPANY_ID,REF_OBJ_ID,REF_OBJ_VER

7.7 Get Data from Naming Tables

This is a public interface that is used to retrieve data from naming-related tables.

This section contains the following topics:

- [Section 7.7.1, "Get the Latest Version"](#)
- [Section 7.7.2, "Get a Maximum Version"](#)
- [Section 7.7.3, "Get the Type of a Naming Object"](#)
- [Section 7.7.4, "Get an Object's Naming Version"](#)
- [Section 7.7.5, "Get an Object's Subtype ID"](#)
- [Section 7.7.6, "Get an Object's Checkout Status"](#)
- [Section 7.7.7, "Get Checkout Properties"](#)
- [Section 7.7.8, "Get a Naming Object's Parent"](#)
- [Section 7.7.9, "Get a Parent Naming Object"](#)
- [Section 7.7.10, "Get the Latest Version of the Parent Object"](#)
- [Section 7.7.11, "Get the Naming Status of a Parent Object"](#)
- [Section 7.7.12, "Get the Validation Status of a Parent Object"](#)
- [Section 7.7.13, "Get a Definition Object"](#)
- [Section 7.7.14, "Get a Lookup Meaning"](#)
- [Section 7.7.15, "Find Whether an Object is an Instance"](#)
- [Section 7.7.16, "Find Whether Checked Out By Current User"](#)
- [Section 7.7.17, "Find Whether a Checkout is User-Specific"](#)
- [Section 7.7.18, "Find Whether Checkout is Implicit"](#)

7.7.1 Get the Latest Version

Use this API to retrieve the latest version available for a given object.

Name CDR_PUB_DF_NAMING_UTIL.GETLASTVERSION

Signature

```
FUNCTION GETLASTVERSION(
  P_API_VERSION IN NUMBER,
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
  PI_BASEOBJECT IN CDR_BASE_OBJ_TYPE
) RETURN NUMBER;
```

Return

Type NUMBER

Description number

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameter:

PI_BASEOBJECT (Mandatory) This is a parameter of table type CDR_BASE_OBJ_TYPE that contains object attributes.

The required attributes are COMPANY_ID,OBJECT_ID,OBJECT_VER,NAMESPACE_OBJ_ID,NAMESPACE_OBJ_VER.

7.7.2 Get a Maximum Version

Use this API to get the maximum versions of a specified object and its namespace.

Name CDR_PUB_DF_NAMING_UTIL.GETMAXOBJANDNSVERSIONS

Signature

```
PROCEDURE GETMAXOBJANDNSVERSIONS (  
    P_API_VERSION IN NUMBER,  
    P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,  
    P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,  
    P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,  
    X_RETURN_STATUS OUT VARCHAR2,  
    X_MSG_COUNT OUT NUMBER,  
    X_MSG_DATA OUT VARCHAR2,  
    PI_COMPID IN NUMBER,  
    PI_OBJID IN NUMBER,  
    PO_MAXOBJVER OUT NUMBER,  
    PO_MAXNSOBJVER OUT NUMBER  
);
```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

- **PI_COMPID** (Mandatory) Enter the COMPANY_ID of the given object.
- **PI_OBJID** (Mandatory) Enter the OBJ_ID of the given object.
- **PO_MAXOBJVER** This is an output parameter. It returns the maximum version of the given object.
- **PO_MAXNSOBJVER** This is an output parameter. It returns the maximum version of the Namespace of the given object.

7.7.3 Get the Type of a Naming Object

Use this API to get the type of a specified naming object.

Name CDR_PUB_DF_NAMING_UTIL.ETNAMINGOBJECTTYPE

Signature

```
FUNCTION GETNAMINGOBJECTTYPE (  
    P_API_VERSION IN NUMBER,  
    P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,  
    P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,  
    P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,  
    PIO_BASEOBJECT IN CDR_BASE_OBJ_TYPE  
    ) RETURN VARCHAR2;
```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameter:

PIO_BASEOBJECT (Mandatory) This is a parameter of table type CDR_BASE_OBJ_TYPE that contains object attributes. The required attributes are COMPANY_ID,OBJECT_ID,OBJECT_VER,NAMESPACE_OBJ_ID,NAMESPACE_OBJ_VER.

7.7.4 Get an Object's Naming Version

Use this API to retrieve an initialized object of table type CDR_NAMING_VERSION_OBJ_TYPE for a given naming object.

Name CDR_PUB_DF_NAMING_UTIL.GETNAMINGVERSIONOBJECT

Signature

```
FUNCTION GETNAMINGVERSIONOBJECT(
  P_API_VERSION IN NUMBER,
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
  PI_BASEOBJECT IN CDR_BASE_OBJ_TYPE
) RETURN CDR_NAMING_VERSION_OBJ_TYPE;
```

Return

Type CDR_NAMING_VERSION_OBJ_TYPE

Description cdr_naming_version_obj_type

Parameters This API has standard parameters (see "[Standard Parameters](#)" on page 5) and the following parameter:

PI_BASEOBJECT (Mandatory) This is a parameter of table type CDR_BASE_OBJ_TYPE that contains object attributes.

The required attributes are COMPANY_ID,OBJECT_ID,OBJECT_VER,NAMESPACE_OBJ_ID,NAMESPACE_OBJ_VER.

7.7.5 Get an Object's Subtype ID

Use this API to retrieve the object subtype ID of a given naming object.

Name CDR_PUB_DF_NAMING_UTIL.GETOBJECTSUBTYPEID

Signature

```
FUNCTION GETOBJECTSUBTYPEID(
  P_API_VERSION IN NUMBER,
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
  PI_BASEOBJECT IN CDR_BASE_OBJ_TYPE
) RETURN NUMBER;
```

Return

Type NUMBER

Description Number

Parameters This API has standard parameters (see "[Standard Parameters](#)" on page 5) and the following parameter:

PI_BASEOBJECT (Mandatory) This is a parameter of table type CDR_BASE_OBJ_TYPE that contains object attributes.

The required attributes are COMPANY_ID,OBJECT_ID,OBJECT_VER,NAMESPACE_OBJ_ID,NAMESPACE_OBJ_VER.

7.7.6 Get an Object's Checkout Status

Use this API to find out whether or not a naming object is checked out.

Name CDR_PUB_DF_NAMING_UTIL.ISNAMINGCHECKEDOUT

Signature

```
FUNCTION ISNAMINGCHECKEDOUT(  
  P_API_VERSION IN NUMBER,  
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,  
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,  
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,  
  PIO_BASEOBJECT IN CDR_BASE_OBJ_TYPE  
) RETURN BOOLEAN;
```

Return

Type BOOLEAN

Description Boolean

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameter:

PIO_BASEOBJECT (Mandatory) This is a parameter of table type CDR_BASE_OBJ_TYPE that contains object attributes.

The required attributes are COMPANY_ID,OBJECT_ID,OBJECT_VER,NAMESPACE_OBJ_ID,NAMESPACE_OBJ_VER.

7.7.7 Get Checkout Properties

Use this API to retrieve the checkout status and implicit checkout property of a specified object.

Name CDR_PUB_DF_NAMING_UTIL.GETCHKOUTPROP

Signature

```
PROCEDURE GETCHKOUTPROP(  
  P_API_VERSION IN NUMBER,  
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,  
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,  
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,  
  X_RETURN_STATUS OUT VARCHAR2,  
  X_MSG_COUNT OUT NUMBER,  
  X_MSG_DATA OUT VARCHAR2,  
  PI_COMPID IN NUMBER,  
  PI_OBJID IN NUMBER,  
  PO_CHKOUTSTATUS OUT VARCHAR2,  
  PO_CHKIMPLPROP OUT VARCHAR2  
);
```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

- **PI_COMPID** (Mandatory) Enter the COMPANY_ID of the given object.
- **PI_OBJID** (Mandatory) Enter the OBJ_ID of the given object.
- **PO_CHKOUTSTATUS** This is an output parameter. It returns the checkout status of the given object
- **PO_CHKIMPLPROP** This is an output parameter. It returns the implicit checkout property of the given object.

7.7.8 Get a Naming Object's Parent

Use this API to retrieve the parent object of a given naming object.

Name CDR_PUB_DF_NAMING_UTIL.GETPARENTNAMING

Signature

```
FUNCTION GETPARENTNAMING (
  P_API_VERSION IN NUMBER,
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
  PI_BASEOBJECT IN CDR_BASE_OBJ_TYPE
) RETURN CDR_BASE_OBJ_TYPE;
```

Return

Type CDR_BASE_OBJ_TYPE

Description CDR_BASE_OBJ_TYPE

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameter:

PI_BASEOBJECT (Mandatory) This is a parameter of table type CDR_BASE_OBJ_TYPE that contains object attributes.

The required attributes are COMPANY_ID,OBJECT_ID,OBJECT_VER,NAMESPACE_OBJ_ID,NAMESPACE_OBJ_VER.

7.7.9 Get a Parent Naming Object

Use this API to retrieve the parent object of a naming object.

Name CDR_PUB_DF_NAMING_UTIL.GETPARENTNAMING

Signature

```
FUNCTION GETPARENTNAMING (
  P_API_VERSION IN NUMBER,
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
  PI_BASEOBJECT IN CDR_BASE_OBJ_TYPE
) RETURN CDR_BASE_OBJ_TYPE;
```

Return

Type CDR_BASE_OBJ_TYPE

Description CDR_BASE_OBJ_TYPE

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameter:

PI_BASEOBJECT (Mandatory) This is a parameter of table type CDR_BASE_OBJ_TYPE that contains object attributes.

The required attributes are COMPANY_ID,OBJECT_ID,OBJECT_VER,NAMESPACE_OBJ_ID,NAMESPACE_OBJ_VER

7.7.10 Get the Latest Version of the Parent Object

Use this API to retrieve the latest version of the parent of the given object.

Name CDR_PUB_DF_NAMING_UTIL.GETLATESTVERSIONOFPARENT

Signature

```
FUNCTION GETLATESTVERSIONOFPARENT(  
  P_API_VERSION IN NUMBER,  
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,  
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,  
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,  
  PI_BASEOBJECT IN CDR_BASE_OBJ_TYPE  
) RETURN CDR_BASE_OBJ_TYPE;
```

Return

Type CDR_BASE_OBJ_TYPE

Description cdr_base_obj_type

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameter:

PI_BASEOBJECT (Mandatory) This is a parameter of table type CDR_BASE_OBJ_TYPE that contains object attributes.

The required attributes are COMPANY_ID,OBJECT_ID,OBJECT_VER,NAMESPACE_OBJ_ID,NAMESPACE_OBJ_VER.

7.7.11 Get the Naming Status of a Parent Object

Use this API to get the naming status of the parent object of the specified object

Name CDR_PUB_DF_NAMING_UTIL.GETPARENTNAMINGSTATUS

Signature

```
FUNCTION GETPARENTNAMINGSTATUS(  
  P_API_VERSION IN NUMBER,  
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,  
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,  
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,  
  PI_COMPANYID IN CDR_NAMINGS.COMPANY_ID%TYPE,  
  PI_NSOBJID IN CDR_NAMINGS.OBJ_ID%TYPE,  
  PI_NSOBJVER IN CDR_NAMING_VERSIONS.OBJ_VER%TYPE  
) RETURN VARCHAR2;
```

Return

Type VARCHAR2

Description varchar2

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

- **PI_COMPANYID** (Mandatory) Enter the COMPANY_ID of the object.
- **PI_NSOBJID** (Mandatory) Enter the OBJ_ID of the given object.
- **PI_NSOBJVER** (Mandatory) Enter the OBJ_VER of the given object.

7.7.12 Get the Validation Status of a Parent Object

Use this API to get the validation status of the parent object of the specified object

Name CDR_PUB_DF_NAMING_UTIL.GETPARENTVALIDATIONSTATUS

Signature

```
FUNCTION GETPARENTVALIDATIONSTATUS(
  P_API_VERSION IN NUMBER,
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
  PI_COMPANYID IN CDR_NAMINGS.COMPANY_ID%TYPE,
  PI_NSOBJID IN CDR_NAMINGS.OBJ_ID%TYPE,
  PI_NSOBJVER IN CDR_NAMING_VERSIONS.OBJ_VER%TYPE
) RETURN VARCHAR2;
```

Return

Type VARCHAR2

Description varchar2

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

- **PI_COMPANYID** (Mandatory) This refers to the company id of the given object.
- **PI_NSOBJID** (Mandatory) Enter the OBJ_ID of the given object.
- **PI_NSOBJVER** (Mandatory) Enter the OBJ_VER of the given object.

7.7.13 Get a Definition Object

Use this API to retrieve the definition object that the given instance object points to.

Name CDR_PUB_DF_NAMING_UTIL.GETREFNAMING

Signature

```
FUNCTION GETREFNAMING(
  P_API_VERSION IN NUMBER,
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
  PI_BASEOBJECT IN CDR_BASE_OBJ_TYPE
) RETURN CDR_BASE_OBJ_TYPE;
```

Return

Type CDR_BASE_OBJ_TYPE

Description CDR_BASE_OBJ_TYPE

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameter:

PI_BASEOBJECT (Mandatory) This is a parameter of table type CDR_BASE_OBJ_TYPE that contains object attributes.

The required attributes are COMPANY_ID,OBJECT_ID,OBJECT_VER,NAMESPACE_OBJ_ID,NAMESPACE_OBJ_VER.

7.7.14 Get a Lookup Meaning

Use this API to get the Lookup Meaning for a Lookup Type and Code

Name CDR_PUB_DF_NAMING_UTIL.GETLOOKUPMEANING

Signature

```
PROCEDURE GETLOOKUPMEANING(  
  P_API_VERSION IN NUMBER,  
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,  
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,  
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,  
  X_RETURN_STATUS OUT VARCHAR2,  
  X_MSG_COUNT OUT NUMBER,  
  X_MSG_DATA OUT VARCHAR2,  
  PI_LOOKUPTYPE IN VARCHAR2,  
  PI_LOOKUPCODE IN VARCHAR2,  
  PO_LOOKUPMEANING OUT VARCHAR2  
);
```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

- **PI_LOOKUPTYPE** (Mandatory) Enter the Lookup Type
- **PI_LOOKUPCODE** (Mandatory) Enter the Lookup Code
- **PO_LOOKUPMEANING** This is an output parameter. It returns the Lookup Meaning.

7.7.15 Find Whether an Object is an Instance

Use this API to check if the given naming object is an instance.

Name CDR_PUB_DF_NAMING_UTIL.ISINSTANCE

Signature

```
FUNCTION ISINSTANCE(  
  P_API_VERSION IN NUMBER,  
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,  
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,  
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,  
  PI_OBJECT_TYPE_RC IN VARCHAR2  
) RETURN VARCHAR2;
```

Return

Type VARCHAR2

Description varchar2

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameter:

PI_OBJECT_TYPE_RC (Mandatory) Object Type RC.

7.7.16 Find Whether Checked Out By Current User

Use this API to find out whether the given naming object is checked out by the current user.

Name CDR_PUB_DF_NAMING_UTIL.ISCHECKEDOUTBYUSER

Signature

```
FUNCTION ISCHECKEDOUTBYUSER(
  P_API_VERSION IN NUMBER,
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
  PIO_BASEOBJECT IN CDR_BASE_OBJ_TYPE
) RETURN BOOLEAN;
```

Return

Type BOOLEAN

Description boolean

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameter:

PIO_BASEOBJECT (Mandatory) This is a parameter of table type CDR_BASE_OBJ_TYPE that contains object attributes.

The required attributes are COMPANY_ID,OBJECT_ID,OBJECT_VER,NAMESPACE_OBJ_ID,NAMESPACE_OBJ_VER.

7.7.17 Find Whether a Checkout is User-Specific

Use this API to find out if an object is user specific or non-user specific. Only the user who checked out a user specific object can check it in; whereas any user may check in a non-user specific object.

Name CDR_PUB_DF_NAMING_UTIL.ISCHECKOUTUSERSPECIFIC

Signature

```
FUNCTION ISCHECKOUTUSERSPECIFIC(
  P_API_VERSION IN NUMBER,
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
  PI_SOURCECDRNAMING IN CDR_NAMING_VERSION_OBJ_TYPE
) RETURN BOOLEAN;
```

Return

Type BOOLEAN

Description Boolean True or False

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameter:

PI_SOURCECDRNAMING (Mandatory) This is a parameter of type cdr_naming_versions_obj_type.

The following attributes are required: COMPANY_ID, OBJECT_TYPE_RC, NAME, NAMESPACE_OBJ_ID, NAMESPACE_OBJ_VER, OWNING_LOCATION_RC, OBJECT_SUBTYPE_ID, DESCRIPTION, REF_COMPANY_ID, REF_OBJ_ID, REF_OBJ_VER.

7.7.18 Find Whether Checkout is Implicit

Use this API to find out whether a naming object is checked out implicitly.

Name CDR_PUB_DF_NAMING_UTIL.ISCHECKOUTIMPLICIT

Signature

```
FUNCTION ISCHECKOUTIMPLICIT(  
  P_API_VERSION IN NUMBER,  
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,  
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,  
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,  
  PI_OBJECT_TYPE_RC IN VARCHAR2,  
  PI_ISINSTONLY IN VARCHAR2  
) RETURN BOOLEAN;
```

Return

Type BOOLEAN

Description boolean

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

- **PI_OBJECT_TYPE_RC** (Mandatory) Enter the Object Type.
- **PI_ISINSTONLY** (Mandatory) This will have the value 'YES' or 'NO', to indicate whether it is called from an Instance or a Definition.

7.8 Read Messages

This is a public interface for reporting using messages from the system's message stack. See ["Code Example Using Security and Error Message APIs"](#) on page 1-5 for an example of a program that calls this reporting API.

This section contains the following topics:

- [Section 7.8.1, "Get a Message"](#)
- [Section 7.8.2, "Get a Message Count"](#)
- [Section 7.8.3, "Initialize a Message Stack"](#)

7.8.1 Get a Message

Use this API to retrieve messages from the message stack.

Name CDR_PUB_MSG_PUB.GET

Signature

```
FUNCTION GET(
  P_API_VERSION IN NUMBER,
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
  P_MSG_INDEX IN NUMBER := G_NEXT,
  P_ENCODED IN VARCHAR2 := 'T'
) RETURN VARCHAR2;
```

Return

Type VARCHAR2

Description varchar2 Message Text

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

- **P_MSG_INDEX** (Mandatory) Enter the number of the message you want to retrieve; for example, if you enter the number 1, the first message is retrieved from the message stack.
- **P_ENCODED** (Mandatory) Enter "T" if you want the message to be encoded, and "F" if you do not.

7.8.2 Get a Message Count

Use this API to retrieve the count of messages in the message stack. This API returns the G_MSG_COUNT value.

Name CDR_PUB_MSG_PUB.COUNT_MSG

Signature

```
FUNCTION COUNT_MSG(
  P_API_VERSION IN NUMBER,
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL
) RETURN NUMBER;
```

Return

Type NUMBER

Description Number of messages in the stack

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5).

7.8.3 Initialize a Message Stack

Use this API to initialize the global message table. This API clears the G_MSG_TBL and resets all its global variables, except the message level threshold value.

Name CDR_PUB_MSG_PUB.INITIALIZE

Signature

```
PROCEDURE INITIALIZE(  
    P_API_VERSION IN    NUMBER,  
    P_INIT_MSG_LIST IN   VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,  
    P_COMMIT IN        VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,  
    P_VALIDATION_LEVEL IN    NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,  
    X_RETURN_STATUS OUT   VARCHAR2,  
    X_MSG_COUNT OUT      NUMBER,  
    X_MSG_DATA OUT       VARCHAR2  
);
```

Parameters This API has standard parameters (see "[Standard Parameters](#)" on page 5).

This is a public interface for Load Set-related operations, including creating, modifying, and removing Load Sets. It also includes APIs for checking Load Sets in and out, undoing a Load Set checkout, and computing the status of a Load Set.

8.1 Define and Modify Load Sets

This section contains the following topics:

- [Section 8.1.1, "Create a Load Set"](#)
- [Section 8.1.2, "Check Out a Load Set Definition"](#)
- [Section 8.1.3, "Modify a Load Set"](#)
- [Section 8.1.4, "Check in a Load Set Definition"](#)
- [Section 8.1.5, "Remove a Load Set"](#)

8.1.1 Create a Load Set

Use this API to create a Load Set definition, Load Set instance or both.

Name CDR_PUB_DF_LOADSET.CREATELOADSET

Signature

```
PROCEDURE CREATELOADSET(
  P_API_VERSION IN NUMBER,
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
  X_RETURN_STATUS OUT VARCHAR2,
  X_MSG_COUNT OUT NUMBER,
  X_MSG_DATA OUT VARCHAR2,
  PIO_SOURCECDRNAMING IN OUT CDR_NAMING_VERSION_OBJ_TYPE,
  PI_CDRLOADSETOBJTYPE IN CDR_LOAD_SET_OBJ_TYPE,
  PI_CREATEOBJECT IN VARCHAR2,
  PI_INSTANCE_SUBTYPE_ID IN CDR_NAMINGS.OBJECT_SUBTYPE_ID%TYPE,
  PI_DEFCLASSIFICATIONCOLL IN CDR_CLASSIFICATIONS_COLL,
  PI_INSTCLASSIFICATIONCOLL IN CDR_CLASSIFICATIONS_COLL
);
```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

- **PIO_SOURCECDRNAMING** :(Mandatory) This is a parameter of table type CDR_NAMING_VERSIONS_OBJ_TYPE that contains CDR Naming Version attributes.

If you are creating a new definition only or a new definition and an instance of it, enter values for the new definition. If you are creating an instance of an existing definition, enter values to identify the existing definition.

For OBJECT_TYPE_RC enter \$OBJTYPES\$LOADSET if you are creating a definition only; \$OBJTYPES\$LOADSETREF if you are creating an instance of an existing definition; and NULL if you are creating a new definition and an instance of it.

- **PI_CDRLOADSETOBJTYPE** (Mandatory) This is a parameter of table type CDR_LOAD_SET_OBJ_TYPE that contains object attributes specific to Load Sets. Enter values for the Load Set that you want to create.

The following attributes are required: COMPANY_ID, ADAPTER_COMPANY_ID, ADAPTER_OBJ_ID, ADAPTER_OBJ_VER.

- **PI_CREATEOBJECT** (Mandatory) Enter DEFN to create a definition only; INST to create an instance of an existing definition; or BOTH to create a definition and an instance of it
- **PI_INSTANCE_SUBTYPE_ID** (Optional) If you are creating a new instance, enter the subtype ID that you want to give the instance.

If you are creating a definition only, do not enter a value for this parameter.

- **PI_DEFCLASSIFICATIONCOLL** (Optional) By default, the new definition is classified according to the subtype you assigned it in the CDR_NAMING_VERSION_OBJ_TYPE.

If you want to override the default classifications for one or more classification levels, use this parameter. This is a collection of CDR_CLA_OBJ_TYPES, which have 5 attributes, including CLA_LEVEL_ID and CLASSIFICATION_ID.

If you want the definition to inherit its classifications for a particular level from its parent, enter the classification level ID and, for the CLASSIFICATION_ID, enter 0 (zero).

If you want to explicitly assign one or more terms for a particular level, initialize a CDR_CLA_OBJ_TYPE for each term, entering the classification level ID and, for the CLASSIFICATION_ID, the term ID. The PAR_ attributes are not relevant to Load Sets. Do not enter any values for them.

If you are not creating a new definition, do not enter values here.

- **PI_INSTCLASSIFICATIONCOLL** PI_INSTANCE_SUBTYPE_ID. If you want to override the default classifications for one or more classification levels, use this parameter. This is a collection of CDR_CLA_OBJ_TYPES, which have 5 attributes, including CLA_LEVEL_ID and CLASSIFICATION_ID.

If you want the instance to inherit its classifications for a particular level from its parent Work Area, enter the classification level ID and, for the CLASSIFICATION_ID, enter 0 (zero).

If you want to explicitly assign one or more terms for a particular level, initialize a CDR_CLA_OBJ_TYPE for each term, entering the classification level ID and, for the CLASSIFICATION_ID, the term ID. The PAR_ attributes are not relevant to Load Sets. Do not enter any values for them.

If you are not creating a new instance, do not enter values here.

8.1.2 Check Out a Load Set Definition

Use this API to check out a Load Set definition.

Name CDR_PUB_DF_LOADSET.CHECKOUTLOADSET

Signature

```
PROCEDURE CHECKOUTLOADSET(
  P_API_VERSION IN NUMBER,
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
  X_RETURN_STATUS OUT VARCHAR2,
  X_MSG_COUNT OUT NUMBER,
  X_MSG_DATA OUT VARCHAR2,
  PIO_BASEOBJECT IN OUT CDR_BASE_OBJ_TYPE,
  PI_COMMENT IN VARCHAR2,
  PI_ISINSTONLY IN VARCHAR2
);
```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

- **PIO_BASEOBJECT** (Mandatory) This is a parameter of table type CDR_BASE_OBJ_TYPE that contains object attributes. You can enter values to identify either the Load Set definition or an instance of it:
 - Pass the Load Set definition details if you want to check out and subsequently modify only the definition.
 - Pass the details of an instance of the Load Set definition if you want the instance to point to the new version of the Load Set definition.

The following attributes are required: COMPANY_ID,OBJ_ID,OBJ_VER,OBJECT_VERSION_NUMBER,NAMESPACE_OBJ_ID,NAMESPACE_OBJ_VER.

To get the OBJECT_VERSION_NUMBER, enter the following query: select Max(OBJECT_VERSION_NUMBER) from cdr_vl_val_docs_v where OBJ_ID = <objid> and OBJ_VER = <objver> and DOC_STATUS_RC = '\$VALINFOSTATUS\$ACTIVE';

NAMESPACE_OBJ_ID. If you are entering information about the Load Set definition, enter the object ID of its containing Application Area. If you are entering information about the Load Set instance, enter the object ID of its containing Work Area.

NAMESPACE_OBJ_VER. If you are entering information about the Load Set, definition, enter the object version number of its containing Application Area. If you are entering information about the Load Set instance, enter the object version number of its containing Work Area.

- **PI_COMMENT** (Optional) Enter the reason you are checking out the Load Set.
- **PI_ISINSTONLY** Enter \$YESNO\$NO if you are checking out only the definition. Enter \$YESNO\$YES if you are checking out the definition through its instance.

8.1.3 Modify a Load Set

Use this API to modify a Load Set definition or instance. You can change the name, description, or version label.

Note: If you are modifying a definition, you must first check it out.

Name CDR_PUB_DF_LOADSET.MODIFYLOADSET**Signature**

```
PROCEDURE MODIFYLOADSET (
  P_API_VERSION IN NUMBER,
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
  X_RETURN_STATUS OUT VARCHAR2,
  X_MSG_COUNT OUT NUMBER,
  X_MSG_DATA OUT VARCHAR2,
  PIO_CDRNAMING IN OUT CDR_NAMING_VERSION_OBJ_TYPE
);
```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

PIO_CDRNAMING (Mandatory) This is a parameter of table type CDR_NAMING_VERSION_OBJ_TYPE that contains object attributes. Enter values to identify the Load Set and enter new values for the attributes you want to modify. All attributes are required.

8.1.4 Check in a Load Set Definition

Use this API to check in a Load Set definition.

Name CDR_PUB_DF_LOADSET.CHECKINLOADSETDEFINITION**Signature**

```
PROCEDURE CHECKINLOADSETDEFINITION(
  P_API_VERSION IN NUMBER,
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
  X_RETURN_STATUS OUT VARCHAR2,
  X_MSG_COUNT OUT NUMBER,
  X_MSG_DATA OUT VARCHAR2,
  PIO_BASEOBJECT IN OUT CDR_BASE_OBJ_TYPE,
  PI_COMMENT IN VARCHAR2
);
```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

- **PIO_BASEOBJECT** (Mandatory) This is a parameter of table type CDR_BASE_OBJ_TYPE that contains object attributes. Enter values to identify the Load Set definition that you want to check in.

The following attributes are required: COMPANY_ID,OBJ_ID,OBJ_VER,OBJECT_VERSION_NUMBER,NAMESPACE_OBJ_ID,NAMESPACE_OBJ_VER.

- **PI_COMMENT** (Optional) Enter the reason for checking in the Load Set.

8.1.5 Remove a Load Set

Use this API to remove one or more Load Set definitions or instances.

Name CDR_PUB_DF_LOADSET.REMOVELOADSET

Signature

```
PROCEDURE REMOVELOADSET (
  P_API_VERSION IN NUMBER,
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
  X_RETURN_STATUS OUT VARCHAR2,
  X_MSG_COUNT OUT NUMBER,
  X_MSG_DATA OUT VARCHAR2,
  PIO_CDRBASEOBJCOLL IN OUT CDR_BASE_OBJ_COLL
);
```

Parameters This API has standard parameters (see "[Standard Parameters](#)" on page 5) and the following parameter:

PIO_CDRBASEOBJCOLL (Mandatory) This is a collection of CDR_BASE_OBJ_TYPES.

For each Load Set definition or instance that you want to remove, initialize a CDR_BASE_OBJ_TYPE and then extend the collection.

The following attributes are required: COMPANY_ID,OBJ_ID,OBJ_VER,OBJECT_VERSION_NUMBER,NAMESPACE_OBJ_ID,NAMESPACE_OBJ_VER.

Parameter Sets

This is a public interface for operations involving Parameter sets. These APIs provide procedures to create Parameter sets, modify Parameter set details, remove Parameter sets, check in, check out and uncheckout Parameter sets.

9.1 Create and Modify Parameter Sets

This section contains the following topics:

- [Section 9.1.1, "Create a Parameter Set Definition"](#)
- [Section 9.1.2, "Check out a Parameter Set Definition"](#)
- [Section 9.1.3, "Modify a Parameter Set Definition"](#)
- [Section 9.1.4, "Modify a Parameter Set Detail"](#)
- [Section 9.1.5, "Check in a Parameter Set Definition"](#)
- [Section 9.1.6, "Remove a Parameter Set Definition"](#)

9.1.1 Create a Parameter Set Definition

Use this API to create a new Parameter Set definition, a new instance of an existing Parameter Set definition, or a new definition and an instance of it.

Name CDR_PUB_DF_PARAMETER_SET.CREATEPARAMETERSET

Signature

```
PROCEDURE CREATEPARAMETERSET(
  P_API_VERSION IN NUMBER,
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
  X_RETURN_STATUS OUT VARCHAR2,
  X_MSG_COUNT OUT NUMBER,
  X_MSG_DATA OUT VARCHAR2,
  PIO_SOURCECDRNAMING IN OUT CDR_NAMING_VERSION_OBJ_TYPE,
  PI_CDRPSOBJTYPE IN CDR_PARAM_SETS_OBJ_TYPE,
  PI_CREATEOBJECT IN VARCHAR2,
  PI_INSTANCE_SUBTYPE_ID IN CDR_NAMINGS.OBJECT_SUBTYPE_ID%TYPE,
  PI_DEFCLASSIFICATIONCOLL IN CDR_CLASSIFICATIONS_COLL
);
```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

- **PIO_SOURCECDRNAMING** (Mandatory) This is a parameter of table type CDR_NAMING_VERSIONS_OBJ_TYPE that contains CDR Naming Version attributes.

If you are creating a new definition only or a new definition and an instance of it, enter values for the new definition.

If you are creating an instance of an existing definition, enter values to identify the definition. For OBJECT_TYPE_RC enter \$OBJTYPES\$PARAMSET if you are creating a definition only; \$OBJTYPES\$PARAMSETREF if you are creating an instance of an existing definition; and NULL if you are creating a new definition and an instance of it.

- **PI_CDRPSOBJTYPE** (Optional) This is a parameter of table type CDR_PARAM_SETS_OBJ_TYPE that contains object attributes specific to Parameter Sets.

If you are creating a new definition, enter values for the new Parameter Set.

The following attributes are required: COMPANY_ID, USAGE, PR_REF_ID, PR_REF_VER.

If you are creating an instance of an existing Parameter Set, do not enter any values here.

- **PI_CREATEOBJECT** (Mandatory) Enter DEFN to create a definition only; INST to create a instance of an existing definition; or BOTH to create a new definition and an instance of it.
- **PI_INSTANCE_SUBTYPE_ID** (Optional) If you are creating a new instance, enter the ID for the subtype you want to give the instance.

If you are creating a definition only, do not enter a value for this parameter.

- **PI_DEFCLASSIFICATIONCOLL** (Optional) By default, the new definition is classified according to the subtype you assigned it in the CDR_NAMING_VERSION_OBJ_TYPE.

If you want to override the default classifications for one or more classification levels, use this parameter. This is a collection of CDR_CLA_OBJ_TYPES, which have 5 attributes, including CLA_LEVEL_ID and CLASSIFICATION_ID.

If you want the definition to inherit its classifications for a particular level from its parent, enter the classification level ID and, for the CLASSIFICATION_ID, enter 0 (zero).

If you want to explicitly assign one or more terms for a particular level, initialize a CDR_CLA_OBJ_TYPE for each term, entering the classification level ID and, for the CLASSIFICATION_ID, the term ID. The PAR_ attributes are not relevant to Parameter Sets. Do not enter any values for them.

If you are not creating a new definition, do not enter values here.

9.1.2 Check out a Parameter Set Definition

Use this API to check out a Parameter Set definition either directly or through an instance of it.

Name CDR_PUB_DF_PARAMETER_SET.CHECKOUTPARAMETERSET

Signature

```
PROCEDURE CHECKOUTPARAMETERSET(  
    P_API_VERSION IN NUMBER,
```

```

P_INIT_MSG_LIST IN    VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
P_COMMIT IN    VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
P_VALIDATION_LEVEL IN    NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
X_RETURN_STATUS OUT    VARCHAR2,
X_MSG_COUNT OUT    NUMBER,
X_MSG_DATA OUT    VARCHAR2,
PIO_BASEOBJECT IN OUT    CDR_BASE_OBJ_TYPE,
PI_COMMENT IN    VARCHAR2,
PI_ISINSTONLY IN    VARCHAR2
);

```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

- **PIO_BASEOBJECT** (Mandatory) This is a parameter of table type CDR_BASE_OBJ_TYPE that contains object attributes. Enter values to identify the Parameter Set that you want to check out.

If you are checking out the Parameter Set definition directly, enter values to identify the definition.

If you are checking out a Parameter Set definition through an instance of it, enter values to identify the instance.

The following attributes are required: COMPANY_ID,OBJ_ID,OBJ_VER,OBJECT_VERSION_NUMBER,NAMESPACE_OBJ_ID,NAMESPACE_OBJ_VER.

- **PI_COMMENT** (Optional) Enter the reason you are checking out the Parameter Set.
- **PI_ISINSTONLY** (Mandatory) Enter \$YESNO\$NO.

9.1.3 Modify a Parameter Set Definition

Use this API to modify the name or description of a Parameter Set definition.

Name CDR_PUB_DF_PARAMETER_SET.MODIFYPARAMETERSETDEFINITION

Signature

```

PROCEDURE MODIFYPARAMETERSETDEFINITION(
P_API_VERSION IN    NUMBER,
P_INIT_MSG_LIST IN    VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
P_COMMIT IN    VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
P_VALIDATION_LEVEL IN    NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
X_RETURN_STATUS OUT    VARCHAR2,
X_MSG_COUNT OUT    NUMBER,
X_MSG_DATA OUT    VARCHAR2,
PIO_CDRNAMING IN OUT    CDR_NAMING_VERSION_OBJ_TYPE
);

```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameter:

PIO_CDRNAMING (Mandatory) This is a parameter of table type CDR_NAMING_VERSION_OBJ_TYPE that contains object attributes. Enter values to identify the Parameter Set and enter new values for the attributes you want to modify. You can change the name or description.

Note: Use separate APIs for modifying the validation status and the version label: CDR_PUB_VL_VALIDATION.UPDATEVALSTATUS and CDR_PUB_DF_NAMING.UPDATEVERSIONLABEL. All attributes are required.

9.1.4 Modify a Parameter Set Detail

Use this API to modify Parameter Set details.

Name CDR_PUB_DF_PARAMETER_SET.MODIFYPARAMETERSETDETAILS

Signature

```
PROCEDURE MODIFYPARAMETERSETDETAILS(  
  P_API_VERSION IN NUMBER,  
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,  
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,  
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,  
  X_RETURN_STATUS OUT VARCHAR2,  
  X_MSG_COUNT OUT NUMBER,  
  X_MSG_DATA OUT VARCHAR2,  
  PIO_CDRNAMING IN OUT CDR_NAMING_VERSION_OBJ_TYPE  
);
```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameter:

PIO_CDRNAMING Naming details of the parameter set object to be modified.

9.1.5 Check in a Parameter Set Definition

Use this API to check in a Parameter Set definition.

Name CDR_PUB_DF_PARAMETER_SET.CHECKINPARAMETERSETDEFINITION

Signature

```
PROCEDURE CHECKINPARAMETERSETDEFINITION(  
  P_API_VERSION IN NUMBER,  
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,  
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,  
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,  
  X_RETURN_STATUS OUT VARCHAR2,  
  X_MSG_COUNT OUT NUMBER,  
  X_MSG_DATA OUT VARCHAR2,  
  PIO_BASEOBJECT IN OUT CDR_BASE_OBJ_TYPE,  
  PI_COMMENT IN VARCHAR2  
);
```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

- **PIO_BASEOBJECT** (Mandatory) This is a parameter of table type CDR_BASE_OBJ_TYPE that contains object attributes. Enter values to identify the Parameter Set definition that you want to check in.

The following attributes are required: COMPANY_ID,OBJ_ID,OBJ_VER,OBJECT_VERSION_NUMBER,NAMESPACE_OBJ_ID,NAMESPACE_OBJ_VER.

- **PI_COMMENT** (Optional) Enter the reason you are checking in the Parameter Set.

9.1.6 Remove a Parameter Set Definition

Use this API to remove one or more Parameter Set definitions or instances.

Name CDR_PUB_DF_PARAMETER_SET.REMOVEPARAMETERSET

Signature

```
PROCEDURE REMOVEPARAMETERSET(
  P_API_VERSION IN NUMBER,
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
  X_RETURN_STATUS OUT VARCHAR2,
  X_MSG_COUNT OUT NUMBER,
  X_MSG_DATA OUT VARCHAR2,
  PIO_CDRBASEOBJCOLL IN OUT CDR_BASE_OBJ_COLL
);
```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameter:

PIO_CDRBASEOBJCOLL (Mandatory) This is a collection of CDR_BASE_OBJ_TYPES.

For each Parameter Set that you want to remove, initialize a CDR_BASE_OBJ_TYPE and then extend the collection.

The following attributes are required: COMPANY_ID,OBJ_ID,OBJ_VER,OBJECT_VERSION_NUMBER,NAMESPACE_OBJ_ID,NAMESPACE_OBJ_VER.

Planned Outputs

This is a public interface for all Planned Output related functions including creating, modifying, removing, and copying Planned Outputs.

10.1 Create and Modify Planned Outputs

This section contains the following topics:

- [Section 10.1.1, "Create a Planned Output"](#)
- [Section 10.1.2, "Get a New Position Number"](#)
- [Section 10.1.3, "Get a Planned Output Object"](#)
- [Section 10.1.4, "Modify a Planned Output"](#)
- [Section 10.1.5, "Identify whether a SAS Object"](#)
- [Section 10.1.6, "Remove a Planned Output Object"](#)

10.1.1 Create a Planned Output

Use this API to create a Planned Output.

Name CDR_PUB_DF_PLANNED_OUTPUT.CREATEPLANNEDOUTPUT

Signature

```
PROCEDURE CREATEPLANNEDOUTPUT(
  P_API_VERSION IN NUMBER,
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
  X_RETURN_STATUS OUT VARCHAR2,
  X_MSG_COUNT OUT NUMBER,
  X_MSG_DATA OUT VARCHAR2,
  PIO_SOURCECDRNAMING IN OUT CDR_NAMING_VERSION_OBJ_TYPE,
  PI_PLANNEDOUTPUTOBJTYPE IN OUT CDR_PLANNEDOUTPUT_OBJ_TYPE,
  PI_DEFCLASSIFICATIONCOLL IN CDR_CLASSIFICATIONS_COLL
);
```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

- **PIO_SOURCECDRNAMING** (Mandatory) This is a parameter of type CDR_NAMING_VERSIONS_OBJ_TYPE.

The following attributes are required: COMPANY_ID, OBJECT_TYPE_RC, NAME, NAMESPACE_OBJ_ID, NAMESPACE_OBJ_VER, OWNING_LOCATION_RC, OBJECT_SUBTYPE_ID, DESCRIPTION, REF_COMPANY_ID, REF_OBJ_ID, REF_OBJ_VER.

For OBJECT_TYPE_RC enter \$OBJTYPES\$PLANNEDOUT.

- **PI_PLANNEDOUTPUTOBJTYPE** (Mandatory) This is a parameter of table type CDR_PLANNEDOUTPUT_OBJ_TYPE.

You need to pass the following attributes: COMPANY_ID, OBJ_ID, OBJ_VER, TITLE, POSITION, FILEREF, FILE_NAME, PRIMARY_FLAG_RC, ERROR_FILE_FLAG_RC, REQ_FILE_FLAG_RC.

For the POSITION attribute, use the GETNEWPOSITIONNUMBER API.

- **PI_DEFCLASSIFICATIONCOLL** (Optional) By default the new PLANNED OUTPUT is classified according to the subtype you assigned it in the CDR_NAMING_VERSION_OBJ_TYPE.

If you want to override the default classifications for one or more classification levels, use this parameter. This is a collection of CDR_CLA_OBJ_TYPES, which have 5 attributes, including CLA_LEVEL_ID and CLASSIFICATION_ID.

If you want the definition to inherit its classifications for a particular level from its parent, enter the classification level ID and, for the CLASSIFICATION_ID, enter 0 (zero).

If you want to explicitly assign one or more terms for a particular level, initialize a CDR_CLA_OBJ_TYPE for each term, entering the classification level ID and, for the CLASSIFICATION_ID, the term ID.

If you want to use a Parameter to classify the actual output, use the PAR attributes to identify the Parameter. The Parameter's list of values must be based on a classification hierarchy level.

10.1.2 Get a New Position Number

Use this API to get a unique position number for a Planned Output within a parent object. This API is used from within the CREATEPLANNEDOUTPUT API, which is used to create a new Planned Output. You can also reorder Planned Outputs using this API.

Name CDR_PUB_DF_PLANNED_OUTPUT.GETNEWPOSITIONNUMBER

Signature

```
FUNCTION GETNEWPOSITIONNUMBER(
  P_API_VERSION IN NUMBER,
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
  PI_NCOMPANYID IN CDR_NAMINGS.COMPANY_ID%TYPE,
  PI_NOBJID IN CDR_NAMINGS.OBJ_ID%TYPE,
  PI_NOBJVER IN CDR_NAMING_VERSIONS.OBJ_VER%TYPE
) RETURN NUMBER;
```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

- **PI_NCOMPANYID** (Mandatory) Enter the COMPANY_ID of the parent object.

- **PI_NOBJID** (Mandatory) Enter the OBJ_ID of the parent object.
- **PI_NOBJVER** (Mandatory) Enter the OBJ_VER of the parent object.

10.1.3 Get a Planned Output Object

Use this API to retrieve a Planned Output object for an LSH object.

Name CDR_PUB_DF_PLANNED_OUTPUT.GETPLANNEDOUTPUTOBJECT

Signature

```
FUNCTION GETPLANNEDOUTPUTOBJECT (
  P_API_VERSION IN NUMBER,
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
  PI_NCOMPANYID IN CDR_NAMINGS.COMPANY_ID%TYPE,
  PI_NOBJID IN CDR_NAMINGS.OBJ_ID%TYPE,
  PI_NOBJVER IN CDR_NAMING_VERSIONS.OBJ_VER%TYPE,
  PO_PLANNEDOUTPUT OUT CDR_PLANNEDOUTPUT_OBJ_TYPE
) RETURN BOOLEAN;
```

Return Type BOOLEAN

Description

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

- **PI_NCOMPANYID** (Mandatory) Enter your company ID. To get your company ID, use CDR_DF_PUB_DEF_CONSTANTS.CURRENT_COMPANY_ID.
- **PI_NOBJID** (Mandatory) Enter the OBJ_ID value of the object for which you want to retrieve the Planned Output object.
- **PI_NOBJVER** (Mandatory) Enter the OBJ_VER value of the object for which you want to retrieve the Planned Output's object.
- **PO_PLANNEDOUTPUT** This is the output parameter of the API returning the Planned Output Object.

10.1.4 Modify a Planned Output

Use this API to modify an existing Planned Output.

Name CDR_PUB_DF_PLANNED_OUTPUT.MODIFYPLANNEDOUTPUT

Signature

```
PROCEDURE MODIFYPLANNEDOUTPUT (
  P_API_VERSION IN NUMBER,
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
  X_RETURN_STATUS OUT VARCHAR2,
  X_MSG_COUNT OUT NUMBER,
  X_MSG_DATA OUT VARCHAR2,
  PI_SOURCECDRNAMING IN OUT CDR_NAMING_VERSION_OBJ_TYPE,
  PI_POUTOBJTYPE IN OUT CDR_PLANNEDOUTPUT_OBJ_TYPE
);
```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

- **PI_SOURCECDRNAMING** (Mandatory) This is a parameter of table type CDR_NAMING_VERSION_OBJ_TYPE that contains object attributes. Enter values to identify the Planned Output.
- **PI_POUTOBJTYPE** (Mandatory) This is a parameter of table type CDR_PLANNEDOUTPUT_OBJ_TYPE that contains attributes specific to Planned Outputs. Enter values for the Planned Output and enter new values for the attributes you want to modify. You can change the name or description of a Planned Output.

Note: Use separate APIs for modifying the validation status and the version label: CDR_PUB_VL_VALIDATION.UPDATE VAL STATUS and CDR_PUB_DF_NAMING.UPDATEVERSIONLABEL.

10.1.5 Identify whether a SAS Object

Use this API to check if the parent object of the Planned Output is a SAS object. SAS objects are: SAS programs, SAS load Sets, SAS Tables.

Name CDR_PUB_DF_PLANNED_OUTPUT.ISSASOBJECT

Signature

```
FUNCTION ISSASOBJECT(
  P_API_VERSION IN      NUMBER,
  P_INIT_MSG_LIST IN    VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN         VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN  NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
  PI_NCOMPANYID IN     CDR_NAMINGS.COMPANY_ID%TYPE,
  PI_NOBJID IN        CDR_NAMINGS.OBJ_ID%TYPE,
  PI_NOBJVER IN       CDR_NAMING_VERSIONS.OBJ_VER%TYPE,
  PI_NSOBJTYPE IN     CDR_NAMINGS.OBJECT_TYPE_RC%TYPE
) RETURN VARCHAR2;
```

Return Type VARCHAR2

Description

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

- **PI_NCOMPANYID** (Mandatory) Enter your company ID.
To get your company ID, use CDR_PUB_DEF_FACTORY_UTILS.GetCompanyId.
- **PI_NOBJID** (Mandatory) Enter the object ID of the Planned Output's parent object.
- **PI_NOBJVER** (Mandatory) Enter the version number of the Planned Output's parent object.
- **PI_NSOBJTYPE** (Mandatory) Enter the OBJ_TYPE value for the Planned Output's parent object.

10.1.6 Remove a Planned Output Object

Use this API to delete one or more Planned Outputs.

Name CDR_PUB_DF_PLANNED_OUTPUT.IREMOVEPLANNEDOUTPUT

Signature

```
PROCEDURE REMOVEPLANNEDOUTPUT(
  P_API_VERSION IN NUMBER,
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
  X_RETURN_STATUS OUT VARCHAR2,
  X_MSG_COUNT OUT NUMBER,
  X_MSG_DATA OUT VARCHAR2,
  PIO_CDRBASEOBJCOLL IN OUT CDR_BASE_OBJ_COLL,
  PI_GETLOCK IN VARCHAR := 'T'
);
```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

- **PIO_CDRBASEOBJCOLL** (Mandatory) This is a collection of CDR_BASE_OBJ_TYPES.

For each Planned Output that you want to remove, initialize a CDR_BASE_OBJ_TYPE and then extend the collection.

The following attributes are required: COMPANY_ID,OBJ_ID,OBJ_VER,OBJECT_VERSION_NUMBER,NAMESPACE_OBJ_ID,NAMESPACE_OBJ_VER.

- **PI_GETLOCK** (Optional) Do not enter a value for this attribute. The default and only acceptable value is 'T'.

This is a public interface for Program-related functions, including creating, modifying, and removing Programs. It also includes functions for checking Programs in and out, and undoing a Program checkout.

11.1 Create and Modify Programs

This section contains the following topics:

- [Section 11.1.1, "Create a Program"](#)
- [Section 11.1.2, "Copy Objects Into a Program"](#)
- [Section 11.1.3, "Modify a Program"](#)
- [Section 11.1.4, "Check In a Program Definition"](#)
- [Section 11.1.5, "Check Out a Program Definition"](#)
- [Section 11.1.6, "Remove a Program"](#)
- [Section 11.1.7, "Create a Planned Output for a Log File"](#)
- [Section 11.1.8, "Assign a Planned Output"](#)
- [Section 11.1.9, "Modify a Manual Validation Flag Value"](#)

11.1.1 Create a Program

Use this API to create a new Program definition, a new instance of an existing Program definition, or a new definition and an instance of it.

Name CDR_PUB_DF_PROGRAM.CREATEPROGRAM

Signature

```
PROCEDURE CREATEPROGRAM(
  P_API_VERSION IN NUMBER,
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
  X_RETURN_STATUS OUT VARCHAR2,
  X_MSG_COUNT OUT NUMBER,
  X_MSG_DATA OUT VARCHAR2,
  PIO_SOURCECDRNAMING IN OUT CDR_NAMING_VERSION_OBJ_TYPE,
  PI_CDRPRGOBJTYPE IN CDR_PROGRAM_OBJ_TYPE,
  PI_CREATEOBJECT IN VARCHAR2,
  PI_INSTANCE_SUBTYPE_ID IN CDR_NAMINGS.OBJECT_SUBTYPE_ID%TYPE,
```

```
PI_DEFCLASSIFICATIONCOLL IN CDR_CLASSIFICATIONS_COLL,  
PI_INSTCLASSIFICATIONCOLL IN CDR_CLASSIFICATIONS_COLL  
);
```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

- **PIO_SOURCECDRNAMING** (Mandatory) This is a parameter of table type CDR_NAMING_VERSIONS_OBJ_TYPE that contains CDR Naming Version attributes.

If you are creating a new definition only or a new definition and an instance of it, enter values for the new definition.

If you are creating an instance of an existing definition, enter values to identify the definition.

The required attributes are: OBJECT_TYPE_RC, NAME, NAMESPACE_OBJ_ID, NAMESPACE_OBJ_VER, NAMESPACE_START_OBJ_VER, NAMESPACE_END_OBJ_VER, OWNING_LOCATION_RC, OBJECT_SUBTYPE_ID.

For OBJECT_TYPE_RC enter \$OBJTYPES\$PROGRAM if you are creating a definition only; \$OBJTYPES\$PROGRAMINST if you are creating an instance of an existing definition; and NULL if you are creating a new definition and an instance of it.

- **PI_CDRPRGOBJTYPE** (Optional) This is a parameter of table type CDR_DATA_MART_OBJ_TYPE that contains object attributes specific to Programs.

If you are creating a new definition, enter values for the new Program. The following attributes are required: CDR_PROGRAM_OBJ_TYPE, TECH_TYPE_ID.

If you are creating an instance of an existing Program, do not enter any values here.

- **PI_CREATEOBJECT** (Mandatory) Enter DEFN to create a definition only; INST to create a instance of an existing definition; or BOTH to create a new definition and an instance of it.
- **PI_INSTANCE_SUBTYPE_ID** (Optional) If you are creating a new instance, enter the ID for the subtype you want to give the instance.

If you are creating a definition only, do not enter a value for this parameter. Definition and Instance are to be created in the same call.

- **PI_DEFCLASSIFICATIONCOLL** (Optional) By default the new definition is classified according to the subtype you assigned it in the CDR_NAMING_VERSION_OBJ_TYPE.

If you want to override the default classifications for one or more classification levels, use this parameter. This is a collection of CDR_CLA_OBJ_TYPES, which have five attributes, including CLA_LEVEL_ID and CLASSIFICATION_ID.

If you want the definition to inherit its classifications for a particular level from its parent, enter the classification level ID and, for the CLASSIFICATION_ID, enter 0 (zero).

If you want to explicitly assign one or more terms for a particular level, initialize a CDR_CLA_OBJ_TYPE for each term, entering the classification level ID and, for the CLASSIFICATION_ID, the term ID. Do not enter any values for them.

If you are not creating a new definition, do not enter values here.

- **PI_INSTCLASSIFICATIONCOLL** (Optional) By default the new instance is classified according to the subtype you assigned it in the CDR_NAMING_VERSION_OBJ_TYPE.

If you want to override the default classifications for one or more classification levels, use this parameter. This is a collection of CDR_CLA_OBJ_TYPES, which have 5 attributes, including CLA_LEVEL_ID and CLASSIFICATION_ID.

If you want the instance to inherit its classifications for a particular level from its parent Work Area, enter the classification level ID and, for the CLASSIFICATION_ID, enter 0 (zero).

If you want to explicitly assign one or more terms for a particular level, initialize a CDR_CLA_OBJ_TYPE for each term, entering the classification level ID and, for the CLASSIFICATION_ID, the term ID. The PAR_ attributes are not relevant to Programs. Do not enter any values for them.

If you are not creating a new instance, do not enter values here.

11.1.2 Copy Objects Into a Program

Use this API to copy objects into a Program.

Name CDR_PUB_DF_PROGRAM.COPYOBJECTINTOPROGRAM

Signature

```
PROCEDURE COPYOBJECTINTOPROGRAM(
  P_API_VERSION IN NUMBER,
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
  X_RETURN_STATUS OUT VARCHAR2,
  X_MSG_COUNT OUT NUMBER,
  X_MSG_DATA OUT VARCHAR2,
  PI_CDRBASEOBJCOLL IN CDR_BASE_OBJ_COLL,
  PI_CDRTARGETCONTAINEROBJECT IN OUT CDR_BASE_OBJ_TYPE,
  PI_CHECKINFLAG IN VARCHAR2
);
```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

- **PI_CDRBASEOBJCOLL** Collection of objects to be copied.
- **PI_CDRTARGETCONTAINEROBJECT** The target container object.
- **PI_CHECKINFLAG** Flag to indicate if the copied objects are to be checked in.

11.1.3 Modify a Program

Use this API to modify a Program definition or instance. You can modify the name and description.

If you are modifying an instance object, you can also change the 3 REF attribute values to select a different source definition.

Note: Note: If you are modifying a definition, you must first check it out.

Name CDR_PUB_DF_PROGRAM.MODIFYPROGRAMDETAILS

Signature

```
PROCEDURE MODIFYPROGRAMDETAILS(  
  P_API_VERSION IN NUMBER,  
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,  
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,  
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,  
  X_RETURN_STATUS OUT VARCHAR2,  
  X_MSG_COUNT OUT NUMBER,  
  X_MSG_DATA OUT VARCHAR2,  
  PIO_CDRNAMING IN OUT CDR_NAMING_VERSION_OBJ_TYPE  
);
```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameter:

PIO_CDRNAMING (Mandatory) This is an IN OUT parameter of table type CDR_NAMING_VERSIONS_OBJ_TYPE that contains CDR Naming Version attributes.

11.1.4 Check In a Program Definition

Use this API to check in a Program definition.

Name CDR_PUB_DF_PROGRAM.CHECKINPROGRAMDEFINITION

Signature

```
PROCEDURE CHECKINPROGRAMDEFINITION(  
  P_API_VERSION IN NUMBER,  
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,  
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,  
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,  
  X_RETURN_STATUS OUT VARCHAR2,  
  X_MSG_COUNT OUT NUMBER,  
  X_MSG_DATA OUT VARCHAR2,  
  PIO_BASEOBJECT IN OUT CDR_BASE_OBJ_TYPE,  
  PI_COMMENT IN VARCHAR2  
);
```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

- **PIO_BASEOBJECT** (Mandatory) This is a parameter of table type CDR_BASE_OBJ_TYPE that contains object attributes. Enter values to identify the Program definition that you want to check in.

The following attributes are required: COMPANY_ID,OBJ_ID,OBJ_VER,OBJECT_VERSION_NUMBER,NAMESPACE_OBJ_ID,NAMESPACE_OBJ_VER.

- **PI_COMMENT** (Optional) Enter the reason you are checking in the Program.

11.1.5 Check Out a Program Definition

Use this API to check out a Program definition either directly or through an instance of it.

Name CDR_PUB_DF_PROGRAM.CHECKOUTPROGRAM

Signature

```

PROCEDURE CHECKOUTPROGRAM(
  P_API_VERSION IN NUMBER,
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
  X_RETURN_STATUS OUT VARCHAR2,
  X_MSG_COUNT OUT NUMBER,
  X_MSG_DATA OUT VARCHAR2,
  PIO_BASEOBJECT IN OUT CDR_BASE_OBJ_TYPE,
  PI_COMMENT IN VARCHAR2,
  PI_ISINSTONLY IN VARCHAR2
);

```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

- **PIO_BASEOBJECT** (Mandatory) This is a parameter of table type CDR_BASE_OBJ_TYPE that contains object attributes. Enter values to identify the Program that you want to check out.

If you are checking out the Program definition directly, enter values to identify the definition.

If you are checking out a Program definition through an instance of it, enter values to identify the instance.

The following attributes are required: COMPANY_ID,OBJ_ID,OBJ_VER,OBJECT_VERSION_NUMBER,NAMESPACE_OBJ_ID,NAMESPACE_OBJ_VER.

- **PI_COMMENT** (Optional) Enter the reason you are checking out the Program.
- **PI_ISINSTONLY** Enter \$YESNO\$NO.

11.1.6 Remove a Program

Use this API to remove one or more Program definitions or instances.

Name CDR_PUB_DF_PROGRAM.REMOVEPROGRAM

Signature

```

PROCEDURE REMOVEPROGRAM(
  P_API_VERSION IN NUMBER,
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
  X_RETURN_STATUS OUT VARCHAR2,
  X_MSG_COUNT OUT NUMBER,
  X_MSG_DATA OUT VARCHAR2,
  PIO_CDRBASEOBJCOLL IN OUT CDR_BASE_OBJ_COLL
);

```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameter:

PIO_CDRBASEOBJCOLL (Mandatory) This is a collection of CDR_BASE_OBJ_TYPES. For each Program that you want to remove, initialize a CDR_BASE_OBJ_TYPE and then extend the collection.

The following attributes are required: COMPANY_ID,OBJ_ID,OBJ_VER,OBJECT_VERSION_NUMBER,NAMESPACE_OBJ_ID,NAMESPACE_OBJ_VER.

11.1.7 Create a Planned Output for a Log File

Use this API to create a log file Planned Output for a Program.

Note: You must define a log file Planned Output, which is part of the Program definition, through an instance of the Program.

Name CDR_PUB_DF_PROGRAM.CREATELOGFILEPLANNEDOUTPUT

Signature

```
PROCEDURE CREATELOGFILEPLANNEDOUTPUT (
  P_API_VERSION IN NUMBER,
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
  X_RETURN_STATUS OUT VARCHAR2,
  X_MSG_COUNT OUT NUMBER,
  X_MSG_DATA OUT VARCHAR2,
  PIO_SOURCECODENAMING IN OUT CDR_NAMING_VERSION_OBJ_TYPE
);
```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameter:

PIO_SOURCECODENAMING (Mandatory) This is a parameter of type cdr_naming_version_obj_type that contains object attributes.

The required attributes are: COMPANY_ID,NAME,NAMESPACE_OBJ_ID,NAMESPACE_OBJ_VER.

11.1.8 Assign a Planned Output

Use this API to assign a Planned Output to a Report Set Entry (RSE). If the Planned Output is already assigned to a different RSE, you must identify that RSE. This API then unassigns the Planned Output from the original RSE and reassigns it to the RSE you specify.

Name CDR_PUB_DF_PROGRAM.ASSIGNPIANDPOTORSENTRY

Signature

```
PROCEDURE ASSIGNPIANDPOTORSENTRY (
  P_API_VERSION IN NUMBER,
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
  X_RETURN_STATUS OUT VARCHAR2,
  X_MSG_COUNT OUT NUMBER,
  X_MSG_DATA OUT VARCHAR2,
  PI_RSECOMPANYID IN CDR_NAMINGS.COMPANY_ID%TYPE,
  PI_RSEOBJID IN CDR_NAMINGS.OBJ_ID%TYPE,
  PI_RSEOBJVER IN CDR_NAMING_VERSIONS.OBJ_VER%TYPE,
  PI_PIOBJID IN CDR_NAMINGS.OBJ_ID%TYPE,
  PI_POCOMPANYID IN CDR_NAMINGS.COMPANY_ID%TYPE,
```

```

PI_POOBJID IN CDR_NAMINGS.OBJ_ID%TYPE,
PI_ASGRSEOBJID IN CDR_NAMINGS.OBJ_ID%TYPE,
PI_ASGRSEOBJVER IN CDR_NAMING_VERSIONS.OBJ_VER%TYPE
);

```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

- **PI_RSECOMPANYID** (Mandatory) Enter the Company ID of the Report Set Entry to which you want to assign the Planned Output. To get your company ID, use CDR_DF_PUB_DEF_CONSTANTS.Current_Company_ID.
- **PI_RSEOBJID** (Mandatory) Enter the object ID of the Report Set Entry to which you want to assign the Planned Output.
- **PI_RSEOBJVER** (Mandatory) Enter the object version of the Report Set Entry to which you want to assign the Planned Output.
- **PI_PIOBJID** (Mandatory) Enter the object ID of the Program instance to which the Planned Output belongs.
- **PI_POCOMPANYID** (Mandatory) Enter the Company ID of the Planned Output.
- **PI_POOBJID** (Mandatory) Enter the object ID of the Planned Output.
- **PI_ASGRSEOBJID** (Optional) If the Planned Output is already assigned to another RSE, enter the object ID of the other Report Set Entry.
- **PI_ASGRSEOBJVER** (Optional) If the Planned Output is already assigned to another RSE, enter the object version of the other Report Set Entry.

11.1.9 Modify a Manual Validation Flag Value

Use this API to change the value of the Program's manual validation (Force Validation Status to Development) flag.

Name CDR_PUB_DF_PROGRAM.MODIFYPROGRAMDETAILS

Signature

```

PROCEDURE MODIFYPROGRAMDETAILS (
  P_API_VERSION IN NUMBER,
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
  X_RETURN_STATUS OUT VARCHAR2,
  X_MSG_COUNT OUT NUMBER,
  X_MSG_DATA OUT VARCHAR2,
  PIO_CDRNAMING IN OUT CDR_NAMING_VERSION_OBJ_TYPE,
  PI_PROGRAMOBJTYPE IN OUT CDR_PROGRAM_OBJ_TYPE
);

```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

- **PIO_CDRNAMING** (Mandatory) This is a parameter of table type CDR_NAMING_VERSION_OBJ_TYPE that contains object attributes. Enter values to identify the Program definition whose flag value you want to change.

The following attributes are required: OBJ_ID, OBJ_VER, COMPANY_ID, NS_OBJ_ID, NS_OBJ_VER.

- **PI_PROGRAMOBJTYPE** (Mandatory) This is a parameter of table type CDR_PROGRAM_OBJ_TYPE that contains Program definition attributes.

The required attributes are OBJ_ID, OBJ_VER, COMPANY_ID. Enter values to identify the Program definition whose flag value you want to change and enter the new flag value in the attribute MANUAL_VALIDATION_FLAG_RC. Enter \$yesno\$yes for yes, and \$yesno\$no for no.

This section contains the following topics:

- [Section 12.1, "Create and Modify Report Set Entries"](#)
- [Section 12.2, "Create and Modify Report Sets"](#)
- [Section 12.3, "Create and Modify Overlay Template Definitions"](#)
- [Section 12.4, "Report Set Overlay Template"](#)

12.1 Create and Modify Report Set Entries

This is a public interface for Report Set Entry-related operations, including creating, modifying, and removing Report Set Entries, getting information about the Report Set and Report Set Entries, and changing the Report Set structure.

This section contains the following topics:

- [Section 12.1.1, "Create a Report Set Entry"](#)
- [Section 12.1.2, "Add and Modify an Entry"](#)
- [Section 12.1.3, "Copy a Report Set Entry into Another"](#)
- [Section 12.1.4, "Modify a Report Set Entry"](#)
- [Section 12.1.5, "Move a Report Set Entry into Another"](#)
- [Section 12.1.6, "Reorder Report Set Entries in a Parent Report Set"](#)
- [Section 12.1.7, "Find if a Report Set is Checked Out"](#)
- [Section 12.1.8, "Check Unique and Strict Numbering in a Report Set"](#)
- [Section 12.1.9, "Identify if a Report Set Contains Child Entries"](#)
- [Section 12.1.10, "Find if a User has Modify Permission"](#)
- [Section 12.1.11, "Remove an Object from a Report Set Entry"](#)
- [Section 12.1.12, "Remove a Report Set Entry"](#)
- [Section 12.1.13, "Get a Report Set Name"](#)
- [Section 12.1.14, "Get a Title"](#)
- [Section 12.1.15, "Get a Chapter Number"](#)
- [Section 12.1.16, "Get a Parent Number"](#)
- [Section 12.1.17, "Get a List of Report Set Entry Titles"](#)
- [Section 12.1.18, "Get All RSE Titles in a Report Set"](#)

- [Section 12.1.19, "Get Attribute Values Derived from a Parent"](#)
- [Section 12.1.20, "Get the Lowest Entry Number"](#)
- [Section 12.1.21, "Get the Total Number of Report Set Entries"](#)
- [Section 12.1.22, "Create a Narrative"](#)
- [Section 12.1.23, "Update a Narrative"](#)
- [Section 12.1.24, "Delete a Narrative"](#)
- [Section 12.1.25, "Check if Copying Retains Valid Numbering in a Target Report Set"](#)
- [Section 12.1.26, "Check if a Move Retains Valid Numbering in a Target Report Set"](#)
- [Section 12.1.28, "Check if Removal Retains Valid Numbering in a Parent Report Set"](#)
- [Section 12.1.28, "Check if Removal Retains Valid Numbering in a Parent Report Set"](#)
- [Section 12.1.29, "Check if Reordering Retains Valid Numbering in a Parent Report Set"](#)
- [Section 12.1.30, "Unassign a Planned Output"](#)

12.1.1 Create a Report Set Entry

Use this API to create a Report Set Entry within a Report Set or another Report Set Entry.

Name CDR_PUB_RS_REPORT_SET_ENTRY.CREATEREPORTSETENTRY

Signature

```
PROCEDURE CREATEREPORTSETENTRY(  
  P_API_VERSION IN NUMBER,  
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,  
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,  
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,  
  X_RETURN_STATUS OUT VARCHAR2,  
  X_MSG_COUNT OUT NUMBER,  
  X_MSG_DATA OUT VARCHAR2,  
  PIO_SOURCECDRNAMING IN OUT CDR_NAMING_VERSION_OBJ_TYPE,  
  PI_CDRRSENTRY IN OUT CDR_RS_ENTRY_OBJ_TYPE  
);
```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

- **PIO_SOURCECDRNAMING** (Mandatory) This is a parameter of table type CDR_NAMING_VERSION_OBJ_TYPE that contains object attributes. Enter values for the new Report Set Entry. Use the NAMESPACE attributes to identify the Report Set or Report Set Entry in which you want to create the new Report Set Entry. For OBJECT_TYPE_RC enter \$OBJTYPES\$REPORTSETENTRY.

The following attributes are required: COMPANY_ID, NAME, NAMESPACE_OBJ_ID, NAMESPACE_OBJ_VER.

- **PI_CDRRSENTRY** (Mandatory) This is a parameter of table type CDR_RS_ENTRY_OBJ_TYPE that contains attributes specific to Report Set Entries. Enter values for the new Report Set Entry.

The following attributes are required: COMPANY_ID,OBJ_ID,OBJ_VER,ENTRY_NUMBER,POSITION,UNIQUE_NUMBERING_FLAG_RC,STRICT_NUMBERING_FLAG_RC,PRE_NARRATIVE_ID,POST_NARRATIVE_ID, OMIT_FROM_INSTALL_FLAG_RC,TITLE,DELIMITER,PREFIX,POSTFIX,PLACEHOLDER_FLAG_RC, VOLUME_BREAK_FLAG_RC,PI_OBJ_ID,PO_COMPANY_ID,PO_OBJ_ID,ENTRY_NUMBER_FLAG_RC,PARENT_FLAG_RC,PREFIX_FLAG_RC,POSTFIX_FLAG_RC,DELIMITER_FLAG_RC.

12.1.2 Add and Modify an Entry

Use this API to add and/or modify one or more Report Set Entries within the same parent Report Set Entry or Report Set definition. For a new RSE to be added, the user can use any number for the OBJ_ID and OBJ_VER like 0 and a positive number.

Name CDR_PUB_RS_REPORT_SET_ENTRY.ADDNEWANDMODIFYENTRIES

Signature

```
PROCEDURE ADDNEWANDMODIFYENTRIES (
  P_API_VERSION IN NUMBER,
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
  X_RETURN_STATUS OUT VARCHAR2,
  X_MSG_COUNT OUT NUMBER,
  X_MSG_DATA OUT VARCHAR2,
  PI_CDRRSENAMEENTRYCOLL IN OUT CDR_RS_ENTRY_NAME_COLL,
  PIO_CDRRSECOLL IN OUT CDR_RS_ENTRY_COLL,
  COMPANYID IN CDR_NAMING_VERSIONS.COMPANY_ID%TYPE,
  NSOBJID IN CDR_NAMINGS.NAMESPACE_OBJ_ID%TYPE,
  NSOBJVER IN CDR_NAMING_VERSIONS.OBJ_VER%TYPE,
  OBJSUBTYPEID IN CDR_NAMINGS.OBJECT_SUBTYPE_ID%TYPE
);
```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

- **PI_CDRRSENAMEENTRYCOLL** (Mandatory) This is a collection of CDR_RS_ENTRY_NAME_OBJS. For each Report Set Entry that you want to modify or add, initialize a CDR_RS_ENTRY_NAME_OBJ and then extend the collection.

If you are modifying an RSE, enter its existing values.

If you are creating a new RSE, enter 1 for OBJ_VER and enter a number for the OBJ_ID (it must be unique within the collection). The following attributes are required: NAME,ENTRY_NUMBER,OBJ_ID,OBJ_VER.

- **PIO_CDRRSECOLL** (Mandatory) This is a collection of CDR_RS_ENTRY_OBJ_TYPES. For each Report Set Entry that you want to modify or add, initialize a CDR_RS_ENTRY_OBJ_TYPE (with new values for the attributes you want to change, if you are modifying existing Entries) and then extend the collection.

The following attributes are required: COMPANY_ID,OBJ_ID,OBJ_VER,ENTRY_NUMBER,POSITION,UNIQUE_NUMBERING_FLAG_RC,STRICT_NUMBERING_FLAG_RC,PRE_NARRATIVE_ID,POST_NARRATIVE_ID, OMIT_FROM_INSTALL_FLAG_RC, TITLE, DELIMITER, PREFIX, POSTFIX, PLACEHOLDER_FLAG_RC, VOLUME_BREAK_FLAG_RC,PI_OBJ_ID,PO_COMPANY_ID,PO_OBJ_ID,ENTRY_NUMBER_FLAG_RC,PARENT_FLAG_RC,PREFIX_FLAG_RC,POSTFIX_FLAG_RC,DELIMITER_FLAG_RC.

Note: You must enter an single integer Entry Number for each Report Set Entry. The API does not create entry numbers for you, but it does enforce the unique and strict numbering settings for the Report Set or Report Set Entry

- **COMPANYID** (Mandatory) Enter your COMPANY_ID.
- **NSOBJID** (Mandatory) Enter the OBJ_ID of the Report Set or Report Set Entry within which you want to add or modify Report Set Entries.
- **NSOBJVER** (Mandatory) Enter the OBJ_VER of the Report Set or Report Set Entry within which you want to add or modify Report Set Entries.
- **OBJSUBTYPEID** (Optional) If you are adding or modifying top-level Report Set Entries, enter the subtype ID of the Report Set.

If you are adding or modifying Report Set Entries contained in another Report Set Entry, leave this parameter null.

12.1.3 Copy a Report Set Entry into Another

Use this procedure to copy one or more Report Set Entries into another Report Set Entry. The target Report Set Entry may or may not belong to the same Report Set hierarchy.

Name CDR_PUB_RS_REPORT_SET_ENTRY.COPYOBJECTSINTOREPORTSETENTRY

Signature

```
PROCEDURE COPYOBJECTSINTOREPORTSETENTRY(
  P_API_VERSION IN NUMBER,
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
  X_RETURN_STATUS OUT VARCHAR2,
  X_MSG_COUNT OUT NUMBER,
  X_MSG_DATA OUT VARCHAR2,
  PIO_CDRBASEOBJCOLL IN OUT CDR_BASE_OBJ_COLL,
  PIO_TARGETBASEOBJ IN OUT CDR_BASE_OBJ_TYPE,
  RENUMBER IN VARCHAR2,
  PI_COPYPRGASSGNMT IN VARCHAR2
);
```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

- **PIO_CDRBASEOBJCOLL** (Mandatory) This is a collection of CDR_BASE_OBJ_TYPES.

For each Report Set Entry that you want to copy into another Report Set Entry, initialize a CDR_BASE_OBJ_TYPE and then extend the collection.

The following attributes are required: COMPANY_ID,OBJ_ID,OBJ_VER,OBJECT_VERSION_NUMBER,NAMESPACE_OBJ_ID,NAMESPACE_OBJ_VER.

- **PIO_TARGETBASEOBJ** (Mandatory) This is a parameter of table type CDR_BASE_OBJ_TYPE that contains object attributes. Enter values to identify the Report Set Entry into which you want to copy other Report Set Entries.

The following attributes are required: COMPANY_ID,OBJ_ID,OBJ_VER,OBJECT_VERSION_NUMBER,NAMESPACE_OBJ_ID,NAMESPACE_OBJ_VER

- **RENUMBER** (Mandatory) Enter 'Y' for copied Report Set Entries to appropriately numbered in their new location.
- **PI_COPYPRGASSGNMT** (Mandatory) When copying Report Set Entries, enter 'Y' to copy Program instances currently assigned to the Report Set Entries, their Planned Output assignments and mappings. Enter 'N' to avoid copying these Program instances in which case, all Planned Output assignments are lost.

12.1.4 Modify a Report Set Entry

Use this API to modify a Report Set Entry.

Name CDR_PUB_RS_REPORT_SET_ENTRY.MODIFYREPORTSETENTRY

Signature

```
PROCEDURE MODIFYREPORTSETENTRY(
  P_API_VERSION IN NUMBER,
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
  X_RETURN_STATUS OUT VARCHAR2,
  X_MSG_COUNT OUT NUMBER,
  X_MSG_DATA OUT VARCHAR2,
  PIO_SOURCECDRNAMING IN OUT CDR_NAMING_VERSION_OBJ_TYPE,
  PI_CDRRSENTRY IN OUT CDR_RS_ENTRY_OBJ_TYPE
);
```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

- **PIO_SOURCECDRNAMING** (Mandatory) This is a parameter of table type CDR_NAMING_VERSIONS_OBJ_TYPE that contains CDR Naming Version attributes. Enter values to identify the Report Set Entry that you want to modify and enter new values for the attributes you want to modify. You can change the name and description. All attributes are required.
- **PI_CDRRSENTRY** (Mandatory) This is a parameter of table type CDR_RS_ENTRY_OBJ_TYPE that contains object attributes. Enter values to identify the Report Set Entry that you want to modify and enter new values for the attributes you want to modify. You can change the Entry and Position numbers, the Strict and Unique Numbering flags, the Omit from Install flag, the Title, Delimiter, Prefix, Postfix, Placeholder flag and Volume Break flag values. All attributes are required.

12.1.5 Move a Report Set Entry into Another

Use this API to move one or more Report Set Entries into another Report Set Entry.

Name CDR_PUB_RS_REPORT_SET_ENTRY.MOVEOBJECTSINTOREPORTSETENTRY

Signature

```
PROCEDURE MOVEOBJECTSINTOREPORTSETENTRY(
  P_API_VERSION IN NUMBER,
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
```

```

P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
X_RETURN_STATUS OUT VARCHAR2,
X_MSG_COUNT OUT NUMBER,
X_MSG_DATA OUT VARCHAR2,
PIO_CDRBASEOBJCOLL IN OUT CDR_BASE_OBJ_COLL,
PIO_TARGETBASEOBJ IN OUT CDR_BASE_OBJ_TYPE,
RENUMBER IN VARCHAR2
);

```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

- **PIO_CDRBASEOBJCOLL** (Mandatory) This is a collection of CDR_BASE_OBJ_TYPES. For each Report Set Entry that you want to move, initialize a CDR_BASE_OBJ_TYPE and then extend the collection.

The following attributes are required: COMPANY_ID,OBJ_ID,OBJ_VER,OBJECT_VERSION_NUMBER,NAMESPACE_OBJ_ID,NAMESPACE_OBJ_VER.

- **PIO_TARGETBASEOBJ** (Mandatory) This is a parameter of table type CDR_BASE_OBJ_TYPE that contains object attributes. Enter values to identify the Report Set or Report Set Entry into which you want to move Report Set Entries.

The following attributes are required: COMPANY_ID,OBJ_ID,OBJ_VER,OBJECT_VERSION_NUMBER,NAMESPACE_OBJ_ID,NAMESPACE_OBJ_VER.

- **RENUMBER** Enter either TRUE or FALSE. When you move a Report Set Entry, the API determines whether or not the numbering of the target Report Set or Report Set Entry is still valid.

If you enter TRUE, the API automatically renumbers the target to make its numbering valid.

If you enter FALSE, the copy operation fails if it creates invalid numbering.

12.1.6 Reorder Report Set Entries in a Parent Report Set

Use this API to change the order of Report Set Entries within a parent Report Set or Report Set Entry.

Name CDR_PUB_RS_REPORT_SET_ENTRY.REORDERREPORTSETENTRY

Signature

```

PROCEDURE REORDERREPORTSETENTRY(
  P_API_VERSION IN NUMBER,
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
  X_RETURN_STATUS OUT VARCHAR2,
  X_MSG_COUNT OUT NUMBER,
  X_MSG_DATA OUT VARCHAR2,
  PI_REORDERCOLL IN OUT CDR_REORDER_OBJ_COLL
);

```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

PI_REORDERCOLL (Mandatory) Initialize a CDR_REORDER_OBJ_TYPE for each child Report Set Entry in the same parent Report Set or Report Set Entry, including the

correct new Position and Entry Number, in the correct new order, and then extend the collection.

The following attributes are required: COMPANY_ID,OBJ_ID,OBJ_VER,OBJECT_VERSION_NUMBER,NAMESPACE_OBJ_ID,NAMESPACE_OBJ_VER,POSITION,ENTRY_NUMBER,OBJECT_VERSION_NUMBER.

12.1.7 Find if a Report Set is Checked Out

Use this API to determine whether or not the Report Set is currently checked out. The API returns \$YESNO\$YES if it is checked out and \$YESNO\$NO if it is not checked out.

Name CDR_PUB_RS_REPORT_SET_ENTRY.GETRSCHECKOUTFLAGRC

Signature

```
FUNCTION GETRSCHECKOUTFLAGRC (
  P_API_VERSION IN NUMBER,
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
  PI_COMPANYID IN CDR_NAMINGS.COMPANY_ID%TYPE,
  PI_OBJID IN CDR_NAMINGS.OBJ_ID%TYPE
) RETURN CDR_NAMINGS.CHECKED_OUT_FLAG_RC%TYPE;
```

Return CDR_NAMINGS.CHECKED_OUT_FLAG_RC%TYPE

Description varchar, returns '\$YESNO\$YES' or '\$YESNO\$NO'

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

- **PI_COMPANYID** (Mandatory) Enter the COMPANY_ID of the Report Set Entry.
- **PI_OBJID** (Mandatory) Enter the OBJ_ID of the Report Set Entry.

12.1.8 Check Unique and Strict Numbering in a Report Set

Use this API to check whether a Report Set's Entries conform to the rules you specify for unique and strict numbering.

Name CDR_PUB_RS_REPORT_SET_ENTRY.ISVALIDCHILDRENRSENTRIES

Signature

```
FUNCTION ISVALIDCHILDRENRSENTRIES (
  P_API_VERSION IN NUMBER,
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
  COMPANYID IN CDR_NAMINGS.COMPANY_ID%TYPE,
  OBJID IN CDR_NAMINGS.OBJ_ID%TYPE,
  OBJVER IN CDR_NAMING_VERSIONS.OBJ_VER%TYPE,
  UNIQUEFLAG IN CDR_RS_ENTRIES.UNIQUE_NUMBERING_FLAG_RC%TYPE,
  STRICTFLAG IN CDR_RS_ENTRIES.STRICT_NUMBERING_FLAG_RC%TYPE
) RETURN VARCHAR2;
```

Return Type VARCHAR2

Description varchar2 true or false

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

- **COMPANYID** Enter the Company ID of the Report Set.
- **OBJID** Enter the object ID of the Report Set.
- **OBJVER** Enter the object version of the Report Set.
- **UNIQUEFLAG** Enter Y to validate the Report Set's numbering for uniqueness. Enter N to allow non-unique Report Set Entry numbers within the Report Set.
- **STRICTFLAG** Enter Y to validate the Report Set for strictly sequential numbering, with no gaps allowed. Enter N to allow gaps in numbering between sibling Report Set Entries within the Report Set.

12.1.9 Identify if a Report Set Contains Child Entries

Use this API to determine whether or not a Report Set or Report Set Entry contains child Report Set Entries.

Name CDR_PUB_RS_REPORT_SET_ENTRY.HASCHILDREN

Signature

```
FUNCTION HASCHILDREN(
  P_API_VERSION IN NUMBER,
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
  PI_COMPANYID IN CDR_NAMINGS.COMPANY_ID%TYPE,
  PI_NS_OBJID IN CDR_NAMINGS.OBJ_ID%TYPE,
  PI_NS_OBJVER IN CDR_NAMING_VERSIONS.OBJ_VER%TYPE
) RETURN VARCHAR2;
```

Return Type VARCHAR2

Description varchar Y or N depending on if the RS has children or not.

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

- **PI_COMPANYID** (Mandatory) Enter the COMPANY_ID of the Report Set or Report Set Entry.
- **PI_NS_OBJID** (Mandatory) Enter the OBJ_ID of the Report Set or Report Set Entry.
- **PI_NS_OBJVER** (Mandatory) Enter the OBJ_VER of the Report Set or Report Set Entry.

12.1.10 Find if a User has Modify Permission

Use this API to determine whether or not you (the current user) have permission to modify a particular Report Set Entry. This API takes into consideration the validation status of the Report Set or RSE and whether you have the RS Modify privilege, the RS Modify QC privilege, the RS Modify Production privilege, or none of these privileges.

Name CDR_PUB_RS_REPORT_SET_ENTRY.HASREPORTMODPERMISSION

Signature

```

FUNCTION HASREPORTMODPERMISSION(
  P_API_VERSION IN NUMBER,
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
  PI_COMPANYID IN CDR_NAMINGS.COMPANY_ID%TYPE,
  PI_OBJID IN CDR_NAMINGS.OBJ_ID%TYPE,
  PI_OBJVER IN CDR_NAMING_VERSIONS.OBJ_VER%TYPE,
  RAISEEXCEPTION IN VARCHAR2 := 'N'
) RETURN VARCHAR2;

```

Return Type VARCHAR2

Description varchar2

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

- **PI_COMPANYID** (Mandatory) Enter the COMPANY_ID of the Report Set Entry.
- **PI_OBJID** (Mandatory) Enter the OBJ_ID of the Report Set Entry.
- **PI_OBJVER** (Mandatory) Enter the OBJ_VER of the Report Set Entry.
- **RAISEEXCEPTION** If you enter Y here and you do not have the required privileges to modify the Report Set Entry, the API raises an exception.

If you enter N, the API tests for different conditions.

If you do not have the required privileges to modify the RSE, the API returns N irrespective of the RSE's validation status.

If the RSE's validation status is Development, the API returns Y if you have modify privileges on the RSE and N if you do not.

If the RSE's validation status is QC or Production, the API checks if you have Modify QC or Modify Production, respectively.

If you do not have the privilege required to modify an RSE of the current validation status, the API returns VIRTUAL_LOCK.

However, you may be able to modify other RSEs in the same Report Set.

12.1.11 Remove an Object from a Report Set Entry

Use this API to remove one or more Report Set Entries from a Report Set or parent Report Set Entry.

Name CDR_PUB_RS_REPORT_SET_ENTRY.REMOVEOBJECTSFROMRSENTRIES

Signature

```

PROCEDURE REMOVEOBJECTSFROMRSENTRIES(
  P_API_VERSION IN NUMBER,
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
  X_RETURN_STATUS OUT VARCHAR2,
  X_MSG_COUNT OUT NUMBER,
  X_MSG_DATA OUT VARCHAR2,
  PIO_CDRBASEOBJCOLL IN OUT CDR_BASE_OBJ_COLL,
  RENUMBER IN VARCHAR2
);

```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

- **PIO_CDRBASEOBJCOLL** (Mandatory) This is a collection of CDR_BASE_OBJ_TYPES. For each Report Set Entry that you want to copy, initialize a CDR_BASE_OBJ_TYPE and then extend the collection.

The following attributes are required: COMPANY_ID, OBJ_ID, OBJ_VER, OBJECT_VERSION_NUMBER, NAMESPACE_OBJ_ID, NAMESPACE_OBJ_VER.

- **RENUMBER** Enter either TRUE or FALSE. When you remove a Report Set Entry, the API determines whether or not the numbering of the parent Report Set or Report Set Entry is still valid. If you enter TRUE, the API automatically renumbers the target to make its numbering valid. If you enter FALSE, the Remove operation fails if it creates invalid numbering.

12.1.12 Remove a Report Set Entry

Use this API to remove a Report Set Entry from a Report Set. If the removal of the RSE causes invalid numbering in the remaining RSEs, the API generates an error.

Name CDR_PUB_RS_REPORT_SET_ENTRY.REMOVEREPORTSETENTRY

Signature

```
PROCEDURE REMOVEREPORTSETENTRY(
  P_API_VERSION IN NUMBER,
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
  X_RETURN_STATUS OUT VARCHAR2,
  X_MSG_COUNT OUT NUMBER,
  X_MSG_DATA OUT VARCHAR2,
  PIO_CDRBASEOBJ IN OUT CDR_BASE_OBJ_TYPE
);
```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameter:

PI_CDRBASEOBJ (Mandatory) This is a parameter of table type CDR_BASE_OBJ_TYPE that contains object attributes. Enter values to identify the Report Set Entry from which you want to unassign the Planned Output.

The following attributes are required: COMPANY_ID, OBJ_ID AND OBJ_VER, NAMESPACE_OBJ_ID, NAMESPACE_OBJ_VER, OBJECT_VERSION_NUMBER.

12.1.13 Get a Report Set Name

Use this API to get the name of the Report Set you specify.

Name CDR_PUB_RS_REPORT_SET_ENTRY.GETREPORTSETNAME

Signature

```
FUNCTION GETREPORTSETNAME(
  P_API_VERSION IN NUMBER,
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
  PI_COMPANYID IN CDR_NAMINGS.COMPANY_ID%TYPE,
```

```

    PI_OBJID IN CDR_NAMINGS.OBJ_ID%TYPE
) RETURN CDR_NAMINGS.NAME%TYPE;

```

Return Type CDR_NAMINGS.NAME%TYPE

Description varchar Name of the RS

Parameters This API has standard parameters (see "[Standard Parameters](#)" on page 5) and the following parameters:

- **PI_COMPANYID** (Mandatory) Enter the Company ID of the Report Set.
- **PI_OBJID** (Mandatory) Enter the Object ID of the Report Set.

12.1.14 Get a Title

Use this API to get the full title of a Report Set or Report Set Entry. If you do not specify a version, the API returns the value for the most recent version.

Name CDR_PUB_RS_REPORT_SET_ENTRY.GETTITLE

Signature

```

FUNCTION GETTITLE(
    P_API_VERSION IN NUMBER,
    P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
    P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
    P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
    PI_COMPANYID IN CDR_NAMINGS.COMPANY_ID%TYPE,
    PI_OBJID IN CDR_NAMINGS.OBJ_ID%TYPE,
    PI_OBJVER IN CDR_NAMING_VERSIONS.OBJ_VER%TYPE
) RETURN VARCHAR2;

```

Return Type VARCHAR2

Description overcharge returns the title of the RS or RSE

Parameters This API has standard parameters (see "[Standard Parameters](#)" on page 5) and the following parameters:

- **PI_COMPANYID** (Mandatory) Enter the COMPANY_ID of the Report Set Entry.
- **PI_OBJID** (Mandatory) Enter the OBJ_ID of the Report Set Entry.
- **PI_OBJVER** (Mandatory) Enter the OBJ_VER of the Report Set Entry.

12.1.15 Get a Chapter Number

Use this API to get the chapter number of a Report Set Entry.

Name CDR_PUB_RS_REPORT_SET_ENTRY.GETCHAPTERNUMBER

Signature

```

FUNCTION GETCHAPTERNUMBER(
    P_API_VERSION IN NUMBER,
    P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
    P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
    P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
    PI_COMPANYID IN CDR_NAMINGS.COMPANY_ID%TYPE,
    PI_OBJID IN CDR_NAMINGS.OBJ_ID%TYPE,
    PI_OBJVER IN CDR_NAMING_VERSIONS.OBJ_VER%TYPE
) RETURN NUMBER;

```

```
) RETURN VARCHAR2;
```

Return Type VARCHAR2

Description varchar returns the chapter number of the reportset entry

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

- **PI_COMPANYID** (Mandatory) Enter the COMPANY_ID of the Report Set Entry.
- **PI_OBJID** (Mandatory) Enter the OBJ_ID of the Report Set Entry.
- **PI_OBJVER** (Mandatory) Enter the OBJ_VER of the Report Set Entry.

12.1.16 Get a Parent Number

Use this API to get the chapter number of the parent Report Set Entry of the RSE you specify. If the parent is the Report Set itself, the API returns Null.

Name CDR_PUB_RS_REPORT_SET_ENTRY.GETPARENTNUMBER

Signature

```
FUNCTION GETPARENTNUMBER(  
  P_API_VERSION IN NUMBER,  
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,  
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,  
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,  
  PI_COMPANYID IN CDR_NAMINGS.COMPANY_ID%TYPE,  
  PI_OBJID IN CDR_NAMINGS.OBJ_ID%TYPE,  
  PI_OBJVER IN CDR_NAMING_VERSIONS.OBJ_VER%TYPE  
) RETURN VARCHAR2;
```

Return Type VARCHAR2

Description varchar returns the parent number of the object

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

- **PI_COMPANYID** (Mandatory) Enter the COMPANY_ID of the Report Set Entry.
- **PI_OBJID** (Mandatory) Enter the OBJ_ID of the Report Set Entry.
- **PI_OBJVER** (Mandatory) Enter the OBJ_VER of the Report Set Entry.

12.1.17 Get a List of Report Set Entry Titles

Use this API to get a list of the full titles and version numbers of all the RSEs in a direct path to a particular Report Set Entry, from the top of the Report Set down to the Report Set Entry you specify.

Name CDR_PUB_RS_REPORT_SET_ENTRY.TOPDOWNLISTOFRSETITLES

Signature

```
FUNCTION TOPDOWNLISTOFRSETITLES(  
  P_API_VERSION IN NUMBER,  
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,  
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,  
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
```



```

PI_NCOMPANYID IN CDR_NAMINGS.COMPANY_ID%TYPE,
PI_NRSEOBJID IN CDR_NAMINGS.OBJ_ID%TYPE,
PI_NRSEOBJVER IN CDR_NAMING_VERSIONS.OBJ_VER%TYPE,
PI_NRSOBJID IN CDR_NAMINGS.OBJ_ID%TYPE,
PI_NRSOBJVER IN CDR_NAMING_VERSIONS.OBJ_VER%TYPE
) RETURN CDR_VALS_COLL;

```

Return Type CDR_VALS_COLL

Description CDR_VALS_COLL returns the list of RSE titles top down

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

- **PI_NCOMPANYID** (Mandatory) Enter the COMPANY_ID of the Report Set Entry.
- **PI_NCOMPANYID** (Mandatory) Enter the OBJ_ID of the Report Set Entry.
- **PI_NRSEOBJID** (Mandatory) Enter the OBJ_ID of the Report Set Entry.
- **PI_NRSOBJID** (Mandatory) Enter the OBJ_ID of the parent Report Set.
- **PI_NRSOBJVER** (Mandatory) Enter the OBJ_VER of the Report Set Entry.

12.1.18 Get All RSE Titles in a Report Set

Use this API to get a list of the full titles of all the RSEs in a Report Set.

Name CDR_PUB_RS_REPORT_SET_ENTRY.TOPDOWNLISTOFRSETITLES

Signature

```

FUNCTION TOPDOWNLISTOFRSETITLES(
  P_API_VERSION IN NUMBER,
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
  PI_COMPANYID IN CDR_NAMINGS.COMPANY_ID%TYPE,
  PI_OBJID IN CDR_NAMINGS.OBJ_ID%TYPE,
  PI_OBJVER IN CDR_NAMING_VERSIONS.OBJ_VER%TYPE
) RETURN CDR_VALS_COLL;

```

Return Type CDR_VALS_COLL

Description CDR_VALS_COLL returns the list of RSE titles top down

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

- **PI_COMPANYID** (Mandatory) Enter the COMPANY_ID of the Report Set Entry.
- **PI_OBJID** (Mandatory) Enter the OBJ_ID of the Report Set Entry.
- **PI_OBJVER** (Mandatory) Enter the OBJ_VER of the Report Set Entry.

12.1.19 Get Attribute Values Derived from a Parent

Use this API to retrieve attribute values for a Report Set Entry that are derived from its parent Report Set or Report Set Entry, including those that are dynamically derived and those that are derived only when the child Report Set Entry is initially created.

Name CDR_PUB_RS_REPORT_SET_ENTRY.GETDERIVEDATTRVALUESFROMPARENT

Signature

```
PROCEDURE GETDERIVEDATTRVALUESFROMPARENT (
  P_API_VERSION IN NUMBER,
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
  X_RETURN_STATUS OUT VARCHAR2,
  X_MSG_COUNT OUT NUMBER,
  X_MSG_DATA OUT VARCHAR2,
  PI_COMPANY_ID IN CDR_NAMINGS.COMPANY_ID%TYPE,
  PI_NAMESPACE_OBJ_ID IN CDR_NAMINGS.NAMESPACE_OBJ_ID%TYPE,
  PI_NAMESPACE_OBJ_VER IN CDR_NAMING_VERSIONS.NAMESPACE_START_OBJ_VER%TYPE,
  PI_CDRRSENTRY IN OUT CDR_RS_ENTRY_OBJ_TYPE,
  PI_PARENT_NUMBER OUT VARCHAR2
);
```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

- **PI_COMPANY_ID** (Mandatory) Enter the COMPANY_ID of the parent Report Set or Report Set Entry.
- **PI_NAMESPACE_OBJ_ID** (Mandatory) Enter the OBJ_ID of the Report Set or Report Set Entry.
- **PI_NAMESPACE_OBJ_VER** (Mandatory) Enter the OBJ_VER of the parent Report Set or Report Set Entry.
- **PI_CDRRSENTRY** (Mandatory) This is a parameter of table type CDR_RS_ENTRY_OBJ_TYPE that contains attributes specific to Report Set Entries. Enter values to identify the Report Set Entry for which you want to retrieve inherited attributes.
- **PI_PARENT_NUMBER** This output parameter returns the chapter number of the parent Report Set Entry.

If the parent is the Report Set itself, the parameter returns NULL.

12.1.20 Get the Lowest Entry Number

Use this API to get the number of the lowest numbered child Report Set Entry in the Report Set or RSE you specify.

Name CDR_PUB_RS_REPORT_SET_ENTRY.GETMINENTRYNUMBER

Signature

```
FUNCTION GETMINENTRYNUMBER (
  P_API_VERSION IN NUMBER,
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
  PI_COMPANY_ID IN CDR_NAMINGS.COMPANY_ID%TYPE,
  PI_NAMESPACE_OBJ_ID IN CDR_NAMINGS.NAMESPACE_OBJ_ID%TYPE,
  PI_NAMESPACE_OBJ_VER IN CDR_NAMING_VERSIONS.NAMESPACE_START_OBJ_VER%TYPE
) RETURN CDR_RS_ENTRIES.ENTRY_NUMBER%TYPE;
```

Return Type CDR_RS_ENTRIES.ENTRY_NUMBER%TYPE

Description Minimum of the number of the RSEs in the report set

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

- **PI_COMPANY_ID** (Mandatory) Enter the COMPANY_ID of the Report Set or Report Set Entry.
- **PI_NAMESPACE_OBJ_ID** (Mandatory) Enter the OBJ_ID of the Report Set.
- **PI_NAMESPACE_OBJ_VER** (Mandatory) Enter the OBJ_VER of the Report Set.

12.1.21 Get the Total Number of Report Set Entries

CDR_PUB_RS_REPORT_SET_ENTRY.GETMAXENTRYNUMBER

Name Use this API to get the number of the highest numbered child Report Set Entry in the Report Set or RSE you specify.

Signature

```
FUNCTION GETMAXENTRYNUMBER (
  P_API_VERSION IN NUMBER,
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
  PI_COMPANY_ID IN CDR_NAMINGS.COMPANY_ID%TYPE,
  PI_NAMESPACE_OBJ_ID IN CDR_NAMINGS.NAMESPACE_OBJ_ID%TYPE,
  PI_NAMESPACE_OBJ_VER IN CDR_NAMING_VERSIONS.NAMESPACE_START_OBJ_VER%TYPE
) RETURN CDR_RS_ENTRIES.ENTRY_NUMBER%TYPE;
```

Return Type CDR_RS_ENTRIES.ENTRY_NUMBER%TYPE

Description Maximum of the number of the RSEs in the report set

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

- **PI_COMPANY_ID** (Mandatory) Enter the COMPANY_ID of the Report Set.
- **PI_NAMESPACE_OBJ_ID** (Mandatory) Enter the OBJ_ID of the Report Set.
- **PI_NAMESPACE_OBJ_VER** (Mandatory) Enter the OBJ_VER of the Report Set.

12.1.22 Create a Narrative

Use this API to create a narrative for an existing Report Set Entry.

Name CDR_PUB_RS_REPORT_SET_ENTRY.CREATENARRATIVE

Signature

```
PROCEDURE CREATENARRATIVE(
  P_API_VERSION IN NUMBER,
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
  X_RETURN_STATUS OUT VARCHAR2,
  X_MSG_COUNT OUT NUMBER,
```

```

X_MSG_DATA OUT VARCHAR2,
PI_CDRRSENARRATIVE IN OUT CDR_RSE_NARRATIVE_OBJ_TYPE,
PIO_BASEOBJECT IN OUT CDR_BASE_OBJ_TYPE
);

```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

- **PI_CDRRSENARRATIVE** (Mandatory) This is a parameter of type CDR_RSE_NARRATIVE_OBJ_TYPE that contains details of the narrative to be added.

The following attributes are required: COMPANY_ID, NARRATIVE_MODE(PRE/POST), NARRATIVE_TEXT, NARRATIVE_TYPE(TEXT or TEXT/PLAIN), FILE_NAME.

- **PIO_BASEOBJECT** (Mandatory) This is a parameter of table type CDR_BASE_OBJ_TYPE that contains object attributes. Enter values to identify the Report Set Entry to which you want to create a Narrative.

The following attributes are required: COMPANY_ID, OBJ_ID AND OBJ_VER, NAMESPACE_OBJ_ID, NAMESPACE_OBJ_VER, OBJECT_VERSION_NUMBER.

12.1.23 Update a Narrative

Use this API to update a narrative for an existing Report Set Entry.

Name CDR_PUB_RS_REPORT_SET_ENTRY.UPDATENARRATIVE

Signature

```

PROCEDURE UPDATENARRATIVE(
  P_API_VERSION IN NUMBER,
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
  X_RETURN_STATUS OUT VARCHAR2,
  X_MSG_COUNT OUT NUMBER,
  X_MSG_DATA OUT VARCHAR2,
  PI_CDRRSENARRATIVE IN OUT CDR_RSE_NARRATIVE_OBJ_TYPE,
  PIO_BASEOBJECT IN OUT CDR_BASE_OBJ_TYPE
);

```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

- **PI_CDRRSENARRATIVE** (Mandatory) This is a parameter of type CDR_RSE_NARRATIVE_OBJ_TYPE that contains details of the narrative to be updated.

The following attributes are required: COMPANY_ID, NARRATIVE_MODE(PRE/POST), NARRATIVE_TEXT, NARRATIVE_TYPE(TEXT or TEXT/PLAIN), FILE_NAME.

- **PIO_BASEOBJECT** (Mandatory) This is a parameter of table type CDR_BASE_OBJ_TYPE that contains object attributes. Enter values to identify the Report Set Entry from which you want to update a narrative.

The following attributes are required: COMPANY_ID, OBJ_ID AND OBJ_VER, NAMESPACE_OBJ_ID, NAMESPACE_OBJ_VER, OBJECT_VERSION_NUMBER.

12.1.24 Delete a Narrative

Use this API to delete a narrative for an existing Report Set Entry.

Name CDR_PUB_RS_REPORT_SET_ENTRY.DELETENARRATIVE

Signature

```
PROCEDURE DELETENARRATIVE(
  P_API_VERSION IN NUMBER,
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
  X_RETURN_STATUS OUT VARCHAR2,
  X_MSG_COUNT OUT NUMBER,
  X_MSG_DATA OUT VARCHAR2,
  PI_CDRRSENARRATIVE IN OUT CDR_RSE_NARRATIVE_OBJ_TYPE,
  PIO_BASEOBJECT IN OUT CDR_BASE_OBJ_TYPE
);
```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

- **PI_CDRRSENARRATIVE** (Mandatory) This is a parameter of type CDR_RSE_NARRATIVE_OBJ_TYPE that contains details of the narrative to be deleted.
The following attributes are required: COMPANY_ID, NARRATIVE_MODE(PRE/POST).
- **PIO_BASEOBJECT** (Mandatory) This is a parameter of table type CDR_BASE_OBJ_TYPE that contains object attributes. Enter values to identify the Report Set Entry from which you want to delete a narrative.
The following attributes are required: COMPANY_ID, OBJ_ID AND OBJ_VER, NAMESPACE_OBJ_ID, NAMESPACE_OBJ_VER, OBJECT_VERSION_NUMBER.

12.1.25 Check if Copying Retains Valid Numbering in a Target Report Set

Use this API to determine whether copying a given set of Report Set Entries into another Report Set or Report Set Entry would result in invalid numbering in the target RS or RSE.

Name CDR_PUB_RS_REPORT_SET_ENTRY.VALIDATECOPYRSELIST

Signature

```
FUNCTION VALIDATECOPYRSELIST(
  P_API_VERSION IN NUMBER,
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
  PIO_CDRBASEOBJCOLL IN CDR_BASE_OBJ_COLL,
  PIO_TARGETBASEOBJ IN CDR_BASE_OBJ_TYPE
) RETURN VARCHAR2;
```

Return Type VARCHAR2

Description varchar2 success or failure

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

- **PIO_CDRBASEOBJCOLL** (Mandatory) This is a collection of CDR_BASE_OBJ_TYPES. For each Report Set Entry that you want to copy, initialize a CDR_BASE_OBJ_TYPE and then extend the collection.

The following attributes are required: COMPANY_ID,OBJ_ID,OBJ_VER,OBJECT_VERSION_NUMBER,NAMESPACE_OBJ_ID,NAMESPACE_OBJ_VER.

- **PIO_TARGETBASEOBJ** (Mandatory) This is a parameter of table type CDR_BASE_OBJ_TYPE that contains object attributes. Enter values to identify the Report Set or Report Set Entry into which you want to copy Report Set Entries.

The following attributes are required: COMPANY_ID,OBJ_ID,OBJ_VER,OBJECT_VERSION_NUMBER,NAMESPACE_OBJ_ID,NAMESPACE_OBJ_VER.

12.1.26 Check if a Move Retains Valid Numbering in a Target Report Set

Use this API to determine whether moving a given set of Report Set Entries into another Report Set or Report Set Entry would result in invalid numbering in the target RS or RSE. The API returns TRUE if the numbering will remain valid or FALSE if the numbering will become invalid.

Name CDR_PUB_RS_REPORT_SET_ENTRY.VALIDATEMOVEINTORSELIST

Signature

```
FUNCTION VALIDATEMOVEINTORSELIST (
  P_API_VERSION IN NUMBER,
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
  PIO_CDRBASEOBJCOLL IN CDR_BASE_OBJ_COLL,
  PIO_TARGETBASEOBJ IN CDR_BASE_OBJ_TYPE
) RETURN VARCHAR2;
```

Return Type VARCHAR2

Description varchar2 success or failure

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

- **PIO_CDRBASEOBJCOLL** (Mandatory) This is a collection of CDR_BASE_OBJ_TYPES. For each Report Set Entry that you want to copy, initialize a CDR_BASE_OBJ_TYPE and then extend the collection.

The following attributes are required: COMPANY_ID,OBJ_ID,OBJ_VER,OBJECT_VERSION_NUMBER,NAMESPACE_OBJ_ID,NAMESPACE_OBJ_VER.

- **PIO_TARGETBASEOBJ** (Mandatory) This is a parameter of table type CDR_BASE_OBJ_TYPE that contains object attributes. Enter values to identify the Report Set or Report Set Entry into which you want to copy Report Set Entries.

The following attributes are required: COMPANY_ID,OBJ_ID,OBJ_VER,OBJECT_VERSION_NUMBER,NAMESPACE_OBJ_ID,NAMESPACE_OBJ_VER.

12.1.27 Check if a Move Retains Valid Numbering in the Parent Report Set

Use this API to determine whether moving a given set of Report Set Entries out of its parent Report Set or RSE would result in invalid numbering in the parent RS or RSE.

Name CDR_PUB_RS_REPORT_SET_ENTRY.VALIDATEMOVEFROMRSELIST

Signature

```
FUNCTION VALIDATEMOVEFROMRSELIST (
  P_API_VERSION IN NUMBER,
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
  PIO_CDRBASEOBJCOLL IN CDR_BASE_OBJ_COLL
) RETURN VARCHAR2;
```

Return Type VARCHAR2

Description varchar2 success or failure

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameter:

PIO_CDRBASEOBJCOLL (Mandatory) This is a collection of CDR_BASE_OBJ_TYPES. For each Report Set Entry that you want to copy, initialize a CDR_BASE_OBJ_TYPE and then extend the collection.

The following attributes are required: COMPANY_ID,OBJ_ID,OBJ_VER,OBJECT_VERSION_NUMBER,NAMESPACE_OBJ_ID,NAMESPACE_OBJ_VER.

12.1.28 Check if Removal Retains Valid Numbering in a Parent Report Set

Use this API to determine whether removing a given set of Report Set Entries would result in invalid numbering in the parent RS or RSE.

Name CDR_PUB_RS_REPORT_SET_ENTRYCDR_PUB_RS_REPORT_SET_ENTRY.VALIDATEREMOVERSELIST

Signature

```
FUNCTION VALIDATEREMOVERSELIST(
  P_API_VERSION IN NUMBER,
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
  PIO_CDRBASEOBJCOLL IN CDR_BASE_OBJ_COLL
) RETURN VARCHAR2;
```

Return Type VARCHAR2

Description varchar2 success or failure

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameter:

PIO_CDRBASEOBJCOLL (Mandatory) This is a collection of CDR_BASE_OBJ_TYPES. For each Report Set Entry that you want to copy, initialize a CDR_BASE_OBJ_TYPE and then extend the collection.

The following attributes are required: COMPANY_ID,OBJ_ID,OBJ_VER,OBJECT_VERSION_NUMBER,NAMESPACE_OBJ_ID,NAMESPACE_OBJ_VER.

12.1.29 Check if Reordering Retains Valid Numbering in a Parent Report Set

Use this API to determine whether reordering a collection of Report Set Entries would result in invalid numbering in the parent RS or RSE. To actually reorder the RSEs use ReorderReportSetEntry.

Name CDR_PUB_RS_REPORT_SET_ENTRY.VALIDATEREORDERLIST

Signature

```
FUNCTION VALIDATEREORDERLIST(  
  P_API_VERSION IN NUMBER,  
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,  
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,  
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,  
  REORDERCOLL IN CDR_REORDER_OBJ_COLL  
) RETURN VARCHAR2
```

Return Type VARCHAR2

Description varchar2 success or failure

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameter:

REORDERCOLL Initialize a CDR_REORDER_OBJ_TYPE for each child Report Set Entry in the same parent Report Set or Report Set Entry, including the correct new position and Entry Number, in the correct new order, and then extend the collection. All the attributes are mandatory.

12.1.30 Unassign a Planned Output

Use this API to unassign a Planned Output from a Report Set Entry.

Name CDR_PUB_RS_REPORT_SET_ENTRY.REMOVEPOASSIGNMENT

Signature

```
PROCEDURE REMOVEPOASSIGNMENT(  
  P_API_VERSION IN NUMBER,  
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,  
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,  
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,  
  X_RETURN_STATUS OUT VARCHAR2,  
  X_MSG_COUNT OUT NUMBER,  
  X_MSG_DATA OUT VARCHAR2,  
  PI_CDRBASEOBJ IN CDR_BASE_OBJ_TYPE  
) ;
```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameter:

PI_CDRBASEOBJ (Mandatory) This is a parameter of table type CDR_BASE_OBJ_TYPE that contains object attributes. Enter values to identify the Report Set Entry from which you want to unassign the Planned Output.

The following attributes are required: COMPANY_ID, OBJ_ID AND OBJ_VER, NAMESPACE_OBJ_ID, NAMESPACE_OBJ_VER, OBJECT_VERSION_NUMBER.

12.2 Create and Modify Report Sets

This is a public interface for all functions related to Report Sets.

This section contains the following topics:

- [Section 12.2.1, "Create a Report Set"](#)
- [Section 12.2.2, "Check Out a Report Set"](#)
- [Section 12.2.3, "Undo a Report Set Checkout"](#)
- [Section 12.2.4, "Copy Objects Into a Report Set"](#)
- [Section 12.2.5, "Get a Summary Output Validation Status"](#)
- [Section 12.2.6, "Modify a Report Set"](#)
- [Section 12.2.7, "Move Objects into a Report Set"](#)

12.2.1 Create a Report Set

Use this API to create a new Report Set definition only, a new instance of an existing Report Set definition, or a new definition and an instance of it.

Name CDR_PUB_RS_REPORT_SET.CREATEREPORTSET

Signature

```
PROCEDURE CREATEREPORTSET(
  P_API_VERSION IN NUMBER,
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
  X_RETURN_STATUS OUT VARCHAR2,
  X_MSG_COUNT OUT NUMBER,
  X_MSG_DATA OUT VARCHAR2,
  PIO_SOURCECDRNAMING IN OUT CDR_NAMING_VERSION_OBJ_TYPE,
  PI_REPORTSET IN CDR_REPORT_SET_OBJ_TYPE,
  PI_CREATEOBJECT IN VARCHAR2,
  PI_INSTANCE_SUBTYPE_ID IN CDR_NAMINGS.OBJECT_SUBTYPE_ID%TYPE,
  PI_DEFCLASSIFICATIONCOLL IN CDR_CLASSIFICATIONS_COLL,
  PI_INSTCLASSIFICATIONCOLL IN CDR_CLASSIFICATIONS_COLL
);
```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

- **PIO_SOURCECDRNAMING** (Mandatory) This is a parameter of table type CDR_NAMING_VERSION_OBJ_TYPE that contains object attributes. Enter values for the new Report Set Entry. Use the NAMESPACE attributes to identify the Report Set or Report Set Entry in which you want to create the new Report Set Entry. For OBJECT_TYPE_RC enter \$OBJTYPES\$REPORTSETENTRY.

The following attributes are required: COMPANY_ID, NAME, NAMESPACE_OBJ_ID, NAMESPACE_OBJ_VER.

- **PI_REPORTSET** (Mandatory) This is a parameter of table type CDR_REPORT_SET_OBJ_TYPE that contains object attributes.

Enter values for the Report Set definition you want to create.

If you are creating an instance of an existing definition, enter values to identify the definition you want to create an instance of. The following attributes are required: UNIQUE_NUMBERING_FLAG_RC, STRICT_NUMBERING_FLAG_RC.

- **PI_CREATEOBJECT** (Mandatory) Enter DEFN to create a definition only; INST to create a instance of an existing definition; or BOTH to create a new definition and an instance of it.
- **PI_INSTANCE_SUBTYPE_ID** (Optional) If you are creating a new instance, enter the ID for the subtype you want to give the instance.

If you are creating a definition only, do not enter a value for this parameter.

- **PI_DEFCLASSIFICATIONCOLL** (Optional) By default the new definition is classified according to the subtype you assigned it in the CDR_NAMING_VERSION_OBJ_TYPE.

If you want to override the default classifications for one or more classification levels, use this parameter. This is a collection of CDR_CLA_OBJ_TYPES, which have 5 attributes, including CLA_LEVEL_ID and CLASSIFICATION_ID.

If you want the definition to inherit its classifications for a particular level from its parent, enter the classification level ID and, for the CLASSIFICATION_ID, enter 0 (zero).

If you want to explicitly assign one or more terms for a particular level, initialize a CDR_CLA_OBJ_TYPE for each term, entering the classification level ID and, for the CLASSIFICATION_ID, the term ID. The PAR_ attributes are not relevant to Report Sets. Do not enter any values for them. If you are not creating a new definition, do not enter values here.

- **PI_INSTCLASSIFICATIONCOLL** (Optional) By default the new instance is classified according to the subtype you assigned it in the PI_INSTANCE_SUBTYPE_ID.

If you want to override the default classifications for one or more classification levels, use this parameter. This is a collection of CDR_CLA_OBJ_TYPES, which have 5 attributes, including CLA_LEVEL_ID and CLASSIFICATION_ID.

If you want the instance to inherit its classifications for a particular level from its parent Work Area, enter the classification level ID and, for the CLASSIFICATION_ID, enter 0 (zero).

If you want to explicitly assign one or more terms for a particular level, initialize a CDR_CLA_OBJ_TYPE for each term, entering the classification level ID and, for the CLASSIFICATION_ID, the term ID. The PAR_ attributes are not relevant to Report Sets. Do not enter any values for them. If you are not creating a new instance, do not enter values here.

12.2.2 Check Out a Report Set

Use this API to check out a Report Set definition.

Name CDR_PUB_RS_REPORT_SET.CHECKOUTREPORTSET

Signature

```
PROCEDURE CHECKOUTREPORTSET(  
  P_API_VERSION IN NUMBER,  
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
```

```

P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
X_RETURN_STATUS OUT VARCHAR2,
X_MSG_COUNT OUT NUMBER,
X_MSG_DATA OUT VARCHAR2,
PIO_CDRREPORTSET IN OUT CDR_BASE_OBJ_TYPE,
PI_COMMENT IN VARCHAR2,
PI_ISINSTONLY IN VARCHAR2,
PI_OPTYPE IN VARCHAR2
);

```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

- **PI_CDRREPORTSET** (Mandatory) This is a parameter of table type CDR_BASE_OBJ_TYPE that contains object attributes. Enter values to identify the Report Set definition that you want to check in.

The following attributes are required: COMPANY_ID,OBJ_ID,OBJ_VER,OBJECT_VERSION_NUMBER,NAMESPACE_OBJ_ID,NAMESPACE_OBJ_VER.

- **PI_COMMENT** (Optional) Enter the reason you are checking in the Report Set definition.
- **PI_ISINSTONLY** (Mandatory) Enter \$YESNO\$NO
- **PI_OPTYPE** (Mandatory) Set to NULL.

12.2.3 Undo a Report Set Checkout

Use this API to undo the checkout of a Report Set definition, discarding any changes that have been made.

Name CDR_PUB_RS_REPORT_SET.UNCHECKOUTREPORTSETDEF

Signature

```

PROCEDURE UNCHECKOUTREPORTSETDEF (
P_API_VERSION IN NUMBER,
P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
X_RETURN_STATUS OUT VARCHAR2,
X_MSG_COUNT OUT NUMBER,
X_MSG_DATA OUT VARCHAR2,
PIO_CDRREPORTSET IN OUT CDR_BASE_OBJ_TYPE
);

```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameter:

- **PIO_CDRREPORTSET** (Mandatory) This is a collection of CDR_BASE_OBJ_TYPES. For each Report Set that you want to remove, initialize a CDR_BASE_OBJ_TYPE and then extend the collection.

The following attributes are required: COMPANY_ID,OBJ_ID,OBJ_VER,OBJECT_VERSION_NUMBER,NAMESPACE_OBJ_ID,NAMESPACE_OBJ_VER.

12.2.4 Copy Objects Into a Report Set

Use this API to copy one or more Report Set Entries and Program instances into a Report Set definition. You may specify a Report Set instance into which you want to copy the Report Set Entries. In that case, the system copies the Report Set Entries into the Report Set definition that the Report Set instance references and the Report Set instance you specify is upgraded to point to the new version of the Report Set definition.

Name CDR_PUB_RS_REPORT_SET.COPYOBJECTSINTOREPORTSET

Signature

```
PROCEDURE COPYOBJECTSINTOREPORTSET(
  P_API_VERSION IN NUMBER,
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
  X_RETURN_STATUS OUT VARCHAR2,
  X_MSG_COUNT OUT NUMBER,
  X_MSG_DATA OUT VARCHAR2,
  PI_CDRBASEOBJECTCOLL IN OUT CDR_BASE_OBJ_COLL,
  PI_CDRTARGETCONTAINEROBJECT IN OUT CDR_BASE_OBJ_TYPE,
  PI_CHECKINFLAG IN VARCHAR2,
  PI_COPYPRGASSGNMT IN VARCHAR2
);
```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

- **PI_CDRBASEOBJECTCOLL** (Mandatory) This is a collection of `cdr_base_obj_` type that is used to describe the Report Set Entries you want to copy.

Enter values for attributes `COMPANY_ID`, `OBJ_ID`, `OBJ_VER`, `NAMESPACE_OBJ_ID`, `NAMESPACE_OBJ_VER`, AND `OBJECT_VERSION_NUMBER` for each RSE you want to copy. All children, grandchildren, etc. RSEs of the RSEs you specify are included in the Copy operation.

Enter `COMPANY_ID`, `OBJ_ID` AND `OBJ_VER`, `NAMESPACE_OBJ_ID`, `NAMESPACE_OBJ_VER`, `OBJECT_VERSION_NUMBER` for each RSE
- **PI_CDRTARGETCONTAINEROBJECT** (Mandatory) This is a parameter of table type `CDR_BASE_OBJ_TYPE` that contains object attributes. Enter values to identify the Report Set into which you want to copy the specified Report Set Entries.

The following attributes are required: `COMPANY_ID`, `OBJ_ID` AND `OBJ_VER`, `NAMESPACE_OBJ_ID`, `NAMESPACE_OBJ_VER`, `OBJECT_VERSION_NUMBER` of target Report Set Definition.
- **PI_CHECKINFLAG** (Mandatory) Enter 'Y' so that the copied Report Set Entries are appropriately numbered in their new location.
- **PI_COPYPRGASSGNMT** (Mandatory) Enter 'Y' to copy any Program instances currently assigned to the Report Set Entries to be copied, with their Planned Output assignments and mappings.

Enter 'N' to avoid copying these Program instances. In this case, all Planned Output assignments are lost.

12.2.5 Get a Summary Output Validation Status

Use this API to calculate the summary output validation status for the entire Report Set hierarchy in the context of a Report Set instance.

Name CDR_PUB_RS_REPORT_SET.GETSOVSFORRSHIERARCHY

Signature

```
FUNCTION GETSOVSFORRSHIERARCHY(
  P_API_VERSION IN NUMBER,
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
  X_RETURN_STATUS OUT VARCHAR2,
  X_MSG_COUNT OUT NUMBER,
  X_MSG_DATA OUT VARCHAR2,
  PI_COMPID IN CDR_NAMINGS.COMPANY_ID%TYPE,
  PI_OBJID IN CDR_NAMINGS.OBJ_ID%TYPE,
  PI_OBJVER IN CDR_NAMING_VERSIONS.OBJ_VER%TYPE,
  PI_RSIOBJID IN CDR_NAMINGS.OBJ_ID%TYPE,
  PI_RSIOBJVER IN CDR_NAMING_VERSIONS.OBJ_VER%TYPE
) RETURN CDR_SOVS_OBJ_COLL;
```

Return Type CDR_SOVS_OBJ_COLL

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

- **PI_COMPID** (Mandatory) Enter the COMPANY_ID of the Column or Table Descriptor.
- **PI_OBJID** (Mandatory) Enter the OBJ_ID of the Column or Table Descriptor.
- **PI_OBJVER** (Mandatory) Enter the OBJ_VER of the Column or Table Descriptor.
- **PI_RSIOBJID** (Mandatory) Enter the object ID of the Report Set instance.
- **PI_RSIOBJVER** (Mandatory) Enter the object version of the Report Set instance.

12.2.6 Modify a Report Set

Use this API to modify a Report Set definition or instance. You can modify the name and description. If you are modifying an instance object, you can also change the 3 REF attribute values to select a different source definition.

Note: To modify a definition, you must first check it out.

Name CDR_PUB_RS_REPORT_SET.MODIFYREPORTSETDETAILS

Signature

```
PROCEDURE MODIFYREPORTSETDETAILS(
  P_API_VERSION IN NUMBER,
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
  X_RETURN_STATUS OUT VARCHAR2,
  X_MSG_COUNT OUT NUMBER,
  X_MSG_DATA OUT VARCHAR2,
```

```

PIO_CDRNAMING IN OUT CDR_NAMING_VERSION_OBJ_TYPE,
PI_REPORTSET IN CDR_REPORT_SET_OBJ_TYPE
);

```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

- **PIO_CDRNAMING** (Mandatory) This is a parameter of table type CDR_NAMING_VERSION_OBJ_TYPE that contains object attributes.

Enter values to identify the Report Set and enter new values for the attributes you want to modify. You can change the name or description for either a definition or instance.

For an instance, you can also change to a different underlying source definition by entering values for the new definition in the three REF attributes. All attributes are required.

Note: Use separate APIs for modifying the validation status and the version label: CDR_PUB_VL_VALIDATION.UPDATE VAL STATUS and CDR_PUB_DF_NAMING.UPDATEVERSIONLABEL.

- **PI_REPORTSET** (Mandatory) This is a parameter of table type CDR_REPORT_SET_OBJ_TYPE that contains Report Set attributes.

Enter values to identify the Report Set definition or instance that you want to modify and enter new values for the attributes you want to modify. You can change the TITLE, the UNIQUE_NUMBERING_FLAG_RC, and the STRICT_NUMBERING_FLAG_RC. All attributes are required.

12.2.7 Move Objects into a Report Set

Use this API to move Program instances and Report Set Entries into a Report Set definition.

Name CDR_PUB_RS_REPORT_SET.MOVEOBJECTSINTOREPORTSET

Signature

```

PROCEDURE MOVEOBJECTSINTOREPORTSET(
  P_API_VERSION IN NUMBER,
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
  X_RETURN_STATUS OUT VARCHAR2,
  X_MSG_COUNT OUT NUMBER,
  X_MSG_DATA OUT VARCHAR2,
  PI_CDRBASEOBJECTCOLL IN OUT CDR_BASE_OBJ_COLL,
  PI_CDRTARGETCONTAINEROBJECT IN OUT CDR_BASE_OBJ_TYPE
);

```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

- **PI_CDRBASEOBJECTCOLL** (Mandatory) This is a collection of cdr_base_obj_type that is used to describe the Report Set Entries you want to copy.

Enter values for attributes COMPANY_ID, OBJ_ID, OBJ_VER, NAMESPACE_OBJ_ID, NAMESPACE_OBJ_VER, AND OBJECT_VERSION_NUMBER for each

RSE you want to copy. All children, grandchildren, etc. RSEs of the RSEs you specify are included in the Copy operation.

Enter COMPANY_ID, OBJ_ID AND OBJ_VER, NAMESPACE_OBJ_ID, NAMESPACE_OBJ_VER, OBJECT_VERSION_NUMBER for each RSE

- **PI_CDRTARGETCONTAINEROBJECT** (Mandatory) This is a parameter of table type CDR_BASE_OBJ_TYPE that contains object attributes. Enter values to identify the Report Set into which you want to copy the specified Report Set Entries.

The following attributes are required: COMPANY_ID, OBJ_ID AND OBJ_VER, NAMESPACE_OBJ_ID, NAMESPACE_OBJ_VER, OBJECT_VERSION_NUMBER of target Report Set Definition

12.2.8 Remove Objects from a Report Set

Use this API to remove one or more objects from a Report Set.

Name CDR_PUB_RS_REPORT_SET.REMOVEOBJECTSFROMREPORTSET

Signature

```
PROCEDURE REMOVEOBJECTSFROMREPORTSET (
  P_API_VERSION IN NUMBER,
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
  X_RETURN_STATUS OUT VARCHAR2,
  X_MSG_COUNT OUT NUMBER,
  X_MSG_DATA OUT VARCHAR2,
  PI_CDRBASEOBJECTCOLL IN OUT CDR_BASE_OBJ_COLL
);
```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameter:

PI_CDRBASEOBJECTCOLL (Mandatory) This is a collection of cdr_base_obj_type that is used to describe the Report Set Entries you want to copy.

Enter values for attributes COMPANY_ID, OBJ_ID, OBJ_VER, NAMESPACE_OBJ_ID, NAMESPACE_OBJ_VER, AND OBJECT_VERSION_NUMBER for each RSE you want to copy. All children, grandchildren, etc. RSEs of the RSEs you specify are included in the Copy operation.

12.2.9 Check In a Report Set

Use this API to check in a Report Set definition.

Name CDR_PUB_RS_REPORT_SET.CHECKINREPORTSETDEF

Signature

```
PROCEDURE CHECKINREPORTSETDEF (
  P_API_VERSION IN NUMBER,
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
  X_RETURN_STATUS OUT VARCHAR2,
  X_MSG_COUNT OUT NUMBER,
```

```
X_MSG_DATA OUT VARCHAR2,  
PI_CDRREPORTSET IN OUT CDR_BASE_OBJ_TYPE,  
PI_COMMENT IN VARCHAR2  
);
```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

- **PI_CDRREPORTSET** (Mandatory) This is a parameter of table type CDR_BASE_OBJ_TYPE that contains object attributes. Enter values to identify the Report Set definition that you want to check in.

The following attributes are required: COMPANY_ID,OBJ_ID,OBJ_VER,OBJECT_VERSION_NUMBER,NAMESPACE_OBJ_ID,NAMESPACE_OBJ_VER.

- **PI_COMMENT** (Optional) Enter the reason you are checking in the Report Set definition.

12.2.10 Remove a Report Set Definition

Use this API to remove a Report Set definition or instance.

Name CDR_PUB_RS_REPORT_SET.REMOVEREPORTSET

Signature

```
PROCEDURE REMOVEREPORTSET(  
  P_API_VERSION IN NUMBER,  
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,  
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,  
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,  
  X_RETURN_STATUS OUT VARCHAR2,  
  X_MSG_COUNT OUT NUMBER,  
  X_MSG_DATA OUT VARCHAR2,  
  PIO_CDRREPORTSET IN OUT CDR_BASE_OBJ_TYPE  
);
```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

PIO_CDRREPORTSET (Mandatory) This is a collection of CDR_BASE_OBJ_TYPES. For each Report Set that you want to remove, initialize a CDR_BASE_OBJ_TYPE and then extend the collection.

The following attributes are required: COMPANY_ID,OBJ_ID,OBJ_VER,OBJECT_VERSION_NUMBER,NAMESPACE_OBJ_ID,NAMESPACE_OBJ_VER.

12.2.11 Remove a Report Set

Use this API to remove one or more objects from a Report Set.

Name CDR_PUB_RS_REPORT_SET.REMOVEREPORTSETS

Signature

```
PROCEDURE REMOVEREPORTSETS(  
  P_API_VERSION IN NUMBER,  
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,  
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,  
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,  
  X_RETURN_STATUS OUT VARCHAR2,
```



```

X_MSG_COUNT OUT NUMBER,
X_MSG_DATA OUT VARCHAR2,
PIO_CDRBASEOBJCOLL IN OUT CDR_BASE_OBJ_COLL
);

```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameter:

PI_CDRBASEOBJECTCOLL (Mandatory) This is a collection of cdr_base_obj_type that is used to describe the Report Set Entries you want to copy.

Enter values for attributes COMPANY_ID, OBJ_ID, OBJ_VER, NAMESPACE_OBJ_ID, NAMESPACE_OBJ_VER, AND OBJECT_VERSION_NUMBER for each RSE you want to copy. All children, grandchildren, etc. RSEs of the RSEs you specify are included in the Copy operation.

12.3 Create and Modify Overlay Template Definitions

This is a public interface used to create, modify and remove OTD files, which are contained by Overlay Template Definitions (OTDs) and used in Report Sets.

This section contains the following topics:

- [Section 12.3.1, "Create an Overlay Template Definition"](#)
- [Section 12.3.2, "Modify an Overlay Template Definition File Definition"](#)
- [Section 12.3.3, "Get an Overlay Template Definition File as a BLOB"](#)
- [Section 12.3.4, "Remove an Overlay Template Definition File Definition"](#)

12.3.1 Create an Overlay Template Definition

Use this API to create an OTD File definition after you have created an Overlay Template Definition (OTD). Use CDR_PUB_RS_OVERLAY_TEMPLATE.CopyObjectsIntoOTD to assign this OTD File definition to an OTD.

Name CDR_PUB_RS_OTD_FILE.CREATEOTDFILE

Signature

```

PROCEDURE CREATEOTDFILE(
  P_API_VERSION IN NUMBER,
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
  X_RETURN_STATUS OUT VARCHAR2,
  X_MSG_COUNT OUT NUMBER,
  X_MSG_DATA OUT VARCHAR2,
  PIO_OTDF_SOURCECDRNAMING IN OUT CDR_NAMING_VERSION_OBJ_TYPE,
  PI_CDROTDFILEOBJTYPE IN OUT CDR_OTDF_OBJ_TYPE,
  PI_LOBMODE IN VARCHAR := NULL
);

```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

- **PIO_OTDF_SOURCECDRNAMING** (Mandatory) This is a parameter of table type CDR_NAMING_VERSION_OBJ_TYPE that contains object attributes. Enter values for the OTD File that you are creating, using the Namespace attributes to identify the parent Overlay Template Definition.

For OBJECT_TYPE_RC enter \$OBJTYPES\$OVERLAYTEMPLATEFILE. The following attributes are required: COMPANY_ID,NAME,NAMESPACE_OBJ_ID,NAMESPACE_OBJ_VER.

- **PI_CDROTDFILEOBJTYPE** (Mandatory) This is a parameter of table type CDR_OTDF_OBJ_TYPE that contains object attributes specific to Overlay Template Definition Files. Enter values for the OTD File that you are creating.

The following attributes are required: OTDF_TYPE_RC,OTDF_PGNO_FLAG,OTDF_ORIENTATION_RC,OTDF_PAPERSIZE,OTDF_LANGUAGE_RC,OTDF_ROTATION,OTDF_FILENAME,OTDF_BLOB.

- **PI_LOBMODE** (Optional) Enter 'IN_DIRECT'. No other value is supported except Null.

12.3.2 Modify an Overlay Template Definition File Definition

Use this API to modify an OTD File definition.

Name CDR_PUB_RS_OTD_FILE.MODIFYOTDFILE

Signature

```
PROCEDURE MODIFYOTDFILE(
  P_API_VERSION IN NUMBER,
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
  X_RETURN_STATUS OUT VARCHAR2,
  X_MSG_COUNT OUT NUMBER,
  X_MSG_DATA OUT VARCHAR2,
  PIO_OTDF_SOURCECDRNAMING IN OUT CDR_NAMING_VERSION_OBJ_TYPE,
  PI_CDROTDFILEOBJTYPE IN OUT CDR_OTDF_OBJ_TYPE,
  PI_LOBMODE IN VARCHAR := NULL
);
```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

- **PIO_OTDF_SOURCECDRNAMING** (Mandatory) This is a parameter of table type CDR_NAMING_VERSION_OBJ_TYPE that contains object attributes. Enter values to identify the OTD File that you are modifying and enter new values for attributes you want to change. You can change the name and description. All attributes are required.
- **PI_CDROTDFILEOBJTYPE** (Mandatory) This is a parameter of table type CDR_OTDF_OBJ_TYPE that contains object attributes specific to Overlay Template Definition Files. Enter values to identify the OTD File that you are modifying and enter new values for attributes you want to change. You can change values for Page Number, Orientation, Paper Size, Rotation, or File Name. All attributes are required.
- **PI_LOBMODE** (Optional) Enter 'IN_DIRECT'. No other value is supported except Null.

12.3.3 Get an Overlay Template Definition File as a BLOB

Use this API to upload the RTF file.

Name CDR_PUB_RS_OTD_FILE.GETOTDBLOB

Signature

```
FUNCTION GETOTDBLOB (
  P_API_VERSION IN NUMBER,
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
  COMPANYID IN CDR_NAMINGS.COMPANY_ID%TYPE,
  OBJID IN CDR_NAMINGS.OBJ_ID%TYPE,
  OBJVER IN CDR_NAMING_VERSIONS.OBJ_VER%TYPE
) RETURN BLOB;
```

Return Type BLOB

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

- **COMPANYID** (Mandatory) Enter the Company ID of the OTD File definition.
- **OBJID** (Mandatory) Enter the Object ID of the OTD File definition.
- **OBJVER** (Mandatory) Enter the Object version of the OTD File definition.

12.3.4 Remove an Overlay Template Definition File Definition

Use this API to remove one or more OTD File definitions from an OTD.

Name CDR_PUB_RS_OTD_FILE.REMOVEOTDFILE

Signature

```
PROCEDURE REMOVEOTDFILE (
  P_API_VERSION IN NUMBER,
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
  X_RETURN_STATUS OUT VARCHAR2,
  X_MSG_COUNT OUT NUMBER,
  X_MSG_DATA OUT VARCHAR2,
  PIO_CDRBASEOBJCOLL IN OUT CDR_BASE_OBJ_COLL
);
```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameter:

PIO_CDRBASEOBJCOLL (Mandatory) This is a collection of CDR_BASE_OBJ_TYPES. For each OTD File definition that you want to remove, initialize a CDR_BASE_OBJ_TYPE and then extend the collection.

The following attributes are required: COMPANY_ID,OBJ_ID,OBJ_VER,OBJECT_VERSION_NUMBER,NAMESPACE_OBJ_ID,NAMESPACE_OBJ_VER.

12.4 Report Set Overlay Template

This package is used to create, check in, check out, and modify the Report Set Entry templates.

This section contains the following topics:

- [Section 12.4.1, "Create an Overlay Template"](#)
- [Section 12.4.2, "Check Out an Overlay Template"](#)

- [Section 12.4.3, "Undo an Overlay Template Checkout"](#)
- [Section 12.4.4, "Copy Objects Into an Overlay Template"](#)
- [Section 12.4.5, "Modify an Overlay Template"](#)
- [Section 12.4.6, "Check In an Overlay Template"](#)
- [Section 12.4.7, "Remove an Overlay Template"](#)

12.4.1 Create an Overlay Template

Use this API to create an Overlay Template definition (OTD).

Name CDR_PUB_RS_OVERLAY_TEMPLATE.CREATEOVERLAYTEMPLATE

Signature

```
PROCEDURE CREATEOVERLAYTEMPLATE (  
  P_API_VERSION IN NUMBER,  
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,  
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,  
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,  
  X_RETURN_STATUS OUT VARCHAR2,  
  X_MSG_COUNT OUT NUMBER,  
  X_MSG_DATA OUT VARCHAR2,  
  PIO_OTD_SOURCECDRNAMING IN OUT CDR_NAMING_VERSION_OBJ_TYPE,  
  PI_CDROTD OBJTYPE IN OUT CDR_OTD_OBJ_TYPE,  
  PO_DEFCLASSIFICATIONCOLL IN CDR_CLASSIFICATIONS_COLL  
);
```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

- **PIO_OTD_SOURCECDRNAMING** (Mandatory) This is a parameter of table type CDR_NAMING_VERSION_OBJ_TYPE that contains object attributes. Enter values for the Overlay Template Definition (OTD) that you are creating.

For OBJECT_TYPE_RC enter \$OBJTYPES\$OVERLAYTEMPLATE. The following attributes are required: COMPANY_ID, NAME, NAMESPACE_OBJ_ID, NAMESPACE_OBJ_VER.
- **PI_CDROTD OBJTYPE** (Mandatory) This is a parameter of table type CDR_OTD_OBJ_TYPE that contains object attributes specific to Overlay Templates. Enter values for the Overlay Template that you are creating.

The following attributes are required: OTD_DEFAULT_PAPERSIZE, OTD_DEFAULT_LANGUAGE_RC.
- **PO_DEFCLASSIFICATIONCOLL** (Optional) By default the new definition is classified according to the subtype you assigned it in the CDR_NAMING_VERSION_OBJ_TYPE.

If you want to override the default classifications for one or more classification levels, use this parameter. This is a collection of CDR_CLA_OBJ_TYPES, which have 5 attributes, including CLA_LEVEL_ID and CLASSIFICATION_ID.

If you want the definition to inherit its classifications for a particular level from its parent, enter the classification level ID and, for the CLASSIFICATION_ID, enter 0 (zero).

If you want to explicitly assign one or more terms for a particular level, initialize a CDR_CLA_OBJ_TYPE for each term, entering the classification level ID and, for

the CLASSIFICATION_ID, the term ID. The PAR_ attributes are not relevant to OTDs. Do not enter any values for them.

12.4.2 Check Out an Overlay Template

Use this API to check out an Overlay Template Definition (OTD).

Name CDR_PUB_RS_OVERLAY_TEMPLATE.CHECKOUTOVERLAYTEMPLATE

Signature

```
PROCEDURE CHECKOUTOVERLAYTEMPLATE (
  P_API_VERSION IN NUMBER,
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
  X_RETURN_STATUS OUT VARCHAR2,
  X_MSG_COUNT OUT NUMBER,
  X_MSG_DATA OUT VARCHAR2,
  PIO_BASEOBJECT IN OUT CDR_BASE_OBJ_TYPE,
  PI_COMMENT IN VARCHAR2,
  PI_ISINSTONLY IN VARCHAR2
);
```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

- **PIO_BASEOBJECT** (Mandatory) This is a parameter of table type CDR_BASE_OBJ_TYPE that contains object attributes. Enter values to identify the OTD that you want to check in.

The following attributes are required: COMPANY_ID,OBJ_ID,OBJ_VER,OBJECT_VERSION_NUMBER,NAMESPACE_OBJ_ID,NAMESPACE_OBJ_VER.

- **PI_COMMENT** (Optional) Enter the reason you are checking in the OTD.
- **PI_ISINSTONLY** (Mandatory) Enter \$YESNO\$NO.

12.4.3 Undo an Overlay Template Checkout

Use this API to undo the checkout of an Overlay Template Definition (OTD).

Name CDR_PUB_RS_OVERLAY_TEMPLATE.UNDOCHECKOUTOVERLAYTEMPLATE

Signature

```
PROCEDURE UNDOCHECKOUTOVERLAYTEMPLATE (
  P_API_VERSION IN NUMBER,
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
  X_RETURN_STATUS OUT VARCHAR2,
  X_MSG_COUNT OUT NUMBER,
  X_MSG_DATA OUT VARCHAR2,
  PIO_BASEOBJECT IN OUT CDR_BASE_OBJ_TYPE
);
```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

PIO_BASEOBJECT (Mandatory) This is a parameter of table type CDR_BASE_OBJ_TYPE that contains object attributes. Enter values to identify the OTD whose checkout you want to undo.

The following attributes are required: COMPANY_ID,OBJ_ID,OBJ_VER,OBJECT_VERSION_NUMBER,NAMESPACE_OBJ_ID,NAMESPACE_OBJ_VER.

12.4.4 Copy Objects Into an Overlay Template

Use this API to copy OTD File definitions into an Overlay Template Definition.

Name CDR_PUB_RS_OVERLAY_TEMPLATE.COPYOBJECTSINTOOTD

Signature

```
PROCEDURE COPYOBJECTSINTOOTD(
  P_API_VERSION IN NUMBER,
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
  X_RETURN_STATUS OUT VARCHAR2,
  X_MSG_COUNT OUT NUMBER,
  X_MSG_DATA OUT VARCHAR2,
  PI_CDRBASEOBJCOLL IN CDR_BASE_OBJ_COLL,
  PI_CDRTARGETCONTAINEROBJECT IN CDR_BASE_OBJ_TYPE
);
```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

- **PI_CDRBASEOBJCOLL** (Mandatory) This is a collection of CDR_BASE_OBJ_TYPES. For each OTD file definition that you want to copy into an OTD, initialize a CDR_BASE_OBJ_TYPE and then extend the collection.

The following attributes are required: COMPANY_ID,OBJ_ID,OBJ_VER,OBJECT_VERSION_NUMBER,NAMESPACE_OBJ_ID,NAMESPACE_OBJ_VER.

- **PI_CDRTARGETCONTAINEROBJECT** (Mandatory) This is a parameter of table type CDR_BASE_OBJ_TYPE that contains object attributes. Enter values to identify the OTD into which you want to copy OTD File definitions. The following attributes are required: COMPANY_ID,OBJ_ID,OBJ_VER,OBJECT_VERSION_NUMBER,NAMESPACE_OBJ_ID,NAMESPACE_OBJ_VER.

12.4.5 Modify an Overlay Template

Use this API to modify an Overlay Template Definition (OTD).

Name CDR_PUB_RS_OVERLAY_TEMPLATE.MODIFYOVERLAYTEMPLATE

Signature

```
PROCEDURE MODIFYOVERLAYTEMPLATE(
  P_API_VERSION IN NUMBER,
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
  X_RETURN_STATUS OUT VARCHAR2,
  X_MSG_COUNT OUT NUMBER,
  X_MSG_DATA OUT VARCHAR2,
  PIO_OTD_SOURCECDRNAMING IN OUT CDR_NAMING_VERSION_OBJ_TYPE,
```

```
PI_CDROTD OBJTYPE IN OUT CDR_OTD_OBJ_TYPE
);
```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

- **PIO_OTD_SOURCECDRNAMING** (Mandatory) This is a parameter of table type CDR_NAMING_VERSION_OBJ_TYPE that contains object attributes. Enter values to identify the Overlay Template Definition (OTD) that you are modifying, and enter new values for the attributes you want to modify. You can change the name and description. All attributes are required.
- **PI_CDROTD OBJTYPE** Object Type of Overlay Template Definition

12.4.6 Check In an Overlay Template

Use this API to check in an Overlay Template Definition.

Name CDR_PUB_RS_OVERLAY_TEMPLATE.CHECKINOVERLAYTEMPLATE

Signature

```
PROCEDURE CHECKINOVERLAYTEMPLATE (
  P_API_VERSION IN NUMBER,
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
  X_RETURN_STATUS OUT VARCHAR2,
  X_MSG_COUNT OUT NUMBER,
  X_MSG_DATA OUT VARCHAR2,
  PIO_BASEOBJECT IN OUT CDR_BASE_OBJ_TYPE,
  PI_COMMENT IN VARCHAR2
);
```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

- **PIO_BASEOBJECT** (Mandatory) This is a parameter of table type CDR_BASE_OBJ_TYPE that contains object attributes. Enter values to identify the OTD that you want to check in.

The following attributes are required: COMPANY_ID,OBJ_ID,OBJ_VER,OBJECT_VERSION_NUMBER,NAMESPACE_OBJ_ID,NAMESPACE_OBJ_VER.

- **PI_COMMENT** (Optional) Enter the reason you are checking in the OTD.

12.4.7 Remove an Overlay Template

Use this API to remove one or more Overlay Template Definitions (OTDs).

Name CDR_PUB_RS_OVERLAY_TEMPLATE.REMOVEOVERLAYTEMPLATE

Signature

```
PROCEDURE REMOVEOVERLAYTEMPLATE (
  P_API_VERSION IN NUMBER,
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
  X_RETURN_STATUS OUT VARCHAR2,
  X_MSG_COUNT OUT NUMBER,
```

```
X_MSG_DATA OUT VARCHAR2,  
PIO_CDRBASEOBJCOLL IN OUT CDR_BASE_OBJ_COLL  
);
```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameter:

PIO_CDRBASEOBJCOLL (Mandatory) This is a collection of CDR_BASE_OBJ_TYPES. For each OTD that you want to remove, initialize a CDR_BASE_OBJ_TYPE and then extend the collection.

The following attributes are required: COMPANY_ID,OBJ_ID,OBJ_VER,OBJECT_VERSION_NUMBER,NAMESPACE_OBJ_ID,NAMESPACE_OBJ_VER.

Software Source Codes

This is a public interface for Source Code-related operations including creating, modifying, and removing Source Code objects.

13.1 Create and Modify Source Code

This section contains the following topics:

- [Section 13.1.1, "Create a Source Code Object"](#)
- [Section 13.1.2, "Get a Source Code CLOB"](#)
- [Section 13.1.3, "Modify Source Code"](#)
- [Section 13.1.4, "Set the Primary Flag to Yes"](#)
- [Section 13.1.5, "Update a Shareable Flag"](#)
- [Section 13.1.6, "Remove a Source Code Object"](#)

13.1.1 Create a Source Code Object

Use this API to create a new instance of an existing Source Code definition or a new Source Code definition and an instance of it.

Note: Source Code definitions and instances are always contained in Program definitions. You cannot create a Source Code definition without also creating an instance of it in the same Program definition.

Name CDR_PUB_DF_SOURCECODE.CREATE_SOURCECODE

Signature

```
PROCEDURE CREATE_SOURCECODE(
  P_API_VERSION IN NUMBER,
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
  X_RETURN_STATUS OUT VARCHAR2,
  X_MSG_COUNT OUT NUMBER,
  X_MSG_DATA OUT VARCHAR2,
  PIO_SCREF_SOURCECDRNAMING IN OUT CDR_NAMING_VERSION_OBJ_TYPE,
  PI_CDRCOBJTYPE IN OUT CDR_SRCCODE_OBJ_TYPE,
  PIO_CDRCREFOBJTYPE IN OUT CDR_SRCCODE_REF_OBJ_TYPE,
  PI_CREATEOBJECT IN VARCHAR2,
  PI_DEFINITON_SUBTYPE_ID IN CDR_NAMINGS.OBJECT_SUBTYPE_ID%TYPE,
```

```
PI_VLOBMODE IN VARCHAR2 := NULL,  
PIO_CDRSCBLOB IN OUT CDR_SRCCODE_BLOB_OBJ_TYPE,  
PIO_CDRSCCLOB IN OUT CDR_SRCCODE_CLOB_OBJ_TYPE  
);
```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

- **PIO_SCREF_SOURCECDRNAMING** (Mandatory) This is a parameter of table type CDR_NAMING_VERSIONS_OBJ_TYPE that contains CDR Naming Version attributes.

Enter values for the Source Code instance you are creating. For OBJECT_TYPE_RC enter \$OBJTYPES\$SRCCDEREF.
- **PI_CDRSCOBJTYPE** (Optional) This is a parameter of table type CDR_SRCCODE_OBJ_TYPE that contains object attributes specific to Source Code definitions.

If you are creating a new definition, enter values for the new Source Code definition. The following attributes are required: TECH_TYPE_ID,SRCCODE_TYPE_RC,SHAREABLE_FLAG_RC,ORACLE_PACKAGE_NAME.

If you are creating an instance of an existing Source Code definition, do not enter any values here.
- **PIO_CDRSCREFOBJTYPE** (Optional) This is a parameter of table type CDR_SRCCODE_REF_OBJ_TYPE that contains object attributes specific to Source Code instances.

If you are creating a new instance, enter values for it.

If you are creating a new Source Code definition only, do not enter any values here.
- **PI_CREATEOBJECT** (Mandatory) Enter INST to create a instance of an existing definition or BOTH to create a new definition and an instance of it.
- **PI_DEFINITON_SUBTYPE_ID** (Optional) Enter a subtype for the Source Code definition.

If you do not enter a value, the API creates the definition with the default subtype.
- **PI_VLOBMODE** Enter 'DIRECT' if your source code is already contained in a BLOB or CLOB file. You enter information about it in one of the next two parameters and the API uploads it immediately.

If you enter anything other than 'DIRECT' the API creates a new, empty BLOB and CLOB in the next parameters. It prompts you to paste your source code in and then uploads the BLOB or CLOB.
- **PIO_CDRSCBLOB** This is a compound object of type CDR_SRCCODE_BLOB_OBJ_TYPE.

If the source code is binary, enter its name for the FILE_NAME attribute value and the BLOB itself for the FILE_BLOB attribute value.
- **PIO_CDRSCCLOB** This is a compound object of type CDR_SRCCODE_CLOB_OBJ_TYPE.

If the source code is text-based, enter its name for the FILE_NAME attribute value and the CLOB itself for the FILE_CLOB attribute value.

13.1.2 Get a Source Code CLOB

Use this API to get the source code CLOB.

Name CDR_PUB_DF_SOURCECODE.GETSOURCECODE

Signature

```
FUNCTION GETSOURCECODE (
  P_API_VERSION IN NUMBER,
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
  COMPANYID IN CDR_NAMINGS.COMPANY_ID%TYPE,
  OBJID IN CDR_NAMINGS.OBJ_ID%TYPE,
  OBJVER IN CDR_NAMING_VERSIONS.OBJ_VER%TYPE,
  NSOBJID IN CDR_NAMINGS.OBJ_ID%TYPE,
  NSOBJVER IN CDR_NAMING_VERSIONS.OBJ_VER%TYPE
) RETURN CLOB;
```

Return Type CLOB

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

- **COMPANYID** (Mandatory) Enter your company ID.
- **OBJID** (Mandatory) Enter the object ID of the Source Code definition.
- **OBJVER** (Mandatory) Enter the object version (OBJ_VER) of the Source Code definition.
- **NSOBJID** (Mandatory) Enter the object ID of the Program definition that contains the Source Code definition.
- **NSOBJVER** (Mandatory) Enter the object version (OBJ_VER) of the Program definition that contains the Source Code definition.

13.1.3 Modify Source Code

Use this API to modify a Source Code definition or instance. You can modify the name and description. If you are modifying a Source Code instance, you can also change the 3 REF attribute values to select a different source definition.

Name CDR_PUB_DF_SOURCECODE.MODIFYSOURCECODEDETAILS

Signature

```
PROCEDURE MODIFYSOURCECODEDETAILS (
  P_API_VERSION IN NUMBER,
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
  X_RETURN_STATUS OUT VARCHAR2,
  X_MSG_COUNT OUT NUMBER,
  X_MSG_DATA OUT VARCHAR2,
  PIO_SCREF_SOURCECDRNAMING IN OUT CDR_NAMING_VERSION_OBJ_TYPE,
  PI_CDRCSCOBJTYPE IN OUT CDR_SRCCODE_OBJ_TYPE,
  PIO_CDRCSCREFOBJTYPE IN OUT CDR_SRCCODE_REF_OBJ_TYPE,
  PI_VLOBMODE IN VARCHAR2 := NULL,
  PIO_CDRCSCBLOB IN OUT CDR_SRCCODE_BLOB_OBJ_TYPE,
```

```
PIO_CDRSCCLOB IN OUT CDR_SRCCODE_CLOB_OBJ_TYPE
);
```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

- **PIO_SCREF_SOURCECDRNAMING** (Mandatory) This is a parameter of table type CDR_NAMING_VERSION_OBJ_TYPE that contains object attributes. Enter values to identify the Source Code definition or instance and enter new values for the attributes you want to modify.

You can change the name or description for either the definition or instance. For an instance you can also change to a different underlying source definition by entering values for the new definition in the three REF attributes.

Note: Neither Source Code definitions nor instances can have a validation status or a version label. All attributes are required.

- **PI_CDRSCOBJTYPE** (Mandatory) This is a parameter of table type CDR_SRCCODE_OBJ_TYPE that contains object attributes specific to Source Code definitions.

If you are modifying a Source Code definition, enter values to identify the definition and enter new values for the attributes you want to modify.

You can modify SHAREABLE_FLAG_RC, ORACLE_PACKAGE_NAME, and ORACLE_PROCEDURE_NAME. All attributes are required.

- **PIO_CDRSCREFOBJTYPE** (Mandatory) This is a parameter of table type CDR_SRCCODE_REF_OBJ_TYPE that contains object attributes specific to Source Code instances.

If you are modifying a Source Code instance, enter values to identify the instance and enter new values for the attributes you want to modify. You can modify PRIMARY_FLAG_RC and FILEREF. All attributes are required.

- **PI_VLOBMODE** Enter 'DIRECT' if your source code is already contained in a BLOB or CLOB file. You enter information about it in one of the next two parameters and the API uploads it immediately.

If you enter anything other than 'DIRECT' the API creates a new, empty BLOB and CLOB in the next parameters. It prompts you to paste in your source code and then uploads the BLOB or CLOB.

- **PIO_CDRSCBLOB** This is a compound object of type CDR_SRCCODE_BLOB_OBJ_TYPE.

If the source code is binary, enter its name for the FILE_NAME attribute value and the BLOB itself for the FILE_BLOB attribute value.

- **PIO_CDRSCCLOB** This is a compound object of type CDR_SRCCODE_CLOB_OBJ_TYPE.

If the source code is text-based, enter its name for the FILE_NAME attribute value and the CLOB itself for the FILE_CLOB attribute value. Enter CLOB if the source code file is a character large object.

13.1.4 Set the Primary Flag to Yes

Use this API to set the Primary Flag attribute of a specified Source Code instance to Yes. If any other Source Code instance in the parent Program is currently set to Yes, the API resets its flag to No.

Name CDR_PUB_DF_SOURCECODE.SETPRIMARYFLAGRC

Signature

```
PROCEDURE SETPRIMARYFLAGRC (
  P_API_VERSION IN NUMBER,
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
  X_RETURN_STATUS OUT VARCHAR2,
  X_MSG_COUNT OUT NUMBER,
  X_MSG_DATA OUT VARCHAR2,
  PI_CDRSCREFBASEOBJTYPE IN CDR_BASE_OBJ_TYPE
);
```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

PI_CDRSCREFBASEOBJTYPE (Mandatory) This is a parameter of table type CDR_BASE_OBJ_TYPE that contains object attributes. Enter values to identify the Source Code instance whose PRIMARY_FLAG_RC you want to set to \$YESNO\$YES.

The following attributes are required: COMPANY_ID,OBJ_ID,OBJ_VER,OBJECT_VERSION_NUMBER,NAMESPACE_OBJ_ID,NAMESPACE_OBJ_VER.

13.1.5 Update a Shareable Flag

Use this API to set the Sharable attribute for a Source Code definition.

Name CDR_PUB_DF_SOURCECODE.UPDATESHAREABLEFLAGRC

Signature

```
PROCEDURE UPDATESHAREABLEFLAGRC (
  P_API_VERSION IN NUMBER,
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
  X_RETURN_STATUS OUT VARCHAR2,
  X_MSG_COUNT OUT NUMBER,
  X_MSG_DATA OUT VARCHAR2,
  PI_CDRSCBASEOBJTYPE IN OUT CDR_BASE_OBJ_TYPE,
  PI_CHANGESTATUSTO IN VARCHAR2
);
```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

- **PI_CDRSCBASEOBJTYPE** (Mandatory) This is a parameter of table type CDR_BASE_OBJ_TYPE that contains object attributes. Enter values to identify the Source Code definition that you want to make sharable or not sharable.

The following attributes are required: COMPANY_ID,OBJ_ID,OBJ_VER,OBJECT_VERSION_NUMBER,NAMESPACE_OBJ_ID,NAMESPACE_OBJ_VER.

- **PI_CHANGESTATUSTO** (Mandatory) Enter SET to set the SHAREABLE_FLAG_RC to \$YESNO\$YES or RESET to set the SHAREABLE_FLAG_RC to '\$YESNO\$NO'.

13.1.6 Remove a Source Code Object

Use this API to remove one or more Source Code definitions or instances.

Name CDR_PUB_DF_SOURCECODE.REMOVESOURCECODE

Signature

```
PROCEDURE REMOVESOURCECODE(  
  P_API_VERSION IN NUMBER,  
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,  
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,  
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,  
  X_RETURN_STATUS OUT VARCHAR2,  
  X_MSG_COUNT OUT NUMBER,  
  X_MSG_DATA OUT VARCHAR2,  
  PIO_CDRBASEOBJCOLL IN OUT CDR_BASE_OBJ_COLL  
);
```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

PIO_CDRBASEOBJCOLL (Mandatory) This is a collection of CDR_BASE_OBJ_TYPES.

For each Source Code that you want to remove, initialize a CDR_BASE_OBJ_TYPE and then extend the collection. The following attributes are required: COMPANY_ID, OBJ_ID, OBJ_VER, OBJECT_VERSION_NUMBER, NAMESPACE_OBJ_ID, NAMESPACE_OBJ_VER.

This is a public interface for all operations related to Tables, Columns, and Constraints; including creation, deletion, modification, and checking in and out of these objects.

14.1 Create and Modify Tables

This section contains the following topics:

- [Section 14.1.1, "Create a Table Definition"](#)
- [Section 14.1.2, "Create a Table Instance"](#)
- [Section 14.1.3, "Create a Temporary Blob"](#)
- [Section 14.1.4, "Create a Table Column"](#)
- [Section 14.1.5, "Create a Table Constraint"](#)
- [Section 14.1.6, "Modify a Table Definition"](#)
- [Section 14.1.7, "Modify a Table Descriptor"](#)
- [Section 14.1.8, "Modify a Table Instance"](#)
- [Section 14.1.9, "Reorder a Column"](#)
- [Section 14.1.10, "Upload a Table Descriptor or Column"](#)
- [Section 14.1.11, "Check in a Table Object"](#)
- [Section 14.1.12, "Remove a Single Object"](#)

14.1.1 Create a Table Definition

Use this API to create a Table definition.

Name CDR_PUB_DF_TABLE.CREATETABLEDEFINITION

Signature

```
PROCEDURE CREATETABLEDEFINITION(
  P_API_VERSION IN NUMBER,
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
  X_RETURN_STATUS OUT VARCHAR2,
  X_MSG_COUNT OUT NUMBER,
  X_MSG_DATA OUT VARCHAR2,
  PIO_NAMING IN OUT CDR_NAMING_VERSION_OBJ_TYPE,
  PIO_TABLE IN OUT CDR_TABLE_OBJ_TYPE,
```

```

PI_INSTANCESUBTYPEID IN     NUMBER,
PI_DEFCLASSIFICATIONCOLL IN   CDR_CLASSIFICATIONS_COLL,
PI_INSTCLASSIFICATIONCOLL IN  CDR_CLASSIFICATIONS_COLL
);

```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

- **PIO_NAMING** (Mandatory) This is a parameter of table type CDR_NAMING_VERSIONS_OBJ_TYPE that contains CDR Naming Version attributes. For OBJECT_TYPE_RC enter \$OBJTYPES\$TABLE.
- **PIO_TABLE** (Optional) This is a parameter of table type CDR_TABLE_OBJ_TYPE that contains object attributes specific to Tables.

If you are creating a new definition, enter values for the new Table. The following attributes are required: COMPANY_ID,OBJ_ID,OBJ_VER,ORACLE_NAME,SAS_NAME, SASV6FLAGRC = '\$YESNO\$NO', SNAPSHOTFLAGRC= '\$YESNO\$YES', BLINDINGFLAGRC= '\$YESNO\$YES', PROCESSTYPERC = '\$PROCESSTYPES\$STAGINGWAUDIT'

If you are creating an instance of an existing Table, do not enter any values here.

- **PI_INSTANCESUBTYPEID** (Mandatory) Enter NULL here.
- **PI_DEFCLASSIFICATIONCOLL** (Optional) By default the new definition is classified according to the subtype you assigned it in the CDR_NAMING_VERSION_OBJ_TYPE.

If you want to override the default classifications for one or more classification levels, use this parameter. This is a collection of CDR_CLA_OBJ_TYPES, which have 5 attributes, including CLA_LEVEL_ID and CLASSIFICATION_ID.

If you want the definition to inherit its classifications for a particular level from its parent, enter the classification level ID and, for the CLASSIFICATION_ID, enter 0 (zero).

If you want to explicitly assign one or more terms for a particular level, initialize a CDR_CLA_OBJ_TYPE for each term, entering the classification level ID and, for the CLASSIFICATION_ID, the term ID.

The PAR_ attributes are not relevant to Tables. Do not enter any values for them.

- **PI_INSTCLASSIFICATIONCOLL** (Mandatory) Enter NULL because you are creating a Table definition.

14.1.2 Create a Table Instance

Use this API to create a Table Instance.

Name CDR_PUB_DF_TABLE.CREATETABLEINSTANCE

Signature

```

PROCEDURE CREATETABLEINSTANCE(
  P_API_VERSION IN     NUMBER,
  P_INIT_MSG_LIST IN   VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN        VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN  NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
  X_RETURN_STATUS OUT   VARCHAR2,
  X_MSG_COUNT OUT      NUMBER,
  X_MSG_DATA OUT       VARCHAR2,

```



```

PIO_NAMING IN OUT CDR_NAMING_VERSION_OBJ_TYPE,
PIO_TABLE_INSTANCE IN OUT CDR_TABLE_REF_OBJ_TYPE,
PI_CREATETYPE IN VARCHAR2,
PI_INSTANCESUBTYPEID IN NUMBER,
PI_DEFCLASSIFICATIONCOLL IN CDR_CLASSIFICATIONS_COLL,
PI_INSTCLASSIFICATIONCOLL IN CDR_CLASSIFICATIONS_COLL
);

```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

- **PIO_NAMING** (Mandatory) This is a parameter of table type CDR_NAMING_VERSIONS_OBJ_TYPE that contains CDR Naming Version attributes. For OBJECT_TYPE_RC enter \$OBJTYPES\$TABLEREF.
- **PIO_TABLE_INSTANCE** (Optional) This is a parameter of table type CDR_TABLE_OBJ_TYPE that contains object attributes specific to Table instances.

The following attributes are required: COMPANY_ID,OBJ_ID,OBJ_VER,ORACLE_NAME,SAS_NAME SASV6FLAGRC = '\$YESNO\$NO', SNAPSHOTFLAGRC= '\$YESNO\$YES', BLINDINGFLAGRC= '\$YESNO\$YES',PROCESSTYPERC = '\$PROCESSTYPES\$STAGINGWAUDIT',BLINDINGSTATUSRC= '\$BLIND_STATS\$BLINDED',COMPRESSFLAGRC= '\$YESNO\$NO',GENERATIONSTATUSRC= '\$YESNO\$NO'.
- **PI_CREATETYPE** (Mandatory) Enter INST to create a Table instance of an existing Table definition. Enter BOTH to create a Table definition and a Table instance of it.
- **PI_INSTANCESUBTYPEID** (Mandatory) Enter the SUBTYPE_ID of the Table instance.
- **PI_DEFCLASSIFICATIONCOLL** (Optional) By default the new definition is classified according to the subtype you assigned it in the CDR_NAMING_VERSION_OBJ_TYPE.

If you want to override the default classifications for one or more classification levels, use this parameter. This is a collection of CDR_CLA_OBJ_TYPES, which have 5 attributes, including CLA_LEVEL_ID and CLASSIFICATION_ID.

If you want the definition to inherit its classifications for a particular level from its parent, enter the classification level ID and, for the CLASSIFICATION_ID, enter 0 (zero).

If you want to explicitly assign one or more terms for a particular level, initialize a CDR_CLA_OBJ_TYPE for each term, entering the classification level ID and, for the CLASSIFICATION_ID, the term ID. The PAR_ attributes are not relevant to Tables. Do not enter any values for them. If you are not creating a new definition, do not enter values here.

- **PI_INSTCLASSIFICATIONCOLL** (Optional) By default the new instance is classified according to the subtype you assigned it in the PI_INSTANCE_SUBTYPE_ID.

If you want to override the default classifications for one or more classification levels, use this parameter. This is a collection of CDR_CLA_OBJ_TYPES, which have 5 attributes, including CLA_LEVEL_ID and CLASSIFICATION_ID.

If you want the instance to inherit its classifications for a particular level from its parent Work Area, enter the classification level ID and, for the CLASSIFICATION_ID, enter 0 (zero).

If you want to explicitly assign one or more terms for a particular level, initialize a CDR_CLA_OBJ_TYPE for each term, entering the classification level ID and, for the CLASSIFICATION_ID, the term ID.

The PAR_ attributes are not relevant to Tables. Do not enter any values for them. If you are not creating a new instance, do not enter values here.

14.1.3 Create a Temporary Blob

Use this API to create a temporary BLOB in a BLOB Table. Call this API before you upload Columns or Table Descriptors using the UPLOADOPERATORCOLUMNS API for a SAS or CPORT file, or before creating a Table for a SAS dataset.

Name CDR_PUB_DF_TABLE.CREATETEMPBLOB

Signature

```
PROCEDURE CREATETEMPBLOB (
  P_API_VERSION IN NUMBER,
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
  X_RETURN_STATUS OUT VARCHAR2,
  X_MSG_COUNT OUT NUMBER,
  X_MSG_DATA OUT VARCHAR2,
  PIO_TMPBLOBOBJ IN OUT CDR_TEMP_BLOBS_OBJ_TYPE
);
```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameter:

PIO_TMPBLOBOBJ (Mandatory) This is parameter of table type CDR_TEMP_BLOBS_OBJ_TYPE that contains information about the BLOB.

The required attributes are: FILE_NAME, FILE_BLOB

14.1.4 Create a Table Column

Use this API to create a Table Column. As with any other object, you can create an instance of an existing Variable or create a new Variable and Column. (Variable is the definition object for Columns.)

Name CDR_PUB_DF_TABLE.CREATECOLUMN

Signature

```
PROCEDURE CREATECOLUMN (
  P_API_VERSION IN NUMBER,
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
  X_RETURN_STATUS OUT VARCHAR2,
  X_MSG_COUNT OUT NUMBER,
  X_MSG_DATA OUT VARCHAR2,
  PIO_NAMING IN OUT CDR_NAMING_VERSION_OBJ_TYPE,
  PIO_VARIABLE IN OUT CDR_VAR_OBJ_TYPE,
  PIO_COLUMN IN OUT CDR_COLUMNS_OBJ_TYPE,
  PI_CREATETYPE IN VARCHAR2,
  PI_DEFCLASSIFICATIONCOLL IN CDR_CLASSIFICATIONS_COLL
);
```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

- **PIO_NAMING** (Mandatory) This is a parameter of table type CDR_NAMING_VERSIONS_OBJ_TYPE that contains CDR Naming Version attributes. For OBJECT_TYPE_RC enter \$OBJTYPES\$COLUMN.
- **PIO_VARIABLE** (Mandatory) This is a parameter of table type CDR_VAR_OBJ_TYPE that contains object attributes specific to Variables.

The following attributes are required: ORACLE_NAME, ORACLE_DATATYPE_RC, LENGTH, PRECISION, SAS_V8_NAME, SAS_LABEL, SAS_FORMAT, NULLABLE_FLAG_RC, DEFAULT_VALUE.

- **PIO_COLUMN** (Mandatory) This is a parameter of table type CDR_COLUMNS_OBJ_TYPE that contains object attributes specific to Columns.

The following attributes are required: COMPANY_ID, OBJ_ID, OBJ_VER, POSITION, SAS_LABEL, NULLABLE_FLAG_RC.

- **PI_CREATETYPE** (Mandatory) Enter INST to create only a Column of an existing definition (Variable); or BOTH to create a new Column and Variable.
- **PI_DEFCLASSIFICATIONCOLL** (Optional) By default the new definition is classified according to the subtype assigned it in the CDR_NAMING_VERSION_OBJ_TYPE.

If you want to override the default classifications for one or more classification levels, use this parameter. This is a collection of CDR_CLA_OBJ_TYPES, which have 5 attributes, including CLA_LEVEL_ID and CLASSIFICATION_ID.

If you want the definition to inherit its classifications for a particular level from its parent, enter the classification level ID and, for the CLASSIFICATION_ID, enter 0 (zero).

If you want to explicitly assign one or more terms for a particular level, initialize a CDR_CLA_OBJ_TYPE for each term, entering the classification level ID and, for the CLASSIFICATION_ID, the term ID. The PAR_ attributes are not relevant to Columns. Do not enter any values for them.

If you are not creating a new definition, do not enter values here.

14.1.5 Create a Table Constraint

Use this API to create a constraint for a Table definition or a Table instance.

Name CDR_PUB_DF_TABLE.CREATETABLECONSTRAINT

Signature

```
PROCEDURE CREATETABLECONSTRAINT (
  P_API_VERSION IN NUMBER,
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
  X_RETURN_STATUS OUT VARCHAR2,
  X_MSG_COUNT OUT NUMBER,
  X_MSG_DATA OUT VARCHAR2,
  PIO_NAMING IN OUT CDR_NAMING_VERSION_OBJ_TYPE,
  PIO_CONSTRAINT IN OUT CDR_TABLE_CONS_OBJ_TYPE,
  PI_CONSTRAINTCOLUMNS IN OUT CDR_TABLE_CONCOLS_LIST_COLL,
  PI_VALS IN CDR_VALS_COLL
```

```
);
```

Return

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

- **PIO_NAMING** (Mandatory) This is a parameter of table type CDR_NAMING_VERSIONS_OBJ_TYPE that contains CDR Naming Version attributes. Enter \$OBJTYPES\$TABLECNSTR for OBJECT_TYPE_RC.
- **PIO_CONSTRAINT** (Mandatory) This is a parameter of table type CDR_TABLE_CONS_OBJ_TYPE. You must enter values for CONSTRAINT_TYPE_RC.

The possible values are: \$CONSTRAINTTYPES\$CHECK, \$CONSTRAINTTYPES\$NUINDEX, \$CONSTRAINTTYPES\$PRIMARYKEY, and \$CONSTRAINTTYPES\$UNIQUE

- **PI_CONSTRAINTCOLUMNS** (Mandatory) This is a collection of table type CDR_TABLE_CONCOLS_OBJ_TYPE. Identify the Table and the Table's columns where you want to apply the Constraints. Depending on the Constraint, you must also provide values for attributes that define Foreign Key, or that identify the List of Values object to store the values for a CHECK Constraint.

The following attributes are required: TABC_COMPANY_ID,TABC_OBJ_ID,TABC_OBJ_VER,FK_COL_COMPANY_ID,FK_COL_OBJ_ID,FK_COL_OBJ_VER,POSITION,COL_COMPANY_ID,COL_OBJ_ID,COL_OBJ_VER,LOV_COMPANY_ID,LOV_ID,LOV_VER

- **PI_VALS** (Optional) This is a collection of CDR_VAL_OBJ_TYPE that contains the values for a CHECK Constraint.

14.1.6 Modify a Table Definition

Use this API to modify a Table definition. You need to check out the Table definition that you want to modify.

Name CDR_PUB_DF_TABLE.MODIFYTABLEDEFINITION

Signature

```
PROCEDURE MODIFYTABLEDEFINITION(  
  P_API_VERSION IN NUMBER,  
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,  
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,  
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,  
  X_RETURN_STATUS OUT VARCHAR2,  
  X_MSG_COUNT OUT NUMBER,  
  X_MSG_DATA OUT VARCHAR2,  
  PIO_NAMING IN OUT CDR_NAMING_VERSION_OBJ_TYPE,  
  PIO_TABLE IN OUT CDR_TABLE_OBJ_TYPE  
);
```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

- **PIO_NAMING** (Mandatory) This is a parameter of table type CDR_NAMING_VERSION_OBJ_TYPE that contains object attributes. Enter values to identify the

Table definition and enter new values for the attributes you want to modify. All attributes are required.

Note: Use separate APIs for modifying the validation status and the version label: CDR_PUB_VL_VALIDATION.UPDATE VAL STATUS and CDR_PUB_DF_NAMING.UPDATEVERSIONLABEL.

- **PIO_TABLE** (Mandatory) This is a parameter of table type CDR_TABLE_OBJ_TYPE that contains attributes specific to Table definitions. Enter the values that you want to change.

14.1.7 Modify a Table Descriptor

Use this API to modify a Table Descriptor. You need to check out the parent object of the Table Descriptor in order to modify it.

Name CDR_PUB_DF_TABLE.MODIFYTABLEDESCRIPTOR

Signature

```
PROCEDURE MODIFYTABLEDESCRIPTOR(
  P_API_VERSION IN NUMBER,
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
  X_RETURN_STATUS OUT VARCHAR2,
  X_MSG_COUNT OUT NUMBER,
  X_MSG_DATA OUT VARCHAR2,
  PIO_NAMING IN OUT CDR_NAMING_VERSION_OBJ_TYPE,
  PIO_TABLE_DESCRIPTOR IN OUT CDR_TABLE_DESC_OBJ_TYPE
);
```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

- **PIO_NAMING** (Mandatory) This is a parameter of table type CDR_NAMING_VERSION_OBJ_TYPE that contains object attributes. Enter values to identify the Table Descriptor and enter new values for the attributes you want to modify. All attributes are required.

Note: Use separate APIs for modifying the validation status and the version label: CDR_PUB_VL_VALIDATION.UPDATE VAL STATUS and CDR_PUB_DF_NAMING.UPDATEVERSIONLABEL.

- **PIO_TABLE_DESCRIPTOR** (Mandatory) This is a parameter of table type CDR_TABLE_OBJ_TYPE that contains attributes specific to Table Descriptors. Enter the values that you want to change.

14.1.8 Modify a Table Instance

Use this API to modify a Table Instance.

Name CDR_PUB_DF_TABLE.MODIFYTABLEINSTANCE

Signature

```
PROCEDURE MODIFYTABLEINSTANCE(  
  P_API_VERSION IN NUMBER,  
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,  
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,  
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,  
  X_RETURN_STATUS OUT VARCHAR2,  
  X_MSG_COUNT OUT NUMBER,  
  X_MSG_DATA OUT VARCHAR2,  
  PIO_NAMING IN OUT CDR_NAMING_VERSION_OBJ_TYPE,  
  PIO_TABLE_INSTANCE IN OUT CDR_TABLE_REF_OBJ_TYPE  
);
```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

- **PIO_NAMING** (Mandatory) This is a parameter of table type CDR_NAMING_VERSION_OBJ_TYPE that contains object attributes. Enter values to identify the Table instance and enter new values for the attributes you want to modify. All attributes are required.

Note: Use separate APIs for modifying the validation status and the version label: CDR_PUB_VL_VALIDATION.UPDATE VAL STATUS and CDR_PUB_DF_NAMING.UPDATEVERSIONLABEL.

- **PIO_TABLE_INSTANCE** (Mandatory) This is a parameter of table type CDR_TABLE_OBJ_TYPE that contains attributes specific to Table instances. Enter the values that you want to change.

14.1.9 Reorder a Column

Use this API to reorder a Table's columns. You need to check out the Table definition whose columns you want to reorder.

Name CDR_PUB_DF_TABLE.REORDERCOLUMNS

Signature

```
PROCEDURE REORDERCOLUMNS(  
  P_API_VERSION IN NUMBER,  
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,  
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,  
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,  
  X_RETURN_STATUS OUT VARCHAR2,  
  X_MSG_COUNT OUT NUMBER,  
  X_MSG_DATA OUT VARCHAR2,  
  PI_REORDEROBJCOLL IN CDR_REORDER_OBJ_COLL  
);
```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

PI_REORDEROBJCOLL (Mandatory) This is a collection of CDR_REORDER_OBJ_TYPE that contains the Column objects that you want to reorder. The value for ENTRY_NUMBER must be NULL. Add the Columns to the collection in the new order in which you want them.

14.1.10 Upload a Table Descriptor or Column

Use this API to upload Columns and/or a Table Descriptor.

Name CDR_PUB_DF_TABLE.UPLOADOPERATORCOLUMNS

Signature

```
PROCEDURE UPLOADOPERATORCOLUMNS (
  P_API_VERSION IN NUMBER,
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
  X_RETURN_STATUS OUT VARCHAR2,
  X_MSG_COUNT OUT NUMBER,
  X_MSG_DATA OUT VARCHAR2,
  PI_COMPID IN NUMBER,
  PI_NSOBJID IN NUMBER,
  PI_NSOBJVER IN NUMBER,
  PI_OBJID IN NUMBER,
  PI_OBJVER IN NUMBER,
  PI_NVCOLL IN CDR_NAME_VALUE_PAIR_COLL
);
```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

- **PI_COMPID** (Mandatory) Enter the COMPANY_ID of the Column or Table Descriptor.
- **PI_NSOBJID** (Mandatory) Enter the Namespace OBJ_ID of the Column or Table Descriptor.
- **PI_NSOBJVER** (Mandatory) Enter the Namespace OBJ_VER of the Column or Table Descriptor.
- **PI_OBJID** (Mandatory) Enter the OBJ_ID of the Column or Table Descriptor.
- **PI_OBJVER** (Mandatory) Enter the OBJ_VER of the Column or Table Descriptor.
- **PI_NVCOLL** (Mandatory) This is a collection of CDR_NAME_VALUE_PAIR_OBJ_TYPE that contains name value pairs for the variable in LSH database to store the uploaded Columns and/or Table Descriptor.

You must call CREATETEMPBLOB API before you use this API.

For SAS/C-PORT files, the variable name is the TMP_BLOB_ID which is defined after you call CREATETEMPBLOB API. For other uploads, the variable name is NULL.

14.1.11 Check in a Table Object

Use this API to check in a Table Object. Check in object depends on object type passed to it.

Name CDR_PUB_DF_TABLE.CHECKIN

Signature

```
PROCEDURE CHECKIN(
  P_API_VERSION IN NUMBER,
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
```

```
P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
X_RETURN_STATUS OUT VARCHAR2,
X_MSG_COUNT OUT NUMBER,
X_MSG_DATA OUT VARCHAR2,
PIO_BASEOBJECT IN OUT CDR_BASE_OBJ_TYPE,
PI_COMMENT IN VARCHAR2
);
```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

- **PIO_BASEOBJECT** (Mandatory) This is a parameter of table type CDR_BASE_OBJ_TYPE that contains object attributes. Enter values to identify the Table definition that you want to check in.

The following attributes are required: COMPANY_ID,OBJ_ID,OBJ_VER,OBJECT_VERSION_NUMBER,NAMESPACE_OBJ_ID,NAMESPACE_OBJ_VER.

- **PI_COMMENT** (Optional) Enter the reason you are checking in the Table.

14.1.12 Remove a Single Object

Use this API to remove a single object of any of the following types: Table definition, Table instance, Table Descriptor, Column, or a Constraint.

Name CDR_PUB_DF_TABLE.REMOVE

Signature

```
PROCEDURE REMOVE(
  P_API_VERSION IN NUMBER,
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
  X_RETURN_STATUS OUT VARCHAR2,
  X_MSG_COUNT OUT NUMBER,
  X_MSG_DATA OUT VARCHAR2,
  PI_NAMING IN OUT CDR_NAMING_VERSION_OBJ_TYPE
);
```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameter:

PI_NAMING (Mandatory) This is a collection of CDR_BASE_OBJ_TYPES. For each object that you want to remove, initialize a CDR_BASE_OBJ_TYPE and then extend the collection.

The following attributes are required: COMPANY_ID,OBJ_ID,OBJ_VER,OBJECT_VERSION_NUMBER,NAMESPACE_OBJ_ID,NAMESPACE_OBJ_VER.

This section contains the following topics:

- [Section 15.1, "Define and Modify Parameters"](#)
- [Section 15.2, "Define Parameter Relations"](#)

15.1 Define and Modify Parameters

This is a public interface for operations involving defined Parameter objects. For further information, see the chapter on Parameters in the *Oracle Life Sciences Data Hub Application Developer's Guide*.

15.1.1 Create a Parameter

Use this API to create a parameter instance or definition or both the parameter instance and its definition.

Name CDR_PUB_DF_PARAMETER.CREATEPARAMETER

Signature

```
PROCEDURE CREATEPARAMETER(
  P_API_VERSION IN NUMBER,
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
  X_RETURN_STATUS OUT VARCHAR2,
  X_MSG_COUNT OUT NUMBER,
  X_MSG_DATA OUT VARCHAR2,
  PIO_PARAMNAMING IN OUT CDR_NAMING_VERSION_OBJ_TYPE,
  PIO_CDRPARAMOBJTYPE IN OUT CDR_PARAMETER_OBJ_TYPE,
  PI_CREATE_OBJECT IN VARCHAR2,
  PI_INSTANCE_SUBTYPE_ID IN CDR_NAMINGS.OBJECT_SUBTYPE_ID%TYPE,
  PI_PARENTNAMING IN OUT CDR_BASE_OBJ_TYPE,
  PO_DEFCLASSIFICATIONCOLL IN CDR_CLASSIFICATIONS_COLL
);
```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

- **PIO_PARAMNAMING** (Mandatory) If you are creating a new instance of an existing Parameter Set definition (and instances of all the Parameters in the Parameter Set definition), enter values to identify the Parameter Set definition. For OBJECT_TYPE_RC enter \$OBJTYPES\$PARAMSETREF.

If you are creating a single Parameter, enter values for the Parameter definition you want to create or, if you are creating an instance of an existing Parameter definition, enter values to identify the definition you want to create an instance of. For OBJECT_TYPE_RC enter \$OBJTYPES\$PARAMETER if you are creating a definition only; \$OBJTYPES\$PARAMREF if you are creating an instance of an existing definition; and NULL if you are creating a new definition and an instance of it.

The following attributes are required: COMPANY_ID, OBJECT_TYPE_RC, NAMESPACE_OBJ_ID, NAMESPACE_OBJ_VER, NAMESPACE_START_OBJ_VER, NAMESPACE_END_OBJ_VER, OWNING_LOCATION_RC, CHECKED_OUT_FLAG_RC, CHECKED_OUT_ID, OBJECT_SUBTYPE_ID, DESCRIPTION, REF_COMPANY_ID, REF_OBJ_ID, REF_OBJ_VER, OBJECT_VERSION_NUMBER, VALIDATION_STATUS_RC, VERSION_LABEL.

- **PIO_CDRPARAMOBJTYPE** (Optional) This is a parameter of table type CDR_PARAMETER_OBJ_TYPE that contains Parameter-specific attributes. If you are creating an instance of an existing Parameter Set, do not enter any values here. If you are creating a single Parameter, enter values for the Parameter definition you want to create or, if you are creating an instance of an existing definition, enter values to identify the definition you want to create an instance of.

The following attributes are required:

For simple parameter, no LOV: COMPANY_ID, PROMPT, INPUT_OUTPUT_RC, READ_ONLY_FLAG_RC, VISIBLE_FLAG_RC, MANDATORY_FLAG_RC, DEFAULT_VALUE, POSITION, PARAM_TYPE_RC, AUTO_SHARE_FIELD_FLAG_RC.

For static LOV type parameter: COMPANY_ID, PROMPT, INPUT_OUTPUT_RC, READ_ONLY_FLAG_RC, VISIBLE_FLAG_RC, MANDATORY_FLAG_RC, DEFAULT_VALUE, POSITION, PARAM_TYPE_RC, AUTO_SHARE_FIELD_FLAG_RC, LOV_COMPANY_ID, LOV_ID, LOV_VER, LOV_MULTI_FLAG_RC, ALLOWED_VALUES_RC, VALIDATION_RULE_RC, VAL_PRG_INST_COMPANY_ID, VAL_PRG_INST_ID, VAL_PRG_INST_VER, VAL_SC_REF_COMPANY_ID, VAL_SC_REF_ID, VAL_SC_REF_VER.

For programatic LOV type parameter: COMPANY_ID, PROMPT, INPUT_OUTPUT_RC, READ_ONLY_FLAG_RC, VISIBLE_FLAG_RC, MANDATORY_FLAG_RC, DEFAULT_VALUE, POSITION, PARAM_TYPE_RC, AUTO_SHARE_FIELD_FLAG_RC, LOV_PRG_INST_COMPANY_ID, LOV_PRG_INST_ID, LOV_PRG_INST_VER, LOV_SC_REF_COMPANY_ID, LOV_SC_REF_ID, LOV_SC_REF_VER, LOV_MULTI_FLAG_RC, ALLOWED_VALUES_RC, VALIDATION_RULE_RC, VAL_PRG_INST_COMPANY_ID, VAL_PRG_INST_ID, VAL_PRG_INST_VER, VAL_SC_REF_COMPANY_ID, VAL_SC_REF_ID, VAL_SC_REF_VER.

For classification LOV type parameter: COMPANY_ID, PROMPT, INPUT_OUTPUT_RC, READ_ONLY_FLAG_RC, VISIBLE_FLAG_RC, MANDATORY_FLAG_RC, DEFAULT_VALUE, POSITION, PARAM_TYPE_RC, AUTO_SHARE_FIELD_FLAG_RC, LOV_CLA_LEVEL_ID, LOV_DEFAULT_CLA_ID, LOV_MULTI_FLAG_RC, ALLOWED_VALUES_RC, VALIDATION_RULE_RC, VAL_PRG_INST_COMPANY_ID, VAL_PRG_INST_ID, VAL_PRG_INST_VER, VAL_SC_REF_COMPANY_ID, VAL_SC_REF_ID, VAL_SC_REF_VER.

- **PI_CREATE_OBJECT** (Mandatory) Enter DEFN to create a Parameter definition only; INST to create a Parameter instance only; BOTH to create a Parameter definition and an instance of it; or PARAMSET if you are creating a new instance of a Parameter Set.

- **PI_INSTANCE_SUBTYPE_ID** (Optional) If you are creating an instance of a single Parameter, enter the ID for the subtype you want to give the instance. If you are creating a Parameter Set instance, do not enter a value here.
- **PI_PARENTNAMING** (Optional) This is a parameter of table type CDR_BASE_OBJ_TYPE that contains object attributes. Enter values to identify the object (for example, the Program or Report Set) that contains the Parameter definition.

The following attributes are required: COMPANY_ID, OBJ_ID, OBJ_VER. If you are creating an instance of a Parameter Set, do not enter a value here.

- **PO_DEFCLASSIFICATIONCOLL** (Optional) By default the new definition is classified according to the subtype you assigned it in the CDR_NAMING_VERSION_OBJ_TYPE. If you want to override the default classifications for one or more classification levels, use this parameter. This is a collection of CDR_CLA_OBJ_TYPES, which have 5 attributes, including CLA_LEVEL_ID and CLASSIFICATION_ID.

If you want the definition to inherit its classifications for a particular level from its parent, enter the classification level ID and, for the CLASSIFICATION_ID, enter 0 (zero). If you want to explicitly assign one or more terms for a particular level, initialize a CDR_CLA_OBJ_TYPE for each term, entering the classification level ID and, for the CLASSIFICATION_ID, the term ID. The PAR_ attributes are not relevant to Parameters. Do not enter any values for them. If you are not creating a new definition, do not enter values here.

15.1.2 Check Out a Parameter

Use this API to check out a Parameter definition.

Name CDR_PUB_DF_PARAMETER.CHECKOUTPARAMETER

Signature

```
PROCEDURE CHECKOUTPARAMETER (
  P_API_VERSION IN NUMBER,
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
  X_RETURN_STATUS OUT VARCHAR2,
  X_MSG_COUNT OUT NUMBER,
  X_MSG_DATA OUT VARCHAR2,
  PIO_CDRNAMING IN OUT CDR_BASE_OBJ_TYPE,
  PI_COMMENT IN VARCHAR2,
  PI_ISINSTONLY IN VARCHAR2
);
```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

- **PIO_CDRNAMING** (Mandatory) This is a parameter of table type CDR_BASE_OBJ_TYPE that contains CDR Naming attributes. Enter values to identify the Parameter you want to check out. The following attributes are required: COMPANY_ID, OBJ_ID, OBJ_VER, OBJECT_VERSION_NUMBER, NAMESPACE_OBJ_ID, NAMESPACE_OBJ_VER.
- **PI_COMMENT** (Optional) Enter an explanation of why you are checking out the Parameter.

- **PI_ISINSTONLY** (Mandatory) Enter \$YESNO\$NO.

15.1.3 Check In a Parameter

Use this API to explicitly check in a Parameter definition.

Name CDR_PUB_DF_PARAMETER.CHECKINPARAMETER

Signature

```
PROCEDURE CHECKINPARAMETER(  
  P_API_VERSION IN NUMBER,  
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,  
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,  
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,  
  X_RETURN_STATUS OUT VARCHAR2,  
  X_MSG_COUNT OUT NUMBER,  
  X_MSG_DATA OUT VARCHAR2,  
  PIO_CDRNAMING IN OUT CDR_BASE_OBJ_TYPE,  
  PI_COMMENT IN VARCHAR2  
);
```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

- **PIO_CDRNAMING** (Mandatory) This is a parameter of table type CDR_BASE_OBJ_TYPE that contains CDR Naming attributes. Enter values to identify the Parameter you want to check out. The following attributes are required: COMPANY_ID,OBJ_ID,OBJ_VER,OBJECT_VERSION_NUMBER,NAMESPACE_OBJ_ID,NAMESPACE_OBJ_VER.
- **PI_COMMENT** (Optional) Enter a checkin comment.

15.1.4 Get Displayed Parameter Values

Use this API to get the Parameter value(s) that must be displayed in the submission Execution Setup in cases where the displayed value differs from the value used internally: for a Parameter with a classification list of values, this API returns a comma-separated list of the terms in the appropriate classification level (instead of the term_id used internally); for a Report Set Entry Title Parameter, the API returns the title (instead of the RSE obj_id); and for a Parameter with a look-up value, the API returns a display value; for example, 'Yes' instead of \$YESNO\$YES. You can also use this API to populate a default value for a Parameter in an Execution Setup.

Name CDR_PUB_DF_PARAMETER.GETDEFAULTCLVALUE

Signature

```
FUNCTION GETDEFAULTCLVALUE(  
  P_API_VERSION IN NUMBER,  
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,  
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,  
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,  
  PALLOWEDVALUE IN CDR_PARAMETERS.ALLOWED_VALUES_RC%TYPE,  
  PDEFAULTVALUE IN VARCHAR2  
) RETURN VARCHAR2;
```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

- **P_COMMIT** (Optional) Accept the default value (FND_API.G_FALSE) to ensure that this individual API does not commit upon completion. Pass FND_API.G_TRUE to override the default behavior.
- **P_VALIDATION_LEVEL** (Optional) Accept the default value to perform full validation. No other values are currently supported.
- **PALLOWEDVALUE** (Optional) To get the allowed values for a Parameter with a classification LOV, enter \$PARAMALLOWVALS\$CLALOV. To get the title for a Report Set Entry, enter \$PARAMALLOWVALS\$ENTRYLOV. To get a look-up value or enter a default value, do not enter a value here.
- **PDEFAULTVALUE** (Optional) To get the allowed values for a Parameter with a classification LOV, enter the level ID of the Parameter's LOV. To get a look-up value, enter \$PARAMALLOWVALS\$LOV. To get the title for a Report Set Entry, enter the RSE object ID. To set a default value for a Parameter in the Execution Setup, enter the string you want to serve as the default value. The API returns the string.

15.2 Define Parameter Relations

This packages contains the following procedures and functions:

- [Section 15.2.1, "Create a Parameter Relation Collection"](#)
- [Section 15.2.2, "Get Parameter Instances for Value Passing"](#)
- [Section 15.2.3, "Remove Parameter Relations"](#)

This is a public interface for operations related to passing values from one Parameter to another within a Report Set or Workflow. For further information, see the chapter on Parameters in the *Oracle Life Sciences Data Hub Application Developer's Guide*.

15.2.1 Create a Parameter Relation Collection

Program instance contained in the Workflow and an input Parameter of another Program instance that is executed later in the Workflow.

Name CDR_PUB_DF_PARAM_RELATION.CREATEPARRELCOLL

Signature

```
PROCEDURE CREATEPARRELCOLL(
  P_API_VERSION IN NUMBER,
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
  X_RETURN_STATUS OUT VARCHAR2,
  X_MSG_COUNT OUT NUMBER,
  X_MSG_DATA OUT VARCHAR2,
  PIO_PARCOLL IN OUT CDR_PARAM_RELATION_COLL,
  PI_VALIDATERELATIONS IN VARCHAR := 'T'
);
```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

- **PIO_PARCOLL** (Mandatory) This is a collection of CDR_PARAM_RELATION_OBJ_TYPES.

For each Parameter relation that you want to create, initialize a CDR_PARAM_RELATION_OBJ_TYPE and then extend the collection. For the SRC attributes enter information about the Parameter whose value will be passed to another Parameter. For the TGT attributes, enter information about the target Parameter that will receive its value from the source Parameter. For RELATION_TYPE enter either LINK or SHARE.

- **PI_VALIDATERELATIONS** (Mandatory) Accept the default value of 'T' to validate the parameter relations in the collection. Enter 'F' to skip validation.

15.2.2 Get Parameter Instances for Value Passing

Use this API to get a list of Parameters that would be valid for either receiving a value from, or passing a value to, the Parameter you specify in the Report Set or Workflow you specify.

Name CDR_PUB_DF_PARAM_RELATION.GETPARAMETERREFS

Signature

```
PROCEDURE GETPARAMETERREFS (
  P_API_VERSION IN NUMBER,
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
  X_RETURN_STATUS OUT VARCHAR2,
  X_MSG_COUNT OUT NUMBER,
  X_MSG_DATA OUT VARCHAR2,
  PI_PSNSCOMPANYID IN CDR_NAMINGS.COMPANY_ID%TYPE,
  PI_PSNSOBJID IN CDR_NAMINGS.OBJ_ID%TYPE,
  PI_PSNSOBJVER IN CDR_NAMING_VERSIONS.OBJ_VER%TYPE,
  PI_PAROBJID IN CDR_NAMINGS.OBJ_ID%TYPE,
  PI_PAROBJVER IN CDR_NAMING_VERSIONS.OBJ_VER%TYPE,
  PO_PARCOLL OUT CDR_PARAM_RELATION_COLL,
  PI_SHARE IN VARCHAR2
);
```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

- **PI_PSNSCOMPANYID** (Mandatory) Enter the company ID of the Report Set or Workflow.
- **PI_PSNSOBJID** (Mandatory) Enter the object ID of the Report Set or Workflow.
- **PI_PSNSOBJVER** (Mandatory) Enter the version number of the Report Set or Workflow.
- **PI_PAROBJID** (Mandatory) Enter the object ID of the Parameter.
- **PI_PAROBJVER** (Mandatory) Enter the version number of the Parameter.
- **PO_PARCOLL** This output parameter is a collection of CDR_PARAM_RELATION_OBJ_TYPES containing Parameter instances in the Report Set or Workflow.
- **PI_SHARE** Enter SHAREDFROM to get a list of potential source Parameters that could pass their value to the Parameter you specified. Enter SHAREDTO to get a

list of potential target Parameters that could receive their value from the Parameter you specified.

15.2.3 Remove Parameter Relations

Use this API to delete one or more Parameter relations from a Report Set or Workflow.

Name CDR_PUB_DF_PARAM_RELATION.REMOVEPARRELCOLL

Signature

```
PROCEDURE REMOVEPARRELCOLL(
  P_API_VERSION IN NUMBER,
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
  X_RETURN_STATUS OUT VARCHAR2,
  X_MSG_COUNT OUT NUMBER,
  X_MSG_DATA OUT VARCHAR2,
  PIO_PARCOLL IN OUT CDR_PARAM_RELATION_COLL
);
```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

PIO_PARCOLL (Mandatory) This is a collection of CDR_PARAM_RELATION_OBJ_TYPES. For each Parameter relation that you want to delete, initialize a CDR_PARAM_RELATION_OBJ_TYPE and then extend the collection.

The following attributes are required: COMPANY_ID, SRC_PARENT_OBJ_ID, SRC_PARENT_OBJ_VER, SRC_PAR_REF_OBJ_ID, SRC_PAR_REF_OBJ_VER, TGT_PARENT_OBJ_ID, TGT_PARENT_OBJ_VER, TGT_PAR_REF_OBJ_ID, TGT_PAR_REF_OBJ_VER.

This is a public interface for Variable-related operations including creating, modifying, and removing Variables. It also includes functions for checking in and checking out Variables.

16.1 Create and Modify Variables

This section contains the following topics:

- [Section 16.1.1, "Create a Variable"](#)
- [Section 16.1.2, "Check Out a Variable"](#)
- [Section 16.1.3, "Modify a Variable"](#)
- [Section 16.1.4, "Check In a Variable"](#)
- [Section 16.1.5, "Remove a Variable"](#)

16.1.1 Create a Variable

Use this API to create a new Variable instance.

Name CDR_PUB_DF_VARIABLE.CREATEVARIABLE

Signature

```
PROCEDURE CREATEVARIABLE(
  P_API_VERSION IN NUMBER,
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
  X_RETURN_STATUS OUT VARCHAR2,
  X_MSG_COUNT OUT NUMBER,
  X_MSG_DATA OUT VARCHAR2,
  PIO_NAMING IN OUT CDR_NAMING_VERSION_OBJ_TYPE,
  PIO_VARIABLE IN OUT CDR_VAR_OBJ_TYPE,
  PI_DEFCLASSIFICATIONCOLL IN CDR_CLASSIFICATIONS_COLL
);
```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

- **PIO_NAMING** (Mandatory) This is a parameter of table type CDR_NAMING_VERSIONS_OBJ_TYPE that contains CDR Naming Version attributes.

For OBJECT_TYPE_RC enter \$OBJTYPES\$CDRVAR.

- **PIO_VARIABLE** (Mandatory) This is a parameter of table type CDR_VAR_OBJ_TYPE that contains attributes specific to Variables.

The required attributes are: ORACLE_NAME, ORACLE_DATATYPE_RC, LENGTH, PRECISION, SAS_V8_NAME, SAS_LABEL, SAS_FORMAT, NULLABLE_FLAG_RC, DEFAULT_VALUE.

Possible values for ORACLE_DATATYPE_RC are: \$ORADATATYPES\$DATE, \$ORADATATYPES\$NUMBER, and \$ORADATATYPES\$VARCHAR2.

Possible values for NULLABLE_FLAG_RC are: \$YESNO\$NO, \$YESNO\$YES.

- **PI_DEFCLASSIFICATIONCOLL** By default, the variable is classified according to the subtype you assigned it in the CDR_NAMING_VERSION_OBJ_TYPE.

If you want to override the default classifications for one or more classification levels, use this parameter. This is a collection of CDR_CLA_OBJ_TYPES, which have 5 attributes, including CLA_LEVEL_ID and CLASSIFICATION_ID.

If you want the definition to inherit its classifications for a particular level from its parent, enter the classification level ID and, for the CLASSIFICATION_ID, enter 0 (zero).

If you want to explicitly assign one or more terms for a particular level, initialize a CDR_CLA_OBJ_TYPE for each term, entering the classification level ID and, for the CLASSIFICATION_ID, the term ID. The PAR_ attributes are not relevant to Variables. Do not enter any values for them.

If you are not creating a new definition, do not enter values here.

16.1.2 Check Out a Variable

Use this API to check out a Variable definition or instance.

Name CDR_PUB_DF_VARIABLE.CHECKOUT

Signature

```
PROCEDURE CHECKOUT (
  P_API_VERSION IN      NUMBER,
  P_INIT_MSG_LIST IN     VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN     VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN  NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
  X_RETURN_STATUS OUT    VARCHAR2,
  X_MSG_COUNT OUT        NUMBER,
  X_MSG_DATA OUT         VARCHAR2,
  PIO_BASEOBJECT IN OUT   CDR_BASE_OBJ_TYPE,
  PI_COMMENT IN     VARCHAR2,
  PI_ISINSTONLY IN     VARCHAR2
);
```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

- **PIO_BASEOBJECT** (Mandatory) This is a parameter of table type CDR_BASE_OBJ_TYPE that contains object attributes. Enter values to identify the Variable definition that you want to check out.

The following attributes are required: COMPANY_ID, OBJ_ID, OBJ_VER, OBJECT_VERSION_NUMBER, NAMESPACE_OBJ_ID, NAMESPACE_OBJ_VER.

- **PI_COMMENT** (Optional) Enter the reason you are checking out the Variable.

- **PI_ISINSTONLY** (Mandatory) Enter \$YESNO\$NO.

16.1.3 Modify a Variable

Use this API to modify a Variable definition or instance.

Note: To modify a Variable definition, you must first check it out.

Name CDR_PUB_DF_VARIABLE.MODIFYVARIABLE

Signature

```
PROCEDURE MODIFYVARIABLE(
  P_API_VERSION IN NUMBER,
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
  X_RETURN_STATUS OUT VARCHAR2,
  X_MSG_COUNT OUT NUMBER,
  X_MSG_DATA OUT VARCHAR2,
  PI_NAMING IN OUT CDR_NAMING_VERSION_OBJ_TYPE,
  PI_VARIABLE IN OUT CDR_VAR_OBJ_TYPE
);
```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

- **PI_NAMING** (Mandatory) This is a parameter of table type CDR_NAMING_VERSIONS_OBJ_TYPE that contains CDR Naming Version attributes. Initialize the attributes COMPANY_ID, OBJECT_ID, and OBJECT_VER.
- **PI_VARIABLE** (Mandatory) This is a parameter of table type CDR_VARS_OBJ_TYPE. Provide values for the attributes you want to modify.

16.1.4 Check In a Variable

Use this API to check in a Variable definition or instance.

Name CDR_PUB_DF_VARIABLE.CHECKIN

Signature

```
PROCEDURE CHECKIN(
  P_API_VERSION IN NUMBER,
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
  X_RETURN_STATUS OUT VARCHAR2,
  X_MSG_COUNT OUT NUMBER,
  X_MSG_DATA OUT VARCHAR2,
  PIO_BASEOBJECT IN OUT CDR_BASE_OBJ_TYPE,
  PI_COMMENT IN VARCHAR2
);
```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

- **PIO_BASEOBJECT** (Mandatory) This is a parameter of table type CDR_BASE_OBJ_TYPE that contains object attributes. Enter values to identify the Variable definition that you want to check in.

The following attributes are required: COMPANY_ID,OBJ_ID,OBJ_VER,OBJECT_VERSION_NUMBER,NAMESPACE_OBJ_ID,NAMESPACE_OBJ_VER.

- **PI_COMMENT** (Optional) Enter the reason you are checking in the Variable.

16.1.5 Remove a Variable

Use this API to remove an existing variable object.

Name CDR_PUB_DF_VARIABLE.REMOVEVARIABLE

Signature

```
PROCEDURE REMOVEVARIABLE(  
  P_API_VERSION IN NUMBER,  
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,  
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,  
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,  
  X_RETURN_STATUS OUT VARCHAR2,  
  X_MSG_COUNT OUT NUMBER,  
  X_MSG_DATA OUT VARCHAR2,  
  PI_NAMING IN OUT CDR_NAMING_VERSION_OBJ_TYPE  
);
```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameter:

PI_NAMING (Mandatory) This is a parameter of table type CDR_NAMING_VERSIONS_OBJ_TYPE that contains CDR Naming Version attributes. Initialize the attributes COMPANY_ID, OBJECT_ID, and OBJECT_VER.

This is a public interface for Work Area-related operations, including creating, modifying, removing, cloning, checking in and installing Work Areas. It also includes an API to copy instance objects into a Work Area and an API to install a single Program.

17.1 Define and Modify Work Areas

This section contains the following topics:

- [Section 17.1.1, "Create a Work Area"](#)
- [Section 17.1.2, "Install a Work Area"](#)
- [Section 17.1.3, "Check in a Work Area"](#)
- [Section 17.1.4, "Modify a Work Area"](#)
- [Section 17.1.5, "Clone a Work Area"](#)
- [Section 17.1.6, "Copy Objects into a Work Area"](#)
- [Section 17.1.7, "Clone an Object"](#)
- [Section 17.1.8, "Remove a Work Area"](#)
- [Section 17.1.9, "Get the Usage Intent RC of a Work Area"](#)
- [Section 17.1.10, "Update a Work Area's Usage Intent"](#)
- [Section 17.1.11, "Install a Program"](#)

17.1.1 Create a Work Area

Use this API to create a new Work Area.

Name CDR_PUB_DF_WORKAREA.CREATEWORKAREA

Signature

```
PROCEDURE CREATEWORKAREA (
    P_API_VERSION IN    NUMBER,
    P_INIT_MSG_LIST IN  VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
    P_COMMIT IN      VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
    P_VALIDATION_LEVEL IN    NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
    X_RETURN_STATUS OUT    VARCHAR2,
    X_MSG_COUNT OUT      NUMBER,
    X_MSG_DATA OUT      VARCHAR2,
    PIO_SOURCECDRNAMING IN OUT  CDR_NAMING_VERSION_OBJ_TYPE,
```

```

PIO_WORKAREAOBJTYPE IN OUT    CDR_WORKAREA_OBJ_TYPE,
PI_DEFCLASSIFICATIONCOLL IN    CDR_CLASSIFICATIONS_COLL
);

```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

- **PIO_WORKAREAOBJTYPE** (Mandatory) This is a parameter of table type CDR_WORKAREA_OBJ_TYPE that contains object attributes specific to Work Areas. Enter values for the Work Area that you want to create.

The following attributes are required: COMPANY_ID, OBJ_ID, OBJ_VER. For OBJECT_TYPE_RC enter \$OBJTYPES\$WORKAREA. By default, new Work Areas receive a Usage Intent value of Development.

- **PIO_SOURCECDRNAMING** (Mandatory) This is a parameter of table type CDR_NAMING_VERSION_OBJ_TYPE that contains object attributes. Enter values to identify the Work Area that you want to create.

The following attributes are required: COMPANY_ID, NAMESPACE_OBJ_ID, NAMESPACE_OBJ_VER, OBJECT_TYPE_RC. FOR OBJECT_TYPE_RC ENTER \$OBJTYPES\$WORKAREA.

- **PI_DEFCLASSIFICATIONCOLL** (Optional) By default the new Work Area is classified according to the subtype you assigned it in the CDR_NAMING_VERSION_OBJ_TYPE.

If you want to override the default classifications for one or more classification levels, use this parameter. This is a collection of CDR_CLA_OBJ_TYPES, which have 5 attributes, including CLA_LEVEL_ID and CLASSIFICATION_ID. If you want the Work Area to inherit its classifications for a particular level from its parent Application Area, enter the classification level ID and, for the CLASSIFICATION_ID, enter 0 (zero). If you want to explicitly assign one or more terms for a particular level, initialize a CDR_CLA_OBJ_TYPE for each term, entering the classification level ID and, for the CLASSIFICATION_ID, the term ID. The PAR_ attributes are not relevant to Work Areas. Do not enter any values for them.

17.1.2 Install a Work Area

Use this API to install a Work Area and the instance objects in it that you specify. The API first tries to check in the Work Area and all the object instances included in the installation. If any object included in the installation is checked out by another user, the installation fails.

Name CDR_PUB_DF_WORKAREA.INSTALLWACONTROLLER

Signature

```

PROCEDURE INSTALLWACONTROLLER(
  P_API_VERSION IN    NUMBER,
  P_INIT_MSG_LIST IN   VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN        VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN   NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
  X_RETURN_STATUS OUT   VARCHAR2,
  X_MSG_COUNT OUT      NUMBER,
  X_MSG_DATA OUT       VARCHAR2,
  PIO_OWABASENAMING IN OUT CDR_BASE_OBJ_TYPE,
  PI_VINSTALLMODE IN    CDR_INSTALLATIONS.INSTALLATION_MODE_RC%TYPE,
  PI_VFORCEREGEN IN     CDR_INSTALLATIONS.FORCE_REGEN_FLAG_RC%TYPE,

```

```

PI_VBATCH IN CDR_INSTALLATIONS.BATCH_FLAG_RC%TYPE,
PI_VACTION IN CDR_INST_ELEMENTS.INSTALL_ACTION_RC%TYPE,
PI_COINSTDETAILS IN CDR_INSTALLATION_DETAILS_COLL
);

```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

- **PIO_OWABASENAMING** (Mandatory) This is a parameter of table type CDR_BASE_OBJ_TYPE that contains object attributes. Enter values to identify the Work Area that you want to install. The following attributes are required: COMPANY_ID, OBJECT_ID, OBJECT_VER, NAMESPACE_OBJ_ID, NAMESPACE_OBJ_VER, OBJECT_VERSION_NUMBER.
- **PI_VINSTALLMODE** (Mandatory) Specify the installation mode you want to use: Enter FULL, UPGRADE, or PARTIAL.
- **PI_VFORCEREGEN** (Optional) If you selected Upgrade mode, enter \$YESNO\$YES to force the system to generate new install scripts (and reinstall) all objects, whether or not they have been modified since the last installation of this Work Area. Enter \$YESNO\$NO to generate install scripts only for objects and object versions that have never been successfully installed.
- **PI_VBATCH** (Mandatory) Enter \$YESNO\$YES to perform installation in batch mode. Enter \$YESNO\$NO to perform installation in interactive mode.
- **PI_VACTION** (Mandatory) Enter COMPLETE if this is the first time the Work Area is being installed, or if the last installation was successful, or if the last installation failed and you want to continue from the last successfully completed phase. Enter CANCEL if the last installation failed and you want to begin the installation process from the beginning.
- **PI_COINSTDETAILS** (Mandatory) This is a collection of CDR_INST_DET_OBJ_TYPES. For each object in the Work Area that you want to install, initialize a CDR_INST_DET_OBJ_TYPE and then extend the collection.

The following attributes are required: COMPANY_ID, OBJ_ID, OBJ_VER, OBJECT_VERSION_NUMBER, NAMESPACE_OBJ_ID, NAMESPACE_OBJ_VER.

For OMIT_FROM_INSTALL_FLAG_RC, enter \$YESNO\$NO to include the object in the installation, subject to the rules for the installation type (Full, Partial, or Upgrade). If you are performing installation in PARTIAL mode, you must provide a value for each object for INSTALL_ACTION_RC of to indicate if you want to drop and replace or upgrade each object.

17.1.3 Check in a Work Area

Use this API to check in a Work Area and all the object instances it contains.

Name CDR_PUB_DF_WORKAREA.CHECKINWORKAREA

Signature

```

PROCEDURE CHECKINWORKAREA(
  P_API_VERSION IN NUMBER,
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
  X_RETURN_STATUS OUT VARCHAR2,
  X_MSG_COUNT OUT NUMBER,
  X_MSG_DATA OUT VARCHAR2,

```

```
PIO_BASENAMING IN OUT CDR_BASE_OBJ_TYPE,  
PI_COMMENT IN VARCHAR2  
);
```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

- **PIO_BASENAMING** (Mandatory) This is a parameter of table type CDR_BASE_OBJ_TYPE that contains object attributes. Enter values to identify the Work Area that you want to check in.

The following attributes are required: COMPANY_ID,OBJECT_ID,OBJECT_VER,NAMESPACE_OBJ_ID,NAMESPACE_OBJ_VER, OBJECT_VERSION_NUMBER.

- **PI_COMMENT** (Optional) Enter the reason you are checking in the Work Area.

17.1.4 Modify a Work Area

Use this API to modify the name and/or description of an existing Work Area. (Use CDR_PUB_DF_WORKAREA.UPDATEUSAGEINTENT to modify a Work Area's Usage Intent attribute.)

Name CDR_PUB_DF_WORKAREA.MODIFYWORKAREA

Signature

```
PROCEDURE MODIFYWORKAREA(  
  P_API_VERSION IN NUMBER,  
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,  
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,  
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,  
  X_RETURN_STATUS OUT VARCHAR2,  
  X_MSG_COUNT OUT NUMBER,  
  X_MSG_DATA OUT VARCHAR2,  
  PIO_SOURCECDRNAMING IN OUT CDR_NAMING_VERSION_OBJ_TYPE,  
  PIO_WORKAREAOBJTYPE IN OUT CDR_WORKAREA_OBJ_TYPE  
);
```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

- **PIO_SOURCECDRNAMING** (Mandatory) This is a parameter of table type CDR_NAMING_VERSION_OBJ_TYPE that contains object attributes. Enter values to identify the Work Area that you want to modify and the values you want to change. All attributes are required.
- **PIO_WORKAREAOBJTYPE** (Mandatory) This is a parameter of table type CDR_WORKAREA_OBJ_TYPE that contains object attributes specific to Work Areas. Enter values to identify the Work Area that you want to modify and enter new values for the attributes you want to modify.

17.1.5 Clone a Work Area

Use this API to clone a Work Area. If you specify another Work Area as the target, this API overwrites that Work Area with the source Work Area. If you specify an Application Area as the target, this API creates a new Work Area identical to the source Work Area in the Application Area you specify.

Name CDR_PUB_DF_WORKAREA.CLONEOBJECTS

Signature

```
PROCEDURE CLONWORKAREA (
  P_API_VERSION IN NUMBER,
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
  X_RETURN_STATUS OUT VARCHAR2,
  X_MSG_COUNT OUT NUMBER,
  X_MSG_DATA OUT VARCHAR2,
  PIO_SOURCEOBJECT IN OUT CDR_BASE_OBJ_TYPE,
  PIO_TARGETOBJECT IN OUT CDR_BASE_OBJ_TYPE,
  PI_VLABEL IN CDR_WORKAREAS.LABEL%TYPE,
  PI_VUSAGEINTENTRC IN CDR_WORKAREAS.USAGE_INTENT_RC%TYPE
);
```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

- **PIO_SOURCEOBJECT** (Mandatory) This is a parameter of table type CDR_BASE_OBJ_TYPE that contains object attributes. Enter values to identify the Work Area that you want to clone.

The following attributes are required: COMPANY_ID, OBJECT_ID, OBJECT_VER, NAMESPACE_OBJ_ID, NAMESPACE_OBJ_VER, OBJECT_VERSION_NUMBER.
- **PIO_TARGETOBJECT** (Mandatory) This is a parameter of table type CDR_BASE_OBJ_TYPE that contains object attributes. Enter values to identify the Work Area or Application Area to serve as the target of the clone. If you specify a Work Area, this API overwrites it with the source Work Area. If you specify an Application Area, this API creates a new Work Area identical to the source Work Area in the Application Area.

The following attributes are required: COMPANY_ID, OBJ_ID, OBJ_VER, OBJECT_VERSION_NUMBER, NAMESPACE_OBJ_ID, NAMESPACE_OBJ_VER.
- **PI_VLABEL** (Mandatory) Enter text for the label you want to assign to the source and target Work Areas.
- **PI_VUSAGEINTENTRC** (Optional) Enter a value for the Usage Intent attribute of the target Work Area. If you do not enter a value, the API assigns the Usage Intent value of the source Work Area to the target Work Area.

17.1.6 Copy Objects into a Work Area

Use this API to copy one or more objects into a Work Area.

Name CDR_PUB_DF_WORKAREA.COPYOBJECTSINTOWA

Signature

```
PROCEDURE COPYOBJECTSINTOWA (
  P_API_VERSION IN NUMBER,
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
  X_RETURN_STATUS OUT VARCHAR2,
  X_MSG_COUNT OUT NUMBER,
  X_MSG_DATA OUT VARCHAR2,
  PI_CDRPRREFOBJCOLL IN CDR_PRREF_OBJ_COLL,
  PI_CDRTARGETCONTAINEROBJECT IN OUT CDR_PRREF_OBJ_TYPE,
```

```

PI_CHECKINFLAG IN VARCHAR,
PI_COPYPRGASSGNMT IN VARCHAR
);

```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

- **PI_CDRPRREFOBJCOLL** (Mandatory) This is a collection of Prref objects that contains information about the instance objects you want to copy into the Work Area.

Provide values for the attributes COMPANY_ID, OBJ_ID, OBJ_VER, PRREF_ID, PRREF_VER, NAMESPACE_OBJ_ID, NAMESPACE_OBJ_VER, OBJECT_VERSION_NUMBER for each instance object. The PRREF_ID and PRREF_VER attributes store the hierarchy information for objects.
- **PI_CDRTARGETCONTAINEROBJECT** (Mandatory) This is a parameter of Prref object type that describes the target Work Area.

Enter values for the attributes COMPANY_ID, OBJ_ID, OBJ_VER, PRREF_ID, PRREF_VER, NAMESPACE_OBJ_ID, NAMESPACE_OBJ_VER, OBJECT_VERSION_NUMBER.
- **PI_CHECKINFLAG** (Mandatory) Enter 'Y' for this flag.
- **PI_COPYPRGASSGNMT** (Optional) This parameter is not applicable.

17.1.7 Clone an Object

Use this API to clone one or more instance objects in a Work Area.

Name CDR_PUB_DF_WORKAREA.CLONEWORKAREA

Signature

```

PROCEDURE CLONEOBJECTS(
  P_API_VERSION IN NUMBER,
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
  X_RETURN_STATUS OUT VARCHAR2,
  X_MSG_COUNT OUT NUMBER,
  X_MSG_DATA OUT VARCHAR2,
  PI_SRCINSTBASEOBJCOLL IN OUT CDR_BASE_OBJ_COLL,
  PI_TGTWABASEOBJTYPE IN OUT CDR_BASE_OBJ_TYPE
);

```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

- **PI_SRCINSTBASEOBJCOLL** (Mandatory) This is a collection of base objects that you want to clone in the Work Area.

Enter the attributes COMPANY_ID, OBJ_ID, OBJ_VER, PRREF_ID, PRREF_VER, NAMESPACE_OBJ_ID, NAMESPACE_OBJ_VER, OBJECT_VERSION_NUMBER for each instance object.
- **PI_TGTWABASEOBJTYPE** (Mandatory) This is a parameter of base object type that describes the Work Area.

Enter the Work Area's COMPANY_ID, OBJ_ID, OBJ_VER, NAMESPACE_OBJ_ID, NAMESPACE_OBJ_VER, OBJECT_VERSION_NUMBER.

17.1.8 Remove a Work Area

Use this API to remove a Work Area and all the instance objects it contains.

Name CDR_PUB_DF_WORKAREA.REMOVEWORKAREA

Signature

```
PROCEDURE REMOVEWORKAREA (
  P_API_VERSION IN NUMBER,
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
  X_RETURN_STATUS OUT VARCHAR2,
  X_MSG_COUNT OUT NUMBER,
  X_MSG_DATA OUT VARCHAR2,
  PIO_SOURCECDRNAMING IN OUT CDR_NAMING_VERSION_OBJ_TYPE
);
```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

PIO_SOURCECDRNAMING (Mandatory) This is a parameter of table type CDR_NAMING_VERSION_OBJ_TYPE that contains object attributes. Enter values to identify the Work Area that you want to remove. The following attributes are required: COMPANY_ID, OBJ_ID, OBJ_VER, OBJECT_VERSION_NUMBER, NAMESPACE_OBJ_ID, NAMESPACE_OBJ_VER.

17.1.9 Get the Usage Intent RC of a Work Area

Use this API to retrieve the current value of the Usage Intent attribute for a particular Work Area.

Name CDR_PUB_DF_WORKAREA.GETUSAGEINTENTRC

Signature

```
PROCEDURE GETUSAGEINTENTRC (
  P_API_VERSION IN NUMBER,
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
  X_RETURN_STATUS OUT VARCHAR2,
  X_MSG_COUNT OUT NUMBER,
  X_MSG_DATA OUT VARCHAR2,
  PI_COMPANY_ID IN CDR_NAMINGS.COMPANY_ID%TYPE,
  PI_OBJ_ID IN CDR_NAMINGS.OBJ_ID%TYPE,
  PI_OBJ_VER IN CDR_NAMING_VERSIONS.OBJ_VER%TYPE,
  PO_USAGEINTENT OUT CDR_WORKAREAS.USAGE_INTENT_RC%TYPE
);
```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

- **PI_COMPANY_ID** (Mandatory) Enter company ID
- **PI_OBJ_ID** (Mandatory) Enter the object ID of the Work Area.
- **PI_OBJ_VER** (Mandatory) Enter the object version (OBJ_VER) of the Work Area.

- **PO_USAGEINTENT** This output parameter returns the current value of the Work Area's Usage Intent attribute.

17.1.10 Update a Work Area's Usage Intent

Use this API to modify the value of the Usage Intent attribute of a Work Area.

Name CDR_PUB_DF_WORKAREA.UPDATEUSAGEINTENT

Signature

```
PROCEDURE UPDATEUSAGEINTENT(
  P_API_VERSION IN NUMBER,
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
  X_RETURN_STATUS OUT VARCHAR2,
  X_MSG_COUNT OUT NUMBER,
  X_MSG_DATA OUT VARCHAR2,
  PIO_SOURCECDRNAMING IN OUT CDR_NAMING_VERSION_OBJ_TYPE,
  PIO_WORKAREAOBJTYPE IN OUT CDR_WORKAREA_OBJ_TYPE
);
```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

- **PIO_SOURCECDRNAMING** (Mandatory) This is a parameter of table type CDR_NAMING_VERSION_OBJ_TYPE that contains object attributes. Enter values to identify the Work Area whose Usage Intent attribute you want to modify.

The following attributes are required: COMPANY_ID,OBJ_ID,OBJ_VER.

- **PIO_WORKAREAOBJTYPE** (Mandatory) This is a parameter of table type CDR_WORKAREA_OBJ_TYPE that contains object attributes specific to Work Areas. For USAGE_INTENT_RC, enter the new value for the Usage Intent attribute.

The allowed values are: \$SYSVALDNSTEPS\$DEVELOPMENT,
\$SYSVALDNSTEPS\$PRODUCTION, \$SYSVALDNSTEPS\$QUALITYCONTROL.

17.1.11 Install a Program

Use this API to install a single Program and the Table instances to which it is mapped. You must install a Program and its source Table instances before you can work on it in an Integrated Development Environment (IDE).

Name CDR_PUB_DF_WORKAREA.INSTALLIDECOMPONENTS

Signature

```
PROCEDURE INSTALLIDECOMPONENTS(
  P_API_VERSION IN NUMBER,
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
  X_RETURN_STATUS OUT VARCHAR2,
  X_MSG_COUNT OUT NUMBER,
  X_MSG_DATA OUT VARCHAR2,
  PI_NCOMPANYID IN NUMBER,
  PI_NWAOBJID IN NUMBER,
  PI_NWAOBJVER IN NUMBER,
```

```

PI_NPRREFID IN    NUMBER,
PI_NPRREFVER IN    NUMBER,
PO_VINSTLOGTYPE OUT  VARCHAR2,
PO_VINSTLOG OUT    VARCHAR2
);

```

Parameters This API has standard parameters (see "[Standard Parameters](#)" on page 5) and the following parameters:

- **PI_NCOMPANYID** (Mandatory) Enter your company ID. To get your company ID, use CDR_PUB_DEF_FACTORY_UTILS.GetCompanyId.
- **PI_NWAOBJID** (Mandatory) Enter the object ID of the Work Area where the Program instance is located.
- **PI_NWAOBJVER** (Mandatory) Enter the object version (OBJ_VER) of the Work Area.
- **PI_NPRREFID** (Mandatory) Enter the object ID of the Program instance that you want to install.
- **PI_NPRREFVER** PrrefVer of the Program Instance to be installed
- **PO_VINSTLOGTYPE** This output parameter returns one of the following values to indicate whether the installation ended with a status of Warning (G_RET_IDE_INST_WARNING) or Success (G_RET_IDE_INST_INFO).
- **PO_VINSTLOG** This output parameter returns the installation log file (maximum length 32000 characters).

This is a public interface for Workflow-related operations, including creating, modifying, and removing Workflows.

18.1 Create and Modify Workflows

This section contains the following topics:

- [Section 18.1.1, "Create a Workflow"](#)
- [Section 18.1.2, "Check Out a Workflow Definition"](#)
- [Section 18.1.3, "Create a Workflow Transition"](#)
- [Section 18.1.4, "Create a Workflow Structure Instance"](#)
- [Section 18.1.5, "Modify a Workflow"](#)
- [Section 18.1.6, "Modify a Workflow"](#)
- [Section 18.1.7, "Check in a Workflow Definition"](#)
- [Section 18.1.8, "Remove a Transition"](#)
- [Section 18.1.9, "Remove a Workflow Activity"](#)
- [Section 18.1.10, "Remove a Workflow Instance"](#)
- [Section 18.1.11, "Remove a Workflow Definition"](#)

18.1.1 Create a Workflow

Use this API to create a Workflow definition or instance.

Name CDR_PUB_DF_WORKFLOW.CREATEWORKFLOW

Signature

```
PROCEDURE CREATEWORKFLOW(
    P_API_VERSION IN NUMBER,
    P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
    P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
    P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
    X_RETURN_STATUS OUT VARCHAR2,
    X_MSG_COUNT OUT NUMBER,
    X_MSG_DATA OUT VARCHAR2,
    PIO_SOURCECDRNAMING IN OUT CDR_NAMING_VERSION_OBJ_TYPE,
    PI_CREATEOBJECT IN VARCHAR2,
    PI_INSTANCE_SUBTYPE_ID IN CDR_NAMINGS.OBJECT_SUBTYPE_ID%TYPE,
```

```

PI_DEFCLASSIFICATIONCOLL IN CDR_CLASSIFICATIONS_COLL,
PI_INSTCLASSIFICATIONCOLL IN CDR_CLASSIFICATIONS_COLL
);

```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

- **PIO_SOURCECDRNAMING** (Mandatory) This is a parameter of table type CDR_NAMING_VERSIONS_OBJ_TYPE that contains CDR Naming Version attributes.

For OBJECT_TYPE_RC enter \$OBJTYPES\$WORKFLOW if you are creating a definition only; \$OBJTYPES\$WORKFLOWREF if you are creating an instance of an existing definition; and also if you are creating a new definition and an instance of it.
- **PI_CREATEOBJECT** (Mandatory) Enter DEFN to create a definition only; INST to create an instance of an existing definition; or BOTH to create a new definition and an instance of it.

Valid parameters are: Definition—DEFN, instance—INST, both —BOTH.
- **PI_INSTANCE_SUBTYPE_ID** (Optional) If you are creating a new instance, enter the ID for the subtype you want to give the instance.

If you are creating a definition only, do not enter a value for this parameter.
- **PI_DEFCLASSIFICATIONCOLL** (Optional) By default the new definition is classified according to the subtype you assigned it in the CDR_NAMING_VERSION_OBJ_TYPE.

If you want to override the default classifications for one or more classification levels, use this parameter. This is a collection of CDR_CLA_OBJ_TYPES, which have 5 attributes, including CLA_LEVEL_ID and CLASSIFICATION_ID.

If you want the definition to inherit its classifications for a particular level from its parent, enter the classification level ID and, for the CLASSIFICATION_ID, enter 0 (zero). If you want to explicitly assign one or more terms for a particular level, initialize a CDR_CLA_OBJ_TYPE for each term, entering the classification level ID and, for the CLASSIFICATION_ID, the term ID. The PAR_ attributes are not relevant to Workflow definitions. Do not enter any values for them.
- **PI_INSTCLASSIFICATIONCOLL** (Optional) By default the new instance is classified according to the subtype you assigned it in the PI_INSTANCE_SUBTYPE_ID.

If you want to override the default classifications for one or more classification levels, use this parameter. This is a collection of CDR_CLA_OBJ_TYPES, which have 5 attributes, including CLA_LEVEL_ID and CLASSIFICATION_ID.

If you want the instance to inherit its classifications for a particular level from its parent Work Area, enter the classification level ID and, for the CLASSIFICATION_ID, enter 0 (zero).

If you want to explicitly assign one or more terms for a particular level, initialize a CDR_CLA_OBJ_TYPE for each term, entering the classification level ID and, for the CLASSIFICATION_ID, the term ID. The PAR_ attributes are not relevant to Workflows. Do not enter any values for them. If you are not creating a new instance, do not enter values here.

18.1.2 Check Out a Workflow Definition

Use this API to check out a Workflow definition.

Name CDR_PUB_DF_WORKFLOW.CHECKOUTWORKFLOW

Signature

```
PROCEDURE CHECKOUTWORKFLOW(
  P_API_VERSION IN NUMBER,
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
  X_RETURN_STATUS OUT VARCHAR2,
  X_MSG_COUNT OUT NUMBER,
  X_MSG_DATA OUT VARCHAR2,
  PIO_CDRWORKFLOW IN OUT CDR_BASE_OBJ_TYPE,
  PI_COMMENT IN VARCHAR2,
  PI_ISINSTONLY IN VARCHAR2,
  PI_OPTYPE IN VARCHAR2
);
```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

- **PIO_CDRWORKFLOW** [Mandatory] This is a parameter of table type CDR_BASE_OBJ_TYPE that contains object attributes. Enter values to identify the Workflow definition that you want to check in.

The following attributes are mandatory: COMPANY_ID, OBJECT_ID, OBJECT_VER, NAMESPACE_OBJ_ID, NAMESPACE_OBJ_VER, OBJECT_VERSION_NUMBER. Initialize these attributes in CDR_BASE_OBJ_TYPE.
- **PI_COMMENT** [Optional] Enter the reason for checking out the Workflow definition.
- **PI_ISINSTONLY** (Mandatory) Enter \$YESNO\$NO. (The \$YESNO\$YES setting is used internally only.)
- **PI_OPTYPE** (Mandatory) Enter NULL for this parameter.

18.1.3 Create a Workflow Transition

Use this API to create a Workflow transition. A Workflow transition connects two Workflow activities.

Name CDR_PUB_DF_WORKFLOW.CREATEWFTRANSITION

Signature

```
PROCEDURE CREATEWFTRANSITION(
  P_API_VERSION IN NUMBER,
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
  X_RETURN_STATUS OUT VARCHAR2,
  X_MSG_COUNT OUT NUMBER,
  X_MSG_DATA OUT VARCHAR2,
  PIO_SOURCECDRNAMING IN OUT CDR_NAMING_VERSION_OBJ_TYPE,
  PI_CDRWFTRANSITION IN OUT CDR_WMG_TRANS_OBJ_TYPE
);
```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

- **PIO_SOURCECDRNAMING** (Mandatory) This is a parameter of table type CDR_NAMING_VERSIONS_OBJ_TYPE that contains CDR Naming Version attributes.

For OBJECT_TYPE_RC enter \$OBJTYPES\$WORKFLOW if you are creating a definition only; \$OBJTYPES\$WORKFLOWREF if you are creating an instance of an existing definition; and also if you are creating a new definition and an instance of it.
- **PI_CDRWFTRANSITION** The Object ID and Version of the two Workflow activities being connected through this transition should be populated in the CDR_WMG_TRANS_OBJ_TYPE.

In the CONDITION_RC attribute, specify the activity condition based on which the workflow transitions to the other specified activity.

The possible values are \$WFTRANSITIONS\$NONE,
\$WFTRANSITIONS\$SUCCESS,
\$WFTRANSITIONS\$ERROR,\$WFTRANSITIONS\$WARNING

18.1.4 Create a Workflow Structure Instance

Use this API to create a Workflow Structure. These are the Workflow structures: And, Or, Start, End_Success, End_Warning, End_Error, and Fork.

Name CDR_PUB_DF_WORKFLOW.CREATEWFSTRUCTREF

Signature

```
PROCEDURE CREATEWFSTRUCTREF (
  P_API_VERSION IN NUMBER,
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
  X_RETURN_STATUS OUT VARCHAR2,
  X_MSG_COUNT OUT NUMBER,
  X_MSG_DATA OUT VARCHAR2,
  PIO_SOURCECDRNAMING IN OUT CDR_NAMING_VERSION_OBJ_TYPE
);
```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameter:

PIO_SOURCECDRNAMING (Mandatory) This is a parameter of table type CDR_NAMING_VERSIONS_OBJ_TYPE that contains CDR Naming Version attributes.

For OBJECT_TYPE_RC enter \$OBJTYPES\$WORKFLOW if you are creating a definition only; \$OBJTYPES\$WORKFLOWREF if you are creating an instance of an existing definition; and also if you are creating a new definition and an instance of it.

18.1.5 Modify a Workflow

Name CDR_PUB_DF_WORKFLOW.MODIFYWORKFLOW

Signature

```
PROCEDURE MODIFYWORKFLOW (
```

```

P_API_VERSION IN NUMBER,
P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
X_RETURN_STATUS OUT VARCHAR2,
X_MSG_COUNT OUT NUMBER,
X_MSG_DATA OUT VARCHAR2,
PIO_SOURCECDRNAMING IN OUT CDR_NAMING_VERSION_OBJ_TYPE
);

```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

PIO_SOURCECDRNAMING (Mandatory) This is a parameter of table type CDR_NAMING_VERSIONS_OBJ_TYPE that contains CDR Naming Version attributes.

For OBJECT_TYPE_RC enter \$OBJTYPES\$WORKFLOW if you are creating a definition only; \$OBJTYPES\$WORKFLOWREF if you are creating an instance of an existing definition; and also if you are creating a new definition and an instance of it.

18.1.6 Modify a Workflow

Use this API to reorder workflow transitions.

Name CDR_PUB_DF_WORKFLOW.REORDERWFTRANSITIONS

Signature

```

PROCEDURE REORDERWFTRANSITIONS(
P_API_VERSION IN NUMBER,
P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
X_RETURN_STATUS OUT VARCHAR2,
X_MSG_COUNT OUT NUMBER,
X_MSG_DATA OUT VARCHAR2,
PI_REORDEROBJCOLL IN CDR_REORDER_OBJ_COLL
);

```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameter:

PI_REORDEROBJCOLL Collection of the columns to be re-ordered.

18.1.7 Check in a Workflow Definition

Use this API to check in a Workflow definition object.

Name CDR_PUB_DF_WORKFLOW.CHECKINWORKFLOWDEF

Signature

```

PROCEDURE CHECKINWORKFLOWDEF(
P_API_VERSION IN NUMBER,
P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
X_RETURN_STATUS OUT VARCHAR2,
X_MSG_COUNT OUT NUMBER,
X_MSG_DATA OUT VARCHAR2,

```

```

PIO_CDRWORKFLOW IN OUT    CDR_BASE_OBJ_TYPE,
PI_COMMENT IN      VARCHAR2
);

```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

- **PIO_CDRWORKFLOW** This parameter refers to the workflow definition to be checked in.

Initialize in `cdr_base_obj_type`, the basic naming details (COMPANY_ID, OBJ_ID, OBJ_VER, NAMESPACE_OBJ_ID, NAMESPACE_OBJ_VER, OBJECT_VERSION_NUMBER) of the workflow to be checked in.

- **PI_COMMENT** Comment to be associated with the check in operation

18.1.8 Remove a Transition

Use this API to remove one or more Workflow transitions.

Name CDR_PUB_DF_WORKFLOW.REMOVEWFTRANSITION

Signature

```

PROCEDURE REMOVEWFTRANSITION(
  P_API_VERSION IN      NUMBER,
  P_INIT_MSG_LIST IN     VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN      VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN   NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
  X_RETURN_STATUS OUT    VARCHAR2,
  X_MSG_COUNT OUT      NUMBER,
  X_MSG_DATA OUT      VARCHAR2,
  PI_CDRCHILDOBJ IN     CDR_BASE_OBJ_COLL
);

```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameter:

PI_CDRCHILDOBJ (Mandatory) This is a collection of CDR_BASE_OBJ_TYPES.

For each Workflow transition that you want to remove, initialize a CDR_BASE_OBJ_TYPE and then extend the collection.

The following attributes are required for each Workflow transition: COMPANY_ID, OBJ_ID, OBJ_VER, NAMESPACE_OBJ_ID, NAMESPACE_OBJ_VER, OBJECT_VERSION_NUMBER.

18.1.9 Remove a Workflow Activity

Use this API to remove one or more Workflow activities. Workflow activities include all executable objects: Load Sets, Programs, Data Marts, and Report Sets; and also Workflow structures: And, Or, Start, End_Success, End_Warning, End_Error, and Fork.

Name CDR_PUB_DF_WORKFLOW.REMOVEOBJECTSFROMWORKFLOW

Signature

```

PROCEDURE REMOVEOBJECTSFROMWORKFLOW(
  P_API_VERSION IN      NUMBER,
  P_INIT_MSG_LIST IN     VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN      VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,

```

```

P_VALIDATION_LEVEL IN    NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
X_RETURN_STATUS OUT    VARCHAR2,
X_MSG_COUNT OUT    NUMBER,
X_MSG_DATA OUT    VARCHAR2,
PI_CDRCHILDOBJ IN    CDR_BASE_OBJ_COLL
);

```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameter:

PI_CDRCHILDOBJ (Mandatory) This is a collection of CDR_BASE_OBJ_TYPES.

For each Workflow activity that you want to remove, initialize a CDR_BASE_OBJ_TYPE and then extend the collection.

The following attributes are required for each Workflow activity: COMPANY_ID, OBJ_ID, OBJ_VER, NAMESPACE_OBJ_ID, NAMESPACE_OBJ_VER, OBJECT_VERSION_NUMBER.

18.1.10 Remove a Workflow Instance

Use this API to remove a Workflow instance object.

Name CDR_PUB_DF_WORKFLOW.REMOVE

Signature

```

PROCEDURE REMOVE(
  P_API_VERSION IN    NUMBER,
  P_INIT_MSG_LIST IN    VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN    VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN    NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
  X_RETURN_STATUS OUT    VARCHAR2,
  X_MSG_COUNT OUT    NUMBER,
  X_MSG_DATA OUT    VARCHAR2,
  PI_BASEOBJCOLL IN OUT    CDR_BASE_OBJ_COLL
);

```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameter:

PI_BASEOBJCOLL This refers to collection of workflow instances to be removed.

18.1.11 Remove a Workflow Definition

Use this API to remove one or more Workflow definitions.

Name CDR_PUB_DF_WORKFLOW.REMOVEWORKFLOW

Signature

```

PROCEDURE REMOVEWORKFLOW(
  P_API_VERSION IN    NUMBER,
  P_INIT_MSG_LIST IN    VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN    VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN    NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
  X_RETURN_STATUS OUT    VARCHAR2,
  X_MSG_COUNT OUT    NUMBER,
  X_MSG_DATA OUT    VARCHAR2,
  PIO_CDRWORKFLOW IN OUT    CDR_BASE_OBJ_TYPE
);

```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameter:

PIO_CDRWORKFLOW (Mandatory) This is a parameter of CDR_BASE_OBJ_TYPES.

For each Workflow that you want to remove, initialize a CDR_BASE_OBJ_TYPE.

The following attributes are required: COMPANY_ID, OBJ_ID, OBJ_VER, NAMESPACE_OBJ_ID, NAMESPACE_OBJ_VER, OBJECT_VERSION_NUMBER of the workflow to be removed should be initialized in cdr_base_obj_type.

Workflow Notifications

This is a public interface for Notifications-related operations.

19.1 Create and Modify Notifications

This section contains the following topics:

- [Section 19.1.1, "Create a Notification"](#)
- [Section 19.1.2, "Create a Notification Recipient"](#)
- [Section 19.1.3, "Create a Notification Link"](#)
- [Section 19.1.4, "Check Out a Notification Definition"](#)
- [Section 19.1.5, "Modify a Notification Definition"](#)
- [Section 19.1.6, "Modify a Notification Instance"](#)
- [Section 19.1.7, "Send a Notification"](#)
- [Section 19.1.8, "Check in a Notification Definition"](#)
- [Section 19.1.9, "Remove a Notification Link"](#)
- [Section 19.1.10, "Remove a Notification Recipient"](#)
- [Section 19.1.11, "Remove a Notification"](#)

19.1.1 Create a Notification

Use this API to create a Notification definition or instance. This API also initializes the classification of the new Notification object.

Name CDR_PUB_DF_NOTIFICATIONS.CREATENOTIFICATION

Signature

```
PROCEDURE CREATENOTIFICATION(
  P_API_VERSION IN NUMBER,
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
  X_RETURN_STATUS OUT VARCHAR2,
  X_MSG_COUNT OUT NUMBER,
  X_MSG_DATA OUT VARCHAR2,
  PIO_SOURCECDRNAMING IN OUT CDR_NAMING_VERSION_OBJ_TYPE,
  PI_CDRNOTIFICATION IN CDR_NOTIFICATION_OBJ_TYPE,
  PI_CREATEOBJECT IN VARCHAR2,
```

```
PI_DEFCLASSIFICATIONCOLL IN CDR_CLASSIFICATIONS_COLL  
);
```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

- **PIO_SOURCECDRNAMING** (Mandatory) This is a parameter of table type CDR_NAMING_VERSIONS_OBJ_TYPE that contains CDR Naming Version attributes.

If you are creating a new definition only or a new definition and an instance of it, enter values for the new definition.

If you are creating an instance of an existing definition, enter values to identify the existing definition.

For OBJECT_TYPE_RC enter \$OBJTYPES\$NOTIFICATION if you are creating a definition only; \$OBJTYPES\$NOTIFREF if you are creating an instance of an existing definition; and also if you are creating a new definition and an instance of it.

- **PI_CDRNOTIFICATION** (Mandatory) This is a parameter of table type CDR_NOTIFICATION_OBJ_TYPE that contains Notification specific attributes.

Enter FYI or APPROVAL for NOTIF_TYPE_RC.

Enter HIGH, MEDIUM, or LOW for NOTIF_PRIORITY_RC.

Enter ALL or ANY for ALL_REPLIES_FLAG_RC for Notifications of type APPROVAL.

- **PI_CREATEOBJECT** Enter DEFN for creating a definition, INST for creating an instance, and BOTH for creating a definition and an instance of it.

- **PI_DEFCLASSIFICATIONCOLL** (Optional) By default the new definition is classified according to the subtype you assigned it in the CDR_NAMING_VERSION_OBJ_TYPE.

If you want to override the default classifications for one or more classification levels, use this parameter. This is a collection of CDR_CLA_OBJ_TYPES, which have 5 attributes, including CLA_LEVEL_ID and CLASSIFICATION_ID.

If you want the definition to inherit its classifications for a particular level from its parent, enter the classification level ID and, for the CLASSIFICATION_ID, enter 0 (zero).

If you want to explicitly assign one or more terms for a particular level, initialize a CDR_CLA_OBJ_TYPE for each term, entering the classification level ID and, for the CLASSIFICATION_ID, the term ID.

The PAR_ attributes are not relevant to Notifications. Do not enter any values for them.

19.1.2 Create a Notification Recipient

Use this API to create Notification recipients. Notification recipients are group roles of a user group.

Name CDR_PUB_DF_NOTIFICATIONS.CREATENOTIFICATIONRECIPIENT

Signature

```
PROCEDURE CREATENOTIFICATIONRECIPIENT (
```



```

P_API_VERSION IN NUMBER,
P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
X_RETURN_STATUS OUT VARCHAR2,
X_MSG_COUNT OUT NUMBER,
X_MSG_DATA OUT VARCHAR2,
PI_CDRNOTIFRECIPIENTS IN CDR_NTFRCP_COLL
);

```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameter:

PI_CDRNOTIFRECIPIENTS This is a collection of CDR_NOTIF_RECIPIENT_OBJ_TYPE.

If the Notification is of type APPROVAL, for the attribute FALLBACK_FLAG_RC you need to enter \$NOTIFRCPTTYPE\$PRIMARY if the recipient is Primary or \$NOTIFRCPTTYPE\$BACKUP if the recipient is Backup.

If the Primary recipients do not respond to an APPROVAL type of Notification within the defined time frame, then the Notification is sent to the Backup recipients.

19.1.3 Create a Notification Link

Use this API to create links to Planned Outputs of executables owned by a Workflow.

Name CDR_PUB_DF_NOTIFICATIONS.CREATE_NOTIFICATION_LINKS

Signature

```

PROCEDURE CREATE_NOTIFICATION_LINKS(
P_API_VERSION IN NUMBER,
P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
X_RETURN_STATUS OUT VARCHAR2,
X_MSG_COUNT OUT NUMBER,
X_MSG_DATA OUT VARCHAR2,
PI_CDRNOTIFLINKS IN CDR_NOTIF_LINKS_OBJ_COLL
);

```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

PI_CDRNOTIFLINKS This is a collection of CDR_NOTIF_LINKS_OBJ_TYPE.

You need to enter values for the following attributes: COMPANY_ID, NFINST_OBJ_ID, NFINST_OBJ_VER, PO_COMPANY_ID, PO_OBJ_ID, ACTIVITY_COMPANY_ID, ACTIVITY_OBJ_ID, ACTIVITY_OBJ_VER.

19.1.4 Check Out a Notification Definition

Use this API to check out a Notification definition.

Name CDR_PUB_DF_NOTIFICATIONS.CHECKOUTNOTIF

Signature

```

PROCEDURE CHECKOUTNOTIF(
P_API_VERSION IN NUMBER,

```

```
P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
X_RETURN_STATUS OUT VARCHAR2,
X_MSG_COUNT OUT NUMBER,
X_MSG_DATA OUT VARCHAR2,
PIO_CDRNOTIF IN OUT CDR_BASE_OBJ_TYPE,
PI_COMMENT IN VARCHAR2,
PI_ISINSTONLY IN VARCHAR2,
PI_OPTYPE IN VARCHAR2
);
```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

- **PIO_CDRNOTIF** [Mandatory] This is a parameter of table type CDR_BASE_OBJ_TYPE that contains object attributes. Identify the Notification definition you want to check out.

Provide the basic naming attributes: COMPANY_ID, OBJECT_ID, OBJECT_VER, NAMESPACE_OBJ_ID, NAMESPACE_OBJ_VER, OBJECT_VERSION_NUMBER. Initialize these attributes in CDR_BASE_OBJ_TYPE.

- **PI_COMMENT** (Optional) Enter the reason you are checking in the Notification.
- **PI_ISINSTONLY** Enter \$YESNO\$NO.
- **PI_OPTYPE** Enter NULL for this parameter.

19.1.5 Modify a Notification Definition

Use this API to modify a Notification definition. You need to check out the Notification definition first.

Name CDR_PUB_DF_NOTIFICATIONS.MODIFYNOTIFICATION

Signature

```
PROCEDURE MODIFYNOTIFICATION(
  P_API_VERSION IN NUMBER,
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
  X_RETURN_STATUS OUT VARCHAR2,
  X_MSG_COUNT OUT NUMBER,
  X_MSG_DATA OUT VARCHAR2,
  PIO_SOURCECDRNAMING IN OUT CDR_NAMING_VERSION_OBJ_TYPE,
  PI_CDRNOTIFICATION IN CDR_NOTIFICATION_OBJ_TYPE
);
```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

- **PIO_SOURCECDRNAMING** (Mandatory) This is a parameter of table type CDR_NAMING_VERSIONS_OBJ_TYPE that contains CDR Naming Version attributes.
Initialize the attributes COMPANY_ID, OBJECT_ID, and OBJECT_VER.
- **PI_CDRNOTIFICATION** (Mandatory) This is a parameter of table type CDR_NOTIFICATION_OBJ_TYPE. Provide values for the attributes you want to modify.

19.1.6 Modify a Notification Instance

Use this API to modify a Notification instance.

Name CDR_PUB_DF_NOTIFICATIONS.MODIFYNOTIFICATIONINSTANCE

Signature

```
PROCEDURE MODIFYNOTIFICATIONINSTANCE (
  P_API_VERSION IN NUMBER,
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
  X_RETURN_STATUS OUT VARCHAR2,
  X_MSG_COUNT OUT NUMBER,
  X_MSG_DATA OUT VARCHAR2,
  PIO_SOURCECDRNAMING IN OUT CDR_NAMING_VERSION_OBJ_TYPE,
  PI_CDRNOTIFICATION IN CDR_NOTIFICATION_OBJ_TYPE
);
```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

- **PIO_SOURCECDRNAMING** (Mandatory) This is a parameter of table type CDR_NAMING_VERSIONS_OBJ_TYPE that contains CDR Naming Version attributes.
Initialize the attributes COMPANY_ID, OBJECT_ID, and OBJECT_VER.
- **PI_CDRNOTIFICATION** (Mandatory) This is a parameter of table type CDR_NOTIFICATION_OBJ_TYPE. Provide values for the attributes you want to modify.

19.1.7 Send a Notification

Use this API to send an information Notification either from a Program or from another database user.

Name CDR_PUB_DF_NOTIFICATIONS.SEND_FYI_NOTIFICATION

Signature

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

- **PI_JOB_ID** Enter the job ID created for the corresponding job for the notifications sent.
- **PI_USER_GROUP** Enter the user group identifier.
- **PI_ROLE_CODE** Enter the role code identifier.
- **PI_SUBJECT** Enter the subject of the notification.
- **PI_BODY** Enter the body content of the notification.
- **PI_URL** Enter the URL to be embedded in the notification.

19.1.8 Check in a Notification Definition

Use this API to check in a Notification definition.

Name CDR_PUB_DF_NOTIFICATIONS.CHECKINNOTIFDEF

Signature

```
PROCEDURE CHECKINNOTIFDEF (
  P_API_VERSION IN NUMBER,
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
  X_RETURN_STATUS OUT VARCHAR2,
  X_MSG_COUNT OUT NUMBER,
  X_MSG_DATA OUT VARCHAR2,
  PIO_CDRNOTIF IN OUT CDR_BASE_OBJ_TYPE,
  PI_COMMENT IN VARCHAR2
);
```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

- **PIO_CDRNOTIF** [Mandatory] This is a parameter of table type CDR_BASE_OBJ_TYPE that object attributes.

Identify the Notification definition you want to check in. Provide the basic naming attributes: COMPANY_ID, OBJECT_ID, OBJECT_VER, NAMESPACE_OBJ_ID, NAMESPACE_OBJ_VER, OBJECT_VERSION_NUMBER. Initialize these attributes in CDR_BASE_OBJ_TYPE.
- **PI_COMMENT** (Optional) Enter the reason you are checking in the Notification.

19.1.9 Remove a Notification Link

Use this API to remove links to Planned Outputs of executables owned by the Workflow.

Name CDR_PUB_DF_NOTIFICATIONS.REMOVENOTIFICATIONLINKS

Signature

```
PROCEDURE REMOVENOTIFICATIONLINKS (
  P_API_VERSION IN NUMBER,
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
  X_RETURN_STATUS OUT VARCHAR2,
  X_MSG_COUNT OUT NUMBER,
  X_MSG_DATA OUT VARCHAR2,
  PI_CDRNOTIFLINKS IN CDR_NOTIF_LINKS_OBJ_COLL
);
```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameter:

PI_CDRNOTIFLINKS (Mandatory) This is a collection of CDR_NOTIF_LINKS_OBJ_TYPE. For each Planned Output link that you want to remove, initialize a CDR_NOTIF_LINKS_OBJ_TYPE and then extend the collection.

19.1.10 Remove a Notification Recipient

Use this API to remove a Notification recipient.

Name CDR_PUB_DF_NOTIFICATIONS.REMOVENOTIFICATIONRECIPIENTS

Signature

```
PROCEDURE REMOVENOTIFICATIONRECIPIENTS(
  P_API_VERSION IN NUMBER,
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
  X_RETURN_STATUS OUT VARCHAR2,
  X_MSG_COUNT OUT NUMBER,
  X_MSG_DATA OUT VARCHAR2,
  PI_CDRNOTIFRECIPIENTS IN CDR_NTFRCP_COLL
);
```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

PI_CDRNOTIFRECIPIENTS This is a collection of CDR_NOTIF_RECIPIENT_OBJ_TYPE.

For each Recipient that you want to remove, initialize a CDR_NOTIF_RECIPIENT_OBJ_TYPE and then extend the collection.

The following attributes are required: COMPANY_ID,OBJ_ID,OBJ_VER,USER_GROUP_ID,ROLE_ID,FALLBACK_FLAG_RC.

19.1.11 Remove a Notification

Use this API to remove a Notification definition.

Name CDR_PUB_DF_NOTIFICATIONS.REMOVENOTIFICATIONS

Signature

```
PROCEDURE REMOVENOTIFICATIONS(
  P_API_VERSION IN NUMBER,
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
  X_RETURN_STATUS OUT VARCHAR2,
  X_MSG_COUNT OUT NUMBER,
  X_MSG_DATA OUT VARCHAR2,
  PI_BASEOBJCOLL IN OUT CDR_BASE_OBJ_COLL
);
```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameter:

PI_BASEOBJCOLL (Mandatory) This is a collection of CDR_BASE_OBJ_TYPE. For each Notification that you want to remove, initialize a CDR_BASE_OBJ_TYPE and then extend the collection.

The following attributes are required: COMPANY_ID,OBJ_ID,OBJ_VER,OBJECT_VERSION_NUMBER,NAMESPACE_OBJ_ID,NAMESPACE_OBJ_VER.

Part III

Common APIs

This part of the Oracle Life Sciences Data Hub (Oracle LSH) API guide contains APIs that you can use to perform common tasks such as creating and modifying execution setups, mapping, managing outputs, labels and jobs. This part also contains APIs that you use for classification, validation and handling security in Oracle LSH.

Part III contains the following chapters:

- [Chapter 20, "Execution Setups"](#)
- [Chapter 21, "Mappings"](#)
- [Chapter 22, "Outputs"](#)
- [Chapter 23, "Version Labels"](#)
- [Chapter 24, "Classification"](#)
- [Chapter 25, "Job Execution"](#)
- [Chapter 26, "Security Policy"](#)
- [Chapter 27, "Validation"](#)

Execution Setups

This is a public interface for Execution Setup-related operations, including creating, modifying, and removing Execution Setups. It also includes functions for checking Execution Setups in and out.

20.1 Create and Modify Execution Setups

This section contains the following topics:

- [Section 20.1.1, "Create an Execution Setup"](#)
- [Section 20.1.2, "Check Out an Execution Setup"](#)
- [Section 20.1.3, "Modify an Execution Setup"](#)
- [Section 20.1.4, "Modify a Parameter"](#)
- [Section 20.1.5, "Modify an Execution Setup Parameter"](#)
- [Section 20.1.6, "Load Parameter Details"](#)
- [Section 20.1.7, "Copy an Execution Setup"](#)
- [Section 20.1.8, "Check In an Execution Setup"](#)
- [Section 20.1.9, "Submit an Execution Setup"](#)
- [Section 20.1.10, "Submit an Execution Setup for Instances"](#)
- [Section 20.1.11, "Upgrade an Execution Setup"](#)
- [Section 20.1.12, "Upgrade All Execution Setups"](#)
- [Section 20.1.13, "Make an Execution Setup Active"](#)
- [Section 20.1.14, "Remove an Execution Setup"](#)

20.1.1 Create an Execution Setup

Use this API to create a new Execution Setup.

Name CDR_PUB_DF_EXECUTIONSETUP.CREATEEXECUTIONSETUP

Signature

```
PROCEDURE CREATEEXECUTIONSETUP(
  P_API_VERSION IN NUMBER,
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
```

```

X_RETURN_STATUS OUT    VARCHAR2,
X_MSG_COUNT OUT      NUMBER,
X_MSG_DATA OUT      VARCHAR2,
PIO_SOURCECDRNAMING IN OUT    CDR_NAMING_VERSION_OBJ_TYPE,
PO_DEFCLASSIFICATIONCOLL IN    CDR_CLASSIFICATIONS_COLL
);

```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

- **PIO_SOURCECDRNAMING** (Mandatory) This is a parameter of table type CDR_NAMING_VERSIONS_OBJ_TYPE that contains CDR Naming Version attributes. For OBJECT_TYPE_RC enter \$OBJTYPES\$EXECSETUP.
- **PO_DEFCLASSIFICATIONCOLL** (Optional) By default the new definition is classified according to the subtype you assigned it in the CDR_NAMING_VERSION_OBJ_TYPE.

If you want to override the default classifications for one or more classification levels, use this parameter. This is a collection of CDR_CLA_OBJ_TYPES, which have 5 attributes, including CLA_LEVEL_ID and CLASSIFICATION_ID.

If you want the definition to inherit its classifications for a particular level from its parent, enter the classification level ID and, for the CLASSIFICATION_ID, enter 0 (zero).

If you want to explicitly assign one or more terms for a particular level, initialize a CDR_CLA_OBJ_TYPE for each term, entering the classification level ID and, for the CLASSIFICATION_ID, the term ID. The PAR_ attributes are not relevant to Execution Setups. Do not enter any values for them. If you are not creating a new definition, do not enter values here.

20.1.2 Check Out an Execution Setup

Use this API to check out an Execution Setup.

Name CDR_PUB_DF_EXECUTIONSETUP.CHECKOUTEXECUTIONSETUP

Signature

```

PROCEDURE CHECKOUTEXECUTIONSETUP (
  P_API_VERSION IN    NUMBER,
  P_INIT_MSG_LIST IN   VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN   VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN    NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
  X_RETURN_STATUS OUT    VARCHAR2,
  X_MSG_COUNT OUT      NUMBER,
  X_MSG_DATA OUT      VARCHAR2,
  PIO_BASEOBJECT IN OUT    CDR_BASE_OBJ_TYPE,
  PI_COMMENT IN   VARCHAR2,
  PI_ISINSTONLY IN   VARCHAR2
);

```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

- **PIO_BASEOBJECT** (Mandatory) This is a parameter of table type CDR_BASE_OBJ_TYPE that contains object attributes. Enter values to identify the Execution Setup that you want to check out.

The following attributes are required: COMPANY_ID,OBJ_ID,OBJ_VER,OBJECT_VERSION_NUMBER,NAMESPACE_OBJ_ID,NAMESPACE_OBJ_VER.

- **PI_COMMENT** (Optional) Enter the reason you are checking out the Execution Setup.
- **PI_ISINSTONLY** (Mandatory) Enter \$YESNO\$NO.

20.1.3 Modify an Execution Setup

Use this API to modify an Execution Setup. You can change an Execution Setup's name and description. You must check out the Execution Setup before modifying it.

Name CDR_PUB_DF_EXECUTIONSETUP.MODIFYEXECUTIONSETUP

Signature

```
PROCEDURE MODIFYEXECUTIONSETUP(
  P_API_VERSION IN NUMBER,
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
  X_RETURN_STATUS OUT VARCHAR2,
  X_MSG_COUNT OUT NUMBER,
  X_MSG_DATA OUT VARCHAR2,
  PIO_SOURCECDRNAMING IN OUT CDR_NAMING_VERSION_OBJ_TYPE
);
```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameter:

- **PIO_SOURCECDRNAMING** (Mandatory) This is a parameter of table type CDR_NAMING_VERSION_OBJ_TYPE that contains object attributes. Enter values to identify the Execution Setup and enter new values for the attributes you want to modify. All attributes are required.

Note: Use separate APIs for modifying the validation status and the version label: CDR_PUB_VL_VALIDATION.UPDATEVALSTATUS and CDR_PUB_DF_NAMING.UPDATEVERSIONLABEL.

20.1.4 Modify a Parameter

Use this API to modify Execution Setup parameters.

Name CDR_PUB_DF_EXECUTIONSETUP.MODIFYPARAMETER

Signature

```
PROCEDURE MODIFYPARAMETER(
  P_API_VERSION IN NUMBER,
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
  X_RETURN_STATUS OUT VARCHAR2,
  X_MSG_COUNT OUT NUMBER,
  X_MSG_DATA OUT VARCHAR2,
  PI_CHANGEDPARAMETERCOLL IN CDR_SUBMISSION_DETAILS_COLL
);
```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameter:

PI_CHANGEDPARAMETERCOLL (Mandatory) This is a collection of CDR_SUBMISSION_DETAILS.Collection of Parameter Instances on which the modify operation has been requested.

20.1.5 Modify an Execution Setup Parameter

Use this API to modify the parameters of an Execution Setup.

Name CDR_PUB_DF_EXECUTIONSETUP.MODIFYESPARAMETERS

Signature

```
PROCEDURE MODIFYESPARAMETERS (
  P_API_VERSION IN NUMBER,
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
  X_RETURN_STATUS OUT VARCHAR2,
  X_MSG_COUNT OUT NUMBER,
  X_MSG_DATA OUT VARCHAR2,
  PIO_PARAMETERCOLL IN OUT CDR_PARAMETER_COLL
);
```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameter:

PIO_PARAMETERCOLL (Mandatory) This is a collection of cdr_parameter_coll. Enter the values for parameters you want to change.

The attributes you can change are: read_only_flag_rc, mandatory_flag_rc, and visible_flag_rc. Enter \$yesno\$yes for yes, and \$yesno\$no for no.

20.1.6 Load Parameter Details

Use this API to insert all parameters into a CDR_ES_TEMP table before submitting Report Set instance and Work Flow instance jobs.

Name CDR_PUB_DF_EXECUTIONSETUP.LOADESTEMPTABLE

Signature

```
PROCEDURE LOADESTEMPTABLE(
  P_API_VERSION IN NUMBER,
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
  X_RETURN_STATUS OUT VARCHAR2,
  X_MSG_COUNT OUT NUMBER,
  X_MSG_DATA OUT VARCHAR2,
  PI_BASEOBJ IN CDR_BASE_OBJ_TYPE,
  PI_NODEPRREFID IN NUMBER := NULL,
  PI_NODEPRREFVER IN NUMBER := NULL,
  PI_JOBID IN NUMBER := NULL
);
```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

- **PI_BASEOBJ** (Mandatory) This is a parameter of cdr_base_obj type for the Execution Setup. Enter the necessary attributes.
- **PI_NODEPRREFID** (Mandatory) If you are submitting a single RSE, enter the prref_id of that RSE, else enter NULL.
- **PI_NODEPRREFVER** (Mandatory) If you are submitting a single RSE, enter the prref_ver of that RSE, else enter NULL.
- **PI_JOBID** (Mandatory) If you are re-submitting an existing job, enter the previous job_id, else enter NULL.

20.1.7 Copy an Execution Setup

Use this API to duplicate one or more Execution Setups for an object.

Name CDR_PUB_DF_EXECUTIONSETUP.COPYEXECUTIONSETUP

Signature

```
PROCEDURE COPYEXECUTIONSETUP (
  P_API_VERSION IN NUMBER,
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
  X_RETURN_STATUS OUT VARCHAR2,
  X_MSG_COUNT OUT NUMBER,
  X_MSG_DATA OUT VARCHAR2,
  PI_EXECUTIONSETUP IN OUT CDR_BASE_OBJ_COLL
);
```

Parameters This API has standard parameters (see "[Standard Parameters](#)" on page 5) and the following parameter:

- **PI_EXECUTIONSETUP** (Mandatory) This is a collection of CDR_BASE_OBJ_TYPES. For each Execution Setup that you want to copy, initialize a CDR_BASE_OBJ_TYPE and then extend the collection.

The following attributes are required: COMPANY_ID,OBJ_ID,OBJ_VER,OBJECT_VERSION_NUMBER,NAMESPACE_OBJ_ID,NAMESPACE_OBJ_VER.

20.1.8 Check In an Execution Setup

Use this API to check in an Execution Setup.

Name CDR_PUB_DF_EXECUTIONSETUP.CHECKINEXECUTIONSETUP

Signature

```
PROCEDURE CHECKINEXECUTIONSETUP (
  P_API_VERSION IN NUMBER,
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
  X_RETURN_STATUS OUT VARCHAR2,
  X_MSG_COUNT OUT NUMBER,
  X_MSG_DATA OUT VARCHAR2,
  PIO_BASEOBJECT IN OUT CDR_BASE_OBJ_TYPE,
  PI_COMMENT IN VARCHAR2
);
```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

- **PIO_BASEOBJECT** (Mandatory) This is a parameter of table type CDR_BASE_OBJ_TYPE that contains object attributes. Enter values to identify the Execution Setup that you want to check in.

The following attributes are required: COMPANY_ID,OBJ_ID,OBJ_VER,OBJECT_VERSION_NUMBER,NAMESPACE_OBJ_ID,NAMESPACE_OBJ_VER

- **PI_COMMENT** (Optional) Enter the reason you are checking in the Execution Setup.

20.1.9 Submit an Execution Setup

Use this API to submit an Execution Setup.

Name CDR_PUB_DF_EXECUTIONSETUP.SUBMITEXECUTIONSETUP

Signature

```
PROCEDURE SUBMITEXECUTIONSETUP(
  P_API_VERSION IN NUMBER,
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
  X_RETURN_STATUS OUT VARCHAR2,
  X_MSG_COUNT OUT NUMBER,
  X_MSG_DATA OUT VARCHAR2,
  PI_EXECUTIONSETUP IN CDR_BASE_OBJ_TYPE,
  PI_CHANGEDSYSTEMPARAMETERCOLL IN CDR_SUBMISSION_DETAILS_COLL,
  PI_TICOLL IN CDR_SNAPSHOT_TABLE_COLL,
  PI_INCLUDEDOBJCOLL IN CDR_SUBMISSION_DETAILS_COLL,
  PI_CURRENTJOBID OUT VARCHAR2,
  PI_OUTPUTTITLE IN VARCHAR2,
  PI_OUTPUTDESC IN VARCHAR2
);
```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

- **PI_EXECUTIONSETUP** (Mandatory) This is a parameter of table type CDR_BASE_OBJ_TYPE that contains object attributes. Enter values to identify the Execution Setup that you want to submit.

The following attributes are required: COMPANY_ID,OBJ_ID,OBJ_VER,OBJECT_VERSION_NUMBER,NAMESPACE_OBJ_ID,NAMESPACE_OBJ_VER.

- **PI_CHANGEDSYSTEMPARAMETERCOLL**
- **PI_TICOLL** (Mandatory) This is a collection of CDR_SNAPSHOT_TABLE_OBJ_TYPE.
- **PI_INCLUDEDOBJCOLL** (Mandatory) This is a collection of CDR_SUBMISSION_DETAILS_OBJ_TYPE that contains PRREF_IDs of Programs to include in the Execution Setup. For Report Sets and Report Set Entries, the user can include only selected Report Sets for execution. Enter only those PRREF_IDs.
- **PI_CURRENTJOBID** (Mandatory) Enter the JOB_ID of the Job that this Execution Setup submission created. This parameter is used to generate user's feedback.

- **PI_OUTPUTTITLE** (Mandatory) Enter a title for the output from this Execution Setup.
- **PI_OUTPUTDESC** (Mandatory) Enter the description for the output from this Execution Setup.

20.1.10 Submit an Execution Setup for Instances

Use this API to submit an Execution Setup for Report Set instances and Workflow instances. You must call the loadESTempTable() API before calling this API.

Name CDR_PUB_DF_EXECUTIONSETUP.SUBMITEXECUTIONSETUP

Signature

```
PROCEDURE SUBMITEXECUTIONSETUP (
  P_API_VERSION IN NUMBER,
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
  X_RETURN_STATUS OUT VARCHAR2,
  X_MSG_COUNT OUT NUMBER,
  X_MSG_DATA OUT VARCHAR2,
  PI_EXECUTIONSETUP IN OUT CDR_BASE_OBJ_TYPE,
  PIO_CHANGEDSYSTEMPARAMETERCOLL IN OUT CDR_SUBMISSION_DETAILS_COLL,
  PI_TICOLL IN CDR_SNAPSHOT_TABLE_COLL,
  PO_CURRENTJOBID OUT VARCHAR2,
  PI_OUTPUTTITLE IN VARCHAR2,
  PI_OUTPUTDESC IN VARCHAR2
);
```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

- **PI_EXECUTIONSETUP** (Mandatory) This is a parameter of cdr_base_obj_type.
Enter values for attributes that describe the Execution Setup: COMPANY_ID, OBJ_ID, OBJ_VER, NAMESPACE_OBJ_ID, NAMESPACE_OBJ_VER, OBJECT_VERSION_NUMBER.
- **PIO_CHANGEDSYSTEMPARAMETERCOLL** (Mandatory) This is a parameter of cdr_submission_details_coll type.
You must provide values for the following system parameters: company_id (use CDR_DF_PUB_DEF_CONSTANTS.CURRENT_COMPANY_ID); submission_id (enter null); prref_id (enter -1), prref_ver (enter -1), parameter_ref_obj_id, and parameter_ref_obj_id. Query cdr_parameters on company_id, obj_id, and obj_ver to find values for the default_value attribute. Use this value to set the attribute parameter_value.
- **PI_TICOLL** (Mandatory) This is a collection of data snapshots. This value may be null if you want to use current data.
Otherwise the required attributes are: TI_OBJ_ID, TI_OBJ_VER, SRC_MASTER_JOB_ID, SRC_COMPANY_ID
- **PO_CURRENTJOBID** (Mandatory) This is an output parameter. The system generates a Job ID for the submitted Execution Setup. You can print this parameter through your program.
- **PI_OUTPUTTITLE** (Mandatory) Enter a title for the Execution Setup. It is easy to track an Execution Setup with a meaningful title.

- **PI_OUTPUTDESC** (Mandatory) Enter a description for the Execution Setup output.

20.1.11 Upgrade an Execution Setup

Use this API to upgrade one single Execution Setup.

Name CDR_PUB_DF_EXECUTIONSETUP.UPGRADEEXECSETUP

Signature

```
PROCEDURE UPGRADEEXECSETUP(  
    P_API_VERSION IN NUMBER,  
    P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,  
    P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,  
    P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,  
    X_RETURN_STATUS OUT VARCHAR2,  
    X_MSG_COUNT OUT NUMBER,  
    X_MSG_DATA OUT VARCHAR2,  
    PI_ESCOMPID IN NUMBER,  
    PI_ESOBJID IN NUMBER,  
    PI_ESOBJVER IN NUMBER,  
    PO_UPGRADESTATUS IN OUT VARCHAR2  
);
```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

- **PI_ESCOMPID** (Mandatory) Enter the COMPANY_ID of the Execution Setup.
- **PI_ESOBJID** (Mandatory) Enter the OBJ_ID of the Execution Setup.
- **PI_ESOBJVER** (Mandatory) Enter the OBJ_VER of the Execution Setup.
- **PO_UPGRADESTATUS** This is an output parameter that indicates whether or not the Execution Setup's upgrade was successful.

20.1.12 Upgrade All Execution Setups

Use this API to upgrade all the Execution Setups associated with an object.

Name CDR_PUB_DF_EXECUTIONSETUP.UPGRADEEXECSETUPS

Signature

```
PROCEDURE UPGRADEEXECSETUPS(  
    P_API_VERSION IN NUMBER,  
    P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,  
    P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,  
    P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,  
    X_RETURN_STATUS OUT VARCHAR2,  
    X_MSG_COUNT OUT NUMBER,  
    X_MSG_DATA OUT VARCHAR2,  
    PI_EOICOMPID IN NUMBER,  
    PI_EOIOBJID IN NUMBER,  
    PI_EOIOBJVER IN NUMBER,  
    PO_NOTRUNNABLEESLIST OUT CDR_BASE_OBJ_COLL  
);
```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

- **PI_EOICOMPID** (Mandatory) Enter the COMPANY_ID of the executable object instance for which the Execution Setup is intended.
- **PI_EOIOBJID** (Mandatory) Enter the OBJ_ID of the executable object instance for which the Execution Setup is intended.
- **PI_EOIOBJVER** (Mandatory) Enter the OBJ_VER of the executable object instance for which the Execution Setup is intended.
- **PO_NOTRUNNABLEESLIST** This is an output parameter that returns a collection of CDR_BASE_OBJ_TYPE containing Execution Setups whose status has changed from Runnable to Not-Runnable.

20.1.13 Make an Execution Setup Active

Use this API to set the status of an Execution Setup to Active.

Name CDR_PUB_DF_EXECUTIONSETUP.SETACTIVE

Signature

```
PROCEDURE SETACTIVE(
  P_API_VERSION IN NUMBER,
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
  X_RETURN_STATUS OUT VARCHAR2,
  X_MSG_COUNT OUT NUMBER,
  X_MSG_DATA OUT VARCHAR2,
  PI_ESCOMPID IN NUMBER,
  PI_ESOBJID IN NUMBER,
  PI_ESOBJVER IN NUMBER
);
```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

- **PI_ESCOMPID** (Mandatory) Enter the COMPANY_ID of the Execution Setup.
- **PI_ESOBJID** (Mandatory) Enter the OBJ_ID of the Execution Setup.
- **PI_ESOBJVER** (Mandatory) Enter the OBJ_VER of the Execution Setup.

20.1.14 Remove an Execution Setup

Use this API to delete an Execution Setup.

Name CDR_PUB_DF_EXECUTIONSETUP.REMOVEEXECUTIONSETUP

Signature

```
PROCEDURE REMOVEEXECUTIONSETUP(
  P_API_VERSION IN NUMBER,
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
  X_RETURN_STATUS OUT VARCHAR2,
  X_MSG_COUNT OUT NUMBER,
  X_MSG_DATA OUT VARCHAR2,
  PI_EXECUTIONSETUP IN OUT CDR_BASE_OBJ_COLL
);
```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameter:

PI_EXECUTIONSETUP (Mandatory) This is a collection of CDR_BASE_OBJ_TYPEs. For each Execution Setup that you want to remove, initialize a CDR_BASE_OBJ_TYPE and then extend the collection.

The following attributes are required: COMPANY_ID,OBJ_ID,OBJ_VER,OBJECT_VERSION_NUMBER,NAMESPACE_OBJ_ID,NAMESPACE_OBJ_VER.

This is a public interface for mapping-related operations; including—creating and modifying mappings at the Table Descriptor and Column levels, creating a Table Descriptor from a Table instance, or a Table instance from a Table Descriptor, and mapping the two. It also includes functions for getting the unique PRREF_ID and PRREF_VER for the executables and Business Areas that contain Table Descriptors. You need these identifiers to run most of the mapping APIs.

21.1 Create and Modify Mappings

This section contains the following topics:

- [Section 21.1.1, "Map a Column"](#)
- [Section 21.1.2, "Map a Table Descriptor to a Table Instance"](#)
- [Section 21.1.3, "Create a Table Descriptor from a Table Instance"](#)
- [Section 21.1.4, "Create a Table Instance from a Table Descriptor"](#)
- [Section 21.1.5, "Modify a Mapping Column"](#)
- [Section 21.1.6, "Modify a Mapping at the Table Descriptor Level"](#)
- [Section 21.1.7, "Get a PRREF_ID for an Executable in a Workflow"](#)
- [Section 21.1.8, "Get a PRREF_ID for an Object in a Work Area"](#)
- [Section 21.1.9, "Get a PRREF_ID for a Program in a Report Set"](#)

21.1.1 Map a Column

Use this API to map a Table Descriptor's Columns to a Table instance's Columns using default criteria such as Name, Data Type, and Length. Before you run this API you must map the Table Descriptor and instance and note the Mapping ID and version.

Name CDR_PUB_DF_MAPPING.GENERATEDEFAULTMAPPING

Signature

```
PROCEDURE GENERATEDEFAULTMAPPING (
  P_API_VERSION IN NUMBER,
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
  X_RETURN_STATUS OUT VARCHAR2,
  X_MSG_COUNT OUT NUMBER,
  X_MSG_DATA OUT VARCHAR2,
```

```
PI_MAPPING_NAMING IN CDR_NAMING_VERSION_OBJ_TYPE
);
```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameter:

PI_MAPPING_NAMING (Mandatory) This is a parameter of table type CDR_NAMING_VERSION_OBJ_TYPE that contains object attributes. Enter values to identify the Mapping that you want to extend to the Column level.

The following attributes are required: OBJ_ID and OBJ_VER.

21.1.2 Map a Table Descriptor to a Table Instance

Use this API to map a Table Descriptor to a Table instance. You specify the Table Descriptor and Table instance and the API maps the columns if it is possible.

Name CDR_PUB_DF_MAPPING.AUTOMAPTABLEDESC

Signature

```
PROCEDURE AUTOMAPTABLEDESC (
  P_API_VERSION IN NUMBER,
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
  X_RETURN_STATUS OUT VARCHAR2,
  X_MSG_COUNT OUT NUMBER,
  X_MSG_DATA OUT VARCHAR2,
  PI_PRREFID IN CDR_PROGRAM_REFS.PRREF_ID%TYPE,
  PI_PRREFVER IN CDR_PROGRAM_REFS.PRREF_VER%TYPE,
  PI_TDOBJ IN CDR_NAMING_VERSION_OBJ_TYPE,
  PI_TIOBJ IN CDR_NAMING_VERSION_OBJ_TYPE
);
```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

- **PI_PRREFID** (Mandatory) Enter the PRREF_ID of the executable object—Program, Load Set, Data Mart, Business Area that owns the Table Descriptor that you want to map. (Use other APIs in this package to get the PRREF_ID.)
- **PI_PRREFVER** (Mandatory) Enter the PRREF_VER of the executable object or Business Area that owns the Table Descriptors that you want to map. (Use other APIs in this package to get the PRREF_VER.)
- **PI_TDOBJ** (Mandatory) This is a parameter of table type CDR_NAMING_VERSIONS_OBJ_TYPE that contains CDR Naming Version attributes. Enter values to identify the Table Descriptor you want to map.

The required attributes are: COMPANY_ID, OBJ_ID, OBJ_VER.

- **PI_TIOBJ** (Mandatory) This is a parameter of table type CDR_NAMING_VERSIONS_OBJ_TYPE that contains CDR Naming Version attributes. Enter values to identify the Table instance to which you want to map the Table Descriptor.

The required attributes are: COMPANY_ID, OBJ_ID, OBJ_VER.

21.1.3 Create a Table Descriptor from a Table Instance

Use this API to create a Table Descriptor from an existing Table instance and map the two.

Name CDR_PUB_DF_MAPPING.CREATETABDESCFROMTABINST

Signature

```
PROCEDURE CREATETABDESCFROMTABINST(
  P_API_VERSION IN NUMBER,
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
  X_RETURN_STATUS OUT VARCHAR2,
  X_MSG_COUNT OUT NUMBER,
  X_MSG_DATA OUT VARCHAR2,
  PI_PRREFID IN CDR_PROGRAM_REFS.PRREF_ID%TYPE,
  PI_PRREFVER IN CDR_PROGRAM_REFS.PRREF_VER%TYPE,
  PI_TIOBJ IN CDR_NAMING_VERSION_OBJ_TYPE
);
```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

- **PI_PRREFID** (Mandatory) Enter the PRREF_ID of the executable object—Program, Load Set, Data Mart or Business Area, in which you want to create a Table Descriptor. (Use other APIs in this package to get this value.)
- **PI_PRREFVER** (Mandatory) Enter the PRREF_VER of the executable object or Business Area in which you want to create a Table Descriptor. (Use other APIs in this package to get this value.)
- **PI_TIOBJ** (Mandatory) This is a parameter of table type CDR_NAMING_VERSIONS_OBJ_TYPE that contains CDR Naming Version attributes.

Enter values for the Table instance from which you want to create a Table Descriptor. The required attributes are: COMPANY_ID, OBJ_ID, OBJ_VER.

21.1.4 Create a Table Instance from a Table Descriptor

Use this API to create a Table instance from a Table Descriptor and map the two.

Name CDR_PUB_DF_MAPPING.CREATETABINSTFROMTABDESC

Signature

```
PROCEDURE CREATETABINSTFROMTABDESC(
  P_API_VERSION IN NUMBER,
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
  X_RETURN_STATUS OUT VARCHAR2,
  X_MSG_COUNT OUT NUMBER,
  X_MSG_DATA OUT VARCHAR2,
  PI_PRREFID IN CDR_PROGRAM_REFS.PRREF_ID%TYPE,
  PI_PRREFVER IN CDR_PROGRAM_REFS.PRREF_VER%TYPE,
  PI_TDOBJ IN CDR_NAMING_VERSION_OBJ_TYPE,
  PI_INSTANCESUBTYPEID IN CDR_NAMINGS.OBJECT_SUBTYPE_ID%TYPE
);
```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

- **PI_PRREFID** (Mandatory) Enter the PRREF_ID of the executable object instance—Program, Load Set, Data Mart, OR Business Area instance that owns the Table Descriptors that you want to map. (Use other APIs in this package to get this value.)
- **PI_PRREFVER** (Mandatory) Enter the PRREF_VER of the executable object instance or Business Area instance that owns the Table Descriptors that you want to map. (Use other APIs in this package to get this value.)
- **PI_TDOBJ** (Mandatory) This is a parameter of table type CDR_NAMING_VERSIONS_OBJ_TYPE that contains CDR Naming Version attributes.

Enter values for the Table Descriptor from which you want to create a Table Descriptor. The required attributes are: COMPANY_ID, OBJ_ID, OBJ_VER.
- **PI_INSTANCESUBTYPEID** (Mandatory) Enter a value for the Table instance's subtype.

21.1.5 Modify a Mapping Column

Use this API to update a mapping at the Column level. You can map currently unmapped Columns, map Table Descriptor Columns to different Columns in the Table instance, change the default value for any Column, and supply or change a format string for a Column. This API enforces all Column mapping rules.

Name CDR_PUB_DF_MAPPING.UPDATEMAPPINGCOLUMNS

Signature

```
PROCEDURE UPDATEMAPPINGCOLUMNS (  
  P_API_VERSION IN NUMBER,  
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,  
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,  
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,  
  X_RETURN_STATUS OUT VARCHAR2,  
  X_MSG_COUNT OUT NUMBER,  
  X_MSG_DATA OUT VARCHAR2,  
  PI_MAPPING_COLUMNS IN CDR_MAPPING_COLUMNS_COLL  
);
```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameter:

PI_MAPPING_COLUMNS (Mandatory) This is a collection of CDR_MAPPING_COLUMNS_TYPES. For each Column that you want to modify, initialize a CDR_MAPPING_COLUMNS_TYPE and then extend the collection. All the attributes are required.

21.1.6 Modify a Mapping at the Table Descriptor Level

Use this API to update a mapping at the Table Descriptor level in accordance with all validation rules.

Name CDR_PUB_DF_MAPPING.MODIFYMAPPING

Signature

```

PROCEDURE UPDITEMAPPINGCOLUMNS (
    P_API_VERSION IN NUMBER,
    P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
    P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
    P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
    X_RETURN_STATUS OUT VARCHAR2,
    X_MSG_COUNT OUT NUMBER,
    X_MSG_DATA OUT VARCHAR2,
    PI_MAPPING_COLUMNS IN CDR_MAPPING_COLUMNS_COLL
);

```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

PI_MAPPING_COLUMNS (Mandatory) This is a collection of CDR_MAPPING_COLUMNS_TYPES. For each Column that you want to modify, initialize a CDR_MAPPING_COLUMNS_TYPE and then extend the collection. All the attributes are required.

21.1.7 Get a PRREF_ID for an Executable in a Workflow

Use this API to get the PRREF_ID and PRREF_VER for an executable Object instance contained in a Workflow. You need these values to run Mapping APIs.

Name CDR_PUB_DF_MAPPING.GETPRREFIDFOROBJUNDERWF

Signature

```

PROCEDURE GETPRREFIDFOROBJUNDERWF (
    P_API_VERSION IN NUMBER,
    P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
    P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
    P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
    X_RETURN_STATUS OUT VARCHAR2,
    X_MSG_COUNT OUT NUMBER,
    X_MSG_DATA OUT VARCHAR2,
    PI_SIMPLEOBJ IN CDR_BASE_OBJ_TYPE,
    PI_RSIOBJ IN CDR_BASE_OBJ_TYPE,
    PI_WFIOBJ IN CDR_BASE_OBJ_TYPE,
    PO_PRREFID OUT CDR_PROGRAM_REFS.PRREF_ID%TYPE,
    PO_PRREFVER OUT CDR_PROGRAM_REFS.PRREF_VER%TYPE
);

```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

- **PI_SIMPLEOBJ** (Mandatory) This is a parameter of table type CDR_BASE_OBJ_TYPE that contains object attributes. Enter values to identify the Program, Load Set, or Data Mart instance whose PRREFID you need.

The following attributes are required: COMPANY_ID, OBJ_ID, OBJ_VER.

- **PI_RSIOBJ** (Optional) If you are getting the PRREFID for a Program instance contained in a Report Set that within a Workflow, enter values to identify the Report Set instance in which the Program instance is located. This is a parameter of table type CDR_BASE_OBJ_TYPE that contains object attributes.

The following attributes are required: COMPANY_ID, OBJ_ID, OBJ_VER.

- **PI_WFIOBJ** (Mandatory) This is a parameter of table type CDR_BASE_OBJ_TYPE that contains object attributes. Enter values to identify the Workflow instance that contains the Program, Load Set, or Data Mart instance whose PRREFID you need.
The following attributes are required: COMPANY_ID, OBJ_ID, OBJ_VER.
- **PO_PRREFID** This output parameter returns the executable object instance's PRREF_ID.
- **PO_PRREFVER** This output parameter returns the executable object instance's PRREF_VER.

21.1.8 Get a PRREF_ID for an Object in a Work Area

Use this API to get the PRREF_ID and PRREF_VER for a Program, Load Set, Data Mart, or Business Area instance contained directly in a Work Area. You need these values to run Mapping APIs.

Name CDR_PUB_DF_MAPPING.GETPRREFIDFORSIMPLEOBJECT

Signature

```
PROCEDURE GETPRREFIDFORSIMPLEOBJECT (
  P_API_VERSION IN NUMBER,
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
  X_RETURN_STATUS OUT VARCHAR2,
  X_MSG_COUNT OUT NUMBER,
  X_MSG_DATA OUT VARCHAR2,
  PI_SIMPLEOBJ IN CDR_BASE_OBJ_TYPE,
  PO_PRREFID OUT CDR_PROGRAM_REFS.PRREF_ID%TYPE,
  PO_PRREFVER OUT CDR_PROGRAM_REFS.PRREF_VER%TYPE
);
```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

- **PI_SIMPLEOBJ** (Mandatory) This is a parameter of table type CDR_BASE_OBJ_TYPE that contains object attributes. Enter values to identify the Program, Load Set, Data Mart, or Business Area instance whose PRREFID you need in order to map its Table Descriptors.
The following attributes are required: COMPANY_ID, OBJ_ID, OBJ_VER.
- **PO_PRREFID** This output parameter returns the Program, Load Set, Data Mart, or Business Area instance's PRREF_ID.
- **PO_PRREFVER** This output parameter returns the Program, Load Set, Data Mart, or Business Area instance's PRREF_VER.

21.1.9 Get a PRREF_ID for a Program in a Report Set

Use this API to get the PRREF_ID and PRREF_VER for a Program instance contained in a Report Set. You need these values to run Mapping APIs.

Name CDR_PUB_DF_MAPPING.GETPRREFIDFORPGMUNDERRSE

Signature

```
PROCEDURE GETPRREFIDFORPGMUNDERRSE (
```



```

P_API_VERSION IN NUMBER,
P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
X_RETURN_STATUS OUT VARCHAR2,
X_MSG_COUNT OUT NUMBER,
X_MSG_DATA OUT VARCHAR2,
PI_SIMPLEOBJ IN CDR_BASE_OBJ_TYPE,
PI_RSIOBJ IN CDR_BASE_OBJ_TYPE,
PO_PRREFID OUT CDR_PROGRAM_REFS.PRREF_ID%TYPE,
PO_PRREFVER OUT CDR_PROGRAM_REFS.PRREF_VER%TYPE
);

```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

- **PI_SIMPLEOBJ** (Mandatory) This is a parameter of table type CDR_BASE_OBJ_TYPE that contains object attributes. Enter values to identify the Program instance whose PRREFID you need in order to map its Table Descriptors.

The following attributes are required: COMPANY_ID, OBJ_ID, OBJ_VER.

- **PI_RSIOBJ** (Mandatory) This is a parameter of table type CDR_BASE_OBJ_TYPE that contains object attributes. Enter values to identify the Report Set instance that contains the Program instance whose PRREFID you need.

The following attributes are required: COMPANY_ID, OBJ_ID AND OBJ_VER.

- **PO_PRREFID** Output Prref_Id
- **PO_PRREFVER** Output Prref Ver

This package includes APIs for submitting a job for printing, and for retrieving the BLOB and CLOB objects associated with Oracle LSH output.

22.1 Generate Outputs

This section contains the following topics:

- [Section 22.1.1, "Submit a Print Request"](#)
- [Section 22.1.2, "Get an Output's BLOB"](#)
- [Section 22.1.3, "Get an Output's CLOB"](#)

22.1.1 Submit a Print Request

Use this API to print a specified output. The API submits a request to the Oracle LSH printing concurrent program that prints the specified output.

Name CDR_PUB_PRINT_OUTPUT.SUBMITPRINTREQUEST

Signature

```
FUNCTION SUBMITPRINTREQUEST(
  P_API_VERSION IN NUMBER,
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
  X_RETURN_STATUS OUT VARCHAR2,
  X_MSG_COUNT OUT NUMBER,
  X_MSG_DATA OUT VARCHAR2,
  PI_NCOMPANYID IN CDR_NAMINGS.COMPANY_ID%TYPE,
  PI_NOUTPUTID IN CDR_NAMINGS.OBJ_ID%TYPE,
  PI_NOUTPUTOBJVER IN CDR_NAMING_VERSIONS.OBJ_VER%TYPE,
  PI_VPRINTERNAME IN FND_PRINTER.PRINTER_NAME%TYPE := NULL,
  PI_VCOVERSHEET IN VARCHAR2 := NULL
) RETURN NUMBER;
```

Return Type NUMBER

Description Concurrent Request Id

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

- **PI_NCOMPANYID** (Mandatory) Enter your company ID.

To get your company ID, use CDR_DF_PUB_DEF_CONSTANTS.Current_Company_ID.

- **PI_NOUTPUTID** (Mandatory) Enter the obj_id of the output you want to print.
- **PI_NOUTPUTOBJVER** (Mandatory) Enter the obj_ver of the output you want to print.
- **PI_VPRINTERNAME** (Mandatory) Enter the printer name.
- **PI_VCOVERSHEET** (Mandatory) Enter the text for the coversheet. You can enter text only up to 4000 bytes.

22.1.2 Get an Output's BLOB

Use this API to retrieve the BLOB associated with an output object.

Name CDR_PUB_PRINT_OUTPUT.GETOUTPUTBLOB

Signature

```
FUNCTION GETOUTPUTBLOB (  
  P_API_VERSION IN NUMBER,  
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,  
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,  
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,  
  PI_NCOMPANYID IN CDR_NAMINGS.COMPANY_ID%TYPE,  
  PI_NOUTPUTID IN CDR_NAMINGS.OBJ_ID%TYPE,  
  PI_NOUTPUTOBJVER IN CDR_NAMING_VERSIONS.OBJ_VER%TYPE  
) RETURN BLOB;
```

Return Type BLOB

Description BLOB

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

- **PI_NCOMPANYID** (Mandatory) Enter your company ID.
To get your company ID, use CDR_DF_PUB_DEF_CONSTANTS.Current_Company_ID.
- **PI_NOUTPUTID** (Mandatory) Enter the obj_ID of the output whose BLOB you want to retrieve.
- **PI_NOUTPUTOBJVER** (Mandatory) Enter the obj_ver of the output whose BLOB you want to retrieve.

22.1.3 Get an Output's CLOB

Use this API to retrieve the CLOB associated with a specified output object.

Name CDR_PUB_PRINT_OUTPUT.GETOUTPUTCLOB

Signature

```
FUNCTION GETOUTPUTCLOB (  
  P_API_VERSION IN NUMBER,  
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,  
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,  
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
```

```
PI_NCOMPANYID IN CDR_NAMINGS.COMPANY_ID%TYPE,  
PI_NOUTPUTID IN CDR_NAMINGS.OBJ_ID%TYPE,  
PI_NOUTPUTOBJVER IN CDR_NAMING_VERSIONS.OBJ_VER%TYPE  
) RETURN CLOB;
```

Return Type CLOB

Description Clob

Parameters This API has standard parameters (see "[Standard Parameters](#)" on page 5) and the following parameters:

- **PI_NCOMPANYID** (Mandatory) Enter your company ID.
To get your company ID, use CDR_DF_PUB_DEF_CONSTANTS.Current_Company_ID.
- **PI_NOUTPUTID** (Mandatory) Enter the obj_ID of the output whose CLOB you want to retrieve.
- **PI_NOUTPUTOBJVER** (Mandatory) Enter the obj_ver of the output whose CLOB you want to retrieve.

Version Labels

This is a public interface which hosts the Naming API for updating the Version label.

23.1 Modify Version Labels

This section contains one API for updating a version label.

23.1.1 Update a Version Label

Use this API to create or modify an object version label. If the same label exists for another version of the object, the API returns that version number. * @param p_api_version (Mandatory) Enter the current version of the API you are calling. The API compares the version numbers of incoming calls to its current version number and returns an error if they are incompatible.

@param p_api_version (Mandatory)

Name CDR_PUB_DF_NAMING.UPDATEVERSIONLABEL

Signature

```
PROCEDURE UPDATEVERSIONLABEL (
  P_API_VERSION IN NUMBER,
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
  X_RETURN_STATUS OUT VARCHAR2,
  X_MSG_COUNT OUT NUMBER,
  X_MSG_DATA OUT VARCHAR2,
  PIO_NAMING IN OUT CDR_NAMING_VERSION_OBJ_TYPE
);
```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

PIO_NAMING (Mandatory) This is a parameter of table type CDR_NAMING_VERSION_OBJ_TYPE that contains object attributes. Enter values to identify the object version that you want to label.

The following attributes are required: COMPANY_ID,OBJ_ID,OBJ_VER,VERSION_LABEL. For VERSION_LABEL enter the text of the label you want to apply to this object version.

This section contains the following topics:

- [Section 24.1, "Classify Objects"](#)
- [Section 24.2, "Classify Subtypes"](#)
- [Section 24.3, "Create and Modify Classification Hierarchy Values"](#)

24.1 Classify Objects

This is a public interface for assigning and removing object classifications.

This section contains the following topics:

- [Section 24.1.1, "Classify an Object"](#)
- [Section 24.1.2, "Declassify an Object"](#)

24.1.1 Classify an Object

Use this API to classify Objects

Name CDR_PUB_CLA_OBJ_CLASSIFICATION.ASSIGNOBJECTCLASSIFICATION

Signature

```
PROCEDURE ASSIGNOBJECTCLASSIFICATION(
  P_API_VERSION IN NUMBER,
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
  X_RETURN_STATUS OUT VARCHAR2,
  X_MSG_COUNT OUT NUMBER,
  X_MSG_DATA OUT VARCHAR2,
  PIO_SOURCECDRNAMING IN OUT CDR_NAMING_VERSION_OBJ_TYPE,
  PI_OCLASSIFICATIONS IN CDR_CLASSIFICATIONS_COLL
);
```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

- **PIO_SOURCECDRNAMING** (Mandatory) This is a parameter of table type CDR_NAMING_VERSION_OBJ_TYPE that contains object attributes. Enter values to identify the object that you want to classify.

The following attributes are required: COMPANY_ID,OBJ_ID,OBJ_VER,OBJECT_VERSION_NUMBER,NAMESPACE_OBJ_ID,NAMESPACE_OBJ_VER,OBJECT_SUBTYPE_ID.

- **PI_OCLASSIFICATIONS** This is a collection of CDR_CLA_OBJ_TYPEs, which have 5 attributes, including CLA_LEVEL_ID and CLASSIFICATION_ID.

If you want the OBJECT to inherit its classifications for a particular level from its parent, enter the classification level ID and, for the CLASSIFICATION_ID, enter 0 (zero).

If you want to explicitly assign one or more terms for a particular level, initialize a CDR_CLA_OBJ_TYPE for each term, entering the classification level ID and, for the CLASSIFICATION_ID, the term ID. The PAR_ attributes are relevant only to Planned Outputs.

If you are not classifying a Planned Output, do not enter any values for them.

If you are classifying a Planned Output and want to use a Parameter with a classification-driven list of values, use the PAR attributes to identify the Parameter you want to use.

24.1.2 Declassify an Object

Use this procedure to remove a single classification value from a defined Object.

Name CDR_PUB_CLA_OBJ_CLASSIFICATION.DECLASSIFY

Signature

```
PROCEDURE DECLASSIFY(
  P_API_VERSION IN      NUMBER,
  P_INIT_MSG_LIST IN    VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN          VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
  X_RETURN_STATUS OUT   VARCHAR2,
  X_MSG_COUNT OUT       NUMBER,
  X_MSG_DATA OUT        VARCHAR2,
  PI_NOBJECTID IN      CDR_NAMINGS.OBJ_ID%TYPE,
  PI_NCLALEVELID IN    PLS_INTEGER,
  PI_NCLASSIFICATIONID IN PLS_INTEGER
);
```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

- **PI_NOBJECTID** ((Mandatory) Enter the object ID of the object from which you want to remove classifications.)
- **PI_NCLALEVELID** (Mandatory) Enter the ID of the classification hierarchy level that contains the classification value, or term, that you want to remove.
- **PI_NCLASSIFICATIONID** (Mandatory) Enter the ID of the classification value, or term, that you want to remove.

24.2 Classify Subtypes

This is a public interface for all Classification functions related to Subtypes.

This section contains the following topics:

- [Section 24.2.1, "Get a Subtype Classification Level"](#)
- [Section 24.2.2, "Get an Object Classification Value"](#)
- [Section 24.2.3, "Get a Parent Term"](#)

24.2.1 Get a Subtype Classification Level

Use this API to retrieve all the classification hierarchy levels assigned to an Object Subtype. The function returns a collection of CDR_HIER_LEVEL_VAL_OBJ_TYPE.

Name CDR_PUB_CLA_SUBTYPES.GETCLASSIFICATIONLEVELS

Signature

```
FUNCTION GETCLASSIFICATIONLEVELS (
  P_API_VERSION IN NUMBER,
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
  PIOBJECTSUBTYPEID IN CDR_OBJECT_SUBTYPES_TL.OBJECT_SUBTYPE_ID%TYPE
) RETURN CDR_HIER_LEVEL_VALUES_COLL;
```

Return

Type CDR_HIER_LEVEL_VALUES_COLL

Description classification levels.

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameter:

PIOBJECTSUBTYPEID Enter the ID of the Object Subtype whose assigned classification levels you want to retrieve.

24.2.2 Get an Object Classification Value

Use this API to get the classifications assigned to the given object ID and version.

Name CDR_PUB_CLA_SUBTYPES.GETOBJECTCLAVALUES

Signature

```
FUNCTION GETOBJECTCLAVALUES (
  P_API_VERSION IN NUMBER,
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
  POBJECTID IN CDR_OBJ_CLA_MAPPINGS.OBJ_ID%TYPE,
  PIOBJECTSUBTYPEID IN CDR_OBJECT_SUBTYPES_TL.OBJECT_SUBTYPE_ID%TYPE
) RETURN CDR_HIER_LEVEL_VALUES_COLL;
```

Return

Type CDR_HIER_LEVEL_VALUES_COLL

Description Classification values

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

- **POBJECTID** (Mandatory) Enter the Object Id.

- **PIOBJECTSUBTYPEID** (Mandatory) Enter the Object Subtype Id.

24.2.3 Get a Parent Term

Use this API to retrieve some or all of the terms on a particular level that are children of a particular parent term. The function returns a collection of CDR_HIER_LEVEL_VAL_OBJ_TYPES.

Name CDR_PUB_CLA_SUBTYPES.GETCLAHIERVALUES

Signature

```
FUNCTION GETCLAHIERVALUES(  
  P_API_VERSION IN NUMBER,  
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,  
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,  
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,  
  PLEVELIDS IN CDR_OPA_ID_COLL,  
  PTERMS IN CDR_OPA_STRING_COLL,  
  PDOMAINID IN PLS_INTEGER,  
  PCLALEVELID IN CDR_SUBTYPE_CLA_LEVELS.CLA_LEVEL_ID%TYPE  
) RETURN CDR_HIER_LEVEL_VALUES_COLL;
```

Return

Type CDR_HIER_LEVEL_VALUES_COLL

Description Classification hierarchy values

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

- **PLEVELIDS** (Mandatory) This is a collection of CDR_OPA_ID_OBJ_TYPES. For each hierarchy level from the top level to the level from which you want to retrieve terms (but not lower), initialize a CDR_OPA_ID_OBJ_TYPE and then extend the collection.

The following attribute is required: CDR_OPA_ID.

- **PTERMS** (Mandatory) This is a collection of CDR_OPA_STRING_OBJ_TYPES. For each hierarchy level from the top level to the one from which you want to retrieve terms (but not lower), initialize a CDR_OPA_ID_OBJ_TYPE and then extend the collection. For the required attribute, CDR_OPA_STRING, enter the term whose related terms you want to retrieve, in order starting with the top level.
- **PDOMAINID** Enter the ID of the LSH Instance Domain. Use the following query to get this ID: select * from TMS.TMS_DEF_DOMAINS where name = 'CDR_USER_HIER'
- **PCLALEVELID** Enter the ID of the classification hierarchy level that contains the terms you are searching for.

24.3 Create and Modify Classification Hierarchy Values

This is a public interface for classification hierarchy value-related operations.

This section contains the following topics:

- [Section 24.3.1, "Insert a Classification Value"](#)
- [Section 24.3.2, "Update a Classification Value"](#)

- [Section 24.3.3, "Delete a Classification Value"](#)

24.3.1 Insert a Classification Value

Use this API to insert values, or terms, into a classification hierarchy level, related to a term in the next higher level. The function returns 0 if the transaction failed and 1 if it succeeded.

Name CDR_PUB_CLA_HIERARCHY_VALS.INSERTVALUES

Signature

```
FUNCTION INSERTVALUES(
  P_API_VERSION IN NUMBER,
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
  PPARENTCONTENTID IN TMS.TMS_DICT_CONTENTS.DICT_CONTENT_ID%TYPE,
  PLEVELID IN TMS.TMS_DEF_LEVELS.DEF_LEVEL_ID%TYPE,
  PVALUES IN OUT CDR_HIER_VAL_COLL
) RETURN PLS_INTEGER;
```

Return

Type PLS_INTEGER

Description 0 is returned if the transaction fails

1 is returned if the transaction succeeds.

Parameters This API has standard parameters (see "[Standard Parameters](#)" on page 5) and the following parameters:

- **PPARENTCONTENTID** Enter the ID of a term that serves as a parent to the terms you are inserting.
- **PLEVELID** Enter the ID of the classification hierarchy level into which you want to insert the terms.
- **PVALUES** (Mandatory) This is a collection of CDR_HIER_VAL_TYPES. For each classification value (term) that you want to add as a child to the term you specified, initialize a CDR_HIER_VAL_TYPE and then extend the collection.

The following attributes are required: CONTENT_ID,TERM,ERROR_MSG,APPROVED_FLAG.

24.3.2 Update a Classification Value

Use this API to modify classification hierarchy values. It returns 1 for transaction success and 0 for failure. It also returns a PVALUES collection that includes error messages for any terms that could not be updated.

Name CDR_PUB_CLA_HIERARCHY_VALS.UPDATEVALUES

Signature

```
FUNCTION UPDATEVALUES(
  P_API_VERSION IN NUMBER,
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
```

```
PVALUES IN OUT CDR_HIER_VAL_COLL  
) RETURN PLS_INTEGER;
```

Return

Type PLS_INTEGER

Description 0 is returned if the transaction fails (Values will contain the errors).

1 is returned if the transaction succeeds.

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameter:

PVALUES (Mandatory) This is a collection of CDR_HIER_VAL_TYPES. For each classification value (term) that you want to modify, initialize a CDR_HIER_VAL_TYPE and then extend the collection.

The following attributes are required: CONTENT_ID,TERM,APPROVED_FLAG.

You can modify the term itself or its Approved flag value.

24.3.3 Delete a Classification Value

Use this API to delete classification values (terms). The API does not delete terms if they have been assigned as the default value for an object subtype or if they have been assigned to any object. If neither case is true, then the API deletes the term and any related terms it may have lower in the classification hierarchy.

Name CDR_PUB_CLA_HIERARCHY_VALS.DELETEVALUES

Signature

```
PROCEDURE DELETEVALUES(  
  P_API_VERSION IN NUMBER,  
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,  
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,  
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,  
  X_RETURN_STATUS OUT VARCHAR2,  
  X_MSG_COUNT OUT NUMBER,  
  X_MSG_DATA OUT VARCHAR2,  
  PVALUES IN OUT CDR_HIER_VAL_COLL  
) ;
```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameter:

PVALUES (Mandatory) This is a collection of CDR_HIER_VAL_TYPES. For each classification value (term) that you want to delete, initialize a CDR_HIER_VAL_TYPE and then extend the collection.

The following attribute is required: CONTENT_ID.

This section contains the following topics:

- [Section 25.1, "Create and Execute Output Jobs"](#)
- [Section 25.2, "Retrieve Information about Ongoing Jobs"](#)
- [Section 25.3, "Set Execution Statuses"](#)
- [Section 25.4, "Submit Messages"](#)
- [Section 25.5, "Create Submission Records"](#)

25.1 Create and Execute Output Jobs

This is a public interface that hosts the API for uploading output CLOBs into Oracle LSH. These output CLOBs are generated by Oracle LSH executables outside the Oracle LSH database. For example, a PDF file output from a SAS print program; or a SAS CPORT file output from a Data Mart. This public interface also includes APIs that adapters may need to call during the execution of a Load Set, Data Mart, or Program.

This section contains the following topics:

- [Section 25.1.1, "Create a Binary Output"](#)
- [Section 25.1.2, "Upload an Output BLOB"](#)
- [Section 25.1.3, "Upload an Output Clob"](#)
- [Section 25.1.4, "Upload a LOB to a Temporary Table"](#)
- [Section 25.1.5, "Download a Job Output BLOB"](#)
- [Section 25.1.6, "Queue a Job"](#)
- [Section 25.1.7, "Wait for a Job to Complete"](#)
- [Section 25.1.8, "Generate an XML Payload"](#)

25.1.1 Create a Binary Output

Use this API to create a binary output object.

Name CDR_PUB_EXE_EXTERNAL.CREATEBINARYOUTPUT

Signature

```
PROCEDURE CREATEBINARYOUTPUT(
  P_API_VERSION IN NUMBER,
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
```

```
P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
X_RETURN_STATUS OUT VARCHAR2,
X_MSG_COUNT OUT NUMBER,
X_MSG_DATA OUT VARCHAR2,
PI_NCOMPANYID IN NUMBER,
PI_VFILENAME IN VARCHAR2,
PI_VDATA IN RAW := NULL
);
```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

- **PI_NCOMPANYID** (Mandatory) Enter Company Id.
- **PI_VFILENAME** (Mandatory) Enter the File Name.
- **PI_VDATA** (Optional) Enter the RAW input to stream up the output.

25.1.2 Upload an Output BLOB

Use this API to upload an output BLOB generated by an external processing engine into Oracle LSH.

Name CDR_PUB_EXE_EXTERNAL.UPLOADBLOBOUTPUT

Signature

```
PROCEDURE UPLOADBLOBOUTPUT(
  P_API_VERSION IN NUMBER,
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
  X_RETURN_STATUS OUT VARCHAR2,
  X_MSG_COUNT OUT NUMBER,
  X_MSG_DATA OUT VARCHAR2,
  PI_NJOBID IN VARCHAR2,
  PI_VFILENAME IN VARCHAR2,
  PI_NPRREFID IN VARCHAR2,
  PIO_BLOBSTREAM IN OUT BLOB
);
```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

- **PI_NJOBID** (Mandatory) Enter the JOB_ID of the job that generated the output.
- **PI_VFILENAME** (Mandatory) Enter the filename associated with the Planned Output.
- **PI_NPRREFID** (Mandatory) Enter the PRREF_ID of the Oracle LSH executable. This attribute is available from the cdr_jobs_v view.
- **PIO_BLOBSTREAM** (Mandatory) This is a parameter of type BLOB. Enter BLOB to be uploaded. @rep:scope public.

25.1.3 Upload an Output Clob

Use this API to upload an output CLOB into Oracle LSH.

Name CDR_PUB_EXE_EXTERNAL.UPLOADCLOBOUTPUT

Signature

```

PROCEDURE UPLOADCLOBOUTPUT (
  P_API_VERSION IN NUMBER,
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
  X_RETURN_STATUS OUT VARCHAR2,
  X_MSG_COUNT OUT NUMBER,
  X_MSG_DATA OUT VARCHAR2,
  PI_NJOBID IN VARCHAR2,
  PI_VFILENAME IN VARCHAR2,
  PI_NPRREFID IN VARCHAR2,
  PIO_CLOBSTREAM IN OUT CLOB
);

```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

- **PI_NJOBID** (Mandatory) Enter the JOB_ID of the job that generated the output.
- **PI_VFILENAME** (Mandatory) Enter the filename associated with the Planned Output.
- **PI_NPRREFID** (Mandatory) Enter the PRREFID of the Oracle LSH executable. This attribute is available from the CDR_JOBS table.
- **PIO_CLOBSTREAM** (Mandatory) Enter the variable name for the CLOB in the database.

25.1.4 Upload a LOB to a Temporary Table

Use this API to upload one or more BLOBs or CLOBs (binary or character large objects) to a temporary table.

Name CDR_PUB_EXE_EXTERNAL.CREATETEMPLOBS

Signature

```

PROCEDURE CREATETEMPLOBS (
  P_API_VERSION IN NUMBER,
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
  X_RETURN_STATUS OUT VARCHAR2,
  X_MSG_COUNT OUT NUMBER,
  X_MSG_DATA OUT VARCHAR2,
  PI_NJOBID IN NUMBER,
  PI_BZIP IN BOOLEAN,
  PI_BLOBNAMES IN CDR_VC_LIST_COLL,
  PI_BLOBENTRIES IN CDR_BLOB_LIST_COLL,
  PI_CLOBNAMES IN CDR_VC_LIST_COLL,
  PI_CLOBENTRIES IN CDR_CLOB_LIST_COLL
);

```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

- **PI_NJOBID** (Mandatory) Enter the Job_ID. You can get the Job ID by running CDR_PUB_EXE_RUNTIME.GETCURRENTLYEXECUTINGJOBID.
- **PI_BZIP** Is the input lob in zip format? Enter TRUE or FALSE.

- **PI_BLOBNAMES** This parameter is of type `cdr_vc_list_coll` which is a collection of `varchar2(2000)`. The varchar contains the BLOB file name.
- **PI_BLOBENTRIES** This parameter is a collection of `cdr_blob_list_coll` which is a collection of BLOB types. This parameter contains the actual file BLOBs. This is always a collection so even if you are uploading a single CLOB, initialize the collection with that BLOB and pass it here.
- **PI_CLOBNAMES** This parameter is of type `cdr_vc_list_coll` which is a collection of `varchar2(2000)`. The varchar contains the CLOB file name.
- **PI_CLOBENTRIES** This parameter is a collection of `cdr_clob_list_coll` which is a collection of CLOB type. This contains the actual file CLOBs. This is always a collection so even if you are uploading a single CLOB, initialize the collection with that CLOB and pass it here.

25.1.5 Download a Job Output BLOB

Use this API to download a job output BLOB.

Name CDR_PUB_EXE_EXTERNAL.DOWNLOADTEMPBLOB

Signature

```
FUNCTION DOWNLOADTEMPBLOB(  
  P_API_VERSION IN NUMBER,  
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,  
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,  
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,  
  PI_NOBJID IN NUMBER,  
  PO_VFILENAME OUT VARCHAR2  
) RETURN BLOB;
```

Return Type BLOB

Description returns the output lob file as a BLOB.

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

- **PI_NOBJID** (Mandatory) Enter the `tmp_blob_id` of the job output LOB. You can use the following query to get this ID:

```
SELECT tmp_blob_id FROM cdr_temp_blobs_v WHERE job_id = pi_nJobId;
```
- **PO_VFILENAME** (Mandatory) This Out parameter contains the file name of the downloaded lob file.

25.1.6 Queue a Job

Use this API to queue the job into a service location for execution.

Name CDR_PUB_EXE_EXTERNAL.SENDJOB

Signature

```
PROCEDURE SENDJOB(  
  P_API_VERSION IN NUMBER,  
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,  
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,  
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
```

```

X_RETURN_STATUS OUT    VARCHAR2,
X_MSG_COUNT OUT      NUMBER,
X_MSG_DATA OUT      VARCHAR2,
PI_VRECEIVER IN      VARCHAR2,
PI_NJOBID IN        NUMBER,
PI_VPAYLOAD IN      VARCHAR2
);

```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

- **PI_VRECEIVER** (Mandatory) Enter the name of the Service Location.
- **PI_NJOBID** (Mandatory) Enter the Job_ID. You can get the Job ID by running CDR_PUB_EXE_RUNTIME.GETCURRENTLYEXECUTINGJOBID.
- **PI_VPAYLOAD** (Mandatory) Enter the actual XML Payload generated by the CDR_PUB_EXE_EXTERNAL.GenerateXMLPayload API.

25.1.7 Wait for a Job to Complete

Use this API to enable synchronous execution so that program control waits for a Job to complete before proceeding with the rest of the logic.

Name CDR_PUB_EXE_EXTERNAL.WAITFORFINALSTATUS

Signature

```

PROCEDURE WAITFORFINALSTATUS (
  P_API_VERSION IN      NUMBER,
  P_INIT_MSG_LIST IN     VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN     VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN  NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
  X_RETURN_STATUS OUT    VARCHAR2,
  X_MSG_COUNT OUT      NUMBER,
  X_MSG_DATA OUT      VARCHAR2,
  PI_NJOBID IN        NUMBER,
  PI_NTIMEOUT IN      NUMBER,
  PI_NSERVICEINSTANCEID IN  NUMBER
);

```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

- **PI_NJOBID** (Mandatory) Enter the Job ID of the Job in process. The Job_ID is returned by the API CDR_PUB_EXE_SUBMISSION.CREATE SUBMISSION and in the UI.
- **PI_NTIMEOUT** (Mandatory) Enter in seconds, the job completion period before the API times out.
- **PI_NSERVICEINSTANCEID** (Mandatory) Enter the service instance that is processing the job. Get the ID from the cdr_jobs_v view using the Job_Id.

25.1.8 Generate an XML Payload

Use this API to generate the required XML payload for a job execution.

Name CDR_PUB_EXE_EXTERNAL.GENERATEXMLPAYLOAD

Signature

```
FUNCTION GENERATEXMLPAYLOAD(  
  P_API_VERSION IN NUMBER,  
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,  
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,  
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,  
  PI_NJOBID IN NUMBER,  
  PI_VJOBTYPE IN VARCHAR2,  
  PI_NDOWNLOADCONFIGID IN NUMBER,  
  PI_VPROGRAM IN VARCHAR2,  
  PI_VWORKDIRECTORY IN VARCHAR2,  
  PI_VRUNSCRIPT IN VARCHAR2,  
  PI_VOUTPUTPATH IN VARCHAR2,  
  PI_VPRIORITY IN VARCHAR2,  
  PI_VSCHEMA IN VARCHAR2,  
  PI_VUSERID IN VARCHAR2,  
  PI_VSUBDIRECTORIES IN CDR_VC_LIST_COLL,  
  PI_NSURROGATEJOBID IN CDR_JOBS_V.JOB_ID%TYPE := NULL,  
  PI_VTECHTYPE IN VARCHAR2 := NULL,  
  PI_NSURROGATEPRREFID IN CDR_JOBS_V.PRREF_ID%TYPE := NULL  
) RETURN CLOB;
```

Return Type CLOB

Description Returns the generated XML as a CLOB.

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

- **PI_NJOBID** (Mandatory) Enter the Job_ID.
- **PI_VJOBTYPE** (Mandatory) Enter the Job Type—either *tmp* for an internal job or *exe* for a user-executed job
- **PI_NDOWNLOADCONFIGID** (Optional) If the entire job configuration is stored in *cdr_temp_blobs* (against the Job_ID), you can enter the ID of the BLOB for the job.
Query *cdr_temp_blobs_v* to get the value. If you do not enter a BLOB ID, enter 0.
- **PI_VPROGRAM** (Mandatory) Enter the command to be executed on the server.
- **PI_VWORKDIRECTORY** (Mandatory) Enter the full path of the root folder in the DP server Home under which the job folder gets created.
- **PI_VRUNSCRIPT** (Mandatory) Enter the name of the main script to be executed for the job.
- **PI_VOUTPUTPATH** (Mandatory) Enter the path where the output will be generated, relative to the work directory/ folder.
- **PI_VPRIORITY** (Mandatory) Enter the job priority. The possible values are the lookup codes in the lookup type 'CDR_JOB_PRIORITIES'.
- **PI_VSCHEMA** (Mandatory) Enter the ID of the ZZ_Schema allocated for the current job. You can query CDR_JOBS_V to get this ID.
- **PI_VUSERID** (Mandatory) Enter the UserId that is executing the job. Use the API CDR_PUB_DEF_FACTORY_SUPPORT.GETUSERID to get this ID.
- **PI_VSUBDIRECTORIES** This is a collection of type CDR_VC_LIST_COLL. Enter the names of subdirectories that should be created under the Job directory in the DP Server.

- **PI_NSURROGATEJOBID** SurrogateJobId. (Optional) Enter the job ID under which the created outputs will be uploaded if it is different from the current job; for example, a master job.
- **PI_VTECHTYPE** (Mandatory) Enter the TechType name being used for the job.
- **PI_NSURROGATEPRREFID** SurrogatePrrefId(Optional) Enter the ID of the master job for this job, if any.

25.2 Retrieve Information about Ongoing Jobs

This is a public interface to retrieve information about an ongoing job.

This section contains the following topics:

- [Section 25.2.1, "Get an Ongoing Job ID"](#)
- [Section 25.2.2, "Get Currently Executing Parameters"](#)
- [Section 25.2.3, "Get Information About a Job"](#)
- [Section 25.2.4, "Get Job Information \(Overloaded\)"](#)

25.2.1 Get an Ongoing Job ID

Use this API to retrieve the job ID of the job that is currently running.

Name CDR_PUB_EXE_RUNTIME.GETCURRENTLYEXECUTINGJOBID

Signature

```
FUNCTION GETCURRENTLYEXECUTINGJOBID(
  P_API_VERSION IN NUMBER,
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL
) RETURN CDR_JOBS.JOB_ID%TYPE;
```

Return Type CDR_JOBS.JOB_ID%TYPE

Description the job ID of the job which is executing in the current session.

Parameters This API has standard parameters. See ["Standard Parameters"](#) on page 5) for details.

25.2.2 Get Currently Executing Parameters

Use this API to retrieve the parameters in use by the job that is currently running.

Name CDR_PUB_EXE_RUNTIME.GETCURRENTLYEXECUTINGPARAMS

Signature

```
FUNCTION GETCURRENTLYEXECUTINGPARAMS(
  P_API_VERSION IN NUMBER,
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL
) RETURN CDR_PARAMETER_VALUES_COLL;
```

Return Type CDR_PARAMETER_VALUES_COLL

Description a collection of parameter/values for job which is executing in the current session.

Parameters This API has standard parameters. See ["Standard Parameters"](#) on page 5) for details.

25.2.3 Get Information About a Job

Use this API to retrieve information about a Job by passing its JOB_ID.

Name CDR_PUB_EXE_RUNTIME.GETJOBINFO

Signature

```
PROCEDURE GETJOBINFO(  
  P_API_VERSION IN NUMBER,  
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,  
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,  
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,  
  X_RETURN_STATUS OUT VARCHAR2,  
  X_MSG_COUNT OUT NUMBER,  
  X_MSG_DATA OUT VARCHAR2,  
  PI_NJOBID IN CDR_JOBS.JOB_ID%TYPE,  
  PO_RSUBMISSION_V OUT CDR_SUBMISSIONS_V%ROWTYPE,  
  PO_RJOB_V OUT CDR_JOBS_V%ROWTYPE  
);
```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

- **PI_NJOBID** (Mandatory) Enter the JOB_ID of the job you want information about. You can get the Job ID by running CDR_PUB_EXE_RUNTIME. Get Currently Executing Job ID.
- **PO_RSUBMISSION_V** This is an output parameter. The API returns the row corresponding to the SUBMISSION_ID associated with the JOB_ID value in CDR_JOBS from the CDR_SUBMISSIONS table.
- **PO_RJOB_V** This is an output parameter. The API returns the row corresponding to the JOB_ID from the CDR_JOBS table.

25.2.4 Get Job Information (Overloaded)

Use this API to retrieve information about a Job by passing its JOB_ID.

Name CDR_PUB_EXE_RUNTIME.GETJOBINFO

Signature

```
PROCEDURE GETJOBINFO(  
  P_API_VERSION IN NUMBER,  
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,  
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,  
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,  
  X_RETURN_STATUS OUT VARCHAR2,  
  X_MSG_COUNT OUT NUMBER,  
  X_MSG_DATA OUT VARCHAR2,  
  PI_NJOBID IN CDR_JOBS.JOB_ID%TYPE,  
  PO_RSUBMISSION OUT CDR_SUBMISSIONS%ROWTYPE,
```

```

PO_RJOB OUT CDR_JOBS%ROWTYPE,
PO_BISTOPLEVELJOB OUT BOOLEAN,
PO_BISMASTERJOB OUT BOOLEAN
);

```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

- **PI_NJOBID** (Mandatory) Enter the JOB ID.
- **PO_RSUBMISSION** This is an output parameter. The API returns the row corresponding to the SUBMISSION_ID (associated with the JOB_ID value in CDR_JOBS) from the CDR_SUBMISSIONS table.
- **PO_RJOB** This is an output parameter. The API returns the row corresponding to the JOB_ID from the CDR_JOBS table.
- **PO_BISTOPLEVELJOB** This is an output parameter. The API returns "T" if the Job is a Top Level Job.
- **PO_BISMASTERJOB** This is an output parameter. The API returns "T" if the job is a Master job.

25.3 Set Execution Statuses

This package contains APIs for setting and retrieving the execution status of Oracle LSH Programs. It also contains APIs for setting output parameters from external tools.

This section contains the following topics:

- [Section 25.3.1, "Set a User-specific Completion Status"](#)
- [Section 25.3.2, "Set a Customized Output Title"](#)
- [Section 25.3.3, "Set a Customized Output Subtitle"](#)
- [Section 25.3.4, "Set an Output Parameter"](#)
- [Section 25.3.5, "Get a Completion Status"](#)

25.3.1 Set a User-specific Completion Status

Use this API to set the completion status to a user specified value. Valid status values are: 1 for OK; 2 for OK With Warnings; 3 for Failure.

Name CDR_PUB_EXE_USER_UTILS.SETCOMPLETIONSTATUS

Signature

```

PROCEDURE SETCOMPLETIONSTATUS(
  P_API_VERSION IN NUMBER,
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
  X_RETURN_STATUS OUT VARCHAR2,
  X_MSG_COUNT OUT NUMBER,
  X_MSG_DATA OUT VARCHAR2,
  PI_NCOMPLETIONSTATUS IN NUMBER := 1
);

```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameter:

PI_NCOMPLETIONSTATUS (Mandatory) Enter the completion status value. Valid values are 1, 2, or 3.

25.3.2 Set a Customized Output Title

Use this API to set a title for individual RSE outputs.

Name CDR_PUB_EXE_USER_UTILS.SETCUSTOMOUTPUTTITLE

Signature

```
PROCEDURE SETCUSTOMOUTPUTTITLE(  
  P_API_VERSION IN NUMBER,  
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,  
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,  
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,  
  X_RETURN_STATUS OUT VARCHAR2,  
  X_MSG_COUNT OUT NUMBER,  
  X_MSG_DATA OUT VARCHAR2,  
  PI_VFILEREFS IN CDR_PLANNED_OUTPUTS.FILEREFS%TYPE,  
  PI_VVALUE IN VARCHAR2  
);
```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

- **PI_VFILEREFS** (Mandatory) Enter the file reference name of the Planned Output to which you want to assign the title.
- **PI_VVALUE** (Mandatory) Enter the title text.

25.3.3 Set a Customized Output Subtitle

Use this API to set a subtitle for individual RSE outputs.

Name CDR_PUB_EXE_USER_UTILS.SETCUSTOMOUTPUTSUBTITLE

Signature

```
PROCEDURE SETCUSTOMOUTPUTSUBTITLE(  
  P_API_VERSION IN NUMBER,  
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,  
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,  
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,  
  X_RETURN_STATUS OUT VARCHAR2,  
  X_MSG_COUNT OUT NUMBER,  
  X_MSG_DATA OUT VARCHAR2,  
  PI_VFILEREFS IN CDR_PLANNED_OUTPUTS.FILEREFS%TYPE,  
  PI_VVALUE IN VARCHAR2  
);
```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

- **PI_VFILEREFS** (Mandatory) Enter the file reference name of the Planned Output to which you want to assign the subtitle.
- **PI_VVALUE** (Mandatory) Enter the subtitle text.

25.3.4 Set an Output Parameter

Use this API to send custom parameters and their values to Oracle LSH from external sources such as SAS. Parameter names and their values passed to this API get added to the cdr_temp_output_params table.

Name CDR_PUB_EXE_USER_UTILS.SETOUTPUTPARAMS

Signature

```
PROCEDURE SETOUTPUTPARAMS(
  P_API_VERSION IN NUMBER,
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
  X_RETURN_STATUS OUT VARCHAR2,
  X_MSG_COUNT OUT NUMBER,
  X_MSG_DATA OUT VARCHAR2,
  PI_VPARAMNAME IN CDR_TEMP_OUTPUT_PARAMS.PARAMETER_NAME%TYPE,
  PI_VPARAMVALUE IN CDR_TEMP_OUTPUT_PARAMS.PARAMETER_VALUE%TYPE
);
```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

- **PI_VPARAMNAME** (Mandatory) Enter the parameter name.
- **PI_VPARAMVALUE** (Mandatory) Enter a value for the parameter.

25.3.5 Get a Completion Status

Use this API to retrieve a completion status value. The completion status value can only be one of the following: 1 for OK; 2 for OK With Warnings; 3 for Failure.

Name CDR_PUB_EXE_USER_UTILS.GETCOMPLETIONSTATUS

Signature

```
FUNCTION GETCOMPLETIONSTATUS(
  P_API_VERSION IN NUMBER,
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL
) RETURN NUMBER;
```

Return Type NUMBER

Description Completion Status. The values are 1: OK 2: OK_WITH_WARNINGS 3: FAILURE

Parameters This API has standard parameters. See ["Standard Parameters"](#) on page 5) for details.

25.4 Submit Messages

This package contains one API related to the submission of messages.

25.4.1 Submit a Message

Use this API to add a submission request to the message queue.

Name CDR_PUB_EXE_MSG_API.SUBMIT_MESSAGE

Signature

```
PROCEDURE SUBMIT_MESSAGE(  
    P_API_VERSION IN NUMBER,  
    P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,  
    P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,  
    P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,  
    X_RETURN_STATUS OUT VARCHAR2,  
    X_MSG_COUNT OUT NUMBER,  
    X_MSG_DATA OUT VARCHAR2,  
    PI_MSG IN VARCHAR2 := NULL  
);
```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameter:

PI_MSG (Mandatory) Enter in XML format, the message that you want to add to the message queue.

25.5 Create Submission Records

This package contains procedures to log messages during a job run and to create a submission record.

This section contains the following topics:

- [Section 25.5.1, "Start a Job"](#)
- [Section 25.5.2, "Create a Submission"](#)
- [Section 25.5.3, "Create a Submission from a Job"](#)
- [Section 25.5.4, "Add a Job Log"](#)

25.5.1 Start a Job

Use this API to start the execution of a job.

Name CDR_PUB_EXE_SUBMISSION.STARTJOB

Signature

```
PROCEDURE STARTJOB(  
    P_API_VERSION IN NUMBER,  
    P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,  
    P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,  
    P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,  
    X_RETURN_STATUS OUT VARCHAR2,  
    X_MSG_COUNT OUT NUMBER,  
    X_MSG_DATA OUT VARCHAR2,  
    PI_VEXECMODE IN VARCHAR2 := 'NONE',  
    PI_NJOBID IN CDR_JOBS_V.JOB_ID%TYPE,  
    PI_NSTREAMID IN NUMBER := NULL  
);
```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

- **PI_VEXECMODE** (Mandatory) Enter the mode of execution. There are four possible values: SYNCHRONOUS (start the job and wait for completion), QUEUE (enqueue the job on the LSH queues), DIRECT (directly submit the job to OWB but do not wait), STREAM (The stream ID has to be set if this mode is used).
- **PI_NJOBID** (Mandatory) Enter the Job_ID of the job to be executed.
- **PI_NSTREAMID** Enter the OWB Stream ID. The default value is Null. This parameter is required only if mode=STREAM.

25.5.2 Create a Submission

Use this API to create a submission before starting the job.

Name CDR_PUB_EXE_SUBMISSION.CREATESUBMISSION

Signature

```
FUNCTION CREATSUBMISSION(
  P_API_VERSION IN NUMBER,
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
  PIO_OSUBMISSION IN OUT CDR_SUBMISSION_OBJ_TYPE,
  PIO_COSUBDETAILS IN OUT CDR_SUBMISSION_DETAILS_COLL,
  PI_JOBCONTEXTRC IN CDR_JOBS_V.JOB_CONTEXT_RC%TYPE,
  PI_EXECMODE IN VARCHAR2,
  PI_REFRESHES IN CDR_JOBS_V.REFRESH_TS%TYPE
) RETURN CDR_JOBS_V.JOB_ID%TYPE;
```

Return CDR_JOBS_V.JOB_ID%TYPE

Description Returns the Job_ID. This is a number and the type is CDR_JOBS_V.JOB_ID%TYPE

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

- **PIO_OSUBMISSION** (Mandatory) This parameter is of type CDR_SUBMISSION_OBJ_TYPE.

Enter values for the following attributes: COMPANY_ID, EXECUTION_SETUP_OBJ_ID, EXECUTION_SETUP_OBJ_VER, WA_OBJ_ID, MASTER_PRRF_ID, MASTER_PRRF_VER, ACTIVE_FLAG_RC, SUBMISSION_TYPE_RC.

You can query MASTER_PRRF_ID and MASTER_PRRF_VER from CDR_PROGRAM_REFS_V with the Object ID and version of the object to be executed as the Prrf Obj Id and Prrf Obj ver.
- **PIO_COSUBDETAILS** (Mandatory) This parameter is part of a collection of runtime parameters. It is of type CDR_SUBMISSION_DETAILS_COLL. Enter values for the runtime parameters that you want to include in the job submission.

The required attributes are: COMPANY_ID, SUBMISSION_ID, PRRF_ID, PRRF_VER, PARAMETER_REF_OBJ_ID, PARAMETER_REF_OBJ_VER, PARAMETER_VALUE.
- **PI_JOBCONTEXTRC** (Mandatory) Enter the Job Context.

The possible values are the lookup_codes inside the lookup_type CDR_JOB_CONTEXTS: \$JOBCONTEXT\$BACKCHAIN, \$JOBCONTEXT\$COMPONENT, \$JOBCONTEXT\$SCHEDULED; \$JOBCONTEXT\$SUBMISSION.

- **PI_EXECMODE** (Mandatory) Enter a value for the execution mode. There are 3 possible values: SYNCHRONOUS (start the job and wait for completion), QUEUE (enqueue the job on the LSH queues), DIRECT (directly submit the job to OWB but would not wait).
- **PI_REFRESHTS** (Mandatory) Enter the Refresh timestamp you want to have associated with the job. It is normally 'sysdate,' but if you want to explicitly set a timestamp you can enter it here; for example, for a recovery job.

25.5.3 Create a Submission from a Job

This API creates a Submission from the initial Job.

Name CDR_PUB_EXE_SUBMISSION.CREATESUBMISSION

Signature

```
PROCEDURE CREATSUBMISSION(
  P_API_VERSION IN NUMBER,
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
  X_RETURN_STATUS OUT VARCHAR2,
  X_MSG_COUNT OUT NUMBER,
  X_MSG_DATA OUT VARCHAR2,
  PIO_OSUBMISSION IN OUT CDR_SUBMISSION_OBJ_TYPE,
  PIO_COPROGRAMSUBDETAILS IN OUT CDR_SUBMISSION_DETAILS_COLL,
  PIO_COSYSTEMSUBDETAILS IN OUT CDR_SUBMISSION_DETAILS_COLL,
  PI_NOACCOUNTID IN CDR_SUBMISSIONS.OA_ACCOUNT_ID%TYPE := NULL,
  PI_COSNAPSHOT IN CDR_SNAPSHOT_TABLE_COLL := CDR_SNAPSHOT_TABLE_COLL()
);
```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

- **PIO_OSUBMISSION** Object containing Submission attributes like submission_type_rc, execution_setup_id, master_prref_id etc.
- **PIO_COPROGRAMSUBDETAILS** This is part of submission details which is a collection of Run time parameters.
- **PIO_COSYSTEMSUBDETAILS** This is part of submission details which is a collection of system parameters.
- **PI_NOACCOUNTID** Enter the OA account ID of the user making the submission.
- **PI_COSNAPSHOT** This is a collection of snapshots attributes like Tables Obj_id, Obj_Ver, source_master_job_Id etc.

25.5.4 Add a Job Log

Use this API to populate the cdr_job_log with the log entry for a given job.

Name CDR_PUB_EXE_SUBMISSION.ADDJOBLOGENTRY

Signature

```
PROCEDURE ADDJOBLOGENTRY(  
    P_API_VERSION IN NUMBER,  
    P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,  
    P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,  
    P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,  
    X_RETURN_STATUS OUT VARCHAR2,  
    X_MSG_COUNT OUT NUMBER,  
    X_MSG_DATA OUT VARCHAR2,  
    PI_NCOMPANYID IN CDR_JOB_LOG.COMPANY_ID%TYPE,  
    PI_NJOBID IN CDR_JOB_LOG.JOB_ID%TYPE,  
    PI_VLOGENTRY IN VARCHAR2  
);
```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

- **PI_NCOMPANYID** Enter the Company ID.
- **PI_NJOBID** Enter the Job ID.
- **PI_VLOGENTRY** Enter a Log Entry. This accepts a text message.

This is a public interface for object security-related operations. You need the CDR_SECURITY_ADMIN or CDR_DATA_SECURITY_ADMIN application role to use any of these APIs.

26.1 Create and Modify Security Policies

This section contains the following topics:

- [Section 26.1.1, "Create a Subtype"](#)
- [Section 26.1.2, "Copy a Subtype"](#)
- [Section 26.1.3, "Modify a Subtype"](#)
- [Section 26.1.4, "Assign Roles to a Subtype Operation"](#)
- [Section 26.1.5, "Assign Operations to a Subtype Role"](#)
- [Section 26.1.6, "Remove a Subtype"](#)
- [Section 26.1.7, "Create a Role"](#)
- [Section 26.1.8, "Modify a Role"](#)
- [Section 26.1.9, "Add a Group Role"](#)
- [Section 26.1.10, "Get Roles for a User"](#)
- [Section 26.1.11, "Remove a Role"](#)
- [Section 26.1.12, "Remove a Group Role"](#)
- [Section 26.1.13, "Create a User Group"](#)
- [Section 26.1.14, "Add Users to a Group"](#)
- [Section 26.1.15, "Remove Users from a Role in a User Group"](#)
- [Section 26.1.16, "Assign a User Group to an Object"](#)
- [Section 26.1.17, "Copy a User Group"](#)
- [Section 26.1.18, "Copy a User Group with its Users"](#)
- [Section 26.1.19, "Modify a User Group"](#)
- [Section 26.1.20, "Remove All Group Roles from a User Group"](#)
- [Section 26.1.21, "Remove All Users in a Group"](#)
- [Section 26.1.22, "Revoke a User Group From an Object"](#)
- [Section 26.1.23, "Undo a Revoke a User Group Action"](#)

- [Section 26.1.24, "Remove a User Group"](#)
- [Section 26.1.25, "Unassign a User Group From an Object"](#)
- [Section 26.1.26, "Unassign Roles from an Operation on an Object's Subtype"](#)
- [Section 26.1.27, "Unassign Operations on an Object Subtype's Role"](#)

26.1.1 Create a Subtype

Use this API to create a new subtype.

Name CDR_PUB_SECURITY_PKG.CREATESUBTYPE

Signature

```
PROCEDURE CREATSUBTYPE(  
    P_API_VERSION IN NUMBER,  
    P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,  
    P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,  
    P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,  
    X_RETURN_STATUS OUT VARCHAR2,  
    X_MSG_COUNT OUT NUMBER,  
    X_MSG_DATA OUT VARCHAR2,  
    PIO_SUBTYPE IN OUT CDR_SUBTYPE_OBJ_TYPE  
);
```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameter:

PIO_SUBTYPE (Mandatory) This is a collection of CDR_USER_GROUPS_OBJ_TYPE that contain attributes related to User Groups.

The required attributes are: NAME,OBJECT_SUBTYPE_ID,OBJECT_TYPE_RC.

26.1.2 Copy a Subtype

Use this API to make a copy of a subtype.

Name CDR_PUB_SECURITY_PKG.COPYSUBTYPE

Signature

```
PROCEDURE COPYSUBTYPE(  
    P_API_VERSION IN NUMBER,  
    P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,  
    P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,  
    P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,  
    X_RETURN_STATUS OUT VARCHAR2,  
    X_MSG_COUNT OUT NUMBER,  
    X_MSG_DATA OUT VARCHAR2,  
    PI_SUBTYPE IN CDR_SUBTYPE_OBJ_TYPE  
);
```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameter:

PI_SUBTYPE (Mandatory) This a parameter of table type CDR_SUBTYPE_OBJ_TYPE that contains information about the subtype.

26.1.3 Modify a Subtype

Use this API to update a subtype.

Name CDR_PUB_SECURITY_PKG.MODIFYSUBTYPE

Signature

```
PROCEDURE MODIFYSUBTYPE(
  P_API_VERSION IN NUMBER,
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
  X_RETURN_STATUS OUT VARCHAR2,
  X_MSG_COUNT OUT NUMBER,
  X_MSG_DATA OUT VARCHAR2,
  PIO_SUBTYPE IN OUT CDR_SUBTYPE_OBJ_TYPE
);
```

Parameters This API has standard parameters (see "[Standard Parameters](#)" on page 5) and the following parameter:

PIO_SUBTYPE (Mandatory) This is a parameter of table type CDR_SUBTYPE_OBJ_TYPE that contains information about the object subtype.

26.1.4 Assign Roles to a Subtype Operation

Use this API to assign a role to an operation for a subtype of an object.

Name CDR_PUB_SECURITY_PKG.ASSIGNOPRTOSUBTYPEROLE

Signature

```
PROCEDURE ASSIGNROLESTOSUBTYPEOPERATION(
  P_API_VERSION IN NUMBER,
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
  X_RETURN_STATUS OUT VARCHAR2,
  X_MSG_COUNT OUT NUMBER,
  X_MSG_DATA OUT VARCHAR2,
  PIO_ROLESTOOPR IN OUT CDR_SUBTYPE_OPR_ROLES_COLL
);
```

Parameters This API has standard parameters (see "[Standard Parameters](#)" on page 5) and the following parameters:

PIO_ROLESTOOPR (Mandatory) This is a collection of CDR_SUBTYPE_OPR_ROLE_OBJ_TYPE.

26.1.5 Assign Operations to a Subtype Role

Use this API to assign an operation to a role of an object subtype.

Name CDR_PUB_SECURITY_PKG.ASSIGNOPRTOSUBTYPEROLE

Signature

```
PROCEDURE ASSIGNOPRTOSUBTYPEROLE(
  P_API_VERSION IN NUMBER,
```

```
P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
X_RETURN_STATUS OUT VARCHAR2,
X_MSG_COUNT OUT NUMBER,
X_MSG_DATA OUT VARCHAR2,
PIO_ROLESTOOPR IN OUT CDR_SUBTYPE_OPR_ROLE_COLL
);
```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameter:

PIO_ROLESTOOPR (Mandatory) This is a collection of CDR_SUBTYPE_OPR_ROLE_OBJ_TYPE.

26.1.6 Remove a Subtype

Use this API to delete a subtype that is not Active. If objects are assigned to the subtype, you cannot delete it even if it is Inactive.

Name CDR_PUB_SECURITY_PKG.REMOVESUBTYPE

Signature

```
PROCEDURE REMOVESUBTYPE(
  P_API_VERSION IN NUMBER,
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
  X_RETURN_STATUS OUT VARCHAR2,
  X_MSG_COUNT OUT NUMBER,
  X_MSG_DATA OUT VARCHAR2,
  PI_SUBTYPEID IN CDR_OBJECT_SUBTYPES_B.OBJECT_SUBTYPE_ID%TYPE,
  PI_COMPANYID IN CDR_OBJECT_SUBTYPES_B.COMPANY_ID%TYPE,
  PI_OBJECTTYPE RC IN CDR_OBJECT_SUBTYPES_B.OBJECT_TYPE_RC%TYPE
);
```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

- **PI_SUBTYPEID** (Mandatory) Enter the OBJECT_SUBTYPE_ID of the subtype you want to delete.
- **PI_COMPANYID** (Mandatory) Enter the COMPANY_ID associated with the OBJ_SUBTYPE_ID.
- **PI_OBJECTTYPE RC** (Mandatory) Enter the OBJECT_TYPE_RC value for the object type associated with the subtype.

26.1.7 Create a Role

Use this API to create a new Role.

Name CDR_PUB_SECURITY_PKG.CREATE_ROLE

Signature

```
PROCEDURE CREATE_ROLE(
  P_API_VERSION IN NUMBER,
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
```

```

P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
X_RETURN_STATUS OUT VARCHAR2,
X_MSG_COUNT OUT NUMBER,
X_MSG_DATA OUT VARCHAR2,
PIO_ROLE IN OUT CDR_ROLE_OBJ_TYPE
);

```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

PIO_ROLE (Mandatory) This is a parameter of table type CDR_ROLE_OBJ_TYPE that contains attributes related to a Role.

Required Attributes are: NAME, CODE, OBJECT VERSION NUMBER (pass 1 for this).

26.1.8 Modify a Role

Use this API to update a Role. You can change the name, description, and Active status of a Role.

Name CDR_PUB_SECURITY_PKG.MODIFYROLE

Signature

```

PROCEDURE MODIFYROLE(
  P_API_VERSION IN NUMBER,
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
  X_RETURN_STATUS OUT VARCHAR2,
  X_MSG_COUNT OUT NUMBER,
  X_MSG_DATA OUT VARCHAR2,
  PIO_ROLE IN OUT CDR_ROLE_OBJ_TYPE
);

```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameter:

PIO_ROLE (Mandatory) This is a parameter of table type CDR_ROLE_OBJ_TYPE that contains attributes related to a Role.

Required Attributes are: NAME, CODE, OBJECT VERSION NUMBER (pass 1 for this).

26.1.9 Add a Group Role

Use this API to create roles for a User Group.

Name CDR_PUB_SECURITY_PKG.ADDGRPROLES

Signature

```

PROCEDURE ADDGRPROLES(
  P_API_VERSION IN NUMBER,
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
  X_RETURN_STATUS OUT VARCHAR2,
  X_MSG_COUNT OUT NUMBER,
  X_MSG_DATA OUT VARCHAR2,
  PIO_ROLES IN OUT CDR_UG_ROLE_OBJ_TYPE
);

```

```
);
```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameter:

PIO_ROLES (Mandatory) This is a parameter of table type CDR_UG_ROLE_OBJ_TYPE.

Following attributes are required: COMPANY_ID,USER_GROUP_ID,ROLE_ID,OBJECT_VERSION_NUMBER

26.1.10 Get Roles for a User

Use this API to retrieve all Roles assigned to a user.

Name CDR_PUB_SECURITY_PKG.GETROLESFORUSER

Signature

```
FUNCTION GETROLESFORUSER(  
  P_API_VERSION IN NUMBER,  
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,  
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,  
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,  
  P_USERID IN VARCHAR2  
) RETURN CLOB;
```

Return Type CLOB

Description CLOB for all roles for given user.

Parameters This API has standard parameters. See ["Standard Parameters"](#) on page 5) for details.

26.1.11 Remove a Role

Use this API to delete a role.

Name CDR_PUB_SECURITY_PKG.REMOVEROLE

Signature

```
PROCEDURE REMOVEROLE(  
  P_API_VERSION IN NUMBER,  
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,  
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,  
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,  
  X_RETURN_STATUS OUT VARCHAR2,  
  X_MSG_COUNT OUT NUMBER,  
  X_MSG_DATA OUT VARCHAR2,  
  PI_COMPANYID IN NUMBER,  
  PI_ROLEID IN NUMBER  
);
```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

- **PI_COMPANYID** (Mandatory) Enter the COMPANY_ID associated with the Role.
- **PI_ROLEID** (Mandatory) Enter the ROLE_ID of the Role that you want to delete.

26.1.12 Remove a Group Role

Use this API to remove a single Role from a User Group. You can remove all Roles from the User Group at the same time by using the Remove All Group Roles API.

Name CDR_PUB_SECURITY_PKG.REMOVEGRPROLES

Signature

```
PROCEDURE REMOVEGRPROLES (
  P_API_VERSION IN NUMBER,
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
  X_RETURN_STATUS OUT VARCHAR2,
  X_MSG_COUNT OUT NUMBER,
  X_MSG_DATA OUT VARCHAR2,
  PIO_ROLES IN CDR_UG_ROLE_OBJ_TYPE
);
```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameter:

PIO_ROLES (Mandatory) This parameter is of table type CDR_UG_ROLE_OBJ_TYPE that contains information about User Groups and Roles.

26.1.13 Create a User Group

Use this API to create a new User Group.

Name CDR_PUB_SECURITY_PKG.CREATEUSERGROUP

Signature

```
PROCEDURE CREATEUSERGROUP (
  P_API_VERSION IN NUMBER,
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
  X_RETURN_STATUS OUT VARCHAR2,
  X_MSG_COUNT OUT NUMBER,
  X_MSG_DATA OUT VARCHAR2,
  PIO_USERGRP IN OUT CDR_USER_GROUP_OBJ_TYPE
);
```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

PIO_USERGRP (Mandatory) This is a collection of CDR_USER_GROUPS_OBJ_TYPE that contains attributes related to User Groups.

Required attributes are: USER_GROUP_ID,COMPANY_ID, NAME.

26.1.14 Add Users to a Group

Use this API to add users to a User Group.

Name CDR_PUB_SECURITY_PKG.ADDUSERTOGRP

Signature

```
PROCEDURE ADDUSERTOGRP (
    P_API_VERSION IN NUMBER,
    P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
    P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
    P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
    X_RETURN_STATUS OUT VARCHAR2,
    X_MSG_COUNT OUT NUMBER,
    X_MSG_DATA OUT VARCHAR2,
    PIO_USERUGROLES IN OUT CDR_USER_UG_ROLE_OBJ_TYPE
);
```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

PIO_USERUGROLES (Mandatory) This is a parameter of table type CDR_USER_UG_ROLE_OBJ_TYPE.

Required Attributes are: UG_COMPANY_ID,USER_GROUP_ID,ROLE_ID,USER_ID,ROLE_ID

26.1.15 Remove Users from a Role in a User Group

Use this API to delete users from a Role in a User Group.

Name CDR_PUB_SECURITY_PKG.REMOVEUSERSINGRP

Signature

```
PROCEDURE REMOVEUSERSINGRP (
    P_API_VERSION IN NUMBER,
    P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
    P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
    P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
    X_RETURN_STATUS OUT VARCHAR2,
    X_MSG_COUNT OUT NUMBER,
    X_MSG_DATA OUT VARCHAR2,
    PIO_USERUGROLES IN OUT CDR_USER_UG_ROLE_OBJ_TYPE
);
```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameter:

PIO_USERUGROLES (Mandatory) This parameter is of table type CDR_USER_UG_ROLE_OBJ_TYPE that contains information about user, User Groups, and Roles.

26.1.16 Assign a User Group to an Object

Use this API to assign a User Group to an object.

Name CDR_PUB_SECURITY_PKG.ASSIGNUSRGRPTOOBJ

Signature

```
PROCEDURE ASSIGNUSRGRPTOOBJ (
    P_API_VERSION IN NUMBER,
    P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
    P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
    P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
    X_RETURN_STATUS OUT VARCHAR2,
    X_MSG_COUNT OUT NUMBER,
```

```

X_MSG_DATA OUT VARCHAR2,
PI_BASEOBJECTTYPE IN OUT CDR_BASE_OBJ_TYPE,
PI_CDROBJUGCOLL IN CDR_OBJ_UG_COLL
);

```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

- **PI_BASEOBJECTTYPE** (Mandatory) This is a parameter of table type CDR_BASE_OBJ_TYPE that contains object attributes.

Provide the basic naming attributes for the object to which you want to assign the User Group. (COMPANY_ID, OBJECT_ID, OBJECT_VER, NAMESPACE_OBJ_ID, NAMESPACE_OBJ_VER, OBJECT_VERSION_NUMBER). Initialize these attributes in CDR_BASE_OBJ_TYPE.
- **PI_CDROBJUGCOLL** (Mandatory) This is a collection of CDR_OBJ_UG_OBJ_TYPE. Enter User Group details in this parameter.

The following are required parameters: UG_COMPANY_ID, OBJ_COMPANY_ID, USER_GROUP_ID, OBJ_ID and EXCLUSION_FLAG.

26.1.17 Copy a User Group

Use this API to make a copy of a User Group including its Roles but not its users.

Name CDR_PUB_SECURITY_PKG.COPYUSERGROUP

Signature

```

PROCEDURE COPYUSERGROUP(
  P_API_VERSION IN NUMBER,
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
  X_RETURN_STATUS OUT VARCHAR2,
  X_MSG_COUNT OUT NUMBER,
  X_MSG_DATA OUT VARCHAR2,
  PIO_USERGRP IN OUT CDR_USER_GROUPS_COLL
);

```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameter:

PIO_USERGRP (Mandatory) This is a collection of CDR_USER_GROUPS_OBJ_TYPE that contains attributes related to User Groups.

Required attributes are: USER_GROUP_ID, COMPANY_ID, NAME.

26.1.18 Copy a User Group with its Users

Use this API to make a copy of a User Group including its roles and users.

Name CDR_PUB_SECURITY_PKG.COPYUSERGROUPWITHUSERS

Signature

```

PROCEDURE COPYUSERGROUPWITHUSERS(
  P_API_VERSION IN NUMBER,
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,

```

```
P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
X_RETURN_STATUS OUT VARCHAR2,
X_MSG_COUNT OUT NUMBER,
X_MSG_DATA OUT VARCHAR2,
PIO_USERGRP IN OUT CDR_USER_GROUPS_COLL
);
```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameter:

PIO_USERGRP (Mandatory) This is a collection of CDR_USER_GROUPS_OBJ_TYPE that contains attributes related to User Groups.

Required attributes are: USER_GROUP_ID,COMPANY_ID, NAME.

26.1.19 Modify a User Group

Use this API to modify a User Group.

Name CDR_PUB_SECURITY_PKG.MODIFYUSERGROUP

Signature

```
PROCEDURE MODIFYUSERGROUP(
  P_API_VERSION IN NUMBER,
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
  X_RETURN_STATUS OUT VARCHAR2,
  X_MSG_COUNT OUT NUMBER,
  X_MSG_DATA OUT VARCHAR2,
  PIO_USERGRP IN OUT CDR_USER_GROUP_OBJ_TYPE
);
```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

PIO_USERGRP (Mandatory) This is a collection of CDR_USER_GROUPS_OBJ_TYPE that contains attributes related to User Groups.

Required attributes are: USER_GROUP_ID,COMPANY_ID, NAME.

26.1.20 Remove All Group Roles from a User Group

Use this API to remove all Roles from the User Group.

Name CDR_PUB_SECURITY_PKG.REMOVEALLGRPROLES

Signature

```
PROCEDURE REMOVEALLGRPROLES(
  P_API_VERSION IN NUMBER,
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
  X_RETURN_STATUS OUT VARCHAR2,
  X_MSG_COUNT OUT NUMBER,
  X_MSG_DATA OUT VARCHAR2,
  PI_USERGRPID IN NUMBER,
  PI_COMPANY_ID IN NUMBER
);
```


Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

- **PI_USERGRPID** (Mandatory) Enter the numeric ID to identify the User Group. This parameter is of type Number and corresponds to the CDR_UG_ROLES.USER_GROUP_ID%TYPE column.
- **PI_COMPANY_ID** (Mandatory) Enter the Company Id.

26.1.21 Remove All Users in a Group

Use this API to remove all users from a Role in a User Group.

Name CDR_PUB_SECURITY_PKG.REMOVEALLUSERSINGRP

Signature

```
PROCEDURE REMOVEALLUSERSINGRP(
  P_API_VERSION IN NUMBER,
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
  X_RETURN_STATUS OUT VARCHAR2,
  X_MSG_COUNT OUT NUMBER,
  X_MSG_DATA OUT VARCHAR2,
  PIO_USERUGROLES IN OUT CDR_USER_UG_ROLE_OBJ_TYPE
);
```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameter:

PIO_USERUGROLES (Mandatory) This parameter is of table type CDR_USER_UG_ROLE_OBJ_TYPE that contains information about users, User Groups, and Roles.

26.1.22 Revoke a User Group From an Object

Use this API to revoke a User Group from an object.

To remove access to an object through an inherited User Group, you must revoke the User Group assignment.

Use Unassign User Group from Object (UNASSIGNUSRGRPFROMOBJ) for User Groups assigned explicitly.)

Name CDR_PUB_SECURITY_PKG.REVOKEUSRGRPFROMOBJ

Signature

```
PROCEDURE REVOKEUSRGRPFROMOBJ(
  P_API_VERSION IN NUMBER,
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
  X_RETURN_STATUS OUT VARCHAR2,
  X_MSG_COUNT OUT NUMBER,
  X_MSG_DATA OUT VARCHAR2,
  PI_BASEOBJECTTYPE IN OUT CDR_BASE_OBJ_TYPE,
  PI_CDROBJUGOBJTYPE IN CDR_OBJ_UG_OBJ_TYPE,
  PO_HASVIEWPERMAFTERREVOKE OUT VARCHAR2
);
```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

- **PI_BASEOBJECTTYPE** (Mandatory) This is a parameter of table type CDR_BASE_OBJ_TYPE that contains object attributes. Enter values to identify the object from which the User Group is to be revoked.

The following attributes are required: COMPANY_ID,OBJ_ID,OBJ_VER,OBJECT_VERSION_NUMBER,NAMESPACE_OBJ_ID,NAMESPACE_OBJ_VER.

- **PI_CDROBJUGOBJTYPE** (Mandatory) This is a parameter of table type CDR_OBJ_UG_OBJ_TYPE that contains information about the object and the User Group.
- **PO_HASVIEWPERMAFTERREVOKE** (Mandatory) Enter appropriate values for this parameter to specify whether view permissions exist after the revoking of the User Group from the object.

26.1.23 Undo a Revoke a User Group Action

Use this API to undo the revoking of a User Group from an object.

Name CDR_PUB_SECURITY_PKG.UNREVOKEUSRGRPFROMOBJ

Signature

```
PROCEDURE UNREVOKEUSRGRPFROMOBJ (  
  P_API_VERSION IN NUMBER,  
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,  
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,  
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,  
  X_RETURN_STATUS OUT VARCHAR2,  
  X_MSG_COUNT OUT NUMBER,  
  X_MSG_DATA OUT VARCHAR2,  
  PI_BASEOBJECTTYPE IN OUT CDR_BASE_OBJ_TYPE,  
  PI_CDROBJUGOBJTYPE IN CDR_OBJ_UG_OBJ_TYPE  
);
```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

- **PI_BASEOBJECTTYPE** (Mandatory) This is a parameter of table type CDR_BASE_OBJ_TYPE that contains object attributes. Enter values to identify the object.

The following attributes are required: COMPANY_ID,OBJ_ID,OBJ_VER,OBJECT_VERSION_NUMBER,NAMESPACE_OBJ_ID,NAMESPACE_OBJ_VER.

- **PI_CDROBJUGOBJTYPE** (Mandatory) This is a parameter of table type CDR_OBJ_UG_OBJ_TYPE that contains information about the object and the User Group.

26.1.24 Remove a User Group

Use this API to delete a User Group from the system. Once deleted, a User Group cannot be reactivated.

Name CDR_PUB_SECURITY_PKG.REMOVEUSERGROUP

Signature

```
PROCEDURE REMOVEUSERGROUP (
```

```

P_API_VERSION IN NUMBER,
P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
X_RETURN_STATUS OUT VARCHAR2,
X_MSG_COUNT OUT NUMBER,
X_MSG_DATA OUT VARCHAR2,
PIO_USERGRP IN OUT CDR_USER_GROUPS_COLL
);

```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameter:

PIO_USERGRP (Mandatory) This is a collection of CDR_USER_GROUPS_OBJ_TYPE that contains attributes related to User Groups.

The required attributes are: USER_GROUP_ID, COMPANY_ID.

26.1.25 Unassign a User Group From an Object

Use this API to unassign a User Group from an object. You can unassign User Groups explicitly assigned to the Object. You have to revoke User Groups that are inherited.

Name CDR_PUB_SECURITY_PKG.UNASSIGNUSRGRPFROMOBJ

Signature

```

PROCEDURE UNASSIGNUSRGRPFROMOBJ(
  P_API_VERSION IN NUMBER,
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
  X_RETURN_STATUS OUT VARCHAR2,
  X_MSG_COUNT OUT NUMBER,
  X_MSG_DATA OUT VARCHAR2,
  PI_BASEOBJECTTYPE IN OUT CDR_BASE_OBJ_TYPE,
  PI_CDROBJUGOBJTYPE IN CDR_OBJ_UG_OBJ_TYPE,
  PO_HASVIEWPERMAFTERUNASSIGN OUT VARCHAR2
);

```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

- **PI_BASEOBJECTTYPE** (Mandatory) This is a parameter of table type CDR_BASE_OBJ_TYPE that contains object attributes. Enter values to identify the object.
The required attributes are COMPANY_ID, OBJ_ID, OBJ_VER, OBJECT_VERSION_NUMBER, NAMESPACE_OBJ_ID, NAMESPACE_OBJ_VER.
- **PI_CDROBJUGOBJTYPE** (Mandatory) This is a parameter of table type CDR_OBJ_UG_OBJ_TYPE that contains information about the object and the User Group.
- **PO_HASVIEWPERMAFTERUNASSIGN** (Mandatory) Enter appropriate values for this parameter to specify whether view permissions exist after unassigning the User Group from the object.

26.1.26 Unassign Roles from an Operation on an Object's Subtype

Use this API to unassign Roles from an Operation on an object's subtype.

Name CDR_PUB_SECURITY_PKG.UNASSIGNROLETOSUBTYPEOPERATION

Signature

```
PROCEDURE UNASSIGNROLETOSUBTYPEOPERATION(  
  P_API_VERSION IN NUMBER,  
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,  
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,  
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,  
  X_RETURN_STATUS OUT VARCHAR2,  
  X_MSG_COUNT OUT NUMBER,  
  X_MSG_DATA OUT VARCHAR2,  
  PI_STOPROLE IN OUT CDR_SUBTYPE_OPR_ROLE_OBJ_TYPE  
);
```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameter:

PI_STOPROLE (Mandatory) This parameter is of table type CDR_SUBTYPE_OPR_ROLE_OBJ_TYPE that contains information about object subtype, Role, and operation.

26.1.27 Unassign Operations on an Object Subtype's Role

Use this API to unassign operations on an object subtype's role.

Name CDR_PUB_SECURITY_PKG.UNASSIGNOPRTOSUBTYPEROLE

Signature

```
PROCEDURE UNASSIGNOPRTOSUBTYPEROLE(  
  P_API_VERSION IN NUMBER,  
  P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,  
  P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,  
  P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,  
  X_RETURN_STATUS OUT VARCHAR2,  
  X_MSG_COUNT OUT NUMBER,  
  X_MSG_DATA OUT VARCHAR2,  
  PI_STOPROLE IN OUT CDR_SUBTYPE_OPR_ROLE_OBJ_TYPE  
);
```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameter:

PI_STOPROLE (Mandatory) This parameter is of table type CDR_SUBTYPE_OPR_ROLE_OBJ_TYPE that contains information about object subtype, Role, and operation.

This is a public interface for validation-related operations.

This section contains the following topics:

- [Section 27.1, "Validate Objects"](#)
- [Section 27.2, "Create and Modify Validation Supporting Documents"](#)

27.1 Validate Objects

This section contains one API for updating the validation status of an object.

27.1.1 Update an Object's Validation Status

Use this API to update an object's validation status. The API performs a cascade validation on this object and its related objects.

If this object is an instance, the API also validates its source definition. If this object contains other objects with a validation status, the API updates the validation status of all of them; and if they are instances, their source definitions.

The operation fails if any of the underlying definitions are checked out. If you are validating a Report Set, the operation also fails if any of the Program instances in the Report Set have a validation status lower than the one to which the Report Set is being upgraded.

Name CDR_PUB_VL_VALIDATION.UPDATEVALSTATUS

Signature

```
PROCEDURE UPDATEVALSTATUS (
    P_API_VERSION IN NUMBER,
    P_INIT_MSG_LIST IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
    P_COMMIT IN VARCHAR2 := CDR_PUB_DEF_CONSTANTS.G_FALSE,
    P_VALIDATION_LEVEL IN NUMBER := CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL,
    X_RETURN_STATUS OUT VARCHAR2,
    X_MSG_COUNT OUT NUMBER,
    X_MSG_DATA OUT VARCHAR2,
    PI_VALOBJ IN CDR_VAL_STATUS_OBJ_TYPE,
    PO_CASCADEDOBJCOLL OUT CDR_BASE_OBJ_COLL,
    PO_ERRORNAMINGCOLL OUT CDR_BASE_OBJ_COLL
);
```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameters:

- **PI_VALOBJ** (Mandatory) This is a parameter of table type CDR_VAL_STATUS_OBJ_TYPE that contains object attributes. Enter values to identify the object whose validation status you want to update.

The following attributes are required: COMPANY_ID, OBJ_ID, OBJ_VER, OBJ_TYPE_RC, VALIDATION_STATUS_RC, OBJECT_VERSION_NUMBER.

- **PO_CASCADEDOBJCOLL** This output parameter is a collection of all the objects whose validation status was updated due to cascading. If this parameter contains a value, the validation update operation succeeded.
- **PO_ERRORNAMINGCOLL** This output parameter is a collection of objects whose validation status could not be updated. If this parameter contains a value, the validation update operation failed.

27.2 Create and Modify Validation Supporting Documents

This section contains the following topics:

- [Section 27.2.1, "Create a Validation Supporting Document"](#)
- [Section 27.2.2, "Update a Validation Supporting Document"](#)
- [Section 27.2.3, "Obsolete a Validation Supporting Document"](#)

27.2.1 Create a Validation Supporting Document

Use this API to create a validation supporting document.

Name CDR_PUB_VL_VALIDATION.CREATEVALDOCUMENT

Signature

```
PROCEDURE CREATEVALDOCUMENT(  
  P_API_VERSION IN NUMBER  
  , P_INIT_MSG_LIST IN VARCHAR2 DEFAULT CDR_PUB_DEF_CONSTANTS.G_FALSE  
  , P_COMMIT IN VARCHAR2 DEFAULT CDR_PUB_DEF_CONSTANTS.G_FALSE  
  , P_VALIDATION_LEVEL IN NUMBER DEFAULT CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL  
  , X_RETURN_STATUS OUT NOCOPY VARCHAR2  
  , X_MSG_COUNT OUT NOCOPY NUMBER  
  , X_MSG_DATA OUT NOCOPY VARCHAR2  
  , PI_VALDOCOBJ IN CDR_VAL_DOC_BLOB_OBJ_TYPE  
) ;
```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameter:

PI_VALDOCOBJ (Mandatory) This is a parameter of type CDR_VAL_DOC_BLOB_OBJ_TYPE that contains object attributes.

The following attributes are required: COMPANY_ID, OBJ_ID, OBJ_VER, DOCUMENT_NAME, DESCRIPTION, FILE_NAME, OS_FILE_PATH, FILE_BLOB, FILE_CONTENT_TYPE.

27.2.2 Update a Validation Supporting Document

You can use this API to upload a new document, change attributes such as its description, or both.

Name CDR_PUB_VL_VALIDATION.UPDATEVALDOCUMENT

Signature

```
PROCEDURE UPDATEVALDOCUMENT(
P_API_VERSION IN NUMBER
,P_INIT_MSG_LIST IN VARCHAR2 DEFAULT CDR_PUB_DEF_CONSTANTS.G_FALSE
,P_COMMIT IN VARCHAR2 DEFAULT CDR_PUB_DEF_CONSTANTS.G_FALSE
,P_VALIDATION_LEVEL IN NUMBER DEFAULT CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL
,X_RETURN_STATUS OUT NOCOPY VARCHAR2
,X_MSG_COUNT OUT NOCOPY NUMBER
,X_MSG_DATA OUT NOCOPY VARCHAR2
, PI_VALDOCOBJ IN CDR_VAL_DOC_BLOB_OBJ_TYPE
);
```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameter:

PI_VALDOCOBJ (Mandatory) This is a parameter of type CDR_VAL_DOC_BLOB_OBJ_TYPE that contains object attributes. The following attributes of the document to be updated are required: DOCUMENT_ID, COMPANY_ID, OBJ_ID, OBJ_VER, DOCUMENT_NAME, DOC_STATUS_RC, DOCUMENT_VER, DESCRIPTION, CHANGE_REASON, FILE_ID, FILE_NAME, OS_FILE_PATH, FILE_BLOB, FILE_CONTENT_TYPE, OBJECT_VERSION_NUMBER.

To get the OBJECT_VERSION_NUMBER, enter the following query:

```
select Max(OBJECT_VERSION_NUMBER) from cdr_vl_val_docs_v
where OBJ_ID = <objid> and OBJ_VER = <objver> and DOC_STATUS_RC =
'$VALINFOSTATUS$ACTIVE';
```

27.2.3 Obsolete a Validation Supporting Document

Use this API to remove a validation supporting document.

Name CDR_PUB_VL_VALIDATION.REMOVEVALDOCUMENT

Signature

```
PROCEDURE REMOVEVALDOCUMENT(
P_API_VERSION IN NUMBER
,P_INIT_MSG_LIST IN VARCHAR2 DEFAULT CDR_PUB_DEF_CONSTANTS.G_FALSE ,P_COMMIT IN
VARCHAR2 DEFAULT CDR_PUB_DEF_CONSTANTS.G_FALSE
,P_VALIDATION_LEVEL IN NUMBER DEFAULT CDR_PUB_DEF_CONSTANTS.G_VALID_LEVEL_FULL
,X_RETURN_STATUS OUT NOCOPY VARCHAR2
,X_MSG_COUNT OUT NOCOPY NUMBER
,X_MSG_DATA OUT NOCOPY VARCHAR2
, PI_VALDOCOBJ IN CDR_VAL_DOC_BLOB_OBJ_TYPE
);
```

Parameters This API has standard parameters (see ["Standard Parameters"](#) on page 5) and the following parameter:

PI_VALDOCOBJ (Mandatory) This is a parameter of type CDR_VAL_DOC_BLOB_OBJ_TYPE that contains object attributes.

The following attributes of the document to be obsoleted are required: DOCUMENT_ID, COMPANY_ID, DOCUMENT_VER, OBJECT_VERSION_NUMBER.

To get the OBJECT_VERSION_NUMBER, enter the following query:

```
select Max(OBJECT_VERSION_NUMBER) from cdr_vl_val_docs_v
where OBJ_ID = <objid> and OBJ_VER = <objver> and DOC_STATUS_RC =
'$VALINFOSTATUS$ACTIVE';
```

