

SPARC and Netra SPARC T4 Series Servers

Administration Guide



Part No.: E22989-07
October 2012

Copyright © 2011, 2012, Oracle and/or its affiliates. All rights reserved.

This software and related documentation are provided under a license agreement containing restrictions on use and disclosure and are protected by intellectual property laws. Except as expressly permitted in your license agreement or allowed by law, you may not use, copy, reproduce, translate, broadcast, modify, license, transmit, distribute, exhibit, perform, publish, or display any part, in any form, or by any means. Reverse engineering, disassembly, or decompilation of this software, unless required by law for interoperability, is prohibited.

The information contained herein is subject to change without notice and is not warranted to be error-free. If you find any errors, please report them to us in writing.

If this is software or related software documentation that is delivered to the U.S. Government or anyone licensing it on behalf of the U.S. Government, the following notice is applicable:

U.S. GOVERNMENT END USERS. Oracle programs, including any operating system, integrated software, any programs installed on the hardware, and/or documentation, delivered to U.S. Government end users are "commercial computer software" pursuant to the applicable Federal Acquisition Regulation and agency-specific supplemental regulations. As such, use, duplication, disclosure, modification, and adaptation of the programs, including any operating system, integrated software, any programs installed on the hardware, and/or documentation, shall be subject to license terms and license restrictions applicable to the programs. No other rights are granted to the U.S. Government.

This software or hardware is developed for general use in a variety of information management applications. It is not developed or intended for use in any inherently dangerous applications, including applications that may create a risk of personal injury. If you use this software or hardware in dangerous applications, then you shall be responsible to take all appropriate fail-safe, backup, redundancy, and other measures to ensure its safe use. Oracle Corporation and its affiliates disclaim any liability for any damages caused by use of this software or hardware in dangerous applications.

Oracle and Java are registered trademarks of Oracle and/or its affiliates. Other names may be trademarks of their respective owners.

Intel and Intel Xeon are trademarks or registered trademarks of Intel Corporation. All SPARC trademarks are used under license and are trademarks or registered trademarks of SPARC International, Inc. AMD, Opteron, the AMD logo, and the AMD Opteron logo are trademarks or registered trademarks of Advanced Micro Devices. UNIX is a registered trademark of The Open Group.

This software or hardware and documentation may provide access to or information on content, products, and services from third parties. Oracle Corporation and its affiliates are not responsible for and expressly disclaim all warranties of any kind with respect to third-party content, products, and services. Oracle Corporation and its affiliates will not be responsible for any loss, costs, or damages incurred due to your access to or use of third-party content, products, or services.

Copyright © 2011, 2012, Oracle et/ou ses affiliés. Tous droits réservés.

Ce logiciel et la documentation qui l'accompagne sont protégés par les lois sur la propriété intellectuelle. Ils sont concédés sous licence et soumis à des restrictions d'utilisation et de divulgation. Sauf disposition de votre contrat de licence ou de la loi, vous ne pouvez pas copier, reproduire, traduire, diffuser, modifier, breveter, transmettre, distribuer, exposer, exécuter, publier ou afficher le logiciel, même partiellement, sous quelque forme et par quelque procédé que ce soit. Par ailleurs, il est interdit de procéder à toute ingénierie inverse du logiciel, de le désassembler ou de le décompiler, excepté à des fins d'interopérabilité avec des logiciels tiers ou tel que prescrit par la loi.

Les informations fournies dans ce document sont susceptibles de modification sans préavis. Par ailleurs, Oracle Corporation ne garantit pas qu'elles soient exemptes d'erreurs et vous invite, le cas échéant, à lui en faire part par écrit.

Si ce logiciel, ou la documentation qui l'accompagne, est concédé sous licence au Gouvernement des Etats-Unis, ou à toute entité qui délivre la licence de ce logiciel ou l'utilise pour le compte du Gouvernement des Etats-Unis, la notice suivante s'applique :

U.S. GOVERNMENT END USERS. Oracle programs, including any operating system, integrated software, any programs installed on the hardware, and/or documentation, delivered to U.S. Government end users are "commercial computer software" pursuant to the applicable Federal Acquisition Regulation and agency-specific supplemental regulations. As such, use, duplication, disclosure, modification, and adaptation of the programs, including any operating system, integrated software, any programs installed on the hardware, and/or documentation, shall be subject to license terms and license restrictions applicable to the programs. No other rights are granted to the U.S. Government.

Ce logiciel ou matériel a été développé pour un usage général dans le cadre d'applications de gestion des informations. Ce logiciel ou matériel n'est pas conçu ni n'est destiné à être utilisé dans des applications à risque, notamment dans des applications pouvant causer des dommages corporels. Si vous utilisez ce logiciel ou matériel dans le cadre d'applications dangereuses, il est de votre responsabilité de prendre toutes les mesures de secours, de sauvegarde, de redondance et autres mesures nécessaires à son utilisation dans des conditions optimales de sécurité. Oracle Corporation et ses affiliés déclinent toute responsabilité quant aux dommages causés par l'utilisation de ce logiciel ou matériel pour ce type d'applications.

Oracle et Java sont des marques déposées d'Oracle Corporation et/ou de ses affiliés. Tout autre nom mentionné peut correspondre à des marques appartenant à d'autres propriétaires qu'Oracle.

Intel et Intel Xeon sont des marques ou des marques déposées d'Intel Corporation. Toutes les marques SPARC sont utilisées sous licence et sont des marques ou des marques déposées de SPARC International, Inc. AMD, Opteron, le logo AMD et le logo AMD Opteron sont des marques ou des marques déposées d'Advanced Micro Devices. UNIX est une marque déposée d'The Open Group.

Ce logiciel ou matériel et la documentation qui l'accompagne peuvent fournir des informations ou des liens donnant accès à des contenus, des produits et des services émanant de tiers. Oracle Corporation et ses affiliés déclinent toute responsabilité ou garantie expresse quant aux contenus, produits ou services émanant de tiers. En aucun cas, Oracle Corporation et ses affiliés ne sauraient être tenus pour responsables des pertes subies, des coûts occasionnés ou des dommages causés par l'accès à des contenus, produits ou services tiers, ou à leur utilisation.



Adobe PostScript

Contents

Using This Documentation ix

Understanding System Administration Resources 1

- Oracle ILOM Overview 1
- Platform-Specific Oracle ILOM Features 2
- Oracle Solaris OS Overview 3
- OpenBoot Overview 4
- Oracle VM Server for SPARC Overview 4
- Multipathing Software 5
- Hardware Management Pack Overview 6
- Source for Downloading Hardware Management Pack Software 7
- Hardware Management Pack Documentation 7

Accessing the Server 9

- ▼ Log In to Oracle ILOM 9
- ▼ Log In to the System Console 10
- ▼ Display the ok Prompt 11
- ▼ Display the Oracle ILOM -> Prompt 12
- ▼ Use a Local Graphics Monitor 13
- Oracle ILOM Remote Console 14

Controlling the Server 15

- ▼ Power On the Server (Oracle ILOM) 15

- ▼ Power Off the Server (Oracle ILOM) 16
- ▼ Reset the Server (Oracle Solaris OS) 17
- ▼ Reset the Server (Oracle ILOM) 17
- ▼ Reset the SP to Default Values 18

Configuring Hardware RAID 19

- Hardware RAID Support 19
- Important Hardware RAID Guidelines 21
- ▼ Prepare to Use the FCode Utility 21
- FCode Utility Commands 23
- ▼ Create a Hardware RAID Volume 23
- Hot Spare Drives in RAID Volumes (LSI) 24
- Determining If a Drive Has Failed 25
 - Service Required Drive LEDs 25
 - Error Messages (System Console and Log Files) 25
 - ▼ Display Status (show-volumes Command, OBP) 26
 - ▼ Display Status (sas2ircu Utility, LSI) 27
- RAID Drive Replacement Strategies 27
- ▼ Locate Device Paths 28

Changing Server Identification Information 31

- ▼ Change Customer Data on FRU PROMs 31
- ▼ Change System Identifier Information 32

Configuring Policy Settings 33

- ▼ Specify Cooldown Mode 33
- ▼ Restore the Host Power State at Restart 34
- ▼ Specify the Host Power State at Restart 34
- ▼ Disable or Re-Enable the Host Power-On Delay 35
- ▼ Specify Parallel Boot of the SP and Host 36

- ▼ Configure Host Behavior (Keyswitch State) 36

Configuring Network Addresses 39

SP Network Address Options 39

- ▼ Disable or Re-Enable Network Access to the SP 40
- ▼ Display the DHCP Server IP Address 40
- ▼ Display the IP Address of the SP 41
- ▼ Display the Host MAC Address 42

Using an In-band Connection to the SP 43

Oracle ILOM In-band (Sideband) Management 43

- ▼ Configure SP In-band (Sideband) Access 44

Configuring Boot Mode 47

Boot Mode Overview 47

- ▼ Configure the Host Boot Mode (Oracle VM Server for SPARC) 48
- ▼ Change the Host Boot Mode Behavior at Reset 49
- ▼ Manage the Host Boot Mode Script 50
- ▼ Display Host Boot Mode Expiration Date 51
- ▼ Override OBP Settings to Reset the Server 51

Configuring Server Behavior at Restart 53

- ▼ Specify Behavior When the Host Resets 53
- ▼ Specify Behavior When the Host Stops Running 54
- ▼ Set the Boot Timeout Interval 54
- ▼ Specify Behavior at Boot Timeout 55
- ▼ Specify Behavior if Restart Fails 55
- ▼ Specify Maximum Restart Attempts 56

Configuring Devices 57

- ▼ Unconfigure a Device Manually 57

- ▼ Reconfigure a Device Manually 57

Monitoring the Server 59

Monitoring Faults 59

Diagnostics Overview 59

- ▼ Discover Faults (Oracle ILOM) 61
- ▼ Discover Faults (Oracle ILOM Fault Management Shell) 61
- ▼ Discover Faults Using POST 63
- ▼ Display Console History 63
- ▼ Repair a Fault (Oracle ILOM Fault Management Shell) 65
- ▼ Clear a Fault 66

Enabling Automatic System Recovery 67

Automatic System Recovery Overview 67

- ▼ Enable ASR 68
- ▼ Disable ASR 68
- ▼ View Information on Components Affected by ASR 69
- ▼ Display Server Components 69
- ▼ Locate the Server 70

Updating the Firmware 73

- ▼ Display the Firmware Version 73
- ▼ Update the Firmware 73
- ▼ Display OpenBoot Version 76
- ▼ Display POST Version 76

Identifying WWN-Designated SAS2 Devices 79

World Wide Name Syntax 79

Mapping WWN Values to Hard Drives (OBP `probe-scsi-all` Command) 80

`probe-scsi-all` WWN Mapping Overview 81

probe-scsi-all WWN Mapping Example (SPARC T4-1)	82
probe-scsi-all WWN Mapping Example (Netra SPARC T4-1)	85
probe-scsi-all WWN Mapping Example (SPARC T4-2)	87
probe-scsi-all WWN Mapping Example (Netra SPARC T4-2)	90
probe-scsi-all WWN Mapping Example (SPARC T4-4 With Four CPUs)	92
probe-scsi-all WWN Mapping Example (SPARC T4-4 With Two CPUs)	95
probe-scsi-all WWN Mapping Example (SPARC T4-1B and Netra SPARC T4-1B)	98
▼ Identify a Disk Slot Using prtconf (Oracle Solaris OS)	100
WWN Syntax in an OS Installation on an Individual Drive	104
WWN Syntax in an OS Installation on a RAID Volume	105

Glossary 107

Index 113

Using This Documentation

This administration guide is for system administrators of servers in the Oracle SPARC T4 server series. The guide includes general descriptive information about the server, and detailed instructions for configuring and administering the server. To use the information in this document, you must have working knowledge of computer network concepts and terms, and advanced familiarity with the Oracle Solaris Operating System (Oracle Solaris OS).

Note – The *SPARC T4 Series Servers Administration Guide* applies to several server and server module products. Specific examples used in this document are based on one of these servers. Your output may vary from the examples based on your product.

- “Related Documentation” on page ix
- “Feedback” on page x
- “Support and Accessibility” on page x

Related Documentation

Documentation	Links
All Oracle products	http://www.oracle.com/documentation

Documentation	Links
Oracle Solaris OS and other systems software	http://www.oracle.com/technetwork/indexes/documentation/index.html#sys_sw
Oracle Integrated Lights Out Manager (ILOM) 3.0	http://www.oracle.com/pls/topic/lookup?ctx=ilom30
Oracle VTS 7.0	http://www.oracle.com/pls/topic/lookup?ctx=OracleVTS7.0

Feedback

Provide feedback on this documentation at:

<http://www.oracle.com/goto/docfeedback>

Support and Accessibility

Description	Links
Access electronic support through My Oracle Support	http://support.oracle.com For hearing impaired: http://www.oracle.com/accessibility/support.html
Learn about Oracle's commitment to accessibility	http://www.oracle.com/us/corporate/accessibility/index.html

Understanding System Administration Resources

These topics provide a summary of common tools used to administer the server.

- [“Oracle ILOM Overview” on page 1](#)
- [“Platform-Specific Oracle ILOM Features” on page 2](#)
- [“Oracle Solaris OS Overview” on page 3](#)
- [“OpenBoot Overview” on page 4](#)
- [“Oracle VM Server for SPARC Overview” on page 4](#)
- [“Multipathing Software” on page 5](#)
- [“Hardware Management Pack Overview” on page 6](#)

Oracle ILOM Overview

Oracle Integrated Lights Out Manager (Oracle ILOM) is system management firmware that is preinstalled on some SPARC servers. Oracle ILOM enables you to actively manage and monitor components installed in your server. Oracle ILOM provides a browser-based interface and a command-line interface, as well as SNMP and IPMI interfaces.

The ILOM service processor runs independently of the server and regardless of the server power state as long as AC power is connected to the server (or to the modular system that contains the server module). When you connect your server to AC power, the ILOM service processor immediately starts up and begins monitoring the server. All environmental monitoring and control are handled by Oracle ILOM.

The `->` prompt indicates that you are interacting with the Oracle ILOM SP directly. This prompt is the first prompt you see when you log in to the server through the SER MGT port or NET MGT port, regardless of the host's power state. On a modular system, that prompt is also present when you log in to a server module either directly or through Oracle ILOM on the CMM of the modular system.

You can also access the ILOM service processor prompt (->) from the OpenBoot ok prompt, or from the Oracle Solaris # or % prompt, provided the system console is configured to be accessible through the SER MGT and NET MGT ports.

The ILOM service processor supports a total of ten concurrent sessions per server: nine SSH or web connections are available through the NET MGT port and one connection is available through the SER MGT port.

For more information about how to work with Oracle ILOM features that are common to all platforms managed by Oracle ILOM, see the Oracle ILOM documentation at:

<http://www.oracle.com/pls/topic/lookup?ctx=ilom30>

Related Information

- “Platform-Specific Oracle ILOM Features” on page 2
- “Log In to Oracle ILOM” on page 9

Platform-Specific Oracle ILOM Features

Oracle ILOM operates on many platforms, supporting features that are common to all platforms. Some Oracle ILOM features belong to only a subset of platforms. This topic describes the difference between Oracle ILOM features supported on the SPARC T4 series servers and the common set of features described in the Oracle ILOM 3.0 base documentation.

Note – To perform some procedures documented in Oracle’s ILOM 3.0 base documentation, you must create a serial connection to the server and activate the Physical Presence switch on the server. For information about creating a serial connection, see the installation guide for your server.

Among the Oracle ILOM features supported on other platforms, Oracle ILOM does *not* support the following features on the SPARC T4 rack-mount servers:

- Chassis monitoring module (CMM) features, such as single signon.

Note – The T4-1B blade servers in a modular system do support the CMM features.

- The POST diagnostics `user-reset` trigger is not available.

Oracle ILOM supports the following feature on this server, which may not be available on other platforms:

- POST diagnostics `hw-change` trigger. This new trigger (`hw-change error-reset`) is the *default setting* for the server, and causes POST to run each time the server is AC power-cycled, or the top cover is removed (if applicable). For more information on POST, see the service manual for your server.

Related Information

- [“Oracle ILOM Overview” on page 1](#)

Oracle Solaris OS Overview

The Oracle Solaris OS includes commands and other software resources to use for server administration. For an introduction to these management tools see one of the following manuals in the documentation collection for your Oracle SolarisOS release:

Oracle Solaris 11 OS	<i>Oracle Solaris Administration: Common Tasks</i>
Oracle Solaris 10 8/11 OS	<i>Oracle Solaris Administration: Basic Administration</i>

Oracle Solaris software includes SunVTS software. SunVTS tests and validates Oracle hardware by verifying the connectivity and functionality of hardware devices, controllers and peripherals.

In addition to the SunVTS information in the Oracle Solaris documentation, SunVTS documentation collections are available at:

<http://www.oracle.com/pls/topic/lookup?ctx=OracleVTS7.0>

Related Information

- [“OpenBoot Overview” on page 4](#)

OpenBoot Overview

The OpenBoot firmware starts the OS, validates installed hardware, and can be used for other server administration tasks below the OS level. For more information about OpenBoot commands, see the *OpenBoot 4.x Command Reference Manual* in the Oracle Solaris 11 documentation collection.

Related Information

- [“Oracle Solaris OS Overview” on page 3](#)

Oracle VM Server for SPARC Overview

A *logical domain* is a discrete logical grouping with its own operating systems, resources, and identity within a single computer system. Application software can run in logical domains. Each logical domain can be created, destroyed, reconfigured, and rebooted independently.

Oracle VM Server for SPARC software enables you to create and manage as many as 32 logical domains, depending on the hardware configuration of the server on which the Oracle VM Server for SPARC Manager has been installed. You can virtualize resources and define network, storage, and other I/O devices as services that can be shared between domains.

The Oracle VM Server for SPARC configurations are stored on the SP. Using Oracle VM Server for SPARC CLI commands, you can add a configuration, specify a configuration to be used, and list the configurations on the SP. You can also use the Oracle ILOM `set /HOST/bootmode config=configfile` command to specify an Oracle VM Server boot configuration.

Related Information

- [“Configuring Boot Mode” on page 47](#)
- Oracle VM Server for SPARC documentation

<http://www.oracle.com/technetwork/documentation/vm-sparc-194287.html>

Multipathing Software

Multipathing software enables you to define and control redundant physical paths to I/O devices such as storage devices and network interfaces. If the active path to a device becomes unavailable, the software can automatically switch to an alternate path to maintain availability. This capability is known as *automatic failover*. To take advantage of multipathing capabilities, you must configure the server with redundant hardware, such as redundant network interfaces or two host bus adapters connected to the same dual-ported storage array.

For the SPARC T4 series servers, three different types of multipathing software are available:

- Oracle Solaris IP Network Multipathing software provides multipathing and load-balancing capabilities for IP network interfaces. includes commands and other software resources to use for server administration. For instructions on how to configure and administer Oracle Solaris IP Network Multipathing see one of the following manuals in the documentation collection for your Oracle SolarisOS release:

Oracle Solaris 11 OS	<i>Oracle Solaris Administration: Network Services and Network Virtualization</i>
Oracle Solaris 10 8/11 OS	<i>System Administration Guide: IP Services</i>

- VVM software includes a feature called DMP, which provides disk multipathing as well as disk load balancing to optimize I/O throughput. For information about VVM and its DMP feature, refer to the documentation provided with the VERITAS Volume Manager software.
- StorageTek Traffic Manager is an architecture fully integrated within the Oracle Solaris OS (beginning with the Oracle Solaris 8 release) that enables I/O devices to be accessed through multiple host controller interfaces from a single instance of the I/O device. For information about StorageTek Traffic Manager, refer to your Oracle Solaris OS documentation.

Related Information

- [“Oracle Solaris OS Overview” on page 3](#)
- [“Oracle VM Server for SPARC Overview” on page 4](#)

Hardware Management Pack Overview

The Hardware Management Pack (HMP) from Oracle provides tools you can use to manage and configure Oracle servers from the host operating system. To use these tools, you must install the HMP software on your server. After installing the software, you will be able to perform the following server management tasks described in the following table.

TABLE: Hardware Management Pack -- Server Management Tasks

Server Management Task From Host OS*	Hardware Management Pack Implementation	Tool
Monitor Oracle hardware with host IP address	Use the Hardware Management Agent and the associated Simple Network Management Protocol (SNMP) plug-ins at the operating-system level to enable in-band monitoring of your Oracle hardware. This in-band monitoring functionality enables you to use your host operating system IP address to monitor your Oracle servers without the need of connecting the Oracle ILOM management port to your network.	Host OS-level management tool
Monitor storage devices, including RAID arrays	Use the Server Storage Management Agent at the operating-system level to enable in-band monitoring of the storage devices configured on your Oracle servers. The Server Storage Management Agent provides an operating-system daemon that gathers information about your server's storage devices, such as hard disk drives (HDDs) and RAID arrays, and sends this information to the Oracle ILOM SP. The Storage Monitoring features in Oracle ILOM enable you to view and monitor the information provided by the Server Storage Management Agent. You can access the Storage Monitoring features in Oracle ILOM from the command-line interface (CLI).	Oracle ILOM 3.0 CLI Storage Monitoring features
Query, update, and validate firmware versions on supported SAS storage devices	Use the fwupdate CLI tool from the host operating system to query, update, and validate firmware versions on supported storage devices such as SAS host bus adapters (HBAs), embedded SAS storage controllers, LSI SAS storage expanders, and disk drives.	Host OS-level fwupdate CLI

TABLE: Hardware Management Pack -- Server Management Tasks *(Continued)*

Server Management Task From Host OS*	Hardware Management Pack Implementation	Tool
Restore, set, and view Oracle Oracle ILOM configuration settings	Use the <code>ilomconfig</code> CLI tool from the host operating system to restore Oracle ILOM configuration settings, as well as to view and set Oracle ILOM properties associated with network management, clock configuration, and user management.	Host OS-level <code>ilomconfig</code> CLI
View or create RAID volumes on storage drives	Use the <code>raidconfig</code> CLI tool from the host operating system to view and create RAID volumes on storage drives that are attached to RAID controllers, including storage arrays.	Host OS-level <code>raidconfig</code> CLI
Use IPMItool to access and manage Oracle servers	Use the open source command-line IPMItool from the host operating system to access and manage your Oracle servers via the IPMI protocol.	Host OS-level command-line IPMItool

* Supported host operating systems include: Oracle Solaris, Linux, Windows, and VMware

Source for Downloading Hardware Management Pack Software

You can download the Hardware Management Pack software from the following location:

<http://support.oracle.com>

Hardware Management Pack Documentation

You can download Hardware Management Pack documentation from the following location:

<http://www.oracle.com/pls/topic/lookup?ctx=ohmp>

For additional details about how to use the Storage Monitoring features in Oracle ILOM, see the *Oracle Integrated Lights Out Manager (ILOM) 3.0 Daily Management -- Concepts Guide* and the *Oracle Integrated Lights Out Manager (ILOM) 3.0 Daily Management -- CLI Procedures Guide*.

For additional details about accessing and managing your server via SNMP or IPMI, see the *Oracle Integrated Lights Out Manager (ILOM) 3.0 SNMP, IPMI, CIM, WS-MAN, Protocol Management Reference*.

Links to these Oracle ILOM manuals are provided on the web site shown above. You can find the complete set of Oracle ILOM documentation at this location:

<http://www.oracle.com/pls/topic/lookup?ctx=ilom30>

Accessing the Server

These topics include information on establishing low-level communication with the server using the Oracle ILOM tool and the system console.

- “Log In to Oracle ILOM” on page 9
- “Log In to the System Console” on page 10
- “Display the ok Prompt” on page 11
- “Display the Oracle ILOM -> Prompt” on page 12
- “Use a Local Graphics Monitor” on page 13
- “Oracle ILOM Remote Console” on page 14

▼ Log In to Oracle ILOM

This procedure assumes the default configuration of the SP as described in your server’s installation guide.

Note – For a SPARC T4 server module, you can either log in directly to the modular server’s SP or you can start Oracle ILOM through the chassis’ CMM. Refer to the modular server’s installation guide for instructions on both approaches.

- Open an SSH session and connect to the SP by specifying its IP address.

The Oracle ILOM default username is *root* and the default password is *changeme*.

```
% ssh root@xxx.xxx.xxx.xxx
...
Are you sure you want to continue connecting (yes/no) ? yes
...
Password: password (nothing displayed)

Integrated Lights Out Manager

Version 3.0.16.3 r66969

Copyright 2011 Oracle and/or its affiliates. All rights reserved.

->
```

You are now logged in to Oracle ILOM. Perform tasks as needed.

Note – To provide optimum server security, change the default server password.

Related Information

- [“Oracle ILOM Overview” on page 1](#)
- [“Log In to the System Console” on page 10](#)

▼ Log In to the System Console

- At the Oracle ILOM *->* prompt, type:

```
-> start /HOST/console [-option]
Are you sure you want to start /HOST/console (y/n) ? y
Serial console started. To stop, type #.
.
.
.
```

where *option* can be:

- **-f** | **force** – Enables a user with a Console (c) role to take the console from any current user and force that user into view mode.

- -script – Bypasses the prompt for a yes or no confirmation.

Note – If the Oracle Solaris OS is not running, the server displays the ok prompt.

Related Information

- “Display the Oracle ILOM -> Prompt” on page 12
- “Use a Local Graphics Monitor” on page 13
- “Log In to Oracle ILOM” on page 9

▼ Display the ok Prompt

This procedure assumes the default system console configuration.

- **Choose the appropriate shutdown method from the following table to reach the ok prompt.**

Note – To ensure getting to the ok prompt, set the following Oracle ILOM property before performing the procedures below:

-> **set /HOST/bootmode script="setenv auto-boot? false"**



Caution – When possible, reach the ok prompt by performing a graceful shutdown of the OS. Any other method used might result in the loss of server state data.

Server State	What To Do
OS running and responsive	<p>Shut down the server beginning at the host prompt:</p> <p>From a shell or command tool window, type an appropriate command (for example, the <code>shutdown</code> or <code>init 0</code> command) as described in the Oracle Solaris system administration documentation.</p> <p>Then take one of the following steps:</p> <ul style="list-style-type: none"> • At the Oracle ILOM prompt, type: -> stop /SYS • Use the server Power button.
OS unresponsive	<p>Disable autoboot and then reset the host.</p> <p>(Provided the operating system software is not running and the server is already under OpenBoot firmware control.)</p> <p>At the Oracle ILOM prompt, type:</p> <pre>-> set /HOST send_break_action=break</pre> <p>Press Enter.</p> <p>Then type:</p> <pre>-> start /HOST/console</pre>
OS unresponsive and need to prevent auto-boot	<p>Shut down the server from Oracle ILOM and disable autoboot.</p> <p>At the Oracle ILOM prompt, type:</p> <pre>-> set /HOST/bootmode script="setenv auto-boot? false"</pre> <p>Press Enter.</p> <p>Then type:</p> <pre>-> reset /SYS</pre> <pre>-> start /HOST/console</pre>

Related Information

- [“Monitoring Faults” on page 59](#)

▼ Display the Oracle ILOM -> Prompt

- Use one of the following ways to display the Oracle ILOM -> prompt:
 - From the system console, type the Oracle ILOM escape sequence (#.).
 - Log in to Oracle ILOM directly from a device connected to the SER MGT port or NET MGT port.
 - Log in to Oracle ILOM through an SSH connection. See [“Log In to Oracle ILOM” on page 9](#).

Related Information

- [“Oracle ILOM Overview” on page 1](#)
- [“Log In to Oracle ILOM” on page 9](#)

▼ Use a Local Graphics Monitor

You can redirect the system console to a local graphic monitor. You *cannot* use a local graphics monitor to perform the initial server installation, nor can you use a local graphics monitor to view POST messages.

To use a local graphics monitor:

1. **Connect the monitor video cable to a video port on the server.**
Tighten the thumbscrews to secure the connection. Refer to your system’s documentation for any special connection instructions that might apply to your server.
2. **Connect the monitor power cord to an AC outlet.**
3. **Connect the USB keyboard cable to one USB port.**
4. **Connect the USB mouse cable to another USB port on the server.**
5. **Display the `ok` prompt.**
See [“Display the `ok` Prompt” on page 11](#).
6. **At the `ok` prompt, set the following OBP configuration variables:**

```
ok setenv input-device keyboard
ok setenv output-device screen
```

7. **Make the changes take effect:**

```
ok reset-all
```

The server stores the parameter changes and boots automatically.

Note – Instead of using the `reset-all` command to store the parameter changes, you can also power cycle the server using the Power button.

You can now type system commands and view system messages using your local graphics monitor. To activate the GUI interface, continue to the next step.

8. Activate the Oracle Solaris OS GUI interface.

Once the Oracle Solaris OS is installed and booted, type the following commands to display the GUI login screen.

```
# ln -s /dev/fbs/ast0 /dev/fb
```

```
# fbconfig -xserver Xorg
```

```
# reboot
```

Related Information

- [“Display the ok Prompt” on page 11.](#)
- [“Oracle ILOM Remote Console” on page 14](#)

Oracle ILOM Remote Console

Oracle ILOM Remote Console is a Java application that enables you to remotely redirect and control the following devices on the host server. This group of devices is commonly abbreviated as KVMS.

- Keyboard
- Video console display
- Mouse
- Serial console display
- Storage devices or images (CD/DVD)

Oracle ILOM Remote Console is documented in the *Oracle Integrated Lights Out Manager (ILOM) 3.0 Daily Management Web Interface Procedures Guide* (“Managing Remote Hosts Redirection and Securing the Oracle ILOM Remote Console”).

Related Information

- [“Oracle ILOM In-band \(Sideband\) Management” on page 43](#)

Controlling the Server

These topics include procedures for controlling basic server operations.

- [“Power On the Server \(Oracle ILOM\)” on page 15](#)
- [“Power Off the Server \(Oracle ILOM\)” on page 16](#)
- [“Reset the Server \(Oracle Solaris OS\)” on page 17](#)
- [“Reset the Server \(Oracle ILOM\)” on page 17](#)
- [“Reset the SP to Default Values” on page 18](#)

▼ Power On the Server (Oracle ILOM)

1. Log in to Oracle ILOM.

[“Log In to Oracle ILOM” on page 9.](#)

Note – If you have a modular system, make sure you are logged in to the desired server module.

2. At the Oracle ILOM -> prompt, type:

```
-> start /SYS
Are you sure you want to start /SYS (y/n) ? y
Starting /SYS

->
```

Note – To skip being prompted for confirmation, use the `start -script /SYS` command.

Related Information

- [“Power Off the Server \(Oracle ILOM\)” on page 16](#)

- “Reset the Server (Oracle Solaris OS)” on page 17
- “Reset the Server (Oracle ILOM)” on page 17

▼ Power Off the Server (Oracle ILOM)

1. Shut down the Oracle Solaris OS.

At the Oracle Solaris prompt, type:

```
# shutdown -g0 -i0 -y
# svc.startd: The system is coming down. Please wait.
svc.startd: 106 system services are now being stopped.
Sep 12 17:52:11 bur381-14 syslogd: going down on signal 15
svc.startd: The system is down.
syncing file systems...done
Program terminated

SPARC T4-1, No Keyboard
Copyright (c) 1998, 2011, Oracle and/or its affiliates. All rights
reserved.
OpenBoot 4.33.1, 32256 MB memory available, Serial #95593628.
Ethernet address 0:21:28:b2:a4:9c, Host ID: 85b2a49c.
{0} ok
```

2. Switch from the system console prompt to the SP console prompt.

```
{0} ok #.
->
```

3. From the Oracle ILOM -> prompt, type:

```
-> stop /SYS
Are you sure you want to stop /SYS (y/n)? y
Stopping /SYS

->
```

Note – To perform an immediate shutdown, use the `stop -force -script /SYS` command. Ensure that all data is saved before typing this command.

Related Information

- [“Power On the Server \(Oracle ILOM\)” on page 15](#)
- [“Reset the Server \(Oracle Solaris OS\)” on page 17](#)
- [“Reset the Server \(Oracle ILOM\)” on page 17](#)

▼ Reset the Server (Oracle Solaris OS)

It is not necessary to power the server off and on to perform a reset.

- To reset the server from the Oracle Solaris prompt, type one of the following commands:

```
# shutdown -g0 -i6 -y
```

or

```
# reboot
```

Related Information

- [“Power Off the Server \(Oracle ILOM\)” on page 16](#)
- [“Power On the Server \(Oracle ILOM\)” on page 15](#)
- [“Reset the Server \(Oracle ILOM\)” on page 17](#)

▼ Reset the Server (Oracle ILOM)

The Oracle ILOM `reset` command generates a graceful or forced hardware reset of the server. By default, the reset command gracefully resets the server.

- Type one of the following commands to reset the server.
 - Perform a graceful reset from Oracle ILOM:

```
-> reset /SYS
```

- If a graceful reset is not possible, perform a forced hardware reset from Oracle ILOM:

```
-> reset -force /SYS
```

Related Information

- [“Power Off the Server \(Oracle ILOM\)” on page 16](#)
- [“Power On the Server \(Oracle ILOM\)” on page 15](#)
- [“Reset the Server \(Oracle Solaris OS\)” on page 17](#)
- [“Override OBP Settings to Reset the Server” on page 51](#)

▼ Reset the SP to Default Values

If your SP becomes corrupt, or you want to reset the SP to the factory default values, change the `/SP reset_to_defaults` setting then power off the host to implement the changes. This is new behavior. Previously you did not have to power off the host to reset default values to the SP. You need administrator permissions to perform this task.

1. To reset the SP to the default values, type:

```
-> set /SP reset_to_defaults=value
```

where *value* can be:

- `all` – Removes all of the SP configuration data.
- `factory` – Removes all SP configuration data as well as all log files.

2. Power off and restart the host to complete the setting change.

```
-> stop /SYS  
-> reset /SP
```

Related Information

- [“Power Off the Server \(Oracle ILOM\)” on page 16](#)

Configuring Hardware RAID

These topics describe how to configure and manage RAID disk volumes using the server's onboard SAS-2 disk controller.

- [“Hardware RAID Support” on page 19](#)
 - [“Prepare to Use the FCode Utility” on page 21](#)
 - [“Create a Hardware RAID Volume” on page 23](#)
 - [“Hot Spare Drives in RAID Volumes \(LSI\)” on page 24](#)
 - [“Determining If a Drive Has Failed” on page 25](#)
 - [“RAID Drive Replacement Strategies” on page 27](#)
 - [“Locate Device Paths” on page 28](#)
-

Hardware RAID Support

In the SPARC and Netra SPARC T4 series servers and blades, hardware RAID support is provided by either onboard SAS2 RAID controllers or pluggable RAID expansion modules (REMs). Both types of controller enable you to create logical disk volumes consisting of two or more redundant disk drives. The following table identifies the type of hardware RAID controller used by each T4 platform.

TABLE: Hardware RAID Support for T4 Series Servers and Server Modules

Platform	Controller Description	Supported RAID Levels
SPARC T4-1	Two onboard SAS2 controllers	0, 1, 1e
SPARC T4-2	One onboard SAS2 controller	0, 1, 1e
SPARC T4-4	Two pluggable SAS2 REMs	0, 1
SPARC T4-1B	One pluggable SAS2 REM	0, 1

TABLE: Hardware RAID Support for T4 Series Servers and Server Modules (*Continued*)

Platform	Controller Description	Supported RAID Levels
Netra SPARC T4-1	Two onboard SAS2 controllers (one not used)	0, 1
Netra SPARC T4-2	One onboard SAS2 controller	0, 1
Netra SPARC T4-1B	One pluggable SAS2 REM	0, 1

Note – Up to two logical volume can be configured on each RAID controller.

There are three sets of RAID management utilities you can use with the onboard SAS2 controllers provided on SPARC T4-1, SPARC T4-2, Netra SPARC T4-1, and Netra SPARC T4-2 servers.

- Fcode utility -- You can use Fcode commands to display targets and manage logical volumes on your server. These commands are accessed through OBP.

The examples shown in this manual rely on Fcode commands.

- Oracle Hardware Management Pack -- You can use the `raidconfig` commands contained in this software's Oracle Server CLI Tools component to create and manage RAID volumes on your server. To use these commands, download and install the Oracle Hardware Management Pack version 2.2 or later. Refer to the *Oracle Hardware Management Pack 2.2 Installation Guide* for instructions.

You can find documentation for the Oracle Hardware Management Pack software at this location:

<http://www.oracle.com/pls/topic/lookup?ctx=ohmp>

- LSI SAS2 2008 RAID Management Utility (`sas2ircu`) -- You can use `sas2ircu` commands (version 6.250.02.00 or later) to manage RAID functionality for the onboard SAS2 controllers.

The `sas2ircu` utility for Oracle's T4-1 and T4-2 servers, together with user documentation, are available on the LSI website:

<http://www.lsi.com/sep/Pages/oracle/index.aspx>

Note – You can download documentation for the REM controllers from:

<http://docs.oracle.com/cd/E19946-01/index.html>



Caution – Firmware updates for the onboard SAS controllers *must* be acquired from Oracle's support site <http://support.oracle.com>. Firmware applied to the onboard SAS controllers from any other location or any vendor other than Oracle is not supported.

Related Information

- [“Create a Hardware RAID Volume” on page 23](#)
- [“Prepare to Use the FCode Utility” on page 21](#)

Important Hardware RAID Guidelines

The following points are important to understand when configuring RAID volumes on a SPARC T4 series server:

- Before configuring and using RAID disk volumes on a SPARC T4 series server, ensure that you have installed the latest patches or SRU available for your operating system. Review the most recent product notes provided for your system for further guidance in keeping your OS up to date.
- Volume migration (relocating all RAID volume disk members from one T4 series server to another) is not supported. If you must perform this operation, contact your authorized Oracle service provider.



Caution – When you create a RAID volume using the on-board disk controllers, all data currently on the disks you include in the volume will be lost.

▼ Prepare to Use the FCode Utility

Perform the following procedure from an `xterm` or an equivalent terminal window that supports scrolling.

Note – FCode commands produce large amounts of detailed output. An `xterm` and `gnome` terminal windows provide scroll bar functionality, which helps view such output.

1. **Either apply power to the system or reset the system if power is already present and disable auto-boot in OBP.**
See [“Display the ok Prompt” on page 11](#).
2. **Enter the OBP environment.**

3. Use the `show-devs` command to list the device paths on the server.

```
{0} ok show-devs
...
/pci@400/pci@1/pci@0/pci@4/scsi@0
/pci@400/pci@2/pci@0/pci@4/scsi@0
...
```

Note – For a server module, the device path might be
`/pci@400/pci@1/pci@0/pci@2/LSI,sas@0`.

4. Use the `select` command to choose the controller where you want to create a hardware RAID volume. For example, on the SPARC T4-1:

```
{0} ok select /pci@400/pci@2/pci@0/pci@4/scsi@0
```

Note – The device path in the above example is not valid for all SPARC T4 series servers.

Instead of using the entire device path for the controller, you can use a preconfigured alias for a controller. For example:

```
{0} ok select scsi_alias
```

where *scsi_alias* corresponds to the preconfigured alias for your path.

Note – To view the preconfigured aliases on your server, use the `devalias` command. See [“Locate Device Paths” on page 28](#).

Display the SAS addresses of any connected drives using the `show-children` command.

Related Information

- [“Display the ok Prompt” on page 11](#)
- [“FCCode Utility Commands” on page 23](#)
- [“Locate Device Paths” on page 28](#)

FCode Utility Commands

FCode Command	Description
show-children	Lists all connected physical drives and logical volumes.
show-volumes	Lists all connected logical volumes in detail.
create-raid0-volume	Creates a RAID 0 volume (minimum two targets).
create-raid1-volume	Creates a RAID 1 volume (exactly two targets).
create-raidle-volume	Creates a RAID 1e volume (minimum three targets).
delete-volume	Deletes a RAID volume.
activate-volume	Re-activate a RAID volume after the motherboard has been replaced.

Related Information

- [“Create a Hardware RAID Volume” on page 23](#)
- [“Prepare to Use the FCode Utility” on page 21](#)

▼ Create a Hardware RAID Volume

1. **Prepare to create a RAID volume.**
See [“Prepare to Use the FCode Utility” on page 21](#).
2. **Use the `show-children` command to list the physical drives on the selected controller.**

```
{0} ok show-children
```

```
FCode Version 1.00.54, MPT Version 2.00, Firmware Version 5.00.17.00
```

```
Target 9
```

```
Unit 0 Disk SEAGATE ST930003SSUN300G 0B70 585937500 Blocks, 300 GB
```

```
SASDeviceName 5000c5001771776f SASAddress 5000c5001771776d PhyNum 0
```

```
Target a
```

```
Unit 0 Disk SEAGATE ST930003SSUN300G 0B70 585937500 Blocks, 300 GB
```

```
SASDeviceName 5000c5001d0c38c7 SASAddress 5000c5001d0c38c5 PhyNum 1
Target b
Unit 0 Disk SEAGATE ST930003SSUN300G 0B70 585937500 Blocks, 300 GB
SASDeviceName 5000c5001d097407 SASAddress 5000c5001d097405 PhyNum 2
Target c
Unit 0 Disk SEAGATE ST930003SSUN300G 0B70 585937500 Blocks, 300 GB
SASDeviceName 5000c5001d09a51f SASAddress 5000c5001d09a51d PhyNum 3
{0} ok
```

3. Use the `create-raid0-volume`, `create-raid1-volume`, or `create-raid1e-volume` command to create a logical drive from the physical disks.

For example, to create a RAID 0 volume with targets 9 and a, type the targets first then type the create command:

```
{0} ok 9 a create-raid0-volume
```

For example, to create a RAID 1e volume with targets a, b, and c, type:

```
{0} ok a b c create-raid1e-volume
```

4. To verify creation of the volume, type:

```
{0} ok show-volumes
```

5. Type `unselect-dev` to deselect the controller.

```
{0} ok unselect-dev
```

Related Information

- [“FCode Utility Commands” on page 23](#)
- [“Display the ok Prompt” on page 11](#)

Hot Spare Drives in RAID Volumes (LSI)

You can configure two global hot spare drives to protect data on mirrored RAID volumes. If one of the drives in a RAID 1 or RAID 1E mirrored volume fails, the onboard RAID controller will replace the failed drive automatically with a hot spare drive and then resynchronize the mirrored data.

Use the `sas2ircu` LSI utility to add global hot spare drives or HMP. Refer to the *SAS2 Integrated RAID Solution User Guide* for more information about adding hot spare drives.

Determining If a Drive Has Failed

These topics explain various ways to determine if a drive contained in a RAID volume has failed:

- [“Service Required Drive LEDs” on page 25](#)
- [“Error Messages \(System Console and Log Files\)” on page 25](#)
- [“Display Status \(show-volumes Command, OBP\)” on page 26](#)
- [“Display Status \(sas2ircu Utility, LSI\)” on page 27](#)

Service Required Drive LEDs

When a fault occurs on a drive in a SPARC T4 system, the amber Service Required LED will light on the front of the drive. This amber LED will allow you to locate the faulted drive in the system. Additionally, the front and rear panel Service Action Required LEDs also light when the system detects a hard drive fault. Refer to your service manual for the location and description of these LEDs.

Error Messages (System Console and Log Files)

When a fault occurs on a drive, error messages will be displayed on the system console. This is an example of a system console display indicating that volume 905 has been degraded with the loss of PhysDiskNum 1:

```
Mar 16 16:28:26 hostname scsi: /pci@400/pci@2/pci@0/pci@e/scsi@0 (mpt_sas0):
Mar 16 16:28:26 hostname      PhysDiskNum 1 with DevHandle 0xc in slot 0 for
enclosure with handle 0x0 is now offline
Mar 16 16:28:26 hostname scsi: /pci@400/pci@2/pci@0/pci@e/scsi@0 (mpt_sas0):
Mar 16 16:28:26 hostname      PhysDiskNum 1 with DevHandle 0xc in slot 0 for
enclosure with handle 0x0 is now , active, out of sync
Mar 16 16:28:26 hostname scsi: WARNING: /pci@400/pci@2/pci@0/pci@e/scsi@0
(mpt_sas0):
Mar 16 16:28:26 hostname      Volume 905 is degraded
Mar 16 16:28:26 hostname scsi: /pci@400/pci@2/pci@0/pci@e/scsi@0 (mpt_sas0):
```

```
Mar 16 16:28:26 hostname      Volume 0 is now degraded
Mar 16 16:28:26 hostname scsi: WARNING: /pci@400/pci@2/pci@0/pci@e/scsi@0
(mpt_sas0):
Mar 16 16:28:26 hostname      Volume 905 is degraded
```

You can also view these messages by reviewing the `/var/adm/messages` files:

```
# more /var/adm/messages*
. . .
Mar 16 16:45:19 hostname SC Alert: [ID 295026 daemon.notice] Sensor | minor:
Entity Presence : /SYS/SASBP/HDD3/PRSNT : Device Absent
Mar 16 16:45:19 hostname scsi: [ID 107833 kern.notice]
/pci@400/pci@2/pci@0/pci@e/scsi@0 (mpt_sas0):
Mar 16 16:45:19 hostname PhysDiskNum 0 with DevHandle 0xd in slot 0 for enclosure
with handle 0x0 is now offline
Mar 16 16:45:19 hostname scsi: [ID 107833 kern.notice]
/pci@400/pci@2/pci@0/pci@e/scsi@0 (mpt_sas0):
Mar 16 16:45:19 hostname PhysDiskNum 0 with DevHandle 0xd in slot 0 for enclosure
with handle 0x0 is now , active, out of sync
Mar 16 16:45:19 hostname scsi: [ID 107833 kern.warning] WARNING:
/pci@400/pci@2/pci@0/pci@e/scsi@0 (mpt_sas0):
Mar 16 16:45:19 hostname Volume 905 is degraded
Mar 16 16:45:19 hostname scsi: [ID 107833 kern.notice]
/pci@400/pci@2/pci@0/pci@e/scsi@0 (mpt_sas0):
Mar 16 16:45:19 hostname Volume 0 is now degraded
Mar 16 16:45:19 hostname scsi: [ID 107833 kern.warning] WARNING:
/pci@400/pci@2/pci@0/pci@e/scsi@0 (mpt_sas0):
Mar 16 16:45:19 hostname Volume 905 is degraded
```

Refer to the *View the System Message Log Files* topic in your service manual for more information about examining these messages.

▼ Display Status (show-volumes Command, OBP)

You can halt the system and use the show-volumes OBP command to determine if a drive has failed.

1. Halt the system and display the OBP `ok` prompt.

See [“Display the ok Prompt” on page 11](#).

2. Select the SAS controller device.

```
ok select /pci@400/pci@2/pci@0/pci@e/scsi@0
```

See “Prepare to Use the FCode Utility” on page 21 for more information.

3. Type the `show-volumes` command to display the RAID volumes and their associated disks.

In the following example, the secondary disk in a RAID 1 volume is offline.

```
ok show-volumes
Volume 0 Target 389   Type RAID1 (Mirroring)
  Name raid1test   WWID 04eec3557b137f31
  Degraded   Enabled
  2 Members
  Disk 1
    Primary Optimal
    Target c   HITACHI   H101414SCSUN146G SA25
  Disk 0
    Secondary Offline Out Of Sync
    Target 0   SEAGATE
```

4. Type the `unselect-dev` command to deselect the SAS controller device.

```
ok unselect-dev
```

▼ Display Status (sas2ircu Utility, LSI)

- Use the LSI `sas2ircu` utility to display the status of the RAID volume and its associated drives.

Refer to the *SAS2 Integrated RAID Solution User Guide* for more information about displaying and interpreting device status using the `sas2ircu` utility.

RAID Drive Replacement Strategies

Follow the strategies described below when replacing a failed drive in a RAID volume.

RAID Volume Level	Strategy
RAID 0	If a drive fails in a RAID 0 volume, you will lose all data on that volume. Replace the failed drive with a new drive of the same capacity, recreate the RAID 0 volume, and restore the data from a backup.
RAID 1	Remove the failed drive and replace it with a new drive of the same capacity. The new drive will be automatically configured and synced with the RAID volume.
RAID 1E	Remove the failed drive and replace it with a new drive of the same capacity. The new drive will be automatically configured and synced with the RAID volume.

Note – The `cfgadm` instructions in the service manual are for individual drives that are not part of RAID volumes. When a drive is part of a RAID volume, you do not need to unconfigure it before hot swapping it with a new drive.

▼ Locate Device Paths

Use this procedure to locate device paths specific to your server.

1. Display the `ok` prompt.

See “[Display the `ok` Prompt](#)” on page 11.

2. From the `ok` prompt, type:

Note – This example represents `devalias` output for a sample T4-x server. The specific devices displayed will differ for different products.

```
{0} ok devalias
screen                /pci@400/pci@2/pci@0/pci@0/pci@0/display@0
mouse                 /pci@400/pci@2/pci@0/pci@f/pci@0/usb@0,2/hub@2/device@4
/mouse@1
rcdrom                /pci@400/pci@2/pci@0/pci@f/pci@0/usb@0,2/hub@2/hub@3
/storage@2/disk@0
rkeyboard              /pci@400/pci@2/pci@0/pci@f/pci@0/usb@0,2/hub@2/device@4
/keyboard@0
rscreen                /pci@400/pci@2/pci@0/pci@0/pci@0/display@0:r1280x1024x60
```

```

net3          /pci@400/pci@2/pci@0/pci@7/network@0,1
net2          /pci@400/pci@2/pci@0/pci@7/network@0
net1          /pci@400/pci@2/pci@0/pci@6/network@0,1
net0          /pci@400/pci@2/pci@0/pci@6/network@0
net           /pci@400/pci@2/pci@0/pci@6/network@0
disk7         /pci@400/pci@2/pci@0/pci@4/scsi@0/disk@p3
disk6         /pci@400/pci@2/pci@0/pci@4/scsi@0/disk@p2
disk5         /pci@400/pci@2/pci@0/pci@4/scsi@0/disk@p1
disk4         /pci@400/pci@2/pci@0/pci@4/scsi@0/disk@p0
cdrom         /pci@400/pci@2/pci@0/pci@4/scsi@0/disk@p6
scsi1         /pci@400/pci@2/pci@0/pci@4/scsi@0
disk3         /pci@400/pci@1/pci@0/pci@4/scsi@0/disk@p3
disk2         /pci@400/pci@1/pci@0/pci@4/scsi@0/disk@p2
disk1         /pci@400/pci@1/pci@0/pci@4/scsi@0/disk@p1
disk0         /pci@400/pci@1/pci@0/pci@4/scsi@0/disk@p0
disk          /pci@400/pci@1/pci@0/pci@4/scsi@0/disk@p0
scsi0         /pci@400/pci@1/pci@0/pci@4/scsi@0
scsi          /pci@400/pci@1/pci@0/pci@4/scsi@0
virtual-console /virtual-devices@100/console@1
name          aliases
{0} ok

```

Related Information

- [“Display the ok Prompt” on page 11](#)
- [“Prepare to Use the FCode Utility” on page 21](#)

Changing Server Identification Information

These topics describe how to store information (for purposes such as inventory control or site resource management) on the SP and FRU PROMs using the Oracle ILOM CLI interface.

- [“Change Customer Data on FRU PROMs” on page 31](#)
- [“Change System Identifier Information” on page 32](#)

▼ Change Customer Data on FRU PROMs

Use the `/SP customer_frudata` property to store information in all FRU PROMs. This field can be used to identify a particular system to a third-party application, or for any other identification needs in your environment.

- At the Oracle ILOM -> prompt, type:

```
-> set /SP customer_frudata="data"
```

Note – You must enclose the data string (*data*) in quote marks.

Related Information

- [“Log In to Oracle ILOM” on page 9](#)
- [“Change System Identifier Information” on page 32](#)

▼ Change System Identifier Information

Use the `/SP system_identifier` property to store customer identification information. This string is encoded in all trap messages generated by SNMP. Assigning a unique system identifier can be useful in distinguishing which system generates which SNMP message.

- At the Oracle ILOM -> prompt, type:

```
-> set /SP system_identifier="data"
```

Note – The data string (*data*) must be enclosed in quote marks.

Related Information

- [“Log In to Oracle ILOM” on page 9](#)
- [“Change Customer Data on FRU PROMs” on page 31](#)

Configuring Policy Settings

These topics describe managing configuration policies using Oracle ILOM.

- [“Specify Cooldown Mode” on page 33](#)
- [“Restore the Host Power State at Restart” on page 34](#)
- [“Specify the Host Power State at Restart” on page 34](#)
- [“Disable or Re-Enable the Host Power-On Delay” on page 35](#)
- [“Specify Parallel Boot of the SP and Host” on page 36](#)
- [“Configure Host Behavior \(Keyswitch State\)” on page 36](#)

▼ Specify Cooldown Mode

Some SPARC T4 systems support the host cooldown mode, but not all. Setting the `HOST_COOLDOWN` property to enabled causes the server to enter cooldown mode while the host is powering off. The cooldown mode directs Oracle ILOM to monitor certain components to ensure that they are below a minimum temperature so as not to cause harm to the user if internal components are accessed.

Once the components are below the threshold temperature, power is removed from the server, which allows the cover interlock switch to release. If the monitored temperatures take longer than 4 minutes to reach the threshold, the host tuns off.

- **At the Oracle ILOM -> prompt, type:**

```
-> set /SP/policy HOST_COOLDOWN=value
```

where *value* can be:

- `enabled` – Server cools certain components before powering off.
- `disabled` – Component temperatures are not monitored during power off.

Related Information

- [“Power Off the Server \(Oracle ILOM\)” on page 16](#)

▼ Restore the Host Power State at Restart

Use the `/SP/policy HOST_LAST_POWER_STATE` property to control the behavior of the server after an unexpected power outage. When external power is restored, the Oracle ILOM SP starts to run automatically. Normally, the host power is not turned on until you use Oracle ILOM to turn it on.

Oracle ILOM records the current power state of the server in nonvolatile storage. If the `HOST_LAST_POWER_STATE` policy is enabled, Oracle ILOM can restore the host to the previous power state. This policy is useful in the event of a power failure, or if you physically move the server to a different location.

For example, if the host server is running when power is lost and the `/SP/policy HOST_LAST_POWER_STATE` property is set to disabled, the host server remains off when power is restored. If the `/SP/policy HOST_LAST_POWER_STATE` property is set to enabled, the host server restarts when the power is restored.

- At the Oracle ILOM -> prompt, type:

```
-> set /SP/policy HOST_LAST_POWER_STATE=enabled
```

where *value* can be:

- enabled – When power is restored, returns the server to the state it was in before the power was removed.
- disabled – Keeps the server off when power is applied (the default).

If you enable `HOST_LAST_POWER_STATE`, you should also configure `/SP/policy HOST_POWER_ON_DELAY`. For further information, see [“Disable or Re-Enable the Host Power-On Delay” on page 35](#).

Related Information

- [“Disable or Re-Enable the Host Power-On Delay” on page 35](#)
- [“Specify the Host Power State at Restart” on page 34](#)

▼ Specify the Host Power State at Restart

Use `/SP/policy HOST_AUTO_POWER_ON` to power on the host when external power is applied to the server. If this policy is set to enabled, the SP sets `HOST_LAST_POWER_STATE` to disabled.

- At the Oracle ILOM -> prompt, type:

```
-> set /SP/policy HOST_AUTO_POWER_ON=value
```

where *value* can be:

- `enabled` – When power is applied, automatically powers on the host when the SP has been booted.
- `disabled` – Keeps the host power off when power is applied (the default).

Related Information

- [“Restore the Host Power State at Restart” on page 34](#)
- [“Disable or Re-Enable the Host Power-On Delay” on page 35](#)

▼ Disable or Re-Enable the Host Power-On Delay

Use the `/SP/policy HOST_POWER_ON_DELAY` property to cause the server to wait for a short time before powering on automatically. The delay is a random interval of one to five seconds. Delaying the server power on helps minimize current surges on the main power source. This power-on delay is important when multiple servers in racks power on after a power outage.

- At the Oracle ILOM -> prompt, type:

```
-> set /SP/policy HOST_POWER_ON_DELAY=value
```

where *value* can be:

- `enabled` – Causes the server to wait for a short time before powering on automatically.
- `disabled` – Server powers on automatically without a delay (the default).

Related Information

- [“Specify the Host Power State at Restart” on page 34](#)

▼ Specify Parallel Boot of the SP and Host

The `/SP/policy PARALLEL_BOOT` property, when enabled, allows the host to boot and power on in parallel with the SP if an auto-power policy (`HOST_AUTO_POWER_ON` or `HOST_LAST_POWER_STATE`) was on or a user presses the power button while the SP is in the process of booting. Oracle ILOM has to be running in order to allow the host to power on when the power button is pressed or the the auto-power policies are set. When this property is set to disabled, the SP boots first, then the host boots.

Note – Parallel boot is not supported on server modules.

- At the Oracle ILOM `->` prompt, type:

```
-> set /SP/policy PARALLEL_BOOT=value
```

where *value* can be:

- enabled – SP and host boot concurrently.
- disabled – SP and host boot serially.

Related Information

- [“Power On the Server \(Oracle ILOM\)” on page 15](#)
- [“Power Off the Server \(Oracle ILOM\)” on page 16](#)

▼ Configure Host Behavior (Keyswitch State)

Use the `/SYS keyswitch_state` property to control the position of the virtual keyswitch.

- At the Oracle ILOM -> prompt, type:

```
-> set /SYS keyswitch_state=value
```

where *value* can be:

- **normal** – The server can power itself on and start the boot process (the default).
- **standby** – Powers off host, disables power on.
- **diag** – Host power on is allowed, it overrides the settings of `/HOST/diag target`, resulting in Max POST being executed.
- **locked** – Host power on is allowed, however, you are prohibited from updating flash devices or setting `/HOST send_break_action=break`.

Related Information

- [“Power On the Server \(Oracle ILOM\)” on page 15](#)
- [“Power Off the Server \(Oracle ILOM\)” on page 16](#)

Configuring Network Addresses

These topics describe managing network addresses with Oracle ILOM.

- [“SP Network Address Options” on page 39](#)
- [“Disable or Re-Enable Network Access to the SP” on page 40](#)
- [“Display the DHCP Server IP Address” on page 40](#)
- [“Display the IP Address of the SP” on page 41](#)
- [“Display the Host MAC Address” on page 42](#)
- [“Using an In-band Connection to the SP” on page 43](#)

SP Network Address Options

You can access the SP on your system in multiple ways. Consider the following options and choose the access method that is best for your environment.

You can physically connect to the SP using a serial connection or a network connection. The network connection can be configured to use a static IP address or DHCP (the default). Optionally, the T4 Series servers can use an in-band network connection to the SP, rather than the default out-of-band NET MGT port.

For more information on each option, see the following documentation:

- To use a serial connection to the SP, see:
Connect a Terminal or Emulator to the SER MGT Port, in the installation guide for your server or *Communicating With the Server Module During Startup* in the installation guide for your server module.
- To assign a static IP address to the SP, see:
Assign a Static IP Address to the SP, in the installation guide for your server.
- To use an in-band connection to the SP, see:
[“Oracle ILOM In-band \(Sideband\) Management” on page 43](#)

Related Information

- Oracle Integrated Lights Out Manager (ILOM) 3.0 Documentation
- [“Oracle ILOM Overview” on page 1](#)
- [“Log In to Oracle ILOM” on page 9](#)

▼ Disable or Re-Enable Network Access to the SP

Use the `/SP/network state` property to enable or disable the SP's network interface.

- At the Oracle ILOM -> prompt, type:

```
-> set /SP/network state=value
```

where *value* can be:

- enabled (the default)
- disabled

Related Information

- [“Log In to Oracle ILOM” on page 9](#)
- [“SP Network Address Options” on page 39](#)

▼ Display the DHCP Server IP Address

To display the IP address of the DHCP server that provided the dynamic IP address requested by the SP, view the `dhcp_server_ip` property.

- At the Oracle ILOM -> prompt, type:

```
-> show /SP/network

/SP/network
Targets:
    interconnect
```

```
ipv6
test

Properties:
  commitpending = (Cannot show property)
  dhcp_server_ip = 10.8.31.5          <--- DHCP server
  ipaddress = 10.8.31.188
  ipdiscovery = dhcp
  ipgateway = 10.8.31.248
  ipnetmask = 255.255.252.0
  macaddress = 00:14:4F:7E:83:4F
  managementport = /SYS/MB/SP/NETMGMT
  outofbandmacaddress = 00:21:28:8F:13:5F
  pendingipaddress = 10.8.31.188
  pendingipdiscovery = dhcp
  pendingipgateway = 10.8.31.248
  pendingipnetmask = 255.255.252.0
  sidebandmacaddress = 00:21:28:8F:13:5E
  state = enabled

Commands:
  cd
  set
  show
```

Note – The list of properties might vary based on your server.

Related Information

- [“Log In to Oracle ILOM” on page 9](#)
- [“Display the Host MAC Address” on page 42](#)

▼ Display the IP Address of the SP

To display the IP address of the SP, view the `ipaddress` property.

- **At the Oracle ILOM -> prompt, type:**

```
-> show /SP/network

/SP/network
Targets:
```

```

interconnect
ipv6
test

Properties:
  commitpending = (Cannot show property)
  dhcp_server_ip = 10.8.31.5
  ipaddress = 10.8.31.188          <--- IP address of SP
  ipdiscovery = dhcp
  ipgateway = 10.8.31.248
  ipnetmask = 255.255.252.0
  macaddress = 00:14:4F:7E:83:4F
  managementport = /SYS/MB/SP/NETMGMT
  outofbandmacaddress = 00:21:28:8F:13:5F
  pendingipaddress = 10.8.31.188
  pendingipdiscovery = dhcp
  pendingipgateway = 10.8.31.248
  pendingipnetmask = 255.255.252.0
  sidebandmacaddress = 00:21:28:8F:13:5E
  state = enabled

Commands:
  cd
  set
  show

```

▼ Display the Host MAC Address

The `/HOST macaddress` property is automatically configured by the server software, so you cannot set or change the property. The value is read and determined from the server's removable system configuration card (SCC PROM) or from the server module's ID PROM and then stored as a property in Oracle ILOM.

`/HOST macaddress` is the MAC address for the `net0` port. The MAC addresses for each additional port increments from the `/HOST macaddress`. For example, `net1` is equal to the value of `/HOST macaddress` plus one (1).

- At the Oracle ILOM -> prompt, type:

```
-> show /HOST macaddress
```

Related Information

- [“Log In to Oracle ILOM” on page 9](#)
- [“Display the DHCP Server IP Address” on page 40](#)

Using an In-band Connection to the SP

These topics describe how to use an in-band, or sideband connection, to the SP.

- [“Oracle ILOM In-band \(Sideband\) Management” on page 43](#)
- [“Configure SP In-band \(Sideband\) Access” on page 44](#)

Oracle ILOM In-band (Sideband) Management

By default, you connect to the server’s SP using the out-of-band NET MGT port. The Oracle ILOM sideband management feature enables you to select either the NET MGT port or one of the server’s Gigabit Ethernet ports (NET n), which are in-band ports, to send and receive Oracle ILOM commands to and from the server SP. In-band ports are also called sideband ports.

The advantage of using a sideband management port to manage the server’s SP is that one fewer cable connection and one fewer network switch port are needed. In configurations where numerous servers are being managed, such as data centers, sideband management can represent a significant savings in hardware and network utilization.

Note – In-band connection is not recommended for server modules.

When sideband management is enabled in Oracle ILOM, the following conditions might occur:

- Connectivity to the server SP might be lost when the SP management port configuration is changed while you are connected to the SP using a network connection, such as SSH, web, or Oracle ILOM Remote Console.
- In-chip connectivity between the SP and the host operating system might not be supported by the on-board host Gigabit Ethernet controller. If this condition occurs, use a different port or route to transmit traffic between the source and destination targets instead of using L2 bridging/switching.

- Server host power cycles might cause a brief interruption of network connectivity for server Gigabit Ethernet ports (NET n) that are configured for sideband management. If this condition occurs, configure the adjacent switch/bridge ports as host ports.

Related Information

- [“Configure SP In-band \(Sideband\) Access” on page 44](#)
- [“SP Network Address Options” on page 39](#)

▼ Configure SP In-band (Sideband) Access

This procedure describes how to access the SP from an in-band (or sideband) management using a host network port.

If you perform this procedure using a network connection, you might lose connectivity to the server. Using a serial connection for this procedure eliminates the possibility of losing connectivity during sideband management configuration changes.

1. Log in to Oracle ILOM.

See [“Log In to Oracle ILOM” on page 9](#).

2. If you logged in using the serial port, you can assign a static IP address.

For instructions, see the information about assigning an IP address in the installation guide for your server.

3. View the current network settings.

```
-> show /SP/network

/SP/network
Targets:
  interconnect
  ipv6
  test

Properties:
  commitpending = (Cannot show property)
  dhcp_server_ip = none
  ipaddress = 129.148.62.55
  ipdiscovery = static
  ipgateway = 129.148.62.225
  ipnetmask = 255.255.255.0
  macaddress = 00:11:3T:80:44:B7
```

```
managementport= /SYS/MB/SP/NETMGMT
outofbandmacaddress = 00:11:3T:80:44:B7
pendingipaddress = 129.148.62.55
pendingipdiscovery = static
pendingipgateway = 129.148.62.225
pendingipnetmask = 255.255.255.0
pendingmanagementport = /SYS/MB/SP/NETMGMT
sidebandmacaddress = 00:11:3T:80:44:B7
state = enabled
```

Commands:

```
cd
set
show
```

4. Set the SP management port to a sideband port. (where n is 0-3).

For SPARC T4-1B systems, n is 0-1. For all other systems, n is 0-3.

```
-> set /SP/network pendingmanagementport=/SYS/MB/NET $n$ 

-> set /SP/network commitpending=true
```

5. Verify the change.

```
-> show /SP/network

/SP/network
Targets:
  interconnect
  ipv6
  test

Properties:
  commitpentding = (Cannot show property)
  dhcp_server_ip = none
  ipaddress = 129.148.62.55
  ipdiscovery = static
  ipgateway = 129.148.62.225
  ipnetmask = 255.255.255.0
  macaddress = 00:11:3T:80:44:B7
  managementport= /SYS/MB/NET0
  outofbandmacaddress = 00:11:3T:80:44:B7
  pendingipaddress = 129.148.62.55
  pendingipdiscovery = static
  pendingipgateway = 129.148.62.225
  pendingipnetmask = 255.255.255.0
```

```
pendingmanagementport = /SYS/MB/NET0
sidebandmacaddress = 00:11:3T:80:44:B7
state = enabled
```

Commands:

```
cd
set
show
```

Related Information

- [“Oracle ILOM In-band \(Sideband\) Management” on page 43](#)
- [“SP Network Address Options” on page 39](#)

Configuring Boot Mode

Use the Oracle ILOM boot mode properties to specify how the host boots when correcting a problem with OpenBoot or Oracle VM Server for SPARC settings.

- [“Boot Mode Overview” on page 47](#)
- [“Configure the Host Boot Mode \(Oracle VM Server for SPARC\)” on page 48](#)
- [“Change the Host Boot Mode Behavior at Reset” on page 49](#)
- [“Manage the Host Boot Mode Script” on page 50](#)
- [“Display Host Boot Mode Expiration Date” on page 51](#)
- [“Override OBP Settings to Reset the Server” on page 51](#)

Boot Mode Overview

Boot mode (`bootmode`) properties enable you to override the default method the server uses when it boots. This ability is useful to override particular OpenBoot or Oracle VM Server settings that might be incorrect, to set up OpenBoot variables using a script, or to perform similar tasks.

For example, if the OpenBoot settings have become corrupt, you can set the `bootmode` state property to `reset_nvram` then reset the server to its factory default OpenBoot settings.

Service personnel might instruct you to use the `bootmode` script property for problem resolution. The full extent of script capabilities are not documented and exist primarily for debugging.

Because `bootmode` is intended to be used to correct a problem with the OpenBoot or Oracle VM Server settings, the `bootmode` takes effect for a single boot only. Additionally, to prevent an administrator from setting a `bootmode` state property and forgetting about it, a `bootmode` state property expires if the host is not reset within 10 minutes of the `bootmode` state property being set.

Related Information

- “Reset the Server (Oracle Solaris OS)” on page 17
- “Reset the Server (Oracle ILOM)” on page 17
- “OpenBoot Overview” on page 4
- “Oracle VM Server for SPARC Overview” on page 4

▼ Configure the Host Boot Mode (Oracle VM Server for SPARC)

Note – You must use a valid Oracle VM Server configuration name for this task.

1. Determine the valid Oracle VM Server configurations on your SP, at the Oracle ILOM -> prompt, type:

```
-> show /HOST/domain/configs
```

2. Set the boot mode configuration, at the Oracle ILOM -> prompt, type:

```
-> set /HOST/bootmode config=configname
```

where the `config` property takes a *configname* value that is a valid named logical domain configuration.

For example, if you created a Oracle VM Server configuration called `ldm-set1`:

```
-> set /HOST/bootmode config=ldm-set1
```

To return the boot mode `config` to the factory default configuration, specify `factory-default`.

For example:

```
-> set /HOST/bootmode config=factory-default
```

Related Information

- “Reset the Server (Oracle ILOM)” on page 17

- [“Boot Mode Overview” on page 47](#)
- [“Oracle VM Server for SPARC Overview” on page 4](#)

▼ Change the Host Boot Mode Behavior at Reset

The `/HOST/bootmode` state property controls how OpenBoot NVRAM variables are used. Normally the current settings of these variables are retained. Setting `/HOST/bootmode state=reset_nvram` changes the OpenBoot NVRAM variables to their default settings at the next reset.

- **At the Oracle ILOM -> prompt, type:**

```
-> set /HOST/bootmode state=value
```

where *value* is one of the following:

- `normal` – At next reset, retains current NVRAM variable settings.
- `reset_nvram` – At next reset, returns OpenBoot variables to default settings.

Note – `state=reset_nvram` will return to `normal` after the next server reset or 10 minutes (see `expires` property in [“Display Host Boot Mode Expiration Date” on page 51](#)). `config` and `script` properties do not expire and will be cleared upon the next server reset or manually by setting *value* to `""`.

Related Information

- [“Reset the Server \(Oracle ILOM\)” on page 17](#)
- [“Boot Mode Overview” on page 47](#)
- [“Oracle VM Server for SPARC Overview” on page 4](#)

▼ Manage the Host Boot Mode Script

- At the Oracle ILOM -> prompt, type:

```
-> set /HOST/bootmode script=value
```

where *script* controls the host server OBP firmware method of booting.

script does not affect the current /HOST/bootmode setting.

value can be up to 64 bytes in length.

You can specify a /HOST/bootmode setting and set the script within the same command. For example:

```
-> set /HOST/bootmode state=reset_nvram script="setenv diag-switch? true"
```

After the server resets and OBP reads the values stored in the script, the OBP sets the OBP variable *diag-switch?* to the user-requested value of *true*.

Note – If you set /HOST/bootmode *script=""*, Oracle ILOM sets the script to empty.

Related Information

- [“Reset the Server \(Oracle ILOM\)” on page 17](#)
- [“Boot Mode Overview” on page 47](#)
- [“Oracle VM Server for SPARC Overview” on page 4](#)

▼ Display Host Boot Mode Expiration Date

- At the Oracle ILOM -> prompt, type:

```
-> show /HOST/bootmode expires
Properties:
    expires = Thu Oct 14 18:24:16 2010
```

where expires is the date and time when the current boot mode will expire.

Related Information

- [“Reset the Server \(Oracle ILOM\)” on page 17](#)
- [“Boot Mode Overview” on page 47](#)
- [“Oracle VM Server for SPARC Overview” on page 4](#)

▼ Override OBP Settings to Reset the Server

Use this procedure to override the OBP settings and initiate reboot of the control domain, which results in the host booting to the ok prompt.

- At the Oracle ILOM -> prompt, type:

```
-> set /HOST/domain/control auto-boot=disabled
-> reset /HOST/domain/control [-force] [-script]
```

The host reboots and stops at the ok prompt.

Related Information

- [“Change the Host Boot Mode Behavior at Reset” on page 49](#)
- [“Configuring Boot Mode” on page 47](#)
- [“Boot Mode Overview” on page 47](#)
- [“Oracle VM Server for SPARC Overview” on page 4](#)

Configuring Server Behavior at Restart

Use the following procedures to configure how Oracle ILOM should behave during the following restart scenarios.

- [“Specify Behavior When the Host Resets” on page 53](#)
- [“Specify Behavior When the Host Stops Running” on page 54](#)
- [“Set the Boot Timeout Interval” on page 54](#)
- [“Specify Behavior at Boot Timeout” on page 55](#)
- [“Specify Behavior if Restart Fails” on page 55](#)
- [“Specify Maximum Restart Attempts” on page 56](#)

▼ Specify Behavior When the Host Resets

Specify if the host should continue to boot if an error is encountered.

- **Set this property:**

`-> set /HOST autorunonerror=value`

where *value* can be:

- `false` – The host continues to boot if an error is encountered.
- `true` – The host *does not* continue to boot if an error is encountered.

Related Information

- [“Configuring Policy Settings” on page 33](#)

▼ Specify Behavior When the Host Stops Running

Specify what Oracle ILOM should do when the host leaves the `RUNNING` state (when the watchdog timer expires).

- **Set this property:**

```
-> set /HOST autorestart=value
```

where *value* can be:

- `none` – Oracle ILOM takes no action other than to issue a warning.
- `reset` – Oracle ILOM attempts to reset the server when the Oracle Solaris watchdog timer expires (the default).
- `dumpcore` – Oracle ILOM attempts to force a core dump of the OS when the watchdog timer expires.

Related Information

- [“Display Console History” on page 63](#)

▼ Set the Boot Timeout Interval

- **Set the time delay between a request to boot the host and booting the host:**

```
-> set /HOST boottimeout=seconds
```

The default value of `boottimeout` is 0 (zero seconds) or no timeout. Possible values are in the range from 0 to 36000 seconds.

Related Information

- [“Specify Behavior at Boot Timeout” on page 55](#)

▼ Specify Behavior at Boot Timeout

Specify what Oracle ILOM should do if the host fails to boot before the boot timeout interval.

- **Specify behavior at the completion of** `boottimeout`:

```
-> set /HOST bootrestart=value
```

where *value* can be:

- none (the default)
- reset

Related Information

- [“Set the Boot Timeout Interval” on page 54](#)

▼ Specify Behavior if Restart Fails

Specify what Oracle ILOM should do if the host fails to reach the Oracle Solaris running state.

- **At the Oracle ILOM -> prompt, type:**

```
-> set /HOST bootfailrecovery=value
```

where *value* can be:

- powercycle
- poweroff (the default)

Related Information

- [“Specify Maximum Restart Attempts” on page 56](#)

▼ Specify Maximum Restart Attempts

Specify how many times Oracle ILOM should attempt to restart the host.

- At the Oracle ILOM -> prompt, type:

```
-> set /HOST maxbootfail=attempts
```

The default value of `maxbootfail` is 3 (three attempts).

If the host does not boot successfully within the number of tries indicated by `maxbootfail`, the host is powered off or powercycled (depending upon the setting of `bootfailrecovery`). In either case, `boottimeout` is set to 0 (zero seconds), disabling further attempts to restart the host.

Related Information

- [“Specify Behavior if Restart Fails” on page 55](#)

Configuring Devices

These topics contain information about configuring devices in the server.

- [“Unconfigure a Device Manually” on page 57](#)
- [“Reconfigure a Device Manually” on page 57](#)

▼ Unconfigure a Device Manually

The Oracle ILOM firmware provides a `component_state=disabled` command, which enables you to unconfigure server devices manually. This command marks the specified device as `disabled`. Any device marked `disabled`, whether manually or by the system firmware, is removed from the server’s machine description prior to transfer of control to other layers of system firmware, such as OBP.

- **At the Oracle ILOM -> prompt, type:**

```
-> set component-name component_state=disabled
```

Related Information

- [“Log In to Oracle ILOM” on page 9](#)
- [“Reconfigure a Device Manually” on page 57](#)
- [“Display Server Components” on page 69](#)
- [“Locate Device Paths” on page 28](#)

▼ Reconfigure a Device Manually

The Oracle ILOM firmware provides a `component_state=enabled` command, which enables you to reconfigure server devices manually. Use this command to mark the specified device as `enabled`.

- At the Oracle ILOM -> prompt, type:

```
-> set component-name component_state=enabled
```

Related Information

- [“Log In to Oracle ILOM” on page 9](#)
- [“Unconfigure a Device Manually” on page 57](#)
- [“Display Server Components” on page 69](#)
- [“Locate Device Paths” on page 28](#)

Monitoring the Server

The SPARC T4 series servers provide many ways to indicate faulty behavior, including LEDs, Oracle ILOM, and POST. For specific information about LEDs, and for complete troubleshooting information, refer to the service manual for your server.

- [“Monitoring Faults” on page 59](#)
- [“Enabling Automatic System Recovery” on page 67](#)
- [“Display Server Components” on page 69](#)
- [“Locate the Server” on page 70](#)

Monitoring Faults

These topics contain a summary of diagnostic tools and basic information about finding server faults using pre-OS tools, including Oracle ILOM and POST. For complete troubleshooting information, see the service manual for your server.

- [“Diagnostics Overview” on page 59](#)
- [“Discover Faults \(Oracle ILOM\)” on page 61](#)
- [“Discover Faults \(Oracle ILOM Fault Management Shell\)” on page 61](#)
- [“Discover Faults Using POST” on page 63](#)
- [“Display Console History” on page 63](#)
- [“Repair a Fault \(Oracle ILOM Fault Management Shell\)” on page 65](#)
- [“Clear a Fault” on page 66](#)

Diagnostics Overview

You can use a variety of diagnostic tools, commands, and indicators to monitor and troubleshoot a server. See the service manual for your server for complete information about these diagnostic tools:

- **LEDs** – Provide a quick visual notification of the status of the server and of some of the FRUs.
- **Oracle ILOM** – This firmware runs on the SP. In addition to providing the interface between the hardware and OS, Oracle ILOM also tracks and reports the health of key server components. Oracle ILOM works closely with POST and Oracle Solaris Predictive Self-Healing technology to keep the server running even when there is a faulty component.
- **Power-on self-test** – POST performs diagnostics on server components upon server reset to ensure the integrity of those components. POST is configurable and works with Oracle ILOM to take faulty components offline if needed.
- **Oracle Solaris OS Predictive Self-Healing** – This technology continuously monitors the health of the CPU, memory, and other components, and works with Oracle ILOM to take a faulty component offline if needed. The PSH technology enables servers to accurately predict component failures and mitigate many serious problems before they occur.
- **Log files and command interface** – Provide the standard Oracle Solaris OS log files and investigative commands that can be accessed and displayed on the device of your choice.
- **SunVTS** – An application that exercises the server, provides hardware validation, and discloses possible faulty components with recommendations for repair.

The LEDs, Oracle ILOM, PSH, and many of the log files and console messages are integrated. For example, when the Oracle Solaris software detects a fault, it displays the fault, and logs it, and passes information to Oracle ILOM, where it is logged.

Related Information

- [“Discover Faults \(Oracle ILOM\)” on page 61](#)
- [“Discover Faults Using POST” on page 63](#)
- [“Discover Faults \(Oracle ILOM Fault Management Shell\)” on page 61](#)
- See the *server service manual section detecting and managing faults*

▼ Discover Faults (Oracle ILOM)

- At the Oracle ILOM -> prompt, type:

```
-> show faulty
```

This command displays the target, the property, and the value of the fault.
For example:

```
-> show faulty
```

Target	Property	Value
/SP/faultmgmt/0	fru	/SYS
/SP/faultmgmt/1	fru	/SYS/MB/CMP0/BOBO/CH1/D0
/SP/faultmgmt/1/faults/0	fru_part_number	18JS25672PDZ1G1F1

```
->
```

Related Information

- [“Discover Faults Using POST” on page 63](#)
- [“Log In to Oracle ILOM” on page 9](#)
- [“Locate the Server” on page 70](#)
- [“Clear a Fault” on page 66](#)
- [“Enabling Automatic System Recovery” on page 67](#)
- [“Discover Faults \(Oracle ILOM Fault Management Shell\)” on page 61](#)

▼ Discover Faults (Oracle ILOM Fault Management Shell)

The Oracle ILOM Fault Management shell provides a way to use the Oracle Solaris Fault Manager commands (`fmadm`, `fmstat`) from within Oracle ILOM, and to view both host and Oracle ILOM faults.

1. To start the captive shell, at the Oracle ILOM -> prompt, type:

```
-> start /SP/faultmgmt/shell
```

```
Are you sure you want to start /SP/faultmgmt/shell (y/n)? y
```

```
faultmgmtsp>
```

2. For a list of current server faults, type:

faultmgmtsp> fmadm faulty			

Time	UUID	msgid	Severity

2010-09-03/20:46:23	fa4a2f86-5156-4243-8e88-d6516db12970	SPT-8000-DH	Critical
Fault class : fault.chassis.voltage.fail			
FRU : /SYS/MB			
(Part Number: 541-4197-04)			
(Serial Number: 1005LCB-1025D40059)			
Description : A chassis voltage supply is operating outside of the allowable range.			
Response : The system will be powered off. The chassis-wide service required LED will be illuminated.			
Impact : The system is not usable until repaired. ILOM will not allow the system to be powered on until repaired.			
Action : The administrator should review the ILOM event log for additional information pertaining to this diagnosis. Please refer to the Details section of the Knowledge Article for additional information.			

Note – If the server detects the replacement of the faulty FRU, the repair does not require a user command, and the fault will be cleared automatically.

3. Discover more information about a specific fault.

Find the fault MSG-ID (SPT-8000-DH in the preceeding example), and type it in the Search Knowledge Base search window at <http://support.oracle.com>.

4. For information on how to repair the fault, see:

“Repair a Fault (Oracle ILOM Fault Management Shell)” on page 65.

5. To leave the Fault Management shell and return to Oracle ILOM, type:

```
faultmgmtsp> exit
->
```


Related Information

- “Oracle Solaris 10 OS Feature Spotlight: Predictive Self Healing” at www.oracle.com/technetwork/systems/dtrace/self-healing/index.html
- “Log In to Oracle ILOM” on page 9
- “Discover Faults (Oracle ILOM)” on page 61
- “Repair a Fault (Oracle ILOM Fault Management Shell)” on page 65

▼ Discover Faults Using POST

The virtual keyswitch can be used to run full POST diagnostics without having to modify the diagnostic property settings. Note that POST diagnostics can take a significant amount of time to run at server reset.

1. Log in to Oracle ILOM.

See “Log In to Oracle ILOM” on page 9.

2. At the Oracle ILOM -> prompt, type:

```
-> set /SYS keyswitch_state=diag
```

The server is set to run full POST diagnostics on server reset.

3. To return to your normal diagnostic settings *after* running POST, at the Oracle ILOM -> prompt, type:

```
-> set /SYS keyswitch_state=normal
```

Related Information

- “Discover Faults (Oracle ILOM)” on page 61
- “Locate the Server” on page 70
- “Clear a Fault” on page 66

▼ Display Console History

This topic describes displaying the host server console output buffers.

There are two console history buffers that can contain up to 1 Mbyte of information. The `/HOST/console/history` target writes all types of log information. The `/HOST/console/bootlog` target writes boot information and initialization data into the console buffer until Oracle ILOM is notified by the server that the Oracle Solaris OS is up and running. This buffer is kept until the host is booted again.

Note – You must have Oracle ILOM Administrator level user permission to use this command.

1. To manage the `/HOST/console/history` log, at the Oracle ILOM -> prompt, type:

```
-> set /HOST/console/history property=option [...]
-> show /HOST/console/history
```

where *property* can be:

- `line_count` – This option accepts a value within the range of 1 to 2048 lines. Specify "" for an unlimited number of lines. The default is all lines.
- `pause_count` – This option accepts a value of 1 to any valid integer or "" for infinite number of lines. The default is not to pause.
- `start_from` – The options are:
 - `end` – The last line (most recent) in the buffer (the default).
 - `beginning` – The first line in the buffer.

If you type the `show /HOST/console/history` command without first setting any arguments with the `set` command, Oracle ILOM displays all lines of the console log, starting from the end.

Note – Timestamps recorded in the console log reflect server time. These timestamps reflect local time, and the Oracle ILOM console log uses UTC (Coordinated Universal Time). The Oracle Solaris OS system time is independent of the Oracle ILOM time.

2. To view the `/HOST/console/bootlog`, at the Oracle ILOM -> prompt, type:

```
-> show /HOST/console/bootlog property
```

where *property* can be:

- `line_count` – This option accepts a value within the range of 0 to 2048 lines. Specify "0" for an unlimited number of lines. The default is all lines.
- `pause_count` – This option accepts a value of within the range of 0 to 2048 lines. Specify "0" for an unlimited number of lines. The default is not to pause.

- `start_from` – The options are:
 - `end` – The last line (most recent) in the buffer (the default).
 - `beginning` – The first line in the buffer.

Note – Timestamps in the console log reflect server time. By default, the Oracle ILOM console log uses Greenwich Mean Time (GMT), but you can use the `/SP/clock timezone` command to set the SP clock to use other timezones. The Oracle Solaris OS system time is independent of the Oracle ILOM time.

Related Information

- [“Specify the Host Power State at Restart” on page 34](#)

▼ Repair a Fault (Oracle ILOM Fault Management Shell)

You can use the `fmadm repair` command to fix faults diagnosed by Oracle ILOM. (Faults diagnosed by Oracle ILOM, rather than the host, have message IDs starting with “SPT.”)

The only time you should use the `fmadm repair` command in the Oracle ILOM Fault Management shell for a host-diagnosed fault is when the fault is repaired and Oracle ILOM is unaware of the repair. For example, Oracle ILOM might be down when the fault is repaired. In that case, the host would no longer display the fault, yet the fault is still displayed in Oracle ILOM. Use the `fmadm repair` command to clear the fault.

1. Locate the fault:

faultmgmtsp> fmadm faulty			

Time	UUID	msgid	Severity

2010-09-03/20:46:23	fa4a2f86-5156-4243-8e88-d6516db12970	SPT-8000-DH	Critical
Fault class : fault.chassis.voltage.fail			
FRU : /SYS/MB			
(Part Number: 541-4197-04)			
(Serial Number: 1005LCB-1025D40059)			
Description : A chassis voltage supply is operating outside of the allowable range.			

Response	: The system will be powered off. The chassis-wide service required LED will be illuminated.
Impact	: The system is not usable until repaired. ILOM will not allow the system to be powered on until repaired.
Action	: The administrator should review the ILOM event log for additional information pertaining to this diagnosis. Please refer to the Details section of the Knowledge Article for additional information.

```
faultmgmtsp> fmadm repair fa4a2f86-5156-4243-8e88-d6516db12970
faultmgmtsp>
```

2. To repair an Oracle ILOM-detected fault, use the `fmadm repair` command:

```
faultmgmtsp> fmadm repair fa4a2f86-5156-4243-8e88-d6516db12970
faultmgmtsp>
```

Note – You can use either the NAC name (for instance, `/SYS/MB`) or the UUID (for instance, `fa4a2f86-5156-4243-8e88-d6516db12970`) of the fault with the `fmadm repair` command.

3. To leave the Fault Management shell and return to Oracle ILOM, type:

```
faultmgmtsp> exit
->
```

Related Information

- [“Discover Faults \(Oracle ILOM Fault Management Shell\)” on page 61](#)

▼ Clear a Fault

- At the Oracle ILOM `->` prompt, type:

```
-> set /SYS/component clear_fault_action=true
```

Setting `clear_fault_action` to `true` clears the fault at the component and all levels below it in the `/SYS` tree.

Related Information

- [“Discover Faults \(Oracle ILOM\)” on page 61](#)
- [“Discover Faults Using POST” on page 63](#)
- [“Display Server Components” on page 69](#)

Enabling Automatic System Recovery

These topics include information about configuring your server to automatically recover from minor faults.

Note – This section refers to the automatic system recovery feature, not the similarly named auto service request feature.

- [“Automatic System Recovery Overview” on page 67](#)
- [“Enable ASR” on page 68](#)
- [“Disable ASR” on page 68](#)
- [“View Information on Components Affected by ASR” on page 69](#)

Automatic System Recovery Overview

The server provides for ASR from failures in memory modules or PCI cards.

ASR functionality enables the server to resume operation after experiencing certain nonfatal hardware faults or failures. When ASR is enabled, the system’s firmware diagnostics automatically detect failed hardware components. An autoconfiguring capability designed into the system firmware enables the system to unconfigure failed components and to restore server operation. As long as the server is capable of operating without the failed component, the ASR features enable the server to reboot automatically, without operator intervention.

Note – ASR is not activated until you enable it. See [“Enable ASR” on page 68](#).

For more information about ASR, refer to the service manual for your server.

Related Information

- [“Enable ASR” on page 68](#)

- [“Disable ASR” on page 68](#)
- [“View Information on Components Affected by ASR” on page 69](#)

▼ Enable ASR

1. At the Oracle ILOM -> prompt, type:

```
-> set /HOST/diag mode=normal
-> set /HOST/diag level=max
-> set /HOST/diag trigger=power-on-reset
```

2. At the ok prompt, type:

```
ok setenv auto-boot? true
ok setenv auto-boot-on-error? true
```

Note – For more information about OpenBoot configuration variables, refer to the service manual for your server.

3. To cause the parameter changes to take effect, type:

```
ok reset-all
```

The server permanently stores the parameter changes and boots automatically when the OpenBoot configuration variable `auto-boot?` is set to `true` (its default value).

Related Information

- [“Automatic System Recovery Overview” on page 67](#)
- [“Disable ASR” on page 68](#)
- [“View Information on Components Affected by ASR” on page 69](#)

▼ Disable ASR

1. At the ok prompt, type:

```
ok setenv auto-boot-on-error? false
```

2. To cause the parameter changes to take effect, type:

```
ok reset-all
```

The server permanently stores the parameter change.

After you disable the ASR feature, it is not activated again until you re-enable it.

Related Information

- [“Enable ASR” on page 68](#)
- [“View Information on Components Affected by ASR” on page 69](#)
- [“Automatic System Recovery Overview” on page 67](#)

▼ View Information on Components Affected by ASR

- At the Oracle ILOM -> prompt, type:

```
-> show /SYS/component component_state
```

In the `show /SYS/component component_state` command output, any devices marked `disabled` have been manually unconfigured using the system firmware. The command output also shows devices that have failed firmware diagnostics and have been automatically unconfigured by the system firmware.

Related Information

- [“Automatic System Recovery Overview” on page 67](#)
- [“Enable ASR” on page 68](#)
- [“Disable ASR” on page 68](#)
- [“Unconfigure a Device Manually” on page 57](#)
- [“Reconfigure a Device Manually” on page 57](#)

▼ Display Server Components

View real-time information about the components installed in your server using the Oracle ILOM `show components` command.

- At the Oracle ILOM prompt, type:

Note – This is a sample of show components output. Specific components will vary based on your server.

-> show components		
Target	Property	Value
-----+-----+-----		
/SYS/MB/RISER0/ PCIE0	component_state	Enabled
/SYS/MB/RISER0/ PCIE3	component_state	Disabled
/SYS/MB/RISER1/ PCIE1	component_state	Enabled
/SYS/MB/RISER1/ PCIE1	component_state	Enabled
/SYS/MB/NET0	component_state	Enabled
/SYS/MB/NET1	component_state	Enabled
/SYS/MB/NET2	component_state	Enabled

Related Information

- [“Locate Device Paths” on page 28](#)

▼ Locate the Server

In case you need to service a component, lighting the system locator LED assists in easily identifying the correct server. You do not need administrator permissions to use the `set /SYS/LOCATE` and `show /SYS/LOCATE` commands.

1. Log in to Oracle ILOM.

See [“Log In to Oracle ILOM” on page 9](#).

2. Manage the Locator LED with the following commands.

- To turn on the Locator LED, from the ILOM service processor command prompt, type:

```
-> set /SYS/LOCATE value=Fast_Blink
```


- To turn off the Locator LED, from the ILOM service processor command prompt, type:

```
-> set /SYS/LOCATE value=off
```

- To display the state of the Locator LED, from the ILOM service processor command prompt, type:

```
-> show /SYS/LOCATE
```

Related Information

- [“Monitoring Faults” on page 59](#)
- [“Configuring Devices” on page 57](#)

Updating the Firmware

These topics describe how to update the system firmware and view current versions of firmware for Oracle's SPARC T4 series servers.

- [“Display the Firmware Version” on page 73](#)
- [“Update the Firmware” on page 73](#)
- [“Display OpenBoot Version” on page 76](#)
- [“Display POST Version” on page 76](#)

▼ Display the Firmware Version

The `/HOST sysfw_version` property displays information about the system firmware version on the host.

- **View the current setting for this property.** At the Oracle ILOM `->` prompt, type:

```
-> show /HOST sysfw_version
```

Related Information

- [“Update the Firmware” on page 73](#)

▼ Update the Firmware

1. **Ensure that the Oracle ILOM SP network management port is configured.**
See the installation guide for your server for instructions.

2. Open an SSH session to connect to the SP:

```
% ssh root@xxx.xxx.xxx.xxx
...
Are you sure you want to continue connecting (yes/no) ? yes

...
Password: password (nothing displayed)
Waiting for daemons to initialize...

Daemons ready

Integrated Lights Out Manager

Version 3.x.x.x

Copyright 2010 Oracle and/or its affiliates. All rights reserved.
Use is subject to license terms.

->
```

3. Power off the host:

```
-> stop /SYS
```

4. Set the `keyswitch_state` parameter to normal:

```
-> set /SYS keyswitch_state=normal
```

5. Type the `load` command with the path to the new flash image.

The `load` command updates the SP flash image and the host firmware. The `load` command requires the following information:

- IP address of a TFTP server on the network that can access the flash image.
- Full path name to the flash image that the IP address can access.

The command usage is as follows:

```
load [-script] -source tftp://xxx.xxx.xx.xxx/pathname
```

where:

- `-script` - Does not prompt for confirmation and acts as if `yes` was specified.

- **-source** - Specifies the IP address and full path name (URL) to the flash image.

```
-> load -source tftp://129.99.99.99/pathname
NOTE: A firmware upgrade will cause the server and ILOM to be reset.
It is recommended that a clean shutdown of the server be done prior
to the upgrade procedure.
An upgrade takes about 6 minutes to complete. ILOM will enter a
special mode to load new firmware.
No other tasks can be performed in ILOM until the firmware upgrade
is complete and ILOM is reset.
Are you sure you want to load the specified file (y/n)?y
Do you want to preserve the configuration (y/n)? y
.....
Firmware update is complete.
ILOM will now be restarted with the new firmware.
Update Complete. Reset device to use new image.
->
```

After the flash image has been updated, the server automatically resets, runs diagnostics, and returns to the login prompt on the serial console.

```
U-Boot 1.x.x

Custom AST2100 U-Boot 3.0 (Aug 21 2010 - 10:46:54) r58174
***
Net:   faradaynic#0, faradaynic#1
Enter Diagnostics Mode
['q'uick/'n'ormal(default)/e'x'tended(manufacturing mode)] .....
0
Diagnostics Mode - NORMAL
<DIAGS> Memory Data Bus Test ... PASSED
<DIAGS> Memory Address Bus Test ... PASSED
I2C Probe Test - SP
      Bus      Device                                Address Result
      ==      =====                                =====
      6              SP FRUID (U1101)                 0xA0    PASSED
      6              DS1338(RTC) (U1102)               0xD0    PASSED

<DIAGS> PHY #0 R/W Test ... PASSED
<DIAGS> PHY #0 Link Status ... PASSED
<DIAGS> ETHERNET PHY #0, Internal Loopback Test ... PASSED
## Booting image at 110a2000 ... ***

Mounting local filesystems...
Mounted all disk partitions.

Configuring network interfaces...FTGMAC100: eth0:ftgmac100_open
```

```
Starting system log daemon: syslogd and klogd.  
Starting capidirect daemon: capidirectd . Done  
Starting Event Manager: eventmgr . Done  
Starting ipmi log manager daemon: logmgr . Done  
Starting IPMI Stack: . Done  
Starting sshd.  
Starting SP fishwrap cache daemon: fishwrapd . Done  
Starting Host deamon: hostd . Done  
Starting Network Controller Sideband Interface Daemon: ncsid . Done  
Starting Platform Obfuscation Daemon: pod . Done  
Starting lu main daemon: lumain . Done  
Starting Detection/Diagnosis After System Boot: dasboot Done  
Starting Servicetags discoverer: stdiscoverer.  
Starting Servicetags listener: stlistener.  
Starting Dynamic FRUID Daemon: dynafrud Done  
  
hostname login:
```

Related Information

- [“Display the Firmware Version” on page 73](#)

▼ Display OpenBoot Version

The `/HOST obp_version` property displays information about the version of OpenBoot on the host.

- **View the current setting for this property:**

```
-> show /HOST obp_version
```

Related Information

- [“Update the Firmware” on page 73](#)
- [“OpenBoot Overview” on page 4](#)

▼ Display POST Version

The `/HOST post_version` property displays information about the version of POST on the host.

- View the current setting for this property:

```
-> show /HOST post_version
```

Related Information

- [“Update the Firmware” on page 73](#)

Identifying WWN-Designated SAS2 Devices

These topics explain how to identify SAS2 devices based on their WWN values.

- [“World Wide Name Syntax” on page 79](#)
- [“probe-scsi-all WWN Mapping Overview” on page 81](#)
- [“Mapping WWN Values to Hard Drives \(OBP probe-scsi-all Command\)” on page 80](#)
- [“Identify a Disk Slot Using prtconf \(Oracle Solaris OS\)” on page 100](#)
- [“WWN Syntax in an OS Installation on an Individual Drive” on page 104](#)
- [“WWN Syntax in an OS Installation on a RAID Volume” on page 105](#)

World Wide Name Syntax

The Oracle Solaris OS uses the World Wide Name (WWN) syntax in place of the locally unique `tn` (target ID) field in logical device names. This change affects how device names can be mapped to specific SCSI devices. The following points are key to understanding the impact of this change:

- Before the change to WWN nomenclature, the Oracle Solaris OS would ordinarily identify the default boot device as `c0t0d0`.
- With the change, the device identifier for the default boot device is now referred to as `c0tWWNd0`, where `WWN` is a hexadecimal value that is unique to this device throughout the world.
- This WWN value is assigned by the manufacturer of the device and, therefore, has a random relationship to the server’s device tree structure.

Because WWN values do not conform to the traditional logical device name structure, you cannot directly identify a target device from its `c#tWWNd#` value. Instead, you can use one of the following alternative methods to map WWN-based device names to physical devices.

- One method consists of analyzing the output of the OBP command `probe-scsi-all`. You use this method when the OS is *not* running. See [“Mapping WWN Values to Hard Drives \(OBP probe-scsi-all Command\)”](#) on page 80 for more information.

Note – For example, you would analyze `probe-scsi-all` output when you want to identify a boot device.

- When the OS is running, you can analyze the output of the command `prtconf -v`. See [“Identify a Disk Slot Using prtconf \(Oracle Solaris OS\)”](#) on page 100 for more information.

Related Information

- [“Mapping WWN Values to Hard Drives \(OBP probe-scsi-all Command\)”](#) on page 80
- [“Identify a Disk Slot Using prtconf \(Oracle Solaris OS\)”](#) on page 100
- [“WWN Syntax in an OS Installation on an Individual Drive”](#) on page 104
- [“WWN Syntax in an OS Installation on a RAID Volume”](#) on page 105

Mapping WWN Values to Hard Drives (OBP `probe-scsi-all` Command)

These topics explain how to map WWN values to specific SAS2 drives using the OBP command `probe-scsi-all`. Separate explanations are provided for each SPARC T4-x server model.

- [“probe-scsi-all WWN Mapping Overview”](#) on page 81
- [“probe-scsi-all WWN Mapping Example \(SPARC T4-1\)”](#) on page 82
- [“probe-scsi-all WWN Mapping Example \(Netra SPARC T4-1\)”](#) on page 85
- [“probe-scsi-all WWN Mapping Example \(SPARC T4-2\)”](#) on page 87
- [“probe-scsi-all WWN Mapping Example \(Netra SPARC T4-2\)”](#) on page 90
- [“probe-scsi-all WWN Mapping Example \(SPARC T4-4 With Four CPUs\)”](#) on page 92
- [“probe-scsi-all WWN Mapping Example \(SPARC T4-4 With Two CPUs\)”](#) on page 95
- [“probe-scsi-all WWN Mapping Example \(SPARC T4-1B and Netra SPARC T4-1B\)”](#) on page 98

probe-scsi-all WWN Mapping Overview

The output displayed by `probe-scsi-all` lists all SCSI devices in the server and provides a basic set of information about each device. When analyzing the `probe-scsi-all` output, look for the following data fields:

Entity Name	Definition
Target	Each SAS or SATA drive is assigned a unique Target ID.
SASDeviceName	This is the WWN value assigned to a SAS drive by the manufacturer. The Oracle Solaris OS recognizes this name.
SASAddress	This is the WWN value assigned to a SCSI device that is recognized by the OBP firmware.
PhyNum	This is a hexadecimal ID of the controller port that is attached to the target drive.
VolumeDeviceName (when a RAID volume is configured)	This is the WWN value assigned to a RAID volume that is recognized by Oracle Solaris OS. <code>VolumeDeviceName</code> replaces the <code>SASDeviceName</code> of every SCSI device contained in the RAID volume.
VolumeWWID (when a RAID volume is configured)	This is the WWN-based value assigned to a RAID volume that is recognized by the OBP firmware. <code>VolumeWWID</code> replaces the <code>SASAddress</code> of every SCSI device contained in the RAID volume.

At a high level, the WWN mapping process consists of the following stages:

- Identify the physical location of the hard drive that is to be the target of the operation.
- Then identify the controller port that is attached to that physical location.
- Finally, find the WWN-based device name of the drive attached to that controller port.

Examples of this process are provided for each of the SPARC T4 server models:

- SPARC T4-1 -- [“probe-scsi-all WWN Mapping Example \(SPARC T4-1\)” on page 82](#)
- Netra SPARC T4-1 -- [“probe-scsi-all WWN Mapping Example \(Netra SPARC T4-1\)” on page 85](#)
- SPARC T4-2 -- [“probe-scsi-all WWN Mapping Example \(SPARC T4-2\)” on page 87](#)

- Netra SPARC T4-2 -- “probe-scsi-all WWN Mapping Example (Netra SPARC T4-2)” on page 90
- SPARC T4-4 with four CPUs -- “probe-scsi-all WWN Mapping Example (SPARC T4-4 With Four CPUs)” on page 92
- SPARC T4-4 with two CPUs -- “probe-scsi-all WWN Mapping Example (SPARC T4-4 With Two CPUs)” on page 95
- SPARC and Netra SPARC T4-1B -- “probe-scsi-all WWN Mapping Example (SPARC T4-1B and Netra SPARC T4-1B)” on page 98

Note – Refer to your service manual for a description of the physical drive slot organization on your system.

Related Information

- “World Wide Name Syntax” on page 79
- “Identify a Disk Slot Using prtconf (Oracle Solaris OS)” on page 100
- “WWN Syntax in an OS Installation on an Individual Drive” on page 104
- “WWN Syntax in an OS Installation on a RAID Volume” on page 105

probe-scsi-all WWN Mapping Example (SPARC T4-1)

The SPARC T4-1 server has two SAS2 RAID controllers on the motherboard. Each controller is connected to four slots on the disk backplane. The following table shows the PhyNum-to-disk slot mapping for the eight-slot SPARC T4-1 backplane.

TABLE: SAS2 Controller Port Mapping for the SPARC T4-1 Disk Backplane

SAS2 Controller	Controller Port (PhyNum)	Disk Slot	SAS2 Controller	Controller Port (PhyNum)	Disk Slot
0	0	0*	1	0	4
	1	1		1	5
	2	2		2	6
	3	3		3	7

* Default boot drive

This table shows that ports 0-3 of controller 0 are connected to backplane slots 0-3 and ports 0-3 of controller 1 are connected to slots 4-7.

The following example is based on a SPARC T4-1 server with eight hard drives. These hard drives are deployed as six individual storage devices and a virtual drive. The virtual drive consists of two hard drives configured as a RAID volume. Controllers 0 and 1 are attached to these storage devices in the following manner:

- Controller 0 is attached to Targets 9 and b (two individual storage devices).
- Controller 0 is also attached to Target 523 (a RAID volume).
- Controller 1 is attached to Targets 9, b, c, and d (four individual storage devices).
- Controller 1 is also attached to Target a (a DVD unit).

Note – For SPARC T4-1 servers, the second field of the device path specifies the controllers: /pci@400/pci@1 = controller 0 and /pci@400/pci@2 = controller 1.

```
ok probe-scsi-all
/pci@400/pci@2/pci@0/pci@f/pci@0/usb@0,2/hub@2/hub@3/storage@2
Unit 0    Removable Read Only device    AMI        Virtual CDROM    1.00

/pci@400/pci@2/pci@0/pci@4/scsi@0                                <---- SAS controller 1

FCode Version 1.00.56, MPT Version 2.00, Firmware Version 9.00.00.00

Target 9
  Unit 0    Disk    SEAGATE    ST930003SSUN300G 0B70    585937500 Blocks, 300 GB
  SASDeviceName 5000c5001d33fba7 SASAddress 5000c5001d33fba5 PhyNum 0
Target a
  Unit 0    Removable Read Only device    TEAC        DV-W28SS-R    1.0C
  SATA Device PhyNum 6
Target b
  Unit 0    Disk    HITACHI    H103030SCSUN300G A2A8    585937500 Blocks, 300 GB
  SASDeviceName 5000cca00a76e380 SASAddress 5000cca00a76e381 PhyNum 1
Target c
  Unit 0    Disk    SEAGATE    ST930003SSUN300G 0B70    585937500 Blocks, 300 GB
  SASDeviceName 5000cca00a76ddcc SASAddress 5000cca00a76ddcd PhyNum 2
Target d
  Unit 0    Disk    HITACHI    H106060SDSUN600G A2B0    1172123568 Blocks, 600 GB
  SASDeviceName 5000cca01201e544 SASAddress 5000cca01201e545 PhyNum 3

/pci@400/pci@1/pci@0/pci@4/scsi@0                                <---- SAS controller 0

FCode Version 1.00.56, MPT Version 2.00, Firmware Version 9.00.00.00

Target 9
  Unit 0    Disk    HITACHI    H103030SCSUN300G A2A8    585937500 Blocks, 300 GB
  SASDeviceName 5000cca00a75dcac SASAddress 5000cca00a75dcad PhyNum 0
Target a
  Unit 0    Disk    SEAGATE    ST930003SSUN300G 0B70    585937500 Blocks, 300 GB
```

```
SASDeviceName 5000c5001d33eb5f SASAddress 5000c5001d33eb5d PhyNum 1
Target 523 Volume 0
Unit 0 Disk LSI Logical Volume 3000 583983104 Blocks, 298 GB
VolumeDeviceName 3ce534e42c02a3c0 VolumeWWID 0ce534e42c02a3c0

ok
```

In this example, the controller ports are attached to the hard drives and the DVD in the following manner:

SAS2 Controller	Controller Port (PhyNum)	Disk Slot ID	Target	SAS2 Controller	Controller Port (PhyNum)	Disk Slot ID	Target
0	0	0*	9	1	0	4	9
	1	1	a		1	5	b
	2	2	RAID Target 523		2	6	c
	3	3	RAID Target 523		3	7	d
					6	DVD	a

* Default boot drive

Note – Target values are not static. The same storage device can appear in two consecutive probe-scsi-all listings with different Target values.

The default boot device has the following values:

- Controller = 0
- Target = 9
- PhyNum = 0
- SASDeviceName = 5000cca00a75dcac
- SASAddress = 5000cca00a75dcad

If you want to specify another drive to be the boot device, find its PhyNum value in the output and use the SASDeviceName assigned to that device. For example, if you want to use the hard drive in disk slot 5, it has the following values:

- Controller = 1
- Target = b
- PhyNum = 1
- SASDeviceName = 5000cca00a76e380

- SASAddress = 5000cca00a76e381

Related Information

- [“World Wide Name Syntax” on page 79](#)
- [“probe-scsi-all WWN Mapping Overview” on page 81](#)
- [“WWN Syntax in an OS Installation on an Individual Drive” on page 104](#)
- [“WWN Syntax in an OS Installation on a RAID Volume” on page 105](#)

probe-scsi-all WWN Mapping Example (Netra SPARC T4-1)

The Netra SPARC T4-1 server uses only one of the two SAS2 RAID controllers on the motherboard. The controller connects to one slot on the disk backplane. The following table shows the PhyNum-to-disk slot mapping.

TABLE: SAS2 Controller Port Mapping for the Netra SPARC T4-1 Disk Backplane

SAS2 Controller	Controller Port (PhyNum)	Disk Slot	SAS2 Controller	Controller Port (PhyNum)	Disk Slot
0	Not Used		1	0*	0
				1	1
				2	2
				3	3

* Default boot drive

The following example is based on a Netra SPARC T4-1 server with four hard drives. These hard drives are deployed as four individual storage devices. Controller 1 is attached to these storage devices in the following manner:

- Controller 1 is attached to Targets 9, b, c, and d (four individual storage devices).
- Target a (is a DVD drive).

Note – For Netra SPARC T4-1 servers, the second field of the device path specifies the controllers: /pci@400/pci@2 = controller 1 and /pci@400/pci@1 = controller 0.

```
ok probe-scsi-all
/pci@400/pci@2/pci@0/pci@f/pci@0/usb@0,2/hub@2/hub@3/storage@2
Unit 0   Removable Read Only device   AMI       Virtual CDROM   1.00
```

```
/pci@400/pci@2/pci@0/pci@4/scsi@0                <---- SAS controller 1

FCode Version 1.00.56, MPT Version 2.00, Firmware Version 9.00.00.00

Target 9
Unit 0   Disk HITACHI  H106030SDSUN300G A2B0      585937500 Blocks, 300 GB
SASDeviceName 5000cca012b76b40 SASAddress 5000cca012b76b41  PhyNum 0<-HD slot 0
Target a
Unit 0   Removable Read Only device  TEAC      DV-W28SS-V      1.0B
SATA device  PhyNum 6                                <- DVD
Target b
Unit 0   Disk  HITACHI  H103030SCSUN300G A2A8      585937500 Blocks, 300 GB
SASDeviceName 5000cca00a4d2ff0 SASAddress 5000cca00a4d2ff1  PhyNum 2<-HD slot 2
Target c
Unit 0   Disk  SEAGATE  ST930003SSUN300G 0868      585937500 Blocks, 300 GB
SASDeviceName 5000c50017871633 SASAddress 5000c50017871631  PhyNum 1 <- HD slot 1
Target d
Unit 0   Disk  SEAGATE  ST930003SSUN300G 0868      585937500 Blocks, 300 GB
SASDeviceName 5000c5001cb42adf SASAddress 5000c5001cb42add  PhyNum 3 <- HD slot 3

/pci@400/pci@1/pci@0/pci@4/scsi@0                <---- SAS controller 0 (Not Used)

FCode Version 1.00.56, MPT Version 2.00, Firmware Version 9.00.00.00

ok
```

In this example, the controller ports are attached to the hard drives and the DVD in the following manner:

SAS2 Controller	Controller Port (PhyNum)	Disk Slot ID	Target	SAS2 Controller	Controller Port (PhyNum)	Disk Slot ID	Target
0		Not Used		1	0*	0	9
					1	1	b
					2	2	c
					3	3	d
					6	DVD	a

* Default boot drive

Note – Target values are not static. The same storage device can appear in two consecutive probe-scsi-all listings with different Target values.

The default boot device has the following values:

- Controller = 1
- Target = 9
- PhyNum = 0
- SASDeviceName = 5000cca012b76b40
- SASAddress = 5000cca012b76b41

If you want to specify another drive to be the boot device, find its `PhyNum` value in the output and use the `SASDeviceName` assigned to that device. For example, if you want to use the hard drive in disk slot 2, it has the following values:

- Controller = 1
- Target = b
- PhyNum = 2
- SASDeviceName = 5000cca00a4d2ff0
- SASAddress = 5000cca00a4d2ff1

Related Information

- [“World Wide Name Syntax” on page 79](#)
- [“probe-scsi-all WWN Mapping Overview” on page 81](#)
- [“WWN Syntax in an OS Installation on an Individual Drive” on page 104](#)
- [“WWN Syntax in an OS Installation on a RAID Volume” on page 105](#)

probe-scsi-all WWN Mapping Example (SPARC T4-2)

The SPARC T4-2 server has one SAS2 RAID controller on the motherboard. This controller is connected to six slots on the disk backplane.

The following table shows the `PhyNum`-to-disk slot mapping for the six-slot SPARC T4-2 backplane.

TABLE: SAS2 Controller Port Mapping for the SPARC T4-2 Disk Backplane

SAS2 Controller	Controller Port (PhyNum)	Disk Slots and DVD
0	0	0*
	1	1
	2	2
	3	3
	4	4
	5	5
	6	Not connected
	7	DVD

* Default boot drive

The following example is based on a SPARC T4-2 server with six hard drives. These hard drives are deployed as four individual storage devices and a virtual drive that consists of two hard drives configured as a RAID volume. The controller is attached to these devices in the following manner:

- Targets 9, d, e, and f (four individual storage devices).
- Target 389 (a RAID volume).
- Target a (a DVD unit).

```
ok probe-scsi-all
/pci@400/pci@2/pci@0/pci@4/scsi@0                                <---- SAS controller

FCode Version 1.00.56, MPT Version 2.00, Firmware Version 9.00.00.00

Target 9
  Unit 0   Disk   SEAGATE  ST930003SSUN300G 0868 585937500 Blocks, 300 GB
  SASDeviceName 5000c5001cb4a637 SASAddress 5000c5001cb4a635 PhyNum 0
Target a
  Unit 0   Removable Read Only device  TEAC    DV-W28SS-R      1.0C
  SATA device  PhyNum 7
Target d
  Unit 0   Disk   HITACHI  H103030SCSUN300G A2A8    585937500 Blocks, 300 GB
  SASDeviceName 5000c5001cb477cb SASAddress 5000c5001cb477c9 PhyNum 1
Target e
  Unit 0   Disk   SEAGATE  ST930003SSUN300G 0B70    585937500 Blocks, 300 GB
  SASDeviceName 5000c5001cb47f93 SASAddress 5000c5001cb47f91 PhyNum 2
Target f
```

```
Unit 0   Disk   SEAGATE   ST930003SSUN300G 0B70      585937500 Blocks, 300 GB
SASDeviceName 5000c5001cb47f7f SASAddress 5000c5001cb47f7d PhyNum 3
Target 389 Volume 0
Unit 0   Disk   LSI       Logical Volume 3000 583983104 Blocks, 298 GB
VolumeDeviceName 3ce534e42c02a3c0 VolumeWWID 0ce534e42c02a3c0

/pci@400/pci@1/pci@0/pci@b/pci@0/usb@0,2/hub@2/hub@3/storage@2
Unit 0   Removable Read Only device   AMI       Virtual CDROM    1.00

ok
```

In this example, the controller ports are attached to the hard drives and the DVD in the following manner:

SAS2 Controller	Controller Port (PhyNum)	Disk Slot ID	Target
0	0	0*	9
	1	1	d
	2	2	e
	3	3	f
	4	4	RAID Target 389
	5	5	RAID Target 389
	6	Not connected	--
	7	DVD	a

* Default boot drive

Note – Target values are not static. The same storage device can appear in two consecutive probe-scsi-all listings with different Target values.

The default boot device has the following values:

- Controller = 0
- Target = 9
- PhyNum = 0
- SASDeviceName = 5000c5001cb4a637
- SASAddress = 5000c5001cb4a635

If you want to specify another drive to be the boot device, find its `PhyNum` value in the output and use the `SASDeviceName` assigned to that device. For example, if you want to use the hard drive in disk slot 3, it has the following values:

- `Controller = 0`
- `Target = f`
- `PhyNum = 3`
- `SASDeviceName = 5000c5001cb47f7f`
- `SASAddress = 5000c5001cb47f7d`

Related Information

- [“World Wide Name Syntax” on page 79](#)
- [“probe-scsi-all WWN Mapping Overview” on page 81](#)
- [“WWN Syntax in an OS Installation on an Individual Drive” on page 104](#)
- [“WWN Syntax in an OS Installation on a RAID Volume” on page 105](#)

probe-scsi-all WWN Mapping Example (Netra SPARC T4-2)

The Netra SPARC T4-2 server has one SAS2 RAID controller on the motherboard. This controller is connected to eight hard drive slots on the disk backplane and one DVD slot.

The following table shows the `PhyNum`-to-disk slot mapping for the Netra SPARC T4-2 backplane.

SAS2 Controller	Controller Port (PhyNum)	Disk Slot ID	Target	SAS2 Controller	Controller Port (PhyNum)	Disk Slot ID	Target
0	0*	0	9	1	0	4	9
	1	1	a		1	5	b
	2	2	b		2	6	c
	3	3	c		3	7	d
					6	DVD	a

* Default boot drive

The following example is based on a Netra SPARC T4-2 server with eight hard drives.

```
ok probe-scsi-all
/pci@500/pci@1/pci@0/pci@4/scsi@0                                <---- SAS controller 1

FCode Version 1.00.56, MPT Version 2.00, Firmware Version 9.00.00.00

Target 9
Unit 0 Disk    HITACHI  H106060SDSUN600G A2B0      1172123568 Blocks, 600 GB
SASDeviceName 5000cca012640718 SASAddress 5000cca012640719 PhyNum 0<-HD slot 4
Target a
Unit 0 Removable Read Only device    TEAC      DV-W28SS-V      1.0B
SATA device  PhyNum 6 <-DVD
Target b
Unit 0  Disk    HITACHI  H106060SDSUN600G A2B0      1172123568 Blocks, 600 G
SASDeviceName 5000cca01263ce30 SASAddress 5000cca01263ce31 PhyNum 1<-HD slot 5
Target c
Unit 0  Disk    HITACHI  H106060SDSUN600G A2B0      1172123568 Blocks, 600 GB
SASDeviceName 5000cca01261b2fc SASAddress 5000cca01261b2fd PhyNum 2<-HD slot 6
Target d
Unit 0  Disk    HITACHI  H106060SDSUN600G A2B0      1172123568 Blocks, 600 GB
SASDeviceName 5000cca012633e3c SASAddress 5000cca012633e3d PhyNum 3<-HD slot 7

/pci@400/pci@2/pci@0/pci@e/scsi@0                                <---- SAS controller 0

FCode Version 1.00.56, MPT Version 2.00, Firmware Version 9.00.00.00

Target 9
Unit 0  Disk    HITACHI  H106060SDSUN600G A2B0      1172123568 Blocks, 600 GB
SASDeviceName 5000cca0120f9dbc SASAddress 5000cca0120f9dbd PhyNum 0<-HD slot 0
Target a
Unit 0  Disk    HITACHI  H106060SDSUN600G A2B0      1172123568 Blocks, 600 GB
SASDeviceName 5000cca012633c18 SASAddress 5000cca012633c19 PhyNum 1<-HD slot 1
Target b
Unit 0  Disk    HITACHI  H106060SDSUN600G A2B0      1172123568 Blocks, 600 GB
SASDeviceName 5000cca0126406ec SASAddress 5000cca0126406ed PhyNum 2<-HD slot 2
Target c
Unit 0  Disk    HITACHI  H106060SDSUN600G A2B0      1172123568 Blocks, 600 GB
SASDeviceName 5000cca01260f594 SASAddress 5000cca01260f595 PhyNum 3<-HD slot 3

/pci@400/pci@1/pci@0/pci@b/pci@0/usb@0,2/hub@2/hub@3/storage@2
Unit 0  Removable Read Only device    AMI      Virtual CDROM    1.00

ok
```

Note – Target values are not static. The same storage device can appear in two consecutive `probe-scsi-all` listings with different Target values.

The default boot device has the following values:

- Controller = 0
- Target = 9
- PhyNum = 0
- SASDeviceName = 5000cca0120f9dbc
- SASAddress = 5000cca0120f9dbd

If you want to specify another drive to be the boot device, find its `PhyNum` value in the output and use the `SASDeviceName` assigned to that device. For example, if you want to use the hard drive in disk slot 3, it has the following values:

- Controller = 0
- Target = c
- PhyNum = 3
- SASDeviceName = 5000cca01260f594
- SASAddress = 5000cca01260f595

Related Information

- [“World Wide Name Syntax” on page 79](#)
- [“probe-scsi-all WWN Mapping Overview” on page 81](#)
- [“WWN Syntax in an OS Installation on an Individual Drive” on page 104](#)
- [“WWN Syntax in an OS Installation on a RAID Volume” on page 105](#)

probe-scsi-all WWN Mapping Example (SPARC T4-4 With Four CPUs)

The SPARC T4-4 server has two REM cards plugged into the motherboard. These modules are referred to as controllers 0 and 1. Each SAS controller is connected to a separate four-slot disk backplane. The following table shows the `PhyNum`-to-disk slot mapping for the two four-slot SPARC T4-4 backplanes.

TABLE: SAS2 Controller Port Mapping for the SPARC T4-4 Disk Backplane

Disk Backplane 0			Disk Backplane 1		
SAS2 Controller	Controller Port ID (PhyNum)	Disk Slot ID	SAS2 Controller	Controller Port ID (PhyNum)	Disk Slot ID
0	0	0*	1	0	4
	1	1		1	5
	2	2		2	6
	3	3		3	7

* Default boot drive

This table shows that ports 0-3 of controller 0 are connected to backplane slots 0-3 and ports 0-3 of controller 1 are connected to slots 4-7.

The following example is based on a SPARC T4-4 server with four CPUs and eight hard drives. These hard drives are deployed as six individual storage devices and a virtual drive that consists of two hard drives configured as a RAID volume.

Controllers 0 and 1 are attached to these storage devices in the following manner:

- Controller 0 is attached to Targets 9 and a (two individual storage devices).
- Controller 0 is also attached to Target 688 (a RAID volume).
- Controller 1 is attached to Targets 9, a, b, and c (four individual storage devices).

Note – OBP uses a different device path for SAS controller 1 in SPARC T4-4 servers, depending on whether the server has four processors or two processors. The path for SAS controller 0 is the same for both processor configurations.

```
ok probe-scsi-all
/pci@700/pci@1/pci@0/pci@0/LSI,sas@0                                <---- SAS controller 1

FCode Version 1.00.54, MPT Version 2.00, Firmware Version 5.00.17.00

Target 9
  Unit 0   Disk   HITACHI  H103030SCSUN300G A2A8      585937500 Blocks, 300 GB
  SASDeviceName 5000cca00abc5cc8 SASAddress 5000cca00abc5cc9 PhyNum 0
Target a
  Unit 0   Disk   HITACHI  H103030SCSUN300G A2A8      585937500 Blocks, 300 GB
  SASDeviceName 5000cca00abaf620 SASAddress 5000cca00abaf621 PhyNum 1
Target b
  Unit 0   Disk   HITACHI  H103030SCSUN300G A2A8      585937500 Blocks, 300 GB
  SASDeviceName 5000cca00abcec4c SASAddress 5000cca00abcec4d PhyNum 2
```

```

Target c
  Unit 0   Disk   HITACHI   H103030SCSUN300G A2A8       585937500 Blocks, 300 GB
  SASDeviceName 5000cca00abc5218  SASAddress 5000cca00abc5219  PhyNum 3

/pci@400/pci@1/pci@0/pci@0/LSI,sas@0                <---- SAS controller 0

FCode Version 1.00.54, MPT Version 2.00, Firmware Version 5.00.17.00

Target 9
  Unit 0   Disk   HITACHI   H103030SCSUN300G A2A8       585937500 Blocks, 300 GB
  SASDeviceName 5000cca00abcde0  SASAddress 5000cca00abcde1  PhyNum 0
Target a
  Unit 0   Disk   HITACHI   H103030SCSUN300G A2A8       585937500 Blocks, 300 GB
  SASDeviceName 5000cca00abc51a8  SASAddress 5000cca00abc51a9  PhyNum 1
Target 688 Volume 0
  Unit 0   Disk   LSI       Logical Volume   3000    583983104 Blocks,    298 GB
  VolumeDeviceName 3ce534e42c02a3c0  VolumeWWID 0ce534e42c02a3c0

ok

```

In this example, the controller ports are attached to the hard drives in the following manner:

Disk Backplane 0			Disk Backplane 1		
Controller Port (PhyNum)	Disk Slot ID	Target	Controller Port (PhyNum)	Disk Slot ID	Target
0	0*	9	0	4	9
1	1	a	1	5	a
2	2	RAID Target 688	2	6	b
3	3	RAID Target 688	3	7	c

* Default boot drive

Note – Target values are not static. The same storage device can appear in two consecutive `probe-scsi-all` listings with different Target values.

The default boot device has the following values:

- Controller = 0
- Target = 9

- `PhyNum = 0`
- `SASDeviceName = 5000cca00abcede0`
- `SASAddress = 5000cca00abcede1`

If you want to specify another drive to be the boot device, find its `PhyNum` value in the output and use the `SASDeviceName` assigned to that device. For example, if you want to use the hard drive in disk slot 1, it has the following values:

- `Controller = 0`
- `Target = a`
- `PhyNum = 1`
- `SASDeviceName = 5000cca00abc51a8`
- `SASAddress = 5000cca00abc51a9`

Related Information

- [“World Wide Name Syntax” on page 79](#)
- [“probe-scsi-all WWN Mapping Overview” on page 81](#)
- [“WWN Syntax in an OS Installation on an Individual Drive” on page 104](#)
- [“WWN Syntax in an OS Installation on a RAID Volume” on page 105](#)

probe-scsi-all WWN Mapping Example (SPARC T4-4 With Two CPUs)

The SPARC T4-4 server has two REM cards plugged into the motherboard. These modules are referred to as controllers 0 and 1. Each SAS controller is connected to a separate four-slot disk backplane. The following table shows the `PhyNum`-to-disk slot mapping for the two four-slot SPARC T4-4 backplanes.

TABLE: SAS2 Controller Port Mapping for the SPARC T4-4 Disk Backplane

Disk Backplane 0			Disk Backplane 1		
SAS2 Controller	Controller Port ID (PhyNum)	Disk Slot ID	SAS2 Controller	Controller Port ID (PhyNum)	Disk Slot ID
0	0	0*	1	0	4
	1	1		1	5
	2	2		2	6
	3	3		3	7

* Default boot drive

This table shows that ports 0-3 of controller 0 are connected to backplane slots 0-3 and ports 0-3 of controller 1 are connected to slots 4-7.

The following example is based on a SPARC T4-4 server with two CPUs and eight hard drives. These hard drives are deployed as six individual storage devices and a virtual drive that consists of two hard drives configured as a RAID volume.

Controllers 0 and 1 are attached to these storage devices in the following manner:

- Controller 0 is attached to Targets 9 and a (two individual storage devices).
- Controller 0 is also attached to Target 457 (a RAID volume).
- Controller 1 is attached to Targets 9, a, b, and c (four individual storage devices).

Note – OBP uses a different device path for SAS controller 1 in SPARC T4-4 servers, depending on whether the server has four processors or two processors. The path for SAS controller 0 is the same for both processor configurations.

```
ok probe-scsi-all
/pci@500/pci@1/pci@0/pci@0/LSI,sas@0                <---- SAS controller 1

FCode Version 1.00.54, MPT Version 2.00, Firmware Version 5.00.17.00

Target 9
  Unit 0   Disk   HITACHI   H103030SCSUN300G A2A8       585937500 Blocks, 300 GB
  SASDeviceName 5000cca00abc5cc8 SASAddress 5000cca00abc5cc9 PhyNum 0
Target a
  Unit 0   Disk   HITACHI   H103030SCSUN300G A2A8       585937500 Blocks, 300 GB
  SASDeviceName 5000cca00abaf620 SASAddress 5000cca00abaf621 PhyNum 1
Target b
  Unit 0   Disk   HITACHI   H103030SCSUN300G A2A8       585937500 Blocks, 300 GB
  SASDeviceName 5000cca00abcec4c SASAddress 5000cca00abcec4d PhyNum 2
Target c
  Unit 0   Disk   HITACHI   H103030SCSUN300G A2A8       585937500 Blocks, 300 GB
  SASDeviceName 5000cca00abc5218 SASAddress 5000cca00abc5219 PhyNum 3

/pci@400/pci@1/pci@0/pci@8/pci@0/usb@0,2/hub@2/hub@3/storage@2
Unit 0   Removable Read Only device   AMI       Virtual CDROM   1.00

/pci@400/pci@1/pci@0/pci@0/LSI,sas@0                <---- SAS controller 0

FCode Version 1.00.54, MPT Version 2.00, Firmware Version 5.00.17.00

Target 9
  Unit 0   Disk   HITACHI   H103030SCSUN300G A2A8       585937500 Blocks, 300 GB
  SASDeviceName 5000cca00abcede0 SASAddress 5000cca00abcede1 PhyNum 0
```

```

Target a
  Unit 0   Disk   HITACHI   H103030SCSUN300G A2A8      585937500 Blocks, 300 GB
  SASDeviceName 5000cca00abc51a8  SASAddress 5000cca00abc51a9  PhyNum 1
Target 457 Volume 0
  Unit 0   Disk   LSI       Logical Volume   3000    583983104 Blocks,   298 GB
  VolumeDeviceName 3ce534e42c02a3c0  VolumeWWID 0ce534e42c02a3c0

ok

```

In this example, the controller ports are attached to the hard drives in the following manner:

Disk Backplane 0			Disk Backplane 1		
Controller Port (PhyNum)	Disk Slot ID	Target	Controller Port (PhyNum)	Disk Slot ID	Target
0	0*	9	0	4	9
1	1	a	1	5	a
2	2	RAID Target 457	2	6	b
3	3	RAID Target 457	3	7	c

* Default boot drive

Note – Target values are not static. The same storage device can appear in two consecutive `probe-scsi-all` listings with different Target values.

The default boot device has the following values:

- Controller = 0
- Target = 9
- PhyNum = 0
- SASDeviceName = 5000cca00abcede0
- SASAddress = 5000cca00abcede1

If you want to specify another drive to be the boot device, find its `PhyNum` value in the output and use the `SASDeviceName` assigned to that device. For example, if you want to use the hard drive in disk slot 1, it has the following values:

- Controller = 0
- Target = a

- PhyNum = 1
- SASDeviceName = 5000cca00abc51a8
- SASAddress = 5000cca00abc51a9

Related Information

- [“World Wide Name Syntax” on page 79](#)
- [“probe-scsi-all WWN Mapping Overview” on page 81](#)
- [“WWN Syntax in an OS Installation on an Individual Drive” on page 104](#)
- [“WWN Syntax in an OS Installation on a RAID Volume” on page 105](#)

probe-scsi-all WWN Mapping Example (SPARC T4-1B and Netra SPARC T4-1B)

The SPARC and Netra SPARC T4-1B blades have two SCSI disk slots in the disk backplane. A Sun Blade 6000 RAID 0/1 SAS2 HBA REM, which is plugged into the motherboard, manages storage devices installed in these backplane slots.

The following table shows the PhyNum-to-disk slot mapping for the two-slot SPARC T4-1B backplane.

TABLE: SAS2 Controller Port Mapping for the SPARC T4-1B Disk Backplane

Controller Port (PhyNum)	Controller Port (PhyNum)
0	1
Disk Slot ID	Disk Slot ID
0*	1

* Default boot drive

The following example is based on a SPARC T4-1B blade with both hard drives attached to the controller as individual storage devices.

```
ok probe-scsi-all
/pci@400/pci@1/pci@0/pci@c/LSI,sas@0          <===== SAS Controller

FCode Version 1.00.54, MPT Version 2.00, Firmware Version 5.00.17.00

Target 9
  Unit 0   Disk      SEAGATE ST930003SSUN300G 0868      585937500 Blocks, 300 GB
  SASDeviceName 5000c500231694cf SASAddress 5000c500231694cd PhyNum 0
```

```

Target a
Unit 0   Disk      SEAGATE ST973402SSUN72G 0603      143374738 Blocks, 73 GB
SASDeviceName 5000c50003d37fcb SASAddress 5000c50003d37fc9   PhyNum 1

/pci@400/pci@1/pci@0/pci@0/pci@0/usb@0,2/hub@3/storage@2
Unit 0   Removable Read Only device    AMI      Virtual CDROM    1.00

ok

```

In this example, the controller ports are attached to the hard drives in the following manner:

Controller Port (PhyNum)	Controller Port (PhyNum)
0	1
Target 9 (Disk Slot ID 0)	Target a (Disk Slot ID 1)

Note – Target values are not static. The same storage device can appear in two consecutive `probe-scsi-all` listings with different Target values.

The default boot device has the following values:

- Controller = 0
- Target = 9
- PhyNum = 0
- SASDeviceName = 5000c500231694cf
- SASAddress = 5000c500231694cd

If you want to specify the hard drive in disk slot 1 to be the boot device, it would have the following values in this example:

- Controller = 0
- Target = a
- PhyNum = 1
- SASDeviceName = 5000c50003d37fcb
- SASAddress = 5000c50003d37fc9

The following example is based on a SPARC T4-1B blade with both hard drives attached to the controller as a RAID volume.

```
ok probe-scsi-all
/pci@400/pci@1/pci@0/pci@2/LSI,sas@0          <===== SAS Controller

FCode Version 1.00.54, MPT Version 2.00, Firmware Version 5.00.17.00

Target 377 Volume 0
  Unit 0   Disk   LSI       Logical Volume   3000   583983104 Blocks,   298 GB
  VolumeDeviceName 3ce534e42c02a3c0   VolumeWWID 0ce534e42c02a3c0

/pci@400/pci@1/pci@0/pci@0/pci@0/usb@0,2/hub@3/storage@2
  Unit 0   Removable Read Only device   AMI       Virtual CDROM   1.00

ok
```

In this example, the controller ports are attached to a RAID volume containing the hard drives installed in disk slots 0 and 1.

Related Information

- [“World Wide Name Syntax” on page 79](#)
- [“probe-scsi-all WWN Mapping Overview” on page 81](#)
- [“WWN Syntax in an OS Installation on an Individual Drive” on page 104](#)
- [“WWN Syntax in an OS Installation on a RAID Volume” on page 105](#)

▼ Identify a Disk Slot Using prtconf (Oracle Solaris OS)

The procedure described below applies to SPARC T4-1 and SPARC T4-4 servers, which have eight-disk backplane configurations. The same methodology can be used for the SPARC T4-2 server and SPARC T4-1B blade systems.

1. Run the format command.

```
# format
Searching for disks...done

AVAILABLE DISK SELECTIONS:
  0. c0t5000CCA00ABBAEB8d0 <SUN300G cyl 46873 alt 2 hd 20 sec 625>
    /scsi_vhci/disk@g5000cca00abbaeb8
  1. c0t5000C5001D40D7F7d0 <SUN300G cyl 46873 alt 2 hd 20 sec 625>
    /scsi_vhci/disk@g5000c5001d40d7f7
[...]
```

The remaining steps in this example will identify the physical slot that corresponds to the device name `c0t5000CCA00ABBAEB8d0`.

2. Run `prtconf -v` and search for the device link containing the device name `c0t5000CCA00ABBAEB8d0`.

```
Device Minor Nodes:
dev=(32,0)
dev_path=/scsi_vhci/disk@g5000cca00abbaeb8:a
spectype=blk type=minor
dev_link=/dev/dsk/c0t5000CCA00ABBAEB8d0s0      <==== Device link
dev_link=/dev/sd3a
dev_path=/scsi_vhci/disk@g5000cca00abbaeb8:a,raw
spectype=chr type=minor
dev_link=/dev/rdisk/c0t5000CCA00ABBAEB8d0s0    <==== Device link
dev_link=/dev/rsd3a
```

3. Search the `prtconf` output for the `name='wwn'` entry that shows the WWN value `5000cca00abbaeb8`.

Note the `obp-path` value listed under WWN `5000cca00abbaeb8`.

Refer to the following table to find the controller.

SPARC T4-1

Controller 0 /pci@400/pci@1/pci@0/pci@4/scsi@0/disk@w5000cca00abbaeb9,0

Controller 1 /pci@400/pci@2/pci@0/pci@4/scsi@0/disk@w5000cca00abbaeb9,0

SPARC T4-4

(4 processor)

Controller 0 /pci@400/pci@1/pci@0/pci@0/LSI,sas@0/disk@w5000cca00abbaeb9,0

Controller 1 /pci@700/pci@1/pci@0/pci@0/LSI,sas@0/disk@w5000cca00abbaeb9,0

SPARC T4-4

(2 processor)

Controller 0 /pci@400/pci@1/pci@0/pci@0/LSI,sas@0/disk@w5000cca00abbaeb9,0

Controller 1 /pci@500/pci@1/pci@0/pci@0/LSI,sas@0/disk@w5000cca00abbaeb9,0

For SPARC T4-1 servers, the controller is identified in the second field: pci@1 = controller 0 and pci@2 = controller 1.

For SPARC T4-4 servers, the controller is identified in the first field. For systems with a four-processor configuration, pci@400 = controller 0 and pci@700 = controller 1. For systems with a two-processor configuration, pci@400 = controller 0 and pci@500 = controller 1.

Note – Because SPARC T4-2 and SPARC T4-1B systems contain only one SAS controller, only controller 0 will be listed.

The following output example shows the `obp-path` for a SPARC T4-1 server.

```
Paths from multipath bus adapters:
mpt_sas#5 (online)
  name='wwn' type=string items=1
    value='5000cca00abbaeb8'           <<==== Hard drive WWN ID
  name='lun' type=int items=1
    value=00000000
  name='target-port' type=string items=1
    value='5000cca00abbaeb9'           <<==== Hard drive SAS address
  name='obp-path' type=string items=1
    value='/pci@400/pci@1/pci@0/pci@4/scsi@0/disk@w5000cca00abbaeb9,0'
  name='phy-num' type=int items=1
    value=00000000
  name='path-class' type=string items=1
    value='primary'
```

In this SPARC T4-1 example, the `obp-path` is:

```
/pci@400/pci@1/pci@0/pci@4/scsi@0/disk@w5000cca00abbaeb9,0
```

Based on the previous table, this disk is on controller 0.

The following output example shows the `obp-path` for a SPARC T4-4 server.

```
Paths from multipath bus adapters:
mpt_sas#5 (online)
  name='wwn' type=string items=1
    value='5000cca00abbaeb8'           <<==== Hard drive WWN ID
  name='lun' type=int items=1
    value=00000000
  name='target-port' type=string items=1
    value='5000cca00abbaeb9'           <<==== Hard drive SAS address
  name='obp-path' type=string items=1
    value='/pci@400/pci@1/pci@0/LSI,sas@0/disk@w5000cca00abbaeb9,0'
  name='phy-num' type=int items=1
    value=00000000
  name='path-class' type=string items=1
    value='primary'
```

In this SPARC T4-4 example, the obp-path is:

/pci@400/pci@1/pci@0/pci@0/LSI,sas@0/disk@w5000cca00abbaeb9,0

Based on the previous table, this disk is on controller 0.

4. This phy-num value corresponds to physical disk slot 0, as shown in the following port mapping table.

SAS Controller	PhyNum	Disk Slot	SAS Controller	PhyNum	Disk Slot
0	0	0*	1	0	4
	1	1		1	5
	2	2		2	6
	3	3		3	7

* Default boot drive

Related Information

- [“World Wide Name Syntax” on page 79](#)
- [“probe-scsi-all WWN Mapping Overview” on page 81](#)
- [“WWN Syntax in an OS Installation on an Individual Drive” on page 104](#)
- [“WWN Syntax in an OS Installation on a RAID Volume” on page 105](#)

WWN Syntax in an OS Installation on an Individual Drive

The following Oracle Solaris Jumpstart profile example shows how to use the WWN syntax when installing the operating system on a specific disk drive. In this example, the device name contains the WWN value 5000CCA00A75DCAC.

Note – All alpha characters in the WWN value must be capitalized.

install_type flash_install
boot_device c0t5000CCA00A75DCACd0s0 preserve

```

archive_location nfs
***.***.***.***:/export/install/media/solaris/builds/s10u9/flar/latest.flar

# Disk layouts
#
partitioning explicit
filesys rootdisk.s0      free /
filesys rootdisk.s1      8192 swap

```

Related Information

- [“World Wide Name Syntax” on page 79](#)
- [“probe-scsi-all WWN Mapping Overview” on page 81](#)
- [“Mapping WWN Values to Hard Drives \(OBP probe-scsi-all Command\)” on page 80](#)
- [“Identify a Disk Slot Using prtconf \(Oracle Solaris OS\)” on page 100](#)
- [“WWN Syntax in an OS Installation on a RAID Volume” on page 105](#)

WWN Syntax in an OS Installation on a RAID Volume

The following Oracle Solaris Jumpstart profile example shows how to use the WWN syntax when installing the OS on a RAID volume. When installing software on a RAID volume, use the virtual device’s `VolumeDeviceName` instead of an individual device name. In this example, the RAID volume name is `3ce534e42c02a3c0`.

```

#
install_type flash_install
boot_device 3ce534e42c02a3c0      preserve

archive_location nfs
***.***.***.***:/export/install/media/solaris/builds/s10u9/flar/latest.flar

# Disk layouts
#
partitioning explicit
filesys rootdisk.s0      free /
filesys rootdisk.s1      8192 swap

```

Related Information

- [“World Wide Name Syntax” on page 79](#)
- [“probe-scsi-all WWN Mapping Overview” on page 81](#)
- [“Mapping WWN Values to Hard Drives \(OBP probe-scsi-all Command\)” on page 80](#)
- [“Identify a Disk Slot Using prtconf \(Oracle Solaris OS\)” on page 100](#)
- [“WWN Syntax in an OS Installation on an Individual Drive” on page 104](#)

Glossary

A

ANSI SIS	American National Standards Institute Status Indicator Standard.
ASF	Alert standard format (Netra products only).
ASR	Automatic system recovery.
AWG	American wire gauge.

B

blade	Generic term for server modules and storage modules. See <i>server module</i> and <i>storage module</i> .
blade server	Server module. See <i>server module</i> .
BMC	Baseboard management controller.
BOB	Memory buffer on board.

C

chassis	For servers, refers to the server enclosure. For server modules, refers to the modular system enclosure.
CMA	Cable management arm.

CMM	Chassis monitoring module. The CMM is the service processor in the modular system. Oracle ILOM runs on the CMM, providing lights out management of the components in the modular system chassis. <i>See Modular system and Oracle ILOM.</i>
CMM Oracle ILOM	Oracle ILOM that runs on the CMM. <i>See Oracle ILOM.</i>
CMP	Chip multiprocessor.

D

DHCP	Dynamic Host Configuration Protocol.
disk module or disk blade	Interchangeable terms for storage module. <i>See storage module.</i>
DTE	Data terminal equipment.

E

EIA	Electronics Industries Alliance.
ESD	Electrostatic discharge.

F

FEM	Fabric expansion module. FEMs enable server modules to use the 10GbE connections provided by certain NEMs. <i>See NEM.</i>
FRU	Field-replaceable unit.

H

HBA	Host bus adapter.
------------	-------------------

host The part of the server or server module with the CPU and other hardware that runs the Oracle Solaris OS and other applications. The term *host* is used to distinguish the primary computer from the SP. See [SP](#).

I

ID PROM Chip that contains system information for the server or server module.

IP Internet Protocol.

K

KVM Keyboard, video, mouse. Refers to using a switch to enable sharing of one keyboard, one display, and one mouse with more than one computer.

L

LwA Sound power level.

M

MAC Machine access code.

MAC address Media access controller address.

Modular system The rackmountable chassis that holds server modules, storage modules, NEMs, and PCI EMs. The modular system provides Oracle ILOM through its CMM.

MSGID Message identifier.

N

name space	Top-level Oracle ILOM CMM target.
NEBS	Network Equipment-Building System (Netra products only).
NEM	Network express module. NEMs provide 10/100/1000 Mbps Ethernet, 10GbE Ethernet ports, and SAS connectivity to storage modules.
NET MGT	Network management port. An Ethernet port on the server SP, the server module SP, and the CMM.
NIC	Network interface card or controller.
NMI	Nonmaskable interrupt.

O

OBP	OpenBoot PROM.
Oracle ILOM	Oracle Integrated Lights Out Manager. Oracle ILOM firmware is preinstalled on a variety of Oracle systems. Oracle ILOM enables you to remotely manage your Oracle servers regardless of the state of the host system.
Oracle Solaris OS	Oracle Solaris operating system.

P

PCI	Peripheral component interconnect.
PCI EM	PCIe ExpressModule. Modular components that are based on the PCI Express industry-standard form factor and offer I/O features such as Gigabit Ethernet and Fibre Channel.
POST	Power-on self-test.
PROM	Programmable read-only memory.
PSH	Predictive self healing.

Q

QSFP Quad small form-factor pluggable.

R

REM RAID expansion module. Sometimes referred to as an HBA *See* [HBA](#). Supports the creation of RAID volumes on drives.

S

SAS Serial attached SCSI.

SCC System configuration chip.

SER MGT Serial management port. A serial port on the server SP, the server module SP, and the CMM.

server module Modular component that provides the main compute resources (CPU and memory) in a modular system. Server modules might also have onboard storage and connectors that hold REMs and FEMs.

SP Service processor. In the server or server module, the SP is a card with its own OS. The SP processes Oracle ILOM commands providing lights out management control of the host. *See* [host](#).

SSD Solid-state drive.

SSH Secure shell.

storage module Modular component that provides computing storage to the server modules.

T

TIA Telecommunications Industry Association (Netra products only).

Tma Maximum ambient temperature.

U

UCP	Universal connector port.
UI	User interface.
UL	Underwriters Laboratory Inc.
US. NEC	United States National Electrical Code.
UTC	Coordinated Universal Time.
UUID	Universal unique identifier.

W

WWN	World wide name. A unique number that identifies a SAS target.
------------	--

Index

Symbols

- > prompt
 - about, 1
 - ways to access, 12

A

- alias, SCSI controller, 22
- Automatic System Recovery (ASR)
 - disabling, 68
 - enabling, 68
 - viewing affected components, 69

B

- boot mode
 - expiration date, 51
 - managing at reset, 49
 - managing configuration, 48
 - managing script, 50
 - managing system, 47
 - Oracle VM Server (LDom)s, 48
 - overview, 47

C

- cables, keyboard and mouse, 13
- console history, displaying, 63

D

- dealias command, 22
- device paths, 28
- devices
 - configuring, 58
 - managing, 57
 - unconfiguring, 57
- DHCP server, displaying IP Address, 40
- diagnostics, 59

F

- faults
 - bypassing, 67
 - clearing, 66
 - discovering with ILOM, 61
 - discovering with POST, 63
 - handling, 59
- FCode utility
 - commands, 23
 - RAID, 21
- firmware, updating, 73
- FRU data, changing, 31

H

- host power state
 - managing power-on delay, 35
 - restoring at restart, 34
 - specifying at restart, 34

I

- ILOM
 - accessing the system console, 10
 - default username and password, 10
 - logging in, 9
 - overview, 1
 - parallel boot policy, 36
 - platform-specific features, 2
 - prompt, 10, 12
 - specifying host power state property, 34

K

- keyboard, attaching, 13
- keyswitch, specifying host behavior, 36

L

- local graphics monitor, 13

locating the server, 70

M

MAC address, displaying host, 42

multipathing software, 5

N

network access, enabling or disabling, 40

network address options, 39

O

ok prompt, displaying, 11

OpenBoot

displaying version, 76

setting configuration variables, 13

Oracle VM Server for SPARC overview, 4

P

POST

displaying version, 73, 76

running diagnostics, 63

power off, 16

power on, 15

preconfigured SCSI controller alias, 22

R

RAID

configuring, 19

creating volumes, 23

FCode utility, 21

support, 19

restart behavior

setting the boot timeout interval, 54

specifying behavior at boot timeout, 55

specifying behavior if restart fails, 55

specifying behavior when host stops running, 54

specifying max restart attempts, 56

specifying on host reset, 53

S

SCSI controller alias, 22

select command, 22

server

controlling, 15

resetting from ILOM, 17

resetting from the OS, 17

show-children command, 22

SP, resetting, 18

SunVTS, 60

system administration overview, 1

system communication, 9

system console, logging in, 10

system identification, changing, 32