

StorageTek SL150 Modular Tape Library
SCSI Reference Guide

E51473-06

December 2018

Copyright © 2018, Oracle and/or its affiliates. All rights reserved.

This software and related documentation are provided under a license agreement containing restrictions on use and disclosure and are protected by intellectual property laws. Except as expressly permitted in your license agreement or allowed by law, you may not use, copy, reproduce, translate, broadcast, modify, license, transmit, distribute, exhibit, perform, publish, or display any part, in any form, or by any means. Reverse engineering, disassembly, or decompilation of this software, unless required by law for interoperability, is prohibited.

The information contained herein is subject to change without notice and is not warranted to be error-free. If you find any errors, please report them to us in writing.

If this is software or related documentation that is delivered to the U.S. Government or anyone licensing it on behalf of the U.S. Government, then the following notice is applicable:

U.S. GOVERNMENT END USERS: Oracle programs, including any operating system, integrated software, any programs installed on the hardware, and/or documentation, delivered to U.S. Government end users are "commercial computer software" pursuant to the applicable Federal Acquisition Regulation and agency-specific supplemental regulations. As such, use, duplication, disclosure, modification, and adaptation of the programs, including any operating system, integrated software, any programs installed on the hardware, and/or documentation, shall be subject to license terms and license restrictions applicable to the programs. No other rights are granted to the U.S. Government.

This software or hardware is developed for general use in a variety of information management applications. It is not developed or intended for use in any inherently dangerous applications, including applications that may create a risk of personal injury. If you use this software or hardware in dangerous applications, then you shall be responsible to take all appropriate fail-safe, backup, redundancy, and other measures to ensure its safe use. Oracle Corporation and its affiliates disclaim any liability for any damages caused by use of this software or hardware in dangerous applications.

Oracle and Java are registered trademarks of Oracle and/or its affiliates. Other names may be trademarks of their respective owners.

Intel and Intel Xeon are trademarks or registered trademarks of Intel Corporation. All SPARC trademarks are used under license and are trademarks or registered trademarks of SPARC International, Inc. AMD, Opteron, the AMD logo, and the AMD Opteron logo are trademarks or registered trademarks of Advanced Micro Devices. UNIX is a registered trademark of The Open Group.

This software or hardware and documentation may provide access to or information about content, products, and services from third parties. Oracle Corporation and its affiliates are not responsible for and expressly disclaim all warranties of any kind with respect to third-party content, products, and services unless otherwise set forth in an applicable agreement between you and Oracle. Oracle Corporation and its affiliates will not be responsible for any loss, costs, or damages incurred due to your access to or use of third-party content, products, or services, except as set forth in an applicable agreement between you and Oracle.

Contents

Preface	vii
Documentation Accessibility	vii
Related Documents	vii
 1 SL150 FC Implementation	
Library Support	1-1
Hub Support	1-1
Switch Support	1-2
 2 SL150 SCSI Operation and Configuration	
Running on Both Fibre Channel or SAS Ports	2-1
Logical Unit Number Addressing	2-1
Drive Element Addressing Mode Configuration	2-1
Address All Drive Slots Mode	2-2
Address Installed Drives Only	2-2
Multiple Initiator Support	2-3
Host Timeout Characteristics	2-3
Reservation Handling	2-3
Compatible Reservation Handling Bit	2-3
Reserve and Release Management Method Command Restrictions	2-3
Persistent Reservation Management Method Command Restrictions	2-4
Persistent Binding	2-5
SCSI Element Addressing	2-5
 3 SL150 SCSI Commands	
Command Descriptor Block (CDB) Structure	3-1
Control Byte Structure	3-2
Supported SCSI Command Status Byte Codes	3-3
Initialize Element Status (07h)	3-4
Initialize Element Status with Range (37h)	3-5
Inquiry (12h)	3-6
Standard Inquiry Data Definition	3-8
Supported Pages	3-11
Unit Serial Number Page	3-12
Device Identification Page	3-13

SCSI Ports Page.....	3-16
SCSI Port Identification Descriptor Data.....	3-16
Specific Device Capabilities Page (HP LTO6 Bridged Tape Drive Only).....	3-17
Log Sense (4Dh)	3-18
Supported Pages Page	3-19
Last <i>n</i> Errors Events Page	3-20
Informational Exceptions TapeAlert Page.....	3-21
TapeAlert Flags	3-22
Mode Select 6-byte (15h) and Mode Select 10-byte (55h)	3-24
Mode Select Parameter Header.....	3-26
FC Disconnect/Reconnect Page.....	3-27
SAS Disconnect/Reconnect Page.....	3-29
Fibre Channel Logical Unit Page	3-30
SAS Logical Unit Page.....	3-31
Fibre Channel Port Control Page	3-32
SAS Port Control Page.....	3-34
SAS Phy Control and Discover Mode Subpage.....	3-36
SAS Phy Mode Descriptor Data.....	3-37
Information Exceptions TapeAlert Page.....	3-39
Test Modes	3-40
Element Address Assignment Mode Page.....	3-41
Element Address Assignments	3-42
Mode Sense 6-byte (1Ah) and Mode Sense 10-byte (5Ah)	3-43
Mode Sense Parameter Header	3-46
FC Disconnect/Reconnect Page.....	3-47
SAS Disconnect/Reconnect Page.....	3-48
FC Logical Unit Control Page.....	3-49
SAS Logical Unit Page.....	3-50
FC Port Control Page	3-51
SAS Port Control Page.....	3-52
SAS Phy Control and Discover Mode Subpage.....	3-53
SAS Shared Control Mode Subpage.....	3-54
SAS Enhanced Phy Control Subpage	3-55
Enhanced Phy Control Mode Descriptor Data	3-56
Phy Capabilities Data	3-56
Informational Exceptions Tape Alert Control Page	3-58
Element Address Assignment Page	3-59
Transport Geometry Mode Page.....	3-60
Device Capabilities Page	3-61
Move Medium (A5h)	3-63
Persistent Reserve In (5Eh)	3-65
Read Keys Data.....	3-66
Read Reservation Data	3-67
Reservation Descriptor	3-68
Report Capabilities Data	3-69
Read Full Status Data	3-71
Full Status Descriptor	3-71

Transport ID Data	3-72
Persistent Reserve Out (5Fh)	3-73
Persistent Reserve Out Parameter List	3-75
Position to Element (2Bh)	3-77
Prevent/Allow Medium Removal (1Eh)	3-78
Read Element Status (B8h)	3-79
Element Status Data Header	3-81
Element Status Page Header	3-82
Element Descriptors	3-83
Release 6-byte (17h) and Release 10-byte (57h)	3-89
Report LUNs (A0h)	3-90
Report LUNs Data	3-91
Report Target Port Groups (A3h)	3-92
Report Target Port Group Data	3-93
Target Port Group Descriptor Data	3-94
Target Port Descriptor Data	3-96
Request Sense (03h)	3-97
Request Sense Data	3-98
Additional Sense Codes and Qualifiers	3-100
Not Ready Sense Key (2h) Codes	3-100
Medium Error (3h) Codes	3-101
Hardware Error Sense Key (4h) Codes	3-101
Illegal Request Sense Key (5h) Codes	3-101
Unit Attention Sense Key (06h) Codes	3-102
Aborted Command Sense Key (0Bh) Codes	3-103
Request Volume Element Address (B5h)	3-105
Volume Element Address Header	3-106
Reserve 6-byte (16h) and Reserve 10-byte (56h)	3-107
Send Diagnostic (1Dh)	3-108
Send Volume Tag (B6h)	3-109
Send Volume Tag Parameter List	3-110
Test Unit Ready (00h)	3-111

List of Tables

2-1	Action when the Library is Reserved by Another Initiator	2-3
2-2	Persistent Reservation Command Restrictions when the Library is Reserved by Another Initiator	2-4
3-1	Persistent Reserve Out Service Actions and Valid Parameters.....	3-75
3-2	Service Action Reservation Key Information.....	3-76

Preface

This guide contains information about the Small Computer System Interface (SCSI) command set. It is intended for independent software vendors (ISVs), operating system developers, and engineers responsible for implementing the SCSI over a Fibre Channel (FC) physical interface on Oracle's StorageTek SL150 Tape Library.

Note: Refer to the tape drive documentation for information about SCSI commands for a specific tape drive.

Documentation Accessibility

For information about Oracle's commitment to accessibility, visit the Oracle Accessibility Program website at

<http://www.oracle.com/pls/topic/lookup?ctx=acc&id=docacc>.

Access to Oracle Support

Oracle customers that have purchased support have access to electronic support through My Oracle Support. For information, visit

<http://www.oracle.com/pls/topic/lookup?ctx=acc&id=info> or visit

<http://www.oracle.com/pls/topic/lookup?ctx=acc&id=trs> if you are hearing impaired.

Related Documents

- *American National Standard Dictionary for Information Processing Systems* - X3/TR-1-82
- *SCSI-3 Primary Commands (SPC)* - X3.301-1997
- *SCSI-3 Primary Commands (SPC-2)* - T10/Project 1236D
- *SCSI-3 Medium Changer Commands (SMC)* - T10/Project 1383D
- *SCSI-3 Architecture Model (SAM)* - X3.270-1996
- *SCSI Architecture Model – 2 (SAM-2)* - T10/Project 1157D
- *Fibre Channel Physical and Signaling Interface (FC-PH)* - X3.230-1994 Revision 4.3, X3.230-1996 (Amendment 1), X3.230-1997 (Amendment 2)
- *Fibre Channel Physical and Signaling Interface (FC-PH-2)* - X3.297-1996 Revision 7.4
- *Fibre Channel Physical and Signaling Interface (FC-PH-3)* - X3.303-199x Revision 9.3
- *Fibre Channel Arbitrated Loop (FC-AL)* - X3.272-1996 Revision 4.5

- *Fibre Channel Arbitrated Loop (FC-AL-2)* - X3.272-199x Revision 7.0

SL150 Documentation

Go to the Tape Storage section of the Oracle Help Center

(<http://docs.oracle.com/en/storage/#tape>) for additional SL150 documentation.

SL150 FC Implementation

The FC implementation on the SL150 conforms to the American National Standards Institute (ANSI) and National Committee for Information Technology Standards (NCITS), formerly X3. The following lists support details.

- [Library Support](#)
- [Hub Support](#)
- [Switch Support](#)

Library Support

- Supports arbitrated loop and direct fabric attach
- FCP (SCSI-3) command set for medium changer devices
- Class 3 level of service
- Private and public loop operations
- Direct fabric attach operation
- Hard-assigned port addresses (AL-PA)
- Basic and extended link services
- Connections to an external hub (or switch)
- Data transfer rates of 100 MB/s
- Standard approved length shortwave fibre optic cables
- Multimode laser operating at 780 nm (shortwave) non-OFC

Hub Support

- Multiple ports
- Standard approved length fibre optic and copper cables
- Multimode laser operating at 780 nm (shortwave) non-OFC
- Single mode laser operating at 1300 nanometers (longwave)
- Cascading hub attachments
- Gigabit Interface Converter (GBIC) connections in the hub

Switch Support

- Attachment to FL_Ports

SL150 SCSI Operation and Configuration

- [Running on Both Fibre Channel or SAS Ports](#)
- [Logical Unit Number Addressing](#)
- [Drive Element Addressing Mode Configuration](#)
- [Multiple Initiator Support](#)
- [Host Timeout Characteristics](#)
- [Reservation Handling](#)
- [Persistent Binding](#)
- [SCSI Element Addressing](#)

Running on Both Fibre Channel or SAS Ports

When the drive has 2 ports, Oracle recommends that Host Application treat the second SL150 drive port as a fail over port. The library may report a CHECK CONDITION to a command received on one port, when the other port is already busy with a library command. When a host application receives either of the following new CHECK CONDITIONS, it should reissue the command:

- Not Ready, Logical Unit Offline (02/04/12h)
- Aborted Command, Logical Unit Communication Failure (0Bh/08/00)
- No Sense, Operation in Progress (00/00/16h)

Logical Unit Number Addressing

- LUN 0 is used to communicate with the tape drive.
- LUN 1 is used to communicate with the SL150 library.

Drive Element Addressing Mode Configuration

The administrator for the SL150 Modular Tape Library can chose one of the following two drive element addressing modes. The mode chosen affects the way SCSI element addresses are reported over the library SCSI interface.

- [Address All Drive Slots Mode](#)
- [Address Installed Drives Only](#)

Address All Drive Slots Mode

Setting the mode to Address All Drive Slots results in the following:

- All drive slots (empty or installed) are reported to the host application over the library SCSI interface. Using this mode allows for the addition of new tape drives without restarting the library.
- Each drive and empty drive bay is assigned a drive SCSI Element Address. Drive element addresses are assigned sequentially starting at 500 for each partition from the topmost drive in the partition to the bottom drive in the partition. Similarly, for non-partitioned libraries, drive element address are also assigned sequentially starting at 500 from the top of the library to the bottom of the library.
- A SCSI MODE SENSE command requesting the Element Address Assignment page will end in Good status. The total number of data transfer elements reported will include empty drive bays.
- A SCSI READ ELEMENT STATUS command that includes an empty drive slot will end in Good status. The Data Transfer Element Descriptor data for the empty drive slot will return the ED bit set to 1 (disabled) and an exception condition indicating an Empty Drive Bay; the Except Bit will be set to 1, the ASC field will be set to 3Bh, and the ASCQ field will be set to 1Ah.
- A SCSI MOVE command from an empty drive slot will end in Check Condition Status. The sense data will indicate Illegal Request, Source Empty (Sense Key = 5h, ASC = 3Bh, ASCQ = 0Eh).
- A SCSI MOVE command to an empty drive slot will end in Check Condition Status. The sense data will indicate Illegal Request, Empty Drive Bay (Sense Key = 5h, ASC = 3Bh, ASCQ = 1Ah).
- A SCSI POSITION TO ELEMENT command to an empty drive slot will end in Good Status. The robot will move in front of the empty drive bay.

Address Installed Drives Only

Setting the mode to Address Installed Drives Only results in the following:

- Only drives present at initialization are reported to a host application over the library SCSI interface. If a new drive is added, the library must be rebooted before the new drive can be used by a host application.
- Each installed drive is assigned a drive SCSI Element Address during library initialization. Drive element addresses are assigned sequentially starting at 500 for each partition from the topmost drive in the partition to the bottom drive in the partition. Similarly, for non-partitioned libraries, drive element address are also assigned sequentially starting at 500 from the top of the library to the bottom of the library.
- A SCSI MODE SENSE command requesting the Element Address Assignment page will end in Good status. The total number of data transfer elements reported will include only the number of drives found to be present at initialization.
- If a drive is removed, a SCSI READ ELEMENT STATUS command for the now empty drive slot will end in Good status. The Data Transfer Element Descriptor data for the empty drive slot will return the ED bit set to 1 (disabled) and an exception condition indicating a Tape Drive error; the Except Bit will be set to 1, the ASC field will be set to 40h, and the ASCQ field will be set to 02h.

Multiple Initiator Support

- The library supports unit reserve, release, and persistent reserve commands. Host software should reserve resources whenever possible.
- The library does not maintain a separate "prevent" or "allow" state for each initiator. There is a single state for all initiators. Therefore, if any initiator sends a Prevent Medium Removal command, the library locks the CAPs. If any initiator sends an Allow Media Removal command, the library unlocks the CAPs. For more information, see ["Prevent/Allow Medium Removal \(1Eh\)"](#) on page 3-78.

Host Timeout Characteristics

Host timeout values for SCSI commands may require adjustment based on the configuration of the library.

Reservation Handling

The library supports the following reservation management methods:

- Reserve and Release — defined by the ANSI SCSI-3 Primary Commands (SPC-2) Standard. See [Table 2-1](#) for command reservation restrictions.
- Persistent Reservation — defined by the ANSI SCSI-3 Primary Commands (SPC-3) Standard. See [Table 2-2](#) for command reservation restrictions.

[Table 2-1](#) and [Table 2-2](#) use the following definitions:

- **Conflict** — The library terminates the command with a [Reservation Conflict \(18h\)](#) status.
- **Allowed** — The library executes the command normally.

Compatible Reservation Handling Bit

The library returns 0 for the Compatible Reservation Handling (CRH) bit in the [Persistent Reserve In \(5Eh\) Report Capabilities Data](#) page.

A CRH value of 0 indicates the library processed the reserve or release command as defined in SPC-2. Therefore, the library will return a [Reservation Conflict \(18h\)](#) when it receives a reserve or release command from the same initiator that holds the persistent reservation.

Reserve and Release Management Method Command Restrictions

Table 2-1 Action when the Library is Reserved by Another Initiator

Command	HP Bridged Drive	IBM Bridged Drive
Initialize Element Status (07h)	Conflict	Conflict
Initialize Element Status w/Range (37h)	Conflict	Conflict
Inquiry (12h)	Allowed	Allowed
Log Sense (4Dh)	Allowed	Allowed
Mode Select (15h/55h)	Conflict	Conflict
Mode Sense (1Ah/5Ah)	Conflict	Allowed
Move Medium (A5h)	Conflict	Conflict
Persistent Reserve In (5Eh)	Conflict	Conflict

Table 2–1 (Cont.) Action when the Library is Reserved by Another Initiator

Command	HP Bridged Drive	IBM Bridged Drive
Persistent Reserve Out (5Fh)	Conflict	Conflict
Position to Element (2Bh)	Conflict	Conflict
Prevent/ Allow Media Removal (1Eh)	Prevent = 0, Allowed Prevent = 1, Conflict	Prevent = 0, Allowed Prevent = 1, Conflict
Read Element Status (B8h)	Conflict	Conflict
Release (17h)	Allowed ¹	Allowed ¹
Report LUNs (A0h)	Allowed	Allowed
Report Target Port Groups (A3h)	Allowed	Allowed
Request Sense (03h)	Allowed	N/A ²
Request Volume Element Address (B5h)	Conflict	Allowed
Reserve (16h)	Conflict	Conflict
Send Diagnostics (1Dh)	Conflict	Conflict
Send Volume Tag (B6h)	Conflict	Conflict
Test Unit Ready (00h)	Conflict	Conflict

¹ The reservation is not released.

² The Report Target Port Group command is not supported by the IBM drive.

Persistent Reservation Management Method Command Restrictions

Table 2–2 Persistent Reservation Command Restrictions when the Library is Reserved by Another Initiator

Command	Non-Registered Initiator ¹	Registered Initiator: Exclusive Access Reservation ²	Registered Initiator: Exclusive Access Registrant Only ³
Initialize Element Status (07h)	Conflict	Conflict	Allowed
Initialize Element Status w/Range (37h)	Conflict	Conflict	Allowed
Inquiry (12h)	Allowed	Allowed	Allowed
Log Sense (4Dh)	Allowed	Allowed	Allowed
Mode Select (15h/55h)	Conflict	Conflict	Allowed
Mode Sense (1Ah/5Ah)	Conflict	Conflict	Allowed
Move Medium (A5h)	Conflict	Conflict	Allowed
Persistent Reserve In (5Eh)	Allowed	Allowed	Allowed
Persistent Reserve Out (5Fh) - SA=Register	Allowed	Allowed	Allowed
Persistent Reserve Out (5Fh) - SA=Reserve	Conflict	Conflict	Conflict
Persistent Reserve Out (5Fh) - SA=Release	Conflict	Allowed ⁴	Allowed ⁴
Persistent Reserve Out (5Fh) - SA=Clear	Conflict	Allowed	Allowed
Persistent Reserve Out (5Fh) - SA=Preempt	Conflict	Allowed	Allowed
Persistent Reserve Out (5Fh) - SA=Preempt/Abort	Conflict	Allowed	Allowed
Persistent Reserve Out (5Fh) - SA=Register and Ignore	Allowed	Allowed	Allowed

Table 2–2 (Cont.) Persistent Reservation Command Restrictions when the Library is Reserved by Another Initiator

Command	Non-Registered Initiator¹	Registered Initiator: Exclusive Access Reservation²	Registered Initiator: Exclusive Access Registrant Only³
Persistent Reserve Out (5fh) - SA=Resister and Move	Conflict	Conflict	Conflict
Position to Element (2Bh)	Conflict	Conflict	Allowed
Prevent/ Allow Media Removal (1Eh) Prevent = 0	Allowed	Allowed	Allowed
Prevent/ Allow Media Removal (1Eh) Prevent = 1	Conflict	Conflict	Allowed
Read Element Status (B8h) HP Drive	Conflict	Conflict	Allowed
Read Element Status (B8h) IBM Drive	Allowed	Allowed	Allowed
Release (17h)	Conflict	Conflict	Allowed
Report LUNs (A0h)	Allowed	Allowed	Allowed
Report Target Port Groups (A3h) ⁵	Allowed	Allowed	Allowed
Request Sense (03h)	Allowed	Allowed	Allowed
Request Volume Element Address (B5h)	Conflict	Conflict	Allowed
Reserve (16h)	Conflict	Conflict	Allowed
Send Diagnostics (1Dh)	Conflict	Conflict	Allowed
Send Volume Tag (B6h)	Conflict	Conflict	Allowed
Test Unit Ready (00h) HP Drive	Allowed	Allowed	Allowed
Test Unit Ready (00h) IBM Drive	Conflict	Conflict	Allowed

¹ Action when a non-registered initiator sends a command to a library reserved by another initiator.

² Action when a registered initiator sends a command to a library reserved by another initiator that has an Exclusive Access reservation.

³ Action when a registered initiator sends a command to a library reserved by another initiator that has an Exclusive Access Registrant Only reservation.

⁴ The reservation is not released.

⁵ HP Drive Only. The Report Target Port Group command is not supported by the IBM drive

Persistent Binding

When a server is started, it discovers attached devices and assigns SCSI target and LUN IDs. It is possible for these SCSI assignments to change between restarts. Some operating systems do not guarantee that devices will always be allocated the same SCSI target ID after restarting. Also, some software depends on this association, so you do not want it to change.

The issue of SCSI ID assignment is addressed by persistent binding. Persistent binding is a host bus adapter (HBA) function that allows a subset of discovered targets to be bound between a server and device.

Implemented by a WWNN or WWPN, persistent binding causes a tape drive's WWN to be bound to a specific SCSI target ID.

SCSI Element Addressing

See the *SL150 Library Guide* for more information.

SL150 SCSI Commands

- Initialize Element Status (07h)
- Initialize Element Status with Range (37h)
- Inquiry (12h)
- Log Sense (4Dh)
- Mode Select 6-byte (15h) and Mode Select 10-byte (55h)
- Mode Sense 6-byte (1Ah) and Mode Sense 10-byte (5Ah)
- Move Medium (A5h)
- Persistent Reserve In (5Eh)
- Persistent Reserve Out (5Fh)
- Position to Element (2Bh)
- Prevent/Allow Medium Removal (1Eh)
- Read Element Status (B8h)
- Release 6-byte (17h) and Release 10-byte (57h)
- Report LUNs (A0h)
- Report Target Port Groups (A3h)
- Request Sense (03h)
- Request Volume Element Address (B5h)
- Reserve 6-byte (16h) and Reserve 10-byte (56h)
- Send Diagnostic (1Dh)
- Send Volume Tag (B6h)
- Test Unit Ready (00h)

Command Descriptor Block (CDB) Structure

- The first byte contains the operation code — a Group Code that provides eight groups of commands and a Command Code that provides 32 command codes for each group.
- The second byte starts the command parameters.
- The last byte is the control byte (see "[Control Byte Structure](#)" on page 3-2).

For some commands, a list of parameters accompanies the request during data out. For all commands, if there is an invalid parameter in the CDB, then the library terminates the command without altering the medium.

Figure 3–1 6-Byte Command Structure

	Bit							
Byte	7	6	5	4	3	2	1	0
0	Group Code			Command Code				
1	Reserved			Command Parameters				
2 to 4	Command Parameters							
5	Control Byte							

SLK_065

Figure 3–2 10-Byte Command Structure

	Bit							
Byte	7	6	5	4	3	2	1	0
0	Operation Code							
1	Reserved			Command Parameters				
2 to 8	Command Parameters							
9	Control Byte							

SLK_066

Figure 3–3 12-Byte Command Structure

	Bit							
Byte	7	6	5	4	3	2	1	0
0	Operation Code							
1	Reserved			Command Parameters				
2 to 9	Command Parameters							
10	Reserved							
11	Control Byte							

SLK_067

Control Byte Structure

The control byte is the last byte of every CDB.

Byte	Bit							
	7	6	5	4	3	2	1	0
5, 9, or 11	Vendor Specific		Reserved			NACA (0)	Flag (0)	Link (0)

SLK_068

Vendor Specific

Provides information about the device.

NACA (Normal auto contingent allegiance)

Controls the rules for handling an auto contingent condition caused by a command. When NACA is 0, the command will return a check condition if a contingent allegiance condition occurs.

Flag (not supported)

Causes an interrupt in the initiator allowing a device to respond with intermediate status. This bit is should be 0.

Link (not supported)

Allows devices that support command linking to continue the I/O process. This bit should be 0.

Supported SCSI Command Status Byte Codes

Good (00h)

Indicates the device successfully completed the command.

Check Condition (02h)

Occurs when an error, unit exception, or abnormal condition generates sense data caused by one of the following conditions:

- Issuing an invalid command or parameter
- Issuing a command to a device that is not ready
- Detecting a hardware error
- Sensing an illegal request

Busy (08h)

Occurs when the target cannot accept a command from an otherwise acceptable initiator. Normally, to recover from a Busy status, the initiator reissues the command.

Reservation Conflict (18h)

Occurs whenever a SCSI initiator attempts to access a logical unit that is reserved by another initiator.

Task Aborted (40h)

Occurs whenever the a task is aborted by another SCSI initiator port.

Initialize Element Status (07h)

Initialize Element Status (07h) requests an audit of the library. The library accepts this command for compatibility, but it does not perform any action.

At power-on the library performs a full audit and then maintains a cartridge inventory during operation. Use [Read Element Status \(B8h\)](#) to obtain the cartridge inventory.

	Bit							
Byte	7	6	5	4	3	2	1	0
0	Operation Code (07h)							
1	Ignored			Reserved				
2 to 4	Reserved							
5	Control Byte (00h)							

SLK_069

Initialize Element Status with Range (37h)

Initialize Element Status with Range (37h) requests an audit for a range of cells in the library. The library accepts this command for compatibility, but it does not perform any action.

At power-on the library performs a full audit and then maintains a cartridge inventory while operating. Use [Read Element Status \(B8h\)](#) to obtain the cartridge inventory.

	Bit							
Byte	7	6	5	4	3	2	1	0
0	Operation Code (37h)							
1	Ignored			Reserved			Fast (Ignored)	Range(Ignored)
2 to 3	Element Address (Ignored)							
4 to 5	Reserved							
6 to 7	Number of Elements (Ignored)							
8	Reserved							
9	Control Byte (00h)							

SLK_070

Inquiry (12h)

Inquiry (12h) requests information about library parameters.

Note: The Inquiry command returns [Check Condition \(02h\)](#) status only when it cannot return the requested data. This command will not clear any pending unit attention conditions.

	Bit							
Byte	7	6	5	4	3	2	1	0
0	Operation Code (12h)							
1	Ignored			Reserved			CmdDt	EVDP
2	Page Code							
3 to 4	Allocation Length							
5	Control Byte (00h)							

SLK_071

CmdDt (Command Support Data - not supported)

Set this to 0.

EVDP (Enable vital product data)

0 = Requests standard inquiry data

1 = Requests vital support product data

Page Code

If EVDP is 0, set the page code to 00h.

If EVDP is 1, set the page code to:

- 00h = Supported vital product page
- 80h = Unit serial number page
- 83h = Device identification page
- 88h = SCSI ports page
- C8h = Vendor Specific Device Capabilities Page (Bridged HP LTO-6 Tape Drive)

Allocation Length

The library transfers either the number of bytes specified by the Allocation Length field or all of the available inquiry data, whichever is less. The page lengths are:

- 0 = no inquiry data will be transferred. This is not considered an error.
- 24h = Standard Inquiry Data Length (IBM Bridged Tape Drive)
- 4Ah = Standard Inquiry Data Length (HP Bridged Tape Drive)
- 08h = Supported Pages Length
- 09h = Supported Pages Length (HP LTO-6 Bridged Tape Drive)
- 16h = Unit Serial Number Page Length
- 3Eh = Device Identification Page Length (IBM Bridged Tape Drive)
- 46h = Device Identification Page Length (HP Bridged Tape Drive)

- 34h = SCSI Ports Page Length
- 08h = Vendor Specific Device Capabilities Page Length (HP LTO-6 Bridged Tape Drive)

Standard Inquiry Data Definition

Figure 3–4 Standard Inquiry Data Definition - HP Bridged

	Bit							
Byte	7	6	5	4	3	2	1	0
0	Peripheral Qualifier			Peripheral Device Type				
1	RMB	Reserved						
2	Version (05h)							
3	Reserved		NACA	HiSup	Response Data Format			
4	Additional Length							
5	SCCS	ACC	TPGS		3PC	Reserved		Protect
6	BQue	EncServ	VS	MultiP	MChngr	Reserved		
7	Reserved				LINKED	Reserved	CmdQue	SttRe
8 to 15	Vendor Identification							
16 to 31	Product Identification							
32 to 35	Product Revision Level							
36 to 57	Reserved							
58 to 59	Version Descriptor 1							
...	...							
72 to 73	Version Descriptor 8							

L207_269

Figure 3–5 Standard Inquiry Data Definition - IBM Bridged

	Bit							
Byte	7	6	5	4	3	2	1	0
0	Peripheral Qualifier			Peripheral Device Type				
1	RMB	Reserved						
2	Version (05h)							
3	Reserved		NACA	HiSup	Response Data Format			
4	Additional Length							
5	SCCS	ACC	TPGS		3PC	Reserved		Protect
6	Reserved	EncServ	VS	MultiP	MChngr	Reserved		ADDR16
7	Reserved	Reserved	WBUS16	SYNC	Reserved	Reserved	CmdQue	VS
8 to 15	Vendor Identification							
16 to 31	Product Identification							
32 to 35	Product Revision Level							

L207_270

Peripheral Qualifier

000b = The specified peripheral device type is currently connected to this logical unit.

011b = The command was sent to an unsupported logical unit.

Peripheral Device Type

08h = The library is a medium changer device.

1Fh = The command was sent to an unsupported logical unit.

RMB (Removable Medium)

1 = The medium is removable.

Version

05h = The library complies with SCSI-3.

NACA (Normal Auto Contingent Allegiance - not supported)

0 = The library does not support setting NACA to one in the control byte of a CDB.

HiSup (Hierarchical Addressing Support)

1 = The library uses the hierarchical addressing module to identify logical units.

Response Data Format

2 = The data complies with the SCSI-3 specification.

Additional Length

1Fh = The library has 31 additional bytes of Standard Inquiry Data available to the initiator.

45h = The library has 69 additional bytes of Standard Inquiry Data available to the initiator. This value is returned if the Allocation Length in the CDB is 36 bytes or larger.

SCCS

0 = The library does not contain an embedded storage array controller component.

ACC (Access Control Coordinator)

0 = The library does not contain an ACC that may be addressed through this logical unit.

TPGS (Target Port Group Support)

01b = Implicit asymmetric logical unit access is supported. The SCSI target device is capable of changing target port asymmetric access states without a SET TARGET PORT GROUPS command. The REPORT TARGET PORT GROUPS command is supported and the SET TARGET PORT GROUPS command is not supported.

3PC (Third-Party Commands - not supported)

The library returns 0.

Protect (Information Protection - not supported)

The library returns 0.

VS (Vendor Specific)

0 = There is no vendor specific information with this command.

MultiP

0 = There are no multiple target ports.

1 = The library has multiple target ports.

MChngr

0 = The library is not embedded in or attached to a medium transport element.

ADDR16

The library returns 0.

WBUS16

The library returns 0.

SYNC

The library returns 0.

LINKED (Linked commands - not supported)

The library returns 0.

CmdQue (Command Queuing)

0 = the library does not support command queuing

1 = the library supports command queuing

SftRe (Soft Reset - not supported)

The library returns 0.

Vendor Identification

Contains the ASCII character sequence "STK" followed by blanks. If the specified logical unit is not supported, this field contains all blanks.

Product Identification

Contains the ASCII character sequence "SL150" followed by blanks.

Product Revision Level

Contains an ASCII character sequence that represents the product revision level.

Version Descriptors

The bridged drive returns up to eight Version Descriptors that are used to identify up to eight standards to which the drive conforms.

Supported Pages

	Bit							
Byte	7	6	5	4	3	2	1	0
0	Peripheral Qualifier			Peripheral Device Type				
1	Page Code (00h)							
2	Reserved							
3	Additional Page Length							
4	Supported Pages (00h)							
5	Unit Serial Number Page (80h)							
6	Device Identification Page (83h)							
7	SCSI Ports Page (88h)							
8	Vendor Specific Device Capabilities page (C8h)							

Peripheral Qualifier

See [Peripheral Qualifier](#).

Peripheral Device Type

See [Peripheral Device Type](#).

Page Code

00h = The vital page

Additional Page Length

4h = The library has 4 additional bytes of Supported Pages Inquiry data available to the initiator

5h = The bridged drive is an HP LTO-6 drive. The library has 5 additional bytes of Supported Pages Inquiry data available to the initiator

Supported pages

80h = Unit serial number page

83h = Device identification page

88h = SCSI ports page

C8h = Vendor Specific Device Capabilities Page (Bridged HP LTO-6 Tape Drive)

Unit Serial Number Page

	Bit							
Byte	7	6	5	4	3	2	1	0
0	Peripheral Qualifier			Peripheral Device Type				
1	Page Code (80h)							
2	Reserved							
3	Additional Page Length (0Ch or 12h)							
4 to n	Unit Serial Number							

SLK_074

Peripheral Qualifier

See [Peripheral Qualifier](#).

Peripheral Device Type

See [Peripheral Device Type](#).

Page Code

80h = The unit serial number page.

Additional Page Length

12h = 18 bytes of unit serial number data.

Unit Serial Number

Contains a unique 18 character ASCII Serial Number for the library. For example:

- 464970G+1221XX0005

Where XX indicates the library partition identifier (such as P1 for partition 1). For nonpartitioned libraries, XX is 00.

Device Identification Page

Figure 3–6 Device Identification Page - HP Bridged

	Bit							
Byte	7	6	5	4	3	2	1	0
0	Peripheral Qualifier			Peripheral Device Type				
1	Page Code (83h)							
2	Reserved							
3	Additional Page Length							
T10 Vendor Identifier								
4	Protocol Identifier			Code Set				
5	PIV	Reserved	Association		Identifier Type			
6	Reserved							
7	Identifier Length							
8 to 15	Vendor Identification							
16 to 31	Product Identification							
32 to 49	Unit Serial Number							
Bridged Tape Drive Node Name Identifier								
50	Protocol Identifier			Code Set				
51	PIV	Reserved	Association		Identifier Type			
52	Reserved							
53	Identifier Length							
54 to 61	NAA Identifier (WWNN of Bridged Drive)							
Relative Target Port Identifier								
62	Protocol Identifier			Code Set				
63	PIV	Reserved	Association		Identifier Type			
64	Reserved							
65	Identifier Length							
66 to 69	Relative Target Port							

L207_272

Figure 3–7 Device Identification Page - IBM Bridged

	Bit							
Byte	7	6	5	4	3	2	1	0
0	Peripheral Qualifier			Peripheral Device Type				
1	Page Code (83h)							
2	Reserved							
3	Additional Page Length							
T10 Vendor Identifier								
4	Protocol Identifier			Code Set				
5	PIV	Reserved	Association		Identifier Type			
6	Reserved							
7	Identifier Length							
8 to 15	Vendor Identification							
16 to 31	Product Identification							
32 to 49	Unit Serial Number							
Bridged Tape Drive Node Name Identifier								
50	Protocol Identifier			Code Set				
51	PIV	Reserved	Association		Identifier Type			
52	Reserved							
53	Identifier Length							
54 to 61	NAA Identifier (WWNN of Bridged Drive)							

L207_273

Peripheral QualifierSee [Peripheral Qualifier](#).**Peripheral Device Type**See [Peripheral Device Type](#).**Additional Page Length**

42h = 66d additional bytes of Device ID Inquiry Data available to the initiator.

Protocol Identifier

0h = FC protocol

6h = Serial Attached SCSI

Code Set

1h = Binary values

2h = ACSII printable characters

Identifier Type

1h = Contains T10 Vendor ID data

3h = Contains a 64-bit IEEE formatted address

4h = Contains the Relative Target Port Identifier

Identifier Length

04h = 4-bytes long for Relative Port Identifier

08h = 8-bytes long for Node Name Identifier

2Ah = Length for T10 Vendor ID data

PIV (Protocol Identifier Valid)

0 = The protocol identifier contents are reserved

1 = The protocol identifier is valid

Association

0 = The identifier field is associated with the addressed logical unit

1 = The identifier field is associated with the port that received the request

NAA IEEE Registered Identifier

An 8-byte identifier. The first 4 bits are the Name Address Authority — NAA (5h). The next 24 bits are the Oracle company ID (00 10 4Fh). The remaining bits are the vendor-specific identifier. The NAA IEEE Registered Identifier is unique for each library and Fibre Channel port.

Relative Target Port

01h = Port 1

02h = Port 2

Vendor Identification

Contains the ASCII character sequence “STK” followed by blanks. If the specified logical unit is not supported, this field contains all blanks.

Product Identification

Contains the ASCII character sequence “SL150” followed by blanks.

Unit Serial Number

Contains a unique 18 character ASCII Serial Number for the library. For example:

■ 464970G+1221XX0005

Where XX indicates the library partition identifier (such as P1 for partition 1). For nonpartitioned libraries, XX is 00.

SCSI Ports Page

	Bit							
Byte	7	6	5	4	3	2	1	0
0	Peripheral Qualifier			Peripheral Device Type				
1	Page Code (88h)							
2	Reserved							
3	Additional Page Length							
4 to 27	SCSI Port Identification Descriptor							
28 to 51	SCSI Port Identification Descriptor (included if drive 2 ports enabled)							

L207_274

Peripheral Qualifier

See [Peripheral Qualifier](#).

Peripheral Device Type

See [Peripheral Device Type](#).

Additional Page Length

18h = 24d additional bytes of SCSI Ports Data available to the initiator.

30h = 48d additional bytes of SCSI Ports Data available to the initiator. This value is returned, if the drive has 2 SCSI ports and both SCSI ports are enabled

SCSI Port Identification Descriptor Data

	Bit							
Byte	7	6	5	4	3	2	1	0
0 to 1	Reserved							
2 to 3	Relative Port Identifier							
4 to 9	Reserved							
10 to 11	Target Port Descriptor Length							
12	Protocol Identifier				Code Set			
13	PIV	Reserved	Association		Identifier Type			
14	Reserved							
15	Identifier Length							
16 to 23	Port Name Identification							

L207_275

Relative Port Identifier

1 = Port 1

2 = Port 2

Protocol Identifier

0 = Fibre Channel

6 = Serial Attached SCSI

Code Set

1 = Binary values

Association

1 = identifier field is associated with the port that received the request.

PIV
1 = protocol identifier is valid

Port Name Identification
Contains the 64-bit IEEE formatted address for the Port Name.

Specific Device Capabilities Page (HP LTO6 Bridged Tape Drive Only)

	Bit							
Byte	7	6	5	4	3	2	1	0
0	Peripheral Qualifier			Peripheral Device Type				
1	Page Code (C8h)							
2	Reserved							
3	Additional Page Length							
4 to 7	Reserved							

Peripheral Qualifier
See [Peripheral Qualifier](#).

Peripheral Device Type
See [Peripheral Device Type](#).

Page Code
C8h = Identifies the page as the vendor specific device capabilities page.

Additional Page Length
14h = 4d bytes

Log Sense (4Dh)

Log Sense (4Dh) returns library error logs and statistics.

	Bit							
Byte	7	6	5	4	3	2	1	0
0	Operation Code (4Dh)							
1	Ignored			Reserved			PPC	SP
2	PC		Page Code					
3 to 4	Reserved							
5 to 6	Parameter Pointer							
7 to 8	Allocation Length							
9	Control Byte (00h)							

SLK_076

PPC (Parameter Pointer Control - not supported)

Set this to 0.

SP (Save Parameters - not supported)

Set this to 0.

PC (Page Control)

The library accepts values of 0 or 1.

Page Code

00h = List supported pages

07h = List last *n* error events page

2Eh = Informational Exceptions TapeAlert page (0 or 1 in the PC field)

Parameter Pointer

Set this to 0.

Allocation Length

The library transfers either the number of bytes specified by the Allocation Length field or all of the available log sense data, whichever is less. The page lengths are:

- 00h = List Supported pages—length is 7h
- 07h = List Last *n* Error Events page—length is 3C4h
- 2Eh = Informational Exceptions TapeAlert page—length is 144h

Supported Pages Page

The Supported Pages Page lists all the Log Sense page codes supported by the library.

Byte	Bit							
	7	6	5	4	3	2	1	0
0	Page Code (00h)							
1	Reserved							
2 to 3	Page Length (03h)							
4	Supported Pages Page Code (00h)							
5	Last n Errors Events Page Code (07h)							
6	Informational Exceptions TapeAlert Page Code (2Eh)							

L207_277

Last n Errors Events Page

The Last n Errors Events page provides a list of the most recent errors events logged on the library. Each event is an ASCII string that includes a time stamp, a fault symptom code (FSC), and an optional mechanism. Each error event is 48 bytes long, and can contain up to 20 events. Time is in universal time.

	Bit							
Byte	7	6	5	4	3	2	1	0
0	Page Code (07h)							
1	Reserved							
2 to 3	Page Length							
ASCII String for Event Specified by Parameter Pointers								
4 to 7	Result Code							
8 to 11	Activity Code							
12 to 15	Request ID							
16 to 19	Op State							
20 to 23	Module							
24 to 27	Row							
28 to 31	Column							
32 to 33	Month							
34 to 35	Day							
36 to 37	Hour							
38 to 39	Minute							
40 to 42	Second							
43 to 51	Pad (ASCII spaces)							
Additional Events (48d bytes per event)								
52 to n	Additional Log Parameters							

L207_278

Informational Exceptions TapeAlert Page

The library provides the Informational Exceptions TapeAlert page at a minimum of:

- At the beginning of a write/read job occurring on a device inside the library, even if media is not loaded in that device
- Immediately after a fatal error during a write/read job occurring on a device inside the library
- At the end of a write/read job occurring on a device inside the library

Though not mandatory, the host software may also poll the Log Sense page every 60 seconds while the tape library is idle. Each flag will be cleared to zero at library power on, when the TapeAlert Log page is read, or on a reset. The TapeAlert page returns A4h bytes in this format. The n represents a TapeAlert flag: currently, all values are set to default. Unsupported flags are also returned as defaults.

	Bit							
Byte	7	6	5	4	3	2	1	0
0	Page Code (2Eh)							
1	Reserved							
2 to 3	Page Length (5n)							
TapeAlert Flags: n goes from 1 to 32								
5n-1 to 5n	Parameter Code							
5n + 1	DU	DS	TSD	ETC	TMC	Reserved	LBIN	LP
5n + 2	Parameter Length							
5n + 3	Value of Flag							Flag

Parameter Code

2-byte field that represents the TapeAlert flag number.

DU (Disable Update)

0 = the target updates the log parameter instead of the initiator

DS (Disable Save)

1 = saving the log is not supported

TSD (Target Save Disable)

Always set to 0.

ETC (Enable Threshold Comparison)

Always set to 0

TMC (Threshold Met Criteria)

Always set to 0.

LBIN (Not used)

Library returns 0.

LP (List Parameter)

0 = log parameter is a data counter

Parameter Length

Always set to 0x01. All are 1-byte flags.

Flag

0x01 = the flag that the Parameter Code points to is active. All other values are off.

TapeAlert Flags

Flags are in sequential order, have valid values of 0 (off) or 1 (on), and reports all 32.

Type codes indicate C (critical), W (warning), and I (informational)

Code	Flag Name	Type
0001h	Media changer/data transfer device communication fault. Set when the operator removes a tape drive that has an assigned SCSI Element Address. If the library is partitioned, the tape alert is only set in the affected partition.	C
0002h	Hardware Warning	W
0003h	Mechanical Hardware Fault	C
0004h	Hardware Fault	C
0005h	Diagnostics Requested	I
0006h	Host Interface Failure	C
0007h	Predictive Failure	W
0008h	Preventative Maintenance	W
0009h	Humidity Limits	C
000Ah	Temperature Limits	C
000Bh	Voltage Limits	C
000Ch	Unexpected Volume	W
000Dh	Pick Retry	W
000Eh	Place Retry	W
000Fh	Load Retry	W
0010h	Door Open	C
0011h	Import/Export Element Fault	C
0012h	Magazine Inaccessible	C
0013h	Obsolete	
0014h	Obsolete	
0015h	Media Changer Offline	I
0016h	Data Transfer Device Offline	I
0017h	Barcode Scan Retry	W
0018h	Inventory Information Inconsistent	C
0019h	Media Changer Illegal Operation	W
001Ah	Multi-port Interface Error on a Primary Port	W
001Bh	Cooling Fan Failure	W
001Ch	Power supply. Set when an operator either pulls a power supply or a power supply power cord.	W
001Dh	Power Consumption	W
001Eh	Pass-through Mechanism Failure	C

Code	Flag Name	Type
001Fh	Obsolete	
0020h	Unreadable Bar Code Labels	I

Mode Select 6-byte (15h) and Mode Select 10-byte (55h)

The Mode Select commands specify operating parameters for the library. The library uses the configuration parameters during power-on or after a logical unit reset. If you set the parameter list length field to 0, then no Mode Select data is required.

Otherwise, you must provide the following mode parameter data in a parameter list:

- A 4-byte or 8-byte [Mode Select Parameter Header](#)
- An 8-byte [Fibre Channel Logical Unit Page](#) or [SAS Logical Unit Page](#)
- An 8-byte [Fibre Channel Port Control Page](#) or [SAS Port Control Page](#)
- A 12-byte [Information Exceptions TapeAlert Page](#)
- A 20-byte [Element Address Assignment Mode Page](#)

The library accepts the Mode Select command for compatibility, but the library does not support changing Mode parameters. The library returns a check condition if a SCSI host issues a Mode Select command and attempts to change a mode page. When the library receives a Mode Select command, the library validates all parameters. If a value is invalid, the library returns an error.

Figure 3–8 Mode Select 6-Byte Command

	Bit							
Byte	7	6	5	4	3	2	1	0
0	Operation Code (15h)							
1	Ignored			PF	Reserved			SP
2 to 3	Reserved							
4	Parameter List Length							
5	Control Byte (00h)							

SLK_079

Figure 3–9 Mode Select 10-Byte Command

	Bit							
Byte	7	6	5	4	3	2	1	0
0	Operation Code (55h)							
1	Ignored			PF	Reserved			SP
2 to 6	Reserved							
7 to 8	Parameter List Length							
9	Control Byte (00h)							

SLK_084

PF (Page Format)

Set this to 1 to indicate the page format supports the SCSI-3 specification

SP (Saved Pages)

0 = Current mode values are changed to the values specified by this command. Saved values are not affected.

1 = Current mode values and saved mode values are changed to the values specified by this command.

Parameter List Length

The parameter list length field specifies the length in bytes of the mode parameter list that shall be contained in the data out sent by the host. The parameter list length is the sum of the length of the mode page header and one or more mode pages.

If the parameter length results in the truncation of the mode parameter header or mode page, then the command shall be terminated with CHECK CONDITION status, with the sense key set to ILLEGAL REQUEST, and the additional sense code set to PARAMETER LIST LENGTH ERROR.

A value of 00h is not considered an error.

For Mode Select 6:

HP Bridged Tape Drive Parameter List Lengths:

- 14h = Disconnect Reconnect Page
- 0Ch = Logical Unit Page
- 0Ch = Fibre Channel Port Control Page
- 14h = SAS Port Control Page
- 68h = SAS Phy Control and Discover Mode Subpage
- 10h = Informational Exceptions Tape Alert Mode Page
- 18h = Element Address Assignment Page

IBM Bridged Tape Drive Parameter List Lengths:

- 10h = Informational Exceptions Tape Alert Mode Page
- 18h = Element Address Assignment Page

For Mode Select 10:

HP Bridged Tape Drive Parameter List Lengths:

- 18h = Disconnect Reconnect Page
- 10h = Logical Unit Page
- 0C10h = Fibre Channel Port Control Page
- 18h = SAS Port Control Page
- 6Ch = SAS Phy Control and Discover Mode Subpage
- 140h = Informational Exceptions Tape Alert Mode Page
- 1Ch = Element Address Assignment Page

IBM Bridged Tape Drive Parameter List Lengths:

- 14h = Informational Exceptions Tape Alert Mode Page
- 1Ch = Element Address Assignment Page

Mode Select Parameter Header

The header definitions for the library must all be 00h.

Figure 3–10 Mode Select 6-Byte Parameter Header

Bit								
Byte	7	6	5	4	3	2	1	0
0 to 3	Reserved							

SLK_080

Figure 3–11 Mode Select 10-Byte Parameter Header

Bit								
Byte	7	6	5	4	3	2	1	0
0 to 7	Reserved							

SLK_085

FC Disconnect/Reconnect Page

	Bit							
Byte	7	6	5	4	3	2	1	0
0	PS	SPF	Page Code					
1	Page Length							
2	Buffer Full Ratio							
3	Buffer Empty Ratio							
4 to 5	Bus Inactivity Limit							
6 to 7	Disconnect Time Limit							
8 to 9	Connect Time Limit							
10 to 11	Maximum Burst Size							
12	EMPD	FAA	FAB	FAC	Restricted			
13	Reserved							
14 to 15	First Burst Size							

PS (Parameters Saveable)

Set to 0.

SPF (SubPage Format)

0 = the page_0 format is being used.

Page Code

02h = Identifies the page as the Disconnect/Reconnect page

Buffer Full Ratio

Indicates the device server, during read operations, how full the buffer should be prior to requesting an interconnect tenancy.

Buffer Empty Ratio

Indicates the device server, during write operations, how empty the buffer should be prior to transmitting an FCP_XFER_RDY IU that requests the initiator to send data.

Bus Inactivity Limit

Indicates the maximum time that the target is permitted to maintain an interconnect tenancy without data or information transfer, measured in transmission word increments.

0000h = no bus inactivity limit.

Disconnect Time Limit

Indicates the minimum delay between interconnect tenancies measured in increments of 128 transmission words.

0000h = disconnect time limit does not apply.

Connect Time Limit

Indicates the maximum duration of a single interconnect tenancy, measured in increments of 128 transmission words.

0000h = no connect time limit.

Maximum Burst Size

Indicates the maximum size of FCP_DATA IU that the device server transfers to the initiator. This value is expressed in increments of 512 bytes.

0000h = no limit on the amount of data transferred per data transfer operation.

EMPD (Enable Modify Data Pointers)

Indicates whether or not the target may use the random buffer access capability to reorder FCP_DATA IUs for a single SCSI command.

0 = Target shall generate continuously increasing relative offset values for each FCP_DATA IU for a single SCSI command.

1 = Target may transfer the FCP_DATA IUs for a single SCSI command in any order.

FAA, FAB, FAC (Fairness Access bits)

Indicate whether a target in a loop configuration shall use the access fairness algorithm. A value of 0 indicates that the target does not use fairness, while a value of 1 indicates that the target does use a fairness algorithm.

The FAA bit controls arbitration when the target wishes to send one or more FCP_DATA IU frames to an initiator.

The FAB bit controls arbitration when the initiator wishes to send one or more FCP_XFER_RDY IU frames to a target.

The FAC bit controls arbitration when the target wishes to send an FCP_RSP IU frame to an initiator.

First Burst Size

0000h = no first burst size limit. This field value is expressed in increments of 512.

SAS Disconnect/Reconnect Page

	Bit							
Byte	7	6	5	4	3	2	1	0
0	PS	SPF	Page Code					
1	Page Length							
2 to 3	Reserved							
4 to 5	Bus InactivityTime Limit							
6 to 7	Reserved							
8 to 9	Maximum Connect Time Limit							
10 to 11	Maximum Burst Size							
12 to 13	Reserved							
14 to 15	First Burst Size							

PS (Parameters Saveable)

Set to 0.

SPF (SubPage Format)

0 = the page_0 format is being used.

Page Code

02h = Identifies the page as the Disconnect/Reconnect page

Bus Inactivity Time Limit

This field contains the maximum time in 100 μ s increments that an SSP target port is permitted to maintain a connection without transferring a frame to the SSP initiator port.

0000h = no bus inactivity limit.

Maximum Connect Time Limit

This field contains the maximum duration of a connection in 100 μ s increments.

0000h = no connect time limit.

Maximum Burst Size

For read data, this field contains the maximum amount of data in 512-byte increments that is transferred during a connection by an SSP target port per I_T_L_Q nexus without transferring at least one frame for a different I_T_L_Q nexus.

For write data, the value shall specify the maximum amount of data that an SSP target port requests via a single XFER_RDY frame.

0000h in this field specifies that there is no maximum burst size.

First Burst Size

If the ENABLE FIRST BURST bit in the COMMAND frame is set to zero, then the FIRST BURST SIZE field is ignored.

If the ENABLE FIRST BURST bit in the COMMAND frame is set to one, then the value in the FIRST BURST SIZE field contains the maximum amount of write data in 512-byte increments that may be sent by the SSP initiator port to the SSP target port without having to receive an XFER_RDY frame from the SSP target port.

Fibre Channel Logical Unit Page

	Bit							
Byte	7	6	5	4	3	2	1	0
0	PS	SPF	Page Code (18h)					
1	Page Length (06h)							
2	Reserved				Protocol Identifier			
3	Reserved							EPDC
4 to 7	Reserved							

SLK_081

PS (Parameters Savable)

The library sets this to 0.

SPF (SubPage Format)

The library sets this to 0 to indicate page_0 format.

Protocol Identifier

0h = FC protocol.

EPDC (Enable Precise Delivery Checking)

0 = The target shall not use the precise delivery function and shall ignore the contents of the CRN field

1 = The logical unit shall use precise delivery function defined in the FCP-2 standard.

SAS Logical Unit Page

	Bit							
Byte	7	6	5	4	3	2	1	0
0	PS	SPF	Page Code (18h)					
1	Page Length (06h)							
2	Reserved			TLR	Protocol Identifier			
3	Reserved							

PS (Parameters Savable)

The library sets this to 0.

SPF (SubPage Format)

The library sets this to 0 to indicate page_0 format.

TLR (Transport Layer Retires)

0b = Disabled

1b = Enabled for Transfer Ready and Data Frames for the logical unit.

Protocol Identifier

06h = Serial Attached SCSI protocol

Fibre Channel Port Control Page

	Bit							
Byte	7	6	5	4	3	2	1	0
0	PS	SPF	Page Code (19h)					
1	Page Length (06h)							
2	Reserved				Protocol Identifier (0h)			
3	DTFD	PLPB	DDIS	DLM	RHA	ALWI	DTIPE	DTOLI
4 to 5	Reserved							
6	Reserved					RR_TOV Units		
7	RR_TOV Values							

SLK_082

PS (Parameters Savable)

The library sets this to 0.

SPF (SubPage Format)

0 = page_0 format.

Protocol Identifier

0h = FC protocol.

DTFD (Disable Target Fabric Discovery)

If the library is not attached to an arbitrated loop, it will ignore the DTFD bit.

0 = The target attached by an arbitrated loop shall discover a fabric loop port if present on the loop and perform the public loop functions defined for targets by FC-FLA.

1 = The target attached by an arbitrated loop shall not recognize the presence of a fabric loop port on the loop.

PLPB (Prevent Loop Port Bypass)

If the library is not attached to an arbitrated loop, it will ignore the PLPB bit.

0 = The target allows the Loop Port Bypass (LPB) and Loop Port Enable (PBE) primitive sequences to control the port bypass circuit and participation on the loop as specified by FC-AL-2.

1 = The target attached to an FC-AL-2 loop shall ignore any Loop Port Bypass (LPB) and Loop Port Enable (LPE) primitive sequences.

DDIS (Disable Discovery)

If the library is not attached to an arbitrated loop, it will ignore the DDIS bit.

0 = The target shall wait to complete target discovery as defined by FC-PLDA, FC-FLA, and FC-TAPE before allowing processing of tasks to resume.

1 = The target without a valid FLOGI attached to an arbitrated loop will not require receipt of Address or Port Discovery (ADISC or PDISC ELs) following loop initialization as described in FC-PLDA and FC-FLA.

DLM (Disable Loop Master)

If the library is not attached to an arbitrated loop, it will ignore the DLM bit.

0 = The target may participate in loop master arbitration in the normal manner and, if successful, may become loop master during the loop initialization process.

1 = The target attached to an FC-AL-2 loop shall not participate in loop master arbitration and shall not become loop master. The target shall only repeat LISM frames it receives.

RHA (Require Hard Address)

If the library is not attached to an arbitrated loop, it will ignore the RHA bit.

0 = The target follows the normal initialization procedure, including the possibility of obtaining a soft address during the loop initialization process.

1 = The target attached to an arbitrated loop shall only attempt to obtain its hard address. If there is a conflict for the hard address selection during loop initialization or the target does not have a valid hard address available, the target shall enter the nonparticipating state.

ALWI (Allow Login without Loop Initialization)

If the library is not attached to an arbitrated loop, it will ignore the ALWI bit.

0 = The target shall perform the normal loop initialization procedure before entering the monitoring mode and accepting a login ELS.

1 = The target attached to an FC-AL-2 loop shall use the hard address available in the connector or in device address jumpers, enter the monitoring state in participating mode, and accept logins without using the loop initialization procedure (see FC-AL-2).

DTIPE (Disable Target Initiated Port Enable)

If the library is not attached to an arbitrated loop, it will ignore the DTIPE bit.

0 = The target shall enable itself onto the loop in accordance to the rules specified in FC-AL-2.

1 = The target attached to an arbitrated loop shall wait for an initiator to send the Loop Port Enable (LPE) primitive sequence before inserting itself into a loop (see FC-AL-2)

DTOLI (Disable Target Originated Loop Initialization)

If the library is not attached to an arbitrated loop, it will ignore the DTOLI bit.

0 = The target attached by an arbitrated loop shall generate LIP(F7,xx) after it enables a port into a loop.

1 = The target attached by an arbitrated loop shall not generate a LIP following insertion into the loop.

RR_TOV Units (Resource Recovery Timeout Units)

011b = 0.1 second units.

RR_TOV Values (Resource Recovery Timeout Value)

F0h = 24 seconds.

SAS Port Control Page

	Bit							
Byte	7	6	5	4	3	2	1	0
0	PS	SPF	Page Code (19h)					
1	Page Length							
2	Reserved	Cont. AWT	BAE	LED	Protocol Identifier			
3	Reserved							
4 to 5	I_T Nexus Loss Time							
6 to 7	Initiator Response Timeout							
8 to 9	Reject to Open Limit							
10 to 15	Reserved							

L207_283

PS (Parameters Savable)

The library sets this to 0.

SPF (SubPage Format)

0 = page_0 format.

Page Code

19h = SAS Port Control mode page.

Protocol Identifier

06h = Serial Attache SCSI protocol

Cont. AWT (Continuous Arbitration Wait Time)

0 = The SAS port shall stop the AWT timer and set the AWT timer to zero when it receives an OPEN_REJECT (RETRY).

1 = The SAS port shall not stop the AWT timer and shall not set the AWT timer to zero when the SAS port receives an OPEN_REJECT (RETRY).

BAE (Broadcast Asynchronous Event)

0 = Disable origination of Broadcast (Asynchronous Event).

1 = Enable origination of Broadcast (Asynchronous Event).

Ready LED Meaning

The Ready LED Meaning bit specifies the READY LED signal behavior.

I_T Nexus Loss Time

This field contains the minimum time that the SSP Target Port shall retry connection requests to an SSP initiator port that are rejected with responses indicating the SSP initiator port may no longer be present before recognizing an I_T nexus loss:

0000h = Vendor-specific amount of time.

0001h - FFFFh = Time in milliseconds.

FFFFh = The SSP target port shall never recognize an I_T nexus loss.

Initiator Response Timeout

This field contains the minimum time in milliseconds that the SSP target port shall wait for the receipt of a frame before aborting the command associated with that frame.

0000h indicates that the SSP target port shall wait forever.

Reject to Open Limit

This field contains the minimum time in 10 microsecond increments that the target port shall wait to establish a connection request with an initiator port on an I_T nexus after receiving an OPEN_REJECT (RETRY), OPEN_REJECT (RESERVED CONTINUE 0), or OPEN_REJECT (RESERVED CONTINUE 1).

0000h indicates that minimum time is vendor specific.

SAS Phy Control and Discover Mode Subpage

	Bit							
Byte	7	6	5	4	3	2	1	0
0	PS	SPF	Page Code (19h)					
1	Subpage Code (01h)							
2 to 3	Page Length							
4	Reserved							
5	Reserved				Protocol Identifier			
6	Generation Code							
7	Number of Phys							
SAS Phy Mode Descriptor List								
8 to 55	First SAS Phy Mode Descriptor							
56 to 103	Second SAS Phy Mode Descriptor							

L207_284

PS (Parameters Savable)

The library sets this to 0.

SPF (SubPage Format)

0 = page_0 format.

Page Code

19h = SAS Port Control mode page.

SubPage Code

01h = SAS Phy Control and Discover Mode Subpage

Protocol Identifier

06h = Serial Attache SCSI protocol

Generation Code

This field is a one-byte counter that shall be incremented by one by the device server every time the values in this mode page are changed.

Number of Phy

This field contains the number of phys in the SAS target device and indicates the number of SAS Phy Mode Descriptors in the SAS Phy Mode descriptor list.

SAS Phy Mode Descriptor Data

	Bit							
Byte	7	6	5	4	3	2	1	0
0	Reserved							
1	Phy Identifier							
2 to 3	Reserved							
4	Reserved	Attached Device Type			Reserved			
5	Reserved				Negotiated Physical Link Rate			
6	Reserved				SSP Init.	STP Init.	SMP Init.	Reserved
7	Reserved				SSP Target	STP Target	SMP Target	Reserved
8 to 15	SAS Address							
16 to 23	Attached SAS Address							
24	Attached Phy Address							
25 to 31	Reserved							
32	Programmed Minimum Physical Link Rate				Hardware Minimum Physical Link Rate			
33	Programmed Maximum Physical Link Rate				Hardware Maximum Physical Link Rate			
34 to 41	Reserved							
42 to 43	Vendor Specific							
44 to 47	Reserved							

PS (Parameters Savable)

The library sets this to 0.

Phy Identifier

A unique identifier is returned for each Phy.

Attached Device Type

000b = No device attached

001b = SAS device

010b = Expander device

011b = Expander device compliant with a previous version of the SAS standard

Negotiated Physical Link Rate

0h = UNKNOWN. Phy is enabled. Unknown Physical link rate.

1h = DISABLED. Phy is disabled.

2h = PHY_RESET_PROBLEM

3h = SPINUP_HOLD

4h = PORT_SELECTOR

8h = G1. Physical link rate is 1.5 Gb/s

9h = G2. Physical link rate is 3.0 Gb/s

Ah =G3. Physical link rate is 6.0 Gb/s

Attached SSP, STP, SMP, SSP, STP, and SMP Initiator Port

This bit indicates the value of the Initiator Port field received in the IDENTIFY address frame during the identification sequence.

SAS Address

The SAS Address of the drive that is the bridged interface for the library or partition.

Attached SAS Address

The SAS Address field transmitted in the IDENTIFY address frame during the identification sequence.

Attached Phy Address

The Attached Phy Address received in the IDENTIFY address frame during the identification sequence.

Link Rate

8h = 1.5 Gb/s

9h = 3.0 Gb/s

Ah = 6.0 Gb/s

Information Exceptions TapeAlert Page

	Bit							
Byte	7	6	5	4	3	2	1	0
0	PS	SPF	Page Code (1Ch)					
1	Page Length							
2	Perf	Reserved	EBF	EWasc	DExcpt	Test	Reserved	LogErr
3	Reserved				MRIE			
4 to 7	Interval Timer							
8 to 11	Report Counter / Test Flag Number							

PS (Parameters Savable)

The library sets this to 0.

SPF (SubPage Format)

0 = page_0 format.

Perf

Performance bit is set to 0, which indicates acceptance of informational exception operations that cause delays.

EBF

Enable Background Functions bit will always be 0.

EWasc

This should be set to 0 for the enable warning bit, indicating warning reporting shall be disabled.

DExcpt

The library accepts a value of 1, which indicates the target Disables All Information Exception operations and ignores the MRIE field. In this mode, the software must poll the TapeAlert Log page.

Test

0 = The library does not generate false/test informational exceptions.

1 = The library generates false/test informational exception conditions.

LogErr

The Log Error information exception conditions is set to 0, which indicates this is vendor-specific.

MRIE

Method the library uses to Report Informational Exceptions must be 3h, which indicates that the library reports any informational exception conditions by returning Check Condition status.

Interval Timer

Bytes 4 through 7 must be 00h. The library will only report informational exception condition one time.

Report Counter/Test Flag Number

This is a dual purpose field:

When the Test Flag bit is 0, this field is the report counter. Bytes 8 through 11 must be set to 00h to indicate there is no limit to the number of times the library will report the informational exception condition. This value is returned with Mode Sense.

When the Test bit is 1, this field is the test flag number.

Test Modes

Two test mode options are supported in the current TapeAlert implementation.

Test Mode for All Bits Supported

Using the mode select command to initiate this test will set all of the flags supported by the TapeAlert implementation in the TapeAlert log page. The TapeAlert log sense page then can be read to give the host a snapshot of the supported flags.

The flags will be cleared when the page is read. To do this, set the test mode flag in the TapeAlert mode select page. This indicates that the Report Count/Test Flag Number field is in Test Flag Number mode. Next, set the test flag number to 0x7FFF and issue the Mode Select command. When the command is complete, the TapeAlert log sense page can be read.

Test Mode for Individual Bits

Another test mode allows individual bits to be turned on. This can be useful for the host to debug/test operator interfaces.

Any flag set must be a supported flag. If the flag is not supported, a check condition with an incorrect parameter code is returned. The TapeAlert log sense page then can be read to allow the host to get a log page with the flag of interest set. The flag will be cleared when the page is read.

To test a flag, set the Test Flag in the TapeAlert mode select page. This indicates that the Report Count/Test Flag Number field is in Test Flag mode. Set the number of the flag to be tested. Issue the Mode Select command. When the command is complete, the TapeAlert log sense page can be read.

Element Address Assignment Mode Page

The library does not support changing Element Addresses. A check condition will be returned if the SCSI host issues a Mode Select command and attempts to change parameters in this page.

	Bit							
Byte	7	6	5	4	3	2	1	0
0	PS (0)	Reserved	Page Code (1Dh)					
1	Page Length (12h)							
2 to 3	First Medium Transport Element Address							
4 to 5	Number of Medium Transport Elements							
6 to 7	First Storage Element Address							
8 to 9	Number of Storage Elements							
10 to 11	First Import/Export Element Address							
12 to 13	Number of Import/Export Elements							
14 to 15	First Data Transfer Element Address							
16 to 17	Number of Data Transfer Elements							
18 to 19	Reserved							

PS (Parameters Savable)

Set to 0.

Page Code

1Dh = Element Address Assignment mode page.

Parameter Length

12h = 18d bytes of parameter data following this byte

First Medium Transport Element Address

0000h = The address of the robot in the library.

Number of Medium Transport Elements

Identifies the number of hands in the library.

The library has only one hand, so this field must be 0001h (1d).

First Storage Element Address

03E8h (1000d) = The address of the first data cartridge cell in the library or partition.

Number of Storage Elements

The number of data cartridge cells in the library or partition. This number depends on the configuration of the library or partition. The number must be the same number returned by Mode Sense. To obtain this value, use Mode Sense of mode page 1Dh.

First Import/Export Element Address

000Ah (10d) = The address of the first mailslot in the library or partition.

Number of Import/Export Elements

The number of mailslots in the library or partition. This number depends on the configuration of the library or partition. The number must be the same number returned by Mode Sense. To obtain this value, use Mode Sense of mode page 1Dh.

First Data Transfer Element Address

01F4h (500d) = The address of the first drive or empty drive slot in the library or partition. If the Address All Drive Slots option is set, then the first Data Transfer Element Address may be an empty drive slot.

Number of Data Transfer Elements

The number of drives and empty drive slots in the library. This number depends on the configuration of the library. The number must be the same number returned by Mode Sense. To obtain this value, use Mode Sense of mode page 1Dh.

Element Address Assignments

An initiator can modify the element addresses in the library using a Mode Select command. The four element types are:

- Medium transport (the hand)
- Storage element (storage cells)
- Import/export (mailslot cells)
- Data transfer (tape drives)

Each element type is defined as a range of consecutive elements based on a starting element and a count. The ranges may be configured in any order, but one element type range may not overlap another element type range, and gaps between ranges are allowed.

To change the element address assignments, an initiator should first perform a Mode Sense of mode page 1Dh (Element Address Assignment Page). This provides the count of each element type. The count of each element type cannot be changed and must be used as obtained from the Mode Sense command. Only the starting element number can be modified. The initiator must calculate the starting addresses of each type to ensure no overlaps.

Because the library supports the saved page function, the element address assignments can be saved in non-volatile memory. These values are used to configure the library during power-on and after a logical unit reset.

Mode Sense 6-byte (1Ah) and Mode Sense 10-byte (5Ah)

The Mode Sense commands return information about the library's operating mode parameters. The data can be truncated to the length specified in the allocation length field. The library returns a [Mode Sense Parameter Header](#) followed by one or more of the following mode pages:

- [FC Disconnect/Reconnect Page](#)
- [SAS Disconnect/Reconnect Page](#)
- [FC Logical Unit Control Page](#)
- [SAS Logical Unit Page](#)
- [FC Port Control Page](#)
- [SAS Port Control Page](#)
- [SAS Phy Control and Discover Mode Subpage](#)
- [SAS Shared Control Mode Subpage](#)
- [SAS Enhanced Phy Control Subpage](#)
- [Informational Exceptions Tape Alert Control Page](#)
- [Element Address Assignment Page](#)
- [Transport Geometry Mode Page](#)
- [Device Capabilities Page](#)

Figure 3–12 Mode Sense 6-Byte Command

	Bit							
Byte	7	6	5	4	3	2	1	0
0	Operation Code (1Ah)							
1	Ignored			Reserved	DBD	Reserved		
2	Page Control		Page Code					
3	SubPage Code							
4	Allocation Length							
5	Control Byte (00h)							

Figure 3–13 Mode Sense 10-Byte Command

	Bit							
Byte	7	6	5	4	3	2	1	0
0	Operation Code (5Ah)							
1	Ignored			LLBA	DBD	Reserved		
2	Page Control		Page Code					
3	SubPage Code							
4 to 6	Reserved							
7 to 8	Allocation Length							
9	Control Byte (00h)							

LLBA (10-byte only)

Set this to 0. The library will return 0 for LONGBLA in the parameter data.

DBD (Disable Block Descriptor)

The library ignores this field.

Page Control

0h (00b) = Current Values. The library returns the requested pages with each supported parameter set to its current value.

1h (01b) = Changeable Parameter Values. The library returns the requested pages indicating which parameters the initiator can change (1 indicates a changeable parameters and 0 indicates an unchangeable parameter).

2h (10b) = Default Values. The library returns the requested pages with each supported parameter set to its default. The default values are the same as the current values. Parameters not supported by the library are set to 0.

3h (11b) = Saved Values. This option is valid only with mode pages that can be saved. If the mode page cannot be saved, then a Check Condition is returned

Page Code

HP Bridged Tape Drive:

- 02h = Protocol Specific Disconnect/Reconnect page
- 18h = Protocol Specific Logical Unit page
- 19h = Protocol Specific Port Control page
- 1Ch = Informational Exceptions TapeAlert page
- 1Dh = Element Address Assignment page
- 1Eh = Transport Geometry page
- 1Fh = Device Capabilities page
- 3Fh = All pages (in the above order)

IBM Bridged Tape Drive:

- 1Ch = Informational Exceptions TapeAlert page
- 1Dh = Element Address Assignment page
- 1Eh = Transport Geometry page
- 1Fh = Device Capabilities page
- 3Fh = All pages (in the above order)

SubPage Code

Specifies which mode subpages are returned by the library. The supported mode subpages depend on the bridged tape drive.

HP Bridged Tape Drive: The field indicates the Serial Attached SCSI Port Control subpage, when the protocol is Serial Attached SCSI and the Page Code is set to 19h. The following subpages are supported:

01h = Serial Attached SCSI Phy Control and Discover Mode Subpage

02h = Serial Attached SCSI Shared Port Control Mode Subpage

03h = Serial Attached SCSI Enhanced Phy Control Mode Subpage

IBM Bridged Tape Drive: This field must be 00h. There are no supported mode subpages.

Allocation Length

The allocation length field specifies the maximum number of bytes that the initiator has allocated for data returned from the Mode Sense command. The library transfers either the number of bytes specified by the allocation length field or all of the available mode sense data, whichever is less. The allocation length depends on the mode page and the bridged tape drive. The maximum number of bytes returned by the library is 68h (104d) bytes for Mode Sense 6 and 6Ch (108h) bytes for Mode Sense 10.

A value of 00h indicated that no mode sense data is to be transferred. This condition is not considered an error.

For Mode Sense 6-byte:

HP Bridged Tape Drive:

- 04h = Mode Sense 6 Parameter Header Length
- 08h = Mode Sense 10 Parameter Header Length
- 10h = Disconnect Reconnect Page Length
- 08h = Logical Unit Page Length
- 08h = Fibre Channel Port Control Page Length
- 10h = SAS Port Control Page Length
- 64h = SAS Phy Control and Discover Mode Subpage Length
- 0Ch = Informational Exceptions Tape Alert Mode Page Length
- 14h = Element Address Assignment Page Length
- 04h = Transport Geometry Page Length
- 14h = Device Capabilities Page Length

IBM Bridged Tape Drive:

- 04h = Mode Sense 6 Parameter Header Length
- 08h = Mode Sense 10 Parameter Header Length
- 0Ch = Informational Exceptions Tape Alert Mode Page Length
- 14h = Element Address Assignment Page Length
- 04h = Transport Geometry Page Length
- 14h = Device Capabilities Page Length

IBM Bridged Tape Drive:

- 08h = Mode Sense Parameter Header Length
- 0Ch = Informational Exceptions Tape Alert Mode Page Length
- 14h = Element Address Assignment Page Length
- 04h = Transport Geometry Page Length
- 14h = Device Capabilities Page Length

Mode Sense Parameter Header

Figure 3–14 Mode Sense 6-Byte Parameter Header

Byte	Bit							
	7	6	5	4	3	2	1	0
0	Mode Data Length							
1 to 2	Reserved							
3	Block Descriptor Length (00h)							

SLK_088

Figure 3–15 Mode Sense 10-Byte Parameter Header

Byte	Bit							
	7	6	5	4	3	2	1	0
0 to 1	Mode Data Length							
2 to 5	Reserved							
6 to 7	Block Descriptor Length (00h)							

SLK_089

Mode Data Length

The bytes of parameter information available regardless of the allocation length. This value excludes the Mode Data Length byte, but includes three additional bytes (for Mode Sense 6-byte) or six additional bytes (for Mode Sense 10-byte) and the length of any mode pages that follow.

Block Descriptor Length (not supported)

The library returns 0.

FC Disconnect/Reconnect Page

See ["FC Disconnect/Reconnect Page"](#) on page 3-27

SAS Disconnect/Reconnect Page

See "[SAS Disconnect/Reconnect Page](#)" on page 3-29.

FC Logical Unit Control Page

See ["Fibre Channel Logical Unit Page"](#) on page 3-30.

SAS Logical Unit Page

See "[SAS Logical Unit Page](#)" on page 3-31.

FC Port Control Page

See ["Fibre Channel Port Control Page"](#) on page 3-32.

SAS Port Control Page

See "[SAS Port Control Page](#)" on page 3-34.

SAS Phy Control and Discover Mode Subpage

See "[SAS Phy Control and Discover Mode Subpage](#)" on page 3-36.

SAS Shared Control Mode Subpage

	Bit							
Byte	7	6	5	4	3	2	1	0
0	PS	SPF	Page Code (19h)					
1	Sub-Page Code							
2 to 3	Page Length							
4	Reserved							
5	Reserved				Protocol Identifier			
6 to 7	Power Loss Timeout							
8 to 15	Reserved							

PS (Parameters Saveable)

The library returns 0.

SPF (SubPage Format)

The library returns a value of 1 for the SubPage Format bit, indicating this page uses the sub_page mode page format.

Page Code

The value 19h identifies the page as the SAS Port Control mode page.

Subpage Code

The value 02h identifies the sub-page as the SAS Shared Port Control Mode Subpage.

Protocol Identifier

06h = Serial Attache SCSI protocol.

Power Loss Timeout

This field contains the maximum time, in one millisecond increments, that a target port shall respond to connection requests with OPEN_REJECT (RETRY) after receiving NOTIFY (POWER LOSSEXPECTED).

The value 0000h indicates that maximum time is vendor-specific.

SAS Enhanced Phy Control Subpage

	Bit							
Byte	7	6	5	4	3	2	1	0
0	PS	SPF	Page Code (19h)					
1	Subpage Code							
2 to 3	Page Length							
4	Reserved							
5	Reserved				Protocol Identifier			
6	Generation Code							
7	Number of Phys							
Enhanced Phy Mode Descriptor List								
8 to 27	First Enhanced Phy Mode Descriptor							
28 to 47	Second Enhanced Phy Mode Descriptor							

PS (Parameters Saveable)

The library returns 0.

SPF (SubPage Format)

The library returns a value of 1 for the SubPage Format bit, indicating this page uses the sub_page mode page format.

Page Code

The value 19h identifies the page as the SAS Port Control mode page.

Subpage Code

03h = SAS Enhanced Phy Control Mode Subpage

Protocol Identifier

06h = Serial Attache SCSI protocol.

Generation Code

This field is a one-byte counter that shall be incremented by one by the device server every time the values in this mode page are changed.

Number of Phys

This field contains the number of phys in the SAS target device and indicates the number of Enhanced Phy Control Mode Descriptors in the Enhanced Phy Control Mode descriptor list.

Enhanced Phy Control Mode Descriptor Data

Byte	Bit							
	7	6	5	4	3	2	1	0
0	Reserved							
1	Phy Identifier							
2 to 3	Descriptor Length							
4 to 7	Programmed Phy Capabilities							
8 to 11	Current Phy Capabilities							
12 to 15	Attached Phy Capabilities							
16 to 17	Reserved							
18	Reserved			Neg. SSC	Negotiated Physical Link Rate			
19	Reserved							Hdw. Muxing

Phy Identifier

A unique Phy Identifier is returned for each Phy.

Descriptor Length

The library returns a value of 10h (16d) bytes.

Programmed, Current, and Attached Phy Capabilities

This field indicates the SNW-3 (Speed Negotiation Window) Phy capabilities bits that are going to be transmitted in the next link reset sequence containing SNW-3 as defined below. If the last link reset sequence did not include SNW-3, then the field will be set to 00000000h.

Negotiated SSC

The Negotiated SSC bit is only valid when the Negotiated Physical Link Rate is greater than or equal to 8h. When valid:

0 = SSC is enabled.

1 = SSC is disabled.

Hardware Muxing Support

0 = The Phy does not support multiplexing.

1 = The Phy supports multiplexing.

Phy Capabilities Data

	Bit							
Byte	7	6	5	4	3	2	1	0
0	Start (1B)	TX SSC Type	Reserved		Requested Logical Link Rate			
Supported Settings								
1	G1 w/out SCC	G1 with SCC	G2 w/out SCC	G2 with SCC	G3 w/out SCC	G3 with SCC	Reserved	
2	Reserved							
3	Reserved							Parity

TX SSC Type

The value 0 indicates that the phy's transmitter uses down-spreading SSC when SSC is enabled (for example, the phy is a SAS phy), or that the phy does not support SSC.

The value 1 indicates that the phy's transmitter uses center-spreading SSC when SSC is enabled (for example, the phy is an expander phy).

Requested Logical Link Rate

This field indicates if the Phy device supports multiplexing and, if so, the logical link rate that the Phy device is requesting.

G* With and Without SSC

0 = Does not support

1 = Supports that G level

Parity

The Parity bit shall be set to one or zero such that the total number of SNW-3 Phy device capabilities bits that are set to one is even, including the Start bit and the Parity bit.

Informational Exceptions Tape Alert Control Page

See "[Information Exceptions TapeAlert Page](#)" on page 3-39.

Element Address Assignment Page

See "Element Address Assignment Mode Page" on page 3-41.

Transport Geometry Mode Page

	Bit							
Byte	7	6	5	4	3	2	1	0
0	PS (0)	Reserved	Page Code (1Eh)					
1	Page Length (02h)							
2	Reserved							Rotate (0)
3	Member Number in Transport Element Set (00h)							

SLK_091

PS (Parameters Savable)

The library returns 0.

Page Code

1Eh = the Transport Geometry mode page.

Page Length

The number of additional types of transport geometry descriptor data to follow the header. Each descriptor has two bytes of information.

02h = The library has one transport mechanism.

Rotate

0 = The library does not use multiple-sided media.

Member Number in Transport Element Set

Identifies the transport element in the system.

00h = The library has one transport element.

Device Capabilities Page

- DT — Data Transfer Element (drive)
- I/E — Import/Export Element (CAP cells)
- ST — Storage Element (cartridge storage cell)
- MT — Medium transport (robot hand)

	Bit							
Byte	7	6	5	4	3	2	1	0
0	PS (0)	Reserved	Page Code (1Fh)					
1	Page Length (12h)							
2	Reserved				StorDT (1)	StorI/E (1)	StorST (1)	StorMT (0)
3	Reserved							
4	Reserved				MT > DT (0)	MT > I/E (0)	MT > ST (0)	MT > MT (0)
5	Reserved				ST > DT (1)	ST > I/E (1)	ST > ST (1)	ST > MT (0)
6	Reserved				I/E > DT (1)	I/E > I/E (1)	I/E > ST (1)	I/E > MT (0)
7	Reserved				DT > DT (1)	DT > I/E (1)	DT > ST (1)	DT > MT (0)
8 to 11	Reserved							
12	Reserved				MT <> DT (0)	MT <> I/E (0)	MT <> ST (0)	MT <> MT (0)
13	Reserved				ST <> DT (0)	ST <> I/E (0)	ST <> ST (0)	ST <> MT (0)
14	Reserved				I/E <> DT (0)	I/E <> I/E (0)	I/E <> ST (0)	I/E <> MT (0)
15	Reserved				DT <> DT (0)	DT <> I/E (0)	DT <> ST (0)	DT <> MT (0)
16 to 19	Reserved							

PS (Parameters Savable)

The library returns 0.

Page Code

1Fh = The Device Capabilities mode page.

Page Length

12h = 18 bytes of device capabilities data to follow.

StorDT

1 = A tape drive can function as element storage.

StorI/E

1 = A CAP cell can function as element storage.

StorST

1 = A cartridge cell can function as element storage.

StorMT

0 = The robot hand cannot function as element storage. You cannot use the robot as the source or destination of a move.

MT > DT, MT > I/E, MT > ST, MT > MT, ST > MT, I/E > MT, DT > MT

0 = The robot hand (MT) cannot be the source or destination of a move.

ST > DT, ST > I/E, ST > ST, I/E > DT, I/E > I/E, I/E > ST, DT > DT, DT > I/E, DT > ST

1 = Tape drives (DT), CAP cells (I/E), and cartridge cells (ST) are valid sources or destinations for a move.

All <> Parameters

0 = The library does not support the exchange medium command.

Move Medium (A5h)

Move Medium (A5h) moves a cartridge tape from one element location to another. [Device Capabilities Page](#) of the Mode Sense command provides a matrix with the valid source and destination element combinations for Move Medium.

The Fast Load option on the library controls the completion of the move command when the destination element is a tape drive. If the fast load option is disabled, the library performs the move motion and waits until the tape drive load operation completes before returning status for the move command. When the fast load option is enabled, the library performs the move motion and verifies the tape drive load starts before returning status for the move command.

Note: If you issue a Move command from a CAP cell that contains an upside down cartridge, the library will return a check condition and set the sense data to Illegal Request (05h), ASC to 3Bh, and ASCQ to 18h.

	Bit							
Byte	7	6	5	4	3	2	1	0
0	Operation Code (A5h)							
1	Ignored			Reserved				
2 to 3	Transport Element Address							
4 to 5	Source Element Address							
6 to 7	Destination Element Address							
8 to 9	Reserved							
10	Reserved							Invert (0)
11	Move Option		Control Byte (00h)					

Transport Element Address

00h = The default robot hand. All other values will be ignored.

Source Element Address

The element address for the cartridge, which can be a storage cell, a CAP slot, or a tape drive.

Destination Element Address

The element address for the cartridge move, which can be a storage cell, a CAP cell, or a tape drive.

Invert (not supported)

Set this to 0.

Move Option

00b = The library performs a normal move operation

01b = Not supported

10b = The library performs a mount operation with write protection enabled. This is only valid if the destination is a drive. If the drive does not support this feature or fails to acknowledge the write-protected mount option, the mount fails and the library returns the Hardware Error sense key (04) with an ASC of 40 and an ASCQ of 02 (Drive Error).

11b = The drive performs a rewind, unload, and then move operation. This option is valid only when the source element address is a drive.

Caution: The 11b option might interfere with operations on the drive data path.

Persistent Reserve In (5Eh)

Persistent Reserve In (5Eh) returns information about active registrations or an active reservation. You can use Persistent Reserve In to help resolve contention among multiple initiators and multiple-port targets within the system.

	Bit							
Byte	7	6	5	4	3	2	1	0
0	Operation Code (5Eh)							
1	Ignored			Service Action				
2 to 6	Reserved							
7 to 8	Allocation Length							
9	Control Byte (00h)							

SLK_034

Service Action

00h = Returns [Read Keys Data](#)

01h = Returns [Read Reservation Data](#)

02h = Returns [Report Capabilities Data](#)

03h = Returns [Read Full Status Data](#)

04h through 1Fh are reserved.

Allocation Length

Indicates the space reserved for the returned parameter list. If the length is not sufficient to contain the entire parameter list, the parameter list will be incomplete. However, a partial list is not an error

Read Keys Data

The Read Keys Data is a list of all the currently registered reservation keys.

	Bit							
Byte	7	6	5	4	3	2	1	0
0 to 3	PRGeneration							
4 to 7	Additional Length ($n - 7$)							
Reservation Key List								
8 to 15	First Reservation Key							
More	Additional Reservation Keys							
$n - 7$ to n	Last Reservation Key							

PR Generation

A 32-bit counter that increments each time a Persistent Reserve Out command requests a Register, a Register and Ignore, a Clear, a Preempt, or a Preempt and Abort operation. The counter allows the application client to determine if another application client has changed the configuration.

A Power-On-Reset sets the counter to zero.

Additional Length

The number of bytes in the reservation key list.

Reservation Key List

Contains the eight-byte reservation keys registered with the library through a Persistent Reserve Out command.

Read Reservation Data

The Read Reservation Data is a description of all currently registered reservation keys.

Byte	Bit							
	7	6	5	4	3	2	1	0
0 to 3	PRGeneration							
4 to 7	Additional Length ($n - 7$)							
8 to n	Reservation Descriptor							

PR Generation

A 32-bit counter that increments each time a Persistent Reserve Out command requests a Register, a Register and Ignore, a Clear, a Preempt, or a Preempt and Abort operation. The counter allows the application client to determine if another application client has changed the configuration.

A Power-On-Reset sets the counter to zero.

Additional Length

The number of bytes in the reservation descriptor list.

0 = No reservation held

16 = Active reservation data

Reservation Descriptor

Each persistent reservation for a logical unit has one reservation descriptor that has the format shown below.

	Bit							
Byte	7	6	5	4	3	2	1	0
0 to 7	Reservation Key							
8 to 11	Obsolete							
12	Reserved							
13	Scope				Type			
14 to 15	Obsolete							

SLK_097

Reservation Key

The reservation key for the descriptor data that follows.

Scope

Indicates whether a persistent reservation applies to an entire logical unit or to an element. The only valid value is 0h.

0h = The persistent reservation applies to the logical unit

Type

3h = Exclusive access. The initiator holding the persistent reservation has exclusive access. Some commands (such as Move Medium) are only allowed for the persistent reservation holder.

6h = Exclusive Access, Registrants Only. Any currently registered initiator has exclusive access. Some commands (such as Move Medium) are only allowed for registered I_T nexuses.

8h = Exclusive Access, Registrants Only: This value indicates that any currently registered initiator has exclusive access. Some commands (such as Move Medium) are only allowed for registered I_T nexuses.

Report Capabilities Data

	Bit							
Byte	7	6	5	4	3	2	1	0
0 to 1	Length (0008h)							
2	Reserved			CRH	SIP_C	ATP_C	Reserved	PTPL_C
3	TVM	Reserved						PTPL_A
Persistent Reservation Mask								
4	WR_EX_AR	EX_AC_RO	WR_EX_RO	Reserved	EX_AC	Reserved	WR_EX	Reserved
5	Reserved							EX_AC_AR
6 to 7	Reserved							

Length

The length in bytes of the parameter data.

CRH (Compatibility Reservation Handling)

1 = The library supports the exceptions to the SPC-2 RESERVE and RELEASE commands as described in SPC-3.

SIP_C (Specify Initiator Ports Capable)

1 = The library supports the SPEC_I_PT bit in the PERSISTENT RESERVE OUT command parameter data.

ATP_C (All Target Ports Capable)

0 = The library does not support the ALL_TG_PT bit in the [Persistent Reserve Out \(5Fh\)](#) command parameter data.

1 = The library supports the ALL_TG_PT bit in the PERSISTENT RESERVE OUT command parameter data.

PTPL_C (Persist Through Power Loss Capable)

0 = The library does not support the persist through power loss capability for persistent reservations and the APTPL bit in the [Persistent Reserve Out \(5Fh\)](#) command parameter data.

1 = The library supports the persist through power loss capability for persistent reservations and the APTPL bit in the in PERSISTENT RESERVE OUT command parameter data

TMV (Type Mask Valid)

0 = Ignore the persistent reservation type mask.

1 = The persistent reservation type mask field contains a bit map indicating which persistent reservation types the library supports.

PTPL_A (Persist Through Power Loss Activated)

0 = The library does not support the Persist Through Power Loss Activated bit.

1 = The persist through power loss capability is activated.

WR_EX_AR (Write Exclusive-All Registrants)

0 = The library does not support the Write Exclusive-All Registrants persistent reservation type.

EX_AC_RO (Exclusive Access Registrants Only)

1 = The library supports this persistent reservation type.

WR_EX_RO (Write Exclusive Registrants Only)

0 = The library does not support the Write Exclusive-Registrants Only persistent reservation type.

EX_AC (Exclusive Access)

1 = The library supports this persistent reservation type.

WR_EX (Write Exclusive)

0 = The library does not support the Write Exclusive persistent reservation type.

EX_AC_AR (Exclusive Access All Registrants)

0 = The library does not support the Exclusive Access-All Registrants persistent reservation type.

Read Full Status Data

The Read Full Status service action requests that the library return a list of all the current Reservation keys it has registered along with information about each initiator.

	Bit							
Byte	7	6	5	4	3	2	1	0
0 to 3	PRGeneration							
4 to 7	Additional Length (n-7)							
Full Status Descriptors								
8 to 55	First Full Status Descriptor							
n-47 to n	Last Full Status Descriptor							

PR Generation

A 32-bit counter that increments each time a Persistent Reserve Out command requests a Register, a Register and Ignore, a Clear, a Preempt, or a Preempt and Abort operation. The counter allows the application client to determine if another application client has changed the configuration.

A Power-On-Reset sets the counter to zero.

Additional Length

Number of bytes in the list of the full status descriptors.

Full Status Descriptor

	Bit							
Byte	7	6	5	4	3	2	1	0
0 to 7	Reservation Key							
8 to 11	Reserved							
12	Reserved						ALL_TG_PT	R_HOLD_ER
13	Scope				Type			
14 to 17	Reserved							
18 to 19	Relative Target Port Identifier							
20 to 23	Additional Descriptor Length							
Transport ID Data								
24	Format Code		Reserved		Protocol Identifier			
25 to 31 (FC) 25 to 27 (SAS)	Reserved							
32 to 39 (FC) 28 to 35 (SAS)	N_Port_Name (FC) / SAS Address							
40 to 47 (FC) 36 to 47 (SAS)	Reserved							

Reservation Key

The reservation key for the descriptor data that follows.

ALL_TG_PT (All Target Port Groups)

0 = single I_T nexus.

1 = all the I_T nexuses that are associated with both the initiator port specified by the Transport ID Data and every target port in the SCSI target device. Indicates that all the I_T nexuses are registered with the same reservation key and all the I_T nexuses are either reservation holders or not reservation holders as indicated by the R_HOLDER bit.

R_Holder

0 = All I_T nexuses described by this full status descriptor are registered but are not persistent reservation holders.

1 = All I_T nexuses described by this full status descriptor are registered and are persistent reservation holders.

Type

When the Reservation Holder Bit is 1, this field indicates the type of Persistent Reservation:

3h = Exclusive Access

6h = Exclusive Access - Registrants Only

8h = Exclusive Access - All Registrants

Relative Target Port Identifier

1 = Target Port 1

2 = Target Port 2

Transport ID Data**Protocol Identifier**

0h = Fibre Channel protocol

06h = Serial Attached SCSI protocol

N_PORT_NAME (Fibre Channel)

This field specifies the N_Port_Name that is returned by the initiator in the PLOGI extended link service frame.

SAS Address

SAS Address of the initiator port

Persistent Reserve Out (5Fh)

Persistent Reserve Out (5Fh) uses service actions to create, manage, or remove a persistent reservation.

The application client provides a registered reservation key that identifies the initiator. An application client may use the [Persistent Reserve In \(5Eh\)](#) command to obtain the reservation key for the initiator holding a persistent reservation. The client may use the Persistent Reserve Out command to preempt that persistent reservation.

Note: For more information on command processing when the library has a persistent reservation, see "[Reservation Handling](#)" on page 2-3.

	Bit							
Byte	7	6	5	4	3	2	1	0
0	Operation Code (5Fh)							
1	Ignored			Service Action				
2	Scope				Type			
3 to 4	Reserved							
5 to 8	Parameter List Length							
9	Control Byte (00h)							

Service Action

- 00h = Register — registers or unregisters a reservation key.
- 01h = Reserve — creates a persistent reservation of the scope and type specified in Byte 2.
- 02h = Release — removes an active persistent reservation, if the initiator holds the persistent reservation.
- 03h = Clear — clears all persistent reservations for all initiators and reset all reservation keys to 0.
- 04h = Preempt — removes all reservations and registrations for the initiators associated with the service action reservation key in the parameter list.
- 05h = Preempt and Abort — perform a Preempt action and terminate all commands by initiators associated with the cleared service action reservation key. This also clears any CAP locks and contingent allegiance in effect for these initiators.
- 06h = Register and Ignore Existing Key — registers or unregisters a reservation key with the library.
- 07h = Register and Move — register a reservation key for another I_T nexus with the device server and move a persistent reservation to that I_T nexus.

Scope

Indicates whether a persistent reservation applies to an entire logical unit or to an element.

0h = The persistent reservation applies to the logical unit (library or partition). This is the only valid value.

Type

3h = Exclusive access. The initiator holding the persistent reservation has exclusive access. Some commands (such as Move Medium) are only allowed for the persistent reservation holder.

6h = Exclusive Access, Registrants Only. Any currently registered initiator has exclusive access. Some commands (such as Move Medium) are only allowed for registered initiators.

8h = Exclusive Access, All Registrants: Some commands (for example, Move Medium) are only allowed for registered I_T nexuses. Each registered I_T nexus is a persistent reservation holder.

Parameter List Length

The parameter data for the Persistent Reserve Out command includes all fields, even when a field is not required for the specified service action.

Persistent Reserve Out Parameter List

Byte	Bit							
	7	6	5	4	3	2	1	0
0 to 7	Reservation Key							
8 to 15	Service Action Reservation Key							
16 to 19	Obsolete							
20	Reserved				SPEC_I_PT	ALL_TGT_PT	Reserved	APTPL
21	Reserved							
22 to 23	Obsolete							

SLK_126

Reservation Key

An 8-byte value that identifies the initiator.

Service Action Reservation Key

This field contains information needed for five service actions: Register, Register and Ignore Existing Key, Preempt, Preempt and Abort, and Register and Move.

SPEC_I_PT (Specify Initiator Ports - not supported)

The Specify Initiator Ports bit is only applicable to the Register and Register and Ignore Service Actions:

0 = The library shall apply the registration only to the I_T nexus that sent the Persistent Reservation Out command.

1 = The additional parameter data shall include a list of Transport IDs and the library shall also apply the registration to the I_T nexus for each initiator port specified by a TransportID.

ALL_TG_PT (All Target Ports - not supported)

The All Target Ports bit is not supported and must be set to 0.

APTPL (Activate Persist Through Power Loss)

The Activate Persist Through Power Loss bit is only valid for the Register, Register and Ignore, and Register and Move service actions and is defined as follows:

0 = The library shall not preserve any persistent reservation and all registrations if power is lost and later returned.

1 = The library preserves any persistent reservation and all registrations if power is lost and later returned.

Table 3–1 Persistent Reserve Out Service Actions and Valid Parameters

Service Action	Scope	Type	Reservation Key	Service Action Res. Key	ALL_TG_PT, and APTPL	SPEC_I_PT
Register	Ignored	Ignored	Valid	Valid	Valid	Valid
Register and Ignore	Ignored	Ignored	Ignored	Valid	Valid	Valid
Reserve	LU_SCOPE	Valid	Valid	Ignored	Ignored	Ignored
Release	LU_SCOPE	Valid	Valid	Ignored	Ignored	Ignored
Clear	Ignored	Ignored	Valid	Ignored	Ignored	Ignored
Preempt	LU_SCOPE	Valid	Valid	Valid	Ignored	Ignored
Preempt Abort	LU_SCOPE	Valid	Valid	Valid	Ignored	Ignored
Register and Move	LU_SCOPE	Valid	Valid	Valid	Valid	Ignored

Table 3–2 Service Action Reservation Key Information

If the service action is...	Then the information in the field is the...
Register	New reservation key to be registered.
Register and Ignore Existing Key	New reservation key to be registered.
Preempt	Reservation key of the persistent reservation being preempted.
Preempt and Abort	Reservation key of the persistent reservation being preempted.
Register and Move	Reservation key to be registered on the specified I_T nexus.

Position to Element (2Bh)

Position to Element (2Bh) moves the robot to the destination element.

Note: The Position to Element command (2Bh) is supported only for compatibility with existing applications. The library accepts this command for compatibility.

	Bit							
Byte	7	6	5	4	3	2	1	0
0	Operation Code (2Bh)							
1	Ignored			Reserved				
2 to 3	Transport Element Address							
4 to 5	Destination Element Address							
6 to 7	Reserved							
8	Reserved							Invert (0)
9	Control Byte (00h)							

Transport Element Address

0000h = The element address of the robot.

Destination Element Address

The element address of the storage cell, mailslot cell, or drive. The robot positions the hand at this location.

Invert (not supported)

Set this to 0.

Prevent/Allow Medium Removal (1Eh)

The Prevent/ Allow Medium Removal command (1Eh) requests that the library enable or disable operator access to the mailslot and magazine(s).

- If allowed, the mailslot and magazine(s) are unlocked. The mailslot may be opened and the magazine(s) may be unlatched from the user interface.
- If prevented, the mailslot and magazine(s) are locked. The mailslot cannot be opened and the magazine(s) cannot be unlatched from the user interface.

All initiators are set to an allow media removal state, which enables user interface access to the mailslots and magazine(s), after a power on reset, library reset, bridged tape drive reset, or SCSI task management reset that affects LUN 1.

The Prevent/ Allow Media Removal Behavior depends on the bridged tape drive in a multi-initiator environment.

- The HP Bridged Tape Drive keeps Prevent/Allow data on a per-initiator basis. If any initiator has set a prevent state, the library prevents anyone from opening the mailslot or unlatching the magazine(s).
- The IBM Bridged Tape Drive keeps Prevent data on a per-initiator basis. If any initiator issues an Allow Media Removal command, then the Prevent data is cleared for all initiators and Media Removal is allowed.

	Bit							
Byte	7	6	5	4	3	2	1	0
0	Operation Code (1Eh)							
1	Ignored			Reserved				
2 to 3	Reserved							
4	Reserved						Prevent	
5	Control Byte (00h)							

SLIK_100

Prevent

0 = Allow — The library unlocks the mailslot and magazines.

1 = Prevent — The library locks the mailslot and magazines.

Read Element Status (B8h)

Read Element Status (B8h) returns the status of elements in the library or partition.

The library returns an eight-byte [Element Status Data Header](#), followed by an element page (or four element pages if you set the type code to All Element Types). Each element page consists of an eight-byte [Element Status Page Header](#), followed by the element type descriptor. Supported element type descriptors include:

- [Medium Transport Element Descriptor](#)
- [Storage Element Descriptor](#)
- [Import/Export Element Descriptor](#)
- [Data Transfer Element Descriptor \(DvcID = 0\)](#)
- [Data Transfer Element Descriptor \(DvcID = 1\)](#)

	Bit							
Byte	7	6	5	4	3	2	1	0
0	Operation Code (B8h)							
1	Ignored			VolTag	Element Type Code			
2 to 3	Starting Element Address							
4 to 5	Number of Elements							
6	Reserved						CurData	DvcID
7 to 9	Allocation Length							
10	Reserved							
11	Control Byte (00h)							

VolTag

0 = The library does not report Volume Tag information

1 = The library reports Volume Tag information

Element Type Code

0h = All Element Types

1h = Medium Transport Element (robot hand)

2h = Storage Element (cartridge cells)

3h = Import/Export Element (mailslot cells)

4h = Data Transfer Element (drives or empty drive slots)

Starting Element Address

Specifies the minimum element address. The library reports elements with an element address greater than or equal to the Starting Element Address.

Number of Elements

The maximum number of element descriptors to transfer. This is not an element address range.

CurData

The library ignores the CurData bit and will use the robots to obtain information if needed.

0 = The library can use the robots to gather data

1 = The library will not perform mechanical operations to obtain the data

DvcID

0 = The library will not return device identification information

1 = The library returns device identification information for data transfer elements.

Allocation Length

The length in bytes of the space allocated by the initiator for the transfer of element descriptors. Only complete element descriptors are transferred. Data can be truncated based on the length specified in the allocation field.

Element Status Data Header

Byte	Bit							
	7	6	5	4	3	2	1	0
0 to 1	First Element Address Reported							
2 to 3	Number of Elements Available							
4	Reserved							
5 to 7	Byte Count of Report Available (all pages, $n - 7$)							
8 to n	Element Status Page							

SLK_102

First Element Address Reported

The lowest element address found for the specified Element Type Code that is greater than or equal to the Starting Element Address.

Number of Elements Available

The number of elements found for the specified Element Type Code that are greater than or equal to the Starting Element Address. This number is always less than or equal the Number of Elements specified in the CBD.

Byte Count of Report Available

The number of bytes of element status data available. This count does not include the Element Status Data header bytes. The count is not adjusted to match the allocation length you specified in the Read Element Status command.

Element Status Page Header

	Bit							
Byte	7	6	5	4	3	2	1	0
0	Reserved				Element Type Code			
1	PVolTag	AVolTag (0)	Reserved					
2 to 3	Element Descriptor Length							
4	Reserved							
5 to 7	Byte Count of Report Available (all pages, $n - 7$)							
8 to n	Element Descriptor							

SLK_103

Element Type Code

1h = Medium Transport Element (robot hand)

2h = Storage Element (cartridge cells)

3h = Import/Export Element (mailslot cells)

4h = Data Transfer Element (drives or empty drive slots)

PVolTag

0 = The library omits Primary Volume Tag information from the element descriptors.

1 = The library includes Primary Volume Tag information in the element descriptors.

AVolTag

0 = The library does not support Alternative Volume Tags.

Element Descriptor Length

The total number of bytes contained in a single element descriptor.

Byte Count of Descriptor Data Available

The number of bytes of element descriptor data available. This count does not include the Element Status Page header bytes. The count is not adjusted to match the allocation length you specified in the Read Element Status command.

Element Descriptors

[Medium Transport Element Descriptor](#)

[Storage Element Descriptor](#)

[Import/Export Element Descriptor](#)

[Data Transfer Element Descriptor \(DvcID = 0\)](#)

[Data Transfer Element Descriptor \(DvcID = 1\)](#)

Element Descriptors

Figure 3–16 Medium Transport Element Descriptor

Byte		Bit							
PVolTag=0	PVolTag=1	7	6	5	4	3	2	1	0
0 to 1	0 to 1	Element Address							
2	2	Reserved					Except	Reserved	Full
3	3	Reserved							
4	4	Additional Sense Code							
5	5	Additional Sense Code Qualifier							
6 to 8	6 to 8	Reserved							
9	9	SValid	Invert (0)	Reserved		ED	Medium Type		
10 to 11	10 to 11	Source Storage Element Address							
--	12 to 47	Primary Volume Tag Information (omitted if PVolTag = 0)							
12	48	Reserved				Code Set (0)			
13	49	Reserved				Identifier Type (0)			
14	50	Reserved							
15	51	Identifier Length (0)							
16	52	Media Domain							
17	53	Media Type							
18 to 19	54 to 55	Reserved							

SLK_104

Figure 3–17 Storage Element Descriptor

Byte		Bit							
PVolTag=0	PVolTag=1	7	6	5	4	3	2	1	0
0 to 1	0 to 1	Element Address							
2	2	Reserved				Access (1)	Except	Reserved	Full
3	3	Reserved							
4	4	Additional Sense Code							
5	5	Additional Sense Code Qualifier							
6 to 8	6 to 8	Reserved							
9	9	SValid	Invert (0)	Reserved		ED	Medium Type		
10 to 11	10 to 11	Source Storage Element Address							
--	12 to 47	Primary Volume Tag Information (omitted if PVolTag = 0)							
12	48	Reserved				Code Set (0)			
13	49	Reserved				Identifier Type (0)			
14	50	Reserved							
15	51	Identifier Length (0)							
16	52	Media Domain							
17	53	Media Type							
18 to 19	54 to 55	Reserved							

SLK_105

Figure 3–18 Import/Export Element Descriptor

Byte		Bit							
PVolTag=0	PVolTag=1	7	6	5	4	3	2	1	0
0 to 1	0 to 1	Element Address							
2	2	OIR	CMC (0)	InEnab (1)	ExEnab(1)	Access	Except	ImpExp	Full
3	3	Reserved							
4	4	Additional Sense Code							
5	5	Additional Sense Code Qualifier							
6 to 8	6 to 8	Reserved							
9	9	SValid	Invert (0)	Reserved		ED	Medium Type		
10 to 11	10 to 11	Source Storage Element Address							
--	12 to 47	Primary Volume Tag Information (omitted if PVolTag = 0)							
12	48	Reserved				Code Set (0)			
13	49	Reserved				Identifier Type (0)			
14	50	Reserved							
15	51	Identifier Length (0)							
16	52	Media Domain							
17	53	Media Type							
18 to 19	54 to 55	Reserved							

SLK_106

Figure 3–19 Data Transfer Element Descriptor (DvcID = 0)

Byte		Bit							
PVolTag=0	PVolTag=1	7	6	5	4	3	2	1	0
0 to 1	0 to 1	Element Address							
2	2	Reserved				Access	Except	Reserved	Full
3	3	Reserved							
4	4	Additional Sense Code							
5	5	Additional Sense Code Qualifier							
6 to 8	6 to 8	Reserved							
9	9	SValid	Invert (0)	Reserved		ED	Medium Type		
10 to 11	10 to 11	Source Storage Element Address							
--	12 to 47	Primary Volume Tag Information (omitted if PVolTag = 0)							
12	48	Reserved				Code Set (0)			
13	49	Reserved				Identifier Type (0)			
14	50	Reserved							
15	51	Identifier Length (0)							
16	52	Media Domain							
17	53	Media Type							
18	54	Transport Domain							
19	55	Transport Type							
20 to 51	56 to 87	Transport Serial Number							

SLK_107

Figure 3–20 Data Transfer Element Descriptor (DvcID = 1)

Byte		Bit							
PVolTag=0	PVolTag=1	7	6	5	4	3	2	1	0
0 to 1	0 to 1	Element Address							
2	2	Reserved				Access	Except	Reserved	Full
3	3	Reserved							
4	4	Additional Sense Code							
5	5	Additional Sense Code Qualifier							
6 to 8	6 to 8	Reserved							
9	9	SValid	Invert (0)	Reserved		ED	Medium Type		
10 to 11	10 to 11	Source Storage Element Address							
--	12 to 47	Primary Volume Tag Information (omitted if PVolTag = 0)							
12	48	Reserved				Code Set (2)			
13	49	Reserved				Identifier Type (0)			
14	50	Reserved							
15	51	Identifier Length (<i>n</i>)							
16 to 16+ <i>n</i> -1	52 to 52+ <i>n</i> -1	Identifier (Drive ASCII Serial Number)							
32 - <i>n</i> bytes	32 - <i>n</i> bytes	Identifier Pad							
48	84	Media Domain							
49	85	Media Type							
50	86	Transport Domain							
51	87	Transport Type							

SLK_108

Element Address

The address of the element (robot hand, cartridge cell, CAP cell, drive, or empty drive slot).

OIR

0 = No operator intervention required to make the CAP accessible

1 = Operator intervention required to make the CAP accessible

CMC

0 = The import/export element is a CAP. The cartridge will not leave the library when prevented by the [Prevent/Allow Medium Removal \(1Eh\)](#) command.

InEnab

1 = The CAP supports importing cartridges.

ExEnab

1 = The CAP supports exporting cartridges.

Access

0 = The robot cannot access the element. For Import/Export elements, this can occur when the CAP is open or a CAP magazine was removed. For Data transfer elements, this can occur when a cartridge is loaded in a drive.

1 = The robot can access the element

Except

0 = The element is in a normal state

1 = The element is in an abnormal state. The Additional Sense Code (ASC) and the Additional Sense Code Qualifier (ASCQ) fields contain information regarding the abnormal state. Other fields in the descriptor might be invalid and should be ignored.

ImpExp

0 = The robot placed the cartridge in the CAP for an export operation.

1 = An operator placed the cartridge in the CAP for an import operation.

Full

0 = The element does not contain a cartridge

1 = The element contains a cartridge

ASC (Additional Sense Code)

This field is valid only if the Except bit is set. In the case of an exception, it contains an ASC as defined for Request Sense data.

ASCQ (Additional Sense Code Qualifier)

This field is valid only if the Except bit is set. In the case of an exception, it contains an ASCQ as defined for Request Sense data.

Condition	ASC Value	ASCQ Value
CAP Open	3Ah	02h
Empty Drive Slot (no drive installed)	3Bh	1Ah
Drive Hardware Error	40h	02h

SValid

0 = The Source Element Address and Invert fields are not valid.

1 = The Source Element Address and Invert fields are valid.

Invert (not supported)

0 = The library does not support multi-sided media.

ED

0 = The element is enabled.

1 = The element is disabled (for example an open CAP, a drive hardware error, or empty drive slot).

Medium Type

The type of medium currently present in the element as determined by the medium changer.

0h = Unspecified - the medium changer cannot determine the medium type.

1h = Data Medium

2h = Cleaning Medium

Source Storage Element Address

This field is valid only if the SValid field is 1. This field provides the address of the last storage element this cartridge occupied. The element address value may or may not be the same as this element.

Primary Volume Tag Information

When PVolTag is 1, the library returns volume tag information. When PVolTag is 0, the library omits volume tag information.

The Primary Volume Tag field contains the null-terminated ASCII barcode label on the tape cartridge. If the label on the cartridge tape is not readable or if the element is

empty, the Primary Volume Tag field is filled with 36 bytes of zeros. The "Volume Label Format" controls the presentation of the volser in the Primary Volume Tag field. The library supports the following settings:

- Full Label
- No Type Checking
- Prepend Last Two Characters
- Trim Last Character
- Trim Last Two Characters
- Trim First Two Characters
- Trim First Character

For more information, see the SL150 Library Guide.

Code Set

0h = Reserved (not supported) for the Medium Transport Element, Storage Element, Import/Export Element, or Data Transfer Element (DvcID = 0) descriptors.

2h = The identifier contains ASCII graphic codes (code values 20h through 7Eh) for Data Transfer Element (DvcID = 1) descriptor.

Identifier Type

The format and assignment authority for the identifier.

0h = The library returns vendor specific data.

Identifier Length

The combined length of the Identifier and the Identifier Pad.

00h = The library returns 0 bytes of identifier data in the descriptors for Medium Transport Elements, Storage Elements, Import/Export Elements, or Data Transfer Elements (DvcID = 0).

20h = The library returns 32 bytes of identifier data for the Data Transfer Element (DvcID = 1).

Identifier (for Data Transfer Element DvcID = 1 Only)

The ASCII Serial Number for the tape drive associated with this data transfer element.

Identifier Pad (for Data Transfer Element DvcID = 1 Only)

Contains ASCII blanks. The number of blanks depends on the length of the Identifier field. The combined length of the Identifier field and the Identifier Pad is 32 bytes.

Media Domain

43h ('C') = The element contains a cleaning cartridge.

4Ch ('L') = The element contains an LTO cartridge.

54h ('T') = The element contains a T10000 cartridge.

FFh = The media domain cannot be determined or the element is empty.

Media Type

FFh = The media type cannot be determined or the element is empty.

If the Media Domain is 43h (C):

- U = The element contains a Universal LTO cleaning cartridge.

If the Media Domain is 4Ch (L):

- 3 = The element contains a 400 GB Generation 3 LTO cartridge.
- 4 = The element contains an 800 GB Generation 4 LTO cartridge.
- 5 = The element contains a 1.5 TB Generation 5 LTO cartridge.
- 6 = The element contains a 2.5 TB Generation 6 LTO cartridge.
- 7 = The element contains a 6 TB Generation 7 LTO cartridge.
- 8 = The element contains a 12 TB Generation 8 LTO cartridge.
- R = The element contains a 9TB M8 LTO cartridge. Note that the physical label for this media type will be M8 (not LR).
- T = The element contains a 400 GB Generation 3 LTO WORM cartridge.
- U = The element contains an 800 GB Generation 4 LTO WORM cartridge.
- V = The element contains a 1.5 TB Generation 5 LTO WORM cartridge.
- W = The element contains a 2.5 TB Generation 6 LTO WORM cartridge.
- X = The element contains a 6 TB Generation 7 LTO WORM cartridge.
- Y = The element contains a 12 TB Generation 8 LTO WORM cartridge.

Transport Domain

4Ch (L) = The drive supports LTO cartridges.

FFh = The element domain cannot be determined.

Transport Type

FFh = The type cannot be determined.

If the Transport Domain is 4Ch (L):

- 3Bh = HP Generation 5 LTO drive
- 3Ch = IBM Generation 5 LTO drive
- 3Dh = HP Generation 6 LTO drive.
- 3Eh = IBM Generation 6 LTO drive.
- 2Dh = IBM Generation 7 LTO drive.
- 2Eh = IBM Generation 8 LTO drive.

Transport Serial Number

The 32-byte ASCII serial number for the drive.

For drives with a serial number less than 32 bytes, the library left-justifies the value by returning ASCII blanks for the unused less-significant bytes. If the serial number is not available from a drive that should support an ASCII serial number, the library returns all ASCII blanks.

Release 6-byte (17h) and Release 10-byte (57h)

Release (17h and 57h) releases a unit reservation of the library. Only the initiator that made the reservation can release the reservation. The 10-byte Release command (57h) enables the initiator to release unit reservations of the library as set using a previous Reserve command and optionally to perform a release for a third party initiator.

If another initiator attempts to release a unit reservation, the library returns **Good (00h)** status, but does not release the reservation. If the library has no active reservations, requesting a release does not cause an error.

Figure 3–21 6-Byte Command

	Bit							
Byte	7	6	5	4	3	2	1	0
0	Operation Code (17h)							
1	Ignored			Obsolete (0h)				
2	Obsolete (00h)							
3 to 4	Reserved							
5	Control Byte (00h)							

SLK_109

Figure 3–22 10-Byte Command

	Bit							
Byte	7	6	5	4	3	2	1	0
0	Operation Code (57h)							
1	Ignored			3rdpty	Reserved		LongID	Obsolete
2	Reserved							
3	Third Party Device ID							
4 to 6	Reserved							
7 to 8	Parameter List Length							
9	Control Byte							

L207_293

3rdpty

This field indicates whether the reservation is on behalf of a third party or not.

0 = The reservation is on behalf of the calling requester.

1 = The reservation is on behalf of a specified Third party Device Id.

Long ID

The library ignores this field.

Third Party Device ID

ID of the third party device.

Parameter List Length

The library ignores this field.

Report LUNs (A0h)

Report LUNS (A0h) returns the known LUNs to which the initiator can send commands.

	Bit							
Byte	7	6	5	4	3	2	1	0
0	Operation Code (A0h)							
1	Ignored			Reserved				
2	Select Report							
3 to 5	Reserved							
6 to 9	Allocation Length							
10	Reserved							
11	Control Byte (00h)							

SLK_110

Select Report

00h = The library returns LUN addresses limited to the LUN addressing method, peripheral device addressing method, and the flat space addressing method.

02h = The library returns all LUNs accessible to the initiator.

Note: IBM Bridged Drive: A Select Report option of 2 is not supported by an IBM Bridged Tape Drive. The SCSI Report LUNs command with a Select Report option of 2 will end in Check Condition Status, when the Bridged Tape Drive is an IBM tape drive. The additional sense data will indicate there is an invalid field in the command descriptor block (CDB).

Allocation Length

The number of bytes allocated for data to be returned from the Report LUNs command.

The Allocation must be at least 16 bytes. If it is less, the library returns a check condition with the sense key set to "illegal request" and the additional sense data set to "invalid field" in the command descriptor block (CDB).

Note: HP Bridged Drive: The Allocation must be at least 16 bytes. If it is less, a check condition is returned with the sense key set to illegal request and the additional sense data set to invalid field in the command descriptor block (CDB).

Report LUNs Data

	Bit							
Byte	7	6	5	4	3	2	1	0
0 to 3	LUN List Length							
4 to 7	Reserved							
LUN Descriptor								
8	Address Method (00b)		Bus ID (0h)					
9	Single Level LUN Address							
10 to 11	Second Level LUN Address (00h)							
12 to 13	Third Level LUN Address (00h)							
14 to 15	Fourth Level LUN Address (00h)							
<i>n-7 to n</i>	Last LUN Descriptor							

LUN List Length

The library returns the length in bytes of the LUN list available for transfer. It is equal to 8 times the number of available logical units for the initiator.

For example: If the allocation length is 16 bytes and 2 logical units are available, this command will return the 8-byte header and 1 logical unit descriptor; however, the LUN list length will still be 16 because 16 bytes were available if the allocation length was sufficient.

Address Method

00b = The library is using single level LUN addressing

Bus ID

0h = There is a logical unit at the current level

Single Level LUN Address

The value of the LUN.

Second, Third, and Fourth Level LUN Address

00h = The library only uses single level addressing.

Report Target Port Groups (A3h)

Report Target Port Groups (A3h) returns the Target Port Group data for all ports.

	Bit							
Byte	7	6	5	4	3	2	1	0
0	Operation Code (A3h)							
1	Ignored			Service Action (0Ah)				
2 to 5	Reserved							
6 to 9	Allocation Length							
10	Reserved							
11	Control Byte (00h)							

SLK_112

Service Action
0Ah

Allocation Length
The length of the parameter list the library returns. The library transfers either the number of bytes specified by the Allocation Length field or all of the available Report Target Port Group data, whichever is less. The maximum allocation length is 20h (32d) bytes.

Report Target Port Group Data

	Bit							
Byte	7	6	5	4	3	2	1	0
0 to 3	Returned Data Length ($n - 3$)							
Target Port Group Descriptors								
4 to x	First Target Port Group Descriptor							
$x+1$ to n	Last Target Port Group Descriptor							

SLK_113

Returned Data Length
The number of bytes of Report Target Port Group data available.

Target Port Group Descriptor Data

	Bit							
Byte	7	6	5	4	3	2	1	0
0	PREF	Reserved			Asymmetric Access State			
1	T_Sup	Reserved			U_Sup	S_Sup	AN_Sup	AO_Sup
2 to 3	Target Port Group							
4	Reserved							
5	Status Code							
6	Reserved							
7	Target Port Group Count							
Target Port Descriptors								
8 to 11	First Target Port Descriptor							
<i>n</i> -3 to <i>n</i>	Last Target Port Descriptor							

SLUK_114

PREF

0 = The target port group is not a preferred target port

1 = The target port group is a preferred target port. All ports in the Active/Optimized group are preferred.

Asymmetric Access State

0h = Active/Optimized — the ports in the group are fully operational.

3h = Unavailable — The library does not have the redundant control paths (multi-port) activation file installed.

T_Sup

0 = The library does not support the transitioning asymmetric access state.

U_Sup

0 = The library does not support the unavailable asymmetric access state.

1 = The library supports the unavailable asymmetric access state.

S_Sup

0 = The library does not support the standby asymmetric access state.

AN_Sup

0 = The library does not support the active/non-optimized asymmetric access state.

AO_Sup

0 = The library does not support the active/optimized asymmetric access state.

1 = The library supports the active/optimized asymmetric access state.

Target Port Group

00h = Target Port Group 0

01h = Target Port Group 1

Status Code

2 = The target port group asymmetric access state is altered by implicit asymmetrical logical unit access behavior.

Target Port Group Count

The number of target ports that are in the target port group and the number of target port descriptors in the target port group descriptor. This can range from 1 to 2.

Target Port Descriptor Data

Byte	Bit							
	7	6	5	4	3	2	1	0
0 to 1	Reserved							
2 to 3	Relative Target Port Identifier							

SLK_115

Relative Target Port Identifier
0000h = No Target Port
0001h = Relative Target Port 1
0002h = Relative Target Port 2

Request Sense (03h)

Request Sense (03h) returns sense data. The library generates sense data if the previous command terminated with [Check Condition \(02h\)](#) status. Multiple errors might occur during the processing of a single SCSI command. The sense key reflects the first error that occurred.

If you issue a Request Sense command to an unsupported LUN, the library does not return a check condition. Instead, the library returns sense data with Sense Key set to Illegal Request (05h), ASC set to LUN Not supported (25h), and ASCQ set to 00h.

If the library is partitioned and you issue a Request Sense command from an initiator that has not been configured with access, the library does not return a check condition. Instead, the library returns sense data for LUN Access not Authorized with the Sense Key set to Not Ready (02h), ASC set to 74h and ASCQ set to 71h.

If no sense data is available, the library returns sense data with the Sense Key set to No Sense (0h), ASC set to Not Additional Sense information (00h), and the ASCQ set to 00h.

The library returns [Check Condition \(02h\)](#) status for a Request Sense command only to report errors specific to the command itself — for example, if the library detects a nonzero reserved bit in the CDB. If the library returns a [Check Condition \(02h\)](#) status for a Request Sense command, the sense data might be invalid.

	Bit							
Byte	7	6	5	4	3	2	1	0
0	Operation Code (03h)							
1	Ignored			Reserved				Desc (0b)
2 to 3	Reserved							
4	Allocation Length							
5	Control Byte (00h)							

Desc

0 = The library will return fixed format sense data.

Allocation Length

The number of bytes allocated for returned sense data. The library provides a maximum of 14h (20d) bytes of sense data.

Request Sense Data

	Bit							
Byte	7	6	5	4	3	2	1	0
0	Valid (0)	Error Code (70h)						
1	Segment Number (00h)							
2	Reserved				Sense Key			
3 to 6	Information (00h)							
7	Additional Sense Length (0Ch)							
8 to 11	Command Specific Information (00h)							
12	Additional Sense Code							
13	Additional Sense Code Qualifier							
14	Field Replaceable Unit Code (00h)							
15	SKSV	C/D	Reserved (0)		BPV (0)	Bit Pointer (000b)		
16 to 17	Field Pointer							
18 to 19	Reserved							

SLK_117

Valid

0 = The library does not return data in the Information field.

Error Code

70h = The library returns only current errors.

Segment Number

00h = The library does not support segment numbers.

Sense Key

Describes the error, along with ASC and ASCQ. See [Additional Sense Codes and Qualifiers](#).

0h = No Sense — no specific sense key information to be reported. A sense key of 0 indicates a successful command.

2h = Not Ready — the addressed logical unit is not ready for library motion commands (library is not initialized, device is not ready).

3h = Medium Error — the command terminated with a non-recovered error condition that may have been caused by a flaw in the medium or an error in the recorded data.

4h = Hardware Error — the device detected an unrecoverable hardware failure while performing the command or during a self-test.

5h = Illegal Request — an illegal parameter in the command descriptor block or in the parameter list data.

6h = Unit Attention — a power-on or reset has occurred to the device, or a not ready-to-ready transition has occurred, or an I/O element has been accessed. Also, this may indicate mode parameters have changed, or the microcode has been changed.

Bh = Aborted Command — the device aborted the command. The initiator might be able to recover by trying the command again.

Information

00h = The library does not support this field.

Additional Sense Length

0Ch = Indicates there are 12d bytes of additional sense bytes to follow. This value is not truncated to reflect the actual transfer length.

Command Specific Information

00h = The library does not support this field.

Additional Sense Code (ASC)

Describes the error. See [Additional Sense Codes and Qualifiers](#).

Additional Sense Code Qualifier (ASCQ)

Describes the error. See [Additional Sense Codes and Qualifiers](#).

Field Replaceable Unit Code

00h = The library does not support this field.

SKSV (Sense Key Specific Valid)

1 = The C/D and field pointer are valid

0 = Ignore the C/D and field pointer

C/D (Command/Data)

0 = The check condition status resulted from illegal parameter in the parameter list.

1 = The check condition status resulted from illegal parameter in the CDB.

BPV (Bit Pointer Valid)

0 = The library does not support this field.

1 = Bit pointer field specifies which bit of the byte designated by the Field Pointer field is in error.

Bit Pointer

When the Bit Pointer Valid field is set to 1, this value indicates which bit of the byte designated by the Field Pointer field is in error.

Field Pointer

The number of the byte where the error occurred. When a multiple-byte field is in error, the Field Pointer contains the value of the most significant byte of the field, which is lowest byte number. Byte numbers start at 00.

Additional Sense Codes and Qualifiers

- [Not Ready Sense Key \(2h\) Codes](#)
- [Medium Error \(3h\) Codes](#)
- [Hardware Error Sense Key \(4h\) Codes](#)
- [Illegal Request Sense Key \(5h\) Codes](#)
- [Unit Attention Sense Key \(06h\) Codes](#)
- [Aborted Command Sense Key \(0Bh\) Codes](#)

Not Ready Sense Key (2h) Codes

The library generates a Not Ready error code if you send a command when the library is in a not ready state.

Description	Sense Key	ASC	ASCQ
Not Ready, Cause Not Reportable	2h	04h	00h
Not Ready, In Process of Becoming Ready	2h	04h	01h
Not Ready, Manual Intervention Required	2h	04h	03h
Not Ready, Logical Unit Not Ready, Operation in progress	2h	04h	07h
Not Ready, Logical Unit Offline	2h	04	12h
Not Ready, Maintenance Mode	2h	04h	81h
Not Ready, Cleaning Cartridge Installed	2h	30h	03h
Not Ready, Mailslot Open	2h	3Ah	02h

Not Ready, Cause Not Reportable

The library detected a not ready state after execution of the command was started.

Not Ready, In Process of Becoming Ready

The library is initializing and performing an audit. Initialization occurs at:

- Power-on
- After the door opens and closes
- When requested from the operator panel or GUI
- As part of a recovery during certain failures

Not Ready, Manual Intervention Required

The library is in an inoperable state. The operator should check the user interface to determine what action is required.

Not Ready, Logical Unit Not Ready, Operation in Progress

The library is busy processing another command.

Not Ready, Logical Unit Offline

The library is offline and cannot process the command.

Not Ready, Maintenance Mode

The library was placed in maintenance mode from the operator panel or user interface.

Not Ready, Cleaning Cartridge Installed

The library is performing an Auto Clean function on the tape drive requested.

Not Ready, MailSlot Open

The library detected that the mailslot is open and a SCSI command was issued to access the mailslot.

Medium Error (3h) Codes

The library generates a Medium Error when a SCSI move command terminates with a non-recovered error condition, which may have been caused by a flaw in the medium or an error in the recorded data.

Description	Sense Key	ASC	ASCQ
Medium Error, Cleaning Cartridge Expired	3h	30h	13h

Medium Error, Cleaning Cartridge Expired

The source cartridge for a SCSI move to a drive is an expired cleaning cartridge.

Hardware Error Sense Key (4h) Codes

The library generates a Hardware Error if it detects a hardware or firmware error during command execution.

Description	Sense Key	ASC	ASCQ
Hardware Error, General	4h	40h	01h
Hardware Error, Tape Drive	4h	40h	02h
Hardware Error, Cartridge Access Port	4h	40h	03h
Hardware Error, Embedded Software	4h	44h	00h
Hardware Error, Media Load/Eject Failed	4h	53h	00h

Hardware Error, General

The library detected an internal electronics error during a command. This includes the electronics, vision system, and robotics of the library.

Hardware Error, Tape Drive

An operation to the drive failed. The problem could be the tape drive or the interface between the library and tape drive.

Hardware Error, CAP

The CAP failed.

Hardware Error, Embedded Software

The embedded software that controls the SCSI interface detected an unexpected condition. This error is used for arbitrary limitations of the embedded software.

Hardware Error, Media Load/Eject Failed

A cartridge mount or dismount failed to complete.

Illegal Request Sense Key (5h) Codes

Any illegal parameters in the CDB or parameter list for a particular command generates an Illegal Request sense key.

In some cases, additional information is available in Byte 15 of the sense data, which includes the sense-key-specific-value (SKSV) and command/data (C/D) fields. This information indicates the byte in the command descriptor block or the parameter list that is in error. If available, the SKSV bit in the sense data is set to 1.

Description	Sense Key	ASC	ASCQ	SKSV
Invalid Field in Command Info Unit	5h	0Eh	03h	No
Parameter Length Error	5h	1Ah	00h	Yes
Invalid Command	5h	20h	00h	Yes
Invalid Element	5h	21h	01h	No
Invalid Field in CDB	5h	24h	00h	Yes
Logical Unit Not Supported	5h	25h	00h	No
Invalid Field in Parameters	5h	26h	00h	Yes
Invalid Release of Persistent Reservation	5h	26h	04h	No
Incompatible Medium	5h	30h	00h	No
Saving Parameters Not Supported	5h	39h	00h	Yes
Medium Not Present, Drive Not Unloaded	5h	3Ah	00h	No
Destination Element Full	5h	3Bh	0Dh	No
Source Element Empty	5h	3Bh	0Eh	No
Magazine Removed	5h	3Bh	12h	No
Empty Tape Drive Slot	5h	3Bh	1Ah	No
Insufficient Resources	5h	55h	03h	No

Unit Attention Sense Key (06h) Codes

The library generates a Unit Attention sense key for all initiators if the library needs to inform the host of an asynchronous event.

Description	Sense Key	ASC	ASCQ
Not Ready-to-Ready Transition	06h	28h	00h
Mailslot Element Accessed	06h	28h	01h
Power On, Reset, or Bus Device Reset Occurred	06h	29h	00h
Power on Occured	6h	29h	01h
Target Reset	06h	29h	02h
LUN Reset	06h	29h	03h
Device Internal Reset	06h	29h	04h
Mode Parameters Changed	06h	2Ah	01h
Reservations Preempted	06h	2Ah	03h
Reservations Released	06h	2Ah	04h
Registrations Preempted	06h	2Ah	05h
Data Transfer Device Removed	06h	3Bh	1Ah
Data Transfer Device Inserted	06h	3Bh	1Bh

Not Ready to Ready Transition

The library transitioned to a Ready state from a Not Ready state. The library sends this unit attention to all initiators.

Mailslot Element Accessed

The operator opened and closed the mailslot. The library sends this unit attention to all initiators. You can issue a Read Element Status command to obtain an updated inventory (see "[Read Element Status \(B8h\)](#)" on page 3-79).

Power On, Reset, or Bus Device Reset Occurred

The IBM Bridged Tape Drive generates this type of Unit Attention when the library is powered on, restarted from the user interface, reset over the interface, or when the bridged tape drive is reset. A Unit Attention is generated for all initiators.

Power On

The HP Bridged Tape Drive generates this type of Unit Attention when the library is powered on, restarted from the user interface, reset over the interface, or when the bridged tape drive is reset. A Unit Attention is generated for all initiators.

LUN Reset

The library is clear of all I/O processes following the LUN reset. The library sends this unit attention to all initiators.

Target Reset

The library is clear of all I/O processes following the Target reset. The library sends this unit attention to all initiators.

Device Internal Reset

The library is clear of all I/O processes following the an internal device reset. The library sends this unit attention to all initiators.

Mode Parameters Changed

The library generates this type of Unit Attention when a different initiator performs a Mode Select operation. Issuing a Mode Sense command can retrieve the current parameters. This Unit Attention is issued for all initiators except the one that performed the Mode Select.

Persistent Reservations/Registrations Preempted or Released

The library generates these types of Unit Attention sense keys when one initiator has its persistent reservations or registrations cleared by another initiator.

Data Transfer Device Removed

The operator physically removed a drive. If partitioned, the library only sends this unit attention to hosts associated with the affected partition.

Data Transfer Device Inserted

The operator physically inserted a drive. If partitioned, the library only sends this unit attention to the hosts associated with the affected partition.

Aborted Command Sense Key (0Bh) Codes

The library generates an Aborted Command error code when a SCSI command is aborted.

Description	Sense Key	ASC	ASCQ
Logical Unit Communication Failure	0Bh	08h	00h

Description	Sense Key	ASC	ASCQ
Logical Unit Communication Timeout	0Bh	08h	01h
Mechanical Positioning Error	0Bh	15h	01h
I_T Nexus Loss	0Bh	29h	07h
Command Phase Error	0Bh	4Ah	00h
Data Phase Error	0Bh	4Bh	00h
Command Overlap	0Bh	4Eh	00h

Logical Unit Communication Failure

The drive returns this status when there is a logical unit communication failure that prevents the library from processing the command.

Logical Unit Communication Timeout

This error is only returned on an IBM Bridged Tape Drive. The IBM bridged tape drive returns this status when the library requires more than 12 minutes to complete a command.

Mechanical Positioning Error

The library detected an error while trying to position and the operation could not be completed.

I_T Nexus Loss

The IBM Bridged Tape Drive detected an I_T Nexus Loss that prevented the library from completing the command.

Command Phase Error

The library detected a command phase error and the operation could not be completed.

Data Phase Error

The library detected a data phase error and the operation could not be completed.

Command Overlap

The library detected another command from an initiator while one was already in process

Request Volume Element Address (B5h)

Request Volume Element Address (B5h) returns the results of a previous Send Volume Tag command.

The returned data consists of an eight-byte [Volume Element Address Header](#), followed by to four element pages (one page per element type). Each element page consists of an eight-byte [Element Status Page Header](#), followed by the element type descriptor. Supported element type descriptors include:

- [Medium Transport Element Descriptor](#)
- [Storage Element Descriptor](#)
- [Import/Export Element Descriptor](#)
- [Data Transfer Element Descriptor \(DvcID = 0\)](#)
- [Data Transfer Element Descriptor \(DvcID = 1\)](#)

	Bit							
Byte	7	6	5	4	3	2	1	0
0	Operation Code (B5h)							
1	Ignored			VolTag	Reserved			
2 to 3	Starting Element Address							
4 to 5	Number of Elements							
6	Reserved							
7 to 9	Allocation Length							
10	Reserved							
11	Control Byte							

VolTag

0 = The library will not report Volume Tag information in the Element Descriptor data.

1 = The library will report Volume Tag information in the Element Descriptor data.

Starting Element Address

Specifies the minimum element address. The library reports elements with an element address greater than or equal to the Starting Element Address.

Number of Elements

The maximum number of element descriptors to transfer. This is not an element address range.

Allocation Length

The length in bytes of the space allocated by the initiator for the transfer of element descriptors. Only complete element descriptors are transferred. Data can be truncated based on the length specified in the allocation field.

Volume Element Address Header

	Bit							
Byte	7	6	5	4	3	2	1	0
0 to 1	First Element Address Reported							
2 to 3	Number of Elements Available							
4	Reserved			Send Action Code (5h)				
5 to 7	Byte Count of Report Available (all pages, $n - 7$)							
8 to n	Element Status Pages							

SLK_119

First Element Address Reported

The lowest element address found for the specified Element Type Code that is greater than or equal to the Starting Element Address.

Number of Elements Available

The number of elements found for the specified Element Type Codes that is greater than or equal to the Starting Element Address. This number is always less than or equal the Number of Elements.

Send Action Code

5h = The action code from the previous Send Volume Tag command.

Byte Count of Report Available

The number of bytes of element status data available. This count does not include the Element Status Data header bytes. The count is not adjusted to match the allocation length you specified in the Read Element Status command.

Element Status Pages

These pages are in the same format as the [Read Element Status \(B8h\)](#) command pages. See "[Element Status Page Header](#)" on page 3-82 and "[Element Descriptors](#)" on page 3-83.

Reserve 6-byte (16h) and Reserve 10-byte (56h)

Reserve allows the initiator to reserve the entire library or partition. Another capability of the Reserve (10) command as opposed to the Reserve (6) command is the ability to do third party reservations. The third party reservation allows the reservation of a logical unit within a logical unit on behalf of another SCSI device.

New host applications should not use 3rd party reservations. These are legacy SPC-2 commands. Persistent Reservations should instead be implemented.

Figure 3–23 Reserve 6-Byte

	Bit							
Byte	7	6	5	4	3	2	1	0
0	Operation Code (16h)							
1	Ignored			Reserved (0h)				
2 to 4	Reserved (00h)							
5	Control Byte (00h)							

SLK_120

Figure 3–24 Reserve 10-Byte

	Bit							
Byte	7	6	5	4	3	2	1	0
0	Operation Code (56h)							
1	Ignored			3rdpty	Reserved		LongID	Obsolete
2	Reserved							
3	Third Party Device ID							
4 to 6	Reserved							
7 to 8	Parameter List Length							
9	Control Byte							

L207_294

3rdpty

This field indicates whether the reservation is on behalf of a third party or not.

0 = The reservation is on behalf of the calling requester.

1 = The reservation is on behalf of a specified Third party Device Id.

Long ID

The library ignores this field.

Third Party Device ID

ID of the third party device.

Parameter List Length

The library ignores this field.

Send Diagnostic (1Dh)

Send Diagnostic (1Dh) requests a self-diagnostic test. The library accepts this command for compatibility, but performs no action.

Byte	Bit							
	7	6	5	4	3	2	1	0
0	Operation Code (1Dh)							
1	Ignored			PF (1)	Reserved	SelfTest (1)	DevOfI (0)	UnitOfI (0)
2	Reserved							
3 to 4	Parameter List Length							
5	Control Byte (00h)							

SLK_121

PF

1 = Page format specified by SCSI-3.

0 = used for self test

SelfTest

1 = The library will run the default self test.

DevOfI (not supported)

Set this to 0.

UnitOfI (not supported)

Set this to 0.

Parameter List Length

0h = For the default self test.

8h = For extended diagnostics (not supported).

Send Volume Tag (B6h)

Send Volume Tag (B6h) requests a VOLSER label template. The library uses the template to search for cartridges. You can send a subsequent [Request Volume Element Address \(B5h\)](#) command to transfer the results of this search.

	Bit							
Byte	7	6	5	4	3	2	1	0
0	Operation Code (B6h)							
1	Ignored			Reserved	Element Type Code			
2 to 3	Starting Element Address							
4	Reserved							
5	Reserved			Send Action Code (5h)				
6 to 7	Reserved							
8 to 9	Parameter List Length							
10	Reserved							
11	Control Byte (00h)							

Element Type Code

0h = All Element Types

1h = Medium Transport Element (robot hand)

2h = Storage Element (cartridge cells)

3h = Import/Export Element (CAP cells)

4h = Data Transfer Element (drive)

Starting Element Address

Specifies the minimum element address. The library reports elements with an element address greater than or equal to the Starting Element Address.

Send Action Code

5h = The library supports the translate and search primary volume tag function.

Parameter List Length

00h = No data. The library does not consider this an error.

28h = A volume identification template

Send Volume Tag Parameter List

Byte	Bit							
	7	6	5	4	3	2	1	0
0 to 31	Volume Identification Template							
32 to 33	Reserved							
34 to 35	Minimum Volume Sequence Number							
36 to 37	Reserved							
38 to 39	Maximum Volume Sequence Number							

SLK_123

Volume Identification Template

This ASCII field specifies a volume identification search template. The first 00 hexadecimal terminates the volume identification search template. The remaining characters are set to 0.

Allowed characters are A through Z, digits 0 through 9, and special characters that include the dollar sign (\$), the pound character (#), and the ASCII space character. The wild-card characters "*" and "?" (2Ah and 3Fh) also may be used.

Minimum Volume Sequence Number (not supported)

Ignore this field.

Maximum Volume Sequence Number (not supported)

Ignore this field.

Test Unit Ready (00h)

Test Unit Ready (00h) allows the initiator to determine if the library is powered on and ready to accept additional commands. This is not a request for a library self-test.

The Test Unit Ready command returns a [Good \(00h\)](#) status if the library is ready to accept additional commands or returns a [Check Condition \(02h\)](#) if the library is not ready or if there are pending Unit Attentions.

	Bit							
Byte	7	6	5	4	3	2	1	0
0	Operation Code (00h)							
1	Ignored			Reserved				
2 to 4	Reserved							
5	Control Byte (00h)							

SLK_124

